

**NUMERICAL PARTS
INTERCHANGEABILITY RECORD**

**HUDSON
BUILT CARS
ALL MODELS**

PUBLISHED—MARCH 1, 1950



**HUDSON MOTOR CAR COMPANY
DETROIT 14, MICHIGAN
U. S. A.**



NUMERICAL PARTS
INTERCHANGEABILITY
RECORD

HUDSON
BUILT
CARS
All Models

Published March 1, 1950

HUDSON MOTOR CAR COMPANY
DETROIT 14, MICHIGAN
U. S. A.

FOREWORD

This 1950 edition of the Numerical Parts Interchangeability Record is the latest published numerical record of replacement parts for Hudson built cars of current and earlier models. It has been brought up to date by adding parts and model information for the years 1947, 1948, 1949 and 1950 to date of publication, and by removing many old numbers which are obsolete and no longer supplied.

In form and arrangement this book is similar to the book previously known as the Numerical Price List with which Hudson parts men are familiar. Part numbers are arranged in numerical order, and each part is identified by part number, description and models on which it is used.

The price column formerly carried in previous issues has been deleted. Prices will be continued in the Parts Price List Supplements.

Space limitation necessitates the use of abbreviations wherever possible. On a succeeding page will be found a list of easily understood abbreviations, arranged in alphabetical order, which are used throughout the book. To assist in identifying cars, a list of chassis models is shown on the following page, in which the cars are designated by name, model, wheelbase and starting serial number.

This book has been carefully checked for accuracy. Should you discover a error of any nature, please bring it to our attention so that it may be corrected promptly.

TELEGRAPH CODE

The following TELEGRAPH CODE PHRASES are offered for the convenience of Zones and other Distributors in ordering parts and transacting business with the Factory Parts Department.

WUPTA	-Ship to use by Air Express	WUTAE	-Ship C.O.D. by Air Express to-
WUPRY	-Ship to us by Air Mail	WUTIM	-Ship C.O.D. by Air Mail to-
WUPAF	-Ship to us by Air Freight	WUTAN	-Ship C.O.D. by Air Freight to-
WUPMU	-Ship to us by Parcel Post	WUTKO	-Ship C.O.D. by Parcel Post to-
WUPOW	-Ship to us by Parcel Post Special Delivery	WUTOT	-Ship C.O.D. by Parcel Post Special Delivery to-
WUPAH	-Ship to us by Express	WUTPU	-Ship C.O.D. by Express to-
WUPIP	-Ship to us by Freight	WUTWA	-Ship C.O.D. by Freight to-
WUPHO	-Ship to us by Motor Truck	WUTYC	-Ship C.O.D. by Motor Truck to-
WUSAF	-Charge our account and ship by Air Express to-	WUUBE	-We will call and pick up parts
WUSDI	-Charge our account and ship by Air Mail to-	WURCI	-When and how (will or did) you ship parts called for in our telegram of-
WUSMA	-Charge our account and ship by Air Freight to-	WUROV	-When and how (will or did) you ship parts called for in our letter of-
WUSEJ	-Charge our account and ship by Parcel Post to-	WURNU	-When and how (will or did) you ship parts called for in our order of (or number)
WUSIN	-Charge our account and ship by Parcel Post Special Delivery to-	WUUF1	-Ship to us by prepaid freight order number-
WUSJO	-Charge our account and ship by Express to-		
WUSTY	-Charge our account and ship by Freight to-		
WUSVA	-Charge our account and ship by motor Truck to-		

When writing telegrams to the factory concerning parts shipments, you can save expense by combining the proper code word with the date or number of your previous telegram, letter or order.

Example: When and how did you ship parts called for in our letter of December 18th?
WUROV DECEMBER EIGHTEEN

In ordering parts by telegraph, spell out quantities of each part desired. Use numerals for the part numbers .

Example: Ship to us by motor truck three 44687 and one 150213.
WUPHO THREE 44687 ONE 150213

Address telegrams concerning parts to

Parts Department, Hudson Motor Car Company,
Detroit 14, Michigan

MODEL IDENTIFICATION

MODEL	NAME	STARTING SERIAL. NO	WHEEL BASE	NO. CYL.	MODEL	NAME	STARTING SERIAL NO.	WHEEL BASE	NO. CYL.
	1927				81	Hudson Terraplane DeLuxe	81,119	117	6
O	Hudson	750,000	127	6	82	Hudson Super Terraplane	82,153	117	6
S	Hudson	1,001	118	6	83	Hudson Six	83,131	122	6
	Essex	500,000	110	6	84	Hudson Eight DeLuxe	84,101	122	8
	1928				85	Hudson Eight Custom	85,160	122	8
O	Hudson	803,569	127	6	87	Hudson Country Club Sedan	87,161	129	8
S	Hudson	12,270	118	6	88	Hudson Terraplane			
	Essex	706,271	110	6		Business Cars	88,174	124	6
	1929				89	Hudson 112	8,928,566	112	6
R	Hudson	825,407	122	6		1939			
L	Hudson	41,384	139	6	90	Hudson 112	90,101	112	6
	Essex Challenger	1,165,674	113	6	90	Hudson Business Cars	90,101	112	6
	1930				91	Hudson Pacemaker	9,132,576	118	6
T	Hudson	893,402	119	8	92	Hudson Six	92,107	118	6
U	Hudson	46,599	126	8	93	Hudson Country Club Six	93,104	122	8
	Essex Challenger	1,165,674	113	6	95	Hudson Country Club Eight	95,106	122	8
	1931				97	Hudson Custom Country			
T	Hudson	914,293	119	8		Club Sedan	97,105	129	8
U	Hudson	57,115	126	8	98	Hudson Business Cars	982,995	119	6
E	Essex Super Six	1,234,267	113	6		1940			
EF	Essex Family Sedan	200,001	113	6	40T	Hudson Six-Traveler Series	40,101	113	6
	1932				40P	Hudson Six DeLuxe	40,101	113	6
T	Hudson-Standard	930,770	119	8	40C	Hudson Six-Business Cars	40,101	113	6
U	Hudson-Sterling	62,884	126	8	41	Hudson Super Six	41,250	118	6
L	Hudson-Major	250,001	132	8	43	Hudson Country Club Six	43,370	125	6
E	Essex Pacemaker	1,281,685	113	6	44	Hudson Eight	44,294	118	8
EC	Essex-Standard	1,297,748	113	6	47	Hudson Country Club Eight	47,167	125	8
K	Terraplane	350,000	106	6	48P	Hudson Big Boy Sedan	48,101	125	6
	1933				48C	Hudson Big Boy Business Cars.	48,101	125	6
E	Hudson Super Six	1,300,501	113	6		1941			
T	Hudson-Standard	936,703	119	8	10T	Hudson Six-Traveler Series	10,101	116	6
L	Hudson-Major	251,117	132	8	10P	Hudson Six DeLuxe	10,101	116	6
K	Terraplane	364,125	106	6	10C	Hudson Six Business Cars	10,101	116	6
KU	Terraplane	5,001	113	6	11	Hudson Super Six	11,201	121	6
KT	Terraplane	65,001	113	8	12	Hudson Commodore Six	12,202	121	6
	Terraplane Comm.	364,125	106	6	14	Hudson Commodore Eight	14,203	121	8
	1934				15	Hudson Commodore Custom			
LT	Hudson	950,000	116	8		Eight Coupe	1,515,490	121	8
LL	Hudson	252,000	123	8	17	Hudson Commodore Custom			
LTS	Hudson Challenger	964,244	116	8		Eight Sedan	17,205	128	8
K	Terraplane	373,000	112	6	18P	Hudson Big Boy Series	1,812,548	128	6
KU	Terraplane	21,500	116	6	18C	Hudson Big Boy Business Cars	1,812,548	128	6
KS	Terraplane Chall'ger	396,727	112	6		1942			
T	Terraplane Comm.	373,000	112	6	20T	Hudson Six	20,101	116	6
	1935				20P	Hudson Six DeLuxe	20,101	116	6
GH	Hudson Six	53,101	116	6	20C	Hudson Six Business Cars	20,101	116	6
HT	Hudson Special Eight	54,101	117	8	21	Hudson Super Six	211,324	121	6
HU	Hudson DeLuxe Eight	55,101	117	8	22	Hudson Commodore Six	221,322	121	6
HHU	Hudson Custom Eight	56,101	124	8	24	Hudson Commodore Eight	241,318	121	8
G	Terraplane Special	51,101	112	6	25	Hudson Commodore Custom			
GU	Terraplane DeLuxe	52,101	112	6		Eight Coupe	255,755	121	8
	Terraplane Comm.	51,101	112	6	27	Hudson Commodore Custom			
	1936					Eight Sedan	271,319	128	8
61	Terraplane DeLuxe	61,101	115	6	28	Hudson Big Boy Business Cars	28,101	128	6
62	Terraplane Custom	62,101	115	6		1946			
63	Hudson Six	63,101	120	6	51	Hudson Super Six	31,101	121	6
64	Hudson DeLuxe	64,101	120	8	52	Hudson Commodore Six	32,101	121	6
65	Hudson Custom	65,101	120	8	53	Hudson Super Eight	33,101	121	8
66	Hudson DeLuxe	66,101	127	8	54	Hudson Commodore Eight	34,101	121	8
67	Hudson Custom	67,101	127	8	58	Hudson Commercial Cars	38,101	128	6
	Terraplane Comm.	61,101	115	6		1947			
	1937				171	Hudson Super Six	171-101	121	6
71	Terraplane DeLuxe	71,101	117	6	172	Hudson Commodore Six	172-101	121	6
72	Super Terraplane	72,101	117	6	173	Hudson Super Eight	173-101	121	8
73	Hudson Six	73,101	122	6	174	Hudson Commodore Eight	174-101	121	8
74	Hudson DeLuxe	74,101	122	8	178	Hudson Commercial Cars	178-101	128	6
75	Hudson Custom	75,101	122	8		1948			
76	Hudson DeLuxe	76,101	129	8	481	Hudson Super Six	481-101	124	6
77	Hudson Custom	77,101	129	8	482	Hudson Commodore Six	482-101	124	6
70	Terraplane Comm.	70,101	117	6	483	Hudson Super Eight	483-101	124	8
78	Terraplane Comm.	78,101	124	6	484	Hudson Commodore Eight	484-101	124	8
	1938					1949			
80	Hudson Terraplane				491	Hudson Super Six	491-101	124	6
	Business Cars	80,150	117	6	492	Hudson Commodore Six	492-101	124	6

MODEL IDENTIFICATION (Cont'd)

MODEL	NAME	STARTING SERIAL NO	WHEEL BASE	NO. CYL.	MODEL	NAME	STARTING SERIAL NO.	WHEEL BASE	NO. CYL.
493	Hudson Super Eight	493-101	124	8	501	Hudson Super Eight	501-101	124	6
494	Hudson Commodore Eight 1950	494-101	124	8	502	Hudson Commodore Eight	502-101	124	6
500	Hudson Pacemaker Six	500-101	119	6	503	Hudson Super Eight	503-101	124	8
					504	Hudson Commodore Eight	504-101	124	8

PARTS SYMBOLS start with a definite number for each year. Starting part numbers for years from 1930 to 1950.

	1930		33,000		1938		155,200
Chassis-Hudson				Chassis			
Chassis-Essex	65,000		65,000	Body and Trim			125,000
Body			85,000				
Trim			86,000		1939		
				Chassis			157,500
	1931		35,000	Body and Trim			133,000
Chassis			89,000				
Body			90,200		1940		
Trim				Chassis			159,500
	1932		37,000	Body and Trim			140,000
Chassis-Hudson-and Essex			40,000	Standard Parts			170,000
Chassis-Terraplane			94,000				
Body			92,700	Chassis	1941		161,900
Trim				Body and Trim			146,000 to 150,000
	1933		42,000	Standard Parts			2 000,000 upward
Chassis			101,400				170,480
Body			106,000		1942		
Trim				Chassis			164,000
	1934		44,500	Body and Trim			203,000
Chassis			107,000	Standard Parts			170,650
Body			110,000				
Trim					1946-1947		
	1935		47,000	Chassis			165,600
Chassis			112,000	Body and Trim			208,600
Body			113,400	Standard Parts			170,872
Trim							
	1936		150,000	Chassis	1948-1949		300,000
Chassis			116,000	Body and Trim			210,000
Body and Trim							
	1937		152,500	Chassis	1950		303,000
Chassis			120,000	Body and Trim			220,000
Body and Trim							

Accelerator	Acc	Inspection	Insp
Adjusting	Adj	Instrument	Inst
All Purpose Delivery	Del	Intake	Int
Ammeter	Amm	Intermediate	Inter
Assembly	Assy	Junction	June
Auxiliary	Aux	Lacquer	Lac
Battery	Batt	Lever	Lev
Bearing	Brg	Light	Lt
Bellcrank	B/C	License	Lic
Black	Blk	Lock	Lk
Bracket	Brkt	Locker	Lkr
Brake	Bke	Lower	Low
Brougham	Bro	Mainshaft	M/S
Bumper	Bmpr	Manifold	Man
Bushing	Bush	Motor	Mtr
Business Coupe-Model 71	71B	Molding	Mldg
Business Coupe-Model 73	73B	Mounting	Mtg
Button	Btn	Operating	Oper
Cab Pickup	CabPu	Optional	Opt
Carburetor	Carb	Ornament	Orn
Carrier	Carr	Overdrive	OD
Carryall	CA	Panel Delivery	Panel
Center	Cen	Passenger	Pass
Channel	Chan	Pedal	Ped
Clutch	Cl	Phaeton	Ph
Coach	Co	Pillar	Pile
Commercial	Comm	Plate	Pl
Compartment	Compt	Pocket	Pkt
Complete	Comp	Pressure	Pres
Connecting or Connector	Conn	Prime	Pr
Control	Cont	Propeller	Prop
Convertible	Cv	Quarter	Qtr
Convertible Two Door Sedan	CvSed	Radiator	Had
Countershaft	Cntrsha	Rear	Rr
Countersunk	Ctsk	Rear Axle	R/A
Coupe	Cpe	Regulator	Reg
Crankshaft	C/S	Reinforcement	Reinf
Cover	Coy	Retainer	Ret
Cross Shaft	C/Shaft	Reverse	Rev
Cushion	Cush	Roadster	Ro
Cylinder	Cyl	Round	Rnd
Delivery	Del	Running Board	Run Bd
DeLuxe	DeL	Sedan	Sed
Differential	Diff	Seven Passenger Sedan	7Sed
Direction Indicator	DI	Shakeproof	Shkeprf
Distributor	Dist	Shock Absorber	Shk Abs
Domestic	Dom	Special	Spec
Dover	Dov	Speedometer	Spdo
Drilled	Drld	Splash	Spl
Eccentric	Ecc	Spring	Sp
Electric	Elec	Standard	Std
Electrolock	E/ Lock	Station Wagon	Station
Enamel	En	Super-Matic Drive	SMD
Engine	Eng	Support	Supp
Engine (3' . bore x 5" stroke)	L ENG	Suburban	Sub'n
Engine (3" bore x 4 1/8" stroke)	Std Eng	Switch	Sw
Essex	Esx	Tail Lamp	T/L
Except	Exc	Terminal	Term
Exhaust	Exh	Terraplane	Terr
Export	Exp	Three Passenger Coupe	3Cpe
Extension	Ext	Throttle	Throt
Fender	Fdr	Touring	Tr
Finish	Fin	Transmission	Trans
Five Passenger Sedan	5Sed	Tubular	Tblr
Four Passenger Coupe	4Cpe	Two Door Sedan	2Sed
Free Wheeling	F/ W	Universal Joint	U/J
Front	F	Upper	Up
Front Axle	F/A	Utility Coach	IX°
Gasoline	Gas	Utility Coupe	UCpe
Gauge	Ga	Vacuum	Vac
Gear	Gr	Vacumotive Drive	VD
Generator	Gen	Vibrator	Vib
Guard	Grd	Victoria	Vic
Handle	Hdl	Victoria Coupe	VicCpe
Headlamp	H/ Lamp	Washer	Wash
High Compression	H C	Water Pump	W/ Pump
Housing	Hsg	Weatherstrip	W/Strip
Hudson	Hud	Wheel	Whl
Hudson Drive-Master	HDM	Windlace	W/ Lace
Hydraulic	Hyd	Window	Wdo
Ignition	Ign	Windshield	W/Shield
Indicator	Ind		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
	54 Cotter Pin-1/8 x 1-1/4	BT 1308	Bolt-Hex Head-3/8"-16 x 1-1/8"
BZ 56	Cotter Pin-3/32" x 3/4"	BZ 1349	Plain Washer-7/32" x 1/2" x 1/16"
BT 57	Ball-Steel-5/8"	BM 1374	Bolt-Hex Head-5/16"-18 x 1-5/8"
ET 58	Ball-Steel-1/2"	BZ 1385	Bolt-Hex Head-7/16"-14 x 1-1/2"
BO 60	Lockwasher-1/2"	BZ 1430	Bolt-Hex Head-5/16"-18 x 1-5/8"
62	Use 12415	BX 1491	Plug-Socket Pipe-3/4"
BZ 63	Cap Screw-Hex Head-3/8"-24 x 3/4"	BZ 1549	Lockwasher-1/4"-Cadmium
71	Use 70414	1586	Use 170019
BZ 72	Nut-Castle-1/2"-20	BT 1634	Screw-Round Head Machine-No. 6-32 x 3/8"
BO 73	Lockwasher-3/8"	BO 1636	Screw-Flat Head Machine-No. 8-32 x 1/2"
80	Rivet-3/8" x 1-1/8" (Use 170857)	1870	Use 70435
BX 82	Rivet-Button Head 3/8" x 7/8"	BM 2335	Screw-1/4"-20 x 1/2"
85	Rivet-3/8" x 1"	2344	Use 71237
BO 90	Lockwasher-Heavy-#10	BZ 2346	Plug-Pipe-Extension Head-3/8"
BM 101	Ball-Steel-3/8"	BM 2350	Screw-10-32 x 7/16"
BX 103	Ball-Steel-1/4"	BO 2352	Bolt-Hex Head-5/16"-24 x 1"
BZ 104	Lockwasher-7/16"	BZ 2354	Taper Pin-No. 5 x 1-3/8"
BO 105	Lockwasher-1/4"	BM 2397	Strap-Exhaust Pipe & Heater Hose
108	Use 71590	BO 2404	Bolt-Hex Head-3/8"-16 x 1-5/8"
BM 110	Nut-3/8"-16 x 3/8"	BZ 2439	Bolt-Hex Head-3/8"-24 x 1-1/2"
BM 113	Bolt-1/2"-13 x 2-1/4"	BZ 2490	Bolt-Hex Head-5/16"-18 x 1-1/8"
BZ 115	Key-Woodruff-No. 9	BX 2655	Gasket-Rear Axle Housing
119	Use 71607	BZ MS3009	Cable-High Tension-7 M M
BM 120	Plug-1/8"	BZ MS3010	Cable-No. 12-Braid Covered-Yellow
BO 121	Bolt-Hex Head-5/16"-18 x 1-3/4"	BZ MS3011	Cable-No. 14-Braid Covered-Yellow
BZ 122	Nut-5/16"-18 x 5/16"	BZ MS3012	Cable-No. 16-Braid Covered-Black
BZ 124	Nut-Castle-3/8"-24 x 13/32"	BZ MS3013	Cable-Double-Armored-2 No. 14
145	Use 71037	BZ MS3017	Cable-Triple Armored
BT 218	Bolt-Hex Head-7/16"-14 x 1-1/8"	BZ MS3018	Cable-No. 10 Braid Covered-Yellow
BM 219	Cap Screw-5/16"-18 x 3/4"	BZ MS3023	Cable-Double Braid-Black-White
BM 227	Stud-3/8"-16 x 1-1/2"	BZ MS3024	Cable-Triple Braid-2 #12, 1 #16
BX 231	Plug-1/4"	BZ 3031	Braid Cable-No. 16
BM 232	Nut-Hex-7/16"-20 x 3/8"	BZ 3037	Taper Pin-No. 2 x 1"
BO 262	Plain Washer 17/64" x 9/16" x 1/16"	BZ MS3043	Cable-Triple-2 #14, 1 #16
BM 271	Bolt-Hex Head-1/4"-20 x 1-1/4"	BZ MS3044	Cable-Double-2 #16-Braid Covered
272	Use 70874	BZ 3118	Pin-Clevis-3/8" x 1-1/8"
BT 273	Bolt-Hex Head-3/8"-16 x 2-1/4"	BX 3197	Rivet-Button Head-5/16" x 7/8"
304	Use 71081	BX 3205	Pin-Clevis-7/16" x 2-3/16"
BM 306	Ball-Steel-9/16"	BZ 3210	Pin-Clevis-3/8 x 1-7/32"
322	Use 1491	BX 3433	Nut-Hex-1/2"-20 x 7/16"
BZ 326	Rivet-5/16" x 3/4"	BT 3488	Nut-Castle-7/16"-20 x 29/64"
345	Washer-Plain-25/64 x 7/8 x 1/16"	BM 3506	Bolt-Hex Head-1/4"-20 x 1-1/4"
BT 395	Bolt-Hex Head-5/16"-18 x 5/8"	BM 3554	Street Ell-1/8" Special
398	Nut-5/8"-18 x 35/64" (Use 171427)	BM 3637	Pin-Dowel 1-1/8" x 5/8"
F 401	Bearing-Annular (New Departure No. 1205)	BO 3788	Bolt-Hex Head-7/16"-20 x 1-1/4"
BZ 405	Nut-Hex-5/8"-18 x 5/16"	BX 3820	Bolt-Hex Head-5/16"-18 x 1/2"
414	Use 71671	3925	Use 219
BX 545	Rivet-Button Head-5/16" x 1"	3987	Use 171226 bolt and 171227 nut
BZ 549	Pin-Clevis-3/8" x 1-23/32"	4131	Use 227
BZ 550	Special Washer-25/64" x 3/4" x 1/16"	4929	Use 70863
551	Use 71591	BO 4931	Button-Glove Fastener-9/16" x 11/64"
553	Use 9159	BM 4934	Bolt-Hex Head-3/8"-16 x 3/4"
BM 555	Rivet-Flat Head-1/8" x 5/16"	4943	Use 12111
BZ 558	Bolt-Hex-Head-7/16"-20 x 2-1/4"	BT 4957	Washer-Plain-21/64 x 9/16 x 1/16"
BO 564	Rivet-1/4" x 5/8"	BZ 4961	Street Ell-1/8"-45°
BT 598	Cork-Clutch (Pkg 500)	BZ 4963	Washer-Plain-25/64" x 1-5/16" x 1/8"
BT 607	Bolt-Hex-Head-3/8"-16 x 1-3/8"	BZ 5282	End-Yoke
611	Use 12481	F 5356	Gasket-Water Outlet
BZ 613	Plain Washer-41/64" x 1-1/4" x 1/8"	BZ 5402	Nut-Hex-3/8"-16 x 3/16"
BZ 636	Key-Woodruff No. 11	BM 5452	Rivet-Round Head-3/16 x 1-1/8"
BZ 673	Plain-Washer-25/64" x 5/8" x 1/16"	BM 5550	Bolt-Hex Head-5/16"-18 x 2-3/4"
BZ 753	Taper Pin-No. 2 x 1-3/8"	5652	Use 70940
BO 771	Washer-Plain 21/64" x 3/4" x 1/16"	BM 5655	Clamp-Oil Tube
794	Use 71443	BT 5662	Pin-Taper
BM 817	Pipe Plug-1/8-Headless	5663	Use 18093
BZ 908	Bolt-Hex Head-5/16"-18 x 7/8"	BM 5710	Plug-Extension Head Pipe-1/2"
BZ 1031	Bolt-Hex Head-3/8"-24 x 1"	BO 5726	Screw-No. 10-32 x 7/16"
BO 1041	Washer-Plain-Parkerized-25/64" x 1 x 3/32"	BZ 5735	Bolt-7/16"-14 x 1"
BX 1061	Bolt-Hex Head-3/8"-24 x 1-1/8"	BZ 5771	Yoke-3/16" Adjustable
1062	Use 71206	BZ 5774	End-Adjustable Yoke-1/4"
BZ 1067	Bushing-Universal Joint	BZ 5777	End-Yoke-5/16"
BZ 1157	Bolt-Hex Head-3/8"-16 x 3/4"	BM 5813	Pin-Taper-#0 x 7/8"
1175	Use 171255	BZ 5825	Pin-Clevis-3/16" x 11/16"
Z 1231	Washer-Plain-17/32 x 1 x 1/32"	BT 5911	Screw-No. 10-24 x 5/8"
Z 1287	Washer-21/64 x 7/8 x 3/64"	6189	Use 170859

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 6371	Wood Screw-No. 10 x 1" Flat Head	BO 12243	Socket-Fastener
BZ 6440	Washer 21/64" x 5/8" x 1-1/16"	BO 12244	Cap-Glove Fastener Socket
BT 6457	Washer 2-3/4" x 1-15/16" x 3/8"	BO 12264	Rivet-Truss Head-1/4" x 3/8"
BM 6791	Gasket-Oil Pump	12272	Use 70327
6955	Use 1385	BZ 12275	Bolt-Hex Head-5/16"-18 x 1"
BZ 6998	Pin-Clevis-1/4" x 5/8"	12279	Use 71073
7435	Use 71073	BO 12285	Bolt-Hex Hd-1/4-28 x 7/8
BM 7525	Nut-Hex-No. 12-24 x 5/32"	BZ 12310	Cap Screw-3/8-24 x 1-3/8
BT 7527	Screw-Fill Hd-#8-32 x 3/8"	BO 12316	Washer No. 10
BZ 7753	Screw-Fill Head-No. 10-32 x 1/2"	BZ 12334	Nut-Hex-7/16"-20 x 1/4"
7762	Use 1349	BZ 12349	Washer-Plain-13/64" x 11/16" x 1/16"
BZ 7819	Cap Screw-Button Head-1/4"-20 x 3/8"	BO 12371	Washer-Plain-25/64" x 7/8" x 1/16"
BZ 7829	Plug-Universal Joint-1/8" Pipe	BZ 12382	Washer-15/32 x 3/4 x 1/16
BZ 7831	Washer-2-1/16" x 1-1/4" x 3/8"	BZ 12401	Nut-7/16"-20 x 3/8"
7833	Use 36350	BX 12415	Nut-3/8"-24 x 21/64"
BZ 7834	Dust Cap-Universal Joint	BZ 12426	Nut-W/W Carrier
BZ 7835	Packing-Universal Joint	HT 12437	Expansion Plug
BZ 7836	Journal-Universal Joint	BM 12440	Clevis Pin-1/4" x 59/64"
BZ 7840	Yoke-Universal Joint	BO 12481	Nut-5/16"-24 x 17/64"
BZ 7843	Casing-Universal Joint	BO 12790	Nut-No. 8-32 x 1/8"
7909	Use 395	12799	Use 71073
BZ 7911	Taper Pin-No. 00-3/4"	BZ 12843	Bolt-Sq Hd
8155	Use 170928	BZ 12844	Nut-5/16"-18 x 1/4"
8156	Use 71116	BO 12851	Bolt-Carriage-5/16"-18 x 2-1/4"
BM 8203	Bolt-Hex Head-3/8"-16 x 5/8"	12857	Washer-Plain 17/64 x 3/4 x 1/16
8222	Use 170095	BM 13031	Bearing-Crankshaft
BM 8228	Nut-Packing-3-5/15" x 2-9/32" x 1"	BM 13041	Valve-Motor
8274	Use 1385	BM 13044	Retainer-Valve Spring
BZ 8624	Washer-Plain-21/64 x 1-1/8 x 3/32	BM 13045	Guide-Valve Stem
8682	Use 71522	BM 13063	Worm-Oil Pump
BZ 8683	Pin-Clevis 5/16" x 1-1/32"	BM 13064	Worm Whl-Oil Pump
BZ 9133	Nut-5/16 x 1/2"	BM 13065	Adj Shaft-Oil Pump
BZ 9152	Rivet Button Head-3/16" x 5/16"	BM 13066	Bushing-Oil Pump
BO 9159	Bolt-Slotted Hex Head-1/4"-20 x 5/8"	BM 13068	Plunger-Oil Pump
BZ 9168	Bolt-Hex Head-7/16"-14 x 1-3/8"	BM 13069	Spring-Oil Pump
BM 9182	Bolt-Hex Head-1/4"-20 x 1"	BM 13072	Gasket-Oil Pump
BZ 9652	Rivet Button Head-5/16" x 9/16"	BM 13073	Stud-5/16"-18 x 1-1/4"
BZ 9655	Rivet-Rd Hd-1/4 x 9/16"	BM 13087	Glass-Oil Gauge
BM 9665	Nut-Hex-7/16"-14 x 3/8"	BM 13088	Washer-Gauge
HX 9681	Nut-Castle-7/8"-14 x 5/8"	BM 13097	Washer-2-1/2" x 1-7/8" x 7/32"
BM 9751	Plug-Welch-7/8"	BM 13121	Gasket-Cylinder
HX 9767	Spider-Rear Axle	BM 13126	Gasket-Oil Resv
BZ 9773	Plug-Pipe-1/8"	BM 13127	Gasket-Water Pump
BT 9824	Bolt-Hex Head-3/8"-16 x 1-1/2"	BM 13143	Stud-Exhaust Mani Elbow
BT 9828	Gasket-M/S Bearing Cap	BM 13194	Welch Plug-1-1/4"
BZ 9844	Boot-Drag Link	BX 13205	Lock-Pivot Pin
BT 9956	Plug-Transmission Case	BZ 13224	Bushing-Front Spring
BT 9957	Gasket-1-1/4" x 1-1/2" x,3/32"	BZ 13336	Bushing-Front Spring
9964	Use 1385	BO 13362	Handle-Bonnet
BZ 10214	Bolt-Hex Head-1/2"-13 x 1-1/4"	BZ 13542	Spring- Thr Cont
BT 10467	Sleeve-Trans Bearing	BM 13569	PackingBearing
HX 10861	Bushing-Tie Rod	BM 13568	PackingBearing
BT 10965	Pin-Dowel-1/8" x 5/16"	BM 13719	Float and Arm-Oil
BZ 11175	Bushing-Front Spring	BO 13733	Clip-Gas Line
11176	Use 11175	BZ 13859	Spring-Rad BOse
11235	Use 18102	BX 13959	Washer-R/A Shaft
BM 11799	Key-Woodruff No. A	BM 14041	Gasket-Water Pump
BM 11828	Nut-Union-5/16"	BM 14112	Welch Plug-1"
11829	Use 170387	BT 14864	Plug-Expansion 9/16"
BM 11841	Union-Fl Tube-1/8" Pipe x 7/16"-20	BZ 14911	Ferrule-1/2"x3/4"x3/32"
BM 11842	Union Nut-1/4"	BZ 15494	Bushing-Strg Gear
BM 12109	Plain Washer-13/32" x 5/8" x 1/16"	BM 16327	Pin-Straight-3/16" x 1-5/8"
BZ 12111	Lockwasher-3/16"	BZ 16352	Nut-9/16"-18 x 3/4"
BO 12112	Union-Flared Tube-1/4"	BZ 16498	Clamp-Exhaust Pipe
BZ 12115	Nut-5/16"-18 x 17/64"	BZ 16499	Clamp-Tail Pipe
BM 12117	Gasket-Oil Pump	A 16667	Fender-Front-R/H
BO 12120	Nut-1/4"-20 x 1/4"	BO 17679	Hinge-Door Lower
12123	Use 70971	BO 17912	Wood Screw-Button Head-No. 8 x 5/8"
BT 12167	Nut-Hex-7/16"-14 x 1/4"	F 17919	Ball-Trans Control-3/16"
12172	Use 71155	BZ 17944	Nut-Hex-No. 10-24 x 1/8"
BO 12194	Bolt-Carriage-5/16"-18 x 1-3/4"	17949	Plain Washer-41/64 x 1-3/16 x 31/32
BM 12213	Taper Pin-No 3 x 1-3/8"	BM 17976	Union-1/8" x 1/2"-20
BO 12214	Elbow-Union-1/8" x 7/16"-20	17993	Use 9152
12216	Use 70924	BT 18018	Washer-25/64" x 3/4" x 1/32"
BO 12222	Plate-Glove Fastener Button-9/16" Dia	BT 18023	Lockwasher-Plain 3/4"

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 18045	Nut-Hex-5/16"-18 x 3/16"	BX 19322	Gasket Housing Cover
BO 18062	Bolt-5/16"-18 x 1-1/4"	BX 19326	Retainer-R/A Felt
BZ 18074	Taper Pin-No. 4 x 1-1/4"	BM 19959	Spring-Oil Pump
BX 18093	Nut-5/8"-18 x 3/8"	BM 19960	Plug-Oil Pump
*SP 18100	Hulb-6-8 Volt-3 C P-Single Contact	BZ 20005	Lock-Steering Gear
BZ 18102	Bearing-Thrust-No 6283	BX 20094	Washer-R/A Hrg
BZ 18106	Bolt-5/16"-24 x 1-1/8"	BZ 20146	Spring-Univ Jt
BZ 18107	Rivet-9/64" x 3/8"	BZ 20147	Retainer-Univ Jt
BZ 18108	Extension-1/8" Pipe	HT 20249	Disc-Clutch Driven
BO 18116	Set Screw-No. 8-32 x 3/16"	BX 20709	Retainer-R/A Hsg
BM 18118	Drain Cock-1/4" Pipe	BX 21005	Nut-F/A Strg Arm
BO 18137	Screw-Round Head Machine-6/32 x 5/16"	BZ 21432	Terminal-Hat
BT 18149	Nut-5/16"-24 x 1/4"	BX 21948	Ball-F/A Strg Arm
BT 18150	Bearing-Annular	BZ 22166	Boot-Drag Link
18164	Use 712.37	BX 22232	Retainer-F/A Wshr
BO 18165	Clip-Terminal-17/64"	BX 22272	Bolt-Front Spring
BO 18166	Clip-Terminal-3/16"	BM 22296	Packing-Exh Manifold
18169	Use 170310	BM 22301	Washer-Camshaft
BM 18192	Grease CupBowen	BO 22448	Hinge-Door Center
BM 18194	Dowel Pin-1/8 x 7/16"	BO 22597	Monkey-Wrench
BO 18197	Clip-5/ 16"-Single	BZ 22641	Nut-Worm Wheel
BZ 18218	Bolt-1/4"-20 x 5/8"	BM 22691	Gasket-Dist
BT 18224	Bearing-Annular	HT 22699	Spring-Clutch
BT 18226	Bearing-Hyatt NC-306	BM 22700	Piston
BO 18227	Washer-3/4" Plain	BM 22703	Bushing-Piston Pin
BO 18228	Bolt-1/4"-28 x 2-5/8"	HT 22779	Gasket-Clutch Cover
BO 18236	Bolt-7/16"-20 x 7/8"	HT 22788	Spring-Clutch
BZ 18239	Rivet-5/16" x 2-7/8"	HT 22792	Spider-Clutch Release
BZ 18240	Rivet-5/16" x 3"	HT 22796	Plate-Clutch Press
BM 18243	Gasket-1" x 1-1/4" x 3/32"	HT 22807	GasketBearing Cap
BM 18244	Bolt-1/4"-20 x 2-1/4"	HT 22838	Spring-Cont Lever
BZ 18245	Bolt-5/16"-18 x 3-34"	HT 22854	Fork-Clutch Shift
BM 18247	Bolt-3/16-18 x 3-1/4	BM 22891	Manifold-W Outlet
BX 18251	Clevis Pin-5/16" x 3/4"	BM 23162	Sleeve-Gen Drive
BX 18257	Washer-Plain-21/32" x 1-1/2" x 3/16"	BM 23239	Gasket-Dist Hrkt
18269	Use 160939	BM 23291	Gasket-Exh Manif
18281	Use 18166	BM 23292	Gasket-Exh Manif
BX 18293	Clevis Pin-7/16" x 2-1/8"	BO 23386	Weatherstrip-W/S
BX 18305	Screw-3/8"-24 x 1-7/16"	23561	Use 30353
BM 18308	Plain Washer-25/64" x 3/4" x 3/32"	BM 23608	Gear-Water Pump
BZ 18316	Lockwasher-7/ 16"	BM 23611	Drive Shaft-Dist
18317	Use 71061	BM 23613	Gear-Dist Shaft
BO 18318	Screw-1/4"-20 x 3/4"	BM 23617	Washer-Fan Pulley
18333	Use 70523	BM 23622	Gasket-Front
BO 18342	Screw-No. 10-32 x 3/4"	BM 23625	Thrust Plate-Camshaft
BO 18347	Use 170583	BM 23627	Chain-Timing
18353	Use 18107	BM 23628	Coupling-Gen Stat
18359	Use 71628	BM 23629	Coupling-Gen Float
BT 18370	Bearing-M/S Pilot	BM 23690	Bushing-W Pump
BM 18379	Gasket-5/8"x7/8"x1/16"	BM 23691	Bushing-W Pump
BZ 18388	Rivet-9/64" x 5/16"	BO 23696	Wire Starter. Motor
BM 18404	Nut-7/16"-20 x 17/32"	BM 23701	Spring-Adj Eccentric
BZ 18407	Screw-No. 18-18 x 1-3/4"	BM 23702	Washer-W Pump
18419	Use 70028	BM 23703	Washer-W Pump
BT 18430	Bolt-3/8"-24 x 2-1/8"	BM 23713	Eccentric
BT 18444	Washer-17/64" x 1/2" x 3/64"	BZ 23738	Spring-Drag Link
BO 18447	Screw-No. 10-32 x 5/8"	BZ 23740	Ball Seat-Drag Link
BO 18450	Nut-No. 10-32 Spec	BO 24410	Spring-Vent
BO 18451	Screw-No. 10-32 x 13/64"	BZ 24465	Bolt-Spring Shackle
BO 18453	Screw-1/4"-20 x 7/16"	BM 24468	Bushing-Dist Shaft
BZ 18454	Rivet-Truss Head-3/16 x 7/16	BO 24495	Washer-Handle Screw
BO 18455	Screw-1/4"-20 x 1-1/2"	BM 24956	Washer
18459	Use 170367	BZ 24972	Lace-Boot
BO 18461	Shakeproof Washer-1/4"	25194	Use 29179 and 29180
BO 18464	Screw-1/4"-20 x 11/16"	BM 25305	Gasket Cylinder Plate
BO 18465	Screw-1/4"-20 x 7/8"	BM 25306	Gasket-Exhaust Manifold
BO 18470	Screw-No. 10-32 x 5/8"	BM 25308	Gasket-Intake Manifold
BO 18474	Rivet.-3/16" x 5/16"	BM 25309	Gasket-Carb
BO 18475	Shakeproof Washer-1/4" Ctsk	BX 25619	Bracket-Brake Pin
BO 18479	Nut-No 10-32 x 3/16"	BX 25628	Bracket-Brake End
18482	Use 170304	BX 25640	Spring-Brake
BO 18483	Nut-5/16"-18 x 1/4"	C 25839	Leaf No. 4
C 18908	Pipe-Exh	C 25840	Leaf No. 5
BO 19044	Terminal Insulator	BX 25886	Pin-F/A Pivot
BX 19144	Washer-Pin Felt	BZ 26137	Bushing-Strg Gear

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BM 26538	Shim-Fan Spindle	BX 29229	Retainer-Cap Sprg
BZ 26556	Main Tube-Strg Gear	BX 29237	Camshaft-Brake
BO 26724	Bumper-Dovetail	BX 29239	Control Lever-Brk
BZ 26877	Boss-Gas Tank Drain Plug	BX 29243	Spring-Brake
BM 27436	Gasket-Adj Eccen	BX 29244	Ball Nut-Brake
BO 27446	Spring-Lock Plunger	BZ 29275	Spring-Brake
BO 27547	Spacer-Door Hinge	BX 29311	Plug-Tie Rod
BO 27873	Clinch on Nut and Ret	BX 29314	Spring-Tie Rod
BZ 28066	Terminal Connector	C 29321	Exhaust Manifold
BZ 28068	Switch-Stop LigBT	BM 29331	Tube-Exh Outlet
BM 28076	Oil Pressure Gauge	BM 29333	Packing-Exh Tube
BM 28207	Lock-Piston Pin	BM 29335	Gasket-Manifold
BZ 28280	Bolt-Rim Clamp	BM 29336	Gasket-Manifold
BM 28357	Gasket-Manifold	BM 29341	Retainer-Spring
BM 28369	Gasket-Carburetor	BT 29352	Pressure Plate
BZ 28491	Bushing-Strg	BT 29359	Spring-Clutch
BZ 28818	Bushing-Spring	BT 29360	Washer-Clutch
C 28848	Pipe-Exhaust	BT 29361	Gasket-Cover
A 28861	Fender-Rear	BM 29363	Gasket-Manifold
BX 28954	Pivot Pin-F/A	BT 29371	Drive Gear-Trans
BX 28956	Bushing-F/A	BT 29580	Drive Plate Assy
BX 28957	Bushing-F/A	BX 29587	Retainer-Washer
BX 28966	Shim-Spindle	BZ 29731	Main Tube-Strg
BX 28967	Shim-Spindle	BZ 29732	Worm-Strg
BM 29013	Gasket-Cyl Head	29743	Use 32153
BM 29015	Manifold-Water Out	29749	Use 32073
BM 29018	Pivot-Rocker Arm	BZ 29750	Thrust Washer-Strg
BM 29034	Seat-Valve Spring	BM 29863	Gasket-Cyl Head
BM 29036	Gasket-Water Out	BM 29866	Gasket-Cyl Hd Coy
29057	Use 30633	BM 29885	Tappet Roller
29058	Use 30782	BM 29886	Tappet Roller Pin
BM 29072	Gasket-Exh Manif	29888	Use 30126
BM 29074	Gasket-Intake Manif	BM 29890	Fan Pulley-"V" Type
BZ 29075	Hub Cap-Front	BM 29909	Gasket-Exh Manifold
BZ 29076	Hub Cap-Rear	BM 29910	Gasket-Exh Manifold
BT 29079	Gear-Speedometer	BM 29912	Push Rod
29170	Use 203990	29918	Use 30451
BZ 29178	Jack Assy	29919	Use 30452
BZ 29179	Extension Handle	BM 29921	Gasket-Int Man
BZ 29180	Jack Handle Crank	BM 29922	Gasket-Exh Man
BX 29206	End Assy-Brk	BM 29923	Body-Oil Pump
BX 29217	Spring-Brake	BM 29925	Spring-Main Plunger
BX 29219	Bracket-Brake	EM 29929	Outlet Tube
BX 29220	Cam and Shaft-Brk	BM 29930	Packing Nut
BX 29222	Shaft-Frt Control	BM 29931	Pkg-By-Pass Tube
BX 29223	Trunnion-Brk	BM 29936	Gasket-Intake Manif
BX 29224	Trunnion Pin Brk	A 29957	Muffler-Assy
BX 29227	Cover Cap-Brk	BM 29985	Spring-Exh Valve
BX 29228	Cap-Spring-Brk		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 30129	Sleeve-Clutch Shifting	27-28 Hudson
BO 30136	Terminal-Headlamp	27 thru 31 All
BM 30173	Hub-Fan	27-28-29 Hudson
30187	Use 32151	
BM 30189	Shaft and Worm Whl-Oil Pump Drive	27-28-29 Hudson
BM 30199	Plunger-Oil Pump	27-28-29 Hudson
BM 30248	Oil Pump Assy	27-28-29 Hudson
BM 30291	Paddle-Pump	27-28-Hudson, 29 Hudson R
BM 30292	Nut-Water Pump Packing-Front	27-28 Hudson, 29 Hudson R
BM 30293	Nut-Water Pump Packing-Rear	27-28 Hudson, 29 Hudson R
BM 30294	Bushing-Water Pump Body-Front	27-28 Hudson, 29 Hudson R
BM 30295	Bushing-Water Pump Body-Rear	27-28 Hudson, 29 Hudson R
BO 30307	Post-Junction	27-28 Hudson
BO 30308	Switch-Light Control	27-28-29 Hudson-Essex
BM 30319	Shaft-Water Pump	27-28-29 Hudson
BM 30321	Body-Water Pump	27-28-29 Hudson
BO 30348	Conduit-Headlamp	27-28-29 Hudson
BO 30350	Socket-Headlamp Terminal	27-28-29 Hud-Esx, 31 Dover-Exp Ph
BO 30351	Sleeve-Headlamp Terminal	27-28-29 Hud-Esx, 31 Dover-Exp Ph
BZ 30353	Cap-Gas Tank	27-28 Hudson
BO 30365	Spring-Headlamp Lens	27-28 Hudson
30371	Use 36158	
BO 30379	Glass-Door-Red	27-28-29 Hudson-Essex
BO 30393	Lens-Headlamp	27-28 Hudson
BO 30440	Gasket-Lens	27-28-29 Hudson
BO 30443	Reflector Assy-Headlamp	27-28-29 Hudson
30450	Use 102583	27-28 Hudson
BM 30451	Pad-Motor Support-Front	27-28-29 Hudson
BM 30452	Pad-Motor Support-Rear	27-28-29 Hudson
BZ 30497	Lever-Steering Gear Throttle	27-28-29 Hudson
BZ 30498	Lever-Hand	27-28 Hudson
BZ 30507	LeverLight Control	27-28-29 Hudson-Essex
BZ 30509	ButtonBOrn	27-28-29 Hudson-Essex
BZ 30513	SpringBOrn Button	27-28-29 Hudson-Essex
BZ 30556	Oil Cup Assy	27-28 Hudson-Essex
BM 30563	Connecting Rod Complete-RH	27-28-29 Hudson
BM 30564	Connecting Rod Complete-LH	27-28-29 Hudson
BM 30566	Nut-Connecting Rod Bolt	27-28-29 Hudson
BO 30659	Lens-Side Lamp	27-28-29 Hudson
BO 30735	Cylinder-Electrolock	27-28 Hudson-Essex
BO 30770	Cable-#14 Armored	33-34 Hudson-Terr
30773	Cable-#7 M M-High Tension (Use MS 3009)	33-34 Hudson-Terr
30774	Cable-#12 Braid Covered (Use 3010)	33-34 Hud-Terr
30776	Cable-#16 Braid Covered (Use 3012)	33-34 Hud-Terr
30777	Cable-#14 Braid Covered (Use 3011)	33-34 Hud-Terr
BZ 30782	Rim Assy	27-28 Hudson
BZ 30783	Clamp-Rim	27-28-29 Hudson
BZ 30785	Nut-Rim Clamp	27 thru 31 Hud, 29 thru 31 Essex, 31 Dover-Ph
BX 30837	Pinion-4-5/12	27-28-29 Hudson
BX 30839	Pinion-Rear Axle Drive-4-1/13	27-28-29 Hudson
BX 30842	Bolt-Lock Drive Gear	27-28-29 Hudson
BX 30843	Lock-R/A Pinion Shaft Bearing Nut	27-28 Hudson
BM 30848	Spindle Fan	27-28-29 Hudson
BM 30849	Washer-Fan Spindle	27-28-29 Hud, 29 thru 32 Essex, 33 Hud
BZ 30868	Clip-Clutch & Brake Spring & Exhaust Damper	27 thru 1950 All
BX 30871	Camshaft & Bushing-Rr Brake	27 thru 31 Hudson-Essex
BX 30875	Diff Case Assy-Rear Axle-R & L	27-28-29 Hudson
30913	Lens-Headlamp	29 Hudson
BZ 30932	Clamp-Strg Gear Jacket Tube	29 thru 32 Hud-Esc, 33 Terr, 34 Hud-Terr
BM 31057	Rocker Arm	29 Mason
BZ 31082	Cap-Hub	29 Hudson
BX 31101	Spindle & Bushing Assy-Frt Axle-RH	29 Hudson
BT 31117	Plate Assy-Clutch Shift	29 Hudson
BT 31121	Pressure Plate-Clutch	29 Hudson
BT 31129	Washer-Clutch Bearing Oil Retainer	29-30-31 Hudson, 30-31 Essex
BT 31133	Gasket-Clutch Cover	29 Hudson
BT 31159	Drive Plate-Clutch	29 Hudson
31216	Use 34204	
BT 31221	Retainer-Clutch Bearing	29 Hudson
BX 31234	Spindle-Pivot Pin	29 Hudson
BX 31237	Nut Assy-Rr Whl Brg Adjusting	29 Hudson
BO 31240	Key-Electrolock	28-29-30 Hudson-Essex
BO 31250	Tail and Stop Light	29 Hud-Essex, 30 thru 32 Essex, 30 Dover
BZ 31251	Cap-Hub	29 Hudson
BM 31263	Gasket-Oil Level Gauge	29 thru 32 Hud-Essex 31 Dover-Phaeton

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 31273	Gauge-Oil Level	29 Hudson
BZ 31276	Gas GaugeTank Unit	29 Hudson
BM 31288	Retainer-Fan Hub Oil	29-30 Hud,31-32 Hud-Essex
BO 31305	Door-Tail Lamp-With Glass	29 Hudson-Essex
31306	Use 31305	
BM 31309	Fan Assy-One-Blade Type	29 Hudson
BZ 31310	Gasket-Gas Gauge	29 thru 32 Hud-Esx,31 Dover-Exp Ph,33 Hud
BO 31355	Booster-Vacuum Tank	29-32-33 Hudson,32 Essex
BO 31451	Block-Junction Post	29 Hud,30 Dover,31 Exp Ph
BX 31473	Bushing-Pivot Pin	29 Hudson
C 31529	Muffler Assy	29 Hudson
BO 31548	Sleeve-Wire	30 thru 1950 All
BX 31613	Washer-Brake Pin	29-30-31 Hudson-Essex
BZ 31672	Gasket-Strg Gr Case Cover-LH	29 Hudson
BZ 31673	Retainer-Strg Gear Oil-RHD	29 Hudson-Essex
31679	Use 31735	
BZ 31680	Outer Ring-Strg Gr Roller Brg	29 Hudson
BZ 31681	Bracket-Strg Gear Control	29 Hudson
BZ 31700	Casing-U/J-Inside	29 Hudson
BZ 31705	Universal Joint Assy-Front	29 Hudson
BZ 31733	Worm and Bearing Assy-Strg Gr	29 Hudson
BZ 31735	Bearing Complete-Strg Gr	29 Hudson
BM 31852	Guide-Arm Push Rod-Upper	29 Hudson
31854	Operating Rod-Rear Brake (Use 63854)	29 Hudson
BX 31877	Pin-Front Axle Pivot	29 Hudson
31912	Use 36389	
31990	Use 34204	
BM 32012	Insulator-High Tension Wire	35 thru 1949 All
BZ 32073	Bushing-Steering Gear	29-30 Hudson
BX 32110	Cam Plate and Block Assy	29-30-31 Hudson
BM 32119	Piston Ring	29 Hudson
BZ 32144	Bushing-Strg Gear Shaft	27 thru 29 Hud-Essex,32 Hudson
32146	Use 32153	
32150	Use 30350 and 30351	
BM 32151	Worm Wheel-Oil Pump	27-28-29 Hudson
BZ 32153	Bushing-Strg Gear Column	27-28-29 Hudson
BX 33012	Drive Gear-Rear Axle-4-3/11-1	30-31-32 Hudson
BM 33081	Fan Belt	30 Hudson
BT 33084	Hand Brake Lever Assy-RHD	30 Hudson-Essex
BZ 33085	Return Spring-Brake Lever	30-31 Hudson-Essex
33089	Use 160331	
33090	Use 160332	
33091	Use 160333	
33092	Use 160334	
33093	Use 160335	
F 33094	Inlet Valve	30 thru 35 8 Cyl
BM 33096	Gasket-Valve Chamber Cover	30 thru 33 8 Cyl
33101	Use 35030	
BM 33103	Starting Jaw-Crankshaft	30 thru 32 Hud-Essex,33 T-L
BM 33109	Bearing Cap-#2 Crankshaft	34 thru 1940 Hudson 8
BM 33114	Bearing Cap-#3 Crankshaft	34 thru 1940 Hudson 8
BM 33119	Bearing Cap-C/S-#4	34 thru 1940 Hudson 8
33144	Gasket-Water Jacket Cover (Use 161751)	30 thru 37 8 Cyl
BM 33148	Piston-Finished	30 Hudson-Essex
BM 33148	Piston-Semi-Finished	30 Hudson-Essex
33154	Breather Tube Support (Use 164594 & 164595)	30 thru 1942 All Models,32 Essex
BM 33156	Gasket-Cylinder Head	30 Hudson
33165	Use 38957	
BM 33166	Gasket-Breather Tube Support	30 thru 32 Hud-Essex,33 Hud-Terr 8
33167	Use 46903	
F 33171	Gasket-Small-Intake Man to Cyl	30 thru 35 Hudson 8,33 Terr 8
F 33172	Gasket-Large-Intake Man to Cyl	30 thru 35 Hudson 8,,33 Terr 8
BM 33176	Gasket-Carb Riser to Intake Man	30 Hudson
MF 33179	Gasket-Oil Pump Body	1930 thru 1947 All, 1948 thru 1950 8 cyl
BM 33182	Oil Pump Shaft	30 thru 33 Hud 8,32 Essex
F 33190	Gasket-Exh Manifold-End	30 thru 35 Hud 8,33 Terr 8
F 33191	Gasket-Exh Manifold-Inter	30 thru 35 Hud 8,33 Terr 8
F 33192	Gasket-Exh Manifold-Center	30 thru 35 Hud 8,33 Terr 8
BM 33194	Gasket-Exh Pipe to Exh Man	30-31-32 Hudson-Essex,33 Hud T-L
BM 33199	Gasket-Exh Manifold Damper	30-.31 Hudson
BM 33204	Gasket-Oil Pan	30 thru 33 Hud 8, 33 Terr 8
BM 33212	Screen Assy-Oil Pan	30-31 Hudson-Essex
BM 33217	Water Pump Body	30 Hudson
BM 33220	Gasket-Water Pump	30 Hudson
BM 33222	Pulley Assy-Water Pump	30-31 Hudson

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 33225	Bearing-W/Pump Shaft-Front	30 thru 33 Hudson 8
BM 33227	Washer-W/Pump Drive Shaft	30 thru 33 Hudson 8
BM 33228	Paddle-W/Pump Shaft	30 Hudson
BM 33229	Packing-Water Pump	30 thru 33 Hudson 8
BM 33231	Packing Nut-W/ Pump	30 thru 33 Hudson 8
BM 33232	BOse-Radiator Outlet	30 Hudson
BM 33235	Bolt Lock-Dist Support	30 thru 33 Hudson 8-Essex
BM 33241	Coupling-Gen Drive Shaft	1930 thru 1933 Hudson
BZ 33255	Return Sprg Hke Pedal Rod	30-31-33 Hud,30-31-32 Essex
BZ 33290	Hub Cap-Wood Wheel	30 Hudson
33330	Use 35087	
BM 33331	Pin-Piston	30 Hudson-Essex
33332	Bushing-Piston Pin (Use 166244)	1930 thru 1942 All
33340	Use 37006-36457-37180	
BX 33378	Lever-Front Bke Crank RH & LH	30-31 Hudson
BZ 33448	Hub Cap-Wire Wheel-Outer	30-31 Hudson
BZ 33454	Cap-Radiator Filler	30-31 Hudson-Essex
BZ 33455	Gasket-Radiator Cap	1930 thru 1933 All
33469	Use 33913	
BO 33470	Lens-Headlamp	30-31 Hudson
BO 33473	Screw-Headlamp Door	30 thru 33 Hudson
BO 33478	Gasket-Headlamp	30-31 Hudson
BO 33491	Bracket-Side Lamp-LH	30 Hud-Exs,31 Hud U 7Sed
BO 33493	Door Assy-Tail & Stop Lamp	30-31 Hud,31 Esx Spec Cpe
33500	Use 34029	
BO 33506	Rivet-Headlamp Lens Lower Clip	92 thru 97,1940 thru 1949 All
BO 33509	Lens-Side Lamp Door	30 Hud,31 Hud Co-Town Sed,31 Hud U 7Sed
BZ 33531	Casing-Outer-U/J-Front End	30-31-32 All,33 Hud-Terr K
BZ 33532	Spring-Outer Casing	30-31-32 All,33 Hud-Terr K
BZ 33539	Spring Clip-Throttle Bell Crank	30 Hud RHD,30-31 Esx,1938 thru 1940 Models with Vac
BZ 33551	Ball Joint-Strg Gr to Throttle Bell Crank	Clutch,1941 thru 1947 All,1948-1949 with HDM or VD, 500 LHD witBOut HDM
33617	Use 33913	
BZ 33619	Electrolock Assy	30-31 Hudson-Essex
BO 33620	Side Lamp Assy-RH	
BZ 33657	Worm-Steering Gear	30-31 Hudson
BZ 33658	Adjusting Nut-Steering Gear Worm	30 Hud,31 Hud U Sed-T Co-Town-Std Sed
BZ 33659	Washer-Steering Gear Shaft Lock	30-31 Hudson
		30-31 Hudson
BM 33801	Nut-Crankshaft Bearing Cap Stud	30-31-33 Hud,34 Hud LL,30-31 Esx,36 RHD
BM 33808	Gasket-Dampner Cover	37 thru 1950 All
C 33833	Cylinder Head Assy	30 thru 37 Hud,32 thru 37 Terr,31-32 Essex
BM 33872	Arm-Fan	30-31 Hudson-Essex
BX 33876	Adjusting Screw-Brake	30 Hudson
BO 33913	Door Assy-Headlamp	30 Hudson-Essex,31 Dover
BZ 33934	Clamp-Muffler Tail Pipe	30-31 Hudson-Essex
BZ 33980	Spring-Throttle and Brake Return	30-31 Hudson
BX 33994	Socket Complete-RH & LBTie Rod	30-31 Hud-Essex,33 E-T-L
BO 34029	Lamp Assy-Tail & Stop	30 thru 1940 All
BM 34041	Arm-Fan	30-31 Hud,29-30-31 Essex-Dover
BM 34042	Belt-Fan	30-31 Essex
BO 34105	Lens-Tail Lamp Door	30 thru 33 Hudson
BT 34160	Spring-Transmission Shift Lock	30 thru 33 Hudson 8
BT 34161	Retainer-Transmission Shift Lock	30-31 Esx,31 Esx & Bro DeLuxe
C 34204	Manifold & Reinforcement Assy-Exhaust	30 thru 35 All
BM 35009	Piston Pin	30 thru 35 All
BM 35022	Ring-Piston	29 Hudson
BM 35032	Spindle-Fan	31 Hudson-Essex
35033	Use 36457	31 Hudson-Essex
BM 35034	Belt-Fan	31-32-33 Hudson,31 Essex
BM 35035	Oil Seal-Fan Hub	
BM 35039	Hose-Water Pump to Cylinder	31 Essex
C 35041	Drag Link Assy	31-32-33 Hudson,31 Essex
35076	Use 35077	31-32-33 Hudson
BM 35077	Bearing Cap #2	31 Essex
F 35081	Gasket-Intake Man to Carb Riser	
BM 35083	Body-Assy-Water Pump-Front	31 thru 1940 6 Cyl
BM 35086	Gasket-Water Pump Body	31-32-33 Hudson
*BM 35087	Bearing Assy-Rear-Water Pump	31-32-33 Hudson
BM 35089	Washer-Water Pump Shaft-Rear	31-32-33 Hudson
C 35102	Tail Pipe	31-32-33 Hudson
BZ 35124	End-Brake Rod	31-32-33 Hudson
BT 35137	Ratchet-Brake Lever	31 Hudson-Essex
		31 Hudson-Essex
		31-32-33 Hudson,31-32 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 35169	Cover Assy-Water Jacket	31 Hudson
BM 35183	Gasket-Cylinder Head	31 Essex
BM 35184	Gasket-Cylinder Head	31 Hudson
35185	Use 37677 & 37678	
35191	Use 37106	
35192	Use 37006-37180-36457	
BZ 35229	Bracket-Front Spring-RH-Front	31 Hudson-Essex
BZ 35230	Bracket-Front Spring-LH-Front	31 Hudson-Essex
C 35272	Case-Transmission-RHD	31 Hudson-Essex
C 35273	Case-Transmission	31 Hudson-Essex
BT 35274	Gear Assy-Transmission Main Drive	31 Hudson-Essex
BT 35280	Main Shaft-Second and High Gear	31 Hudson-Essex
BT 35281	Gear-Transmission Low and Reverse	31 Hudson-Essex
BT 35282	Countershaft-Transmission	31 Hudson-Essex
BT 35283	Gear Assy-Countershaft Drive and Inter	31 Hudson-Essex
BT 35285	Bushing-Transmission Drive and Inter	31 Hudson-Essex
BT 35286	Gear Assy-Low and Reverse	31 Hudson-Essex
35299	Use 37106	
BZ 35354	Clip-Front Spring	31-32 Essex, 33 Hudson
BZ 35355	Clip-Front Spring	31-32-33 Hudson, 32 Essex
EX 35360	Thrust Button-Drive Shaft	31 thru 1950 All
BM 35365	Bearing-Generator Drive Shaft	31 thru 33 Hudson-Essex
BM 35367	Gasket-Generator Drive Shaft	31 thru 33 Hudson-Essex
35368	Driving Plate Assy-Clutch (Use 42512)	31 Hudson-Essex, 30 Essex
BM 35376	Bolt-Crankshaft	31-32 Essex, 32-33 Terr
BM 35377	Lock-Crankshaft Bolt	31-32 Esx, 32-33 Terr, 33 Hudson
BZ 35378	Bumper-Front Spring	31-32 Hudson-Essex
BM 35385	Stud-Cylinder Head	31 Hudson
BM 35386	Chain-Timing	31 thru 33 Hudson-Essex
BM 35388	Sprocket-Crankshaft	31 thru 33 Hudson-Essex
BT 35390	Thrust Ball Seat-Trans Mainshaft	31 thru 33 Hudson-Essex
BM 35391	Valve Spring Seat	31 thru 34 Hudson-Essex, 33-34 Terr
BM 35392	Boss-Oil Pan Drain Plug	33-34 Hud, 34 Terr, 35 thru 1950 All
BZ 35396	Spring-Rear Drag Link	31 thru 34 Hudson-Essex
BM 35399	Inlet-Cylinder Water	31 Essex
35412	Gasket-Cylinder Water Inlet (Use 60049)	31 Essex
BT 35439	Gasket-Transmission Cover	31 Hudson-Essex
35442	Screw-Trans Control (Use 151787)	31-35-36-37 All
BT 35443	Lock-Transmission Control Lever	31 All, 35 thru 39 All
BT 35481	Transmission Mainshaft Assy	31 Hudson-Essex
BO 35539	Loom-1/2"	1940 All
BZ 35571	Rivet-Brake Drum	31 Essex, 32 Terr, 1941 thru 1950 All
BZ 35572	Cover-Brake Drum Insp Bole	31 Essex, 32-33-34 Terr, 34 Hud
BZ 35573	Screw-Brake Drum Insp Bole Cover	31 Essex, 32-34-35 Hud, 32-33-34-35 Terr
BZ 35576	Hub Cap-Wire Wheel	31 Essex
C 35584	Carrier Assy-Wire Wheel	31 Essex
BZ 35638	Gauge Assy-Gas Tank	31 Hudson-Essex
BZ 35660	Seat-Rear Drag Link Ball	31 thru 34 Hudson-Essex
BX 35691	Dust Cover-Inner-Drag Link	31 thru 34 Hudson-Essex
BX 35692	Dust Cover-Outer-Drag Link	31 thru 34 Hudson-Essex
BZ 35707	Finish Plate-Bumperette-RH	31 Hudson
BX 35710	Socket-Drag Link	31 Essex
BX 35714	Socket-Drag Link	31 Hudson
35716	Use 36456	
35726	Use 40757	
BM 35857	BOse-Radiator Water Inlet	31-32 Essex
BO 35903	Lug-Headlamp Door	31 Hudson
BO 35908	Door Assy-Headlamp-Less Lens	31 Hudson
BO 35909	Lens-Headlamp Door	31 Hudson
35917	Use 35908 & 35903	
BO 35918	Gasket-Headlamp Reflector	31 Hudson
BM 35919	Pipe Assy-Oil Pump to Support Plate	31 thru 33 Hudson-Essex
35924	Drag Link Assy (Use 37708)	31 Hudson
35929	Gasket-Crankshaft Oil Throw-Lower (Use 37328)	31 Hudson-Essex
35980	Cable-Double Armored (Use MS 3014)	33-34 Hud-Terr
BM 35986	Pad-Engine Mtg-Outer-Front	30 Hudson-Essex
35987	Pad-Engine Mtg-Inner-Front (Use 35989)	31 Hudson-Essex
BM 35989	Pad-Engine Mtg-Outer-Rear	31 Hudson-Essex
BM 35990	Pad-Engine Mtg-Inner-Rear	31 Hudson-Essex
BZ 35993	Electrolock Assy	31 Essex
C 36033	Drive Shaft Assy-Rear Axle	31 Hudson-Essex
36035	Use 42577	
BZ 36053	Casing-Inner Prop Shaft	31 thru 33 Hudson-Terr, 32 Essex
BZ 36054	Cup-Prop Shaft Baffle	31 thru 33 Hudson-Terr, 32 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
36100	Double Cable-Armored (Use MS3013)	33-34 Hud-Terr
BZ 36107	Bracket-Headlamp-RH	31 Hudson-Essex
BZ 36108	Bracket-Headlamp-LH	31 Hudson-Essex
BZ 36130	Nut-Rear Tire Car Lock Stud	31 Hudson-Essex
BO 36158	Wire and Socket Assy-H/Lamp Reflector	27-28 Hudson
BZ 36160	Cap-Outer Hub-Wood Wheel	31 Hudson
BZ 36163	Arm-Strg Gear Ball	31 Essex
BZ 36165	Arm-Strg Gear Ball	31 Hudson
BZ 36166	Shaft-Steering Gear	31 Essex
36275	Use 110 & 63464	
F 36334	Gasket-Exhaust Manifold	29 Essex
BT 36340	Retainer Assy-Clutch Bearing	31 Hudson-Essex
BT 36342	Retainer-Clutch Bearing Oil	31 Hudson-Essex
BZ 36350	Casing Assy-Prop Shaft-Outer	31 Hudson
BM 36352	Pulley Assy-Water Pump	31-32-33 Hudson
BT 36359	Spring-Clutch Engaging	31-32-33 Hudson, 32 Essex
36361	Use 39264	
36362	Ignition Wires Assy (Use 38978)	30 Hudson
36363	Use 38978	
36364	Use 39264	
36365	Ignition Wires Assy (Use 38978)	30 Essex
36366	Ignition Wires Assy (Use 38978)	31 Essex
BX 36389	Spring-Brake Shoe Spacer Pin	31 Hudson-Essex
36393	Elbow-Oil Pump to Cyl Plate (Use 170386)	31 thru 39 All
BM 36406	Pipe Assy-Oil Return	31 thru 1947 8 Cyl
BZ 36432	Yoke-Propeller Shaft Flange	31-32-33 Hudson, 31-32 Essex
BM 36455	Cover-Flywheel	31 Hudson-Essex
BM 36456	Hub and Oil Seal Assy-Fan	31 Essex
BM 36457	Hub and Oil Seal Assy-Fan	31-32-33 Hudson, 32 Essex
C 36468	Pipe Assy-Exhaust	31 Essex
36555	Use 37106	
36556	Use 37006, 37180, 36457	
BO 36566	Terminal-Coil End-Coil to Distributor Wire	31 thru 1949 All
C 36573	Spring Leaf #1-Front	32-33 Hudson, 31-32 Essex
36692	Use 82535	
36721	Use 38978	
36722	Use 39264	
BZ 36766	Arm-Steering Gear Ball	33 Hudson 6, 31-32 Essex
BZ 36767	Lock-Exhaust Pipe Flange Bolt	31-32-33 Hudson, 31-32 Essex
BM 36896	Felt-Water Pump Shaft Bearing	32-33 Hudson
BT 36902	Lever Assy-Trans Control Hand	31 Hudson-Essex
BZ 36919	Nut-Startix Switch Terminal	33-34 Hudson, 34-33-34 Terr
C 37004	Flywheel Assy	32 Essex, 33 Hudson 6
BM 37006	Dampner Assy-Vibration	32 Essex
BM 37015	Washer-C/S Starting Jaw	32 thru 1947 All
BM 37016	Cap-Crankshaft Bearing #3	32 thru 1940 6 Cyl
37017	Reamed Use 157982	
37017	Unreamed Use 157968	
BM 37018	Bearing-Lower-#3-Crankshaft (Use 162536)	32 thru 39 6 Cyl
37018	Reamed Use 157982	
37019	Use 161763	
37020	Use 161764	
BM 37024	Facing-Vibration Dampner	32 thru 37 All
BM 37025	Plate-Vibration Dampner Cover	32 thru 1950 All
BM 37026	Cap Assy-#3 Crankshaft Bearing	32 thru 39 6 Cyl
BM 37027	Stud-Crankshaft Bearing	32 thru 37 6 Cyl
F 37029	Piston Pin	32 thru 1947 All, 1948 thru 1950 8 Cyl
37031	Use 43443	
37033	Use 43445	
37035	Use 43447	
BX 37044	Gear and Pinion-Rr Axle-Matched-4-7/11	32-33 Hudson-Essex
BM 37048	Valve-Exhaust	32-33 6 Cyl
BM 37049	Valve-Inlet	32-33 6 Cyl
37066	Gauge Assy-Gas Tank (Use 38904 for Essex-38696 for Hudson)	32 Hudson-Essex
C 37068	Pan Assy-Oil	32 Hudson-Essex
C 37071	Tray Assy-Oil Pan	32 Essex-Terr, 33 Hud-Terr
BM 37085	Suction Pipe Assy-Oil	32 Essex
BX 37090	Socket-Front Axle Tie Rod-RH	32-33 Hudson-Essex
BX 37091	Socket-Front Axle Tie Rod-LH	32-33 Hudson-Essex
BX 37092	Clamp-Front Axle Tie Rod Socket	32-33 Hudson-Essex
BX 37095	Bearing-Front Axle Tie Rod Stud	32-33 Hudson-Essex
BX 37096	Rubber-Front Axle Tie Rod Stud	32-33 Hudson-Essex
BX 37097	Spring-Front Axle Tie Rod Stud	32-33 Hudson-Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BX 37099	Stud and Washer Assy-Frt Axle Tie Rod	32-33 Hudson-Essex
BM 37101	Piston	32-33 Hudson
C 37104	Flywheel Assy	32-33 Hudson 8
BM 37106	Vibration Dampner Assy	32-33 Hudson
C 37118	Drive Shaft Assy-Rear Axle	32 Hudson-Essex
BX 37120	Oil Seal-Rear Axle Shaft	32-33 Hudson-Essex
BX 37122	Differential Gear-Rear Axle	32 Hudson-Essex
BX 37123	Housing Assy-Rear Axle Pinion	32-33 Hudson-Essex
	37131 Use 158917	
	37133 Use 43454	
	37135 Use 43456	
BX 37139	Dust Washer-Front Axle Tie Rod	32-33 Hudson-Essex
BM 37144	Gasket-Valve Chamber Cover	32 Essex
BX 37149	Dust Washer-Tie Rod-Upper	32-33 Hudson-Essex
BX 37150	Cover-Tie Rod Washer-Upper	32-33 Hudson-Essex
BX 37151	Cover-Tie Rod Stud Dust Washer-Lower	32-33 Hudson-Essex
C 37171	Tray Assy-Oil Pan	32-33 Hudson,33 Terr
BM 37174	Plunger-Oil Pump	32-33 Hudson-Terr,32 Essex
BM 37180	Belt-Fan-	32 Essex
BM 37185	Suction Pipe Assy-Oil Pump.	32-33 Hudson
*BM 37192	Cover Assy-Cyl Water Jacket	32 Essex
	37196 Gasket-Cyl Water Jacket Cover (Use 161750)	32 thru 38 6 Cyl
	37198 Use 44093	
BM 37223	Gasket-Cylinder Head-6 Cylinder	33 Hudson,32 Essex,32-33 Terr
C 37230	Shaft Assy-Propeller	32-33 Hudson-Essex
	37234 Bearing-Crankshaft-Upper-#1 (Use 157964)	32 thru 39 6 Cyl
	37234 Reamed-Use 157980	
	37235 Bearing-Crankshaft-Lower-#1 (Use 162534)	32 thru 39 6 Cyl
	37235 Reamed-Use 157980	
	37236 Shim-C/Shaft Brg-Thin (Use 161759)	32 thru 38 6 Cyl
	37237 Shim-C/S Brg-#1 Thick (Use 161760)	32 thru 38 6 Cyl
	37238 Use 35077	
BM 37239	Bearing-Crankshaft-Upper-#2	33 Hudson,32 Esx,32-33 Terr
BM 37239	Reamed	
BM 37240	Bearing-Crankshaft-Lower-#2	33 Hudson,32 Esx,32-33 Terr
BM 37240	Reamed	
	37241 Shim-C/Shaft Brg-Thin (Use 161761)	32 thru 38 6 Cyl
	37242 Shim-C/Shaft Brg-Thick (Use 161762)	32 thru 38 6 Cyl
	37243 Use 42512	
BT 37250	Finger-Clutch Throwout	32-33 Hudson-Essex
BT 37254	Cover-Clutch	32-33 Hudson-Essex
BT 37255	Gasket-Clutch Cover	32-33 Hudson-Essex
BT 37256	Bearing-Clutch Throwout	32 Hudson-Essex
BT 37257	Oil Seal-Clutch Bearing	32-33 Hudson-Essex
	37258 Use 42522	
BT 37267	Gear Assy-Trans Countershaft Low & Rev	32-33 Hudson-Essex
BT 37268	Gear Assy-Transmission Idler	32-33 Hudson-Essex
BT 37270	Ball-Oil Check Valve	32 thru 1947 All, 1948 thru 1950 8 Cyl
BT 37275	Oil Seal-Transmission	32-33 Hudson-Essex
BT 37278	Washer-Trans Mainshaft Gear-Front	32-33 Hudson-Essex
BT 37279	Washer-Trans Countershaft Low & Rev Gr	32-33 Hudson-Essex
BT 37281	Countershaft-Transmission	32-33 Hudson-Essex
BT 37286	Bushing-Countershaft Low & Rev Gear	32-33 Hudson,32 Essex
BT 37292	Gasket-Speedometer Gear-Hsg	32-33 Hudson,32 Essex
BT 37295	Sleeve-Trans Mainshaft Second and High	32-33 Hudson
BM 37317	Gauge Assy-Oil Lever	32-33 6 Cyl
BT 37320	Mainshaft Assy-Transmission	32-33 Hudson-Essex
BM 37323	Gasket-Cylinder Head	32-33 Hudson 8
BM 37324	Oil Throw-Crankshaft-Upper	32-33 Hudson-Essex
BM 37326	Oil Throw-Crankshaft-Lower	32-33 Hudson-Essex
BM 37327	Gasket-Crankshaft Oil Throw-Upper	32 thru 1947 All, 1948 thru 1950 8 Cyl
BM 37328	Gasket-Crankshaft Oil Throw-Lower	32 thru 1947 All, 1948 thru 1950 8 Cyl
BM 37334	Bearing-Crankshaft-Upper-#1	32 thru 39 8 Cyl
	37334 Use 157983 Reamed	
BM 37335	Bearing-Crankshaft-Lower-#1	32 thru 39 8 Cyl
	37335 Use 157983 Reamed	
	37336 Shim-Thin-Crankshaft Bearing #1 (Use 161765)	32 thru 1940 8 Cyl
	37337 Shim-Crankshaft Brg #1-Thick (Use 161766)	32 thru 37 8 Cyl
BM 37338	Bearing-Cap Assy-Crankshaft-#3	32 thru 39 8 Cyl
BM 37339	Bearing-Crankshaft-Upger-#2	32 thru 39 8 Cyl
	37339 Use 157984 Reamed	
BM 37340	Bearing-Crankshaft-Lower-#2	32 thru 39 8 Cyl
	37340 Use 157984 Reamed	
	37341 Shim-C/Shaft Brg #2 & 4-Thin (Use 161767)	32 thru 38 8 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
37342	Shim-Thick-Crankshaft Bearing-#2 & #4 (Use 161768)	32 thru 1940 8 Cyl
BM 37343	Bearing Cap Assy-Crankshaft-#3	32 thru 39 8 Cyl
37344	Bearing-C/Shaft #3-Upper-Rmd (Use 157985)	32 thru 38 8 Cyl
BM 37345	Bearing-C/S-Lower-#3	32 thru 39 8 Cyl
37345	Bearing-C/S #3-Lower-Rmd (Use 157985)	32 thru 38 8 Cyl
BM 37346	Shim-Thin-C/S Bearing #3	32 thru 1940 8 Cyl
37347	Shim-C/S Brg #3-Thick (Use 161770)	32 thru 38 8 Cyl
BM 37348	Bearing Cap Assy-C/S-#4	32 thru 39 8 Cyl
BM 37349	Bearing-C/ S-Upper- #4	32 thru 39 8 Cyl
37350	Bearing-C/S-Lower #4 (Use 157986)	32 thru 38 Cyl
BM 37352	Bearing Cap-C/S-#5	34 thru 1940 8 Cyl
BM 37353	Bearing Cap Assy-C/S-#5	32 thru 39 8 Cyl
37354	Bearing-C/S-Upper #5 (Use 157987)	32 thru 38 8 Cyl
37355	Bearing-C/S-Lower #5 (Use 157987)	32 thru 38 8 Cyl
37358	Use 42522	
C 37363	Cross Member Assy-Frame	32 thru 33 Hudson-Essex
BT 37375	Sleeve F/W & Trans Mainshaft	32-33 Hudson-Essex
BT 37378	Drive Gear-Second and High Cl Sleeve	32-33 Hudson-Essex
BT 37381	Retainer-Trans Main Drive Gr Bearing	32 Hudson-Essex
BT 37383	Shift Fork-Trans Second & High Cl Sleeve	32-33 Hudson-Essex
BT 37385	Shift Fork-Trans Low & Reverse	32-33 Hudson-Essex
BT 37445	Speedometer Gear-4-7/11 to 1	32-33 6 Cyl
ET 37446	Speedometer Pinion-4-7/11 to 1	32-33 6 Cyl
BT 37459	Gasket-Transmission Cover	32-33 Hudson-Essex
BT 37462	Transmission Control Lever Assy	32-33 Hudson-Essex
BT 37468	Gasket-Fulcrum Cover-Trans	32-33 Hudson-Essex
BT 37470	Knob-Control Lever	32-33 Hudson-Essex
C 37480	Cross Member Assy-Frame-Front	32 Essex
BZ 37528	Return Spring-Hand Brake	32-33 Hudson-Essex
C 37534	Cable Assy-Front Brake to C/S	32-33 6 Cyl
37536	Cable Assy-Front Brake to C/S (Use 38995)	32 Essex
BT 37547	Lever and Cable Assy-Trans	32-33 Hudson-Essex
37548	Use 44272	
BT 37558	Lock Plunger Assy-F/W Control	32-33 Hudson-Essex
BT 37575	Spring-F/W Cable Lock Plunger	32-33 Hudson-Essex
BT 37596	Fulcrum Cover-Trans Cont Lever	32-33 Hudson-Essex
BZ 37611	Bracket-Brake Cable Support	32-33 Hudson, 32 Esx, 35 Hud-Terr
37631	Use 43557	
C 37634	Cable Assy-Front Brake to C/S	32-33 Hudson
BZ 37667	Gasket-Tank Cap	32 thru 1947 All
BZ 37677	Starting Crank	32 Hudson-Essex
BZ 37678	Extension-Starting Crank	32 Hudson-Essex
BZ 37700	Electrolock Assy	32 Essex
BZ 37701	Electrolock Assy	32 Hudson
C 37708	Drag Link Assy	32-33 Hudson 8
BZ 37718	Socket-Drag Link	33 Hudson 6, 32 Essex
BM 37725	Pad-Engine Mtg-Rear	32 Hudson-Essex
C 37736	Cable Assy-Rr Brake to C/S	32 Hudson L
BO 37737	Switch-Stop Lamp	32 Hudson-Essex
BM 37739	BOse-Radiator Outlet	32 Essex
BM 37758	Stud-Cylinder Head-SBOrt	32 Essex-Terr
37760	Use 42961	
BM 37762	Stud-Cylinder Head-Long	33 Hud 6, 32 Essex-Terr
BM 37764	Stud-Cylinder Head	32 thru 35 Hudson, 84, 85, 87, 1948-1949 8 Cyl
BM 37766	Cover Complete-Cyl Water Jacket	32-33 Hudson
37775	Body-Oil Check Valve (Use 301547)	32-33-34-35 Hud, 32 Esx, 33-34-35 Terr
MF 37776	Contact Pin Assy-Oil Check Valve	32 thru 1947 All, 1948 thru 1950 8 Cyl
MF 37777	Gasket-Oil Check Valve Pin	32 thru 1947 All, 1948 thru 1950 8 Cyl
BM 37787	Spring-Oil Check Valve	32 thru 1947 All, 1948 thru 1950 8 Cyl
BZ 37788	Filler Cap-Radiator	32-33 Hud, 32 Esx, 32-33 Terr
BM 37791	Nut-Oil Check Valve Contact Pin	32 thru 1947 All, 1948 thru 1950 8 Cyl
C 37798	Core Assy-Radiator	32-33 Hudson 8
BZ 37815	Bolt-Wheel Hub	32-33 Hudson
BZ 37816	Bolt-Wheel Hub	32-33 Hudson
BZ 37817	Hub-Cap-Wood Wheel-Outer-Prime	32 Essex
BZ 37818	Hub Cap-Wood Wheel-Outer-Prime	32 Hudson
BZ 37827	Carrier Assy-Hub Cap	32-33 Hudson 8
BZ 37860	Bolt-Wire Wheel Hub	32 All, 33-34 Hudson
BZ 37861	Hub Cap-Wire Wheel-Outer-Prime	32 Essex
BZ 37868	Hub & Brg Cup Assy-Frt-Wire & Wood Whls	33 Hudson 6, 32 Essex-Terr
BZ 37878	Rivet-5/16 x 1-1/8	32 thru 1946 All
BZ 37882	Cover-Inspec BOle-Brake Drum	32-33-34-35 Hud, 32-34 Terr
C 37940	Manifold Assy-Exhaust	32 Essex
BM 37946	Spring-Exhaust Damper	34 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 37947	Retainer-Damper Spring	34 thru 1947 with Automatic Damper, 1948 thru 1950 8 Cyl
BM 37949	Stud-Damper Spring	34 thru 1947 with Automatic Damper, 1948 thru 1950 8 Cyl
BX 37970	Bracket-Brake Conduit	32-33 Hudson, 32 Essex
BX 37971	Guide Assy-Brake Anchor Pin	32-33 Hudson-Terr
BX 37975	Cam Lever-Brake-RH	33 Hudson 6, 32 Essex
BX 37976	Cam Lever-Brake-LH	33 Hudson 6, 32 Essex
F 37977	Eccentric Assy-Brake	32 Esx, 32 thru 38 Hud exc 89, 36 thru 38 Terr, 91 thru 98, 90 Cab-CabPu-Panel-Sta, 40C, 41 thru 47, 48 Sed, 10C
BX 37982	Adjusting Screw-Brake	32-33 Hudson, 32 Essex
BX 37983	Pivot Nut-Brake Adj Screw-RH	32-33 Hudson, 32 Essex
BX 37984	Pivot Nut-Brake Adj Screw-LH	32-33 Hudson, 32 Essex
BX 37985	Spring-Brake Adj Screw	32 Esx, 32 thru 1942 Hud 8, 43, 10C, 53, 54, 58, 173, 174, 178, 1948 thru 1950 All
BX 37986	Spring-Brake Cam Lever	32-33 Hudson, 32 Essex
BX 37997	Hold Down Spring-Brake Shoe	32 thru 37 All
BX 37998	Pin-Brake Shoe Spring	32-33-34-35 Hud-Terr, 32 Essex
F 37999	Cup-Brake Shoe Spring	32 thru 1950 All
38000	Cup-Brake Shoe Spring (Use 37999)	32 thru 1949 All
BX 38001	Spring-Small-Brake Shoe	33 Hudson 6, 32 Essex
BX 38002	Spring-Large-Brake Shoe	33 Hudson 6, 32 Essex
38007	Gasket-Intake Man to Carb Riser (Use 48589)	33 Hud 8, 32 Essex, 32 thru 34 Terr 6
BM 38023	Pipe Assy-Oil Pan Oil Return	32 thru 1947 6 Cyl
38031	Use 151823	
BZ 38032	Cup Washer-Muffler Grommet	32 thru 36 All
BM 38033	Hose-Radiator Outlet	32-33 Hudson 8
38038	Gasket-Exh Manifold-End (Use 48582)	32 thru 35 6 Cyl
F 38039	Gasket-Exh Manifold-Center	32 thru 35 6 Cyl
F 38044	Gasket-Carb Riser to Exh Man	33 Hudson 6, 32 Essex
BZ 38045	Cap-Wheel Hub-Inner	33 Hudson 6, 32 Essex
BZ 38046	Cap-Wheel Hub-Inner	32-33 Hudson
BO 38056	Electrolock Cylinder Assy	32-33 Hudson, 32 Essex
BO 38057	Key-Electrolock and Door Lock	32-33 All
BZ 38059	Bolt-Rear Spring-Rear	32-33 Hudson-Essex
BZ 38060	Bolt-Front Spring-Front	32-33 Hudson-Essex
BT 38067	Sleeve-Trans Speedometer Pinion	32 thru 37 All
BM 38088	Stop-Exhaust Damper Cover	32 thru 1947, 1948 thru 1950 8 Cyl
BM 38089	Bushing-Exhaust Damper Shaft	32 thru 1950
F 38090	Gasket-Exhaust Damper Cover	32 thru 37 except G-61-70-71-78
BZ 38091	Bolt-Rear Spring	32-33 Hudson-Essex
BT 38094	Spring-Anti Rattle-Control Lever	32-33 Hudson-Essex
BM 38109	Cover-Exhaust Pipe	32-33 Hudson
38163	Muffler Assy-Rear (Use 45240)	32-33 Hudson
BZ 38171	Bracket-Tail Pipe-Front	32 Essex, 33 Hudson 6
38173	Use 39044	
38174	Use 42572	
BZ 38177	Connecting Pipe-Muffler	32 Essex
38181	Use 39040	
C 38182	Tail Pipe-Muffler	32 Essex
BZ 38183	Clamp-Muffler Conn Pipe	32 Hudson E, 32 Essex
BZ 38184	Bracket-Tail Pipe Rear	32-33 Hudson, 32 Essex
38202	Use 150710	
BZ 38206	Spring Washer-Acc Pedal HDM Shift Switch	32 thru 1950 All
BZ 38208	Bell Crank Bracket-Hand Throttle & Pedal Link	32 thru 38 All
BZ 38209	Anchor Bracket-Acc Pedal	32 thru 37 All
BO 38236	Switch Assy-Lighting	32-33 All
BO 38237	Switch-Inst Panel Light	32 Hudson-Essex
BO 38238	Switch-Gas & Oil Gauge	32-33 Hudson, 32 Essex
BZ 38293	Connecting Link	32 Hudson
C 38355	Cable Assy-Rr Brake to Cross Shaft	32 Hudson T
BO 38368	Junction Block Assy-2 Post	32-33 Hudson-Essex
BO 38480	Wire Assy-Horn	32 Hudson-Essex, 33 Hudson 6
BM 38513	Cover-Exhaust Pipe-Center-Right	32-33 Hudson
38546	Conn Rod-RH (Use 166500)	32 All, 33 8 Cyl
38547	Conn Rod-LH (Use 166501)	32 All, 33 8 Cyl
BM 38554	Bracket-Horn	32 All
BM 38555	Stud-Cyl Head	32 thru 35 Hudson, 34 Terr
BX 38567	Cover Assy-R/A Housing	30-31-32 Hud-Essex, 33 Hudson
BZ 38587	Plug-Strg Gear Housing	32 thru 1950 All
BZ 38599	Ball Arm-Strg Gear	32-33 Hudson 8
BZ 38603	Shaft-Steering Gear	32-33 Hudson
BZ 38624	Button-Horn	32-33 Hudson-Essex
BM 38631	Piston Ring-Compression	32 thru 35 Terr
BM 38635	Piston Ring-Oil-Lower	32 thru 35 Terr
C 38670	Spring Assy-Front	33 Hudson 6, 32 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
38696	Gauge Assy-Gas Tank	32-33 Hudson
BX 38751	Lining & Rivets Pkg	29-30-31 Essex-Comm
38752	Use 48245	
38756	Use 46825	
38760	Use 60719	
38762	Shim-C/S Brg-Rear-Thin (Use 161763)	32 thru 38 6 Cyl 3
38763	Shim-C/S Brg-Rear-Thick (Use 161764)	2 thru 38 6 Cyl
38764	Shim-Thin-C/S brg-Rear (Use 161771)	32 thru 1940 8 Cyl
38765	Shim-Thick-C/S Brg-Rear (Use 161772)	32 thru 1940 8 Cyl
BX 38798	Tie Rod Sockets-Pkg	32-33 Hudson,32 Essex
38813	Use 151578	
C 38838	Tube & Worm Assy-Strg Gear	33 Hudson 6,32 Essex
C 38840	Tube & Worm Assy-Strg Gear	32-33 Hudson 8
BT 38884	Clip-Wire	1942-1946-1947 with VD or HDM
38904	Gauge Assy-Gas Tank	32 Essex
BO 38909	Wire Clip	34 thru 39 All
38926	Use 64289 and 110	
38927	Use 64289 and 110	
BT 38941	Guide-Lock Strap	32-33 Hudson,32 Essex
BM 38948	Reinforcement-Oil Throw Lower	32 thru 1947 All, 1948 thru 1950 8 Cyl
BM 38957	Gasket-Water Manifold	32-33 Hudson
38977	Use 39264	
BM 38978	Ignition Wire Assy-Boxed	30 thru 33 Hudson 8
BT 38987	Strap-Gear Shift Lock	32-33 Hudson,32 Essex
BT 38993	Cap-Gear Shift Lock Spring	32 thru 35 All,89,90,98
C 38995	Cable Assy-Rear Brake to C/Shaft	33 Hudson 6,32 Essex
C 38996	Cable Assy-Rear Brake to C/Shaft	32 Hudson, 33 Hudson 6
39001	Link-Brake Pedal Rod	32 Hudson-Essex,33 Hudson T-L
C 39004	Drive Shaft Assy-R/A	32-33 Hudson,32 Essex
C 39040	Tail Pipe-Muffler	32 Hudson 6,32 Essex
	Spring-Clutch Pedal	32 Hudson-Essex
39041	Pipe Assy-Exhaust	32 Essex
C 39044	Bushing-Steering Gear Shaft	32-33 Hudson
	Stud-Strg Gear Housing	32 thru 36 RHD
39090	Use 37701	
	Primary Post Assy-Electrolock	33 Hudson
39117	Ignition Wire Assy-Boxed	28-29 Hudson,28 thru 32 Essex
	Use 160330	
39215	Camshaft (Use 1-152644, 12-43806, 1-43723,	
BM	4-40110, 1-48435)	32-33 Terr 6
39227	Spindle-F/A Strg-RH	32 Terr
	Spindle-F/A Strg-LH	32 Terr
39264	Thrust Plate-Camshaft (Use 23625)	33 thru 1939 All,1932 Terr
	Washer -Strg Spindle	32 thru 35 Terr,34-35 Hud
40001	Use 42144	
	Use 42145	
40003	Use 42143	
BX	Shim-Thin-Pivot PM	32 thru 36 Terr,34 thru 36 Hudson
40004	Shim-Thick-Pivot Pin	32 thru 36 Terr,34 thru 36 Hudson
BX	Use 43797	
40005	Use 43797	
	Use 43797	
40006	Grease Washer-F/A Strg Spindle (Use 43797)	32 thru 37 Terr,34 thru 37 Hudson
BX	Steering Arm-RH	32 Terr
40008	Steering Arm-LH	32 Terr
	Clip-Gas Tank (Use 164071)	32 thru 38 Terr,36 thru 1942 Hudson
40013	Use 45142	
	Pressure Plate-Clutch	32-33 Terr
40014	Throwout Finger-Clutch (Use 166248)	32 thru 38 Terr,34 thru 1941 Hudson,20-21 without VD-OD-HDM
40015	Pin-Throwout Finger	32-33-34-35 Terr,34-35 Hudson
BX	Retainer-Clutch Finger (Use 166249)	32 thru 38 Terr,34 thru 1942 Hudson
40017	Use 48595	
BX	Spring-Clutch Engaging	32-33 Terr
40018	Cover-Clutch (Use 166252)	32 thru 37 Terr,35 thru 37 Hud 6,80 Co-Cpe-Sed,81 All, All X Engines,90,92,98 Sed,40,41,48 5Sed,10-20-21-
40019	Gasket-Clutch Cover	32 thru 37 Terr,35 thru 37 Hud 6,80 Co-Cpe-Sed,81 All, All X Engines,90,92,98 Sed,40,41,48 5Sed,10-20-21-51-52-171-172 without VD-OD or HDM,500 without HDM or SMD
40020		
40021	Oil Seal-Clutch Bearing	32 thru 38 Terr,34 thru 1950 Hudson
	Use 41258	
40022	Collar Assy-Clutch (Use 303855)	32 Terr
BX	Housing Assy-Clutch	32-33-34 Terr,34 Hudson
40023		
BX		
40024		
40029		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 40055	Yoke-Clutch Shifter	32 thru 38 Terr,34 thru 1950 Hudson
BT 40058	Lever-Clutch Shaft	32-33 Terr
40059	Use 45544, 44675 and 44677	
BT 40061	Snap Ring-Trans Bearing	32 thru 38 Terr,34 thru 39 Hud,1940 All Without Overdrive
BT 40070	Pinion-Speedometer	32-33-34 Terr,34 Hudson
TF 40079	Gasket-Trans Case	32 thru 38 Terr,34 thru 1940 Hudson
BT 40081	Retainer-Trans Bearing	32 Terr
BT 40082	Shim-Thin-Trans Brg	32 thru 38 Terr,34 thru 1940 Hudson
40083	Shim-Thick-Trans Brg (Use 3-40082)	32 thru 38 Terr,34 thru 1940 Hudson
TF 40084	Oil Seal-Trans Drive Gear Brg	32 thru 38 Terr,34 thru 1940 Hudson
BT 40086	Gear Assy-Trans Main Drive	32 Terr
BT 40088	Bushing-Drive Gear	32-33 Terr
BT 40089	Gear Assy-Main Shaft Inter	32 Terr
BT 40091	Bushing-Inter Gear	32 Terr
BT 40093	Thrust Washer-Rear-Trans	32 thru 38 Terr,34 thru 1940 Hud
BT 40094	Retainer-Thrust Washer	32-33 Terr
40095	Mainshaft-Trans (Use 42918 & 42919)	32 Terr,33 K
BT 40096	Thrust Washer-Trans Mainshaft	32 Terr
40097	Use 42123	
BT 40098	Retainer-Low and Rev Gear	32-33 Terr
BT 40099	Bearing-Trans Mainshaft	32 Terr
F 40100	Countershaft-Trans	32-33-34 Terr,34 Hudson
BT 40101	Bushing-Front-Trans Countershaft	32-33-34-35 Terr,34-35 Hudson
BT 40102	Bushing-Rr-Trans Countershaft	32-33-34-35 Terr,34-35 Hudson
40103	Use 44172	
40105	Shim-Cntr Sha Cap-Thin (Use 160591)	32 thru 38 Terr,34 thru 38 Hudson
40106	Shim-Cntr Sha Cap-Thick (Use 160592)	32 thru 38 Terr,34 thru 38 Hudson
BT 40107	Gasket-Countershaft Cap	32 thru 38 Terr,34 thru 1940 Hudson
BT 40108	Drive-Gear-Countershaft	32 Terr
BT 40109	Inter Gear-Countershaft	32 Terr
BO 40110	Gasket-Fuel Pump to Cyl	32-33 Terr,33 Hudson 6
40111	Use 42126	
*BT 40112	Thrust Washer-Countershaft	32 thru 37 Terr,34 thru 37 Hudson
BT 40113	Retainer-Countershaft Gear	32-33-34 Terr,34 Hudson
BT 40114	Spacer-Countershaft Washer	32-33 Terr
BT 40115	Shaft-Reverse Idler	32-33 Terr
BT 40116	Lock Screw-Rev Idler Shaft	32 Terr
BT 40117	Gear Assy-Reverse Idler	32-33 Terr
BT 40119	Bushing-Reverse Idler Gear	32-33 Terr
BT 40120	Shift Rail-Low & Reverse	32-33-34-35 Terr,34-35 Hud
BT 40121	Shift Rail-Second & High	32-33-34-35 Terr,34-35 Hud
BT 40122	Interlock-Shift Rail	32 thru 38 Terr,34 thru 1950 Hudson
40123	Use 152696	
40125	Use 47298 and 152698	
BT 40126	Lever-Low & Reverse-Inter	32 thru 38 Terr,34 thru 1940 Hudson
BT 40127	Stud-Low & Reverse Lever	32 thru 38 Terr,34 thru 1940 Hudson
BT 40128	Fork Assy-Low & Reverse	32-33 Terr
BT 40130	Shaft-Low & Reverse Fork	32-33 Terr
F 40133	Oil Seal-Spdo Gear Hsg	32 thru 38 Terr,34 thru 1940 Hudson
BT 40134	Gasket-Spdo Housing	32-33 Terr
BT 40135	Companion Flange	32 Terr
BT 40136	Washer-Flange Screw	32 thru 38 Terr,34 thru 38 Hudson
40137	Use 40101	
40146	Use 165907	
F 40147	Gear-Crankshaft	32-33-34-35 Terr,33 Hud 6,34-35 Hudson
40148	Use 166307	
F 40150	Gasket-Timing Gear Cover	32 thru 38 Terr,33 Hud 6,34 thru 1947 Hud
40151	Oil Seal-Timing Gear Cover (Use 302858)	32 thru 38 Terr,33 Hud 6,34 thru 1949 Hud
BM 40153	Cover-Valve Chamber	32-33 Terr,33 Hudson 6
BM 40154	Gasket-Valve Cover	32-33 Terr,33 Hudson 6
C 40155	Pan Assy-Oil	32-33 Terr
BX 40157	Lock-Drive Gear Screw	32 thru 38 Terr,34 thru 38 Hud,90
BX 40161	Gear and Pinion-R/A 4-1/9 to 1	32 Terr
BX 40165	Gear & Pinion-R/A 4-5/9 to 1	32-33 Terr
BX 40172	Grease Deflector-F/A	32 thru 38 Terr,34 thru 1950 Hudson
BX 40175	Oil Seal-Adj Cap R/A Wheel	32 Terr
BX 40176	Shim-Thin-R/A Wheel Bearing	32-33-34-35 Terr
BX 40177	Shim-Medium-Whl Bearing	32-33-34-35 Terr
BX 40178	Shim-Thick-Whl Bearing	32-33-34-35 Terr
BX 40181	Thrust-Drive Shaft Washer Spacer	32 thru 38 Terr,34 thru 1950 Hudson
BX 40182	Washer Assy-Drive Shaft	32 Terr
BX 40183	Washer-Felt-Drive Shaft	32 Terr
40184	Use 40182	
40185	Retainer-Outer Washer (Use 40182)	32 Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
40186	Use 42576	
BX 40189	Gear-Differential	32 Terr
40190	Pinion-Diff (Use 152677)	32-33 Terr,34 thru 37 All
40191	Shaft-Diff Pinion (Use 157553)	32 thru 38 Terr,34 thru 38 Hudson
BX 40192	Retainer-R/A Bearing Shim	32 thru 38 Terr,34 thru 39 Hudson,90
40194	Lock-Bearing Adj Nut (Use 150488)	32-33-34-35 Terr,34-35 Terr,34-35 Hudson
40199	Gasket-Diff Carrier (Use 44584)	'32-33 Terr
BX 40212	Shim-Thin-Pinion Bearing	32 thru 38 Terr,34 thru 38 Hudson,90
BX 40213	Shim-Thick-Pinion Bearing	32 thru 38 Terr,34 thru 38 Hudson,90
BX 40215	Shim-Thin-Bearing Spacer	32-33 Terr
BX 40216	Shim-Medium-Bearing Spacer	32-33 Terr
BX 40218	Oil Seal-Pinion R/A	32 Terr
BX 40219	Oil Baffle-Pinion	32-33 Terr
BX 40220	Companion Flange	32 Terr
C 40221	Control Assy-Transmission	32-33-34-35 Terr,34-35 Hudson
BT 40222	Cover Assy-Trans	32 thru 38 Terr,34 thru 38 Hud,90,98,91 Panel
BX 40224	Pin-Control Lever	32 thru 38 Terr,34 thru 38 Hud,90,98,91 Panel
40226	Gasket-Trans Cover (Use 159039)	32 thru 38 Terr,34 thru 38 Hudson
40227	Use 42976	
BT 40232	Fulcrum-Control Lever	32 thru 38 Terr,34 thru 38 Hudson,90,98
BT 40233	Oil Seal-Control Lever	32 thru 38 Terr,34 thru 38 Hud,90,98,91 Panel
BT 40234	Washer-Trans Lever	32 thru 38 Terr,34 thru 38 Hud,91 Panel
BT 40235	Spring-Control Lever	32 thru 38 Terr,34 thru 38 Hud,90,98,91 Panel
40242	Use 44062	
BM 40243	Body Assy-Water Pump	32-33 Terr,33 Hudson 6
F 40245	Gasket-Water Pump Body	32-33-34-35 Terr,33 Hud 6,34-35 Hud
BM 40248	Bearing-W/Pump Shaft	32-33-34 Terr,33 Hud 6,34 Hud
BM 40249	Felt-W/Pump Shaft Brg	32-33-34 Terr,33 Hud 6,34 Hurl
BM 40250	Bearing Assy-W/Pump Shaft	32-33-34-35 Terr,33 Hud 6,34-35 Hud
40252	Use 40250	
40253	Use 40250	
BM 40254	Thrust Washer-W/Pump Shaft	32-33 Terr
F 40255	Impeller-W/Pump Shaft	32-33-34 Terr,33 Hud 6,34 Hud
40256	Use 45277	
F 40257	Retainer-W/Pump Packing	32-33-34-35 Terr,33 Hud 6,34-35 Hud
BM 40258	Nut-W/Pump Packing	32-33 Terr,33 Hudson 6
BM 40259	Fan Blade	32-33 Terr,33 Hudson 6
F 40260	Fan Belt	32-33-34-35 Terr With Std Head
40261	Use 42100, 42900, 42108 and 42153	
C 40263	Gas Tank Assy	32-33 Terr
40280	Bolt-Flywheel (Use 300264)	32 thru 38 Terr,34 thru 1947 Hudson
BM 40281	Drain Plug-Flywheel	32 thru 38 Terr,34 thru 1950 Hudson
BM 40282	Dowel Pin-Flywheel Cl Cover	32 thru 38 Terr,34 thru 1950 Hudson
BM 40284	Starting Jaw-Crankshaft	32-33 Terr,33 Hudson 6
BM 40285	Vibration Dampner Assy	32-33 Terr
MF 40286	Spacer-Vibration Dampner	32 thru 38 Terr,34 thru 1950 Hudson
BM 40287	Pulley-Vibration Dampner	32-33-34 Terr, 33 Hudson 6
BM 40288	Oil Pump-Complete	32-33 Terr,33 Hudson 6
BM 40292	Bushing-Oil Pump Shaft	32-33 Terr,33 Hudson 6
BM 40293	Screw-Oil Pump Shaft Bushing	32 thru 38 Terr,34 thru 1947 Hudson 1948 thru 1950 8 Cyl
BM 40294	Gear-Oil Pump	32-33 Terr,33 Essex
40295	Use 301547	
BM 40296	Body-Check Valve	32 thru 38 Terr,34 thru 1947 Hudson 1948 thru 1950 8 Cyl
BM 40297	Hose-Rad Outlet	32-33 Terr
BZ 40298	Pipe-Rad Hose-Outlet	32-33 Terr
40301	Pad Assy-Brake Pedal	32 thru 37 Terr,34 thru 37 Hudson
TF 40308	Bushing-Clutch Yoke	33 thru 38 Terr,34 thru 1950 Hudson
BZ 40309	Shaft-Pedal Lever	32 K,33 K-KT,34 thru 36 All
BZ 40313	Bumper-Pedal Toe Plate	32-33 Terr,33 Hudson
40314	Bearing Cap Assy (Use 40315 & 157980)	32 thru 38 Terr,33 thru 38 Hud 6,92,93,98
BZ 40315	Bearing Cap #1	32 thru 38 Terr,35 thru 38 Hud,6,92,93,98
BZ 40317	Spring-Clutch Control	32 thru 37 Terr,34 thru 37 Hudson
BZ 40319	Pad Assy-Clutch Pedal-RHD	32 thru 36 Terr,34 thru 36 Hudson
C 40331	Cylinder & Piston Assy	32-33 Terr
*BM 40332	Cover-Cyl Water Jacket	32-33 Terr,33 Hudson 6
40337	Support Assy Cyl (Use 42787 & 71251)	32 Terr,33 Hudson 6
F 40339	Gasket-Cyl Support Plate	32 thru 38 Terr,33 Hud 6,34 thru 1947 Hud
40341	Use 159551	
F 40342	Gasket-Cyl Support Rear	32 thru 38 Terr,34 thru 39Hud,1940 thru 1947 8 Cyl
BM 40343	Dowel-Cyl Supp Plate	32 thru 38 Terr,34 thru 1950 Hudson
BM 40346	Stud-Long Cyl Head	32-33 Terr
BM 40351	Damper-Exhaust	32-33-34 Terr,34 Hud LTS,35G,61
BM 40352	Gasket-Exhaust Damper	32-33-34 Terr,34 Hud LTS,35G,61

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	Link-Clutch Control	32 Terr
BZ 40364	Use 41067 & 41066	
40368	End-Brake Pedal Rod	32-33 Terr
BZ 40387	Cable Assy-Front Brake	32-33 Terr
C 40389	Cable Assy-Rear Brake	32-33 Terr
C 40391	Use 40701	
40392	Use 41108	
40398	Bracket-Rear-Muffler	32 thru 36 Terr
BZ 40404	Use 43016	
40407	Gasket-Exhaust Flange	32 thru 36 Hudson 6 Terr
BZ 40412	Lock-Exhaust Flange Nut	32 thru 38 Terr,34 thru 1947 Hudson,1948 thru 1950 8
BZ 40413	Boot Assy-Drag Link (Use 152776)	Cyl LHD
40415	Guard-Flywheel.	32 thru 37 Terr,34 thru 37 Hudson
A 40424	Gasket-Valve Cover Screw	32 thru 38 Hud 6 & Terr,1946-1947 6 Cyl
BM 40429	Silencing Spring-Acc Cross Shaft & Hyd Top	32 thru 1950 6 Cyl
BZ 40436	Control & VD Bellcrank Rod Link	34 thru 1949,1950 CvBro,1950 with HDM or SMD
BZ 40439	Link-Acc Pedal .	32 thru 35 Terr,34-35 Hudson
BZ 40443	Spring-Acc to Carb	32-33 Terr,36 Terr 61
BZ 40445	Bushing-Front Spring	32-33 Terr
BZ 40450	Bushing-Front Spring	32-33 Terr
40462	Drag Link Assy (Use 40468)	32-33 Terr
C 40463	Drag Link Assy-RHD	32-33 Terr
40464	Use 40468	
BZ 40466	Dust Cover-Inner	32-33 Terr
BZ 40467	Dust Cover-Outer	32-33 Terr
C 40468	Drag Link	32-33 Terr
BM 40474	Pipe Assy-Suction	32 Terr
BM 40476	Elbow-Oil Pipe	32-33 Terr
BZ 40479	Cup-Engine Support Grommet	34 thru 1947 All
40485	Use 41108	
BZ 40496	Bracket-Front Spring	32 Terr
BZ 40497	Pin-Spring Shackles	32-33 Terr
BZ 40498	Bracket-Front Spring	32-33 Terr
BZ 40499	Reinforcement-Spring Bracket	32-33 Terr
BZ 40500	Bracket-RH-Rear Spring	32-33 Terr
BZ 40501	Bracket-LH-Rear Spring	32-33 Terr
BZ 40504	Nut-Battery Clamp	32 thru 36 Terr,34 thru 36 Hudson
40509	Bumper-Rear Axle (Use 42246)	32 Terr
BZ 40514	Battery Seal	32 thru 36 Terr,34 thru 36 Hudson
BZ 40515	Bracket-Battery Bolt	32 thru 36 Terr,34 thru 36 Hudson
BZ 40516	Insulator-Battery Bolt	32-33 Terr
C 40521	Core Assy-Radiator	32-33 Terr K
40524	Use 41117	
BZ 40526	Pipe Assy-Gas Tank	32-33-34-35 Terr
F 40529	Flexible Connection-Fuel Pump	32 thru 36 Hudson 6-Terr
BZ 40532	Seal-Flange Screw-Trans	32 thru 38 Terr,34 thru 1940 Hudson
40536	Use 43617	
40548	Hub Bolt-Wire Wheel (Use 42964)	32 Terr
40549	Use 40999	
BZ 40558	Hub Cap-Inner	30 thru 38 Terr,34 thru 1950 Hudson
40573	Use 157938	
40574	Use 46718	
40575	Use 46720	
40576	Use 42745	
BZ 40578	Bumper-Front Spring	32 Terr
BZ 40579	Retainer-Spring Bumper	32 thru 35 Terr,34-35 Hudson
BZ 40580	Clip-Front Spring	32 Terr
BZ 40581	Shackle-Spring-Inner	32-33 Terr
BZ 40582	Shackle-Spring-Outer	32-33 Terr
BZ 40583	Bolt-Shackle	32-33 Terr
BZ 40584	Spring-Shackle Tension	32-33 Terr
BZ 40585	Lock-Shackle Nut	32-33 Terr
BZ 40586	Bolt-Front Spring	32-33 Terr
BZ 40587	Lock-Spring Bolt	32-33 Terr
BZ 40588	Clip-Spring	32 Terr
BZ 40593	Bolt-Shackle	32-33 Terr
BM 40596	Gear-Distributor Drive	32 thru 1947 All, 1948 thru 1950 8 Cyl
BM 40602	Pulley-Generator	32-33 Terr,33 Essex,34 KS-LTS
BM 40607	Lock-Ignition Coil	32-33 Terr
BM 40609	Stud-Starting Motor	32 thru 38 Terr,34 thru 1940 Hudson
C 40614	Cylinder Head Assy	32-33 Terr
BZ 40619	Spring-Shackle Tension	32-33 Terr
40626	Use 48590	
BZ 40627	Washer-Gas Tank Strap	32 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 40633	Tube-W/Shield Wiper Conn	34 thru 36 Hudson-Terr,71-73B
BM 40638	Sleeve-Eng Mtg Bolt	32 thru 38 Terr,33 thru 1947 Hudson
40639	Use 2-47121	
40640	Grommet-Lower-Eng Mtg (Use 2-47122)	32-33-34 Terr,33 Hud 6
40641	Use 42545	
BM 40642	Bolt-7/16 x 14 x 1-5/16"	33 thru 1948 All
BT 40662	Gear-Speedometer-4-1/9 to 1	32 thru 38 Terr,34 thru 1940 Hud,89 Comm
BT 40663	Pinion-Speedometer	32 thru 37 Terr,34 thru 37 Hudson
40668	Use 43356	
40674	Ground Conn-Clutch (Use 155776)	32 thru 37 Terr,34 thru 37 Hudson
BZ 40675	Ground Conn-Battery	32-33 Terr
40679	Pedal Assy-Acc (Use 150710-41207-71522)	32 Terr
BT 40682	Stud-Throttle Control Idler	32-33-34-35- Terr,34-35 Hudson
BZ 40684	Retainer-Throttle Control Rod	32-33 Terr
BZ 40688	Spring-Drag Link	32 thru 38 Terr Exc 89,34 thru 38 Bud, 92,93,95,97
BZ 40692	Wrench-Spark Plug	32 thru 38 Terr,34 thru 1947 Hudson
BZ 40693	Jack	32 thru 35 Terr,34-35 Hud,36 thru 1940 Cab-CabPu-Station,10-20 Cab-CabPu,1946-1947 Cab-CabPu
40694	Use 46172	
40695	Use 151578	
BZ 40701	Clip Assy-Cable Support	32-33 Terr
BZ 40705	Switch-Dimmer	32-33 Terr
40706	Bolt-Spring Center (Use 151885)	36 Hudson 8
BM 40707	Stud-Exhaust Manifold	32 thru 38 Hudson 6-Terr
F 40710	Gasket-Carb to Manifold	32 thru 37 Terr,73 B.80,81,88,89,90,92,98,40-10-20 with Std Engine,48,18,28
BX 40722	Bracket-Backing Plate Conduit	32-33-34 Terr,34 Hudson
EX 40723	Bracket-Backing Plate Conduit	32-33-34 Terr,34 Hudson
4072e	Use 48132	
EX 40730	Spring-Small-Anchor Pin	32-33-34-35 Terr,34-35 Hudson
BX 40731	Spring-Large-Anchor Pin	32 Terr
EX 40734	Spring-Cam Lever	32-33 Terr
BX 40735	Eccentric-Brake	32-33-34-35 Terr,34-35 Hudson
BZ 40737	Switch Assy-Stop Lamp	32-33 Terr
BZ 40738	Switch Assy-Stop Lamp RHD	32-33 Terr
F 40739	Screw-Brake Adj	32 thru 38 Terr,34-35 Hud,63,73,78,83,88,89,90,92,93,98,40,41,48,10,11,12,18,20,21,22,28,51,52,171,172
F 40740	Nut-Brake Adj	32 thru 38 Terr,34-35 Hud,63,73,78,83,88,89,90,92,93,98,40,41,48,10,11,12,18,20,21,22,28,51,52,171,172
40741	Socket-Brake Adj (Use 166706)	32 thru 38 Terr,34-35 Hud,63,73,78,83,88,89,90,92,93,98,40,41,48,10,11,12,18,20,21,22,28,51,52,171,172
F 40742	Spring-Brake Adj Screw	32 thru 38 Terr,34-35 Hud,63,73,78,83,88,89,90,92,93,98,40,41,48,10,11,12,18,20,21,22,28,51,52,171,172
BZ 40748	Housing-Cap-Steering Gear-Upper	32 thru 36 Terr,34 thru 36 Hudson
40749	Use 46050	
40750	Use 46051	
BZ 40751	Stud-Strg Gear Hsg Adj	32 thru 36 Terr,34 thru 36 Hudson
40752	Use 41085 & 41086	
BZ 40757	Gasket-Strg Gr Hsg Cover	32 thru 36 Terr,34 thru 36 Hudson
BZ 40758	Arm-Strg Gear Ball	32-33 Terr K
BZ 40759	Arm-Strg Gear Ball-RHD	32-33 Terr
BZ 40761	Shaft-Strg Gear-RHD	32-33-34-35 Terr,34-35 Hudson
BZ 40763	Thrust Washer-Strg Gear Shaft	32 thru 36 Terr,34 thru 36 Hudson
BZ 40764	Screw-Strg Gr Shaft Adj	32 thru 36 Terr,34 thru 36 Hudson
C 40765	Main Column & Worm Assy-Strg Gear	32-33 Terr K
C 40766	Main Column & Worm Assy-RHD	32-33-34-35 Terr,34-35 Hudson
C 40767	Tube-Main Column	32 thru 36 Terr,34 thru 37 Hudson
40768	Use 40767	
40772	Use 46900	
BZ 40773	Thrust Washer-Worm Brg Adj Ring-Upper	32 thru 36 Terr,34 thru 36 Hudson
BZ 40776	Bearing Assy-Worm	32-33-34-35 Terr,34-35 Hudson
BZ 40777	Ring-Steering Gear Worm Bearing	35 thru 39 All,1940 thru 1947 6 Cyl,500
40778	Use 151739	
C 40781	Jacket Tube Assy-Steering Gear	32 thru 36 Terr,34 thru 36 Hudson
BZ 40783	Bushing-Strg Gear Jacket Tube	32 thru 3f Terr,34 thru 36 Hud,89,90,98
BZ 40784	Horn Button	32 thru 36 Terr,34-35 Hudson
BZ 40785	Cover-Horn Button Control	32 thru 35 Terr,34-35 Hudson
BZ 40786	Cup-Horn Button Contact	32 thru 36 Terr,34 thru 36 Hudson
BZ 40787	Dusc-Horn Button Contact	33 thru 36 Terr,34 thru 36 Hudson
BZ 40788	Wire Assy-Horn Button	32 thru 35 Terr,34 Hudson
BZ 40789	Wire Assy-Horn Button RHD	32 thru 36 Terr,34 thru 36 Hudson
BZ 40790	Terminal-Horn Button Wire	32 thru 38 Terr,34 thru 1940 Hud,1941 Del
BZ 40791	Washer-Horn Button Wire	32 thru 36 Terr,34 thru 36 Hudson
BZ 40792	Washer-Seat-Horn Button Wire Insulating	32 thru 36 Terr,34 thru 36 Hudson
40796	Connector Assy-Wire-Single (Use 44093)	32-33 Terr,33 Hudson

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	40797 Use 44094	
BM	40852 Hammer	32 thru 1941 All
BZ	40853 Pliers	32 thru 1948 All
BZ	40854 Screw Driver	32 thru 1948 All
BZ	40859 Gasket-Gas Tank Gauge	32-33 Terr
	40868 Use 42836	
C	40875 Leaf #1-Rear Spring	32-33 Terr
BZ	40887 Clip-Spring-Rebound	32-33 Terr
	40889 Clip-Spring-Rebound (Use 40890)	32-33 Terr
BZ	40890 Clip-Spring-Rebound	32-33-34 Terr,34 Hudson
BZ	40891 Clip-Spring-Rebound	32-33 Terr
BZ	40892 Clip-Spring-Rebound	32 Terr,36Comm,1940 Spring #163049,1946-1947 Spring 165075
BZ	40893 Bolt-Spring Rebound Clip	32-33-34 Terr,34 Hudson
	40897 Use 43397	
C	40898 Cover-Cylinder Head	33 Hudson 6.32-33 Terr
F	40899 Gasket-Cylinder Head to Cover (Pkg 10)	32-33-34-35 Terr,33 Hud 6,35 Hud
BM	40900 Screw-Cylinder Head to Cover	32-33-34-35 Terr,34-35 Hudson
BM	40901 Stud-Cylinder Head	32 Terr
BZ	40906 Oil Seal-Steering Gear Shaft	32-33 Terr
BZ	40907 Retainer-Steering Gr Shaft Oil Seal	32-33 Terr
BZ	40909 Plug-Drag Link	32 thru 38 Terr,34 thru 38 Hud exc 89,92,93,95,97
BZ	40910 Seat-Drag Link Ball	32 thru 38 Terr,34 thru 38 Hud exc 89,92,93,95,97
BZ	40916 Center Bolt Assy-Spring	32 Terr
BZ	40918 Center Assy-Spring	32 Terr
BZ	40919 Clip-Wire	32-33 Terr,35 thru 1947 All,1948-1949 with OD-VD or HDM
F	40942 Fan Belt-Water Pump	32-33 K-KU with H.C. Head,33 E,34-35 Hud 8
C	40946 Tie Rod-Front Axle	32 Terr
BX	40947 Socket-RH Front Axle Tie Rod	32 Terr
BX	40948 Socket-LH Front Axle Tie Rod	32 Terr
BX	40950 Stud & Washer Assy-Front Axle Tie Rod	33 Terr
BX	40953 Bearing-Front Axle Tie Rod Stud	32-33 Terr
BX	40954 Rubber-Front Axle Tie Rod Stud	32-33 Terr
BX	40955 Spring-Front Axle Tie Rod Stud.	32-33 Terr
BX	40956 Dust Washer-Tie Rod Stud-Upper	32-33 Terr
BX	40957 Dust Washer-Tie Rod Stud-Low	32-33 Terr
BX	40958 Sockets-Front Axle Tie Rod-Boxes	32-33 Terr
BT	40971 Shaft-Clutch Shifter Yoke-LHD	32-33 Terr
BZ	40973 Shaft Assy-Accelerator	32-33 Terr
BZ	40980 Rod-Throttle Cont Idler Lev to Carb	32-33 Terr
BZ	40981 Rod Assy-Accelerator to Carb	32-33 Terr
	40982 Use 43991	
	40993 Screw-Shifter Fork Lock (Use 158339)	32 thru 38 Terr,34 thru 38 Hud
	40994 Use 45955	
	40998 Use 41160	
BZ	40999 Hub Cap-Wire Wheel-Outer	32-33 Terr
BZ	41006 Gasket-CI Vac Cont Valve	32-33 Terr
BZ	41008 Pipe Assy-Clutch Vacuum Control	32-33 Terr
BZ	41030 Clip-Pipe	32 thru 38 Terr,36 thru 1947 Hudson
C	41031 Spring Assy-Rear	32 Terr
	41039 Use 43073	
	41040 Use 46439	
BT	41042 Gasket-Companion Flange Screw	32 thru 38 Terr,34 thru 1940 Hudson
	41049 Thrust Washer & Ball Cup Assy-F/A (Use 42143)	32 Terr
BZ	41057 Link-Clutch Control	32-33 Terr
BZ	41066 Rod-Clutch Control	32-33 Terr
BZ	41067 Play Link-Clutch Control Rod	32-33 Terr
BZ	41082 Spring-Accelerator Shaft Anti-Rattle	32 thru 36 Terr,34 thru 36 Hudson
	41083 Extension-Jack Handle (Use 46172)	33-34 Terr,34 Hudson
BZ	41085 Lock Ring-Strg Gr Hsg Adj Sleeve	32 thru 36 Terr,34 thru 36 Hudson
BZ	41086 Nut-Strg Gear Hsg Adj Stud	32 thru 36 Terr,34 thru 36 Hudson
BX	41099 Shim-Rear Axle Pinion Brg (Medium)	32 thru 38 Terr,34 thru 38 Hudson,90
BZ	41101 Sleeve-Wire	32 thru 38 Terr,34 thru 1947 Hudson,I948-1949 CvBro 1950 All
C	41108 Cross Member Assy-Frame Eng Supp	32 thru 36 Terr,32 thru 36 Hudson
BM	41117 Radiator Hose-Upper	32-33 Terr
BM	41121 Gasket-Flywheel Guard	32 thru 38 Terr,34 thru 1950 Hudson
BX	41122 Stud-Washer Assy-F/A Tie Rod	32 Terr
BM	41133 Spring-Throttle Control-Bellcrank	32 thru 37 Terr,34 thru 37Hud,80,81,88,89,90,92,98,40C, 48,10 with Std Engine,18
BZ	41134 Clip-Throttle Control Bellcrank Spring	32 thru 37 Terr,34 thru 37 Hud,89,90-20 UCpe,41,43 LHD, 40T 3 Cpe,40 UC0-UCpe
BT	41149 Kit-Trans-Shift Rail Lock	32 Terr
BT	41151 Spring-Trans Shift Rail Lock Ball & HDM Mtg Brkt	32 thru 38 Terr,34 thru 1947 Hud exc 89,1948 thru 1950 less OD-SMD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 41152	Lever-Trans Shift Rail Lock Strap	32-33-34-35 Terr,34-35 Hudson
BT 41153	Pivot-Trans Shift Rail Lock Strap Lever	32-33 Terr
BT 41154	Strap-Trans Shift Rail Lock	32 thru 35 Terr,34-35 Hudson
BT 41155	Guide-Trans Shift Rail Lock Strap	32 thru 35 Terr,34-35 Hudson
BT 41156	Pin-Trans Shift Lock Strap Clevis	32 thru 35 Terr,34-35 Hudson
BZ 41160	Clip-Wheel Hub Sheel Spring	32-33-34 Terr,34 Hudson
BT 41182	Plunger-Trans Shift Rail Lock	33-34-35 Terr,34-35 Hudson
41183	Guard Assy-Flywheel (Use 40424)	32 thru 38 All,39 thru 1946 All Six Cyl
BZ 41184	Cable Ext Assy-Batt to Startix	32-33-34 Terr,34 Hudson
BO 41186	Insulator-Startix Cable Ext	32-33-34 Terr,34 Hudson
BZ 41187	Cable Assy-Startix to Starter	32-33-34 Terr,34 Hudson
BZ 41189	Wire Assy-Startix to Ground	32-33-34 Terr, 34 Hudson
41204	Use 150710	
41205	Use 150710	
BZ 41207	Spring-Acc Pedal Anti-Rattle	32 thru 38 Terr,34 thru 1947 Hudson
41212	Spring-Brake Shoe to Anchor Pin (Use 43378)	32-33 Terr
41220	Pipe Assy-Exhaust (Use 44648)	33 Terr K-KU
EX 41225	Thrust Washer-Rear Axle Diff Gear	33 thru 38 Terr,34 thru 1950 Hudson
41226	Thrust Washer-R/A Diff Pinion (Use 160172)	33 thru 38 Terr,34 thru 38 Hud
BT 41236	Spring-Trans Gear-Shift Rail Lock Ball	32 thru 35 Terr,34-35 Hud,89,90,98,91 Panel, 1941 thru 1950 with OD or HDM
41244	Ignition Wire Assy-Boxed (Use 46439)	33 Terr
41257	Use 303855	
41258	Bearing Assy-Clutch Throwout (Use 166253)	32 thru 38 Terr,34 thru 1942 Hudson
42003	Use 1-152645-16-43806-1-43723-1-43435	
EX 42007	Thrust Wash-Rr Axle Diff Gear	33 Hudson
BE 42008	Thrust Washer-Rr Axle Diff Pinion	33 Hudson
42019	Gasket-Intake to Exh Man (Use 48591)	33 Terr,34-35 Hud
BM 42024	Retainer-W/Pump Shaft Pulley	33 Hudson-Terr
*BM 42028	Cover-Cyl Water Jacket	33 Terr
C 42034	Cylinder Head Assy	33 Terr KT
BM 42036	Stud-Cyl Head	33 Terr
BM 42038	Gasket-Cyl Head (Pkg 10)	33 Terr KT
C 42042	Drag Link Assy	33 Terr
C 42044	Drag Link Assy	33 Terr
BZ 42051	Rod Assy-Acc to Carb	33 Terr
C 42066	Core Assy-Radiator	33 Terr KT
BZ 42070	Pipe-Rad Outlet Hose Connection	33 Terr
BM 42087	Support-Breather Tube	33 Terr,34 Hudson
C 42100	Case-Transmission	33 Terr
BT 42102	Gear Assy-Trans Main Drive	33 Terr
BT 42104	Gear Assy-Trans M/S Inter	33 Terr
42106	Use 42900	
F 42108	Bearing-Trans Manshaft	33 thru 38 Terr,34 thru 39 Hud,1940 without OD
*F 42110	Drive Gear-Trans Countershaft	33-34-35 Terr,34-35 Hudson
*F 42111	Inter Gear-Trans Countershaft	33-34 Terr,34 Hudson-Terr
BT 42114	Ret-Trans Main Drive Gear Brg	33 thru 38 Terr,34 thru 1940 Hudson
42116	Use 42102 & 42110	
42118	Use 42104 & 42111	
BT 42121	Thrust Wash-Trans M/S Inter Gear	33 Terr
BT 42123.	Gear-Trans M/S Low & Reverse	33 Terr
42124	Use 42102 & 42110	
42125	Use 42104 & 42111	
BT 42126	Gear-Trans Countershaft Low & Reverse	33 Terr
BX 42127	Arm-Front Axle Steering-RH	33 Terr
*BX 42128	Arm-Front Axle Steering-LH	33 Terr
BX 42137	Arm-Front Axle Strg Arm-RH-RHD	33 Terr
42139	Use 43172	
42140	Tie Rod Assy (Use 157204)	1933 Terr 8, 1933 Conn
42142	Tie Rod-Front Axle (Use 157205)	33 Terr,33 Terr Conn
F 42143	Thrust Washer & Ball Cup Assy-F/A	33 Terr,34 thru 36 All
F 42144	Pivot Pin-Steering Spindle	32 thru 36 Terr,34 thru 36 Hudson
F 42145	Bushing-Strg Spindle Pivot Pin	33 Terr,34 thru 36 All
BT 42153	Housing-Speedometer Gear	33 Terr
42172	Use 43966	
BM 42173	Vibration Dampener Assy	33 Hudson
BM 42174	Pulley-Vibration Dampener Fan	33 Hudson
BM 42182	Pipe Assy-Oil Pump to Check Valve	33 Terr
BM 42192	Pipe Assy-Oil Pan Suction	33 Hudson-Terr
C 42211	Brake Cable Assy-Front	33 Terr
BZ 42220	Bracket-Frame Front Spring Front	33 Terr
BZ 42221	Bracket-Frame Rear Spring-Front-RH	33 Terr
BZ 42222	Bracket-Frame Rear Spring-Front-LH	33 Terr
BZ 42223	Bracket-Frame Rear Spring Rear	33 Terr
BZ 42225	Bracket-Frame Front Spring Front	33 Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
42227	Guard Trans Cover (Use 42963)	
BZ 42242	Bracket-Frt Spring	33 Terr
BZ 42245	Flange-Exhaust Pipe	33 Terr,34 thru 36 Hud 8,37 thru 1947 All,1948 thru 1950 8 Cyl
BZ 42246	Gasket-Exhaust Pipe Flange	33 Terr,34 thru 36 Hud 8,37 thru 1947 All,1948 thru 1950 8 Cyl LHD
BO 42252	Switch Assy-Stop Lamp	32 Hudson-Essex
42255	Drive Gear & Pinion Assy (Use 40165-43114-43116)	33 Terr K-KT
BX 42256	Drive Gr-Rr Axle-4-1/9 to 1	33 thru 38 Terr,34 thru 38 Hudson, 90
BX 42265	Drive Shaft Assy-Rear Axle	33 Terr
42267	Felt Washer Assy (Use 156756)	33 Terr
42272	Diff Gr-Rr Axle (Use 166227)	33 thru 38 Terr,34 thru 1942 Hudson
BX 42280	Oil Seal-R/A Pinion	33 Terr
42289	Use 153056	
BZ 42290	Bracket-Muffler-Front	33 Terr,34-35-36 Hudson 8
C 42295	Pipe Assy-Tail	33 Terr
C 42297	Exhaust Pipe Assy	33 Terr KT
BZ 42313	Battery Tray Assy	33 Terr
42323	Flexible Conn Fuel Pump (Use 45479)	33 Terr
BO 42324	Loom-Direction Indicator Rear Wire	1948 thru 1950
BM 42325	Fuel Pump Assy	33 Terr
42329	Use 46062	
42330	Use 46063	
BZ 42333	Steering Gear Shaft	33-34-35 Terr,34-35 Hudson
42334	Use 40761	
C 42335	Tube & Worm Assy-Strg Gear Main Col	33-34-35 Terr,34-35 Hudson
42336	Use 40766	
BZ 42344	Hub & Bearing Cup Assy-Front	33 Terr
BZ 42346	Hub-Rear	33 Terr
C 42347	Brake Drum	33 Terr
F 42349	Gasket-Distributor	33 thru 39 All,1940 thru 1950 8 Cyl
42358	Support Assy-Engine-Frt (Use 43391)	33 Hudson
42424	Plate-Cyl Head-Ethyl Fuel (Use 47603)	33-34-35 Hudson-Terr
42426	Use 44062	
42428	Use 45955	
BM 42435	Pipe Assy-Furl Pump to Carb	33 Hudson-Terr
42496	Use 43923	
BT 42512	Plato Complete-Clutch Driving	32-33 Hudson,32 Essex
42521	Bearing-Clutch Throwout (Use 37256)	33 Hudson
BT 42522	Clutch Collar Assy	32-33 Hudson,32 Essex
42530	Use 2-47123	
BM 42531	Grommet-Eng Front Mtg-Lower	33 Terr,33-34 Hudson
42532	Mounting-Engine Rear (Use 166257)	33 thru 1940 8 Cyl,1941 All
42545	Mounting-Engine Rear (Use 166257)	33-34 Hud,35 thru 1940 6 Cyl,1942 6 Cyl
BZ 42567	Pipe-Rad-Outlet Hose Conn	33 Hudson 6
BM 42568	Hose-Radiator Inlet	33 Hudson 8
C 42570	Exhaust Pipe Assy	33 Hudson 6
C 42572	Exhaust Pipe Assy	33 Hudson 8
BX 42576	Diff Case & Stud Assy-Rear Axle	32-33 Terr
BX 42577	Diff Case & Stud Assy-Rear Axle	32 thru 33 Hudson-Essex
BT 42587	Retainer-Clutch Throwout Brg Grease	33 Terr,34 thru 1950 All
BT 42588	Retainer-Clutch Throwout Brg Grease	33 Hudson
F 42615	Oil Seal-R/A Who Brg Adj Cap	33-34-35 Terr
42620	Plate-Clutch Driving (Use 301246)	
BT 42627	Pressure Plate-Clutch	33 Terr KT
BT 42628	Cover-Clutch	33 KT,34 thru 37 Hud 8,70 exc Co-Cpe,80 exc Co-Cpe- Sed,82 thru 88,93,95,97,98 exc Sed,92M,98 7Sed,43 thru 47,48,12 thru 18
42630	Collar Assy-Clutch (Use 303855)	32-33 Terr,34 thru 1942 All
42631	Collar-Clutch (Use 166256)	32-33 Terr,34 thru 1942 All
F 42632	Gasket-Clutch Cover	33 KT,34 thru 39 Hud 8 ,70 .78 ,82 ,83 ,80 Cab-CabPu- Panel 91,91 Panel,93,98 exc Sed,12 thru18,25thru 28,10- 20-21 with VD-OD-HDM, 53,54,58.173,51-52-171-172 with VD -OD or HDM,1948-1949 All,501 thru 504,500 with OD, HDM or SMD
A 42634	Guard Assy-Flywheel	1933 thru 1947 8 Cyl
42635	Guard Assy-Flywheel (Use 42634)	33 Terr,34 thru 1941 Hudson 8,53,54
BZ 42638	Webbing-Long-Flywheel Guard	33 KT,34 thru 1947 Hudson 8,1948 thru 1950 All
BZ 42639	Webbing-Short-Flywheel Guard	33 KT,34 thru 1947 Hudson 8,1948 thru 1950 All
BM 42647	Wire Assy-#1-Plug to Dist	33 KT,34 thru 1946 Hudson 8
BM 42651	Wire Assy-#3-Plug to Dist	33 KT,34 thru 1947 Hudson 8
BM 42657	Wire Assy-#6-Plug to Dist	33 KT,34 thru 37 Hud Eight #5 and 6 on 84,85,87,95,97, 44,4537,14,15,17,24,25,27,53,54,173,174
BM 42671	Tube Assy-Ignition Cable	33-34 Terr,33 Hudson
42693	Use 37445	
42694	Use 37446	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 42739	Hub Cap-Wire Wheel-Prime	33 Hudson
C 42745	Spring Assy-Front	32-33 Terr K
BZ 42749	Bumper-Front Spring	33-34 Terr, 34 Hudson
BT 42750	Clip-Front Spring	33-34-35 Terr
BT 42759	Gasket-Trans Main Drive Gear Brg	33 Hudson
*BM 42787	Plate Assy-Cylinder Support-Front	33 thru 36 All, 37-38-39 6 Cyl
BZ 42792	Hub Cap-Wire Wheel-Outer	33 Terr
C 42800	Protector-Tire Tube	33-34 Terr
BZ 42822	Shackle-Front Spring & Bolt	33 thru 37 Terr, 34 thru 37 Hud, 81, 82, 92
42824	Bushing Assy-Spring Shackle (Use 153235)	33 thru 36 Terr, 34 thru 36 Hudson
42826	Use 45295	
42828	Use 45928	
BX 42832	Companion Flange-Rear Axle	33 Terr
BT 42833	Companion Flange-Transmission	33-34-35 Terr, 34-35 Hudson
BO 42836	Bracket-Horn	33-34-35 Terr, 34 Hudson
BT 42874	Intermediate Gear Assy-Trans M/S	33 Hudson
BT 42876	Gear Cluster Assy-Trans Cntrshft	33 Hudson
BT 42877	Intermediate Gear-Trans Cntrshaft	33 Hudson
BT 42878	Drive Gear-Trans Countershaft	33 Hudson
BT 42879	Spring-Clutch Engaging-Inner	33 Hudson
BZ 42880	Arm-Steering Gear Ball	33-34 Terr, 34 Hud exc LL
BZ 42881	Arm-Steering Gear Ball-RHD	33-34 Terr, 34 Hud
42882	Use 45744	
C 42883	Drag Link Assy-Complete	33 Terr
C 42885	Drag Link Assy	33 Terr
BZ 42890	Dust Cover-Drag Link-Outer-RHD	33 thru 36 Terr, 34 thru 36 Hudson
BM 42891	Stud-Cyl Head-Short	33 thru 38 Terr, GH, 63, 73, 78, 83, 88
42893	Stud-Cyl Head-Medium (Use 170894)	33-34-35 Terr, 33 Hudson
BM 42895	Stud-Cyl Head-Long	33-34-35 Terr, 33 Hudson
BZ 42897	Dust Cover-Drag Link-Inner	33 thru 36 Terr, 34 thru 36 Hudson
BZ 42898	Dust Cover-Drag Link-Outer	33 thru 36 Terr, 34 thru 36 Hudson
BZ 42899	Spring-Drag Link	32-33 Terr, 34 thru 37 All, 80 thru 88, 92, 93, 95, 97, 1940 thru 1950 All
BT 42900	Thrust Washer Assy-Trans Cntrshaft Drive Gr	33-34-35 Terr, 34-35 Hud
BT 42918	Mainshaft-Trans	33 Terr
BT 42919	Thrust Washer-Trans Mainshaft	33 Terr
BT 42920	Thrust Washer-Trans M/S Inter Gr	33-34-35 Terr, 34-35 Hud
BO 42922	Switch-Gas & Oil Gauge	33 Terr-Hudson
BZ 42926	Cross Shaft & Brkt Assy-Cl Cont	33 Terr
BZ 42938	Felt-Cl Cross Shaft-Outer	33 thru 38 Terr, 34 thru 1950 Hudson
42939	Retainer-Clutch C/Shaft Felt (Use 45054)	33 Terr
C 42945	Cable Assy-Front Brake	33 Terr
C 42947	Cable Assy-Rear Brake	33 Terr
BZ 42948	Bracket-Brake Cable Conduit-RH	33 Terr
BZ 42949	Bracket-Brake Cable Conduit-LH	33 Terr
BZ 42957	Push Rod Assy-Brake Pedal	33-34 Terr, 34 Hud
BZ 42960	Yoke-Bke Pedal Push Rod Adj	33-34 Terr, 34 Hud
BM 42961	Stud-Cyl Head-Short	33-34-35 Terr, 33 Hudson
BT 42963	Guard-Transmission Cover	33 Hudson
BZ 42964	Bolt-Wheel Hub	33 thru 38 Terr, 34 thru 1950 Hudson
BT 42969	Shaft-Cl Shifter Yoke	34 All, 89, 90-98 LHD
BT 42970	Shaft-Cl Shifter Yoke	35 thru 1940 All exc 89
BT 42975	Pin-Cl Yoke Shaft Coupling Lever	34 thru 36 Hudson-Terr
BT 42976	Lever Assy-Trans Control	33-34-35 Terr, 34-35 Hudson
42978	Use 43458	
42979	Use 158421	
BZ 42982	Lever Assy-Clutch Pedal	33 thru 36 Terr, 34 thru 37 Hudson
BZ 42988	Shaft Assy-Pedal Lever	33-34-35 Terr, 34-35 Hudson
C 43016	Pipe Assy-Tail	33 Terr
BZ 43029	Rod-Cl Vac Cont-B/C to Coupling Lev	33-34-35 Terr, 34-35 Hudson
BZ 43031	Bracket Assy-Cl Vac Cont B/C	33 KT, 34 thru 37 Hudson 8
BT 43033	Bushing-Brake Control Lever	35 thru 1950 All
BT 43033	Bushing-Clutch Control Bellcrank Brkt	1940 thru 1950 with VD-HDM or SMD
BZ 43035	Bellcrank-CI Vac Cont Valve	33 thru 36 Terr, 34 thru 36 Hudson
BZ 43036	Rod Assy-Cl Vac Cont Valve	33 Terr, 34-35 Hudson
BZ 43040	Shaft Assy-Accelerator	33-34-35 Terr, 34-35 Hudson
BZ 43042	Lever-Carb Pull Rod-Vacuum Clutch	35-36 Hudson-Terr
BZ 43044	Rod Assy-Acc to Carb	33 KT, 34 thru 36 Hudson 8
BZ 43066	Spoke-Wire Wheel-Short	33 Terr
BT 43073	Pawl & Rod Assy-Hand Brake Lev	33 Terr
BT 43075	Sector-Hand Brake Lev	33 Terr
BZ 43113	Bell Crank Assy-Throt Cont Man	33 Terr
BT 43114	Speedometer Gear-Trans-4-5/9 to 1	33 thru 38 Terr, 34 thru 39 Hud, 1940 without OD
BT 43116	Speedometer Pinion-Trans-4-5/9 to 1	33 thru 36 Terr, 34 thru 36 Hudson

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 43120	Spring Assy-Front	33 Terr KT
43121	Use 43122	
C 43122	Spring Assy-Rear	33 Terr
BZ 43124	Pipe Assy-Gas Tank to Fuel Pump	33 KT,34 LT-LTS,35 HT-HU,64,65
BM 43160	Cover-Exh Pipe Front-Upper	33 Terr
BM 43161	Cover-Exh Pipe Front-Lower	33 Terr,34 Hudson
BO 43162	Cylinder-Ignition Coil Lock	33 Hudson
BT 43164	Ret-Trans M/S Inter Gr Thrust Washer	33 Terr
43165	Use 45353	
43167	Spring Assy-Front (Use 43120)	33 Terr K-KU
BX 43170	Spindle-Front Axle Strg-RH	33 Terr
BX 43171	Spindle-Front Axle Strg-LH	33 Terr
C 43172	Tie Rod Assy-Front Axle	33 Terr 6,33 Commercial
C 43173	Tie Rod-Front Axle	33 Terr 6,33 Commercial
BX 43174	End-Front Axle Tie Rod-RH	33 Terr
BX 43175	End-Front Axle Tie Rod-LH	33 Terr
BX 43176	Ends Complete-Front Axle Tie Rod-Pkg	33 Terr
BZ 43191	Starting Crank	33 Terr
BZ 43192	Starting Crank-First Ext	33 Terr
BZ 43193	Starting Crank-Second Ext	33 Terr
BX 43200	Diff Gear-Rear Axle	33 Hudson
BX 43201	Diff Pinion-Rear Axle	33 Hudson
BZ 43220	Stud-Throttle Cont	33 thru 37 Terr,34 thru 37 Hud,80,81,88,89,90,93,98,40C,48,20 with Std Engine-28 with VD-OD-HDM
BZ 43221	Rod-Throttle Cont Manifold to Carb	33 Terr
C 43246	Spring Assy-Rear	33 Terr
43309	Gear & Shaft Assy (Use 40115 & 40117)	33 Terr
43320	Use 166333	
43321	Use 44538	
43323	Resistor-Ignition Coil (Use 159210)	33 Hud,33 thru 36 Terr,35-36 Hud 6,70,71,73B,78,80,81,88,89
BZ 43356	Cable Assy-Battery to Starter	
BT 43360	Bearing-Trans Mainshaft Pilot	33 Terr
BT 43361	Spacer-Trans M/S Pilot Brg	33 Hudson
43377	Use 48134	
BX 43378	Spring-Bke Shoe to Anchor Pin	33-34-35 Terr,34-35 Hud
F 43379	Pin-Bke Shoe Hold Down Sprg	33 Terr,34 thru 1950 All
BZ 43391	Support Assy-Engine-Front	33 Hudson
C 43397	Cyl Head Assy-High Compression	32-33 Terr,33 Hud 6
C 43399	Center Assy-Front Axle	33 KT
43425	Use 45142	
43426	Use 45153	
43433	Use 45140	
BT 43434	Clutch Assembly	33 KT
BM 43435	Thrust Button-Camshaft	33 thru 1949 All,503,504
BZ 43437	Insulator-Battery Clamp Bolt	33 Terr
BM 43443	Ring-Piston	33 Hudson 6,33 Terr
BM 43445	Ring-Piston-Upper	33 Hudson 6,33 Terr,32 Essex
BM 43447	Ring-Piston-Lower	33 Hudson 6,33 Terr,32 Essex
43452	Ring-Piston (Use 158917)	32-33 Hud 8,34 thru 38 All
43453	Use 158917	
BM 43454	Ring-Piston	32 thru 34 Hudson 8,34 Terr
F 43456	Ring-Piston-Upper Oil-Std Size	32-33 Hudson 8,34 thru 1947 All, 1948 thru 1950 8 Cyl
F 43457	Ring-Piston-Upper Oil-.010 O/S	Cyl
BM 43458	Piston	34 thru 1947 All, 1948 thru 1950 8 Cyl
43459	Piston (Use 166243)	32 Essex-Terr,33 Hud 6-Terr
BM 43460	Pin-Piston Ring	33 Hud 8,34 All
BZ 43463	Rod Assy-Accelerator to Carb-RHD	33 thru 1947 All
BZ 43471	Piston Rod Assy-Vacuum Control Cylinder	33 thru 37 Terr
BZ 43473	Bracket Assy-Cl Vac Cont-B/C	34 Terr
BZ 43475	Rod Assy-Cl Vac Cont Valve	33 thru 37 Terr,35 thru 37 Hudson 6
C 43483	Cable Assy-Rear Brake	33-34-35 Terr
BZ 43508	End Assy-Prop Shaft-Front	33 Terr
F 43509	Yoke-Prop Shaft Sleeve	33-34-35 Terr,34-35 Hudson
43510	Use 43509	
F 43511	Expansion Plug-Prop Shaft Yoke	33 thru 38 Terr,34 thru 1950 Hudson
F 43512	Dust Washer-Prop Shaft Yoke	33 Terr,34-35 Hud,70 thru 75,80 thru 85,89,90 thru 95,40, 41,44,45,10 thru 15,17-18-27-28 with OD,20 thru 25,1946-1947 with OD,1948-1949-1950 All
F 43514	Yoke-Prop Shaft Flange	33-34-35 Terr,34-35 Hudson
F 43515	Journal-Propeller Shaft	33-34 Terr,34 Hudson
43516	Use 43515	
ZF 43517	Gasket-Prop Shaft Journal	33 thru 38 Terr,34 thru 1950 Hudson
ZF 43518	Retainer-Prop Shaft Journal Gasket	33 thru 38 Terr,34 thru 1947 Hudson

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	43520 Use 43809	
F 43521	Snap Ring-Prop Shaft Brg Race	33 thru 38 Terr,34 thru 1950 Hudson
	43526 Retainer (Use 42114).	33 Terr
BZ 43528	Washer-Pedal Toe Plate Bumper	33 thru 1947 All
BZ 43529	Silencer-Propeller Shaft	33 Terr
BZ 43531	Housing Assy-Steering Gear	33 thru 36 Terr,34 thru 36 Hudson
BT 43533	Roller-Clutch Shaft Lever Pin	33 thru 36 Terr,34 thru 36 Hudson
F 43538	Ignition Wires Kit Assy-Boxed	33 Terr,34-35-36 Hudson 8,1946-1947 8 Cyl
BX 43539	Shim-F/A Strg Spindle Pivot Pin	33 thru 36 Terr,34 thru 36 Hudson
	43553 Knob-Control Lever (Use 301996)	33 thru 38 Terr,34 thru 38 Hud exc 89,92,93,95,97
	43554 Use 150710	
	43555 Accelerator Pedal Assy (Use 150710)	33 Terr,34-35 All
BZ 43557	Cover-Pedal Pad	33 Hudson
	43558 Cover-Pedal Pad (Use 165819)	33 thru 35 Terr,34-35 Hud
BT 43588	Speedometer Gear-3-8/9 to 1	33-34 Terr,35 Hud Spec 8,64,65
BT 43590	Pinion-Speedometer-3-8/9 to 1	33-34 Terr,35 Hud 8,64,65
BT 43617	Guard-Trans Control Cover	33 Terr,35 Hudson-Terr
BT 43618	Retainer-Trans M/S Low & Reverse Gear	33-34 Terr,34 Hudson
BZ 43619	Second Extension-Starting Crank	33 Terr
	43623 Bolt-Spring Center (Use 151885)	37 Spring No 153756-153758
BZ 43628	Center Bolt Assy-Spring	33 Terr
BZ 43629	Center Bolt Assy-Spring	33 Terr
BZ 43631	Center Bolt Assy-Spring	33 Terr
BZ 43634	Clip-Spring Rebound-Clinch Type	33 Terr
BZ 43635	Clip-Spring Rebound-Clinch Type	33-34 Terr,34 Hudson
BZ 43637	Clip-Spring Rebound	33 Terr,1942 Springs 164018-19-20-26-7-8
BZ 43638	Clip-Spring Rebound	33 Terr,1941 Springs 162442-3-4-163554-163660, 1942-1946-1947 Springs 164030-1-2
BZ 43639	Clip-Spring Rebound	33 Terr,1942 Spring 164021
BZ 43642	Clip-Spring Rebound-Band Eye Type	33-34 Terr,34 Hudson
C 43646	Leaf #1-Rear Spring	33 Terr
C 43648	Leaf #1-Front Spring	32-33 Terr
BZ 43679	Clip-Rear Spring	33 Comm,34-35 Hud,71 thru 77,81 thru 87,89 Comm, 90 thru 98
BZ 43684	Nipple-Wire Wheel Spoke	33-34 Terr,34 Hudson
	43705 Brake Shoe Assy (Use 46804)	33 Terr
BM 43721	Oil Pump Complete	33 Terr-Hudson
	43723 Gear-Oil Pump (Use 166315)	33 thru 1942 All
BZ 43729	Spoke-Wire Wheel-Short	33-34 Terr,34 Hudson
F 43797	Retainer Assy-Strg Spindle Grease Wash	33 thru 38 Terr,34 thru 1950 Hudson
	43803 Camshaft (Use 1-152644, 4-44694 for 1934-5-6, 4-40110 for 1933 Second Type)	33 thru 36 6 Cyl
	43804 Camshaft (Use 1-152645; 4-40110; 4-44694)	33 Terr KT,34 thru 36 Hud 8
BM 43805	Valve Tappet & Guide Assy	33 Hudson-Terr
BM 43806	Guide-Valve Tappet	33 Hudson-Terr
F 43809	Bearing Assy-Prop Shaft Journal	33 thru 38 Terr,34 thru 1940 Hudson
BM 43827	Hose-Radiator Inlet	33 Terr
	43836 Spring-Use 44998	33 Terr
A 43840	Engine Guard Assy-Engine-RH	33 Terr
A 43841	Engine Guard Assy-Engine-LH	33 Terr
	43870 Use 46825	
	43871 Use 48132	
BT 43912	Nut-Clutch Vacuum Cylinder Rod	33 thru 1950 All
BT 43923	Flange Assy-Cl Ped Lev Shaft Coupling	33 Hudson
	43930 Cross Shaft & Brkt Assy-Cl Control (Use 45042)	33 Terr RHD
BZ 43940	Lever Assy-Cl Yoke Shaft Coupling	33-34-35 Terr,34-35 Hudson
ZF 43964	Bushing-Cl Yoke Shaft Coup Lever	33 thru 38 Terr,34 thru 1950 Hudson
BZ 43966	Gauge Assy-Gas Tank	33 Terr
BZ 43991	Rod Assy-Acc to Carb-RHD	33 thru 36 Terr,35-36 Hudson
BZ 44004	Gasket-Cl Vac Cont Cyl End Plate	33 thru 1950 All
BZ 44020	Gasket-Cl Vac Cont & Acc Valve to Cyl	33 Hud,92,93,95,97,1940 thru 1950 Hud
	44056 Use 45955	
	44059 Pulley & Extension Assy (Use 45955)	33 Terr
*BM 44062	Water Pump Assy	33 Terr
BM 44069	Spring-Valve	32-33 All
	44074 Use 160220, 44675 & 44677	
F 44079	Gear-Flywheel Starter	33-34-35 Terr
BO 44092	Cooland Cent Kit-Rad	33 Terr
BO 44093	Connector Assy-Single	33 thru 36 Hudson-Terr
BO 44094	Connector Assy-Double	33 thru 36 Hudson-Terr
BZ 44097	Shim-Spring-3-1/2°	33 Terr
BZ 44098	Shim-Spring-5-1/2°	33 Terr
	44158 Case Assy-Transmission (Use 47290)	34 Hudson-Terr
BT 44165	Ball Seat-Trans Mainshaft	34 thru 1940 All
BT 44166	Retainer-M/S Inter Gr Thrust Washer	34-35 Hudson-Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	44168 Use 47298	
BT	44169 Needle Roller-Trans M/S	34 thru 1940 All
BT	44170 Ret Ring-M/S Needle Roller	34 thru 1940 All
F	44171 Gear Assy-M/S Low & Reverse	34 Hudson-Terr
BT	44172 Bearing Cap Assy-Trans C/S	34-35 Hudson-Terr
	44174 Gear (Use 47304)	34 Hudson-Terr
BT	44175 Spacer-Countershaft Washer	34 thru 1940 All
BT	44176 Fork Assy-Low & Reverse Shift	34-35 Hudson-Terr
BT	44178 Spring-Low & Reverse Shift Fork	34 thru 1940 All
BT	44179 Seat-Low & Reverse Shift Fork Sprg	34 thru 1940 All
BT	44180 Pin-Spring Seat	34 thru 1940 All
	44181 Use 152698	
BT	44182 Shaft-Stationary-Reverse Gear	34-35 Hudson-Terr
	44183 Use 47306	
BT	44185 Bushing-Rotating Shaft-Rev Gear	34 Hudson-Terr
BT	44187 Retainer-Rev Gear	34 thru 1940 All
	44188 Use 47308	
BT	44189 Cap-Rev Gear Shaft	34-35 Hudson-Terr
BT	44190 Gasket-Rev Gear Shaft Cap	34 thru 39 All,1940 Without OD
BT	44191 Lock Kit-Transmission	33 Terr
	44192 Use 47291	
BT	44195 Lever-Rev Gear Shifters	34 thru 1940 All
BT	44196 Locater-Rev Gear Shift Lever	34 thru 1940 All
	44197 Seat-Rev Gear Shift Locater (Use 47642)	34 All
BT	44199 Lever-Shifter Pick Up	34-35 Hud-Terr
	44201 Spring-Shift Pick Up Lev Plunger (Use 47624)	34 Hudson-Terr
BT	44203 Fulcrum-Shift Lever	34-35 Hudson-Terr,1940 All
BT	44204 Housing-Speedometer Gear	34 thru 37 Hudson-Terr
BT	44206 Gasket-Spdo Gear Housing	34 thru 39 All,1940 Without OD
BT	44207 Pivot-Lock Strap Lever	34-35 Hudson-Terr
	44239 Clip-Radio Cable (Use 38909)	34-35 Hud-Terr
	44263 Bolt (Use 166739)	34 thru 1947 All
	44268 Use 45352-RHD only	
BT	44272 Cable & Knob Assy-F/W Control	32-33 Hudson-Essex
	44514 Use 154930-170050-170051	
BX	44515 Steering Arm-LH	34 Hudson-Terr
	44517 Use 154933-170050-170051	
	44518 Use 157205-159783-159784	
	44519 Tie Rod-F/A (Use 157205)	34 All,35 GU & Hud,36 Hud B
	44537 Carrier & Gear Set Assy (Use 166333)	34 All,35 Terr
C	44538 Carrier & Gear Set Assy-R/A 4-5/9 to 1	34-35 Terr,34 Hudson
F	44539 Gear & Pinion-R/A 4-1/9 to 1	34 thru 38 Hudson-Terr,90
F	44540 Gear & Pinion-R/A 4-5/9 to 1	34 thru 38 Hudson-Terr,90
BX	44541 Gear-R/A 4-5/9 to 1	34 thru 38 Hudson-Terr,90
C	44547 Housing Complete-R/A	34-35 K-KS-G-GU
F	44556 Oil Seal-Wheel Bearing	34-35 Hudson
BX	44557 Snap Ring-Oil Seal	34-35 Hudson
BX	44558 Shim-Thin-Wheel Bearing	34 thru 1950 All
BX	44559 Shim-Medium-Wheel Bearing	34 thru 1950 All
BX	44560 Shim-Thick-Wheel Bearing	34 thru 195Q All
BX	44561 Bolt-Wheel Bearing Cap	34 thru 1950 All
F	44562 Drive Shaft-R/A	34-35 Terr-Hudson Six
F	44563 Drive Shaft-R/A	34-35 Hudson Eight
	44566 Use 156756	
	44567 Use 48342	
	44568 Use 48342	
	44569 Use 156756	
	44570 Use 156756	
	44573 Case & Stud Assy-R/A (Use 150072)	34-35 Hud-Terr
BX	44578 Nut-Diff Bearing Adj	34 thru 1947 All
C	44580 Carrier & Cap Assy-R/A Diff	34 thru 38 Hudson-Terr,90
BX	44584 Gasket-Diff Carrier	34 thru 1947 All
BX	44585 Spacer-Diff Bearing	34 thru 38 Hudson-Terr,90
BX	44586 Shim-Thin-Bearing Spacer R/A	34 thru 1947 All
BX	44587 Shim-Medium-Bearing Spacer R/A	34 thru 1947 All
BX	44588 Shim-Thick-Bearing Spacer R/A	34 thru 1941 All
	44589 Use 155384	
BX	44590 Oil Baffle-Pinion Housing	34 thru 38 Hudson-Terr,90
	44598 Use 155384	
BX	44606 Cap Assy-Wheel Bearing Adj	34-35 Terr
	44610 Vibration Dampener Assy (Use 155480)	34 thru 37 All
F	44612 Valve-Inlet	34-35 Terr,35 Hud 6
F	44613 Valve-Exhaust	34-35 Terr,35 Hud 6
	44615 Use 35391	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
44616	Use 60104	
44617	Use 161965	
BM 44618	Cover Assy-Valve Chamber	34 thru 36 Terr,35-36 Hudson 6
BM 44620	Cover-Valve Chamber	34 thru 1947 Hudson 8
F 44621	Gasket-Valve Chamber Cover	34 thru 37 Terr-Hudson 6
F 44622	Gasket-Valve Chamber Cover	34 thru 1947 Hudson 8
BM 44623	Screw-Valve Chamber Cover	34 thru 1950 6 Cyl
BM 44624	Screw-Long-Valve Chamber Cover	34 thru 1947 6 Cyl
44625	Breather Tube (Use 164594 & 164595)	34 thru 1946 All
44626	Gasket-Tube Support (Use 164595)	34 thru 38 All exc 89
BM 44627	Clip-Breather Tube	34 thru 1946 All
BM 44629	Plate-Valve Chamber Cover	34 thru 1947 Hudson 8
44631	Use 151932	
BM 44632	Shaft & Pulley Assy-W/Pump	34 Hudson-Terr
BM 44634	Fan Blade	34 Hudson-Terr
F 44636	Nut-Water Pump Packing	34-35 Hudson Terr
44637	Cover Assy-Time Gear (Use 166307)	34-35 Hudson-Terr
44643	Use 46483	
F 44647	Valve-Exhaust	34-35 Hudson 8
CF 44648	Pipe Assy-Exhaust	34 Terr
BZ 44653	Bracket-Tail Pipe-Rear	34-35 Hudson-Terr
CF 44658	Pipe Assy-Tail	34-35 Terr
CF 44659	Pipe Assy-Tail	34-35 Hudson
CF 44660	Pipe Assy-Tail	34-35 Hudson
CF 44664	Pipe Assy-Exhaust	34 Hudson
BZ 44666	Cover-Front-Exhaust Pipe	34 thru 36 Hudson 8
BZ 44667	Cover-Rear-Exhaust Pipe	34 thru 36 Hudson 8
BM 44668	Pump Assembly-Fuel	34-35-36 Hudson-Terr
44670	Use 162177	
44671	Starting Jaw-Crankshaft (Use 164169)	34 thru 1942 All
44672	Bearing Cap Assy (Use 35077 & 157981)	34 thru 39 6 Cyl
44673	Bearing-Upper (Use 157966)	34 thru 39 6 Cyl
44674	Bearing-Low-Crankshaft #2 (Use 162535)	34 thru 39 6 Cyl
44674	Reamed-Use 157981 Assembly	
BM 44675	Oil Throw-Upper-Crankshaft	34 thru 1947 All
BM 44677	Oil Throw-Lower-Crankshaft	34 thru 1947 All
44678	Flywheel-Complete (Use 160220)	34-35 Terr,35 Hud 6,33 K-KU
44679	Flywheel-Complete (Use 160222)	34 thru 38 Hudson 8
BM 44684	Pin-Flywheel Driving	34 thru 38 Hudson-Terr
44685	Use 152045	
44686	Pump Complete-Oil (Use 166312)	34 thru 39 All,1940 thru 1942 6 Cyl
BM 44687	Body-Oil Pump	34 thru 1947 All,1948 thru 1950 8 Cyl
BM 44688	Plug-Pump Body	34 thru 1947 All,1948 thru 1950 8 Cyl
BM 44689	Gasket-Oil Pump Body Plug	34 thru 1947 All,1948 thru 1950 8 Cyl
BM 44690	Plunger-Oil Pump	34 thru 1947 All,1948 thru 1950 8 Cyl
44692	Shaft Assy-Oil Pump (Use 166314)	34 thru 1947 All
BM 44693	Bushing-Oil Pump Shaft	34 thru 1947 All,1948 thru 1950 8 Cyl
BM 44694	Gasket-Fuel Pump to Cyl	34 thru 36 Hudson-Terr
BM 44701	Cross Shaft Assy-Brake	34 Hudson-Terr
44704	Conn Rod Assy-RH (Use 166241)	30 thru 37 Hudson-Terr
44705	Conn Rod Assy-LH (Use 166242)	30 thru 37 Hudson-Terr
BM 44710	Shim-Thin-Conn Rod	34 thru 37 Hudson-Terr
BM 44711	Shim-Medium-Conn Rod	34 thru 37 Hudson-Terr
BM 44712	Shim-Thick-Conn Rod	34 thru 37 Hudson-Terr
44713	Bolt-Conn Rod (Use 155655)	34 thru 37 Hudson-Terr
44714	Nut-Conn Rod (Use 155656)	34 thru 37 Hudson-Terr
44725	Use 47113 & 47118	
F 44729	Starter Gear-Flywheel	34-35 Hudson 8,36 thru 1940 All
C 44730	Pan Assy-Oil	34 thru 36 6 Cyl
44734	Gasket-Oil Pan (Use 157875)	34 thru 38 6 Cyl
44735	Gasket-Oil Pan (Use 165398)	34 thru 1947 8 Cyl
BM 44749	Flange-Suction Pipe	34 thru 1947 6 Cyl
BM 44750	Flange-Suction Pipe	34 thru 1950 8 Cyl
BM 44751	Plate-Suction Pipe Soldering	34 thru 1947 All
F 44753	Gauge Assy-Oil Pan	34 Hudson
44754	Tray Assy-Oil Pan (Use 157881)	34 thru 38 6 Cyl
*C 44756	Tray Assy-Oil Pan	34 thru 1941 Hudson 8,53,54,173,174
C 44770	Exhaust Manifold Assy-First Type	34 Hudson
44771	Exhaust Manifold Assy (Use 45529)	34 Terr
44774	Cyl Head Assy (Use 47111)	34-35 Terr,35 Hud 6
44775	Use 47111 & 150378.	
44779	Use 150378	
44780	Use 47118	
BM 44786	Hub-Vibration Dampener	34 thru 37 Hudson-Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 44787	Thrust Washer-Water Pump Shaft	34-35 Hudson-Terr
C 44839	Cross Member-Frame-Front	34 K-KS,35-36 Terr
C 44840	Cross Member-Frame-Front	34 KU,34 thru 36 Hudson
BZ 44846	Radiator Support-Frame Cross Member	34-35 Terr,GH 63
BZ 44847	Support Assy-Engine-RH	34-35 Terr,GH 63
BZ 44864	Bracket-Front Spring-RH	34 K-KS,35 G-GU
BZ 44865	Bracket-Front Spring-LH	34 K-KS,35 G-GU
BZ 44866	Bracket-Front Spring-RH	34 Hudson,34-35 Terr
BZ 44867	Bracket-Front Spring-LH	34 Hudson,34-35 Terr
44868	Bracket-Front Spring-Rear	34-35 Terr,36 Comm
BZ 44869	Bracket-Front Spring-Rear	34-35 Hudson-Terr
BZ 44872	Bracket-Rear Spring-RH-Front	34-35 Hudson-Terr
BZ 44873	Bracket-Rear Spring-LH-Front	34-35 Hudson-Terr
BZ 44875	Bracket-Rear Spring-LH-Front	34-35 Hudson
BZ 44878	Bracket-Rear Spring-RH-Rear	34-35 Hudson-Terr
BZ 44879	Bracket-Rear Spring-LH-Rear	34-35 Hudson-Terr
BZ 44880	Bracket-Rear Spring-RH-Rear	34-35 Hudson
44883	Bracket-Body Bolt #2 (Use 47737)	34-35 All
BZ 44887	Bracket-Run Board-Front	34-35 Hudson-Terr
BZ 44888	Bracket-Run Board-Rear	34 Hudson-Terr
BZ 44890	Tray Assy-Battery	34-35 Terr,34 LTS,35 GH,61,62,63
BZ 44891	Tray Assy-Battery	34 LT-LL,35-36 Hudson 8
BZ 44897	Insulator-Battery Clamp Bolt	34-35 Hudson-Terr
BZ 44906	Engine Support-RH-Front	34 KU,35-36 Hudson 8
BZ 44907	Engine Support-LH-Front	34 KU,35-36 Hudson 8
BM 44912	Pipe Assy-Oil Pump to Valve	34 thru 38 6 Cyl,92,93,98 exc Sed
BM 44914	Pipe Assy-Oil Pump to Valve	34 thru 39 Hudson 8
BM 44916	Pipe Assy-Pump to Cyl	34 thru 38 6 Cyl,92,93,98 Exc Sed
BM 44918	Pipe Assy-Pump to Cyl	34 thru 39 Hudson 8
BM 44920	Pipe Assy-Oil Pump Suction	34 thru 1936 6 Cyl
BM 44922	Pipe Assy-Oil Pump Suction	34 thru 36 Hudson 8
BZ 44926	Ratchet-Hand Brake Lever	34 thru 35 Hud-Terr,36 Terr 61
BZ 44928	Bracket-Hand Brake Lever	34-35 Hudson-Terr,36 Terr 61
BZ 44929	Rod Assy-Hand Brake Lever	34-35 Hudson-Terr,36 Terr 61
BZ 44932	Bolt-Hand Bke Bell Crank Pivot	34-35 Hudson-Terr,36 Terr 61
BZ 44935	Rod-Hand Brake Lever	34 Hudson-Terr
C 44939	Tank Assy-Gasoline	34 Terr
C 44940	Tank Assy-Gasoline	34 Terr
44941	Use 155298	
BZ 44942	Filler Neck-Gas Tank	34-35 Hudson-Terr
BZ 44959	Cushion-Gas Tank Filler Neck to Body	34 thru 38 All,1939-1940 3Cpe-Vic Cpe-CvCpe-CvBro
BZ 44968	Strap-Gas Tank	34-35 Terr
BZ 44971	Hub-Front Wheel	34 Hudson LT,34 Terr
44972	Use 45009	
BZ 44974	Hub-Rear Wheel	34 Hudson LT
44976	Dust Shield-Rear Brake Drum (Use 47437)	34 Terr,34 Hudson LT
BZ 44978	Bumper-Pedal Toe Plate	34 thru 1947 All
44979	Bumper-Pedal Toe Plate-RHD (Use 44978)	34 All
44980	Drag Link Assy (Use 44986)	34-35 Terr
C 44982	Drag Link Assy	34-35 Terr,35 Hudson
C 44983	Drag Link Assy-RHD	34-35 Terr
C 44986	Drag Link	34-35 Terr
C 44988	Drag Link Assy	34-35 Terr,34 Hudson
BZ 44998	Spring-Pedal Toe Plate Bumper	34 thru 1947 All
BZ 44999	Reinforcement-Frame-Frt Fender Supp	34-35 Hudson-Terr
BZ 45002	Carrier-Hub Cap-Outer-Prime	34-35 Hudson
F 45003	Hub Cap-Outer	34 Terr
F 45004	Hub Cap-Outer	34 Hudson LT
F 45005	Hub Cap-Outer	34 Hudson LL
45007	Use 47429	
45008	Hub Assy-Front (Use 47430)	34 Hudson-Terr
C 45009	Hub Assy-Front	34-35 Hudson
BT 45018	Bushing-Intermediate Gear	34 thru 1940 All
45019	Bumper-Trans Side (Use 155538)	34 thru 37 All
BT 45021	Bracket-Trans Bumper-Side	34 thru 38 Hudson-Terr exc 89
BT 45022	Bolt-Trans Bumper-Side	34 thru 36 Hudson-Terr
C 45030	Cable Assy-Brake-Front	34 Hudson
C 45032	Cable Assy-Brake-Rear	34 Hudson
45034	Use 45030	
45041	Cross Shaft & Bracket Assy (Use 150494)	34-35 Hudson-Terr
BZ 45042	Cross Shaft & Bracket Assy-clutch-RHD	34 thru 37 Hudson-Terr
BZ 45053	Retainer-Cross Shaft Felt	34 thru 1950 All
BZ 45054	Spring-Cross Shaft Felt Retainer	34 thru 1950 All
45062	Use 47429	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
45063	Use 47430	
BZ 45075	Hub Cap-Inner-Front Wheel	34-35 Hudson
BZ 45076	Starting Crank	34 Hudson-Terr
BZ 45077	Extension-Starting Crank	34 Terr K
BZ 45078	Extension-Starting Crank	34 Hudson
BZ 45079	Extension-Starting Crank	34 Terr KU
F 45081	Switch Assy-Stop Lamp	34 Hudson- Terr
BZ 45082	Switch Assy-Stop Lamp-RHD	34-35 Hudson-Terr
BZ 45086	Tool Box-Complete	34-35 Hudson
BM 45093	Bracket-Generator Support	34 thru 36 Hudson-Terr
BM 45095	Bracket-Generator Adj	34 thru 1947 All
*BM 45101	Starting Motor Assy-6 Volt	80 thru 85, 87, 88, 89 RHD, 14, 15, 17, 24, 25, 27, 53, 54, 173, 174
A 45116	Engine Guard Assy-LH	34-35 Hudson
45138	Switch Assy (Use 157048, 170553 & 150285)	34 Hudson-Terr
45140	Clutch Assy (Use 166245)	34 thru 37 Hud 6-Terr, 80 Co-Cpe-Sed, 81, 38, 39 All X Engines, 89 Comm, 92, 41, 40-10-20 with 3"x 5" Engine, 11
45141	Clutch Assy (Use 160996)	34 thru 37 Hud 8, 78, 80 exc Co-Cpe-Sed
45142	Drive Plate (Use 166246)	34 thru 37 Hud 6 Terr, 80, Co-Cpe-Sed, 81, 89, 90, 93, 98 Sed, 37 thru 39 X Engines, 40-41 -41X-10-11-12X-20-21 without OD
45143	Drive Plate (Use 301246)	34 thru 37 Hud 8
45148	Spring-Clutch (Use 166250)	34 thru 37 Hud 6- Terr, 80 Co-Cpe-Sed, 81, 89, 90, 93, 98 Sed, 37 thru 39 X Engines, 40-41-41X-42X-10-11-12X Without Overdrive, 20-21 Without 0 D-VD-HDM
45149	Spring-Clutch (Use 166251)	34 thru 37 Hud 8, 78, 80 exc Co-Cpe-Sed, 82 thru 87, 92m, 93, 95, 97, 18 exc Sed, 42 thru 48, 40-41-10-11 With Overdrive, 12 thru 18, 22 thru 28, 20-21 With 0 D-VD-HDM
45152	Pressure Plate-Clutch (Use 166247)	34 thru 37 Hud 6-Terr, 80 Co-Cpe-Sed, 81, 89, 90, 92, 98 Sect, 40-41-42X-10-11-12X-20-21 Without OD
F 45153	Pressure Plate-Clutch	34 thru 37 Hud 8, 78, 80 exc Co-Cpe-Sed, 82 thru 88, 92m, 93, 95, 97, 98 exc Sed, 42 thru 48, 10-11 with 0 D, 12 thru 18
45154	Spring-Clutch-Inner (Use 155224)	34 thru 37 Hud 6-Terr, 80 Co-Cpe-Sed, 81 All P Engines
BM 45157	Insulator-Wire	35 thru 1949 All
BZ 45158	Return Spring-Brake Cont	34 thru 36 Hudson-Terr
45164	Rubber Sleeve-Ace Pedal Link (Use 163378)	34 thru 38 All
BZ 45169	Bell Crank-Throttle Control	34 thru 36 All, 80, 81, 88, 89, 90, 92, 98, 40, 48, 1941 LHD
BZ 45170	Rod Assy-Bell Crank to Carb	34-35 Terr
BZ 45171	Rod Assy-Acc C/Shaft to Man B/C	34-35 Terr
BZ 45172	Rod Assy-Acc C/Shaft to Man B/C	34-35 Hudson
BZ 45175	Ball Joint-Clutch Vacuum Cont	34 thru 37 Hudson-Terr
BZ 45176	Rod-Assy-Bell Crank to Carb.	34-35 Hudson
BZ 45177	Return Spring-Acc Lever (Pkg 5)	34 thru 36 Hudson-Terr
BM 45179	Body Assy-Water Pump	34 Hudson-Terr
45183	Valve & Pendulum Assy (Use 46683 & 46687)	
F 45192	Gasket-Carb to Manifold	34-35 Hudson-Terr
BZ 45195	Bracket-Shock Absorber-Rear	34 Hudson-Terr
45200	Valve Assy-Oil Check (Use 301547)	34 thru 1942 All
BM 45201	Plunger-Check Valve	34 thru 1947, 1948 thru 1950 8 Cyl
BM 45202	Retainer-Check Valve Plunger Pin	34 thru 1947 All, 1948 thru 1950 8 Cyl
BM 45203	Pin-Check Valve Plunger	34 thru 1946 All, 1948 thru 1950 8 Cyl
BM 45210	Gasket-Cylinder Head	34-35 Terr, 36 thru 1941 X Engines
C 45218	Wood Wheel Assy-Artillery-Prime	34-35 Hudson
45224	Hub Complete-Rear (Use 47433)	34 Hudson
BZ 45235	Link Assy-Clutch Control	34 thru 1940 All, 1941 exc Del
BZ 45236	Link-Brake Pedal to Master Cylinder	37 thru 1940 All, 1941 exc Del
BT 45239	Pawl & Rod Assy-Hand Brake Lever	34-35 Hudson-Terr, 61
C 45240	Muffler Assy	34 thru 36 Terr
45241	Muffler Assy (Use 153056)	34 thru 36 Hud 8
BZ 45242	Oil Seal-Steering Gear Shaft	34 thru 36 Hud-Terr exc LL-HHU
BZ 45243	Retainer-Strg Gear Shaft Oil Seal	34 thru 36 Hudson-Terr
BZ 45244	Spring-Strg Gear Oil Seal Retainer	34 thru 36 Hudson-Terr
BZ 45245	Oil Seal-Strg Gear Shaft	34 LL, 35 HHU
BZ 45246	Oil Seal-Strg Gear Shaft	34 thru 36 Hud-Terr (Canada), 37-38-39 All
BZ 45247	Retainer-Strg Gear Shaft Oil Seal	34 thru 36 Hud-Terr (Canada), 37-38-39 All
BZ 45248	Spring-Steering Shaft Retainer	34 thru 36 Hud-Terr (Canada), 37-38-39 All
45270	Use 47432	
F 45277	Packing-Water Pump	32 Terr, 33 thru 35 All
C 45280	Spring Assy-Front	34-35 Terr
C 45281	Spring Assy-Front	34 Hudson
CF 45287	Spring Assy-Rear	34 Hudson LL Sedan
BZ 45289	Bumper-Front Spring	34 Hudson
BZ 45290	Clip-Front Spring	34-35 Hudson-Terr
45291	Threaded Bushing-Front Spring (Use 153231)	34-35-36 Hudson-Terr
45293	Pivot Bolt-Front Spring (Use 153237)	34-35 Hudson-Terr, 36 Comm
BZ 45294	Bushing-Front Sprg Pivot Bolt	34-35 Hud-Terr, 36 thru 38 Comm, 89, 90, 98

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
F 45295	Threaded Bushing Assy-Rear Spring	34 thru 36 Hud-Terr
BZ 45296	Clip-Rear Spring	34 thru 36 Hud-Terr,All with light Scale Springs 37-38-39
BZ 45299	Plate-Rear Spring Clip-RH	34 Hudson-Terr
BZ 45300	Plate-Rear Spring Clip-LH	34 Hudson-Terr
BZ 45301	Stud-Shock Absorber Mounting	34 Hudson-Terr
BZ 45302	Cushion-Rear Spring Clip	34 thru 39 All,1940 thru 1950 exc Cab-CabPu-Panel
BZ 45303	Retainer-Spring Clip Cushion	34 thru 39 All,1940 thru 1950 exc Cab-CabPu-Panel
F 45304	U Bolt Shackle-Rear Spring	34 thru 36 Hudson-Terr
	45305 Plug-Shackle Threaded Bushing (Use 48573)	35 All
BZ 45308	Center Bolt-Rear Spring	34 Hudson-Terr
	45310 Use 151933	
BM 45312	Shaft Assy-Water Pump Pulley	34 Terr KU
BM 45317	Retainer-Water Pump Pulley Shaft	34 Hdson-Terr
BM 45319	Flange-Water Pump Extension	34 Terr
C 45331	Tank Assy-Gasoline	34 Terr Cpe-RD
	45335 Gas Tank Assy(Use 1-47089;1-47090;2-71490;2-12111)	34 Cpe-Rd
BZ 45337	Filler Neck Assy-Gas Tank	34-35 Hudson-Terr
BZ 45338	Filler Neck Assy-Gas Tank	34-35 Hudson-Terr
BZ 45344	Grommet-Gas Tank Neck to Body	34 thru 1940 Hud-Terr,1941-1942 Cab-CabPu-Del-Sta,58,178
BZ 45352	Dimmer Switch-RHD	34-35 Hudson-Terr
BZ 45353	Zerk Fitting	34 thru 1950 All
	45354 Use 45928	
MF 45359	Nut-Tappet Adj	34 thru 1947 All,1948 thru 1950 8 Cyl
	45360 Shock Absorber (Use 1-166133; 2-46711)	
	45362 Shock Absorber-Front (Use 166133)	
	45363 Shock Absorber-Rear (Use 159203)	
	45365 Shock Absorber-Rear (Use 166134; 2-46711)	
BZ 45368	Bracket-Shock Absorber-Front-Lower	34 Hudson
BZ 45369	Pin-Shock Absorber-Rear	34 Hudson-Terr
BZ 45373	Horn Assy	34 Terr Std,35 G,61
BX 45378	Backing Plate Assy-Rear Brake-RH	34-35 Terr
BX 45379	Backing Plate Assy-Rear Brake-LH	34-35 Terr
BX 45384	Backing Plate Assy-Front Brake-RH	34-35 Hudson-Terr
BX 45385	Backing Plate Assy-Front Brake-LH	34-35 Hudson-Terr
BX 45387	Backing Plate Assy-Rear Brake-LH	34-35 Hudson-Terr
BX 45402	Abutment-Backing Pl Bke Cable-RH	34 Hudson-Terr
BX 45404	Cap-Backing Plate Conduit-RH	34 Hudson-Terr
BX 45405	Cap-Backing Plate Conduit-LH	34 Hudson-Terr
BX 45407	Felt-Backing Plate Conduit Cap	34-35 Hud-Terr exc LL-HHU,89-90,40T,40P
BX 45408	Felt-Backing Plate Conduit Cap	34 LL,35 HHU,36-37 All,80 thru 85,87,88,92 thru 98,89-90 Comm,40C,41 thru 47,48C,48 7Sed,1941 thru 1950 All
BX 45409	Lever-Brake Cam Operating-RH-LH	34-35 Hudson
	45410 Use 46804	
	45414 Use 46805	
	45419 Use 48132	
	45420 Use 48134	
	45421 Use 48245	
BX 45422	Spring-Bke Shoe to Anchor Pin-Small	34-35 Hudson
BX 45423	Spring-Bke Shoe to Anchor Pin-Lev Side	34-35 Hudson
F 45424	Spring-Brake Shoe-Hold Down	34 LL,35 HHU,36 thru 1950 All
BX 45425	Guide Assy-Brake Shoe	34-35 Hudson-Terr
BZ 45427	Arm-Brake Cam-RH	34-35 Hud-Terr exc LL-HHU
BX 45428	Arm-Brake Cam-LH	34-35 Hud-Terr exc LL-HHU
BX 45434	Arm-Brake Cam-LH	34 LL,35 HHU
BX 45439	Spring-Brake Cam Arm	34-35 Hudson-Terr
BX 45440	Spring-Brake Cam Arm	34-35 Hudson
BX 45441	Lever-Brake Cam Operating-RH	34-35 Hudson-Terr
BX 45442	Lever-Brake Cam Operating-LH	34-35 Hudson-Terr
F 45443	Tappet-Valve	34 All
	45444 Guide-Valve Tappet (Use 166232)	34 thru 1942 All
BX 45445	Spacer-Brake Eccentric	34-35 Hudson-Terr
F 45447	Screw-Brake Adjusting	34 LL,35 HHU,36 thru 39 Hud 8,43 thru 47,14,15,17,10C,24,25,27,53,54,173,174,178, 1948 thru 1950
F 45448	Nut-Brake Adj Screw Pivot	34 LL,35 HHU,36 thru 39 Hud 8,43 thru 47,10C
F 45449	Socket-Brake Adj Screw	34 LL,35 HHU,36 thru 39 Hud 8,43 thru 47,10C
	45450 Use 159783	
	45451 Use 159784	
	45460 Clamp-Tie Rod (Use 153502)	34-35 All exc G,36 Hud 8
	45464 Propeller Shaft Assy (Use 46483)	34-35 LL-HHU
BM 45475	Pipe Assy-Fuel Pump to Carb	34 thru 36 Terr,35-36 Hudson 6
F 45479	Flexible Conn-Fuel Pump-LHD	34 thru 36 Hud 8,37 thru 1950 All
	45480 Bearing #1-Camshaft (Use 160327)	34 thru 38 Terr-Hud 6

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
45481	Bearing #1-Camshaft (Use 160331)	34 thru 38 Hudson 8,95,97,44,45,47
45482	Bearing #2-Camshaft (Use 160328)	34 thru 38 Terr-Hud 6
45483	Bearing #2-Camshaft (Use 160332)	34 thru 38 Hudson 8,95,97,44,45,47
45484	Bearing #3-Camshaft (Use 160330)	34 thru 38 Terr-Hud 6
45485	Bearing #3-Camshaft (Use 160333)	34 thru 38 Hudson 8,95,97,44,45,47
45486	Bearing #4-Camshaft (Use 160334)	34 thru 38 Hudson 8,95,97,44,45,47
45487	Bearing #5-Camshaft (Use 160335)	34 thru 38 Hudson 8,95,97,44,45,47
45500	Use 46948	
BZ 45501	Screw-Shock Absorber Oil Filler	34 thru 37 Terr,38-39 All
BZ 45502	Gasket-Shock Absorber Oil Filler Screw	34 thru 37 Terr,38-39 All
BZ 45514	Washer-Shock Absorber Oil Seal	35 G-GU-GH,61,62
BM 45519	Cover Assy-Cyl Water Jacket	34-35 Terr
*BM 45520	Cover Assy-Cyl Water Jacket	34-35 Hudson
BM 45523	Pipe-Cylinder Water Jacket Cover	34-35 Terr,35 GH
BM 45527	Gasket-Oil Pan Ga & Rad Water Level	34-35 Hudson-Terr
BM 45528	Thermostat-Exhaust Damper	34-35 exc G,62 thru 67,72 thru 77,82 thru 87,92 thru 97, 41,43 thru 47,11 thru 17,11-20 With L Engine,21 thru 27, 1946-1947 All, 1948 thru 1950 8 Cyl
C 45529	Exhaust Manifold-First Type	34 Terr
BM 45531	Spring-Exhaust Damper-Rear	34 thru 36 Hudson 8
BM 45533	Stud-Exhaust Damper Spring	34-35 exc KS-LTS-G, 62 thru 67,72 thru 77,82,83,92,93,41, 43,11,12,10-20 with LEngine,21,22,1946-1947 6 Cyl
BM 45535	Cover-Exhaust Damper	34 thru 36 Hud-Terr exc G-61-71
BM 45536	Damper & Shaft Assy-Exhaust	34 thru 36 Hud-Terr exc G-61-71
45537	Cyl Head & Fuel Plate Assy-HC (Use 47113)	34-35 Hudson 8
C 45541	Cover-Cylinder Head	34-35 Hudson
F 45542	Gasket-Cyl Head to Cover	34-35 Hudson 8
C 45544	Flywheel-Complete	32-33 Terr
BO 45547	Horn Assy-DeLuxe-LH	34 Hudson-Terr
BO 45548	Bracket Assy-Horn-RH	34 Hudson-Terr
BO 45549	Bracket Assy-Horn-LH	34 Hudson-Terr
F 45556	Hose-Radiator Inlet-Std Head	34-35 Terr
45557	Hose-Radiator Inlet (Use 47948)	34-35 Teri
F 45558	Hose-Radiator Inlet	34-35 Hudson-Terr
BZ 45559	Pipe-Radiator Inlet Hose	34-35 Terr
F 45560	Hose-Radiator Outlet	34-35 Terr
F 45561	Hose-Radiator Outlet	34-35 Terr
BZ 45562	Reinforcing Sprg-Rad Outlet Hose	34-35 Terr
BZ 45563	Pipe-Radiator Outlet Hose	34-35 Terr
BZ 45564	Pipe-Radiator Outlet Hose	34-35 Hudson
BZ 45571	Thermostat-Radiator	34-35 Hudson-Terr
BZ 45574	Gasket-Radiator Inlet	34-35 Hudson-Terr
F 45575	Hose-Radiator Inlet By Pass	34-35 Hudson-Terr
BZ 45577	Gasket-Radiator Filler Cap	34-35 Hudson-Terr
BZ 45578	Inlet-Radiator	34 Terr
BZ 45582	Gasket-Gas Tank Gauge	34 Hudson-Terr
BZ 45583	Outlet Unit-Gas Tank Gauge	34 Terr
BZ 45584	Outlet Unit-Gas Tank Gauge	34 Hudson
BZ 45585	Gasket-Gas Tank Outlet Unit	34 Hudson-Terr
45586	Valve Spring (Use 161965)	34 thru 38 All
BM 45588	Stud-Cyl Head-Short	34-35 Terr
BM 45592	Stud-Cyl Head-Medium	34-35 Hudson
BM 45594	Stud-Cyl Head-Medium	34-35 Hudson
BM 45596	Stud-Cyl Head-Long	34-35 Hudson
45598	Shaft-Low & Reverse Shift Fork (Use 155023)	34 thru 37 Hud-Terr
F 45599	Gauge Assy-Water Level	34-35 Hudson-Terr
BZ 45612	Front End Assy-Prop Shaft	34-35 Hudson
F 45614	Retainer-Prop Shaft Dust Washer	34-35 Hudson
C 45616	Prop Shaft & Rear Joint Assy	
BO 45619	Switch Assy-Inst Light	34-35 Hudson
BO 45620	Button & Wire Assy-Starter	34 Hudson-Terr
45621	Use 45620	
BO 45622	Nut-Starter Button	34-35 Hudson-Terr
F 45625	Main Shaft Assy-Trans	34 Hudson-Terr
BT 45626	Plug-Trans Mainshaft	34 thru 1940 All
BZ 45629	Socket-Drag Link	34-35 Hudson
C 45642	Cable Assy-Brake-Front-RH	34 Terr
C 34643	Cable Assy-Brake-Front-LH	34 Terr
C 45644	Cable Assy-Brake-Front-RH	34 Terr
C 45645	Cable Assy-Brake-Front-LH	34 Terr
C 45646	Cable Assy-Brake-Rear-RH	34 Hudson-Terr
C 45647	Cable Assy-Brake-Rear-RH	34 Hudson-Terr
45648	Use 45642	
45649	Use 45643	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
45650	Use 45644	
45651	Use 45645	
C 45656	Spring Leaf #1-Front	34-35 Hudson-Terr
C 45658	Spring Leaf #3-Front	34-35 Hudson-Terr
C 45678	Spring Leaf #1-Rear	34-35 Hud-Terr exc LL-HHU
C 45679	Spring Leaf #2-Rear	34-35 Hud-Terr exc LL-HHU
C 45680	Spring Leaf #3-Rear	34-35 Hud-Terr exc LL-HHU
C 45694	Main Leaf #1-Rear Spring	34 Hud LL,35 HHU
45724	Shock Absorber (Use 166133; 2-46711)	
45726	Shock Absorber (Use 166134)	
BZ 45728	Terminal-Battery Negative	34 thru 39 LHD exc 89-90-98,89-90-98 RHD
BZ 45730	Clip-Wire	34 thru 39 All
BM 45731	Retainer-Exhaust Damper Spring	34-35 Exc G,62 thru 67,72 thru 77,82 thru 87,92M,93,95,97, 92,41,43 thru 47,11 thru 17,10-20 With L Engine,21 thru 27,1946-1947 All, 1948 thru 1950 8 Cyl
45739	Use 45738	
BO 45742	Cable-Radio Volume	34 Hudson-Terr
BO 45743	Cable-Radio Tuning	34 Hudson-Terr
BZ 45744	Ball Arm-Strg Gear	34 Hudson LL
BM 45751	Spring-Exhaust Damper-Rear	34 Hud-Terr 35 Gu-Gh,62,63,72 thru 77,82 thru 87,92M,93,95,97,92,41,43 thru 47,10-20 with L Engine,21 thru 27,11 thru 17,1946-1947 All, 1948 thru 1950 8 Cyl
BZ 45752	Grommet-Shock Absorber Head	34 Hudson
BZ 45777	Shim-Front Spring-1-1/2°	34-35 Hudson-Terr
C 45779	End Assy-F/A-LH-Axleflex	34-35 Hudson-Terr
BX 45793	Pivot Pin-Front Axle End-Axleflex	34-35 Hudson-Terr
BX 45794	Roller-Frt Axle End Pivot-Axleflex	34-35 Hudson-Terr
BX 45795	Thrust Washer-Front Axle Pivot-Axleflex	34-35 Hudson-Terr
BX 45797	Seal-Front Axle Pivot Race-Axleflex	34-35 Hudson-Terr
BX 45798	Retainer-Front Axle Pivot Roller-Axleflex	34-35 Hudson-Terr
45799	Use 48611-71100	
45804	Shock Absorber (Use 166134)	
45806	Tie Rod Assy (Use 157205-159783 & 159784)	34 All
BO 45865	Wire Assy-Conn-L to R Horn-Rear	34 Hudson
BO 45880	Wire Assy-Conn-L to R Horn-Front	34 Hudson-Terr
45925	Fan Blade (Use 166280)	34 thru 1942
BM 45926	Cushion-Fan-Blade	34 thru 1947
F 45928	Grease Fitting-67-1/2°	34 thru 1950 All
F 45929	Lock-Water Pump Packing Nut	34-35 Hudson-Terr
BZ 45938	Seal-Bolt to Ground Conn	34 thru 39 All
F 45954	Fan Belt-HC Head	34-35 Hudson-Terr
BM 45955	Shaft & Pulley Assy-Fan	33 Terr,33 Hudson 6
BO 45957	Twin Horn-Service Kit	34 Hudson-Terr
BZ 45968	Inlet Assy-Radiator	34-35 Terr
45978	Switch-Dimmer (Use 150870)	34-35 Hud-Terr
45979	Bumper-Ace Pedal Toe Plate (Use 155549)	34 thru 37 All,38 without VD
C 45980	Spring Assy-Front	34 Hudson
BZ 45985	U Volt-Spring Clip	36-37 Comm,71B,80,88,90,98
BO 45986	Key-Ignition Coil and Door Lock	34 thru 1950 All
45989	Suppressor-Distributor (Use 147786)	34 Hudson-Terr
BT 45994	Shift Rail Assy-Trans Low & Reverse	34-35 Hudson-Terr
*BM 45997	Solenoid Switch-Starting Motor	1934 thru 1949 exc 1940
46029	Use 151914	
46040	Use 152165	
BZ 46041	Thrust Washer-Steering Gear Shaft	34-35 Hudson
BZ 46042	Shim-Thin-Steering Gear Shaft	34-35 Hudson
BZ 46043	Shim-Thick-Steering Gear	34-35 Hudson
BZ 46044	Adj Screw-Steering Gear Shaft	34-35 Hudson
46049	Housing Cover-Steering Gear Worm (Use 158878).	34 LL,35 HHu,36 thru 38 All
BZ 46050	Shim-Thin-Steering Gear Worm Cover	34 LL,35 HHu,36 thru 39 All,40,41,44,45,48,10,11,12,18,20,21,22,28,1946-1947 6 Cyl,500
BZ 46051	Shim-Thick-Strg Gear Worm Cover-Upper	34 LL,35 HHu,36 thru 39 All,40,41,44,45,48,10,11,12,18,20,21,22,28,1946-1947 6 Cyl,500
BZ 46052	Cover-Steering Gear Housing Shaft	34-35 Hudson
BZ 46053	Gasket-Steering Gr Housing Shaft Cover	34 LL,35 HHU
C 46060	Column Assy-Steering Gear	34 LL,35 HHU
C 46061	Column Assy-Strg Gear-RHD	34 LL,35 HHU
C 46062	Steering Gear Complete	34 Hudson-Terr
C 46063	Steering Gear Complete-RHD	34 Hudson-Terr
BM 46086	Lock-Fan Blade Bolt	34 thru 1947 All
46094	Use 43116	
C 46143	Gas Tank Assy	34 Terr
BZ 46145	Aux Filler Neck Complete-Gas Tank	34-35 Terr
46165	Use 48915	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 46167	Cushion & Fan Blade	34 Hudson-Terr
46168	Starting Crank (Use 151578)	34-35 Hud-Terr
46169	Extension-Starting Crank (Use 153401)	34-35 Terr K,G & GU
BZ 46170	Extension-Starting Crank	34-35 KU-GH
46171	Extension-Starting Crank	34-35 Hudson
BZ 46172	Adapter-Jack Handle	34-35 Hud-Terr,36 thru 1942 Cab-CabPu-Sta 1946-1947 Cab-CabPu
C 46173	Brake Cable Assy-Front	33 Terr
46199	Center Bolt-Front Spring (Use 151885)	34-35 Terr,35 Hudson 6
46200	Center Bolt-Front Spring (Use 151885)	34-35 Hudson 8
46201	Center Bolt-Front Spring (Use 48316)	35-36 Comm
46202	Center Bolt-Rear Spring (Use 151886)	34 Hudson-Terr,1941 Spring 163049
46203	Center Bolt-Rear Spring (Use 163723)	34 Hudson
BZ 46204	Bolt-Rebound Clip	34 Hud-Terr,36 Comm,90 Cab-CabPu-Sta
46210	Use 48133	
BZ 46211	Rebound Clip-Spring	34 Hud-Terr,36 Comm
BZ 46212	Rebound Clip-Front Spring	34 Hud-Terr,1940 Heavy Scale Springs,1941 Springs #161936-40
BZ 46213	Rebound Clip-Rear Spring #2	34 Hudson-Terr,1942-1946-1947 Sprgs 164022-3-4-5
BZ 46214	Rebound Clip-Rear Spring #3	34 Hud-Terr,1941-1946 Springs 161937-8-9
BZ 46215	Rebound Clip-Rear Spring #2	34 Hud,1941 Springs 161933-4-5,1942-1946-1947 springs 164022-3-4-5-164029-33
BZ 46216	Rebound Clip-Rear Spring #3	34 Hudson
BT 46228	Lock Assy-Hill Hold Release	34-35 Hudson-Terr
46234	Use 46260	
BT 46249	Gasket-Hill Hold Cap	34-35 Hudson-Terr
BT 46251	Oil Seal-Hill Hold Cap	34-35 Hudson-Terr
BT 46260	Release Plate-Complete-Hill Hold	34-35 Hudson-Terr
BZ 46266	Spring Clip-Rear	34 thru 36 Comm
C 46295	Engine Assy-New	34 Terr
46298	Use 47799	
46344	Trim Ring-16" Wheel (Use 156273)	34 thru 36 All
46412	Shock Absorber (Use 166134)	
C 46421	Manifold-Exhaust	34-35 Hudson 8
BO 46428	Extension-Valve Stem	34-35 Hudson,36 Hud-Terr
46438	Switch Assy-Lighting (Use 1-157048, 1-170553 1-150285)	34 Hudson-Terr
F 46439	Ignition Wire Assy-Boxed	32 thru 37 6 Cyl
F 46442	Reverse Gear & Shaft Assy	34 Hudson-Terr
BT 46444	Bushing-Reverse Gear Shaft	34 thru 1940 All
BZ 46455	Oil Seal-Shock Absorber	35 thru 38 Hud exc 89,93,95,97,43,44,45,47,22- 24 exc Cpe,21 Sta,27,1946-1947 All
46469	Use 47772	
46470	Use 46665	
46473	Spring Assy-Rear (Use 47215)	34-35 Terr
C 46483	Shaft Assy-Propeller	34 LL,35 HHU
F 46490	Dust Cap-Sleeve Yoke	35 HHU,66,67,76,77,78,87,88,97,98,43,47,48, 18-18-27-28-58-178 Without OD
F 46491	Washer-Sleeve Yoke Dust Cap	35 HHU,66,67,76,77,78,87,88,97,98,43,47,48, 17-18-27-28-58-178 Without OD
F 46492	Retainer-Sleeve Yoke Dust Cap Washer	35 HHU,66,67,76,77,78,87,88,97,98,43,47,48, 17-18-27-28-1947 Without OD
46563	Retainer-Radio Knob (Use 48049)	34 Hudson-Terr
46587	Tie Rod Assy (157205,159783 & 159784)	34 Hud-Terr,35 Hud,35 GU
46588	Use 159783	
46615	Rebound Clip-Spring-#2 and 3 (DNS)	
46645	Shock Absorber (Use .166133)	
46646	Shock Absorber-Rear (Use 159203)	34 Terr
46647	Use 46948	
BX 46658	Pinion-Rear Axle-3-8/9-1	35 HR-HU,64,65,71 thru 77,81 thru 87
A 46665	Radiator Assy-Prime	34 Terr KS
BZ 46679	Inlet-Radiator	34 KS,35 G
BZ 46683	Valve & Pendulum Assy-Cl Vac Cont	34-35 Terr
BZ 46687	Play Link-Vac Cl Cont Cable	34 thru 36 Hudson-Terr
46700	Shock Absorber (Use 166133)	
46701	Shock Absorber (Use 166134)	
46702	Shock Absorber (Use 166134)	
BZ 46711	Grommet-Shock Absorber Base	34 Hudson
BZ 46716	Oil Seal Assy-Shock Absorber Piston Rod	34 thru 38 Hud exc 89,35 Terr,93,95,97
46717	Cushion-Shock Absorber Base-Front (Use 157938)	34 Hud
ZF 46718	Retainer-Shock Abs Cushion-Front	34 Hudson,35 thru 1950 All
BZ 46719	Washer-Shock Abs Cushion-Front	34-35 Hudson
ZF 46720	Nut-Shock Abs Base-Frt & Stabilizer Conn	34 Hudson,35 thru 1950 All
46730	Shock Absorber-Front (Use 166133)	34 Terr
CF 46740	Spring Assy-Rear	34 Terr
C 46768	Pan Assy-Oil	34 thru 36 Hudson 8

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 46775	Condenser-Radio Power Supply Unit	34 Hudson-Terr
BM 46791	Screen-Oil Pan Tray Overflow	34 thru 38 Hudson-Terr
46798	Use 48134	
46801	Use 48133	
BX 46804	Brake Shoe & Lining Assy	34 Terr
BX 46805	Brake Shoe & Lining Assy	34 Hudson
46810	Use 48132	
46811	Use 48245	
46819	Use 151584 & 151585	
BX 46825	Brake Lining & Rivets-Package	32-33 Hudson 8
46826	Shock Absorber-Front (Use 166133)	34 Hudson
46827	Shock Absorber-Rear (Use 166134)	
46828	Shock Absorber-Rear (Use 166134)	
46849	Use 48134	
46850	Use 46851	
C 46851	Spring Leaf Kit-Front	34 Hud,35 Hud 6,34-35 Terr
46867	Use 151932	
46868	Use 151933	
46869	Use 151932; For KU Use 151933	
F 46871	Pulley & Shaft Assy-Water Pump	34-35 Hudson-Terr
F 46872	Shaft & Extension Assy-W/Pump Pulley	34-35 Terr
F 46878	Bearing-Front-W/Pump Shaft	34-35 Hudson-Terr
BM 46879	Oil Seal Assy-Front-W/Pump Shaft Brg	34-35 Hudson-Terr
BM 46883	Pin-Bke Shoe Hold Down Spring	34-35 Terr
46894	Use 48915	
BZ 46900	Ring-Steering Gear Adjusting	34 LL,35 HHU,37 thru 39 All,40,41,44,45,48,10,11,12,18, 20,21,22,28,1946-1947 6 Cyl,500
BM 46903	Gauge Assy-Oil Level	34 thru 36 Hudson 8
46914	Use 48049	
46931	Hose Connection Assy-Heater (Use 153815)	34 Hudson-Terr
46934	Use 71170	
BZ 46941	Rod Assy-Vacuum Clutch Piston	34 Terr,35 G-GU-GH
F 46948	Head Grommet-Front-Shock Abs	34 Terr
46949	Shock Absorber-Front (Use 166133)	34 Terr
46950	Shock Absorber-Rear (Use 159203)	34 Terr
F 46951	Grommet-Shock Absorber	34 Terr
C 47020	Drag Link Assy	35 Terr
47022	Drag Link Assy (Use 47028)	35 Hudson 8
C 47024	Drag Link Assy	35 Hudson Custom 8
C 47026	Drag Link Assy	35 Terr
C 47028	Drag Link Assy	35 Hudson 8
C 47030	Drag Link Assy	35 Hudson Custom 8
47054	Use 150570-150572-71608	
47055	Use 150570-150572-71608	
47057	Use 154931-170050-170051	
47058	Steering Arm F/A-RH-RHD (Use 154932-170050- 170051)	35-36 All
C 47061	Tie Rod-F/A	35 G
47062	Gear-Camshaft (Pkg 1-2) (Use 165907)	35 Hudson-Terr
BZ 47063	Clamp Assy-Strg Gear Jacket	35 Hudson-Terr,89,90,98
47064	Tappet-Valve (Use 152646)	35-36 Hud-Terr
A 47068	Radiator Assy-Intl Shell	35 GJ
A 47070	Radiator Assy-Intl Shell	35 Hudson 8
BZ 47088	Outlet Unit-Gas Tank	35 Hudson 6-Terr
BZ 47089	Outlet Unit-Gas Tank	35 Hudson 8
BZ 47090	Gasket-Gas Tank Outlet Unit	35 thru 1950 All
F 47091	Gauge Assy-Gas Tank	35 Hudson-Terr
47097	Piston (Use 166586)	35 thru 39 All
47097	Piston - Size J (Use 166587)	35 thru 39 All
47097	Piston - Size L (Use 166588)	35 thru 39 All
BZ 47099	Gasket-Gasoline Tank Gauge	35 Hudson-Terr
C 47102	Muffler Assy	35-36 Hudson-6
CF 47103	Pipe Assy-Exhaust	35-36 Terr Exc Cv
*C 47106	Core Assy-Radiator	35 G
47110	Plate-Cylinder Support-Rear (Use 159551)	35 thru 39 All,44,45,47,14,14,17
C 47111	Cylinder Head Assy-Std	35 Terr
C 47112	Cylinder Head Assy-Std	35 Hudson 6
C 47113	Cylinder Head Assy-Std	34-35 Hud 8
47117	Use 150378	
F 47118	Gasket-Cylinder Head	34-35 Hud 8
47119	Cap-Radiator (Use 150545)	35 Terr Spec
BM 47121	Grommet-Engine Mounting-Front-Upper	35 thru 1947 6 Cyl
BM 47122	Grommet-Engine Mounting-Front-Lower	35 thru 1947 6 Cyl
BM 47123	Grommet-Engine Mounting-Front-Upper	35 thru 1947 Hudson 8
BM 47124	Grommet-Engine Mounting-Front-Lower	35 thru 1947 Hudson 8

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
47125	Use 47301	
BT 47132	Operating Lever-Lock-Low & Reverse	35 Hudson-Terr
CF 47138	Pipe Assy-Exhaust	35-36 Hudson 6 exc Cv
BT 47160	Sector-Hand Brake Lever	35 Hudson-Terr
BT 47162	Pawl-Hand Brake Lever	35 Hudson-Terr
BT 47163	Spring-Hand Brake Lever Pawl Return	35 Hudson-Terr
47164	Rod-Hand Brake Lever Pawl (Use 48237)	35 All
BT 47165	Spring-Hand Brake Pawl Rod Anti-Rattle	35 Hudson-Terr
BT 47165	Spring-Folding Top Valve Oper Lever	1948 thru 1950 CvBro
C 47170	Cable & Conduit Assy-Hand Brake Lever	35 Hudson-Terr
47174	Use 151932	
47175	Use 151933	
BM 47176	Body Assy-Water Pump	35 Hudson-Terr
F 47178	Impeller-Water Pump Shaft	35 Hudson-Terr
BT 47181	Lever-Trans Cont Shaft-Inner	35 thru 38 Hud-Terr,92,93,95,97
BT 47183	Bellcrank Assy-Trans Cross Shift	35-36-37 Hudson-Terr
BT 47187	Retainer-Trans Cent B/C Bush Seal	35 thru 38 Hudson-Terr,92,93,95,97
BT 47190	Retainer-Trans Cont Shaft Seal	35 thru 39 All
BT 47191	Spring-Trans Cont Lever Fulcrum	35 thru 38 Hudson-Terr,92,93,95,97
BT 47192	Washer-Trans Cent Power Unit Brkt	35 Hudson-Terr
BT 47198	Lever Assy-Trans Cont-Lower	35 thru 38 Hudson-Terr,92,93,95,97
BT 47200	Oil Seal-Trans Cont Lever Fulcrum	35 thru 38 Hudson-Terr,92,93,95,97
BT 47201	Rod End-Trans Cent Switch	35 Hudson-Terr
BT 47202	Lever-Trans Cent Shaft-Lower	35 thru 38 All
BT 47204	Gasket-Contact Switch to Trans Cover	35-36 Hudson-Terr
BT 47205	Shaft Assy-Trans Cent	35 Hudson-Terr
BT 47206	Lock Strap-Shift Rail	35 Hudson-Terr
47208	Spring Assy-Front (Use 153758)	35 Terr
47209	Spring Assy-Front (Use 153758)	35 Hudson 8
HZ 47211	Cover Assy-Front Spring-Front	35 Terr GU
BZ 47212	Cover Assy-Front Spring-Rear	35 Terr GU
BZ 47213	Cover Assy-Front Spring-Front	35 Hudson 8
BZ 47214	Cover Assy-Front Spring-Rear	35 Hudson 8
CF 47215	Spring Assy-Rear-Coaches	35 Hudson-Terr
CF 47216	Spring Assy-Rear-Cpe & Cony	35 Hudson 6-Terr
BZ 47218	Bumper-Front Spring	35 Hudson 6-Deluxe 8-Terr
BZ 47221	Stud-Rear Spring Clip Plate	35 Hudson-Terr
47222	Steering Wheel (Use 48595)	
47223	Steering Wheel (Use 48595)	
BZ 47232	Ball Arm-Steering Gear	35 Hudson (Exc Custom 8)-Terr
BZ 47234	Ball Arm-Steering Gear	35 Hudson Custom 8
BT 47235	Spring-Shift Rail Lock Ball	35 Hudson-Terr
BT 47250	Switch-Trans Cont-Off-On	35 Hudson-Terr
BT 47252	Operating Clip-Trans Cent	35 Hudson-Terr
BT 47255	Stud-Transmission Case	35 thru 39 All exc 89-90-98
BT 47256	Bracket Assy-Trans Bumper	35-36-37 Hudson-Terr
47258	Shock Absorber Assy-Front (Use 159205)	35 Terr
47259	Shock Absorber (Use 1-48798 & 2-47278)	
47260	Shock Absorber Assy-Front (Use 159205)	35 Hudson
47265	Shock Absorber Assy-Rear (Use 159214)	
47266	Shock Absorber Assy-Rear (Use 159204)	
47267	Shock Absorber Assy-Rear (Use 166136)	35 Hud Exp
F 47278	Grommet-Shock Absorber	35 thru 1950 All
47279	Cushion-Shock Abs. Base-Front (Use 157938)	35 thru 38 All
BZ 47288	Plate-Rear Spring Clip-RH	35 Hudson-Terr
BZ 47289	Plate-Rear Spring Clip-LH	35 Hudson-Terr
BZ 47290	Case Assy-Transmission	35 Hudson-Terr
CF 47291	Main Drive Gear Assy-Trans	35 thru 1940 exc Model 40 All
47294	Use 1-48800, 2-48802, 1-48803	
*F 47296	Mainshaft Assy-Trans	35 Hudson-Terr
47297	Use 47296	
F 47298	Shift Sleeve-Trans M/S-Second & High	35 Hudson-Terr
F 47299	Low & Reverse Gear-Trans-M/S	35 Hudson-Terr
BT 47300	Retainer-Trans M/S-Low & Reverse Gear	35 thru 1940 All
CF 47301	Countershaft-Trans	35 Hudson-Terr
*F 47302	Intermediate Gear-Trans Countershaft	35 thru 37 All
47303	Retainer-Trans Cntrshft Inter Gear (Use 47305)	35 Hud-Terr
F 47304	Low & Reverse Gear-Trans Cntrshaft	35 Hudson-Terr
BT 47305	Retainer-Trans Cntrshaft Thrust Washer	35 thru 1940 All
CF 47306	Reverse Gear & Shaft Assy-Trans	35 Hudson-Terr
F 47308	Reverse Gear (sliding)-Trans	35 Hudson-Terr
47310	Shifter Assy-Trans Low & Reverse (Use 152696)	35-36 All
47312	Shifter Fork-Trans-Second & High (Use 152698)	35 Hud-Terr
47313	Switch Assy-Trans Cross Shift (Use 48701- 2,47946, 47314	35 Hud- Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 47314	Switch Rod-Trans Cont Cross Shift	35-36-37 Hudson-Terr
47315	Lever Assy-Trans Cont-Upper (Use 155622)	35 thru 37 All
BT 47317	Swivel Assy-Hand Brake Cable End	35 Hudson-Terr
BT 47323	Selector & Wires Assy-Trans Cont	35 Hudson-Terr
BT 47324	Loom-Trans Cont Selector Wire	35 thru 39 exc 89-90-98
BT 47326	Conn Clip-Trans Cont Selector Wires	35 thru 39 exc 89-90-98
47328	Use 48567 & 48745	
BT 47331	Insert-Trans Cont Switch Clip	35-36-37 Hudson-Terr
47332	Housing Assy-Clutch (Use 1-155499,1-170069, 1-170070,2-71680)	35-36-37 Hudson-Terr,80 Co-Cpe-Sed
47333	Radiator Assy (Use 47068)	35 GJ
A 47334	Radiator Assy	35 Hudson 6
BT 47342	Lever Assy-Brake Control	35 Hudson-Terr
BT 47345	Pivot Pin & Bke Cont Lev	35 Hudson-Terr
BT 47349	Push Rod Assy-Brake Pedal	35 Hudson-Terr
BT 47351	End-Brake Pedal Push Rod Adj	35 Hudson-Terr
BZ 47352	Spring-Brake Pedal Push Rod	35-36 Hudson-Terr
BT 47365	Mounting Bracket-Front Brake Cable	35 Terr
CF 47367	Cable Assy-Front Brake-RH	35 Terr
CF 47368	Cable Assy-Front Brake-LH	35 Terr
CF 47369	Cable Assy-Front Brake-RH	35 Hudson exc Custom 8
CF 47370	Cable Assy-Front Brake-LH	35 Hudson exc Custom 8
C 47371	Cable Assy-Front Brake-RH	35 Hudson Custom 8
C 47372	Cable Assy-Front Brake-LH	35 Hudson Custom 8
CF 47373	Cable Assy-Rear Brake-RH	35 Hudson exc Custom 8 - Terr
CF 47374	Cable Assy-Rear Brake-LH	35 Hudson exc Custom 8 - Terr
BT 47377	Return Spring-Brake Cont Lever	35 Hudson-Terr
47378	Use 48611	
BT 47383	Pipe Assy-Short-Trans Cont Power Unit	35 Hudson-Terr
BT 47387	Pipe Assy-Long-Trans Cont Power Unit	35-36 Hudson 8
47389	Use 1-48773,1-48774,2-71556	
BZ 47390	Mounting Bracket-Front Brake Cable-RH	35 Hudson
BX 47394	Brake Shoes Assy	35 Terr
BX 47395	Brake Shoes Assy	35 Hudson exc Custom 8
BZ 47428	Hub Cap-Tire Cover	35 Hudson Custom 8
C 47429	Hub Assy-Front	35 Terr
C 47430	Hub Assy-Front	35 Hudson exc Custom 8
C 47432	Hub Complete-Rear	35 Hudson 6
C 47433	Hub Complete-Rear	35 Hudson Spec-Del 8
BZ 47437	Dust Shield-Rear Brake Drum	35 Hudson exc Custom 8 - Terr
BZ 47438	Hub-Front (Use 47429 for G & GU, 47430 for GH-HT-HU)	35 Hudson exc Custom 8 - Terr
BZ 47439	Hub-Rear	35 Hudson 6-Terr
47440	Use 47433	
	Brake Drum Assy-Rear (Use 47432 For GH, 47433 for HT-HU)	35 Hud exc Custom 8
47442	47433 for HT-HU)	
47443	Use 47429	
47444	Use 47430	
C 47446	Brake Drum-Rear	35 Hudson exc Custom 8
BZ 47448	Washer-Rear Spring Stabilizer Bar	35 Hudson-Terr
BZ 47450	Bushing-Torsion Bar Mounting Brkt	35 Hudson-Terr
BZ 47452	Spacer-Torsion Bar Bracket Bushing	35 Hudson-Terr
BZ 47453	Arm-Rear Spring Stabilizer	35 Hudson-Terr
BZ 47454	Grommet-Rear Spring Stabilizer Arm	35 Hudson-Terr
BZ 47455	Bronze Bushing-Stabilizer Grommet	35 Hudson-Terr
BZ 47456	Bolt-Stabilizer Arm	35 Hudson-Terr
BZ 47457	Sleeve-Stabilizer Arm Bolt	35 Hudson-Terr
BZ 47458	Connection-Stabilizer Arm	35 Hudson-Terr
BZ 47459	Cushion-Stabilizer Connection-Rubber	35-36 Hudson-Terr
BZ 47460	Retainer-Stabilizer Conn Cushion	35-36 Hudson-Terr
BZ 47461	Sleeve-Stabilizer Conn Spacer	35-36 Hudson-Terr
BZ 47462	Plate-Stabilizer-RH	35-36 Hudson-Terr
BZ 47463	Plate-Stabilizer-LH	35-36 Hudson-Terr
BZ 47466	Switch Assy-Lighting	35 Hudson-Terr GU
BO 47481	Horn Assy-LH	35 Hudson Del-Custom 8
47483	End Assy (Use 155005)	35 Terr G
47496	Clamp-F/A Tie Rod (Use 153500)	35 Terr G
BZ 47548	Reinforcement-Frame-RH	35 thru 39 All,1940 exc Cv
BZ 47549	Reinforcement-Frame-LH	35 thru 39 All,1940 exc Cv
BZ 47553	Bracket-Frame Front Spring-Front-RH	35 Terr,36 Conn
BZ 47554	Bracket-Frame Front Spring-Front-LH	35 Terr,36 Conn
BZ 47555	Bracket-Frame Front Spring-Front-RH	35 Hudson 8
BZ 47556	Bracket-Frame Front Spring-Front-LH	35 Hudson 8
BZ 47557	Bracket-Rear Shock Absorber-RH	35 Hudson-Terr
47567	Gasket Paste-2 oz Tube (Use 164848)	All Models

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	47568 Gasket Paste-8 oz Tube (Use 164848)	All Models
F	47575 Cable Assy-Battery to Starter	35 Hudson-Terr
BM	47598 Thrust Washer-Rear-Water Pump Shaft	35 Hudson-Terr
BT	47599 Brake Shoes Assy-2 Shoes	35 Hudson Custom 8
BO	47602 Button & Wire Assy-Starter	35 Hudson-Terr
BM	47603 Fuel Plate-HC Cyl Head	35 Hudson-Terr
ZF	47605 Cup Washer-Frt Shk Abs Base Cush	35 thru 1950 All
A	47617 Engine Guard-RH-Front	35-36 Terr
A	47618 Engine Guard-RH-Rear	35 Hudson 6-Terr
A	47619 Engine Guard-RH-Front	35-36 Hudson 6
CF	47620 Pipe Assy-Exhaust	35-36 Hudson 8
BM	47622 Cover-Exhaust Pipe-Lower-Front	35-36 Hudson 8
BM	47623 Cover-Exhaust Pipe-Lower-Rear	35-36 Hudson 8
BT	47624 Spring-Reverse Shifter Lever Plunger	35 thru 1940 All
	47625 Steering Wheel (Use 48595)	
BZ	47626 Button-Horn	35 Hudson Bro
BZ	47627 Cover-Horn Button Control	35 Hudson Bro,36 All
BO	47630 Cylinder, Keys & Clip Assy-Ignition Coil	35 thru 1950 All
	47631 Cyl Keys & Clip Assy-Ignition Coil (Use 47630)	35 thru 38 All
	47632 Switch Assy-Lighting (Use 157048,150285 & 170553)	35 G
BT	47633 Pin-Clutch Throwout Finger	35 thru 1950 All
	47639 Use 47290	
BT	47641 Spring-Shift Rail Lock Ball	35 thru 39 All,1941 with OD
BT	47642 Seat-Reverse Shifter Lever Locator	35 thru 1940 All
	47648 Zerk-Clutch Housing (Use 158345)	35 thru 39 All
BZ	47737 Bracket-Body Bolt	34 thru 1947 All
BO	47764 Bracket-Horn-RH	35 Hudson-Terr GU
BO	47765 Bracket-Horn-LH	35 Hudson-Terr GU
C	47772 Engine Assy-Std Head	35 Terr G
C	47796 Engine Assy-Std Head	35 Hudson 8
C	47799 Engine Assy-HC Head	35 Hudson 8
BT	47831 Lever Assy-Hand Brake	35 Terr G,61
C	47834 Brake Cable Assy-RH-Rear	35 Hudson Custom 8
C	47835 Brake Cable Assy-LH-Rear	35 Hudson Custom 8
BT	47897 Clip-Wire	35 thru 1947 All,1948-1949-1950 All RHD,500 All
	47944 Switch Assy-Trans Cross Shift (Use 411701,48702)	35 Hud-Terr
	47945 Sleeve-Trans Cont Sw Rod (Use 48702)	35 All
BT	47946 Nut-Special-Trans Cont	35 thru 37 All
F	47948 Hose-Radiator Inlet	35 Hudson 6
CF	47954 Pipe Assy-Tail	35 Terr
CF	47955 Pipe Assy-Tail	35 Hudson exc Custom 8
CF	47956 Pipe Assy-Tail	35 Hudson Custom 8
BO	47967 Suppressor-Spark Plug	35 G
BO	47968 Suppressor-Distributor	35 Hudson-Terr
BO	47979 Regulator-Generator Charge	35-36 Hudson-Terr
BT	47982 Seal-O/D Control Wire	480 Series
	48000 Spring Assy-Front (Use 153758)	35-36 Terr Comm
	48002 Spring Assy-Front (Use 153758 & 45290)	35 Hudson 8 Exp
BO	48032 Coil Assy-Radio Antenna	35 Hudson-Terr
BO	48049 Retainer-Tone Control Knob	35 Hudson-Terr
	48076 Use 48078	
BT	48077 Connector Assy-Selector Wires-Male	35-36 Hudson-Terr
BT	48078 Connector Assy-Selector Wires-Female	35-36 Hudson-Terr
	48089 Screw-Shock Abs Base Oil Filler (Use 151903)	35 Hud
	48090 Gasket-Shock Filler Screw (Use 151904)	35 Hud
	48092 Use 151902	
	48093 Use 151901	
	48094 Gasket-Shock Rod Guide (Use 159146)	35 All,36-37 Hud
BZ	48103 Guide-Shock Abs Piston Rod	35 thru 38 Terr,83,84,85,87,92
BZ	48123 Brake Shoes Assy	35 Terr
F	48132 Brake Shoe Lining Pkg	35 Terr
BX	48133 Brake Shoe Lining Pkg	35 Terr Comm
F	48134 Brake Shoe Lining Pkg	35 Hudson exc Custom 8
	48135 Use 48245	
BZ	48149 Bumper-Front Spring	35 Hudson-Terr
	48150 Battery Assy-17 Plate (Use 302797)	35 thru 1947 6 Cyl
BZ	48179 Gasket-Gas Tank Ext Sleeve	35 Hud-Terr,36-37 Comm
BZ	48180 Gasket-Gas Tank Ext Sleeve	35 Hud-Terr,36-37 Comm
	48218 Use 48751	
BT	48237 Rod-Hand Brake Lever Pawl	35 Hudson-Terr
BT	48238 Gasket-Solenoid Retainer	35 Hudson-Terr
ET	48239 Gasket-Power Unit	35 thru 39 All,1942 thru 1950 with HDM
	48244 Knob-Lighting Switch (Use 150285)	35 Hudson-Terr
F	48245 Brake Shoe Lining Package	32 Essex,33 Hud 6,34-35 Hud 8
BT	48255 Dust Cover-Diaphragm Housing	35 Hudson-Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 48256	Guard-Diaphragm Rod	35 thru 39 All,1942 thru 1950 with HDM
C 48260	Leaf #1-Front Spring	35 Hudson-Terr
C 48261	Leaf #2-Front Spring	35 Hudson-Terr
C 48276	Leaf #1-Front Spring	35-36 Export-Comm
BZ 48316	Center Bolt-Spring	35 Hudson-Export
48318	Center Bolt-Spring (Use 163723)	35 Hudson
BZ 48319	Clip-Spring Rebound	35 G-GU,36 Comm,90 Cab-CabPu-Panel-Station
BZ 48320	Clip-Spring Rebound-#1 & #4	1940 thru 1947 All
BT 48334	Nut-Flared Tube	35 thru 1947 All,1948 thru 1950 with VD-HDM or SMD
BT 48335	Elbow-Power Unit Conn	35 thru 39 All exc 89-90-98
F 48339	Oil Seal-Rear Wheel Bearing	35 Terr
F 48340	Oil Seal-Rear WheelBrg Adjusting Cap	35 Hudson
48341	Oil Seal Assy-R/A Drive Shaft (Use 156756)	35 Hud 6-Terr UCo
F 48342	Oil Seal Assy-R/A Drive Shaft	35 Hud 8-Comm exc UCo
48343	Oil Seal-R/A Drive Pinion (Use 155384)	35 thru 38 Hudson-Terr
48349	Use 48751	
BT 48401	Cyl Assy-Electric Hand Power Unit	36 Hudson-Terr
BT 48409	End Plate Assy-Power Cyl	35-36 Hudson-Terr
48411	Seal-Power Cyl End Plate Piston	35 thru 39 All,1942 thru 1950 with HDM
BT 48412	Lock-Power Cyl End Plate Piston Seal	35 thru 39 All,1942 thru 1950 with HDM
BT 48413	Felt Washer-Power Cylinder Intake	35 thru 39 All
BT 48416	Piston Assy-Trans Control Power Unit	35-36 Hudson-Terr
BT 48418	Plate-Electric Hand Gear Shaft Cyl Piston-Center	35-36 Hudson-Terr
BT 48419	Packing-Electric Hand Power Cyl Piston	35-36 Hudson-Terr
BT 48420	Packing Ring-Electric Hand	35-36 Hudson-Terr
BT 48421	Felt Assy-Electric Hand Cyl Piston	35-36 Hudson-Terr
BT 48423	Retainer-Electric Hand Cyl Piston Felt	35-36 Hudson-Terr
BT 48425	Rod-Gear Shift Cylinder	35-36 Hudson-Terr
BT 48426	Nut-Gear Shift Cylinder Rod	35 thru 39 All,1942 thru 1950 with HDM
BT 48427	End-Power Cyl Piston Rod	35 thru 39 All
BT 48428	Stay Bolt-Power Cyl End Plate	35 thru 39 All
BT 48429	Elbow-Power Cylinder Tube	35 thru 39 All,1942 thru 1950 with HDM
BT 48432	Diaph Assy-Cross Shift	35-36 Hudson-Terr
BT 48433	Diaphragm-Cross Shift	35-36 Hudson-Terr
BT 48435	Flanged Plate-Diaphragm	35-36 Hudson-Terr
BT 48436	Washer-Cross Shift Diaphragm	35 thru 39 All,1942 thru 1950 with HDM or SMD
BT 48437	Rod-Cross Shift Diaphragm	35-36-37 Hudson-Terr
BT 48438	Retainer-Diaphragm Rod Guard	35 Hudson-Terr,1942-1946-1947 with HDM
BT 48444	Spring-Cross Shift Diaphragm Return	35 to 37 Hudson-Terr
BT 48445	Plug-Diaphragm Cyl Mounting	35 thru 39 All,1942 thru 1950 with HDM
BT 48446	Gasket-Diaphragm Cyl Mounting Plug	35 thru 39 All,1942 thru 1950 with HDM
BT 48448	Selector Valve & Tube Assy-Electric Hand	35 Hudson-Terr
BT 48450	Gasket-Selector Valve to Bracket	35 thru 39 All,1942 thru 1950 with HDM
BT 48456	Expansion Plug-Selector Valve Body	35 thru 39 All,1942 thru 1950 with HDM
BT 48465	Nut-HDM Power Cyl to Sel Valve Tube	1948-1949-1950
BT 48466	Elbow-Selector Valve to Cyl Tube	35 thru 39 All,1942 thru 1950 with HDM
BT 48475	Terminal-Solenoid Wire	35 thru 39 All
BT 48493	Shaft Assy-Selector Switch	35 thru 37 Hudson-Terr
BT 48505	Selector Lever Assy	35 Hudson-Terr
48511	Use 48721	
BT 48524	Cut Out Switch-Selector	35 thru 39 All
BT 48529	Plate & Guide Assy-Electric Hand	35-36 Hudson-Terr
BT 48532	Shift Block Assy-Main Contact	35 Hudson-Terr
BT 48537	Cover-Main Contact Plate	35-36 Hudson-Terr
48541	Check Valve-Selector Valve (Use 302753)	35 thru 1941 All,1942 thru 1950 with VD-HDM or SMD
48542	Nut-Selector Valve Check Valve	35 thru 1941 All,1942 thru 1950 with VD-HDM or SMD
BT 48543	Harness-Electric Hand-Upper	36 thru 39 All
BT 48561	Shift Lev & Pin Assy-Main Contact Switch	35-36 Hudson-Terr
BT 48567	Cover Assy-Transmission	35 Hudson-Terr
48569	Use 48751	
BZ 48571	Plug-Front Spring Bushing	35 thru 1950 All
BZ 48572	Plug-Rear Spring Bushing-Tapped	35 Hudson-Terr
BZ 48573	Plug-Rear Spring Bushing-Plain	35 thru 38 Hud-Terr,92,93,95,97
F 48582	Gasket-Exhaust Manifold-End	35-36 Hudson 6 Terr
F 48583	Gasket-Exhaust Manifold-Center	35-36 Hudson 6 Terr
F 48584	Gasket-Exhaust Manifold-End	35-36 Hudson 8
F 48585	Gasket-Exhaust Manifold-Intermediate	35-36 Hudson 8
F 48586	Gasket-Exhaust Manifold-Center	35-36 Hudson 8
F 48587	Gasket-Intake Manifold to Cyl-Small	34-36 Hudson 8
48588	Gasket-Intake Manifold to Cyl (Use 33172)	35-36 Hudson 8
F 48589	Gasket-Intake Manifold to Cyl-Small	35-36 Hudson,6-Terr
F 48590	Gasket-Intake Manifold to Exh Man	35 thru 1947 All 6 Cyl
F 48591	Gasket-Intake Manifold to Exh Man	35-36 Hudson 8
BZ 48592	Insulator-Battery Clamp Bolt	35 Hudson-Terr Comm

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	48594 Steering Wheel-Black (Use 48595)	32 thru 36 Terr,34 LTS
C	48595 Steering Wheel-Black	35 Hud exc Bro,63,64,66
	48596 Steering Wheel-Gray (Use 48595)	35 Hudson Bro
BT	48600 Hose-Electric Hand Intake	35-36 Hudson-Terr
BT	48601 Pipe-Electric Hand Intake	35 Hudson-Terr
BT	48602 Pipe-Electric Hand Intake	35-36 Hudson-Terr,92,93,95,97
BT	48603 Clip-Intake Pipe	35 thru 39 All
BT	48606 Pipe Assy-Electric Hand Vac	35-36 Hudson-Terr
BZ	48609 Pipe Assy-Fuel Pump to Carb	35-36 Hudson 8
C	48611 Manifold-Intake	35 Terr 6 Hudson 6
C	48613 Stud - Int Manifold	35-36 Hud-Terr,70,71,73B,78,80,81,88,89,90,92,98,40, 48,10,18,11X,12X
BM	48615 Air Cleaner-Use with Electric Hand	35 Hudson-Terr
BT	48616 Hose-Electric Hand Intake	35-36 Hudson-Terr
	48620 Dimmer Switch (Use 150670)	35 Hud-Terr
BO	48642 Generator Charge Control Kit	1935,1936
	48647 Extension-Tail Pipe (Use 166496)	35 thru 1942 All
	48648 Shock Absorber Assy-Rear (Use 159204)	35 Terr
	48649 Shock Absorber Assy-Rear (Use 159214)	35 Terr
	48653 Use 151584 & 151586	
	48660 Shock Absorber (Use 159204)	
BX	48671 Drive Gear-R/A-3 5/9-1	35 Hud 8,64,65,71 thru 77,81 thru 85,87
BT	48673 Cap-Trans Lock Ball	35 thru 1940 exc 89
BT	48674 Plunger-Trans Shift Rail Lock	35 thru 1940 exc 89
BT	48675 Rod-Trans Shift Rail Lock	35 thru 1940 exc 89
BT	48676 Sleeve-Trans Shift Rail Lock Rod	35 thru 1947 exc 89
BT	48677 Link-Trans Shift Rail Lock Rod	35 thru 1940 exc 89
BT	48678 Guide-Trans Shift Rail Lock Rod	35 thru 1940 exc 89
BT	48679 Shim-Trans Shift Rail Lock Rod	35 thru 1940 exc 89
BT	48680 Shim-Trans Shift Rail Lock	35 thru 1940 exc 89
BT	48685 Shaft & Lever Assy-Cl Shifter	35 Hudson-Terr
BT	48687 Lever Assy-Cl Shifter Shaft	35-36 Hudson-Terr
BT	48688 Lever Assy-Cl Shifter Shaft RHD	35-36 Hudson-Terr
BT	48691 Lever-Trans Lock Operating	35 thru 1940 All exc 89-90-98
BT	48700 Power Unit Comp-Electric Hand	35-36 Hudson-Terr
BT	48701 Switch Assy-Elec Hand Cross Shift	35-36-37 Hudson-Terr
BT	48702 Sleeve-Cross Shift Sw Rod	35-36-37 Hudson-Terr
BT	48705 1 oz Grease - Electric Hand	35 Hudson-Terr
BT	48706 Guard-Cylinder Diaphragm Rod	35 thru 39 All,1942-1946-1947 with HDM
BT	48709 Body Assy-Selector Valve	35 thru 39 All,1942 throu 1950 with HDM
BT	48711 Plunger Assy-Cylinder Valve	35 thru 39 All,1942 throu 1950 with HDM
	48713 Use 48711	
BT	48715 Spring-Solenoid Valve Plunger	35 thru 1941,1942 thru 1950 with VD-HDM or SMD
BT	48719 Cover Plate Assy-Electric Hand Sel Valve	35-36 Hudson-Terr
BT	48721 Base & Wire Assy-Electric Hand Selector	35-36 Hudson-Terr
	48723 Use 153455	
	48724 Pinion-Trans Spdo 3-5/9 to 1 (Use 153458)	35 Hud,64,65
BT	48729 Solenoid Assy-Electric Hand and HDM	35 thru 39 All,1942 thru 1950 with HDM
BT	48736 Cover-Solenoid	35 thru 39 All,1942 thru 1950 with HDM
BT	48737 Bolt-Solenoid Cover	35 thru 39 All,1942 thru 1950 with HDM
BT	48738 Gasket-Solenoid Cover Bolt	35 thru 39 All,1942 thru 1950 with HDM
BT	48739 Washer-Solenoid Housing	35 thru 39 All,1942 thru 1950 with HDM
BT	48740 Retainer-Solenoid	35 thru 39 All,1942 thru 1950 with HDM
BT	48741 Gasket-Solenoid Ret	35 thru 39 All,1942 thru 1950 with HDM
BT	48744 Plate and Block Assy-Electric Hand	35-36 Hudson-Terr
BT	48745 Shift Block Assy-Electric Hand	35 Hudson-Terr
BO	48751 Antenna-Service Kit	35 Hudson-Terr
BO	48757 Insulator-Radio Antenna	35 thru 39 All
BO	48760 Anchor Clip-Radio Antenna	35-36 Hudson-Terr
BO	48765 Choke-Radio Antenna	35 Hudson-Terr
BZ	48768 Piston-Rear Shock Absorber	35 thru 39 All
BZ	48769 Spacer-Shock Abs Piston	35-36 Terr
	48770 Valve-Shock Absorber (Use 154210)	35-36 Terr
	48771 Spring-Shock Abs Valve (Use 154211)	35-36 Terr
BT	48773 Hose-Electric Hand Power Unit	35-36 Hudson-Terr
BT	48774 Reinf-Electric Hand Unit Hose	35-36 Hudson-Terr
	48786 Shock Abs Assy-Rear (Use 166135)	35 Hudson
	48787 Shock Absorber Assy-Rear (Use 166136)	35 Hudson-Export
	48797 Shock Abs Assy-Front (Use 159205 & 47278)	35 Terr
BZ	48798 Shock Absorber Assy-Front	35 Terr-Export
F	48800 Gear Assy-Main Shaft Inter	35-36-37 Hudson-Terr
F	48802 Thrust Washer-Main Shaft Inter Gear	35 thru 1940 All
F	48803 Retainer-Trans M/S Inter Gear	35 thru 37 Hudson-Terr
BZ	48824 Valve-Rear Shock Absorber	35 Terr,38-39 Cab-CabPu-Panel-Sta

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 48825	Valve-Rear Shock Absorber	35-36 Terr,89,90,98
BM 48841	Thermostat-Std Heater	36 All,70,71
BO 48842	Ground Strap Assy	35 Terr G,37 All
BZ 48845	Brg Assy-Strg Gear Worm	36 thru 39 All,40,41,44,45,48,10,11,12,18,20,21,22,28, 1946-1947 6 Cyl,500
BT 48854	Shaft & Lever Assy-Clutch Shifter	35 Hudson-Terr
BT 48855	Interlocking Device-Service Kit	33K-KU-KT,34-35 All
BT 48876	Plunger Assy-Selector	35 thru 39 All,1942 thru 1950 with HDM
BT 48878	Washer-VD Solenoid Plunger Disc	35 thru 1950 All
BT 48887	Connector-Selector to Cylinder Tube	35 thru 39 All,1942 thru 1950 with HDM
C 48894	Front Spring Leaf Service Kit	35 Hudson 8
BM 48910	Stud-Cylinder Head-Short-3-1/2"	35 Hudson 6-Terr
BM 48911	Stud-Cylinder Head-Short-3-23/32"	35 Hudson 6-Terr
BM 48912	Stud-Cylinder Head-Medium 3-13/16"	35 Hudson 6-Terr
BM 48914	Stud-Cylinder Head-Long-5-13/32"	35 Hudson 6-Terr
C 48915	Shaft & Roller Tooth Assy-Steering Gear-LHD	35 Hudson
48929	Shock Absorber Assy-Front (Use 166133)	34 LT-LTS-LL
48930	Shock Absorber Assy-Rear (Use 166134)	34 LT-LTS-LL
F 48931	Bushing-Shock Absorber	34 LT-LTS-LL
50102	Guide-Rocker Arm Push Rod-(Use 155656)	Essex 4
50122	Use 44714	
F 51271	Dust Cap-Universal Joint	Esx 4,29 Esx,30 thru 35 All,60 thru 65,70 thru 75,80 thru 85,89,90,92,93,95,41,44,45,40-10-20 with std engine ,17-18-27-28 with OD,10-20 With L engine,11,12,14,15, 21, 22,24,25
BZ 51272	Felt Washer-Universal Joint	Esx 4,29 thru 33 exc 29 Hud
F 51275	Retainer-Universal Joint Dust Washer	Esx 4,29 Esx,30 thru 35 All,60 thru 65,70 thru 75,80 thru 85,89,90,92,93,95,41,44,45,40-10-20 with Std Engine, 17-18-27-28 with OD,10-20 with L Engine,11,12,14,15,21, 22,24,25
BX 51501	Bushing-F/A Spindle Pin-Lower	Essex 4
BX 51646	Key-Rear Axle Drive Shaft	Esx 4,27 thru 33 exc 28-29 Hudson Esx
BX 51677	Retainer-R/A Dr Shaft Felt Washer	Esx 4,27 thru 31 exc 28-29 Hud
BX 51678	Retainer-R/A Dr Shaft Felt Washer	Esx 4,27 thru 31 exc 28-29 Hud
BM 60011	Bushing-Camshaft-Rear	24 thru 29 Essex
BM 60019	Sprocket-Camshaft	30-31 Hudson-Essex
BM 60028	Felt Washer-Front Cover	24 thru 32 Esx,30-31-32-33 Hud
BM 60041	Stud-Main Bearing	24 thru 27 All,30 thru 37 All
60043	Ring-Exhaust Manifold (Use 36334)	24 thru 29 Essex
60047	Gasket-Exhaust Manifold (Use 36334)	24 thru 29 Essex
BM 60049	Gasket-Water Inlet Elbow	24 thru 31 Essex
BM 60063	Ring-Piston Pin Lock	33 thru 1947 All,1948 thru 1950 8 Cyl
BM 60075	Packing-Exhaust Manifold	24 thru 29 Essex
BM 60076	Stud-Short-Cyl Head	24 thru 31 Essex
60082	Use 1-33872, 1-1385	
60099	Plate-Valve Tappet	27 thru 33 All
BM 60104	Retainer-Valve Spring	24 thru 27 All,28-29 Esx,30 thru 35 All, 38 thru 1947 All,1948 thru 1950 8 Cyl
BM 60106	Pin-Tappet Roller	24 thru 33 exc 28-29 Hudson
BM 60109	Nut-Tappet Screw	24 thru 33 exc 28-29 Hudson
BM 60115	Bushing-Oil Pump	24 thru 29 Essex
BM 60117	Spring-Oil Pump	24 thru 27 Essex
BM 60118	Bushing-Dist Shaft	24 thru 32 Essex,30-33 Hudson
BM 60124	Shaft-Oil Pump Worm	24 thru 29 Essex
BM 60127	Clamp-Generator Drive	24 thru 29 Essex
60139	Chain-Timing (Use 35386)	24 thru 31 Essex,30-31 Hud
BM 60144	Bushing-Upper-Dist Shaft	24 thru 32 Essex,30 thru 33 Hud
BM 60145	Shaft-Dist Drive	24 thru 32 Essex,31 thru 33 Hud
BM 60148	Gasket-Oil Pump	24 thru 29 Essex
BM 60156	Stud-Fan Arm Locking	24 thru 30 Essex,30 Hudson
BX 60200	Shim-Thick-F/A Steering Knuckle	24 thru 28 Essex
BX 60206	Ball-Steering Arm	24 thru 32 Essex,30 thru 33 Hud
BM 60212	Gasket-Eccentric Adj	24 thru 29 Essex
60219	Use 170058	
BT 60306	Plate-Clutch Driven	24-25-26 Essex
BT 60312	Retainer-Clutch Thrust Bearing	24 thru 26 Essex
BT 60315	Gasket-Clutch Cover	24 thru 26 Essex
60328	Use 65126	
BT 60336	Cap-Trans Main Shaft Front Bearing	24 thru 26 Essex
BT 60346	Gasket-M/S Front Cap	24 thru 29 Essex
BT 60348	Felt Washer-Front-Trans M/S.	24-25 Essex
BT 60352	Shim-Thick-Trans M/ S	24 thru 31 Essex,30-31 Hudson
BT 60361	Spring-Shift Lock Plunger	28 thru 32 Essex,30 thru 32 Hudson
BT 60364	Spring-Control Lever	24 thru 31 Esx,30-31 Hudson
BZ 60380	Bushing-Pedal Bracket	24 thru 32 Esx,30-31-32 Hudson
BZ 60388	Link-Clutch Pedal Control	24 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 60390	Shaft-Pedal Control	24 thru 32,Esx,30 thru 32 Hudson
BT 60399	Cover-Control Lever	24 thru 31 Esx,30-31 Hudson
BT 60406	Lock Screw-Control Lever	24 thru 31 Esx,30 Hudson
60425	Gasket-Control Housing (Use 65743)	24 thru 30 Essex,30 Hudson
BZ 60444	Sleeve-Front & Rear Spring Bolt	24 thru 32 Esx,30-31-32-33 Hud
BZ 60460	Shackle-Tapped-Spring	24 thru 29 Essex
60461	Use 38059	
60462	Use 38060	
BX 60491	Felt Washer-R/A Wheel Hub	24 thru 32 Esx,30-31-32 Hudson
BX 60496	Button-R/A Shaft	24 thru 31 Essex,30-31 Hudson
BX 60498	Felt Washer-Pinion Nut	24 thru 28 Essex
BX 60501	Lock-Pinion Bearing Nut	24 thru 29 Essex
BX 60503	Retainer-Pinion Washer	24 thru 29 Essex,29-31 Dover
BX 60505	Cover -R/ A Housing	24 thru 29 Essex
BX 60511	Bushing-Lower-Pivot Pin	24-25-26 Essex
BX 60518	Bushing-Steering Arm Yoke Pin	24 thru 27 Essex
BZ 60522	Washer-Front Wheel	24 thru 29 Essex
BZ 60523	Plate-Front Wheel-Outer	24 thru 29 Essex
BX 60528	Pin-Tie Rod Yoke	24 thru 27 Essex
BX 60529	Spider-R/A Diff	24 thru 31 Esx,30-31 Hud
BZ 60532	Ball Seat-Drag Link	30 thru 36 Esx 32 Terr,1940 thru 1947 All, 1948-1949-501 thru 504 LHD
BZ 60533	Plug Drag Link	24 thru 27 All,28-29 Hud,30 thru 37 All 80 thru 88,92 thru 97,1940 thru 1950 All
BZ 60534	Spring-Drag Link	24 thru 32 Esx,30-31-32 Hud
BM 60558	Gasket-Carb	24 thru 28 Essex
BM 60559	Tube-Oil Reservoir Filter to Crank Case	24 thru 29 Essex
BZ 60597	Spring-Acc Lever	24 thru 28 Essex
60648	Use 40675	
BZ 60664	Clip-Battery Cable	24 thru 36 All,1940 All
BM 60681	Clamp-Tappet Guide	24 thru 1947 exc 28-29 Hudson,1948 thru 1950 8 Cyl
60701	Washer-Camshaft (Use 162180)	24 thru 38 All exc 28-29 Hud
BZ 60711	Spring-Ace Lever	24 thru 32 Essex,30-32-33 Hudson
BZ 60719	Journal-Universal Joint	24 thru 33 exc 28-29 Hud
BZ 60725	Bushing-Universal Joint	24 thru 33 exc 28-29 Hud
60728	Use 62042	
BZ 60729	Clamp-Muffler Tail Pipe	24 thru 30 Essex,30 Hudson
60885	Use 29180	
BM 60925	Drive Shaft-Generator	24 thru 29 Essex
BM 60926	Gasket-Carb Body Upper	24 thru 28 Essex
BM 60928	Spring-Mixture Control	24 thru 28 Essex
BM 60938	Sleeve-Generator Shaft	24 thru 29 Essex
BT 60950	Lever Assy-Trans Control	27 thru 31 Essex
BM 60976	Cap-Carb Float Cover	24 thru 28 Essex
BT 61034	Drive-Plate-Clutch	24 thru 26 Essex
BR 61035	Pressure Plate-Clutch	24-25-26 Essex
BT 61057	Gear-High & Intermediate	27 thru 29 Essex
BM 61074	Plug-Camshaft Bearing	24 thru 1940 exc 28-29 Hudson
BM 61213	Spindle-Fan	24 thru 27 Essex
BM 61214	Hub-Fan	24 thru 27 Essex
61222	Stud-Long-Cyl Head (Use 150380)	27 thru 31 Essex
C 61246	Drive Shaft-R/A	24 thru 29 Essex
BM 61359	Oil Gauge	24 thru 31 Essex
F 61360	Guide-Valve Stem	24 thru 35 exc 28-29 Hudson
BM 61368	Side Plate Complete-Cylinder	24 thru 29 Essex
C 61373	Tail Pipe Assy-Muffler	24 thru 29 Essex
BM 61431	Plate-Eccentric Adj	24 thru 29 Essex
BZ 61434	Nut-Dem Rim Bolt	24 thru 31 All
61435	Use 63605	
BM 61440	Conn Rod-Complete-LH-Rebabbed	24 thru 27 Essex
BM 61446	Bolt Lock-Motor Plate	24 thru 1946 exc 28-29 Hudson
BT 61475	Spring-Brake Lever	24 thru 33 exc Hud 6
BT 61481	Bronze Washer-Front-Trans M/S	24 thru 28 Essex
BT 61483	Steel Washer-Rear-Trans M/S	24 thru 32 Essex,30-31 Hud
BT 61484	Bronze Washer-Rear-Trans M/S	24 thru 31 Essex,31 Hudson
BX 61487	Steering Spindle-F/A-RH	24 thru 27 Essex
BX 61492	Dust Washer-Spindle Pivot Pin	28 thru 31 Essex,30-31 Hudson
MF 61512	Screw-Tappet Adjusting	24 thru 1947 exc 28-29 Hudson,1948 thru 1950 8 Cyl
61516	Use 33331	
BM 61540	Bearing-Center Lower-Crankshaft.	24 thru 27 Essex
BM 61569	Oil Ring-Generator Drive Shaft	24 thru 30 Essex,30 Hudson
BM 61576	Plunger-Oil Pump Dist	24 thru 28 Essex
BM 61578	Spring-Oil Pump Plunger	24 thru 31 Essex,30-31 Hudson
BZ 61587	Bushing-Strg Gear Worm Wheel	24 thru 27 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 48825	Valve-Rear Shock Absorber	35-36 Terr,89,90,98
BM 48841	Thermostat-Std Heater	36 All,70,71
BO 48842	Ground Strap Assy	35 Terr G,37 All
BZ 48845	Brg Assy-Strg Gear Worm	36 thru 39 All,40,41,44,45,48,10,11,12,18,20,21,22,28, 1946-1947 6 Cyl,500
BT 48854	Shaft & Lever Assy-Clutch Shifter	35 Hudson-Terr
BT 48855	Interlocking Device-Service Kit	33K-KU-KT,34-35 All
BT 48876	Plunger Assy-Selector	35 thru 39 All,1942 thru 1950 with HDM
BT 48878	Washer-VD Solenoid Plunger Disc	35 thru 1950 All
BT 48887	Connector-Selector to Cylinder Tube	35 thru 39 All,1942 thru 1950 with HDM
C 48894	Front Spring Leaf Service Kit	35 Hudson 8
BM 48910	Stud-Cylinder Head-Short-3-1/2"	35 Hudson 6-Terr
BM 48911	Stud-Cylinder Head-Short-3-23/32"	35 Hudson 6-Terr
BM 48912	Stud-Cylinder Head-Medium 3-13/16"	35 Hudson 6-Terr
BM 48914	Stud-Cylinder Head-Long-5-13/32"	35 Hudson 6-Terr
C 48915	Shaft & Roller Tooth Assy-Steering Gear-LHD	35 Hudson
48929	Shock Absorber Assy-Front (Use 166133)	34 LT-LTS-LL
48930	Shock Absorber Assy-Rear (Use 166134)	34 LT-LTS-LL
F 48931	Bushing-Shock Absorber	34 LT-LTS-LL
50102	Guide-Rocker Arm Push Rod-(Use 155656)	Essex 4
50122	Use 44714	
F 51271	Dust Cap-Universal Joint	Esx 4,29 Esx,30 thru 35 All,60 thru 65,70 thru 75,80 thru 85,89,90,92,93,95,41,44,45,40-10-20 with std engine 17-18-27-28 withOD,10-20 With L engine,11,12,14,15,21, 22,24,25
BZ 51272	Felt Washer-Universal Joint	Esx 4,29 thru 33 exc 29 Hud
F 51275	Retainer-Universal Joint Dust Washer	Esx 4,29 Esx,30 thru 35 All,60 thru 65,70 thru 75,80 thru 85,89,90,92,93,95,41,44,45,40-10-20 with Std Engine,17- 18-27-28 with OD,10-20 with L Engine,11,12,14,15,21, 22,24,25
BX 51501	Bushing-F/A Spindle Pin-Lower	Essex 4
BX 51646	Key-Rear Axle Drive Shaft	Esx 4,27 thru 33 exc 28-29 Hudson Esx
BX 51677	Retainer-R/A Dr Shaft Felt Washer	Esx 4,27 thru 31 exc 28-29 Hud
BX 51678	Retainer-R/A Dr Shaft Felt Washer	Esx 4,27 thru 31 exc 28-29 Hud
BM 60011	Bushing-Camshaft-Rear	24 thru 29 Essex
BM 60019	Sprocket-Camshaft	30-31 Hudson-Essex
BM 60028	Felt Washer-Front Cover	24 thru 32 Esx,30-31-32-33 Hud
BM 60041	Stud-Main Bearing	24 thru 27 All,30 thru 37 All
60043	Ring-Exhaust Manifold (Use 36334)	24 thru 29 Essex
60047	Gasket-Exhaust Manifold (Use 36334)	24 thru 29 Essex
BM 60049	Gasket-Water Inlet Elbow	24 thru 31 Essex
BM 60063	Ring-Piston Pin Lock	33 thru 1947 All,1948 thru 1950 8 Cyl
BM 60075	Packing-Exhaust Manifold	24 thru 29 Essex
BM 60076	Stud-Short-Cyl Head	24 thru 31 Essex
60082	Use 1-33872, 1-1385	
60099	Plate-Valve Tappet	27 thru 33 All
BM 60104	Retainer-Valve Spring	24 thru 27 All,28-29 Esx,30 thru 35 All, 38 thru 1947 All,1948 thru 1950 8 Cyl
BM 60106	Pin-Tappet Roller	24 thru 33 exc 28-29 Hudson
BM 60109	Nut-Tappet Screw	24 thru 33 exc 28-29 Hudson
BM 60115	Bushing-Oil Pump	24 thru 29 Essex
BM 60117	Spring-Oil Pump	24 thru 27 Essex
BM 60118	Bushing-Dist Shaft	24 thru 32 Essex,30-33 Hudson
BM 60124	Shaft-Oil Pump Worm	24 thru 29 Essex
BM 60127	Clamp-Generator Drive	24 thru 29 Essex
60139	Chain-Timing (Use 35386)	24 thru 31 Essex,30-31 Hud
BM 60144	Bushing-Upper-Dist Shaft	24 thru 32 Essex,30 thru 33 Hud
BM 60145	Shaft-Dist Drive	24 thru 32 Essex,31 thru 33 Hud
BM 60148	Gasket-Oil Pump	24 thru 29 Essex
BM 60156	Stud-Fan Arm Locking	24 thru 30 -Essex,30 Hudson
BX 60200	Shim-Thick-F/A Steering Knuckle	24 thru 28 Essex
BX 60206	Ball-Steering Arm	24 thru 32 Essex,30 thru 33 Hud
BM 60212	Gasket-Eccentric Adj	24 thru 29 Essex
60219	Use 170058	
BT 60306	Plate-Clutch Driven	24-25-26 Essex
BT 60312	Retainer-Clutch Thrust Bearing	24 thru 26 Essex
BT 60315	Gasket-Clutch Cover	24 thru 26 Essex
60328	Use 65126	
BT 60336	Cap-Trans Main Shaft Front Bearing	24 thru 26 Essex
BT 60346	Gasket-M/S Front Cap	24 thru 29 Essex
BT 60348	Felt Washer-Front-Trans M/S.	24-25 Essex
BT 60352	Shim-Thick-Trans M/ S	24 thru 31 Essex,30-31 Hudson
BT 60361	Spring-Shift Lock Plunger	28 thru 32 Essex,30 thru 32 Hudson
BT 60364	Spring-Control Lever	24 thru 31 Esx,30-31 Hudson
BZ 60380	Bushing-Pedal Bracket	24 thru 32 Esx,30-31-32 Hudson
BZ 60388	Link-Clutch Pedal Control	24 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 60390	Shaft-Pedal Control	24 thru 32.Esx,30 thru 32 Hudson
BT 60399	Cover-Control Lever	24 thru 31 Esx,30-31 Hudson
BT 60406	Lock Screw-Control Lever	24 thru 31 Esx,30 Hudson
60425	Gasket-Control Housing (Use 65743)	24 thru 30 Essex,30 Hudson
BZ 60444	Sleeve-Front & Rear Spring Bolt	24 thru 32 Esx,30-31-32-33 Hud
BZ 60460	Shackle-Tapped-Spring	24 thru 29 Essex
60461	Use 38059	
60462	Use 38060	
BX 60491	Felt Washer-R/A Wheel Hub	24 thru 32 Esx,30-31-32 Hudson
BX 60496	Button-R/A Shaft	24 thru 31 Essex,30-31 Hudson
BX 60498	Felt Washer-Pinion Nut	24 thru 28 Essex
BX 60501	Lock-Pinion Bearing Nut	24 thru 29 Essex
BX 60503	Retainer-Pinion Washer	24 thru 29 Essex,29-31 Dover
BX 60505	Cover-R/A Housing	24 thru 29 Essex
BX 60511	Bushing-Lower-Pivot Pin	24-25-26 Essex
BX 60518	Bushing-Steering Arm Yoke Pin	24 thru 27 Essex
BZ 60522	Washer-Front Wheel	24 thru 29 Essex
BZ 60523	Plate-Front Wheel-Outer	24 thru 29 Essex
BX 60528	Pin-Tie Rod Yoke	24 thru 27 Essex
BX 60529	Spider-R/A Diff	24 thru 31 Esx,30-31 Hud
BZ 60532	Ball Seat-Drag Link	30 thru 36 Esx 32 Terr,1940 thru 1947 All, 1948-1949-501 thru 504 LHD
BZ 60533	Plug Drag Link	24 thru 27 All,28-29 Hud,30 thru 37 All 80 thru 88,92 thru 97,1940 thru 1950 All
BZ 60534	Spring-Drag Link	24 thru 32 Esx,30-31-32 Hud
BM 60558	Gasket-Carb	24 thru 28 Essex
BM 60559	Tube-Oil Reservoir Filter to Crank Case	24 thru 29 Essex
BZ 60597	Spring-Acc Lever	24 thru 28 Essex
60648	Use 40675	
BZ 60664	Clip-Battery Cable	24 thru 36 All,1940 All
BM 60681	Clamp-Tappet Guide	24 thru 1947 exc 28-29 Hudson,1948 thru 1950 8 Cyl
60701	Washer-Camshaft (Use 162180)	24 thru 38 All exc 28-29 Hud
BZ 60711	Spring-Acc Lever	24 thru 32 Essex,30-32-33 Hudson
BZ 60719	Journal-Universal Joint	24 thru 33 exc 28-29 Hud
BZ 60725	Bushing-Universal Joint	24 thru 33 exc 28-29 Hud
60728	Use 62042	
BZ 60729	Clamp-Muffler Tail Pipe	24 thru 30 Essex,30 Hudson
60885	Use 29180	
BM 60925	Drive Shaft-Generator	24 thru 29 Essex
BM 60926	Gasket-Carb Body Upper	24 thru 28 Essex
BM 60928	Spring-Mixture Control	24 thru 28 Essex
BM 60938	Sleeve-Generator Shaft	24 thru 29 Essex
BT 60950	Lever Assy-Trans Control	27 thru 31 Essex
BM 60976	Cap-Carb Float Cover	24 thru 28 Essex
BT 61034	Drive-Plate-Clutch	24 thru 26 Essex
BR 61035	Pressure Plate-Clutch	24-25-26 Essex
BT 61057	Gear-High & Intermediate	27 thru 29 Essex
BM 61074	Plug-Camshaft Bearing	24 thru 1940 exc 28-29 Hudson
BM 61213	Spindle-Fan	24 thru 27 Essex
BM 61214	Hub-Fan	24 thru 27 Essex
61222	Stud-Long-Cyl Head (Use 150380)	27 thru 31 Essex
C 61246	Drive Shaft-R/A	24 thru 29 Essex
BM 61359	Oil Gauge	24 thru 31 Essex
F 61360	Guide-Valve Stem	24 thru 35 exc 28-29 Hudson
BM 61368	Side Plate Complete-Cylinder	24 thru 29 Essex
C 61373	Tail Pipe Assy-Muffler	24 thru 29 Essex
BM 61431	Plate-Eccentric Adj	24 thru 29 Essex
BZ 61434	Nut-Dem Rim Bolt	24 thru 31 All
61435	Use 63605	
BM 61440	Conn Rod Complete-LH-Rebabbited	24 thru 27 Essex
BM 61446	Bolt Lock-Motor Plate	24 thru 1946 exc 28-29 Hudson
BT 61475	Spring-Brake Lever	24 thru 33 exc Bud 6
BT 61481	Bronze Washer-Front-Trans M/S	24 thru 28 Essex
BT 61483	Steel Washer-Rear-Trans M/S	24 thru 32 Essex,30-31 Hud
BT 61484	Bronze Washer-Rear-Trans M/S	24 thru 31 Essex,31 Hudson
BX 61487	Steering Spindle-F/A-RH	24 thru 27 Essex
BX 61492	Dust Washer-Spindle Pivot Pin	28 thru 31 Essex,30-31 Hudson
MF 61512	Screw-Tappet Adjusting	24 thru 1947 exc 28-29 Hudson,1948 thru 1950 8 Cyl
61516	Use 33331	
BM 61540	Bearing-Center Lower-Crankshaft.	24 thru 27 Essex
BM 61569	Oil Ring-Generator Drive Shaft	24 thru 30 Essex,30 Hudson
BM 61576	Plunger-Oil Pump Dist	24 thru 28 Essex
BM 61578	Spring-Oil Pump Plunger	24 thru 31 Essex,30-31 Hudson
BZ 61587	Bushing-Strg Gear Worm Wheel	24 thru 27 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 61595	Cover Assy-Oil Filler	24 thru 31 Essex
61614	Spring-Camshaft Button (Use 163442)	24 thru 1947 Exc 28-29 Hud
BM 61615	Gasket-Side Plate	24 thru 31 Essex
BM 61622	Gasket-Cyl Head	26 thru 28 Essex
BM 61648	Gear & Worm-Oil Pump	29 thru 32 Essex,30 thru 33 Hudson
BT 61656	Bushing-Trans Mainshaft	24 thru 31 Essex,30-31 Hud
61694	Use 62666, 62667	
BM 61695	Tappet-Valve	24 thru 33 exc 28-29 Hud
BM 61696	Roller-Tappet	24 thru 33 exc 28-29 Hud
61697	Use 43806	
61710	Use 43805	
BT 61899	Drum Assy-Clutch	25 thru 27 Essex
61903	Shim-Med-Conn Rod (Use 33160)	24 thru 27 Essex
BM 61916	Cylinder Shield	25 thru 30 Essex
61964	Use 62666	
61965	Use 62667	
BM 61970	Shield-Oil Deflector	24 thru 30 Essex
61972	Valve-Inlet (Use 44647)	26-27-28-31 Essex
BZ 61978	Seal-Camshaft Bearing	24 thru 1950 exc 28-29 Hud
BZ 62013	Clip	24 thru 37 All
BZ 62042	Clamp-Demountable Rim	26-27-28 Essex
BM 62078	Gasket-Front Motor Supp Plate	24 thru 28 Essex
BM 62079	Gasket-Frt Motor Plate Oil Deflector	24 thru 29 Essex
BZ 62088	Contact Washer-Horn Button	24 thru 28 Hudson-Essex
EX 62116	Collar & Nut	24 thru 29 Essex
BT 62165	Retainer-Trans Rear Bearing	28-29-30-31 Essex,30-31 Hud
BO 62254	Gauge-Gasoline	27-28 Essex
BZ 62257	Button-Horn	24 thru 27 Essex
BT 62283	Retainer-Clutch Bearing	27-28-29 Essex
BT 62284	Sleeve-Clutch Shifting	27-28-29 Essex
BT 62285	Throwout-Cross-Clutch	27-28-26 Essex
BT 62290	Gasket-Clutch Cover (Pkg 10)	27-28-29 Essex
BT 62291	Oil Ring-Clutch Throwout Ring	27-28-29 Essex
62297	Use 64494	
BT 62323	Rod-Hand Brake Cont Lever	27 thru 31 Essex,30 Hudson
BT 62326	Spacer-Hand Brake Lev Ratchet Frame	27 thru 31 Hud-Esx,31 Dover
BT 62327	Latch-Hand Brake Cont Lev-Short	27 thru 30 Hudson-Essex,31 Dover
BT 62328	Latch-Hand Brake Cont Lev-Long	27 thru 30 Hudson-Essex,31 Dover
C 62342	Flywheel Assy	27-28-29 Essex-Dover
BT 62343	Drive Gear Assy-Trans Mainshaft	27-28-29 Essex
BT 62344	Plug-Drain	27 thru 31 Essex,31 Hudson
BZ 62352	Cap-Radiator Filler	27 Essex
BZ 62356	Cap-Hub	27-28 Essex
C 62364	Shaft Assy-Rear U-J & Propeller	27-28 Essex
62371	Use 64289	
BM 62381	Spring-Oil Pump	27-28 Essex
BZ 62492	Cable & Conduit Assy-Batt to Starter	27-28-29 Essex
BT 62510	Spring-Clutch	27-28-29 Essex,31 Esx Spec Ph-Dover
BM 62521	Bolt-Connecting Rod	27 thru 31 Essex,30 thru 33 Hud,32-33 Terr
62531	Use 37239	
62532	Use 37240	
62534	Use 65285	
62535	Use 63228	
62538	Shim-C/S Center Brg-Thin (Use 63231)	27-28 Essex
62541	Shim-C/S Rear Brg-Thin (Use 63234)	27-28 Essex
BM 62544	Gasket-Oil Reservoir	27 thru 32 Esx,32-33 Terr,33 Hud 6,31 Esx Spec Ph-Dover Truck
BM 62545	Pulley-Fan	27-28 Essex
F 62552	Gasket-Cover (Pkg 10)	27 thru 32 Esx,30-31-32 Hud,33 Hud 8
BM 62554	Gasket-Front Motor Plate	27 thru 32 Esx,30-31-32 Hud,33 Hud 8
C 62558	Cover Assy-Crankcase Front	27 thru 32 Esx,31 Esx Spec Ph,30-31-32 Hud 33 Hudson 8-Dover
BX 62605	Case Assy-Differential	27-28-29 Essex
BM 62666	Fan Blade-Inner	27-28-29 Essex-Dover
BM 62667	Fan Blade-Outer	27-28-29 Essex-Dover
BM 62672	Gasket-Fan Hub	27 thru 32 All exc 29 Hud L,33 Hud 6-8, 31 Esx Spec Ph-Dover
BM 62673	Spring-Fan Spindle	27 thru 32 Esx,30-31-32-33 Hud, Dover
BT 62684	Bushing-Trans Countershaft Gear	27-28-29-30 Esx,31 Esx
BT 62690	Lever & Housing Assy-Control	27-28-29 Essex-Dover
BX 62710	Pivot Pin-Front Spindle	27-28 Essex
BX 62711	Bushing-Front Spindle-Upper	27-28 Essex
BX 62712	Bushing-Front Spindle-Lower	27-28 Essex
BX 62735	Dust Shield-Front Axle Spindle Brg	27 thru 32 Esx Spec Ph-Dover

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BX 62736	Lever-Front Axle Brake Operating-RH	27-28-29 Esx
BX 62738	Pivot-Front Axle Operating Lever	27-28-29 Esx
BX 62739	Spring-Front Axle Operating Lever	27 thru 31 Esx,29-30-31 Hud,31 Esx Spec Ph-Dover
BX 62740	Dust Shield-Front Axle Oper Lever	27 thru 31 Esx,29-30-31 Hud,31 Esx Spec Ph-Dover
BX 62741	Washer-F/A Oper Lever Dust	27 thru 31 Essex,29-31 Hud
BZ 62772	Rod-Idler to Front Brake Lever	27-28 Essex
BZ 62778	Spring-Brake Pedal & Stop Lt Sw	27-28-29 Esx 31 Esx Spec Ph-Dover
BZ 62805	Link-Throttle Control Bell Crank	27 thru 30 Hud-Esx,31 Esx Ph-Dover
BZ 62842	Hose-Radiator Water Inlet	27-28 Essex
BZ 62849	Outer Ring-Throttle & Light Lever	28-29 Esx,31 Esx Spec Ph-Dover
BX 62859	Drive Pinion-Rear Axle 5-6/10 to 1	27-28-29 Essex,31 Esx Spec Ph
BZ 62860	Outer Ring Lock-Throttle & Lt Lev	28 liud,28-29 Esx,31 Esx Spec Ph-Dover
BT 62872	Ratchet-Hand Brake Lever	27 thru 30 Hud-Esx exc 29 L
BO 62891	Door Assy-Headlamp-Less Lens	27-28 Essex
BX 62931	Spring-Secondary Shoe	27-28 Essex
BO 62963	Gasket-Side Lamp Lens	27-28-29 Esx,31 Hud,30 Hud-Esx
BO 62974	Reflector Assy-Headlamp	27-28-29 Essex
BZ 63027	Friction Band Assy-Strg Gr	31 Hud & Essex
BZ 63042	Sleeve-Eccentric Adjusting	27 thru 37 Esx,32 thru 36 Hud-Terr
BZ 63043	Lock Ring-Eccentric Adj Sleeve	27 thru 32 Esx,32 thru 36 Hud-Terr
	63048 Use 64545	.
BZ 63052	Arm-Steering Gear	28 Essex
C 63059	Column-Steering Gear	28 Essex
BZ 63060	Stud-Strg Gear Case Cover	28 thru 32 Esx,32 thru 36 Hud-Terr
BZ 63068	Silencer-Throttle Tube	27 thru 32 Esx,30 thru 33 Hud
BM 63107	Connecting Rod Assembly	27-28-29 Essex-Dover
	63109 Use 65278	
	63112 Use 37240	
	63113 Use 65284	
	63114 Use 65285	
	63116 Seat-Tie Rod Ball (Use 60532)	27-28 Essex
	63182 Use 63306	
BM 63183	Strap Assy-Generator	27-28-29 Essex
	63194 Use 63853	
	63198 Use 63853	
BX 63199	Lock-F/A Spindle Pivot Pin	27 thru 32 Essex,30 thru 33 Hud
BX 63200	Shim-F/A Knuckle Spindle-Thin	27 thru 32 Essex,30 thru 33 Hud
BX 63201	Shim-F/A Steering Knuckle Spindle-Medium	27 thru 32 Essex,30 thru 33 Hud
BM 63228	Shim-C/S Front Bearing-Thin	27 thru 31 Esx,31 Esx Spec Ph-Dover
BM 63231	Shim-C/S Center Bearing-Thin	27 thru 31 Esx,31 Esx Spec Ph-Dover
BM 63234	Shim-C/S Rear Bearing-Thin	27 thru 31 Esx,31 Esx Spec Ph-Dover
BM 63235	Shim-C/S Rear Bearing-Medium	27 thru 31 Esx,31 Esx Spec Ph-Dover
BM 63306	Bracket Assy-Generator	27-28 Essex-Dover
	63371 Use 41134	
	63384 Use 39117	
BZ 63385	Gasket-Strg Gear Case Cover-RHD	29 Essex,29-30-31 Hudson
BZ 63386	Worm Wheel-Steering Gear	29 Essex
BZ 63390	Arm-Steering Gear	29 Essex
BZ 63393	Retainer-Strg Gear Oil-Lower	29 thru Esx,30 thru 33 Hudson
C 63398	Tube. Strg Gear Main Column	29-30 Essex,30 Hudson
BZ 63400	Bushing-Jacket Tube	28 thru 32 Esx,30 thru 33 Hudson
BZ 63402	Cup-Strg Gear Roller Brg Cage	29 thru 32 Esx,30 thru 33 Hudson
BZ 63412	Channel-Running Broad Front & Rear	29 Esx,31 Spec Ph-Dover
BZ 63426	Fitting-Alemite-Straight	29 thru 32 Hud-Esx,31 Esx Spec Ph-Dover
BZ 63464	Bolt-Rear Spring Center	29 thru 32 Essex.33 Hudson 6
C 63504	Cylinder Head Assy	29-30 Essex
C 63505	Cylinder & Pistons Assy	29 Essex
BZ 63513	Electrolock Complete	29 Hudson,29-30 Essex
BO 63514	Lens-Headlamp	29 Essex
BZ 63515	Bolt-Spring Shackle	29 thru 32 Esx,30 thru 33 Hudson
BM 63527	Gasket-Cylinder Head	29-30 Essex-Dover
C 63531	Water Outlet Manifold	29-30-31 Essex
	63532 Use 35399 & 60069	
	63534 Ring-Piston (Use 65896)	29 Essex
BM 63542	Gasket-Water Jacket Cover	29-30-31 Essex
BM 63545	Gear Assy-Crankshaft	29 Essex
BM 63546	Fan Pulley	29 Essex
BM 63548	Washer-Starting Jaw	29 Essex-Dover
	63549 Use 38957	
BM 63550	Gasket-Carb	29 Essex-Dover
BM 63551	Gasket-Exhaust Manifold	29-30-31 Essex
BM 63552	Gasket-Carb Riser	29-30-31 Essex
BZ 63566	Crank-Starting	29 Essex-Dover
	63589 Use 64452	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
63591	Gasket-(Use 37327)	
BT 63598	Sleeve-Clutch	29 Essex
BT 63601	Washer-Clutch Bearing Retainer	29 Essex
BZ 63604	Clamp-Rim	29-30-31 Essex,30-31 Hudson
BZ 63605	Bolt-Rim	29-30 Essex,30 Hudson
BM 63606	Hose-Radiator Inlet	29 Essex-Dover
C 63627	Frame End-Right-Front	29 Essex-Dover
C 63636	Tie Rod Assy	29 Essex
BM 63640	Plunger-Oil Pump	29 Essex
BM 63641	Spring-Oil Pump	29 Essex
BM 63650	Gasket-Oil Pump Body Cover	29 Essex
BO 63655	Headlamp Assy-Chromium	29-30 Essex
C 63679	Frame Assembly	30 Essex,31 RHD Essex Ph
BM 63693	Gauge-Oil-Level	29 thru 31 Esx,30 thru 33 Hud,33 KT
BZ 63701	Gauge-Gas Tank	29-30 Essex-Dover,30 Hudson
BO 63702	Door Assy-Headlamp	29 Essex
63703	Use 63702	
BO 63708	Door Assy-Side Lamp	29 Esx,30 thru 32 Hud Ph,30 Esx Ph,33 E PH
BZ 63710	Hub Cap-Wire Wheels	29 Essex
C 63741	Muffler Assy	29 Essex
63773	Use 44069	
BX 63783	Dust Cover-Tie Rod	29-30-31 Essex,30-31 Hudson
BX 63784	Retainer-Tie Rod Dust Cover	29-30-31 Essex,30-31 Hudson
BX 63791	End-Tie Rod-RH	29-30-31 Essex,30-31 Hudson
BX 63796	End-Tie Rod-LH	29-30-31 Essex,30-31 Hudson
63797	Exhaust Valve (Use 44647)	30-31 Essex,30 thru 33 8 Cyl
BX 63853	Bushing-Pivot Pin	29 thru 33 exc Terr
BZ 63854	Rod-Idler to Front Brake	29-30 Essex-Dover,30 Hudson
63857	Use 63854	
63869	Use 63027	
BZ 63899	Worm & Roller Assy-Strg Gear	29 Essex
BZ 63900	Worm & Roller Assy-Strg Gear-RHD	29 Essex
63956	Anchor Pin & Reinf Assy (Use 63986)	29 Essex
63958	Lever-Brake Crank-RH (Use 33876)	29,30,31 Essex
BX 63959	Carrier Bracket Assy	29-30-31 Essex,30-31 Hudson
F 63974	Plate-Brake Adj	29 thru 32 Esx,30 thru 1950 All
BX 63975	Nut-Brake Screw-Left	29-30-31 Essex,30-31 Hudson
BX 63984	Lever-Brake Crank-Left	29-30-31 Essex
BX 63985	Lever-Brake Crank-Right	29-30-31 Essex
BX 63986	Anchor Pin & Reinforcement Assy-Brake	29 Essex
BT 64006	Cap-Trans Lock Plunger	29 thru 31 Esx,30 thru 35 Hud,32-33 Terr
64160	Use 1-65442, 1-65444 2-65443	
BX 64179	Shim-Thick-Pinion Bearing	30-31 Hudson-Essex
BX 64180	Shim-Thin-Pinion Bearing	30-31 Hudson-Essex
64200	Use 65518	
64201	Use 33531	
BZ 64202	Packing-Universal Outside Casing	29 thru 32 Esx,30 thru 33 Hud,32 Terr
BZ 64203	Spring-Outside Universal. Casing	29 Essex
64204	Use 36053	
64205	Use 36432	
BZ 64209	Gasket-U/J Flange	29 thru 32 Esx,30 thru 33 Hud,32 thru 33 Terr
BM 64246	Union-Crankcase Oil Tube	29-30-31 Essex
BX 64271	Pivot Pin-F/A Spindle (Pkg 10)	29 thru 32 Essex,30 thru 33 Hudson
BX 64274	Pivot Pin-Front Brake Lever	29 thru 32 Esx,-Dover,30-31 Hudson
BZ 64289	Center Bolt-Spring	29 Essex,32 Hudson
BX 64309	Eccentric Assy-Brake	29-30-31 Essex,30-31 Hudson
BO 64317	Conduit Assy-Headlamp	29 Dover
BX 64334	Camshaft & Crank Assy-Brake	29-31 Essex
BZ 64383	Fender Tire Support	29 Dover
64431	Use 33658	
BM 64450	Oil Plate Assy-Upper-Crankshaft	29-30-31 Essex,30-31 Hudson
BM 64452	Oil Plate Assy-Lower-Crankshaft	29-30-31 Essex,30-31 Hudson
BT 64494	Yoke Assy-Clutch	27-28-29 Essex
BZ 64496	Filler Cap-Gas Tank	29 Dover
64499	Use 33658	
BX 64518	Cam Plate & Block Assy	29-30-31 Essex
64538	Use 38751	
BZ 64545	Bushing-Steering Gear Shaft	27-28-29 Essex
65001	Drive Plate Assy-Clutch (Use 42512)	30 Hudson
BT 65013	Lock Plate-Clutch Throwout Finger	30 thru 33 Hudson-Essex
BT 65015	Spring-Clutch Engaging	30 thru 33 Hudson-Essex-Terr KT
BT 65018	Gasket-Clutch Cover	30-31 Hudson-Essex
BT 65023	Collar Assy-Clutch Throwout	30-31 Hudson-Essex
BX 65033	Drive Gear-R/A-5-4/10 to 1	30-31 Essex,31 Hudson Club Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	65038 Use 38567	
BX	65040 Gasket-R/A Housing Cover	30 thru 33 Hudson-Essex
BX	65043 Cap Assy-Wheel Bearing Adj	30-31 Hudson-Essex
BX	65054 Nut Lock-R/A Differential Bearing	30 thru 33 Hudson-Essex
C	65056 Carrier Assy-Differential	30 thru 33 Hudson-Essex
BX	65059 Housing Assy-R/A Pinion	30-31 Hudson-Essex
BX	65061 Shim-Thin-Pinion Housing	30 thru 33 Hudson-Essex
BX	65064 Dust Washer Assy-R/A Pinion	30-31 Hudson-Essex
BX	65074 Lever-Brake Operating-RH	30-31 Hudson-Essex
BX	65075 Lever-Brake Operating-LH	30-31 Hudson-Essex
BX	65086 Steering Arm-RH	30 thru 33 Hudson-Essex
BX	65087 Steering Arm-LH	30 thru 33 Hudson-Essex
BX	65089 Washer-Steering Spindle	30 thru 33 Hudson-Essex
BZ	65097 Yoke Assy-Clutch Shaft	30 thru 33 Hudson-Essex
BX	65102 Lock-R/A Drive Gear Bolt	30 thru 33 Hudson-Essex
BX	65103 Dust Collar-R/A Pinion	30-31 Hudson-Essex
C	65104 Transmission Assy	30-31 Essex
BT	65115 Gasket-Trans Bearing Cap-Front	30-31-32 Hudson-Essex
BT	65116 Gear Assy-Rear Axle Drive	30 Hudson,30-31 Essex
BT	65118 Main Shaft-Transmission	30 Hudson,30-31 Essex
BT	65119 Gear Assy-Second & High	30 Hudson,30-31 Essex
BT	65120 Gear Mainshaft Low & Reverse	30 Hudson,30-31 Essex
BT	65122 Gear Assy-Drive & Intermediate	30 Hudson-Essex
BT	65126 Shaft Assy-Reverse Idler	30 thru 33 Hudson-Essex
BT	65133 Shift Rail-Low & Reverse	30 Hudson,30-31 Essex
BZ	65139 Shackle-Front Spring-Tapped	30 Hudson-Essex
BZ	65141 Bolt-Front Spring Rear	30 Hudson-Essex
BZ	65143 Shackle-Rear Spring-Tapped	30 thru 33 Hudson-Essex
	65160 Link Assy-Clutch Pedal (Use 162294)	30 thru 33 Hud-Essex,33 K-KU
C	65177 Muffler Assy	30-31 Hudson-Essex
C	65184 Pipe Assy-Tail	30 Hudson-Essex
BZ	65185 Bracket-Tail Pipe	30 Hudson-Essex
BM	65189 Gasket-End-Exhaust Manifold	30-31 Essex
BM	65191 Gasket-Center-Exhaust Manifold	30-31 Essex
BM	65199 Fan Belt	30 Essex
BZ	65241 Bracket-Front-Front Spring-RH	30 Hudson-Essex
BZ	65242 Bracket-Front-Front Spring-LH	30 Hudson-Essex
BZ	65245 Bushing-Front Spring Rear Bracket	30 thru 33 Hudson-Essex
BZ	65252 Bushing-Rear Spring Bracket	30 thru 33 Hudson-Essex
BM	65278 Bearing-Crankshaft-Upper #1	30-31 Essex
BM	65278 Bearing-Crankshaft-Upper #1-Reamed	
	65279 Use 157980	
BM	65280 Bearing Cap-Center #2	30-31 Essex
	65281 Use 37239	
	65282 Use 37240	
BM	65284 Bearing-Crankshaft-Upper #3	30-31 Essex
BM	65284 Bearing-Crankshaft-Upper #3-Reamed	
BM	65285 Bearing-Crankshaft-Lower #3	30-31 Essex
BM	65285 Bearing-Crankshaft-Lower #3-Reamed	
	65304 Conn Rod-RH (Use 166500)	30-31 Hud-Essex,32 Essex
	65305 Conn Rod-LH (Use 166501)	30-31 Hud-Essex,32 Essex
BZ	65307 Starting Crank	30 Hudson,30-31 Essex
BM	65310 Drive Shaft-Generator	30 Hudson-Essex
	65324 Use 34029	
C	65327 Crankshaft Assy	30 Essex
BM	65341 Pipe Assy-Oil Pump to Check Valve	30-31 Essex
	65343 Use 1-35919, 1-170387, 1-170386	
BM	65347 Pipe Assy-Oil Pan Suction	30-31 Hudson-Essex
BM	65349 Cover-Exhaust Pipe	30-31 Hudson-Essex
BM	65373 Stud-Medium-Cyl Head	30-31 Essex
BO	65381 Door Assy-Tail & Stop Lamp	30 Essex,31 Bud Del Bro
	65384 Use 65919	
BM	65387 Hose-Radiator Outlet	30-31 Essex
BM	65389 Gasket-Rear Motor Support Plate	30-31-32 Hudson-Essex
BX	65397 Steering Spindle Assy-RH	30 thru 33 Hudson-Essex
BX	65398 Steering Spindle Assy-LH	30 thru 33 Hudson-Essex
BX	65399 Grease Deflector-Steering Spindle	30-31 Hudson-Essex
BX	65403 Washer & Retainer Assy-Strg Spindle	30 thru 33 Hudson-Essex
BX	65404 Grease Washer-Steering Spindle	30 thru 33 Hudson-Essex
BX	65405 Retainer-Inner-Spindle Grease Washer	30-31-32 Hudson-Essex,33 Hudson
BX	65406 Retainer-Outer-Spindle Grease Washer.	30 thru 33 Hudson-Essex
BM	65442 Eccentric-Generator Drive Shaft	30 thru 33 Hudson-8-Essex
BM	65443 Gasket-Eccentric	30 Hudson-Essex
BZ	65444 Spacer-Dist Support Bolt	30 thru 33 Hudson 8-Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 65445	Blade-Fan	30 thru 33 Hudson 8-Essex
65447	(Use 42512)	
C 65453	Wheel Assy-Wire-Prime	30 Essex
BZ 65457	Spoke Nipple-Wire Wheel	30-31 Hudson,30 Essex
BZ 65470	Hub Cap-Outer-Wire Wheel	30 Essex,31 Essex Exp
BZ 65518	Casing Assy-Propeller Shaft Outer	30 Hud T,30 thru 33 Esx-Terr,31 thru 33 Hud
BZ 65519	Spring-Propeller Shaft Outer Casing	30 thru 33 All
BZ 65525	Ball Joint-Strg Gear to Lighting Switch	31 Essex
BX 65544	Dust Shield-Front Axle Steering Spindle	30 thru 33 Hudson
65553	Use 65280	
BZ 65563	Electrolock Assembly	30-31 Essex
BM 65564	Gasket-Int Man to Carb Riser	30-31 Essex
BO 65575	Door Assy-Headlamp-Less Lens	30-31 Essex
BO 65576	Door Assy-Headlamp	31 Essex Comm
BO 65578	Lens-Headlamp Door	30-31 Essex
BO 65579	Retainer-Headlamp Door Lens	30-31-32 Esx,32-33 Terr Spec
BO 65581	Screw-Headlamp Door	30-31 Essex
BO 65583	Reflector Assy-Headlamp	30-31-32 Esx,32 Terr Sport Ro,33 Terr
BO 65588	Gasket-Headlamp Reflector	30-31-32 Esx,32-33 Terr Std
BO 65596	Terminal-Headlamp Wire	30-31 Hud-Esx
BO 65597	Terminal Body-Headlamp Wire	30-31 Hud-Esx
BZ 65716	Arm-Strg Gear Ball-RHD & LHD	30-31 Essex,31 Hudson
BZ 65719	Thrust Washer-Strg Gear Shaft	30 thru 32 Esx,33 E-K-KT,34 LT-K-KU,35-36 RHD
BZ 65721	Nut-Strg Gear Worm Adj	30-31 Essex
BT 65743	Gasket-Trans Cover	30 Hudson-Essex
BO 65805	Retainer-Side Lamp Door Lens	31 Esx Co-Cpe-Sed,30-32 Essex
BO 65819	Cable Assy-Headlamp	30-31 Essex
BX 65828	Pinion-Rear Axle-5-1/ 10 to 1	30-31 Essex-Hudson
BZ 65853	Flange-Universal Joint Companion-Front	30-31 Hud-Essex,31 Esx Spec Ph
65858	Use 61368	
BZ 65907	Clip-Wire-Enamel	30 thru 1950 All
C 65919	Core Assy-Radiator	30 Essex
65939	Hose-Radiator Inlet (Use 35857)	30 Essex
65947	Use 37068	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
*SP 70001	Bulb-15CP-Mazda 87	BO 70312	Bolt-Round Head-1/4"-20 x 1-1/4"
BO 70004	Rivet-3/16" x 1/2"	BO 70322	Lock Washer-#12-lnt Tooth
70008	Use 71737	BO 70323	Mach Screw No 10-32" x 5/8" Spec Hd
BO 70022	Nut #8-32 x 1/8"	70326	Use 70551
BO 70028	Rivet-Truss Hd-3/16" x 3/8"	F 70327	Hose Clamp-1-13/16"
BO 70031	Nut-Hexagon-1/4"-28 x 7/32"	BZ 70328	Hose Clamp-2-1/2"
BO 70042	Rivet-Crown Hd Tubular-No 9 x 1/4"	BO 70332	Washer-9/32" x 1-1/4" x 3/32"
70044	Use 70526	BZ 70336	Rivet-Rnd Hd Tubular-7/32" x 1/41"
70045	Rivet-Flat Hd Tubular-No 9 x 5/16"	BO 70350	Finish Washer-No 8 Cntrs nk
70047	Nut-USS-Hex-3/8-16 (Use 71463)	BO 70352	Screw-1/4"-20 x 1-1/2"
BO 70058	Screw-Flat Hd Machine-10/32" x 1"	BZ 70356	Rivet-Tubular .143 x 1/4"
70071	Lock Washer-3/16" Shake Proof (Use 170395)	BX 70357	Washer-.439 x 3/4 x .050"
BO 70079	Rivet-Tubular-9/64" x 3/16"	BX 70361	Bolt-5/16"-24 x 1-5/16"
70085	Use 71094	70365	Use 70455
BO 70091	Screw-Flat Head-1/4-20 x 11/16"	70369	Grommet
BX 70094	Cone-Timken Roller Bearing	70385	Use 2-18023
BO 70095	Bolt-Cowl Brkt-5/16"-24 x 3/4"	BO 70386	Nut-3/4"-16 x 7/16"
BO 70097	Bolt-1/4"-20 x 7/8"	BX 70389	Washer-Tie Rod-1" x 1/8"
BO 70098	Lock Washer-#1218-Shake Proof	BZ 70391	Nut-#6-32" x 1/8"
BX 70101	Plug-Oil-1/2"-20 x 1-1/4"	BO 70396	Nut-Clinch #10-32 Rd Type-Long
70108	Use 70157	BO 70397	Nut-Clinch-#10-32-Rd Type-Short
BO 70109	Lock Washer-1/4" Shake Proof	BO 70398	Nut-Clinch 1/4"-20 Rd Type-Long
BX 70110	Bearing-F/A Spindle Pivot	BO 70399	Nut-Clinch 1/4"-20-Short
BO 70112	Screw-Rd Head-#10-32 x 1/2"	BO 70403	Washer-21/64 x 3/4 x 1/32"
BO 70114	Nut-Hex-1/2"-20 x 5/16"	BT 70414	Lock Washer-5/16" Heavy Type
BZ 70120	Pin-Clevis-5/16" x 1 x 1-1/16"	BO 70417	Washer-#6 Finish
BO 70121	Washer-Lock-3/8"	BZ 70434	Mach Screw-No 8-32" x 1/4" Btn Head
70122	Nut-USF Hex-3/8"-24 x 5/32" (Use 170230)	BO 70435	Bolt-Carriage-3/8"-16 x 3-3/4"
BX 70125	Nut-1/2"-20 x 7/16"	BX 70436	Nut-Castle-5/8"-18 x 9/16"
BX 70126	Cap Screw-Fillister Hd 1/4" x 20"	BM 70439	Expansion Plug .921"
BZ 70129	Screw-Oval Hd Mach-1/4"-20 x 7/8"	BO 70443	Washer-Plain-13/32" x 3/4" x 1/32"
BT 70133	Pipe Plug 3/8" Socket	BO 70452	Washer-Cntrsunk, 1/4"-(N.P.)
BM 70134	Stud-5/16"-18 x 1-7/16"	BO 70455	Screw-Oval lid No 8-32 x 3/4"
BO 70135	Taper Pin-No 000 x 3/4"	BO 70465	Lock Washer-No 8 Shakeproof
BT 70138	Bearing-Ball No 1204	BO 70467	Screw-Fil Hd No 6-32 x 3/16"
BO 70139	Screw-Oval Head Machine-1/4"-20 x 3/4"	BZ 70475	Screw .
BZ 70141	Bolt-7/16"-20 x 1-1/8"	BZ 70480	Bolt-Hex Head-1/2"-13 x 3/4"
BO 70142	Ferrule-11/16" Rubber	BM 70484	Cap Screw-1/4"-20 x 7/16"
BX 70144	Shim-Front Axle Tie Rod	BO 70504	Ferrule-Rubber-3/8"
BX 70145	Plain Washer-3/8" x 1-3/16" x 1/16"	BZ 70505	Ferrule-Rubber-9/16"
BO 70149	Screw-Oval Hd Mach-1/4"-20 x 1-1/4"	BM 70510	Gasket-7/8" x 1-1/8" x 3/32" McKim
BO 70151	Rivet-Reflector Spring	BZ 70511	Bolt-1/4"-28 x 5/8" Slotted Hex Hd
BO 70155	Washer-Plain-17/64 x 5/8 x 1/32"	BZ 70521	Mach Screw-Rd Hd-1/4"-20 x 17/64"
BO 70157	Screw-Rd Hd Mach-1/4"-20 x 1/2"	BM 70522	Lock Washer-9/32 x 15/32 x 3/64"
BZ 70174	Screw-No 10-24 x 1/4" Fil Head	BO 70523	Rivet Tubular-3/16 x 5/16"
BZ 70177	Washer-Brass-.317 x 5/8 x 1/32"	BO 70525	Nut-Acorn-3/8"-24 x 19/32"
BO 70181	Screw-Flat Head-1/4"-20 x 2-1/4"	BO 70526	Screw-Oval-Hd Mach No 10-32 x 5/8"
BO 70182	Bolt-Flat Head-1/4"-20 x 3"	BO 70527	Bolt Hex Hd-3/8-16 x 1"
BO 70184	Bolt-Flat Head-1/4"-20 x 2-3/4"	BX 70539	Lock Washer-3/4" Shakeproof
BO 70185	Bolt-Carriage-1/4"-20 x 7/8"	BZ 70541	Woodruff Key No 9
BO 70187	Footman Loop	70543	Use 12481
BZ 70194	Nut-Hexagon-7/16 x 20"	BZ 70545	Bolt-5/16"-24 x 2"
BO 70195	Lock Washer-9/16" Spec	BZ 70549	Screw-1/4"-20 x 1/2"
70200	Bolt-Hex Hd Clamp-5/ 16-24 x 1-1/ 4"(Use 70361)	BZ 70551	Lock Washer-Shakeproof-No 5
BM 70204	Bolt-Hex Hd-5/16-18 x 3-1/4"-Cadmium	70553	Use 71485
BM 70225	Gasket-McKim-5/16"-5/8" x 1/16"	BX 70560	Bolt-3/8"-24 x 1-5/8"
70228	Terminal-High Tension Wire (Use 170310)	BZ 70563	Lock Washer-No 10-Shakeproof
70239	(Use 227)	BM 70568	Plug-Expansion-.750
BM 70242	Screw-Flat Head Cap-Cadmium Plated-1/4"-20 x 3/4"	70572	Use 71590
BO 70243	Ferrule-Rubber-7/8"	BO 70581	Washer 25/64" x 1-1/4" x 1/16"
70247	Nut-Hex-3/8-16 x 3/8" (Use 71058)	BM 70584	Plug-1-7/8" Expansion
BO 70260	Bulb-#1110-L	BZ 70590	Nut-Hex-5/16"-18
BO 70263	Bolt-Flat Head-1/4"-20 x 1-1/8"	BM 70591	Nut-1/4" Tube
BZ 70278	Nut-Hex-9/16"-18 x 3/16"	BM 70592	Nut-5/16" Tube
70285	Use 58	BM 70594	Sleeve-5/16" Tube
BO 70293	Rivet-Truss Head-1/4" x 1/2"	BZ 70597	Ferrule-Rubber-5/8"
BO 70295	Rivet-Truss Head-1/4" x 9/16"	BZ 70623	Lock Washer-5/16" Heavy
70296	Use 70970	70625	Use 70708
BZ 70297	Pipe Extension-1/8" x 1-7/16"	BX 70626	Expansion Plug- 1 -1/16"
BZ 70301	Clevis Pin-5/16" x 1-7/16"	BZ 70627	Nut-3/8-16 x 1/2"
BZ 70302	Bearing-#601-Nice	BZ 70631	Bolt-5/16"-24 x 7/8" Spec
BO 70304	Screw-Flat Head-No 10-32" x 3/4"	BZ 70633	Bolt-5/16"-18 x 3/4" Hex Head
70310	Use 171226 & 171227	70645	Use 170701
		BO 70648	Hole Plug-Enameled-3/4"

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 70656	Rivet-1/4" x 7/16"	BO 70940	Screw-No 10-24 x 7/16"
BO 70660	Lock Washer-•/16"	BZ 70957	Bolt-1/4"-20 x 1-5/8"
BO 70661	Union Elbow-1/8"-7/16"-20 x 135°	BO 70958	Screw-No 10-32 x 1-3/e
BZ 70673	Lock Washer-Parkerized-1/4"	BZ 70970	Rivet-1/4" x 5/8"-Trusshead
BO 70674	Nut-5/16"-18 x 5/16"	BO 70971	Plug-13/32"
BZ 70675	Washer-5/16" Parkerized	70972	Use 70971
70676	(Use 70874)	BZ 70980	Bolt-1/4"-20 x 2-1/2"-Flag Head
70677	Use 71073	70981	Use 71443
BO 70681	Lock Washer-External Tooth-3/16"	BZ 70983	Bolt-5/16"-24 x 7/8"-Hex Head
BZ 70687	Bolt-5/16"-24 x 2-1/4" Hex Head	BO 70985	Screw-Binding Head Sheet Metal-No 10 x 1-1/4"
70690	Use 70350	BZ 70989	Carriage Bolt-7/16"-14 x 3/4"
BO 70691	Hole Plug-1"	BO 70991	Rivet-3/16" x 1/2" Tubular
BZ 70692	Bolt-5/16"-18 x 3/4" Hex Head	BO 70993	Bolt-3/8"-24 x 1- 3/4"
BZ 70693	Bolt-5/16"-18 x 1" Hex Head	BZ 71004	Bolt-1/4"-20 x 1/2"
BO 70697	Wash-13/64" x 1-1/4" x 1/16"	BX 71008	Bearing Cup-R/A Differential
70700	Use 70733	BX 71009	Bearing Cone-Pinion
BO 70701	Mach-Screw-No 10-32 x 1" Oval Hd	BM 71011	Washer-1-1/8" x 25/64" x 3/32"
BO 70704	Mach-Screw-No 10-32 x 1-1/4" OvHd	BM 71012	Oiler-Bowen No 3614W
BZ 70708	Lock Washer-7/16"	F 71013	Hose Clamp-1-5/8"
BZ 70715	Bolt-Carriage-3/8"-16 x 1-3/8"	BM 71014	Bolt-1/4"-28 x 1-7/8"
BZ 70716	Washer-13-32" x 1-3/8" x 1/8"	BM 71015	Bolt-5/16"-18 x 2-3/16"
70727	Lock Washer-3/8" (Use 71234)	BM 71016	Bolt-5/16"-18 x 2-1/2"
BO 70731	Nut-Hex-1/2"-20 x 11/32"	BZ 71020	Bearing Cone-Timken Roller
BO 70733	Screw-No 6 x 7/16" Binding Head	BZ 71021	Bearing Cup-Timken Roller
BO 70740	Screw-No 10-32 x 7/8"	71022	Use 1-71211 and 1-71212
BT 70741	Bolt-Hex Head-5/16"-18 x 7/8"	71023	Use 71211
BZ 70746	Washer-11/32 x 7/8 x 1/8"	BZ 71024	Bearing Cup-Timken Roller
BO 70752	Bolt-Hex Head-5/16"-18 x 1-1/2"	BZ 71026	Cone-Timken Roller Bearing
BO 70756	Wood Screw	BZ 71027	Cup-Timken Roller Bearing
70784	Use 170160	71030	Nut-5/16"-24 x 3/16" (Use 12481)
BZ 70792	Nut-Spring-No 10-32	BO 71036	Bolt-3/8"-16 x 1-1/4"
BZ 70793	Screw-No 12-20 x 3/4"	BZ 71037	Bolt-Rd Head-3/8"-16 x 2-1/8"
BZ 70795	Nut-No 12-28-Hex Head	BO 71039	Screw-6-32 x 9/32"
BO 70796	Machine Screw-No 12-28 x 3/4"	BM 71041	Cotter Pin-1/8 x 1-1/8"
BO 70814	Screw-No-32 x 1/2"-Oval Head	BM 71042	Bolt-5/16"-18 x 1-7/8"
BO 70818	Screw-Oval Head Sheet Metal No 10 x 5/8"	BM 71044	Bolt-3/8"-16 x 1-1/8"
BO 70839	Washer-11/32" x 7/8" x 1/8"	71046	Use 70484
BO 70847	Washer-17/32" x 1-1/4"	BM 71049	Welch Plug-Cyl-1-13/16"
BO 70848	Screw-3/8"-16 x 13/16"	BZ 71050	Rivet-Flat Head-5/16" x 1"
BO 70853	Screw-1/4"-28 x 9/16"	BX 71051	Washer-29/32" x 1-1/2" x 3/16"
70854	Use 6998	71052	Use 71261
70855	Use 71648	BX 71054	Nut-3/4"-20 x 9/16"-Hex Head
70857	Use 70028	BX 71055	Washer-25/32" x 1-1/2" x 3/16"
BZ 70860	Bolt-1/2"-13 x 2"	BM 71058	Nut-3/8"-16 x 3/8"
BZ 70862	Screw-5/16"-18 x 1-7/8"	BM 71060	Bolt-Hex Hd 3/8"-16 x 1"
BZ 70863	Screw-Rd Head Mach-No 8-32 x 1/4"	BM 71061	Brg-#203 Annular
BO 70865	Screw-1/4"-20 x 9/16" Oval Head	BM 71065	Nut-7/16"-14 x 3/8"
BX 70867	Lock Washer-7/16"-Shakeproof	BZ 71067	Bolt-5/16"-18 x 2-3/8"
BO 70870	Rivet-1/4" x 11/16"-Truss Head	BO 71073	Nut-No 10-32 x 1/8"
BZ 70872	Bolt-1/4"-20 x 3/4"	BO 71076	Lock Washer-3/8"-Shakeproof
BZ 70873	Bolt-5/16"-18 x 11/16"	BT 71081	Bolt-3/8"-16 x 1" Hex Head
BZ 70874	Nut-1/4"-20 x 1/4"	BT 71086	Bearing-No 306 Deep Grove Ball
BO 70875	Rivet-1/4" x 1-1/8"	BM 71090	Nut-1/2" Tube
BZ 70877	Bolt-9/16"-12 x 1-5/8"	BM 71091	Union-Oil Pipe-3/8"-3/4"-16
BO 70882	Bolt-1/4"-20 x 1"	BM 71092	Elbow-Oil Pipe-3/8"-3/4"-16
BZ 70883	Bolt-5/16"-18 x 7/8"	71093	Nut-Clinch Type "D"-5/16-18 x 3/4" Dia
BO 70885	Screw-1/4"-20 x 1-1/4"	BT 71094	Brg Assy-No 207 Deep Groove Ball
BO 70886	Clinch Nut-No 10-32	71095	Use 5777
70891	Use 170073	BX 71099	Bolt-Hex Head-5/16"-24 x 5/8"
BO 70899	Bolt-1/4"-20 x 11/16"	BM 71100	Plug-3/8" Pipe-Socket
*SP 70900	Bulb-21-3 CP-Mazda #1158	71101	Use 7819
BZ 70901	Bolt-Special Hd-10-32 x 9/16"	BM 71108	Nut-5/16"-24 x 17/64"
BZ 70904	Bolt-1/2"-13 x 2"	BZ 71109	Washer-13/64" x 3/8" x 1/32"
BZ 70905	Lock Washer-Plain-1/2"	71113	Clevis Pin-1/4" x 2"
BX 70906	Washer-Cadmium-17/32 x 1 x 1/8"	BM 71115	Nut-No 10-32 x 1/8"
BZ 70910	Nut-1/2"-13 x 5/16"	BM 71116	Bolt-1/4"-20 x 1-9/16"
BO 70911	Screw-Flat Head-5/16"-18 x 2-1/4"	BM 71118	Terminal-Plug Type
BO 70919	Bolt-Hex Hd-5/16-24 x 7/16"	BO 71119	Terminal Clip-3/8"
BM 70922	Bolt-Hex Hd-1/4"-20 x 3"	BM 71120	Terminal Clip-1/4"
BO 70924	Screw-No 6-32 x 7/16"	BO 71121	Nut-No 14-24
BO 70925	Bolt-1/4"-20 x 3/4"	BO 71123	Washer-Plain-17/64 x 1/2" x 1/32"
BO 70937	Washer-13/64 x 3/4 x 1/32"	BZ 71126	Lock Washer-5/16" Shakeproof
BO 70938	Screw-No 8 x 3/4"-Sheet Metal	71133	Use 160939
BZ 70939	Bolt-5/16"-18 x 7/8"	71135	Use 9751

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
	71137 Use 12371	71248 Use 170058	
BM 71138	Washer-Plain-15/32 x 15/16 x 1/32"	BM 71249	Drive Screw-No 6 x 3/8"
BM 71141	Gasket-S/P-9/16" x 25/32" x 5/64"	BZ 71250	Bolt-Flat Head-5/16"-18 x 3"
BM 71144	Terminal-Spark Plug	BX 71252	Bolt-3/8"-24 x 1-1/4"
	71146 Use 71118	F 71255	Hose Clamp-1-1/4"
	71151 Use 6440	BT 71256	Clevis Pin-5/16" x 1-1/16"
BO 71152	Nut-No 6-32 x 7/64"	BZ 71257	Bolt-3/8"-24 x 1-1/16"
BO 71153	Lock Washer-5/16"	BT 71258	Screw-5/16"-18 x 13/16"
BM 71154	Key-Woodruff-No 13	BZ 71260	Washer-Cadmium-13/64" x 1/2" x 1/32"
BX 71155	Nut-5/8"-18 x 35/64"	F 71261	Nut-Castle-7/8"-18 x 9/16"
BX 71156	Nut-1/2"-20 x 1/2"	BZ 71264	Bolt-5/16"-24 x 3/4"-Cadmium
	71157 Use 170663	71265	Use 70673
BT 71158	Taper Pin-No 5 x 1-1/8"	BO 71266	Screw-No 10-32 x 5/16" Round Head
BT 71159	Bolt-3/8" x 16" x 2-5/8"	BO 71268	Washer-17/32" x 3/4" x 1/16"
BT 71160	Bolt-7/16"-14 x 1-3/4"	71269	Use 70361
F 71161	Bearing-No 200 Radial Ball	71270	Use 170472
BT 71162	Pin-3/16" x 13/16"	71278	Use 1-71279 & 1-71280
BT 71163	Pin-3/4" x 9/16"	F 71279	Cone-Wheel Brg No 2788-T
BT 71164	Washer-Plain 29/64" x 23/32" x 1/16"	F 71280	Cup-Wheel Brg No 2720
BT 71165	Expansion Plug-1-1/8"	71281	Use 1-71711 & 1-71283
BZ 71167	Nut-Flared Tube-1/2"	F 71283	Cup-Rear Axle-No 28300
BZ 71170	Clamp-1/2"	71286	Use 1 70406
BT 71171	Bolt-3/8"-24 x 1-11/16"	BM 71288	Stud-3/8"-16 x 1-13/16"
	71173 Use 71558	BZ 71289	Lock Washer-1-1/16" Shakeproof
BT 71174	Taper Pin-No 4 x 1-1/8"	71290	Use 5777
BX 71175	Pin-1/4" x 13/16"	BT 71294	Set Screw-1/4-20 x 3/8"
BX 71176	Screw-7/16"-14 x 1-3/4"	BZ 71295	Screw-Self Tapping-5/16" x 5/8"
BM 71177	Bolt-5/16"-24 x 1-1/8"	BO 71296	Washer-15/32 x 7/8 x 1/8"
BX 71178	Bolt-3/8"-24 x 7/8"	BM 71298	Screw-No 10-32 x 3/8" Copper Plated
	71179 Use 71577	BZ 71300	Bolt-1/4"-20 x 1"
BX 71180	Key-.218 x .218 x 2-13/32"-Square	71302	Use 170304
	71181 Use 1-71182 and 1-71192	BO 71305	Washer-Curtain Fastener
F 71182	Cone-Timken No 3199	BO 71306	Eyelet-Curtain Fastener
F 71185	Cup-Timken No 2523	BM 71307	Rivet-1/4" x 3/4"
	71186 Use 1-71187 and 1-71188	BZ 71316	Washer-17/64" x 7/8" x 3/32"
BX 71187	Cone-No 16150 Timken	BO 71317	Screw-No 14-5/8" Sheet Metal
BX 71188	Cup-No 16284 Timken	BO 71323	Rivet-1/4" x 2"
F 71192	Cup-Timken No 3120	BZ 71328	Rivet-3/16" x 3/16"
	71194 Use 71458	BZ 71329	Ferrule-Rubber-3/4"
BM 71195	Pin-1/8" x 7/8"-Straight	BZ 71330	Bolt-3/8"-16 x 2-1/4"
BM 71197	Washer-Plain-29/64" x 1" x 3/32"	71333	Use 70293
	71198 Use 1374	BO 71334	Screw-No 12-28 x 5/8"
BM 71199	Key-Woodruff-A	BZ 71335	Bolt-No 6-32 x 3/8"
BZ 71205	Bolt-3/8"-24 x 1-1/8"	BZ 71337	Screw-3/8"-24 x 1-3/4"
BX 71206	Bolt-3/8"-24 x 7/8"	BO 71348	Screw-No 8 x 1/2"-Sheet Metal
BM 71207	Bolt-7/16"-20 x 2-3/4"	BO 71352	Screw-Sheet Metal No 8 x 3/4"
	71210 Use 1-71211 & 1-71212	BO 71353	Screw-No 8-32 x 8/8"
F 71211	Cone-Wheel Brg-No 09078	71354	Use 170551
F 71212	Cup-Wheel Brg-No 09195	BO 71356	Washer-15/32" x 1-1/4" x 1/8"
	71213 Use 1-71214 & 1-71215	BZ 71359	Bolt-5/10-24 x 7/8"
F 71214	Cone-Wheel Brg-No 15112	BO 71361	Bulb-6-8 Volt-32-21 CP
F 71215	Cup-Wheel Brg-15250	BO 71363	Screw 1110-32 x 3/8"
BZ 71216	Nut-3/4"-16 x 3/8"	BO 71364	Sheet Metal Screw No 10 x 1"
BM 71218	Stud-5/16" X 1-5/8"	BO 71369	Screw-Drive-No 4 x 3/8"
BM 71219	Washer-Plain-15/32" x 1-5/8" x 1/8"	BO 71373	Screw-Oval Head Drive-No 6 x 1/4"
	71221 Use 170289	BO 71374	Bolt-Special-No 20 x 1/4"
BZ 71222	Nut-3/4"-16 x 7/16"	71376	Use 12857
BZ 71223	Lock Washer-9/16" External Tooth	BO 71377	Screw-No 6-32 x 3/8"
BZ 71224	Grommet-Rubber-3/8"	BO 71380	Pin-Clevis-5/16" x 25/32"
BM 71226	Nipple-For 3/16" Flared Tube	BO 71381	Pin-Clevis-5/16" x 21/32"
BZ 71227	Plug- 1 / 8"- Pipe	BO 71384	Bolt-5/16"-18 x 5/8"
BR 71229	Rivet-.185 x 19/32"-Flat Head	BO 71385	Bolt-1/4"-28 x 3/8"
	71230 Use 41042	BO 71386	Rivet-Oval Head Tubular-1/4" x 7/16"
	71231 Use 71016	BO 71389	Washer- Cadmium-21/64" x 3/4" x 1/16"
	71232 Use 71073	BZ 71390	Bolt-1/4"-20 x 9/32"
	71233 Use 170 654	BZ 71391	Washer-9/32" x 1/2" x 1/32"
BZ 71234	Lock Washer-3/8" Heavy	BO 71392	Footman Loop-2-1/4"
	71235 Use 43528	BO 71393	Washer-9/32" x 3/4" x 3/16"
F 71237	Nut-3/8"-24 x 21/64"	BO 71394	Bolt-Rd Head-1/4"-20 x 1-1/8"
BZ 71238	Nut-7/16"-20 x 3/8"	BO 71395	Lock Washer-1/4"
BZ 71239	Nut-3/8"-24 x 21/64"	BO 71396	Stud-Lift the Dot Fstnr No 8-32
BM 71243	Bolt-3/8"-16 x 1-1/4"	BO 71399	Socket Plate-Lift the Dot Fstnr
	71244 Use 1-71245 & 1-71185	BZ 71402	Bolt-5/16"-18 x 13/16"
F 71245	Cone-No 2581-T	BZ 71404	Plug-Hole-9/32"

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 71405	Bolt-1/4"-20 x 1-1/2"	BO 71600	Bolt-Hex Hd-5/16"-24 x 9/16"
BO 71406	Fuse-1-1/4"-14 Ampere	BO 71602	Screw-Rd lid Machine No 12-28 x 1/2"
71409	Use 71648	BO 71605	Bolt-Hex lid No 10-32 x 1/2"
BT 71410	Bolt-5/16"-24 x 5/8"	BO 71606	Screw-Flat Hd Sht Metal-No 8-32
71412	Bolt-5/16-18 x 2-1/4" (Use 71067)	BZ 71607	Bolt-Hex Hd-3/8"-16 x 7/8"
BO 71417	Screw-Rd Hd Machine-No 8-32 x 3/8"	F 71608	Nut-Hex Slotted-11/16" x 18 x 35/64"
BO 71420	Screw-Stove lid Sht Metal-#8 x 1/2"	BO 71609	Screw-Oval Hd Machine No 8-32 x 1-1/4"
BO 71423	Screw-Sheet Metal-No 6 x 3/.16"	BO 71610	Rivet-Tubular-3/16" x 7/32"
71424	Use 70863	BO 71611	Screw-Oval Fillister Hd Mach No 6-32 x 1-3/16"
BZ 71427	Screw-Self Tapping-3/8" x 5/8"	BO 71612	Screw-Fill Hd Mach-1/4"-20"
71429	Use 71654	71613	Use 170864
BO 71430	Screw-Rd Hd Mach No 10-32 x 9/16"	F 71614	Clamp-Hose-1-3/4"
BO 71440	Bolt-Hex Head-5/16"-18 x 1-1/8"	71615	Use 170960
BZ 71442	Gasket-Tank Gauge Screw-Copper	BO 71616	Step Bolt-5/16"-18 x 1-1/4"
BO 71443	Nut-1/4"-28 x 7/32"	BO 71618	Rivet-Oval Hd Tubular-1/4" x 1-7/8"
BO 71444	Rivet-Tubular-9/64" x 9/32"	BM 71622	Nut-Flared Tube-1/4"
BZ 71445	Lock Washer-7/16" Heavy	BZ 71323	Screw-Flat lid Mach-No 10-32 x 1/2"
BO 71449	Screw-Sht Metal Oval Hd	BZ 71624	Plug-Expansion-1-1/4" x .062"
BO 71451	Screw-Flat Spec lid Mach No 10-32 x 5/8"	BO 71625	Screw-Hd Mach 1/4"-20 x 7/8"
BO 71454	Bolt-Hex Hd-3/8-24 x 5/8"	BO 71626	Screw-Special Hd Mach 1/4"-20 x 1-1/8"
71456	Screw-Button Hd-No 10-24 x 7/16" (Use 70940)	BO 71628	Button-Clincher-3/16" x 2"
BO 71458	Oiler-Snap Lid-34 Water Pumps	BO 71630	Rivet-Oval Hd Tubular-1/4"-11/16"
BO 71461	Bolt-Flat Head-1/4"-20 x 1-1/4"	BO 71631	Bolt-Hex Hd 1/4"-20 x 1/2"
BZ 71463	Nut-Hex 3/8"-16 x 21/64"	71633	Use 71392
BO 71465	Lock Washer-3/8"	71634	Use 71630
BO 71467	Bolt-Spec for 34 Top Prop Iron	BO 71636	Bulb-32 C.P.
BO 71476	Tip-Binding End-Square	71637	Use 120894
BO 71477	Tip-Binding End-Pointed	BM 71638	Washer-Plain-11/32" x 11/16" x 1/16"
71480	Use 170971	*SP 71641	Bulb-1 C.P.
BO 71484	Screw-Rd Hd Mach 1/4"-24 x 3/8"	BO 71642	Screw-Flat Hd Cap-1/4"-20 x 7/8"
BO 71485	Screw-Rd Hd Mach No 10-32 x 1/4"	BO 71644	Bolt-Hex Head-5/16"-24 x 2-3/4"
71489	Screw-Rd Hd 10-24 x 5/16" (Use 71490)	BM 71648	Screw Rd Head Mach No 10-32 x 3/8"
BZ 71490	Screw-Rd Hd No -10-24 x 3/8"	BT 71653	Pin-Straight-3/16" x 1"
BZ 71494	Bolt-No 12-28 x 5/8"-Special Hd	BO 71654	Bolt-Hex Head-No 10-32 x 13/16"
BO 71498	Screw-Oval Hd-No 8-32 x 3/8"	BM 71657	Bolt-Carriage-5/16"-24 x 5/8"
BT 71499	Washer-Plain-13/64"-3/8" x 1/32"	BZ 71660	Shim-Ball Seat-1/32"
71506	Use 8683	BZ 71661	Shim-Ball Seat-1/16"
BZ 71511	Washer-Plain-45/64" x 1-1/4" x 1/16"	BZ 71662	Shim-Ball Seat-1/8"
BO 71513	Nut-Acorn-5/16"-24 x 7/16"	71663	Use 71654
BO 71515	Screw-Spec Hd No 6 x 3/8"	BO 71665	Screw-Rd Hd Mach No 8-32 x 5/16"
BO 71518	Washer-Flat Side Plain-13/64" x 7/8" x 1/16"	BX 71667	Nut-Hex Spec-11/16"-18 x 35/64"
BO 71520	Hole Plug-Nickel-41/64"	BZ 71670	Fastener Stud-Top Dust Boot
BT 71521	Washer-Plain-1/2" x 1-1/4" x 5/64"	BZ 71671	Nut-Hex-7/16"-14 x 3/8"
BT 71522	Clevis Pin-1/4" x 7/8"	BO 71672	Nut-Spring-#8-32
BO 71523	Screw-Oval lid Mach-No 8-32	BO 71674	Lag Screw-1/4"-10 x 1-1/2"
BO 71525	Stud-Lift the Dot-No 6 Wood Screw	BT 71677	Screw-Rd Head-No 6-32 x 1"
BZ 71526	Bolt-Hex Head-5/16"-24 x 2"	BO 71678	Screw-Flat Head-1/4"-28 x 1/2"
71527	Use 170662	BT 71680	Bolt-Hex Head 3/e-16 x 1-3/4"
BZ 71532	Cotter Pin-Special for 35 Shock	71681	Use 170041
BO 71533	Screw-Flat Hd Mach No 10-32 x 5/16"	BZ 71682	Bolt-Step-5/16"-18 x 5/8"
BO 71537	Wood Screw-Oval Head-No 8 x 7/8"	BO 71683	Bolt-Hex Hd 5/16"-24 x 7/8"
BO 71538	Screw-Oval Hd-No 8-32 x 1-3/8"	71684	Use 170085
BT 71540	Washer-Plain-15/32 x 1-1/4 x 1/16"	71686	Use 171228
BO 71541	Screw-Rd lid Mach 1/4"-28 x 1/2"	BM 71687	Nut-Hex-5/16"-18 x 17/64"
BZ 71543	Washer-Plain-41/64 x 1-1/4" x 1/16"	BM 71688	Stud-5/16"-18 x 2"
BZ 71545	Washer-25/64" x 7/8" x 1/16"	BM 71691	Stud-5/16"-18 Stud End and 5/16"-24 Nut End x 1-1/16"
BO 71549	Screw-Sheet Metal-No 6 x 9/32"	BM 71692	Elbow-Tube-Single-3/8"-Pipe and 3/4"-16
*SP 71550	Bulb-Lamp-2 C.P.	BM 71694	Tube Tee-3/8" Pipe x 3/4"-16
BZ 71552	Ferrule-Rubber-1/2"	BO 71697	Screw-Special Oval Hd Sht Metal No 8 x 3/4"
BZ 71554	Clip-Conduit-Black Enamel-1/2"	BO 71698	Screw-Oval Hd Wood-No 8 x 7/8"
BO 71555	Screw-Oval Head Mach-#6 x 3/8"	BO 71699	Screw-Oval Hd Sht Metal No 8 x 1"
BT 71556	Clamp-Hose-11/16"	BO 71700	Screw-Special Oval Hd Sht Metal No 8 x 1-1/4"
BZ 71557	Rivet-Button Head-5/16" x 7/16"	BO 71701	Washer-Finish No 6 Countereunk
BO 71558	Screw-Slotted Hex Hd 1/4"-20 x 3-3/8"	71703	Use 71420
BO 71561	Screw-Binding Hd Sht Metal-#8 x 3/8"	BZ 71704	Bolt-Hex Hd -7/16"-20 x 1-1/8"
BT 71571	Screw-Fillister Hd Mach #10-24 x 1/2"	BX 71705	Washer-Special Plain-17/32" x 1-1/16" x 1/8"
BX 71577	Nut-Hex Slotted-3/4"-20 x 9/16"	BO 71706	Screw-Rd Hd Mach #6-32 x 5/16"
BM 71578	Nut-Hex-3/8"-16 x 3/8"	BO 71707	Screw-Binding Hd Sht Metal-#10 x 5/8"
71585	Rivet-Oval Hd Tubular-3/16" x 3/16" (Use 70523)	BO 71708	Scrdw-Fill Hd Mach No 10-24
BZ 71590	Nut-Hex-1/2"-13 x 7/16"	71710	Use 71283 Cup 71711 Cone
BZ 71591	Nut-Hex-7/16"-14 x 3/8"	F 71711	Cone-Roller Bearing
F 71596	Cone-Roller Bearing-Bower No BT-E 25877-T	BZ 71712	Lock Washer-External Tooth-No 8
F 71597	Cup-Roller Brg-Bower No BT-E 2521	BZ 71713	Nut-Special Hex-5/8"-18 x 15/32"
BT 71599	Screw-Oval Hd Mach No 10-32 x 5/8"		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 71714	Screw-Fill Hd 5/16"-24 x 3/4"	BO 71730	Lock Washer-External Tooth-1/4"
BO 71715	Screw-Spec Fillister Hd Mach #10-24	BO 71732	Bolt-Hex Hd-1/4"-28 x 3/4"
BO 71716	Screw-Spec Fillister Hd Mach #10-32 x 3/8"	BM 71733	Bolt-Hex Hd-5/16"-18 x 1-5/8"
BO 71717	Bolt-Hex-1/4"-28 x 1/2"	BO 71734	Rivet-Oval lid Tubular-1/4" x 1-5/8"
BZ 71719	Nut-Companion-3/8"-24	71735	Terminal-Wire-Bullet Type (Use 170562)
BO 71720	Bolt-Hex Hd 3/8"-24 x 1-1/8"	71736	Use 170089
BO 71721	Washer-Plain-13/32" x 7/8" x 1/8"	BO 71737	Screw-Flat Hd Mach 1/4"-20 x 2"
BO 71722	Bolt-Hex Head-3/8"-24 x 1-1/2"	BO 71738	Bolt-Hex Hd 5/16"-24 x 9/16"
BZ 71725	Bolt-Hex Hd 7/16"-14 x 3-1/4"	BO 71739	Bolt-Hex Hd 1/e-20 x 1-1/8"
BO 71726	Screw-Fill Hd #10-32	71740	Use 71449
BO 71727	Screw-Oval Hd Sht Metal Drive No 2 x 1/4"	BO 71741	Screw-Rd Hd Mach No 6-32 x 1/2"
BO 71728	Bolt-Hex Hd-Cadmium-3/8"-16 x 7/8"	BO 71746	Bolt-Hex Hd-1/4"-28 x 3/4"
BO 71729	Lock Washer-External Tooth-3/8"		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 75077	Regulator Assy-Dr Window-LH	26-27 Hud-Esx Co
BO 75149	Dowel-Seat Cushion	26 thru 31 Hud-Esx,37 4Cpe
BO 75152	Retainer-Door Bumper	27 thru 1947 All
BO 75174	Rod-Door Hinge	27-28 Hud S Co-Sed,Esx Cpe Co-Del-Sed; 29 Hud R-Esx Co-Cpe-Sed; Dover
BO 75261	Clip-Dr Glass Run	27 thru 37 All
BO 75318	Spring	28 Hud "O"-Esx Co-Sed
BO 75325	Strap-Door Check	27 Hud "O"-Essex Co
A 77067	Fender-Leaf-Rear	27 Essex Speedabout
BO 78531	Hinge-Door Half	28-29 Co-Cpe-Sed-Dover
78532	Use 80263	
BO 78581	Rest Channel Assy-Window-RH	27-28-29 Co-Cpe-Sed
A 78628	Fender-Rear-RH	28 Hudson S Co-Sed
A 78629	Fender Assy-Rear-LH	28 Hudson S Co-Sed
BO 78641	Check Strap-Door	28-29 Hudson-Essex
A 78665	Splash Guard Assy-Run Bd-LH-Lac	28 Hudson S
A 78913	Fender Assy-Rear-RH-En or Pr	28 Hudson Bro-7Sed-Vic
A 78913	Fender Assy-Rear-RH-Lac	28 Hud Bro-7Sed-Vic
79040	Use 89828	
BO 79149	Spring-Dovetail	27 thru 31 All
BO 79265	Glass Run Assy-Front Door Window	27-28 Hud S-Esx Co-Sed-Esx Cpe
79308	Pin-Wdo Regulator Handle(Use 147278)	27 Thrust All Models
BO 79339	Handle-Cylinder Assy-Door Locking	27-28 Hudson-Essex
BO 79709	Spring-Wdo Reg Handle Escutch	27 thru 47 All,1948-1949 exc 484-494 CvBro,1950 All
BO 79756	Ammeter Assembly	27-28-29 Essex
BO 80263	Hinge & Reinforcement Assy-Door	29 Esx Co-Cpe-Sed,29 Hud H Coach-Coupe-Sed
80381	Use 79241	
BZ 80593	Bracket Assy-Jacket Tube	28-29 Co-Cpe-Sedan
81270	Use 85997	
BZ 81272	Cap-Radiator Filler	29 Hudson-Essex-Dover
BZ 81539	Pivot-Rad Shutter Bell Crank	29 Hudson-Essex
BZ 81554	Bracket-RH-Headlamp	Dover
BZ 81555	Bracket-LH-Headlamp	Dover
BO 81667	Handle-Cowl Ventilator	29 Hudson,Essex-Dover
BZ 81677	Bolt-Spare Tire Clamp	29 Hud R-Dover A,30-31 Hud-Esx
BZ 81679	Bracket-Spare Tire to Dash	29 Hud R-Dover,31 Essex Spec Ph
BZ 81690	Clamp-Front Bumper to Frame	29 Hudson R
BO 81691	Bracket-Visor-RH	29 Hud R Co-Cpe-Sed,Essex Cpe
BZ 81706	Strap Assy-Spare Tire	29-30-31 Hudson-Essex
BO 81710	Mirror-Rear View	29-30-31 Hudson-Essex
BZ 81732	Lock & Key Assy-Spare Tire	31 Essex Spec Ph
BO 81809	Handle Assy-Door Outside	29 Hud-Esx Co-Cpe-Sed
BO 81823	Control Assy-Starter	29 Hudson R-Essex
BO 81950	Lock Assy-Deck Lid	29 thru 32 Cpe-Ro,33 Terr Cpe-Ro
A 82365	Fender-LH-Front-Spec-Prime	29 Hudson L
BZ 82487	Reinforcement-Front Bumper	29 Essex
C 82488	Bar-Bumper-Inside-RH	29 Essex
BZ 82491	Finish Plate-Front Bumper	29 Essex,31 Essex Comm
BZ 82503	Bar-LH-Inside-Rear Bumperette	29 Essex
BZ 82531	Bolt & Nut-For Bumperette Fin Pl	29-30 Essex,31 Esx Corn
BZ 82535	Clamp-Rear Bumper Finish Plate	30-31 Hudson-Essex
A 82657	Fender-LH-Rear-Prime	29 Essex Town Sed
A 82689	Rear Dust Shield-Prime	29 Essex Ro-Town Sed-Conv
A 83035	Bonnet Assy-Prime	29 Essex 80 Ro
C 83049	Tie Rod Assy-Radiator	29 Hudson R-L
BO 83095	Mirror	29 Hudson L
A 83114	Bonnet Complete-Lacquer	29 Essex Exc 80 Ro,Dover
83134	Use 83035	
BO 83191	Attaching Plate-Deck Lid Check Bracket	29 thru 34 Cpe,36 Bro-Sed,37 3Cpe, 39 Bro-Sed-Uco, 1940 thru 1942 All
A 83207	Radiator Shell & Shutter Assy	Dover
BO 83523	Lock Assy-RH Door	29 Phaeton-Ro,31 Essex Spec Ph
BO 83676	Rubber Bumper Door	29 Hud Town Sed,Hud-Esx Cv
A 85065	Splash Guard Assy-Pr	30 Essex
BO 85066	Lock Assy-RH Door	30 Hudson-Essex
BO 85068	Lock Assy-LH Door	30 Hudson-Essex
BO 85297	Plate-Door Lock Striker.	30-31 Hudson-Essex
BO 85425	Spring-Cowl Vent	30 thru 37 All
BO 85426	Weatherstrip-Cowl Vent	30 thru 33 All
BZ 85736	Molding-Front-RH Running Board	30-31 Hudson
BZ 85737	Molding-Front-LH Running Board	30-31 Hudson
BZ 85738	Molding-RH Rear Running Board	30-31 Hudson
BZ 85739	Molding-LH Rear Running Board	30-31 Hudson

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 85747	Clip-Wire and Tube	30 thru 1950 All
C 85763	Drip Molding-RH	30 U Tour Sed-T Sed
A 85930	Bonnet Complete-Lac	30 Essex
85958	Use 95916	
BO 85978	Handle-Remote Control	30 Hud Co-Cpe-Sed,Hud U Bro
BO 85981	Handle Assy-Door Outside	30 Hudson-Essex
BO 85983	Switch & Escutcheon Plate-Dome Light	30 Hud T Co, Hud U Bro-7P Sed,30 Esx Co-Tour Sed-Sed-Cpe
BZ 85997	Cover-Starting Crank Hole	30 Hudson
86009	Use 90008	
BZ 86094	Lock Assy-Spare Tire	30 Esx,31 Hud-Esx
86096	Use 106033	
BO 86205	Wire Assy-Carb Choke	30 Essex
BO 86207	Wire Assy-Starter Control .	29 Esx,30-31 Hud-Esx
BZ 86239	Plate-Bumper Finish	30-31 Hudson
BO 86255	Regulator Assy-Door Wdo-RH	30-31 Hudson-Essex
BO 86256	Regulator Assy-Door Wdo-LH	30-31 Hudson-Essex
BO 86272	Washer-Regulator Attaching Screw	30 thru 1947 All
BO 86280	Motometer-Assy	30 Hud-Esx,31 Hud U 7P Ph,Hud T 5P Ph-Ro
BO 86282	Gauge Assy-Gas or Oil Level	30 Hud-Esx,31 Hud U-T Ph, T Ro
BO 86283	Gauge Assy-Oil Pressure	30 Hud-Exc,31 Hud U-T Ph, T Ro
BO 87117	Plunger & Wire Assy-Carb Choke Knob	30 Hudson-Essex
BO 87152	Remote Control Assy	30 Hudson-Essex
C 87222	Molding-Roof-Front	30 U Tr Sed,Hud T-Esx Sed-Co-Cpe,31 All
C 87224	Molding-Roof-Side	30-31 Hud T-Esx Co-Sed
BO 87598	W/Strip Sides & Bottom-W/Shield	30-31 All
A 87635	Shell Assy-Rad Chrome-Plated Less Shutters	29-30 Hudson
BO 87726	Pocket-Door Dovetail-Complete	30 All,31 Hud T-Esx Co-Cpe,Esx 7 Sed
BO 87776	Spring & Sleeve Assy-W/Shield Regulator	31 U Tr-7P Sed-Bro,T Co-Cpe-Sed
BO 87798	Plate-Deck Door Lock Striker	33 thru 35 Hud,32 thru 35 Terr,36 4 Cpe-CvCpe
*C 88024	Body Lacquer-Ebony Black	
A 89157	Splash Grd-Rear-En or Pr	31 Hudson-Essex
A 89303	Shell Assy-Rad Chromium	31 Essex
A 89336	Fender Well-Front-LB	31 Hudson
A 89606	Splash Guard-Rear-Pr	31 Hud T-Esx,Hud U Del Bro-Spec Sed
BO 89657	Lock Assy-RH-Front Door	31 Hudson-Essex
BO 89658	Lock Assy-LH-Front Door	31 Hudson-Essex
BO 89659	Remote Cent Assy-Door Lock-Front	31 Hudson-Essex
BO 89660	Remote Cont Assy-Door Lock-Front	31 Hudson-Essex
A 89801	Shell Assy-Rad	31 Hudson
BO 89828	Hinge Assy-Seat Back	30 thru 33 Hud,31-32 Esx,33-34 Terr,35 2Cpe, 36 thru 1947 Cab-CabPu
C 89906	Molding-Roof Drip-LH	31 T Town Sed-U Bro,Esx Sed
C 89915	Drip Molding-RH	31 T-U-Essex Sed
C 89916	Drip Molding-LH	31 T-U Essex Sed
BO 90003	Handle & Cylinder Assy-Door Outside	31 Hudson-Essex
BO 90004	Door Handle-Outside-LR-RF	31 Sedan-Bro
BO 90005	Door Handle-Outside-LF-RR	31 Sedan-Bro
BO 90006	Door Handle & Cylinder Assy-Outside	31 Esx Co-Sed-Tr Sed-Cpe
BO 90007	Door Handle-Outside	31 Essex Co-Sed-Tr Sed-Cpe
BO 90008	Handle & Cylinder Assy-Deck Lid	31 Essex 2Cpe-4Cpe
BO 90009	Door Lock Assy	31 U Tr-7P Sed-Bro, T Co-Cpe-Sed-Town Sed,Esx Co-Sed-Tr Sed-Cpe
BO 90010	Door Lock Assy	31 U Tr-7P Sed-Bro, T Co-Cpe-Sed-Town Sed,Esx Co-Sed & Tr Sed-Cpe
BO 90011	Door Lock Assy	31 U Bro Tr-7P Sed, T Sed-Town Sed, Esx Sed Tr-7P Sed
BO 90012	Rubber Bumper	31 thru 35 All
BO 90025	Door Handle-Inside (Use 112672)	31 Essex
BO 90026	Door Handle-Inside	31 Hudson
BO 90037	Brkt-Side Lamp-RH	31 Hud Co-Cpe-Bro-Sed
BO 90038	Brkt-Side Lamp-LH	31 Hud Co-Cpe-Bro-Sed
90040	Use 106033	
BO 90047	Gauge Assy-Oil Pressure	31 Hud-Esx exc T Ph-Re
BO 90048	Gauge Assy-Gas & Oil Level	31 Hud-Esx exc Hud Ph-Re
BO 90049	Ammeter Assy	31 Hud-Esx exc Hud Ph-Re
BO 90050	Motometer Assy	31 Hudson-Essex
90100	Mat & Pad-Ft Floor Complete (Use 201134)	31 T Sed-Cpe-Ro, U Tr Sed-Bro-7Sed- Ph,Esx Tr Sed-Cpe
90194	Wire Assy-Carb Choke (Use 90195)	31 Hudson
BO 90195	Knob & Plunger Assy-Carb Choke Wire	31 Hudson-Essex
BO 90204	Cloth-Seat	31 Essex Co-Sed-Town Sed-Cpe
BO 90208	Cloth-Seat	31 T Cpe-Sed
BO 90261	Switch & Escutcheon Assy-Dome Lamp	31 Esx Co-Sed-Cpe-Tr-7Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
90281	Use 106033	
BZ 90284	Wire Assy-Starter Control	31 Hudson-Essex
90481	Use 92441	
A 91856	Bonnet Complete-Prime	31 U DeL Bro,Esx Spec Cpe
BO 92441	Ornament Assy-Rad	31 Essex
BO 92754	Pull-to-Assy-Door	32 T Spec Cpe, U Spec Sed
M 92830	White Cotton Sheeting	
BO 94115	Bracket-Door Check	32 Hud-Esx,33 Hud,34 thru 1940 All
A 94136	Splash Guard-Radiator-Pr	32 Hudson
A 94159	Splash Guard-Radiator-Pr	32 Essex
BO 94321	Clip-Bonnet Hinge-Upper	32-33-34 All,35 DeLuxe Cv
BO 94322	Clip-Bonnet Hinge-Lower	32-33-34 All,35 DeLuxe Cv
BO 94323	Tapping Plate-Bonnet Hinge Clip	32 thru 38 All
BO 94427	Tapping Plate-Door Lock Striker	32-36 All
BO 94501	Bracket & Hinge Assy-RH Lower	32-33 Sedan
BO 94541	Plate-Door Dovetail	32 thru 39 All,40 Panel
BO 94583	Regulator Assy-RH Front Door Window	32-33 Hud,32 Esx,33 Terr Sed
BO 94584	Regulator Assy-LH Front Door Window	32-33 Hud,32 Esx,33 Terr Sed
BO 94585	Regulator Assy-RH Rear Door Window	32-33 Sedan
94587	Use 100777	
94588	Use 100776	
94589	Use 100778	
BO 94590	Lock Assy-LH Rear Door	32 Hud Sed,Esx Std-Town-Spec Sed,Terr Sed
BO 94597	Wire & Tube Assy-Carb Choke	32 Esx,33 E Co-2Cpe-Ph
BO 94598	Wire & Tube Assy-Carb Choke	32 Hud,33 L Bro-CI Sed
94683	Hub Bolt-Wood Wheel Carrier (Use 37816)	32 Hudson
94684	Hub Bolt-Wood Wheel Carrier (Use 37815)	32 Essex
94685	Use 37860	
94714	Use 96854	
BO 94738	Clamp-Radiator Ornament	32 Hud-Esx,34 LT-LL-K-KU,34-35 All
BZ 94743	Clamp-Radiator and Fender Stay Rod	32-33 Hudson,32 Essex,1941-1947 All
BZ 94744	Plate-Fender to Frame Brace Clamp	1941 thru 1947 All
BO 94780	Hinge Pin-Front & Rear Door-Upper	32-33 All
BO 94781	Hinge Pin-Front & Rear Door-Lower	32-33 All
BO 94784	Hinge-RH Front Door-Upper-Door Half	32 Hud-Esx Co-Cpe-Sed,33 Hud-Terr K-KT
BO 94785	Hinge-LH Front Door-Upper-Door Half	32 Hud-Esx Co-Cpe-Sed,33 Hud-Terr K-KT
BO 94790	Hinge -RH Rear Door-Upper-Door Half	32 Hudson-Esx Sed,32 K Sed
BO 94791	Hinge-LH Rear Door-Upper-Door Half	32 Hudson-Esx Sed,32 K Sed
BO 94792	Hinge-Rear Door-Lower-RH	32-33 Hud-Terr Sed,Esx Std-Town-Spec Sed
BO 94793	Hinge-Rear Door-Lower-LH	32-33 Hud-Terr Sed,Esx Std-Town-Spec Sed
BZ 94794	Brkt-Tail Lamp Support	32-33 Hudson,33 Terr
BZ 94795	Brkt-Tail Lamp Support	32-33 Hudson,32 Essex
A 94808	Splash Guard-Rear-Pr	32 Hud-Esx Cpe,33 E-T Cpe
BO 94828	W-Strip-W/Shield Hinge	32 All
BZ 94856	Brkt-LH Headlamp	32 Hudson
BO 94870	Door Dovetail	32 thru 39 All,40 Panel
BO 94915	Strap-Door Check	32 Hud-Esx,33 Hud,34-35 Hud & Terr
BZ 94923	Support Assy-LH Front Fender	32-33 Hudson
BO 94974	Handle Assy-Door & Qtr Wdo Reg	32 Esx Co-Cpe-Sed,33E 2 Cpe-Co
BO 94975	Handle-Door Inside.	32 Esx Co-Cpe-Sed,33E 2 Cpe-Co
BO 94977	Escutcheon Plate	32 Esx Co-Cpe-Sed,33E 2Cpe-Co
95024	Use 96686 & 96687	
95025	Use 96686 & 96687	
BZ 95037	Bumper Bar-Reinforcement-RH-Rear	32 Essex,33 E
BZ 95038	Bumper Bar-Reinforcement-LH Rear	32 Essex,33 E
C 95042	Bar Reinforcement-Rear Bumper-Right	32 Hudson,33 T-L
C 95043	Bumper Bar Reinforcement-Left Rear	32 Hudson,33 T-L
BO 95075	Bracket-Trim Retainer	32-34-35 All
95121	Handle-Door Inside (Use 107987)	32-33 Hudson T-U-L
BO 95136	Escutcheon Plate	32 thru 35 Closed Models,61,62
95156	Use 106033	
BO 95186	Hinge-RH-Deck Door-Body Half	32 thru 35 Cpe-CvCpe,36 Cv-4Cpe
BO 95187	Hinge-LH-Deck Door-Body Half	32 thru 35 Cpe-CvCpe,36 Cv-4Cpe
BO 95196	Bracket and Hinge Assy-RH-Rear Pillar	32 Hud-Esx Sed,33 All
BZ 95292	Catch Assy-Bonnet Lock	32 Hudson-Essex,33 E Ph
95294	Lock Assy-Bonnet Front (Use 95330)	32-33 Hudson
95295	Use 95331	
BZ 95300	Cover-Bonnet Rear Corner	32 Esx,32 thru 37 Hud,34 thru 37 Terr-Comm
BZ 95330	Lock Assy-Bonnet Front	32 Essex,33 E
BZ 95331	Lock Assy-Bonnet Rear	32 Essex,33 E
BO 95380	Oil & Gas Gauge Assy	32 Hudson-Essex
BO 95407	Bushing-Strg Gear Jacket Tube Brkt	32-34-35 All,33 Hud-Terr KT
95410	Use 99087	
95474	Wire & Knob Assy-Choke (Use 94597)	32 Essex

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 95498	Bumper-Deck Lid	32-33 Coupes-Ro
BO 95509	Glass Run & Clip Assy-Front & Rear Door	32-33 Hud Co-Cpe-Sed,32 Esx Co-Cpe-Sed,33 Terr
BZ 95632	Plug-Rear Splash Guard Center Hole	32 Hudson-Essex,33 Hudson
95816	Use 96865	
95817	Cylinder Assy-(Use 96866)	32-33 Hudson 8
BO 95889	Headlamp Complete	32 Hudson,33 T-L
95890	Stop Lamp Complete (Use 96172)	32 Hudson,33 T-L
95891	Stop & Tail Lamp Complete (Use 95892)	32 Hudson,33 T-L
BO 95892	Tail & Stop Lamp Complete	32 Essex-Terr
95899	Handle & Lock Cyl-Door Outside (Use 116927)	32 Essex
BO 95900	Handle-Door Outside-LH-Front	32 Essex
BO 95901	Handle & Lock Cyl Complete-Door Outside	32-33 Hud 8
BO 95902	Handle-Door Outside-LH-Front	32-33 Hud 8
BO 95903	Handle-Door Outside-RH-Rear	32-33 Hud 8
BO 95904	Handle-Door Outside-LH-Rear	32 Essex
BO 95906	Handle-Door Outside-LH-Rear	32-33 Hud 8
BO 95907	Handle & Lock Cylinder-Deck Lid-Comp	32 Essex 4Cpe-CvCpe
BO 95909	Handle & Lock Cylinder-Comp Deck Lid	32-33 2Cpe
95910	Handle Assy-Door Outside-(Use 116927)	32 Essex,33 E
BO 95911	Handle Assy-Door Outside-Less Cyl	32-33 Hud 8
BO 95916	Shim-Cowl to Bonnet	32-33 All,70,71,72,78,80,81,82,88
BO 95931	Wire & Socket Assy-Oil & Ampere Light	32 Hud-Esx,33 Hud 3 Ph, L Bro-Cl Sed
95960	Lock Assy-Bonnet Rear (Use 95331)	32 All,33 Hud
BO 95978	Retainer-Pick up Box Pin	70-80-89-90 UCpe
BZ 96014	Cup Washer	32 Esx,36 Hud 8,39 thru 1950 All
BO 96023	Tee Nut-1/4"-20	34 thru 1947 All
96028	Drain Tube-Cowl Vent (Use 100523)	32 Hud-Esx,33 Hud E 5-P.Ph. & L 7-P.Ph
BO 96089	Spring-Anti Rattle	32 Esx,33 thru 1950 All
BO 96105	Lens-Headlamp Door	32 Essex
BO 96106	Door Assy-Headlamp-Less Lens	32 Essex
96111	Use 65588	
BO 96116	Screw-Headlamp Door	32 Esx-Terr K,33 E-K
BO 96117	Lug-Headlamp Door	32 Essex
BO 96122	Ornament-Radiator Grille	32 Essex
96125	Use 79709	
BO 96131	Lens-Side Lamp	32 Essex
BO 96172	Stop Lamp-Complete	32 Essex
BO 96198	Lens-Headlamp Door	32 Hudson,33 T-L
BO 96216	Lens-Stop & Tail Light Lamp	32 Essex - Terr K,33 K
BO 96217	Door-Stop & Tail Lamp	32 Esx,32K,33E-K -KT
BO 96219	Spring-Stop & Tail Lamp Lens	32 Esx,32K,33E-K-KT
BO 96220	Lens-Tail & Stop Lamp License	32 Esx,32K,33E-K
BO 96221	Gasket-Tail & Stop Lamp License Lens	32 Esx,32K,33E-K-KT-KU,34-35 Terr,35GH-36 All
96242	Use 102107	
BO 96248	Wire Assy-Carburetor Choke	32-33 T-U,33 L Bro-Cl Sed
BO 96256	Door Assy-Headlamp-Less Lens	32 Hudson,33 T-L
96285	Use 109324	
BO 96370	Lens-Tail & Stop Light	32 Hudson,33 T-L
BO 96371	Lens-Tail Lamp License	32 Hudson,33 T-L
BO 96373	Gasket-Tail & Stop Lamp Door Lens	32 Hudson,33 T-L
C 96428	Wire Assy-Shock Absorber Control	32 Essex
C 96429	Wire Assy-Shock Absorber Control	32 Hudson
BO 96485	Bumper-Door & Qtr Window Glass	32 thru 39 All
BO 96493	W-Strip & Foundation Assy-Front Door Glass	32-33 Hud-Essex Sed-2Cpe-4Cpe,32-33 Terr
C 96686	Bar-Front Bumper-Inside-RH-Pr	32 Essex,33 E
C 96687	Bar-Front Bumper-Inside-LH-Pr	32 Essex,33 E
96698	Use 111523	
BO 96774	Flat Spring-Door Lock & Remote Cont	30-31-32 Hud-Esx,33 Hudson
BO 96779	Washer-Seat Track Rod & Cowl Hinge	27 thru 39 All
BO 96854	Plate-Rear Door Lock Striker	32 Hud-Esx,33 Hud,33K-Kt
BO 96855	Felt-Front Door Lock Striker	32 Ro-CvCpe,33 thru 38 All exc Station
96856	Felt-Rr Door Lock Striker (Use 111630)	32 Hud & Esx,33 Hud & Terr K & KT 34 Comp.Std & Cl Sed & Bro.
BZ 96858	Nut-Wheel Carrier Lock-Cadmium	32-33 Hud-Esx,34 thru 36 Coupe
BO 96865	Cyl Assy-Door Handle & Tire Lock	32 Hud-Esx-Terr K Std-Spt Ro,33 Hud
BO 96866	Cyl Assy-Door Handle Lock	32 Hud,33 T Co-Sed-Cpe,L Tr-7Sed 35 Co-Sed
BZ 96914	Brace-Spare Tire to Dash-Wire Wheels	32 Hudson-Essex
BO 96985	Tee Nut-Front Seat Frame	1932 thru 1947 All
BO 97065	Floor Mat-Rear	32 T Std Sed,Esx Spec-Std Sed
BO 99026	Weatherstrip-Windshield	32 Hudson-Essex,32 Terr
BZ 99087	Bracket Assy-Steering Gear Jacket Tube	32-33 Hudson 8
BO 99200	Glass-Dome lamp	32-33 Essex- Terr Co-Cpe-Sed
BO 99202	Stem-Dome lamp Switch	32-33 Essex-Terr Co-Cpe-Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 99350	Headlamp Door Lens	32 Essex-Terr, 33 K
BO 99351	Headlamp Door Assy-Less Lens	32 Essex-Terr, 33 K
BO 99352	Headlamp Reflector Assy	32 Essex-Terr, 33 K Std
BO 99353	Headlamp Cable Assy	32 Essex-Terr, 33 K Std, 33 E-KT
BO 99354	Headlamp Door Lug	32 Essex, 32-33 K
BO 99425	Regulator Assy-Door Window-RH	32 Hudson-T-Essex Cv
BO 99426	Regulator Assy-Door Window-LH	32 Hudson T-Essex Cv
	99427 Use 99428	
BO 99428	Weatherstrip-Pillar Finish Panel	32 Hud T-Esx Cv, 33 E-T Cv
BO 99450	Spring-Door Lock Bolt	32 Hud-Esx, 33 Hud-Terr K-KT
C 99452	Front End Assy-Body	32 T Cv
BO 99542	Bumper-Quarter Window Glass-Outer-Prime	33-34 Co-Sed, 36-37 Bro-UCo
C 99566	Front End Assy	33 Hud exc Cv
	99739 Use 107249	
BO 99740	Tail & Stop Lamp Complete	33 E
BO 99741	Lens-Stop & Tail Light Door	33 E, 35 Hud Co-Sed
A 99769	Radiator Splash Guard-Pr	33 T-L
	99897 Handle-Door Inside (Use 107987)	33 Hudson T&L
BO 99925	Headlamp Complete	33 E Co-Sed-2Cpe-4Cpe-Cv, 33 KT
C 99930	Front End Assy	33 E Co-2Cpe
C 99931	Front End Assy-RHD	33 E Co-2Cpe
BO 99945	Housing Assy-Tail & Stop Lamp	34 K-KU, 35 G-GU, 61 thru 65 Coupe
	100164 Use 101086	
	100165 Hinge-Front Door Lower-Body Half-(Use 101089)	32 Terr
BO 100166	Hinge-Rear Door-Upper-Body Half	32 K Sed, 33 K -KT Sed
BO 100167	Hinge-Rear Door-Lower-Body Half	32 K Sed, 33 K-KT Sed
A 100168	Fender Assy-RH Rear-Pr	32 K Co-Sed
A 100170	Fender Assy-RH-Rear-RHD-En	32 Terr Co-Sed
A 100195	Splash Guard Assy-Rear-En or Pr	32 Terr Std-Spec Co-Sed, 33 KT Sp Co
BO 100214	Regulator Assy-RH Front Door Window	32 K Sed, 33 K-KT Sed
BO 100215	Regulator Assy-LH Front Door Window	32 K Sed, 33 K-KT Sed
BO 100230	Handle Assy-RH Front Door-Outside-Less Cyl	32-33 Terr exc Cv
BO 100231	Handle Assy-LH Front Door-Outside	32-33 Terr, 33 E
BO 100232	Handle-RH Rear Door-Outside	32-33 Terr, 33 E
A 100250	Radiator Grill-Pr	33 KT-K Comm
BO 100336	Bracket Assy-Front License Plate	32 Terr, 33 KT-Hudson
BO 100337	Bracket Assy-Rear License Plate	32 Terr, 33 E-K, 34 LTS
BO 100341	Clamp-Front & Rear License Plates	32 Terr, 33 thru 1940 All, 10 Del, 11 Sta, 20, 28
BO 100342	Bracket-Tail Lamp Support	32-33 K, 33 KT
BO 100363	Bracket-RH Headlamp	32 Terr, 33 K-KT
BO 100364	Bracket-LH Headlamp	32 Terr, 33 K-KT
C 100391	Bumper Assy-Rear	32-33 K
C 100397	Bar-Rear Bumper Frame-RH	32 K, 33 K-KT
C 100398	Bar-Rear Bumper Frame-LH	32 K, 33 K-KT
C 100400	Running Board Assy-RH	32 K
	100407 Use 100195	
BZ 100465	Lock Cage Assy-Spare Wheel Carrier	32 Terr, 33 K-KT, 34 LT-K-KT Cpe-Ro, 34 Cpe-Cv
BZ 100466	Lock Stud-Spare Wheel Carrier	32-33 Terr, 34 thru 36 Cpe, 70 UCpe
BZ 100467	Pilot Stud-Spare Wheel Carrier	32-33 Terr, 34 thru 35 All, 36-37 Cpe
BZ 100475	Reinf Plate-RH-Front Fender Headlamp	32 Terr
BO 100476	Reinf Plate-LH-Front Fender Headlamp	32 Terr, 33 K-KT
BO 100491	Gauge Assy-Gasoline	32-33 K
BZ 100516	Clamp-Radiator Stay Rod	32-33 Terr, 34 thru 37 All, 1940 All
BZ 100517	Plate-Rad Stay Rod Clamp	32-33 Terr, 34 thru 37 All, 1940 All
BO 100523	Drain Tube-Cowl Ventilator	32-33 K-Hud, 34 K-KU-LT-LL, 35 All
BO 100528	Welt-Rad Shell to Splash Guard	32-33 Terr
BO 100548	Retainer Assy-Body Bolt Nut	32 Terr Ro, 33-34 K Comm, 35 All
BO 100580	Wire Assy-Tail & Stop Lamp	32 Terr, 32-33 K-KT
BO 100582	Washer-Body Bolt and Seat Spacer	32-33 Terr, 33 Comm, 34 thru 1946 All
	100583 Use 101767	
BO 100586	Escutcheon Plate-Inside Handle	32 K, 33 K-KT, 34 LT-LL-K-KU, 35 G-Gu-GH
	100587 Use 106034	
BO 100592	Wire & Socket Assy-Oil & Ampere Lights	32 Terr
BO 100594	Bonnet Lock Assy-Front	32-33 Terr
BO 100599	Reinforcement-Front Fender Lamp	32-33 Terr, 34-35 All, 36 CvCpe-4Cpe
	100600 Lamp Assy-Front Fender (Use 102102)	32 Terr Spec Co-Cpe-Sed-Cv-R0, 33 K-KT
BO 100604	Beacket Assy-Strg Gear Jacket Tube	32 Terr, 33 KT
BO 100612	Spring-Glove Box Door Knob	32 K, 33 K-KT
BO 100613	Nut-Glove Box Door Knob	32 Terr, 33 thru 36 All
	100745 Wire Assy-Starter Control (Use 94597)	32-33 K Std
BO 100750	Wire Assy-Starter Control	32-33 K Spec Models, 33 KT
BO 100755	Wire & Knob Assy-Carb Choke Or Str Cont	32 Essex, 33 E 3Cpe, 32-33 Terr
BO 100776	Lock Assy-RH Front Door	32 Exc Cv-Ro, 33 Exc Ro
BO 100777	Lock Assy-LH Front Door	32 Exc Cv-R0, 33 Exc Ro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 100778	Lock Assy-RH Rear Door	32-33 All
BO 100782	Plug-Hole-Rubber	32 thru 1947 All
BO 100788	Shim-Body Bolt	32 thru 1947 All
BO 100920	Handle Assy Complete-Deck Lid	32 Terr 4Cpe,33 K-KT 4Cpe-Cv-Ro
C 100938	Support & Reinf Assy-RH Front Fender	32 Terr
BO 100941	Retainer Assy-Nut	32 Terr,33 K Comm,38 thru 1942 All
BZ 100946	Bracket-Headlamp to Fender Supp RH	32 K,33 K-KT
BZ 100947	Bracket-Headlamp to Fender Supp LH	32 K,33 K-KT
101029	Mat & Pad Assy-Front Floor (Use 201134)	32-33 K Sed,33 K Spec Sed
BO 101072	Handle Assy-Door Outside-RH-Less Cylinder	32 Terr - Essex Cv,33 K Cv
BO 101086	Hinge-Front Door-Upper Body Half	32 K,33 K-KT
BO 101089	Hinge-Front Door Lower Body Half	32 K,33 K-KT
101153	Wire Assy-Starter Control (Use 94597)	32-33 K Ph
BO 101238	Handle-Door Inside	32-33 K Std Ro
101239	Use 101238	
BO 101374	Wire & Socket Assy-Oil & Ampere Lights	33 K-KT,33 Hud exc Bro-Cl Sed
A 101622	Fender Assy-RH Rear-Pr	33 K Co-Sed,K-KT Spec Co
A 101623	Fender Assy-LH-Rear-LHD-Pr	33 K Co-Sed,K-KT Spec Co
A 101632	Fender Assy-RH Rear-Pr	33 4Cpe
A 101634	Fender Assy-RH Rear-Pr	33 K-KT 2Cpe
A 101638	Fender Assy-RH Rear-Pr	33 K Sed,KU-KT Std Sed
A 101639	Fender Assy-LH-Rear-Pr	33 Terr Sed
A 101668	Fender Assy-RH Front-Pr	33 KT-Exc Co-2Cpe
A 101669	Fender Assy-LH Front-Pr	33 KT Exc Co-2Cpe
BZ 101687	Extension-Front Fender Ledge-RH	33 KU-KT
BZ 101688	Extension-Front Fender Ledge-LH	33 KU-KT
A 101708	Apron Assy-Rad Splash Guard-RH-Pr	33 K-KT
BO 101727	Door Complete-Bonnet Ventilator-Pr	33 KT
BO 101767	Handle Assy-Door & Qtr Window Regulator	33 K-KT
BZ 101790	Name Plate-Radiator	33 K
BZ 101792	Name Plate-Radiator	33 KT
101793	Name Plate-Radiator (Use 101792)	33 KT (Exp)
BO 101798	Spacer-Body Bolt	34-36 CabPu,35 All,70,78,89,1939 thru 1947 All
BO 101892	Wire Assy-Carburetor Choke Control	33 KT
BO 101897	Floor Mat-Front	33 KT Spec Sed
A 101937	Radiator Shell-Chromium	33 Terr
A 101939	Radiator Grill-Chromium	33 KT-KU
BZ 101949	Cover-Starting Crank Hole	33 Hudson, K-KT
101990	Tail & Stop Lamp Complete (Use 108226)	33 K-KT
BO 101991	License Lens-Tail & Stop Lamp	33 thru 35 Terr,35 Gh-HT,36 All
BO 101992	Door Lens-Tail & Stop Lamp-Lettered	33 K-KT,34 K-KU,35 Terr
102003	Use 106391	
BO 102006	Spring-Locker Box Door Knob	33 Hudson
BO 102007	Knob-Locker Box Door Lock	33 Hudson
BO 102008	Bolt-Locker Box Door Lock	33 Hudson, KT
BO 102016	Inside Visor Arm	33 Hudson,K-KT
BO 102034	License Lens-Tail & Stop Lamp	33 T-L
BO 102060	Lock Cyl Assy-Locker Box Door	33 Hudson exc Bro-Cl Sed
BO 102069	Cup Washer-Rear Compt Door Hinge and Lamp	41-42 All,51,52,53,54,171 thru 174, 481,483,491,493;500,501,503
BO 102099	Lens-Front Fender Lamp	33 KT Spec Co-Cpe-Sed-Std & Spt Ro
BO 102102	Lamp Assy-Front Fender	33 KT Spec Co-Cpes-Sed-Std & Spt Ro
102104	Regulator Assy (Use 102105)	33 E-K-Kt Co-Sed-2Cpe-4Cpe
BO 102105	Regulator Assy-Windshield	33 E-K-KT Co-Sed-2Cpe-4Cpe
BO 102107	Regulator Assy-Windshield	33 L Bro-Cl Sed
102145	Use 102105	
BZ 102238	Flexible Shaft Assy-Speedometer	33 K-KT,34K-KU-LT-LL,35 All
BO 102338	Bolt-Front Bumper Finish Plate	33 Hud T-L,33 K-KT,35 K Comm
BZ 102484	Bolt-Wheel to Carrier Clamp-Wood Whl	33 Hud,34 LT-LL-K-KU,35 Custom 8
BZ 102485	Bolt-Whl to Carrier Clamp	33 thru 39 All,1941-1942-1947 Station
BZ 102488	Ferrule-Dash Brkt Carrier Screw Clamp	33 thru 36 All
BZ 102489	Cage Assy-Side Wheel Carrier Lock	33 All,34 LT-LL-K-KU,35 All
BZ 102506	Pilot-Side Wheel to Carrier Clamp-Cadmium	33 Hud,34 Hud LL,35 Hud Custom 8
102513	Pilot-Side Whl to Car Cl-Wire Whl-Cad (Use 102506)	33 LL
BO 102523	Gauge Assy-Gas and Oil	33 Hudson exc Bro-Cl-Ph
BO 102524	Indicator Assy- Temperature	33 Hudson exc Bro-Cl-Ph
A 102549	Tire Well-LH-Front Fender	33 KU-KT
BO 102562	Lock & Keys Assy-Locker Door	33 Hudson exc Bro-Cl-Ph
BO 102569	Door Assy-Headlamp-Less Lens	33 E-KT
BO 102571	Lens-Headlamp Door	33 E-KT
BO 102575	Lug-Headlamp Door	33 E-KT
102576	Gasket-Headlamp Reflector (Use 102579)	33 E-KT
BO 102577	Screw-Headlamp Door	33 E-KT
BO 102579	Gasket & Clip Assy-Headlamp Lens	33 E-KT

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 102582	Reflector Assy-Headlamp	33 E,33 KT Sed-4Cpe
BO 102583	Retainer-Headlamp Door Lens	33 E-KT
BO 102676	Door-Frt Fdr Lamp-Black Opal	33 KT,K Spec Co
BO 102677	Reflector-Front Fender Lamp	33 K-KT
BO 102678	Cable Assy-Front Fender Lamp	33 K-KT
BO 102679	Gasket-Front Fender Lamp Lens	33 K-KT
BO 102684	Spring-Locker Dr Lock Bolt Anti Rattle	33 Hudson exc Bro-Cl
BO 102753	Retainer-Tail Lamp License Lens	34 LTS-Terr,35 All
102756	Use 119861	
BO 102765	Spring-Door Lock	32 K,33 K-KT
C 102876	Inside Bar-Front Bumper-RH	33 K-KT
102887	Use 119861	
BO 102888	Mirror-Exterior-Rear View	33 Cab-CabPu-Panel
103984	Bracket-Robe-Hanger	501-503 exc BsCpe
BO 106033	Regulator Assy-Windshield	33 K Std Ro-Cab-CabPu-Panel
BO 106034	Regulator Assy-Windshield	33 KT Std Ro,K-KT Cv-Spt Ro,E Cv
BO 106047	Handle & Knob Assy-W/Shield Regulator	33 T-L
BO 106048	Spring & Bushing Assy-W/Shield Regulator	33 E-K-KT
106056	Rivet-W/Shield Regulator Handle to Spring	33 Hud,33 K-KT,34 LT-LL-K-KU
BO 106072	Spring-Front Fender Lamp Lens	33 K-T
BO 106103	Clip-W/Shield Frame-Chrome	33 K-KT,34 LT-LL-K-KU
BO 106116	Draft Deflector Assy-LH Front Door	33 Terr Sedan
BO 106131	Draft Deflector Assy-LH-Front Door	33 Hud Exc L Bro-Sed,33 Terr Co-Cpe
BO 106300	Plug-Underbody Panel Hole	33 Terr,34 thru 1940 All
BO 106391	Gauge Assy-Gasoline	33 KT
106428	Bracket-Tail Lamp Support (Use 100342)	33 K-KT DeL
BZ 106431	Bracket-Headlamp-LH	33 KU-KT DeL
106432	Lamp-Tail & Stop (Use 96172)	
106443	Fender Assy-Frt-RH-With Lamp (Use 101800)	33 KU DeL
BZ 106448	Bracket Assy-Headlamp RH	33 KT-KU DeL
BZ 106449	Bracket Assy-Headlamp LH	33 KT-KU DeL
A 107000	Fender Assy-Rear-RH-Pr	34 Terr UCo-Sed Del,35 UCo-Panel
A 107001	Fender Assy-Rear-LH-Pr	34 Co-Sed-UCo,35 UCo
A 107013	Splash Guard Assy-Rr-Pr or En-Side Mount	34 LT-LL-K-KU,35 All
107080	Fender Assy-Front-RH (Use 112218)	34 K
A 107081	Fender Assy-Front-LH-Pr	34 K
107170	Use 107171	
BO 107171	Guide & Bumper Assy-Check Strap	34 thru 1940 Sedan
BO 107172	Channel Assy-Hinge Pillar Glass Run-Rear-RH	34 thru 1947 All
BO 107173	Channel Assy-Hinge Pillar Glass Run-Rear-LH	34 thru 1947 All
BO 107179	Bumper-Door Check Strap	34 thru 1940 All
BO 107186	Channel & Guide Assy-Rr Dr Wdo-RH	34-35-36 Sedan
C 107195	Door Assy-Rear-LH-Pr	34 Std Sed
BO 107210	Lock Assy-RH-Front Door	34-35-36 All
BO 107212	Lock Assy-RH-Rear Door	34-35-36 Sedan
BO 107213	Lock Assy-LH-Rear Door	34-35-36 Sedan
107214	Door Bumper (Us• 142214)	34 thru 38 Hud-Terr
A 107220	Fender Assy-Front-RH-Pr	34 LT-LL-K-KU
A 107221	Fender Assy-Front-LH-Pr	34 LT-LL-K-KU
BO 107226	Striker Plate-Front Door Lock	34 thru 36 All
BO 107230	Regulator Assy-Rear Door Window-RH.	34 thru 36 Sedan
BO 107231	Regulator Assy-Rear Door Window-LH	34 thru 36 Sedan
BZ 107232	Support-Front Fender Apron	34 thru 36 All
C 107242	Windshield Assy-Chrome-Safety Glass	34 LT-LL-K-KU
BO 107249	W/Strip-Windshield	34 LT-LL-K-KU,35 All
107288	Arm & Brkt Assy-(Use 108245)	34 LT-K-KU Co-Sed-2Cpe,34 LL Sed
BO 107297	Check Arm-Rear Compt Door Lower-LH	34-35 Co-Sed,36 2Cpe
BO 107298	Hinge Assy-Rear Compartment Door	34-35 Co-Sed,36 2Cpe
BO 107305	Striker Plate-Rear Compt Door Lock	34-35 Co-Sed-Bro-UCo
BO 107316	Lock Assy-Rear Compartment Door	34 All,35G
BO 107338	Hinge-Frt Door-Upper-Door Half-RH	34 All,35G
BO 107339	Hinge-Frt Door-Upper-Door Half-LH	34 All,35G
BO 107340	Hinge-Frt Door-Lower-Door Half-RH	34 All,35G,35 Cv
BO 107341	Hinge-Frt Door-Lower-Door Half-LH	34 All,35G,35 Cv
BO 107342	Hinge-Frt Door-Upper-Body Half	34 All,35G,35 Sedan
BO 107343	Hinge-Frt Door-Lower Body Half	34 LT-LL-K-KU,KS Cpe,35 CvCpe,35 Terr
BO 107344	Hinge-Rr Door-Upper-Door Half-RH	34 LT-LL-K-KU Sed,35 Sed-Bro
BO 107345	Hinge-Rr Door-Upper-Door Half-LH	34 LT-LL-K-KU Sed,35 Sed-Bro
BO 107346	Hinge-Rr Door-Lower-Door Half-RH	34 LT-LL-K-KU Sed,35 Sed-Bro
BO 107347	Hinge-Er Door-Lower-Door Half-LH	34 LT-LL-K-KU Sed,35 Sed-Bro
BO 107349	Hinge-Rear Door-Lower-Body Half	34 LT-LL-K-KU Sed,35 Sed-Bro
BO 107350	Hinge Pin-Front & Rear Door-Upper	34-35 All,36 CvCpe
BO 107351	Hinge Pin-Front & Rear Door-Lower	34-35 All,36 CvCpe
BO 107452	Weatherstrip-Cowl Ventilator	34 LT-LL-K-KU,35 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	107466 Use 115698	
	107467 Use 115699	
BZ	107472 Bracket-Headlamp to Fender-RH	34 K-KU-LT-LL
BZ	107473 Bracket-Headlamp to Fender-LH	34 K-KU-LT-LL
	107477 Panel Assy-Run BD-LH (Use 112475)	34 K-KU-LT
	107478 Panel Assy-Run BD-RH (Use 112478)	34 LL
	107479 Panel Assy-Run BD-LH (Use 112479)	34 LL
BZ	107487 Wedge-Retaining	34-35-1940-1941 All
BO	107545 Hinge Assy-Deck Door-Door Half	34 Cpe-Ro,35-36 CvCpe-4Cpe
C	107548 Mat Assy-Running Board RH	34 LL,35 Hud Custom 8
C	107549 Mat Assy-Running Board-LH	34 LL,35 Hud Custom 8
	107551 Use 112473	
	107552 Running Board Assy-RH (Use 112478)	34 LL
	107553 Running Board Assy-LH (Use 112479)	
A	107563 Radiator Shell Assy-Pr-Chrome Mldg	34 K-KU-LT-LL
BO	107590 Guide Assy-Front Door Check-RH	34 thru 36 All
BO	107591 Guide Assy-Front Door Check-LH	34 thru 36 All
BZ	107604 Clamp-Rad Grille to Shell-Upper-Cadmium	34 LT-LL-K-KU,35 Cab
A	107611 Grille Assy-Radiator-Velchrome	34 LT-LL
A	107612 Grille Assy-Radiator-Chrome	34 LT-LL
BO	107614 Bracket Assy-Jacket Tube	34 LT-LL-K-KU,35 All
A	107619 Splash Guard Assy-Rear-Lac	34 LT-K-KU Cpe-Ro
BO	107620 Weatherstrip-Deck Lid-Front & Sides	34 thru 36 CvCpe-4Cpe,34 Ro
BO	107621 Weatherstrip-Deck Lid	34 thru 36 2Cpe
BO	107622 Weatherstrip-Rear Compartment Door	34-35 Co-Sed
BO	107624 Bracket-Headlamp-RH	34 LT-LL-K-KU,35 All
BO	107625 Bracket-Headlamp-LH	34 LT-LL-K-KU,35 All
C	107642 Roof Bow #1	34 LT-LL-K-KU
C	107645 Roof Bow #3 & #4	34 Co-Sed
C	107648 Roof Bow #5 & #6	34 Co-Sed
A	107658 Panel-Bonnet Side-RH-Pr	34 Hudson
BO	107664 Bracket-Assy-Inst Panel Service Light	34 LT-LL-K-KU,35 All
BO	107665 Service Light Window-Inst Panel	34 LT-LL-K-KU,35 All
BO	107700 Knob Assy-Light Switch Control	34 LT-LL-K-KU,35 GU
BO	107701 Glass Channel-Quarter Window	34 LT-K-KU Cpe,35 Cpe
BO	107707 Plug-Underbody Panel Hole	34 thru 36 All
	107716 Star Rod Assy-Radiator-En(Use 120683)	34 LT-LL-KU,35 Hud
BO	107762 Lock Assy-Front Bonnet-RH	34 LT-LL-K,35 All
BO	107763 Lock Assy-Front Bonnet-LH	34 LT-LL-K,35 All
BO	107766 Lock Assy-Rear Bonnet	34 LT-LL-K,35 All
	107771 Channel-F Door Glass Run LH (Use 114967)	34 thru 38 All
	107781 Track Assy-F Door-LH (Use 114851)	34 K-KU-LT-LL,35 exc Cv
BO	107784 Door Handle-Bonnet Ventilator	34 LT-LL
BO	107785 Bumper-Rear Compt Door	34 All,35-36 Cpe
C	107786 Roof Molding-Front	35 Co-Sed UCo
C	107790 Roof Molding-Rear-RH	34 LT-K-KU Sed
C	107791 Roof Molding-Rear-LH	34 LT-K-KU Sed
BO	107817 Channel & Brace Assy-Frt Dr Glass-LH	62-63-64-65-72-73-74-75-82-83-84-85-95 Sedan
BO	107836 Cantilever Supp Assy-Frt Dr Glass-RH	34 thru 37 Hud,GU,62,72,82,83,84,85,95,97,92-93 CvCpe-CvBro,1940-1941-1942 Cv
BO	107837 Cantilever Supp Assy-Frt Dr Glass-LH	34 thru 37 Hud,GU,62,72,82,83,84,85,95,97,92-93 CvCpe-CvBro,1940-1941-1942 Cv
C	107840 Tire Carrier Assy-Rear Mount	34 Sedan
BZ	107847 Grommet-Rear Splash Guard Bumper	34-35 All
BO	107850 Windshield Regulator Assy	34 Exc LL
BO	107851 Regulator Assy-Windshield	34 LL
BO	107852 Bracket-W/Shield Reg to Inst Panel	34 LT-K-KU
BO	107856 Link Assy-W/Shield Reg Adjusting	34 LT-K-KU
BO	107866 Bushing-W/Shield Reg Spring-Folding Top	34 LT-LL-K-KU,35 Cv,37 thru 1947 Cv
BO	107870 Rivet-W/S Reg Adjusting Handle	34 LT-LL-K-KU
BO	107874 Mat & Pad Assy-Front Floor-LHD	34 LT-LL-K-KU
BO	107878 Chan & Brkt Assy-Frt Dr Glass Run-RH-Rr	34 thru 36 Hud,34 Terr,35 G11,62
BO	107879 Chan & Brkt Assy-Frt Dr Glass Run-LH-Rr	34 thru 36 Hud,34 Terr,35 GU,62
	107949 Use 111006	
C	107951 Carrier Assy-Spare Wheel Rear Mount	34 LT-K-KU 2Cpe,35 Cpe
BZ	107956 Ferrule-Spare Wheel Carrier Brace	34 thru 36 Cpe
BO	107981 Handle-Door Inside	34 K-KU-Co-Sed-Cpe
	107982 Handle-Assy-Door & Qtr Wdo Reg (Use 112674)	34 K-KU Co-Sed-Cpe-Compt-Vict-Comm
BO	107983 Handle Assy-Door & Quarter Wdo Reg	34 LT Co-Sed-Cpe
BO	107985 Handle Assy-Dr & Qtr Window Reg	34 LT Co-Sed-Cpe
BO	107986 Handle Assy-Frt Dr & Qtr Reg	34 LL,35 HU-HHU,65-67
BO	107987 Handle-Door Inside	34 LL Sed-Bro,35 HU-HHU,66,67
BO	107988 Handle Assy-Dr Wdo & Qtr Wdo Regulator	34 LL Sed-Bro,35 HU-HHU,36 All
	107995 Use 111008	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 108002	Bar-Rear Bumper Outside	34 KS Co-Sed
C 108006	Bar-Rear Bumper Inside-LH	35 Co-Sed
C 108007	Bar-Rear Bumper Frame-RH	34-35 Co-Sed-Bro
C 108008	Bar-Rear Bumper Frame-LH	34-35 Co-Sed-Bro
C 108010	Bar-Rear Bumper Inside-LH	34 Cpe
C 108011	Bar-Rear Bumper Frame-RH	34 Cpe-Sed Del-UCo,35 DeL Cpes
C 108012	Bar-Rear Bumper Frame-LH	34 Cpes-Sed Del-UCo,35 DeL Cpes
C 108025	Channel Assy-Front Door Glass Run-RH	34 thru 37 All,82 thru 87,95,97
C 108026	Channel Assy-Front Door Glass Run-LH	34 thru 37 All,82 thru 87,95,97
BO 108034	W/Strip-Frt Dr Wdo Glass Hdr-LH	34 LT Sed,34 K-KU
BZ 108038	Support Assy-Rear Fender Apron	34 thru 36 All
108042	Use 116927	
108043	Handle Assy-Door Outside (Less Cyl) Use 116927.	34 K-KU
108045	Handle Assy-Rear Door Outside (Use 142021)	34 thru 36 Terr
108046	Handle & Lock Cyl Complete-Outside (Use 116927)	34 LT-LL Co-Sed-Cpe-Comp,35 Hud
F 108047	Handle-Door Outside-Less Cylinder	34 LT Co-Sed-Cpe
108048	Handle-Door Outside-Left Front	34 thru 36 Hudson
108050	Regulator Assy-Ft Dr Wdo-RH (Use 111072)	34 LL Sed-Bro,34 LT-K-KU Co-Cpe
108051	Use 111073	
108052	Use 111074	
108053	Use 111075	
BO 108058	Cover-Hood Rear Corner	34-35 All
BO 108069	Lamp Assy-Dome	34 LL Sed-Bro,35 Co-Cpe,36 Exc Cv
BO 108070	Reflector & Socket Assy-Dome Lamp	34 LL Sed-Bro,35 Co-Cpe,36 Exc Cv
BO 108071	Glass-Dome Lamp	34 thru 36 All
BO 108072	Ring-Dome Lamp Glass Retainer	34 thru 36 Hud
BO 108076	Lamp Assy-Front Fender	34-35 All
BO 108087	Lamp Assy-Tail & Stop-LH	34-35 LT-LL-HU-HHU
BO 108088	Lamp Assy-Tail & Stop-RH	34-35 LT-LL-HU-HHU
BO 108089	Lamp Assy-Tail & Stop-LH	34-35 LT-LL-HU-HHU
BZ 108098	Bar-Front Bumper Frame-LH	34-35 All
BZ 108099	Bracket-Front Bumper Starting Crank	34-35 Terr
108104	Use 108006	
108106	Use 108010	
BO 108139	Striker-Locker Box Catch	34 LT-LL-K-KU
BO 108142	Catch-Locker Box	34 LT-LL-K-KU
BO 108143	Lock Assy-Locker Box Door	34-35 All
108146	Hinge Assy- (Use 112465)	34 LT-LL-K-KU
BO 108147	Door Assy-Locker Box	34-35 All
BO 108149	Bolt-Locker Box Door Lock	34-35 All
BO 108164	Handle & Cylinder Complete-Deck Lid	34-35 CvCpe-4Cpe
BO 108166	Handle Assy-Rear Comp Dr-Less Cyl	34 All,35 G-Co-Sed-Bro-UCo
BO 108168	Handle Assy-Deck Lid-Less Cyl	34-35 4Cpe-CvCpe
BO 108174	Weatherstrip-Front Door Wing-RH	34 thru 37 All,82 thru 87,95,97
BO 108175	Weatherstrip-Front Door Wing-LH	34 thru 37 All,82 thru 87,95,97
108183	Use 111657	
BO 108186	Ornament-Radiator Shell-Lower	34 K-KU-LT-LL,35 Cab
108187	Use 108606	
BO 108188	Ornament-Radiator	34 K-KU,35 Cab-CabPu
108189	Use 112725	
108190	Ornament-Radiator (Use 108492)	34 LT-LL
BO 108205	Bracket-Tail Lamp Support-LH	34 LTS-K-KS,35 G-GU
BZ 108212	Cover-Starting Crank Hole	34 K-KU,35 Cab-CabPu
BZ 108213	Cover-Starting Crank Hole	34 LT-LL
BO 108226	Lamp-Tail & Stop-Complete	34 K-KU,35 Terr
BZ 108228	Reinforcement-Tail Lamp Support Bracket	34 LT-LL-K-KU,35 All
108229	Lamp-Tail & Stop (Use 96172)	
BO 108231	Bracket-Tail Lamp Support-LH-RHD	34 K,35 GU
BO 108232	Bracket-Tail Lamp Support-RH-LHD	34 K-KU,35 GU
BO 108245	Check Arm & Brkt Assy-Rr Compt Dr-LH	34-35 Co-Sed-Bro-UCo
A 108248	Fender Assy-Rear-RH-Pr	34 K-KU Co-Sed,K 2Cpe-UCo,35 Co-Cpe-Sed-UCo
A 108249	Fender Assy-Rear-LH-Pr	34 K-KU Co-Sed,K 2Cpe-UCo,35 Co-Cpe-Sed-UCo
A 108250	Fender Assy-Rear-RH-Pr	34 LT-LL exc 4Cpe-CvCpe
A 108251	Fender Assy-Rear-LH-Pr	34 LT-LL
C 108259	Fin Mldg & W/Strip Assy-Frt Dr Wdo-LH	34 LT-LL-K-KU Co
C 108260	Fin Mldg & W/Strip Assy-Door Window-RH	34 LT-LL-K 2Cpe-4Cpe,34 KU 4 Cpe
C 108262	Fin Mldg & W/Strip Assy-Frt Dr. Wdo-RH	34 LT-LL-K-KU Sed
C 108263	Fin Mldg & W/Strip Assy-Frt Dr Wdo-LH	34 LT-LL-K-KU Sed
C 108293	Trim Het & Brkt Assy-Frt Dr Lock Pillar-LH	34 K-KU-LT Sed,61-62-63 Sedan
BZ 108306	Bracket Assy-Frt Lic Plate-Velchrome.	34 LT-LL-K-KU,35 All
BO 108345	Wire Assy-Front Seat Adj Cent	34 Cpe-Sed,35 2Cpe-4Cpe
BO 108376	Handle Assy-Pull-to	34 All,35 Terr DeLuxe
108377	Handle Assy-PuH-to (Use 108376)	34-35 Hudson,62 thru 67
BO 108426	Spring-Locker Box Door Anti-Rattle	34 thru 36 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 108482	Fender Assy-Front RH-Lac or En	34 K
A 108483	Fender Assy-Front LH-Pr	34 K
A 108484	Fender Assy-Front RH-Pr	34 LT-LL-KU
A 108485	Fender Assy-Front LH-Pr	34 LT-LL-KU
BO 108486	Ornament-Radiator Grill-Upper	34 LT-LL
BO 108487	Ornament-Radiator Grill-Lower	34 LT-LL
BZ 108489	Plug-Dash Panel-H/Lamp Brkt Horn Wire Hole	34 LT-LL-K,35 Spec,38-39 RHD,1940 All,1948,1949
BO 108489	Plug-Dash Panel Tool Hole	1948
BO 108492	Ornament Assy-Radiator	34 LT-LL
108496	Use 108606	
BZ 108499	Bolt-Front Bumper Starting Crank Bracket	34 LT-LL-K-KU,35 All
BO 108500	Cam-Front Door Wing Operating-RH	34 thru 39 All
BO 108501	Cam-Front Door Wing Operating-LH	34 thru 39 All
BO 108502	W/Strip Former-Front Door Window-RH	35-36-37 All,82 thru 87,95,97
BO 108503	W/Strip Former-Front Door Window-LH	35-36-37 All,82 thru 87,95,97
BO 108508	Weatherstrip-Front Door Glass	34 All,35 thru 38 Hud,35 GU,62,72,82,95,97
BO 108510	Shim-Front Door Wing Pivot-Thin	34 All,35 thru 37 Hudson,62,72,81 thru 87, 1939 thru 1947 All,1948-1949-1950 CvBro
BO 108511	Shim-Front Door Wing Pivot-Thick	34 All,35 thru 37 Hud,62,72,81 thru 87,1939 thru 1947 All,1948-1949-1950 CvBro
BO 108515	Cushion-Front Door Wing	34 All,35-36 Hud,62,74 thru 77,82-83 Cv,92,93,95,97. 1940 thru 1942 All,51-171 CvBro,52,54,172,174
108520	Frame-Front Door Wing Glass-RH (Use 134224)	34 LT-LL-K-KU,35 DeLuxe,62 thru 67,72 thru 77, 82 thru 87,95,97
BO 108521	Frame-Front Door Wing Glass-LH	34 LT-LL-K-KU,35 DeLuxe,62 thru 67,72 thru 77, 82 thru 87,95,97
108522	Frame & Glass Assy-Front Door Wing-RH (Use 134224)	34 All,35 thru 37 Hudson,GU,62,72,82 thru 87,95,97
BO 108523	Frame & Glass Assy-Front Door Wing-LH	34 All,35 thru 37 Hudson,GU,62,72,82 thru 87,95,97
BO 108529	Collar-Front Seat Back Pivot	34 thru 36 Co,37 thru 1947 with Swivel or Bucket Seats
BO 108532	Wire Assy-Driver's Seat Adj Cont	34-35 Co-UCo-Panel-Sed DeL
BO 108545	Track Assy-Passenger Seat Outer	34 LT-K-KU Co,35 Hud Co,35 GU Co
BO 108547	Track Assy-Passenger Scat Inner-LHD	34 LT-K-KU Co,35 Bud Co,35 CU Co
108566	Use 109928	
108605	Use 108646	
BO 108606	Ornament Crest Assy-Radiator	34 K-KU,35 Comm
BO 108618	Remote Control Assy-Rear Door Lock-LH	34 thru 36 All
A 108625	Screen Assy-Radiator Grille-En	34 K-KU
BZ 108644	Screw-Side Wheel Carrier	34 LT-LL-K-KU,35 Hud
C 108646	Carrier Assy-Side Wheel-LH	34 LL,35 Cus 8 RHD
108648	Use 108646	
C 108650	Carrier-Complete Side Wheel-RH	34 K
BO 108667	Hinge Clamp-Inside Visor Header-RHD	34 Hud,34-K-KU,35 Co-Sed-2Cpe-4Cpe
BO 108670	Hinge Plate-Inside Visor Header-RHD	34 Hud,34 K-KU,34 Co-Sed-3Cpe-4Cpe
BZ 108688	Pad-Front Fender Lamp Bracket	34-35 All
BO 108696	Switch-Rear Compartment Light	34 All,35 Bro
BZ 108702	Welt-Frt Fdr to Rad Shell-RH-Pr or Lac	34-35 All
BZ 108703	Welt-Frt Fdr to Rad Shell-LH-Pr or Lac	34-35 All
108704	Shim-Cowl to Bonnet (Use 95916)	34 All
BO 108707	Wires & Sockets Assy-Instrument Lamp	34-35 All
BO 108709	Wire & Sockets Assy-Service Lamp	34 All,35 DeLuxe
BO 108725	Ash Receiver Assy-Garnish Mldg	34 LT Co-Sed,1948,1949,501 thru 504
108727	Headlamp Comp-LH (Use 111581)	
108728	Headlamp Comp-RH (Use 111582)	
108729	Headlamp Comp-LH (Use 111581)	
108732	Use 111070	
108733	Use 111071	
BO 108736	Ash Receiver Assy-Garnish Mldg	34 LL Sedan,35 HU-HHU Sedan,66,67
BO 108796	Support Assy-Front Door Track Reinf-RH	35 thru 38 Hud Exc 89,81-89-90-92-93-95 Cv,95,97,1940 CvCpe-CvSed,1941 CvSed
C 108803	Foot Rest Assy	34 LL Sedan,35 HU-HHU Sedan,65,67
C 108836	Bead Mldg-Front Door Trim Pan-RH	34 LT DeL Sed-Compt Sed
C 108837	Bead Mldg-Front Door Trim Pan-LH	34 LT DeL Sed-Compt Sed
108842	Use 111523	
BO 108846	Cradle & Glass-Frt Dr Wing-Complete-RH	34 LT-LL-K-KU
BO 108847	Cradle & Glass-Frt Dr Wing-Complete-LH	34 LT-LL-K-KU
BO 108896	Floor Mat-Rear Compartment	34-35 Coach
BO 108899	Plug-Seat Tray Hole	34-35 All,1941-1942 RHD,1948,1949,1950
A 108900	Instrument Panel Assy-Painted	34 LT-LL-K-KU
BO 108907	Screw-Front Door Wing Pivot	34 thru 38 Hud,GU,62,72,82,1940 thru 1950 CvBro
A 108922	Fender Assy-Rear-RH-Pr	34 4Cpe-CvCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 108925	Shell Assy-Radiator-Pr	34 LTS-K-KU-KS,35 Cab-CabPu-Panel
BO 108993	Dial Assy-Instrument Cluster-Miles	34 K-KU
108998	Dial-Inst Cluster-Miles (Use 108993)	34 K-KU
BO 109005	Bezel-Instrument Cluster	34 Hud-LT-LL,35 All
F 109011	Gauge Assy-Water Level	34 Hud-LT-LL-K-KU,35 All
BO 109012	Gauge Assy-Oil Level	34 Hudson
BO 109017	Glass-Instrument Cluster	34 LT-LL-K-KU,35 All
BO 109018	Gasket-Instrument Cluster	34 LT-LL-K-KU,35 All
A 109021	Screen Assy-Radiator Grill-EN	34 LT-LL-LTS
C 109048	Ring-Tire Cover-Pr	34 K-Comm
C 109050	Ring Assy-Tire Cover-Pr	34 K
C 109053	Ring-Tire Cover-Pr	34 KU
C 109054	Molding-Tire Cover Ring	34 LT-LL-KU
C 109056	Side Plate-Tire Cover Drum-RH-Pr	34 LT-KU
C 109057	Side Plate-Tire Cover Drum-LH-Pr	34 LT-KU
109066	Headlamp-Complete-RH(Use 109068)	34 LTS-K
109067	Headlamp-Complete-LH(Use 109069)	34 LTS-K
BO 109068	Headlamp-Complete-RH	34 LTS-KU
BO 109069	Headlamp-Complete-LH	34 LTS-KU
BO 109075	Lock Cylinder & Keys Assy-Door Handle	34 LT-LL,35 Hudson
BO 109077	Lock Cylinder & Keys Assy-Glove Box Door	34 LT-LL-K-KU,35 All
BO 109078	Lock Cylinder & Key Assy-Ignition & Spare Tire	34 LT-LL-K-KU,35 All
BO 109079	Key-Rear Compt & Glove Box Door	1934 thru 1950
109090	Use 116142	
109091	Bumper-Rear Door Check Strap (Use 107179)	34 thru 1940 All
BO 109126	Channel & Felt Assy-Frt Door Glass	34 LT-LL-K-KU exc Cpe
BO 109127	Channel & Felt Assy-Frt Door Glass	34 LT-LL-K-KU Cpe
BO 109142	Pad-Frt Door Glass Chan Guide-Outer	34 thru 36 exc Cv
BO 109143	Pad-Frt Door Glass Chan Guide-Inner	34 thru 36 exc Cv
BO 109144	Pad-Frt Window Glass Chan Guide-Inner-LH	34 LT-LL-K-KU,35 All
C 109211	Ring-Tire Cover-Pr	34 LT-LL-K-KU
BO 109218	Cover-Tire Cover Valve Hole-Side Mount	34-35 All
109219	Use 109218	
BO 109223	Bumper-Door Window Glass	1937,1940 thru 1947 All
BO 109245	Wing Brake Assy-Front Door Glass-RH	34 thru 39 All
BO 109246	Wing Brake Assy-Front Door Glass-LH	34 thru 39 All
BO 109260	Housing Assy-Headlamp	34 K-KU
F 109261	Headlamp Lens-RH	34 K-KU
F 109262	Headlamp Lens-LH	34 K-KU
BO 109263	Gasket-Headlamp Lens	34 K-KU
BO 109264	Reflector-Headlamp-Without Bulb	34 K-KU
BO 109265	Clip-Headlamp Reflector	34 Terr,35-38 exc 89-90-98
BO 109266	Spring-Headlamp Reflector Retaining	34 Terr,35-38 exc 89-90-98
BO 109267	Cable Assy-Headlamp-Without Bulb	34 K-KU,35 G-GU-GH
BO 109269	Plate-Headlamp Lens Ret Adjusting	34 K-KU
BO 109270	Screw-Headlamp Lens Retainer	34 K-KU
BO 109271	Spring-Headlamp Lens Retainer Screw	34-K-KU
BO 109272	Tapping Plate-Headlamp Lens Ret Screw	34 K-KU
BO 109274	Cable Assy-Headlamp	34 K-KU,35 G-GU-GH
BO 109275	Housing Assy-Headlamp	34 LT-LL
F 109276	Headlamp Lens-RH	34 LT-LL
F 109277	Headlamp Lens-LH	34 LT-LL
BO 109278	Gasket-Headlamp Lens	34 LT-LL
BO 109279	Screw-Headlamp Lens Retainer	34 LT-LL,35 All
BO 109281	Pivot-Spring-Headlamp Lens Retainer	34 LT-LL,35 All
BO 109282	Plate-H/Lamp-Lens Ret Adj	34 LT-LL,35 All
BO 109285	Spring-Headlamp Reflector	34 thru 37 All,80,81,82,88
C 109316	Rest Chan & Brace Assy-Dr Glass-RH	34 thru 36 CvCpe,37-38 CvCpe-CvBro Exc 71-81, 92-93-95 CvCpe-CvBro,1940 thru 1947 Cv
C 109317	Rest Chan & Brace Assy-Dr Glass-LH	34 thru 36 CvCpe,37-38 CvCpe-CvBro Exc 71-81, 92,93,95 CvCpe-CvBro,1940 thru 1947 Cv
BZ 109323	Lock Assy-Spare Tire-Less Cylinder	34 thru 39 All,11-14-21-24 Station
BO 109324	Lock-Spare Tire-Incl Cylinder	34-35 All
BO 109338	Regulator Assy-Windshield	34 LT-LTS-K-KU CvCpe
BO 109366	Channel Assy-Frt Door Glass W/S-RH	34 thru 37 exc Cv-61-70-71,38 Exc 81 and Cv,95 Bro-Sed-3Cpe-VicCpe,97 Sed
BO 109378	Arm & Spring Assy-W/Shield Cleaner	34 LT-LL-K-KU,35 All
BO 109381	Tubing-W/Shield Cleaner	34 LT-LL-K-KU,35 All
BO 109392	Glass & Frame-Wind Deflector-RH	1934 thru 1938 Hud-Terr-92-93-95 CvCpe-CvBro
BO 109393	Glass & Frame Assy-LH Wind Deflector	34 thru 38 All,92,93-95 Cv
BO 109424	Glass Run-Door Window RH-Center	34 thru 1940 CvCpe,37 thru 1947 CvBro
BO 109425	Glass Run-Door Window LH-Center	34 thru 1940 CvCpe,37 thru 1947 CvBro
BO 109426	Weatherstrip-Door Wing-RH	34 thru 1940 CvCpe,37 thru 1947 CvBro
BO 109427	Weatherstrip-Door Wing-LH	34 thru 1940 CvCpe,37 thru 1947 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 109428	Truck Assy-Door-RH	34 thru 39 CvCpe,37 thru 39 CvBro
BO 109429	Truck Assy-Door-LH	34 thru 39 CvCpe,37 thru 39 CvBro
BO 109430	Chain & Roller Assy-Door Wing Cradle	34 thru 39 CvCpe,37 thru 39 CvBro
BO 109431	Glass Stop-Door Window-Lower	34 thru 1940 CvCpe,37 thru 1947 CvBro
BO 109432	Front Fender Lamp Installation Kit	34 LT-LL-K-KU
BO 109434	Chan Assy-Door Wdo Glass Run-Frt-RH	34 thru 39 Cv
BO 109435	Chan Assy-Door Wdo Glass Run-Frt-LH	34 thru 39 Cv
BO 109446	Cradle & Channel Assy-Deflector-RH	34 thru 39 Cv
BO 109447	Cradle & Channel Assy-Deflector-LH	34 thru 39 Cv
109460	Use 111070	
109461	Use 111071	
BO 109462	Regulator Assy-Frt Door Wdo-RH	34 thru 1940 Cv
BO 109463	Regulator Assy-Frt Door Wdo-LH	34 thru 1940 Cv
BZ 109467	Retainer-Radiator Grill Screen	34 Hudson
109490	Use 112492	
C 109497	Front End Assy-RHD	34 LL Bro
BZ 109505	Cover-Valve Hole	34 2Cpe,35 Std-CvCpe
BO 109510	Hinge Assy-Door-RH	34 CvCpe
BO 109512	Door Hinge-Door Half-RH-Upper	34-35 CvCpe
BO 109513	Door Hinge-Door Half-LH-Upper	34-35 CvCpe
109515	Hinge Pin-Door-Upper (Use 118508)	34-35 CvCpe
BO 109527	Weatherstrip-Windshield	34 CvCpe
BO 109592	Clamp Assy-Top Hold-Down	34 CvCpe
BO 109594	Spring-Top Hold Down Clamp	34 thru 1940 CvCpe,37 thru 1947 CvBro
BO 109597	Rivet-Top Hold Down Clamp Handle	34 thru 1940 CvCpe,37 thru 1947 CvBro
BO 109643	Guide Assy-Frt Door Wdo Chan Roller	34 LTS-KS-Commercial
C 109644	Rear Channel-Front Door Window	34 LTS-KS Co-UCo-Cpe
109706	Reg Assy-Front Door Window-LH (Use 111665)	34 Cab-CabPu,KS Sed
109707	Use 111666	
109708	Use 111667	
A 109734	Splash Guard-Rear-En	34-35 CabPu
BO 109764	Door Hinge-Upper Body Half	34-35 Cab-CabPu
BO 109765	Door Hinge-Lower Body Half	34-35 Cab-CabPu
109766	Use 1-112592,1-111633,3-12111.3-71073,3-71451	
BO 109768	Door Assy-Locker Box	34 Sed DeL-UCo
BO 109800	Lens-Front Fender Lamp	34 LT-LL-K-KU,35 AH
BO 109801	Gasket-Front Fender Lamp Lens	34 thru 37 AH
BO 109804	Reflector & Stud Assy-Front Fender Lamp	34 thru 37 All
BO 109806	Spring-Front Fender Lamp Reflector	34 LT-LL •
BO 109807	Spring-Lamp Socket	34 thru 39 All,1942 thru 1949 All,502,504
BO 109811	Housing-Tail Lamp-RH	34 LT-LL
BO 109813	Lens-Tail Lamp-Red	34 LT-LL,35 Hud 8
BO 109814	Bezel-Tail Lamp Lens Retaining	34 LT-LL
BO 109815	Spring-Tail Lamp Lens Retaining	34 LT-LL
BO 109817	Wires & Terminal Assy-Tail Lamp	34 LT-LL
BO 109822	Housing-Tail Lamp-LH	34 LT-LL
BO 109823	Lens-Tail Lamp License	34 LT-LL
BO 109824	Gasket-Tail Lamp License Lens	34 LT-LL
C 109853	Trim Rail Assy-Rear Panel-Upper	34 LT-K-KU Co
C 109861	Finish Molding-Door Window-LH	35 Hudson CvCpe,36 CvCpe
BO 109873	Weatherstrip-Body Lock Pillar-LH	34 thru 37 Cv
109876	W/Strip-Folding Pillar (Use 99428)	34 thru 38 Cv-CvSed
BO 109877	Retainer-Folding PiHar W/Strip	34 thru 38 Cv
BO 109896	Weatherstrip-Top Front Header Rail	34 CvCpe
BO 109897	Weatherstrip-Top Front Header Rail	34 thru 1941 Cv
A 109904	Rear Fender Finish Plate Assy-LH	34 LT-LL-K-KU,35 AH
109906	Use 115653	
109908	Use 115653	
C 109928	Fender-F-RH-Well-With Lamp Hole-Pr	34 LT-LL-KU
BO 109949	W/Strip-Rear Compt Opening Reinf-Lower	34 LT-LL-K-KU,35 All
BO 109954	Brkt-Seat Cushion Frame Support-Upper	34-35 Sed DeL-UCo,KS Co,36 thru 1940 UCo-Panel, 1939-1940 Sed-2Sed-UCpe,40T 3Cpe,20UCo
BO 109959	Lamp-Tail & Stop-Comp With Lic Lens	34-35 Terr Comm
BO 109961	Wire Assy-Tail Lamp	34 K-KU
BO 109962	Mat & Pad Assy-Front Floor	34 LT-LL-K-KU
BO 109982	Door Hinge-Door Half Upper-RH	34 LT-K-KU 2Cpe-4Cpe,35 G-2Cpe-4Cpe
BO 109983	Door Hinge-Door Half Upper-LH	34 LT-K-KU 2Cpe-4Cpe,35 G 2Cpe-4Cpe
BO 109988	Tail Lamp Installation Kit-RH	34 K
BO 109990	Tail Lamp Installation Kit-RH	34 KU
BO 109991	Tail Lamp Installation Kit-LH	34 KU
BO 110098	Carpet Assy-Rear Floor	34 Std Sed,35 Hud Sed-GU Sed
110129	Inside Visor Assy (Use 110257)	34 LT-LL Co-Sed-Cpe,35 Terr Co-Cpe-Sed
C 110212	Trimboard Complete-RH Front Door	34 K-KU Sed
C 110233	Kick Pad Assy-LH Front Door	34 K-KU-LT Co-2Cpe,4Cpe,LL Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 110257	Inside Visor Assy	34 LT-Co-Sed-4Cpe,LL Bro-Sed
C 110266	Door Complete-LH-Front-Cloth-Lac	34 KU Sedan
C 110299	Rr T/B Assy-RF-Dr Fin Mldg-Cloth	34-35 All
C 110390	Trim Pan Assy-Upper-RH-Rear Quarter	34 2Cpe-4Cpe
C 110519	Arm Rest Assy-LH Rear Quarter	34 LT-K-KU Co
C 110526	Arm Rest Assy-RH Rear Quarter	34 Sedan
C 110658	Windlace Assy-Center Pillar	34 Sedan-Bro
C 111006	Outside Bar-Front Bumper	34 LL-LTS-LT
C 111008	Inside Bar-Front Bumper	34-35 All
BO 111009	Welt-Rear Fender	34-35 All
BO 111022	Stop-RH Front Door Wing Reg	34 thru 39 All
BO 111023	Upper Stop-LH Front Door Regulator	34 thru 39 All
111028	License Plate Frames Kit (Use 115526)	34 All Models
BO 111070	Regulator Assy-RF Door Wing	34 LT-LL, 34 LTS Cv, 35-36 exc Cv
BO 111071	Regulator Assy-LF Door Wing	34 LT-LL, 34 LTS Cv, 35-36 exc Cv
BO 111072	Regulator Assy-Front Door Window-RH	34 exc Sed, 35 exc Cv, 66, 67, 76, 77, 82 thru 85 Bro-Cpe, 87 Sed, 95 Bro-3Cpe-VicCpe, 97 Sed
BO 111073	Regulator Assy-Front Door Window-LH	34 Exc Sed, 35 exc Cv, 66, 67, 76, 77, 82 thru 85 Bro-Cpe, 87 Sed, 95 Bro-3Cpe-VicCpe, 97 Sed
BO 111074	Regulator Assy-Front Door Window-RH	34 Sedan, 35 G-HT Sedan, 62 thru 65 Sedan, 72 thru 75 Sed, 82 thru 85 Sed, 95 Sedan
BO 111075	Regulator Assy-Front Door Window-LH	34 Sedan, 35 G-HU Sedan, 62 thru 65 Sedan, 72 thru 75 Sedan, 82 thru 85 Sedan, 95 Sedan
BO 111172	Weather Seal-Front Door Window Glass	34 Co-LL Sed, 35 HHU-GU, 36-37 Bro-Cpe
BO 111173	Weather Seal-Front Door Window Glass	34 LT - Terr Sed, 35 HT-GH-G, 36-37 Sedan
BO 111174	Weather Seal-Rr Wdo Glass to Rest Chan	34 Co-Sed, 35 Cpe, 36-37 Sedan
BO 111175	Weather Seal-Qtr Wdo Glass to Rest Chan	34 Sed-KS Co-KU Co, 35 Cpe
BO 111208	Tail & Stop Lens-Plain	34 LT-LL, 35 Hud 8
BO 111249	Lens-Tail & Stop Lamp-Plain	34 K-KU, 35 Terr Spec
111260	Use 1-111270, 1-111262, 2-71463, 2-71465	
111261	Use 1-111271, 1-111263, 2-71465, 2-71463	
BO 111262	Fender Guard Clamp-RH-Front Bumper	34 LT-LL, 35 Hudson 8
BO 111263	Fender Guard Clamp-LH-Front Bumper	34 LT-LL, 35 Hudson 8
BO 111270	Fender Guard Assy-RH-Front Bumper	34 LT-LL, 35 Hudson
BO 111271	Fender Guard Assy-LH-Front Bumper	34 LT-LL, 35 Hudson
BO 111273	Fender Guard Assy-Rear Bumper-RH or LH	34 LT-LL, 35 Hudson
BO 111277	Glass Run & Clip Assy-Front Door Window Lock Side	34 LTS 2Cpe, KS Cpe
BO 111279	W/Strip-LH Frt Door Window Glass Hdr	34 LTS 2Cpe, K UCo, KS Co-Cpe
111329	Use 114715	
111330	Use 107850	
111348	Wire Assy-Choke Control (use 117393)	34 Terr KS-Comm
BO 111356	Knob Assy-Locker Box Door	34 LT-KS
C 111368	Door Assy-RH Front-Pr	34 Sed DeL-UCo, KS Co
111457	Use 115653	
BO 111468	Coil Spring-Door Lock	34 thru 36 All
BO 111523	Cigar Lighter Kit	34-35 AH
C 111525	Bumper Assy-Rear	34 Terr KS Cpe
BO 111580	H/Lamp Complete-RH With Bulb	34 LT-LL
BO 111581	H/Lamp Complete-LH-with Bulb	34 LT-LL
BO 111582	H/ Lamp Complete-RH-Without Bulb	34 LT-LL
111583	H/Lamp Complete-LH-Without Bulb (Use 111581)	34 LT-LL
BO 111584	Reflector Assy-Headlamp-2 Bulb Type	34 LT-LL
BO 111585	Reflector Assy-Headlamp-1 Bulb Type	34 LT-LL
BO 111586	Socket & Wire Assy-H/Lamp-2 Bulb	34 LT-LL
111587	Socket & Wire Assy-H/Lamp-L Bulb (Use 111586)	34 LT-LL
BO 111616	Tray & Coy Assy-Inst Pan Ash Receiver	34 LT-LL-K-KU
BO 111630	Felt Front Door Lock Striker	34 thru 36 All
111632	Ash Rec. Assy-Inst Pnl (Use 112592)	1934 Terr-Hudson
BO 111633	Adapter Pl-Inst Pan'Ash Rec	34 LT-LL-K-KU, 35 Terr Spec
111636	Use 1-111637, 1-111638, 2-71463, 2-71465	
BO 111637	Fender Grd Assy-Front or Rear Bumper	34 KS-Comm, 35 Terr
BO 111638	Fender Grd Clamp-Front or Rear Bumper	34 KS-Comm, 35 Terr
BO 111657	Lock Assy-Deck Lid	35 2Cpe
111661	Blades-W/Shield Cleaner-Service Pkg (Use 122528)	All Models
BO 111665	Regulator Assy-LH-Front Door Inside	34 KS Sed, K Cab-CabPu
BO 111666	Regulator Assy-RH-Front Door Window	34 LTS 2Cpe, KS Co-Cpe-Sed DeL-UCo
BO 111667	Regulator Assy-LH-Front Door Window	34 LTS 2Cpe, KS Co-Cpe-Sed DeL-UCo
111674	Heating Element-Cigar Lighter (Use 122924)	34 K-KU-LL-LT
BO 111696	Spring-Seat Track and Bonnet Lock	34 thru 1947 All
BO 111733	Retainer-Folding Top Pillar W/Strip-LH	34-35 CvCpe, 37-38 Cv
BO 111752	Cradle Complete-RH Front Door Wind	34 thru 37 exc Cv, 84-85-87-95-97 exc Cv
BO 111753	Cradle Complete-LH-Front Door	34 thru 37 exc Cv, 84-85-87-95-97 exc Cv
BO 111754	Wing Cradle Complete-Less Glass-RH	35 thru 37 All, 84, 85, 87, 95, 97 exc Cv
BO 111755	Wing Cradle Complete-Less Glass-LH	35 thru 37 All, 84, 85, 87, 95, 97 exc Cv

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 111763	Cradle Assy-Complete-RH-Door Wing	34-37-38-39 CvCpe,37 thru 39 CvBro
BO 111764	Cradle Assy-Complete-LH Door Wing	34-37-38-39 CvCpe,37 thru 39 CvBro
111765	Wire-Assy-Carb Choke (Use 121010)	34 Hud LTS
BO 111767	Lens-Tail & Stop Lamp	34 LTS
BO 111843	Bumper-Door Glass Channel	34-36 CvCpe
A 111871	Panel Assy-Bonnet Top-LH-Pr	34 K-KS,35 Terr Cv
A 111872	Panel Assy-Bonnet Top-RH-Pr	34 Hud,34 KU,35 Terr Cv
A 111873	Panel Assy-Bonnet Top-LH-Pr	34 Hud,34 KU,35 Terr Cv
BO 111884	Retaining Pin-Front Door Wing W/Strip	34 thru 1940 All,1941-1942 CvSed,1946-1947 CvBro
BO 111918	Bracket Assy-Foot Rest End-RH	34 Club Sedan,35 Bro-Sedan
111926	Use 114716	
*HS 111939	Wax-Body-8 ounce can	All
111942	Wire & Knob Assy-Carb Choke (Use 121010)	1934 KS
111943	Wire & Knob Assy-Carb Choke (Use 121010)	34 LTS
A 112001	Bonnet Complete-Prime	35 Hudson
A 112003	Bonnet Side Panel-LH-Pr	35 Hudson
A 112011	Radiator Shell Assy-Pr	35 All
BO 112012	Fastening Plate Assy-Qtr Wdo Frame	35 Sed,37 thru 1940 Bro-UCo
A 112030	Fender Assy-RH Rear-Pr	35 UCo-Panel
A 112031	Fender Assy-LH Rear-Pr	35 UCo-Panel
A 112033	Fender Assy-LH Rear-Pr	35 Terr
112047	Use 114786	
A 112054	Radiator Grille Assy-Velchrome	35 Terr
112058	Radiator GriHe Assy-Velchrome (Use 112565, 112726, 112715 & 112926)	35 Hudson 8
112076	Fender Assy-Rear-RH (Use 112030)	1935 Terr 4Cpe & Cony
A 112080	Fender Assy-RH Rear-Pr	35 GH-HT Co-Sed-2Cpe
A 112081	Fender Assy-RH Rear-Pr	35 GH-HT Co-Sed-2Cpe
112090	Fender Assy-RH Rear-Pr (Use 112080)	35 Hudson 8 Co-Sed-2Cpe-Bro
BO 112108	Hinge-RF Door-Upper Door Half	35 All exc Cv
BO 112109	Hinge-LF Door-Upper Door Half	35 All exc Cv
BO 112110	Hinge-RF Door-Upper Body Half	35 All exc Cv
BO 112115	Hinge-LF Door-Lower Door Half	35 All exc Cv
BO 112116	Hinge-RF Door-Lower Body Half	35 All exc Cv
BZ 112154	Bracket-RH H/Lamp to Fender Support	35 All
BZ 112155	Bracket-LH-H/Lamp to Fender Support	35 All
BZ 112156	Reinf Plate-RF Fender H/Lamp	35 All
BZ 112157	Reinf Plate-LF Fender H/Lamp	35 All
BO 112197	Tapping PI-Locker Box to Dash Brkt Bolt	35 thru 1941 All
A 112200	Fender Assy-RH Front-Pr	35 Terr
A 112204	Fender Assy-RH Front-Pr	35 Hudson
112214	Fender Assy-RH Front (Use 107220)	35 Hudson
112215	Fender Assy-LH-Front (Use 107221)	35 Hudson
A 112218	Fender Assy-RH Front-RHD-Pr	35 Terr
112219	Fender Assy-LH Front (Use 107081)	35 Terr
BZ 112275	Clip-Bonnet Side Panel Molding	35 All
BZ 112278	Molding-Bonnet Side Panel	35 Terr - Comm
BZ 112279	Molding-Bonnet Side Panel	35 Hudson
112294	Use 114514	
112295	Use 114514	
BZ 112350	Clip-Bonnet Hinge-Upper Rear	35 All
BZ 112351	Chp-Bonnet Hinge-Lower Rear	35 All
BZ 112363	Bracket-LH Tail Lamp Support	35 GH-HT-HTL
BO 112364	Bracket-RH Tail Lamp Support	35 GH-HT-HTL
BO 112365	Bracket-LH Tail Lamp Support-RHD	35 GH-HT-HTL
112366	Headlamp Complete-En (Use 115828)	35 Hud 6,Spec 8,61
BO 112378	Lens-Tail Lamp	35 Hudson
BO 112379	Tail & Stop Lamp Complete	35 Hudson
BO 112380	Tail & Stop Lamp Complete	35 Hudson
112381	Tail & Stop Lamp-on Trunk (Use 96172)	35 Terr
BO 112396	Cap-Steering Gear Jacket Tube Bracket	89,90,98
BZ 112400	Bracket Assy-Steering Gear Jacket Tube	35 Terr Spec-Comm
BO 112408	Hinge-RH Door-Upper Door Half	35 Cpe
BO 112409	Hinge-LH Door-Upper Door Half	35 Cpe
C 112415	Finish Molding Assy-LF Door Window	35 Terr Spec Co-Panel-UCo
C 112417	Finish Molding Assy-LF Door Window	35 Terr Spec Sed
C 112419	Finish Molding Assy-LF Door Window	35 Terr Spec Cpe
C 112426	Finish Molding Assy-Rear Door Window-LH	35 Hud Sed-Bro,GU Sedan
C 112427	Finish Molding Assy-Rear Door Window-RH	35 Hud Sed-Bro,GU Sedan
C 112428	Finish Molding Assy-RH Quarter Window	35 Hudson
C 112429	Finish Molding Assy-LH Quarter Window	35 Cpe
C 112430	Finish Molding Assy-RH Quarter Window	35 Sed
C 112431	Finish Molding Assy-LH Quarter Window	35 Sed
BO 112445	Lock Assy-Rear Compartment Door	35 Co-Sed-Bro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 112448	Glass Run-Quarter Window-Rear	35 Sed
BO 112450	Regulator Assy-Windshield	35 All exc Cv
BO 112451	Regulator Assy-Windshield	35 CvCpe
BZ 112455	Bracket-RH Headlamp	35 Hudson - Terr DeL
BZ 112456	Bracket-LH Headlamp	35 Hudson - Terr DeL
C 112457	Drain Trough Assy-RH Quarter Window	35-36 All
BO 112465	Hinge & Spring Assy-Locker Box Door	35 AH
BO 112467	Hinge Spring-RH-Locker Box Door (Pkg 5-10)	35 All
BO 112468	Hinge Spring-LH-Locker Box Door (Pkg 5-10)	35 All
BO 112469	Spacer-Locker Box Hinge	35 All
A 112473	Running Board AssyLH	35 GH-HT-HU-G-GU
A 112475	Panel-Running Board-LH	35 GH-HT-HU-G-GU
112476	Running Board Assy-RH (Use 112478)	35 HHU-HUL-HTL
112477	Running Board Assy-LH (Use 112479)	35 HHU-HUL-HTL
A 112478	Panel Assy-Running Board-RH	35 HHU-HUL-HTL
A 112479	Panel Assy-Running Board-LH	35 HHU-HUL-HTL
C 112492	Door Assy-RH	35 CvCpe
C 112493	Door Assy-LH	35 CvCpe
C 112494	Finish Molding-RH Radiator SheH	35 All
C 112495	Finish Molding-LH Radiator SheH	35 All
BO 112531	Mat & Pad Assy-Front Floor	35 Terr Spec Sed-Cpe-Comm
BO 112535	Mat & Pad Assy-Front Floor	35 Hudson - Terr DeL
BO 112543	Cover-Steering Gear Hole-Gray	35 All
BO 112544	Cover-Steering Gear Hole-Brown	35 All
BO 112560	Glass Channel-Rear Window-Safety Glass	35 Sed
BO 112561	Handle & Lock Complete-Rear Compt	35 Hudson - Terr DeL
BO 112562	Handle Assy-Rear Compt Door-Less Cyl	35 Hudson - Terr DeL
A 112565	GriHe Assy-Radiator-Velchrome	35 GH
C 112574	Finish Molding Assy-RR Door Window	35 Sed-Bro
BO 112592	Ash Receiver Assy-Instrument Panel	35 Terr Spec-Comm
BO 112597	Regulator Assy-Quarter Window-RH	36 thru 39 Bro-UCo,1940 UCo-2Sed
BO 112598	Regulator Assy-Quarter Window-LH	36 thru 39 Bro-UCo,1940 UCo-2Sed
C 112617	Outside Bar-Front Bumper	35 GH-HT-HTL
C 112621	Inside Bar-LH Rear Bumper	35 All exc Cpe
C 112625	Inside Bar-LH Rear Bumper	35 Cpe-CvCpe
C 112627	Outside Bar-Front Bumper	35 HU-HHU-HUL
C 112629	Outside Bar-Rear Bumper	35 HU-HHU-HUL
C 112633	Outside Bar-Front Bumper	35 Terr Comm
C 112635	Outside Bar-Rear Bumper	35 G-GU Co-Sed
BO 112650	Regulator Assy-RH Quarter Window	35 Co
BO 112651	Regulator Assy-LH Quarter Window	35 Co
BO 112659	Bumper-Top Front Header Rail	35 thru 1947 Cv
BO 112670	Handle Assy-Front Door Wing Regulator	35 GU
BO 112671	Handle Assy-Door & Quarter Window Reg	35 G-GU
BO 112672	Handle-Door Inside	35 G-GU
BO 112673	Handle Assy-Front Door Wing Regulator	35 GH-HT-HU,62
BO 112674	Handle Assy-Door & Quarter Window Reg	35 GH-HT-HU,62,63 Bro
BO 112675	Handle-Door Inside	35 GH-HT-HTL Co-Sed-Cpe-Cv
BO 112676	Handle Assy-Windshield Regulator	35 G-GU
BO 112677	Handle Assy-Windshield Regulator-	35 Hudson 8
112680	Use 1-112681 & 1-112682	
BO 112681	Adapter Plate-Inst Panel Ash Receiver	35 All
BO 112682	Tray & Cover Assy-Inst Panel Ash Receiver	35 Co
C 112685	Glass Run Assy-Front Door Window	35 GH-HT-HU-GU,36 Sed,72 thru 75 Sed,82 thru 85 Sed
C 112686	Glass Run-Front Door Window	95 Sedan
C 112687	Glass Run Assy-Rear Door Window	35 Sed-Bro,36 thru 1946 Sedan-CA
C 112689	Glass Run Assy-Door Window	35 Hud-GU Co,36-37-38 Bro exc 61-71-81, 76-77-87 Sed
C 112690	Glass Run-Front Door Window	95 Bro,97 Sed
112691	Glass Run Assy-Door Window (Use 112689)	35 Hud-GU Cpe,36-37-38 Cpe exc 61-71-81
112692	Glass Run-Front Door Window (Use 112690)	95 3Cpe-VicCpe
BO 112715	Ornament-Radiator Grill	35 GH
BO 112716	Ornament-Radiator Grill	35 G-GU-G Comm
BO 112717	Ornament-Radiator Grill	35 Hudson 8
BO 112724	Ornament -Crest-Radiator	35 Terr
BO 112725	Ornament-Crest-Radiator	35 Hudson
BZ 112726	Cover Assy-Starting Crank Hole	35 G-GU-GH
BZ 112727	Cover Assy-Starting Crank Hole	35 Hudson 8
112739	Use 114961	
112748	Use 114960	
112749	Use 114961	
112750	Use 114971	
BO 112752	Reg Assy-RH Front Door Window	35 thru 1941 with Sliding Windows

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 112753	Reg Assy-LH Front Door Window	35 thru 1941 with Sliding Windows
BO 112754	Cushion-Frt Dr Lk Pil Glass Run Chan Brkt	35 G,61
BO 112755	Glass Cushion-Frt Dr Lk Pil Chan-Short	35 thru 1941 with Sliding Windows
112760	Use 114971	
112762	Use 114968	
112763	Use 114969	
112765	Glass Run Assy-F Door Lock Pillar (Use 112685).	35 thru 1940 Cab-CabPu-Panel,35G-71-80-89-40T Sed,10T Sed,10-18 Cab-CabPu
C 112767	Glass Run Assy-Front Door Lock PiHar	35 G Co-Cpe,61-71-89 Bro-Cpe,35 thru 1940 UCo-UCpe 88-98-40T-48 Sed,10T Cpe-Sed,10 UCo-UCpe,18P
BO 112768	Glass Run Assy-Front Door Hinge Pillar	35 G Co-Sed-Comm,61-71-89 Bro-Sed,38-39-1940 UCo-Cab-CabPu-Panel,48 Sed,40T Sed-2Sed,10T Sed-2Sed,10 UCo-Cab-CabPu,18P
112769	Glass Run Assy-Front Door Hinge Pillar-(Use 112768)	
BZ 112774	Bracket Assy-Rear License Plate-En	35 G-61-71-80-89-40T Cpe,90-40-10 UCpe,10T Cpe 35 G-GH-HT,36 All,70-80-89 UCpe,89-10-18-20-28 Cab,1946-1947 Cab
BZ 112777	Bracket Assy-Rear License Plate-Chromium	35 With Trunk
112805	Use 114960 & 114972	
112807	Weatherseal-Door Glass to Rest Channel (Use 114992)	1935 Terr Spec Co-Cpe-Panel-UCo
112808	Strap Assy-Dr Wdo Reg & Pillar-RH (Use 112752)	35 Terr Co-Cpe-Panel
BO 112809	Strap Assy-Dr Wdo Reg & PiHar-LH	35 Terr Co-Cpe-Panel
112814	Use 112752	
112815	Use 112753	
112818	Channel Assy-RH-F Dr Glass (Use 114960 & 114976)	35 G Sed-Cab
BO 112850	Bumper-Front Door Upper	35-36 All
C 112851	Retainer-Dr Opening W/Strip-En-RH-Frt	35 GU-GH-HT-HU Sed,62-63-64-65 Sedan
C 112852	Retainer-Dr Opening W/Strip-En-LH-Frt	35 GU-GH-HT-HU Sed,62-63-64-65 Sedan
BO 112865	W/Strip-Front Door Wing Cradle-LH	35 thru 39 exc Cv
112879	Bolt-Radiator Grill Ornament (Use 133694)	35 All
112889	Use 1-112716, 5-133694	
112890	Use 1-112715, 5-133694	
112891	Use 1-112717, 5-133694	
BZ 112916	Name Plate-Radiator	35 Terr
BZ 112919	Name Plate-Radiator	35 thru 37 Hudson 6
BZ 112921	Name Plate-Radiator	35 thru 37 Hudson 8
BZ 112923	Ornament Assy-Radiator	35 Terr
BZ 112926	Ornament Assy-Radiator	35 GH
BZ 112927	Ornament Assy-Radiator-Exp	35 GH
112928	Ornament-Radiator (Use 115621-3-5)	35 Hudson 8
BO 112930	Cover-Instrument Panel Radio Opening	35 G-GU-GH-HT
BO 112935	Plate-Dash Hole Cover	35 thru 39 AH
BO 112987	Wires & Sockets Assy-Oil & Ampere Light	35 AH
BO 112990	Wire Assy-Carburetor Choke	35 G
112991	Use 114626	
112992	Use 114627	
112993	Use 114628	
112994	Use 114629	
112995	Use 114630	
BO 113532	W/Strip Assy-Frt Door Wdo Belt-Inner	35 G Sed
C 113657	Trim Panel-Front Door-LH-Complete	35 G Co-UCo
C 113658	Trimboard Complete-RH Front Door	35 G Sedan
C 113659	Trimboard Complete-LH-Front Door	35 G Sedan
C 113696	Trim Panel-Cowl Side-Black	35 Hudson Bro
C 113697	Trim Panel-Cowl Side-Black	35 Hudson Bro
C 113725	Headlining Assy	35 Sedan exc HHU-HUL
C 113726	Headlining Assy	35 Co,HHU-HUL Sed
BO 113794	Carpet Assy-Rear Floor	35 G Co
C 113883	Trim Panel-LH Door-Complete	35 G Cpe
BO 113930	Headlining Assy	35 Cpe
BZ 114033	Flexible Shaft Assy-Speedometer	36-37 AH
BO 114034	Core-Speedometer Flexible Shaft	36-37 All
C 114043	Frame Bar-Rear Bumper-RH	35 Coach-Sedan with Trunk
C 114044	Frame Bar-Rear Bumper-LH	35 Coach-Sedan with Trunk
BZ 114047	Bolt-Bumper Outer Bar End	35 Hud,36 AH
BZ 114048	Bolt-Bumper Outer Bar End	35 Terr
C 114077	Pillar Assy-Body Hinge-LH-Pr	35 DeLuxe Cpe
C 114079	Pillar Assy-Center-LH-Pr	35 DeLuxe Sed-Bro
114092	Handle-Door Inside (Use 112672)	61,62
114117	Use 114123	
C 114138	Door Assy-Front RH	35 Co-HHU-Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 114139	Door Assy-Front LH-Pr	35 Co-HHU Sed
C 114146	Door Assy-Front RH	35 G Cpe
C 114148	Door Assy-Front RH	35 Terr Sed-Cab-CabPu
C 114178	Riser Assy-Rear Splash Guard to Trunk Floor	35 Coach-Sedan
BO 114181	Grommet-Trunk Panel Bumper-RH	35 Coach-Sedan
BO 114182	Grommet-Trunk Panel Bumper-LH	35 Coach-Sedan
BO 114183	Hinge Assy-Trunk-Center	35 Coach-Sedan
114187	Use 114189 & 114191	
BO 114189	Lock-Trunk-LH-Lid Half	35 Coach-Sedan
BO 114191	Lock-Trunk-Body Half-LH	35 Coach-Sedan
BO 114193	Weatherseal-Trunk Lid	35 Coach-Sedan
BO 114197	Washer-Trunk Hinge Lock Bolt Fibre	35 Coach-Sedan
BZ 114207	Fender Guard Assy-Rear Bumper	35 GH-HT-HTL
C 114225	Spring-Rear Seat Back	35 Coach
BZ 114230	Bracket-Tail Lamp Support-RH	35 Coach-Sedan
BZ 114231	Bracket-Tail Lamp Support-LH	35 Coach-Sedan
BZ 114232	Bracket-Tail Lamp Support-RH	35 Coach-Sedan
BZ 114233	Bracket-Tail Lamp Support-LH	35 Coach-Sedan
114296	Fender Assy-Rear RH (Use 112030)	35 All With Trunk
A 114297	Fender Assy-Rear LH-Pr	35 AH With Trunk
BZ 114425	Pad-Tail & Stop Lamp Support-on Trunk	35 AH
BZ 114449	Clip-Running Board Finish Molding	35 Hud Sed-Bro,37 Hud
A 114469	Splash Guard Assy-Rear-Pr or En	35 Sedan-Bro With Trunk
114474	Mat & Pad Assy-Front Floor (Use 201134)	35 Hudson Bro
F 114476	Lens-Headlamp-For Hall Lamps	35 All,61
F 114477	Lens-Headlamp-For Corcoran Brown Lamps	35 All
114480	Mat & Pad Assy (Use 201134)	35 G Sed-Cpe
114484	Mat & Pad Assy-Front Floor (Use 201134)	35 G Co
HA 114539	Vanity Mirror	35 thru 1942 All
BO 114546	Check Arm-Trunk Lid	35 Coach-Sed-Bro
BO 114547	Lock Plate-Trunk Lid Check	35 All
C 114561	Tool Compartment Lid-Trunk Floor	35 Coach-Sedan-Bro
C 114566	Floor Board-Trunk-Rear	35 Coach-Sedan-Bro
114573	Fender-Rear-Pr (Use 107000)	35 GH-HT
BO 114581	Housing Assy-Headlamp-Pr	35 G-GU-GH-HT-HTL
BO 114583	Gasket-Headlamp Lens	35 G-GU-GH-HT-HTL
BO 114584	Screw-Headlamp Lens Locking	35 G-GU-GH-HT-HTL
BO 114588	Socket Sub Assembly-Headlamp	35 G-GU-GH-HT,34 K-KS-LTS
C 114599	Trimboard Assy-Trunk Floor-Rear Mount	35 Sedan
BO 114626	Molding-Roof	35 All
BO 114627	Molding-Roof	35 All
BO 114628	Molding-Roof	35 Hud exc HHU,G-GU Sed
C 114629	Molding-Roof	35 Coupe
BO 114630	Molding-Roof	35 HHU-HUL
C 114654	Retainer-Door Opening W/Strip-Rear-RH	35 thru 37 Sed exc HHU,89 Sed
C 114655	Retainer-Door Opening W/Strip-Rear-LH	35 thru 37 Sed exc HHU,89 Sed
BO 114660	Anti-Rattler-Door	35 thru 39 CvCpe,38-39CvBro
BO 114692	Reflector Assy-Headlamp	35 All,61
BO 114694	Reflector Assy-Headlamp	35 All
BZ 114716	Rubber Welt-Rear Fender Finish Plate	35 All
BO 114815	Gasket-Headlamp Lens	35 All,61
BO 114817	Socket & Wire Assy-Headlamp	35 4H,61
BO 114850	Track Assy-RH Front Door	35 All,36-37-38 exc 61-71-81,95 exc Cv,97
BO 114851	Track Assy-LH Front Door	35 All,36-37-38 exc 61-71-81,95 exc Cv,97
BO 114853	Spring-Front Door Track	35 All,36-37-38 exc 61-71-81,92 Cv,95,97,1940 All, 1941-1942 CvSed,1946-1947 CvBro
BO 114854	Buffer-Front Door Track Spring	35 All,36-37-38 exc 61-71-81,92 Cv,95,97,1940 All, 1941-1942 CvSed-1946-1947 CvBro
C 114864	Side Plate Assy-Tire Cover Drum-Pr	35 Hud GH-HT-HU 16 x 6.00-6.25 Tires
BO 114875	Clip-Door Lock Bolt Sprg Ret	34 thru 36 All
C 114881	Door Assy-L Front	35 G Co-UCo-Cab
C 114885	Door Assy-Front-RH	35 Panel
114958	Use 114960	
BO 114966	Channel-Frt Door Lock Pillar Glass Run-RH	1939 thru 1942 exc Station-Cv,1946-1947 exc CvBro
BO 114967	Channel-Frt Door Lock Pillar Glass Run-LH	1939 thru 1941 exc Station-Cv,1947 exc CvBro-Cab-CabPu
BO 114968	Glass Run & Channel. Assy-RH Hinge Pillar	35 thru 1941 With Sliding Windows
BO 114969	Glass Run & Channel Assy-LH Hinge Pillar	35 thru 1941 With Sliding Windows
114970	Glass Run-Lower-Lock PiHar (Use 114971)	35 thru 1941 With Sliding Windows
BO 114971	Glass Run-Lower-Hinge Pillar	35 thru 1941 With Sliding Windows
BO 114972	Rest Channel Assy-RH Door	35 G Co-Cpe-UCo
BO 114973	Rest Channel Assy-LH Door	35 G Co-Cpe-UCo
BO 114976	Rest Channel Assy-RH Door	35 G Sedan-Panel-CabPu

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 114977	Rest Channel Assy-LH Door	35 G Sedan-Panel-CabPu
BO 114992	Weatherseal-RH Rest Channel	35 G Co-Cpe-Comm
BO 114993	Weatherseal-LH Rest Channel	35 G Co-Cpe-Comm
114994	Weatherseal-RH Rest Channel (Use 144992)	1935 G Sed,1935 Panel-Cab
114999	Use 121010	
C 115271	Finish Panel-Rear Compt Side-LH	35 Sedan with Trunk
115433	Hasp. Lock & Key Assy (Use 114189)	35 All
BO 115434	Pin-Trunk Lock Hasp	35 AH
BO 115435	Dog-Trunk Lock	35 AH
BO 115436	Pin-Trunk Lock Dog	35 All
C 115491	Fin Mldg-Qtr Window-LH	35 Coach
C 115495	Fin Mldg & Qtr Window-LH	35 Coupe
C 115496	Fin Mldg Assy-Rear Window-RH	35 Coach-Sedan
BO 115516	Fin Mldg Assy-W/Shield-RH	35 CvCpe
BZ 115606	Clip-Tire Cover Side Plate	35 All
BO 115621	Ornament-Radiator Grille	35 Hudson
BO 115623	Ornament-Radiator Grille	35 Hudson
BO 115625	Cover Assy-Starting Crank Hole	35 Hudson
115649	Finish Plate-Rr Fender-LH-En (Use 115653)	35 All
115651	Finish Plate-Rr Fender-LH-Pr (Use 115653)	35 AH
A 115653	Finish Plate-L Rear Fender-Prime	35 All
115654	Welt-R Rr Fender Finish Plate Rubber (Use, 117474)	35 All
115655	Welt-L Rr Fender Finish Plate Rubber (Use 117475)	35 AH
BZ 115698	Support & Reinf Assy-Fender-RH	34 All
BZ 115699	Support & Reinf Assy-Fender-LH	34 AH
BO 115704	Weatherstrip Assy-Inner-Front Door Belt	35 G Coach-Cpe-UCo
115788	Clip-Front Floor Mat (Use 121040)	35 AH
BO 115828	Headlamp Complete-With Parking Bulb-En	35 G-GU-GH-HT-HTL
115830	Headlamp Comp-With Parking Bulb-Chrome (Use 112374)	35 AH
C 115849	Cover Assy-Kari Keen Trunk	34-35 Coach-Sedan
BO 115886	Screw-Headlamp Lens Pressure Lug Spring	35 All
C 116000	Front End & Side Panel Assy-LHD	36 All
116002	Use 116000	
116007	Use 116009	
C 116008	Panel Assy-Cowl Side-RH-Prime	36 All
C 116009	Panel Assy-Cowl Side-LH-Prime	36 All
C 116014	Riser Assy-Toe Board-RH	36 All
C 116015	Riser Assy-Toe Board-LH	36 All
C 116022	Panel-Dash	36 Hud-Terr
C 116031	Panel-Roof	61 thru 65 Bro-Sed-UCo
C 116033	Running Board Assy-RH	61,62
C 116035	Running Board Assy-RH	63,64,65
C 116036	Running Board Assy-LH	63,64,65
C 116037	Running Board Assy-RH	66,67
C 116038	Running Board Assy-LH	66,67
BO 116085	Striker-Rear Comp Door Lock	36-37-38 All,1939-1940 Cpe-Cv
BO 116090	Weatherstrip-Cowl Vent	36 thru 1947 All
C 116100	Panel-RH Quarter-Prime	36 Sedan
C 116101	Panel-LH Quarter-Prime	36 Sedan
116109	Panel-LH Frt Fdr Filler-(Use 118171)	36 Hudson
A 116110	Splash Guard Assy-Rear	36 All Side Mount,36 Bro-Sed Rear Mount
C 116133	Panel Assy-Underbody-Prime	61 thru 65 Sedan
BZ 116142	Stone Guard-Fender	36 thru 1942 exc 10 DeL
116150	Use 116459	
116151	Use 116459	
C 116153	Panel-Wheelhouse-LH	36 Bro-Sed-Station
BO 116193	Bracket-Hinge Pillar to Body Header-L	36 thru 39 Bro-UCo-Cab-CabPu-Panel,1940 thru 1942 UCo-2Sed,1946-1947 Bro
BZ 116213	Nut-Flange	36 thru 1946 All
116236	Use 116522	
116239	Use 116525	
116240	Use 116526	
BO 116253	Arm & Brkt Assy-Rr Compt Door Check	36 Bro-Sed-UCo
BO 116262	Hinge Assy-Rear Compt Door	36 thru 38 Bro-Sed-UCo
BO 116270	Weatherstrip-Rear Compt Door	36 Bro-Sed-UCo
BO 116271	Weatherstrip-Rear Compt Door Reinf	36 Bro-Sed-UCo
BO 116274	Clamp-Spare Tire-Prime-Rear Mount	36-37-38 All
116279	Bonnet-Complete (Use 116306 & 117076-7)	61,62
BZ 116290	Support-RF Fdr Stone Guard-Lower	36 All
BZ 116291	Support-LF Fdr Stone Guard-Lower	36 All
BZ 116297	Support-Rr Fdr Stone Guard-Lower-LH	36-37 All
C 116300	Robe Rail Assy	36 Hudson Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 116306	Hinge-Hood-Female	61,62
A 116307	Hinge-Hood-Female	36 Hudson
116308	Use 117076	
116309	Use 117077	
A 116313	Shield-Radiator Lower Tank	61,62,63,36 Cab-CabPu-UCo
116339	Use 116467	
A 116344	Grille Assy-Radiator-Velchrome	61,62
BO 116350	Brkt Assy-Steering Gear Jacket Tube	36 All
BO 16351	Cover Assyy-Cowl Ventilator	36 All
A 116412	Panel Assy-Inst-LHD-Birch Gray	36 Hudson
116438	Header Assy-RH Body-Pr (Use 119746)	61 thru 65 Sed
BO 116448	Weatherstrip-Windshield	38 Bro-Sed-3Cpe-4Cpe,61 Comm
BO 116449	Bolt-Hood Hinge Clamp	36 thru 38 All
BO 116452	Weatherstrip-Qr Window	36 thru 38 3Cpe-4Cpe,70-80 UCpe
BO 116454	Bracket-RH Front Hood Latch	61 Comm .64 ,65 ,66 .67
BO 116455	Bracket-LH Front Hood Latch	61 Comm ,64,65.66,67
BO 116456	Bracket-RH Rear Hood Latch	36 All
BO 116457	Bracket-LH Rear Hood Latch	36 All
C 116459	Door Assy-Rear Compt-Prime	36 Bro-Sed-UCo
116460	Panel Assy-Trunk Lid-Pr (Use 116459)	36 Bro-Sed-UCo
BO 116466	Door Assy-Locker Box-With Lock	36 Hudson exc Cv
BO 116467	Door Assy-Locker Box-Without Knob	36 Terr exc Cv
BO 116468	Spring-Locker Box Door Hinge-RH	36 All
BO 116469	Spring-Locker Box Door Hinge-LH	36 All
BO 116472	Bumper-Locker Box Door	36 All
BO 116473	Clip-Locker Box Door Fastening	36 All
BO 116493	Door-Locker Box-Complete with Knob	61 exc Cv
116494	Use 116496	
116495	Use 116497	
BZ 116496	Support Assy-RH Front Fender-Pr	36 All
BZ 116497	Support Assy-LH Front Fender-Pr	36 All
BZ 116498	Bracket-Head Lamp Fender Supp-RH	36 All
BZ 116499	Bracket-Head Lamp Fender Supp-LH	36 All
BZ 116502	Cover-Rad Grille Starting Crank Hole Cover	61,62
BZ 116504	Cover-Rad Grille Starting Crank Hole Cover	36 Hudson
BO 116509	Knob-Locker Box Door Lock	62 thru 67
BO 116510	Cyl & Key Assy-Locker Box Door Lock	62 thru 67
BO 116511	Knob Assy-Locker Box Door	61 UCo
C 116522	Mldg Assy-RH Run Bd-Pr-Color-En	61,62
C 116525	Mldg Assy-LH Run Bd-Pr-Color-En	63,64,65
C 116526	Mldg Assy-RH Run Bd-Pr-Color-En	66,67
BO 116528	Cover-Bonnet Rear Corner	36 Hudson
C 116614	Mldg Assy-Rr Door Wdo-RH	61-62 Sedan
BO 116620	Bracket-Rr Compt Door Hinge-RH	36 thru 38 Bro-Sedan,89 UCo
BO 116621	Bracket-Rr Compt Door Hinge-LH	36 thru 38 Bro-Sedan,89 UCo
BO 116628	Hinge Assy-Locker Box Door-RH	36 All
BO 116629	Hinge Assy-Locker Box Door-LH	36 All
BZ 116638	Bracket-Headlamp-RH	36 All
BZ 116639	Bracket-Headlamp-LH	36 All
116641	Use 119585	
116642	Use 119578	
116643	Use 119579	
116647	Use 119585	
116648	Use 119588	
116649	Use 119589	
116651	Use 119593	
116654	Use 119600	
116655	Use 119601	
116656	Use 119604	
116657	Use 119605	
BZ 116679	Ornament-Hood Side Panel-LH Upper	36 Hudson 8
C 116682	Molding-Hood Side Panel	36 Hudson
116684	Center Bar-Windshield Outside (Use 118948)	36 Bro-Sed-3Cpe-4Cpe
116686	Ornament-Cowl Vent Cover (Use 121266)	36 All
C 116697	Mldg-Hood Side Panel-Top & Bottom	61,62
BO 116698	Mldg-Hood Side Panel-Center	61,62
BO 116700	Bracket-Tail Lamp Support-RH-En	36 Bro-Sed-UCo-RHD-Less Trunk
BO 116701	Bracket-Tail Lamp Support-LH-En	36 Bro-Sed-UCo-LHD-Less Trunk
BO 116702	Bracket-Tail Lamp Support-RH-Chrome	36 Bro-Sed-UCo-RHD-Less Trunk
BO 116703	Bracket-Tail Lamp Support-LH-Chrome	36 Bro-Sed-UCo-LHD-Less Trunk
BO 116704	Bracket-Tail Lamp Support-RH-En	36 Bro-Sed-LHD-Less Trunk
BO 116706	Bracket-Tail Lamp Support-RH-Chrome	36 Bro-Sed-LHD-Less Trunk
BO 116707	Bracket-Tail Lamp Support-LH-Chrome	36 Bro-Sed-RHD-Less Trunk
BO 116708	Bracket-Tail Lamp Support-RH-En	36 Bro-Sed-UCo-RHD-With Trunk

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 116709	Bracket-Tail Lamp Support-LH-En	36 Gro-Sed-UCo-LHD-With Trunk
BO 116711	Bracket-Tail Lamp Support-LH-Chrome	36 Bro-Sed-LHD-With Trunk
116712	Bracket-Tail Lamp Support-RH-En (Use 116714)	36 Bro-Sed-UCo-LHD With Trunk
BO 116714	Bracket-Tail Lamp Support-RH-Chrome	36 Bro-Sed-LHD With Trunk
BO 116715	Bracket-Tail Lamp Support-LH-Chrome	36 Bro-Sed-RHD With Trunk
A 116716	Shell Assy-Radiator	61,62
A 116717	Shell Assy-Radiator	36 Hudson
C 116722	Roof Bow #2	36 Bro-Sedan,61 UCo-Cab-CabPu
C 116724	Roof Bow #3	61 thru 65 Sedan
C 116725	Roof Bow #4	36 Bro-Sedan,61 UCo
C 116727	Roof Bow #6	36 Bro-Sedan,61 UCo
BO 116779	Lock Assy-Rr Compt Door	36 thru 39 All,1940 Cpe-Cv
C 116788	Bar Assy-Front Bumper	61,62
116789	Bar Assy-F Bumper (Use 119237)	36 All
C 116790	Bar Assy-Bumper Frame-RH	36 All
C 116792	Bar Assy-Rear Bumper Frame-RH	36 Bro-Sed,61 UCo,36 Cpe-Cv Side Mount
C 116793	Bar Assy-Rear Bumper Frame-LH	36 Bro-Sed,61 UCo,36 Cpe-Cv Side Mount
BZ 116796	Bolt-Bumper Bar Center	36 thru 38 All,90,91,92,98
C 116802	Bar-Rear Bumper	63-64-65 3Cpe-4Cpe-CvCpe
BZ 116803	Bracket Assy-Front License Plate	61 thru 67
C 116807	Rod Assy-Radiator Stay	61,62
116809	Rod Assy-Radiator Stay (Use 120683)	63 thru 67
BO 116811	Latch Assy-Hood-LH	61,62
BO 116814	Bracket-Hood Latch Rod	36-37 All
BO 116815	Handle-Hood	36-37 All
BO 116817	Cigar Lighter Assy-LHD	65 Bro-Cpe-Sed,67 Sed
BO 116823	Ornament-Radiator	61,62
BO 116826	Ornament-Rad Top Panel-RH	63 thru 67
A 116844	Fdr Assy-RH Front-With Well	61,62
A 116852	Fdr Assy-RH Front-With Well	63 thru 67
BO 116865	Handle Assy-Door & Qr Wdo Regulator	63-64 Bro-Cpe-Sed,66 Sed
BO 116867	Handle-Door Inside	63-64 Bro-Cpe-Sed,66 Sed
BO 116869	Escutcheon-Inside Handle	36 Hud Sed-Bro-3Cpe-4Cpe
C 116886	Molding-Rad Grille Side-RH	61,62
C 116887	Molding-Rad Grille Side-LH	61,62
BO 116888	Molding-Rad Grille Center-Upper	61,62
BO 116889	Molding-Rad Grille Center-Lower	61,62
C 116890	Molding-Rad Shell Finish-RH	61,62
C 116891	Molding-Rad Shell Finish-LH	61,62
C 116892	Molding-Rad Shell Finish-RH	63 thru 67
C 116893	Molding-Rad Shell Finish-LH	63 thru 67
BO 116894	Bolt-Rad Shell Molding	36 All
BO 116895	Bolt-Rad Grille Side Molding	61,62
BZ 116896	Grommet-Rr Spl Guard Bumper	61 thru 67
BZ 116897	Grommet-Rr Spl Guard Bumper	61 thru 67
BZ 116898	Grommet-Frt Fdr Bumper	61 thru 67
BZ 116899	Grommet-Frt Fdr Bumper	61 thru 67
BO 116900	Ornament-Front Fender	64 thru 67
BO 116902	Ornament-Trunk-Comp Door-Finish Plate	36 thru 1941 All
BO 116910	Mounting-Radiator Ornament Crest	61,62
116911	Use 119177	
BO 116912	Mounting-Radiator Ornament Crest	63 thru 67
BO 116913	Ornament Crest & Mtg Assy-Radiator	61 thru 67
C 116915	Rest Channel-Qr Window	36-37-38-39 Hud-Terr Bro-UCo,1940 2Sed-UCo
C 116920	Glass Run-Qr Window	36 thru 1940 Bro-UCo
BO 116924	Brace-Door Track to Regulator	1941-1942 CvSed,1946-1947 CvBro
F 116927	Handle & Lock Cyl-Door Outside	61,62
F 116928	Handle-Door Outside-Less Cyl	61-62 Bro-Sed-Cpe-Cv
116929	Handle & Cyl Assy-Door Outside (Use 116927)	36 Hudson Bro-Sed-Cpe
116930	Handle Assy-Door Outside-Less Cyl (Use 116928)	36 Hudson Bro-Sed-Cpe
116931	Lock Cylinder-Blank (Use 206196)	36 Door & Cpe Deck Locks
BO 116935	Bracket-Tail Lamp Support-LH-En-LHD	36 3Cpe-4Cpe-CvCpe
116937	Bracket-Tail Lamp Support-LH-Chrome-LHD (Use 116935)	36 3Cpe-4Cpe-CvCpe
BO 116938	Bracket-Tail Lamp Support-RH-En-LHD	36 3Cpe-4Cpe-CvCpe
BO 116939	Bracket-Tail Lamp Support-LH-En-RHD	62-63-64-65 Cpe-Cv
BO 116942	Pad-Tail Lamp Support Bracket	61 thru 67
BO 116945	Handle Assy-Rr Compt Door-Less Cyl	61-62 Bro-Sed-UCo Without Trunk
BO 116946	Lock Cylinder-Blank	36 Rear Compt & Trunk Locks
116947	Handle & Cyl Assy-Deck Door (Use 116988)	61-62 4Cpe-CvCpe
BO 116948	Handle Assy-Deck Door-Less Cyl	61-62 4Cpe-CvCpe
BO 116950	Channel Assy-Qr Window Glass	36 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 116957	Glass Run-Qr Wdo-Front	36 Sedan
BZ 116959	Clip-Hood Side Panel Molding-Top & Bottom	61,62
BO 116960	Clip-Hood Side Panel Molding-Center	61,62
BO 116961	Mtg Cap-Radiator Ornament Crest	61,62
BO 116962	Mtg Cap-Radiator Ornament Crest	63 thru 67
116963	Use 119468	
116964	Use 119469	
116965	Weatherstrip-Door Opening (Use 2-119468)	66-67 Sedan
C 116966	Ret-Frt Door Opening W/Strip-Lower-RH	62 thru 67 Bro-Sed-3Cpe-4Cpe
BO 116976	Handle & Cyl-Rear Compt Door	36 Bro-Sedan
BO 116977	Handle-Rear Compt-Door-Less Cyl	36 Bro-Sedan
BO 116982	Track Assy-Pass Seat-Inner-LHD	62-63-64-65 Bro
BO 116985	Track Assy-Front Seat-LH-LHD	36 Sed-3Cpe-4Cpe-CvCpe
BO 116986	Track Assy-Front Seat-RH-RHD	36 Sed-3Cpe-4Cpe-CvCpe
BO 116988	Handle & Cyl Assy-Deck Door	36 Hud 4Cpe-CvCpe
BO 116989	Handle Assy-Deck Door-Less Cyl	36 Hud 4Cpe-CvCpe
BO 116996	Mirror Assy-Rear View	36 thru 1949 All exc Comm,500
BO 117016	Nut-Windshield Cleaner Operating	36 thru 1940 All
117024	Use 122528	
BO 117025	Nut-Windshield Cleaner Arm	36 thru 1940 All
BO 117032	Retainer Assy-W/S Motor Connecting Link	36 thru 1947 All
BO 117034	Felt Washer-W/S Cleaner Motor Link	36 thru 1946 All
117038	Mat & Pad Assy-Front Fllor-LHD (Use 201134)	35 With Dash Hand Brake
C 117070	Welt-Rear Fender	36 All
BZ 117072	Support-Tire Carrier	36 3Cpe-4Cpe-CvCpe
BZ 117073	Bracket-Spare Wheel Carrier Frame-En	36 3Cpe-4Cpe-CvCpe-Panel
A 117076	Top & Side Panel Comp-Hood-RH	61 Comm
A 117077	Top & Side Panel Comp-Hood-LH	61 Comm
C 117086	Trimboard Comp-R Rr Door	61 Sedan
BZ 117091	Plate-Radiator Grille Clamp	63 thru 67
A 117104	Fender Assy-RH Rear	36 4Cpe-CvCpe
BO 117138	Molding-Front End Panel Belt-RH	36 Hudson
BO 117139	Molding-Front End Panel Belt-LH	36 Hudson
C 117140	Molding-Front Door Outside Belt-RH	63-64-65-Bro-Cpe,66-67 Sedan
C 117141	Molding-Front Door Outside Belt-LH	63-64-65 Bro-Cpe,66-67 Sedan
C 117145	Molding-Quarter Panel Belt	36-37 Hud Sedan
C 117146	Molding-Quarter Panel Belt	36-37 Hud Bro
C 117147	Molding-Quarter Panel Belt	36 Hud 3Cpe-CvCpe,37 3Cpe-4Cpe
BO 117148	Bracket-Compartment Floor Board-Upper	36-37 Bro-Sed,37 Cpe-CvBro
117149	Use 117479	
BO 117194	Tail & Stop Lamp Complete	61-62 Bro-Sedan
BO 117195	Tail & Stop Lamp Complete	61-62 3Cpe-4Cpe-CvCpe
BO 117196	Tail & Stop Lamp Complete	61-62 Bro-Sed
BO 117197	Tail & Stop Lamp Complete	36 Hudson Bro-Sedan
BO 117198	Tail & Stop Lamp Complete	36 Hud 3Cpe-4Cpe-CvCpe
BO 117199	Tail & Stop Lamp Comp-Without License	36 Hudson Bro-Sedan
BZ 117202	Bolt-Radiator Ornament	61
BO 117204	Lens-Tail Lamp	61
BO 117205	Lens-Tail Lamp	36 Hudson
C 117222	Frame Assy-Front Seat Back-Passenger-RH	36 thru 1942 Bucket Seats
BO 117224	Support-Folding Seat Back-RH	36 thru 1942 Bucket Seats
BO 117228	Bracket-Seat Frame Support Lower-En	61 Bro-UCo-Panel
BO 117229	Link-Pass Seat Slide	62-63-64-65 Bro
BO 117233	Reinforcement-Headlining Cover	36 Bro-Sed-UCo
BO 117249	Washer-Inst Panel Radio Opening Cover	36-37 All,89,90,92,98,1941 All
BO 117255	Cover-Inst Panel Radio Opening	61,62,63;45-65 CvCpe
BO 117256	Cover-Inst Panel Radio Opening	36 Hudson exc Cv
BZ 117289	Bolt-Bumper Bar-Long	36 thru 1947 All
C 117291	Headlining Assy	36 Bro
C 117292	Headlining Assy	61-62-63 Sedan
C 117293	Headlining Assy	66-67 Sedan
BO 117315	Wire & Socket Assy-Inst Lamp-Less Bulb	36 All
BO 117316	Bracket-Inst Panel Service Lamp	36 thru 1939 All,1940 Cv
117318	Wire & Socket Assy-Inst Pnl Service Lamp (Use 160472)	36 thru 38
BO 117320	Wire & Socket Assy-Dimmer Ind Light-Less Bulb	36 Hudson
BO 117321	Carrier Assy-Spare Wheel	36 3Cpe-4Cpe-CvCpe
BZ 117335	Cage Assy-Spare Wheel Carrier Lock	36 3Cpe-4Cpe-CvCpe
BO 117359	Bolt-Body Hold Down	36 thru 1946 All
BO 117365	Hinge Plate-Inside Visor Header	62 thru 67,82 thru 87,88 Sed
BO 117366	Clamp-Inside Visor Support Rod	62 thru 67,82 thru 87,88 Sod
BO 117369	Visor Assy-Inside	61 Bro-Sed-Cpe
BO 117377	Shim-Windshield Center Bar	36 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 117386	Weatherstrip-Frt Door Window Belt	62 thru 65 Sed,72 thru 75 Sed,82 thru 85 Sed,95 Sedan
BO 117387	Weatherstrip -Frt Door Window Belt	62 thru 65,72 thru 75,84-85 Bro-Cpe-CvBro-CvCpe,66-67-76-77-87 Sed,82-83-95 Bro-3Cpe-VicCpe,89-90-93 CvBro-Cpe
BO 117388	Shim-Hood To Cowl	36-37 All
BO 117389	Shim-Hood to Radiator	36 All
BO 117392	Wire Assy-Carburetor Choke-RHD	61
BO 117393	Wire Assy-Carburetor Choke-LHD	61
BO 117395	Wire Assy-Clutch Vacuum Control-LHD	36 All
BO 117398	Spring-Headlamp Reflector Retaining	36 All
BO 117401	Spring-Door Inside Handle Anti Lock	36 All
BO 117404	Glass-Instrument Cluster	36 All
BO 117407	Gasket-Instrument Cluster Glass	36 All
F 117414	Gauge Assy-Water Temperature	62 thru 67
F 117415	Gauge Assy-Gasoline	36 All
BO 117422	Case Assy-Instrument Cluster	62-67
BO 117426	Bracket-Front Hood Latch-RH	61,62,63
BO 117427	Bracket-Front Hood Latch-LH	61,62,63
BO 117430	Weatherstrip-Front Door Bottom	36 exc 61-2-3-4-5 Sed
BO 117431	Weatherstrip-Front Door Bottom	61 thru 65 Sed,61 Cab-CabPu-Panel
117436	Mat & Pad Assy-Frt Floor (Use 201134)	61 LHD With Floor Type Hand Brake
BO 117437	Retainer Assy-Body Hold Down Bolt Nut	36 thru 1946 All
BZ 117474	Welt-Rr Fender Fin Plate-RH	36 All
BZ 117475	Welt-Rr Fender Fin Plate-LH	36 All
BO 117477	Bracket-Rear View Mirror	36 thru 39 All,1940-1941 Cv,1946-1947 CvBro
BO 117479	Bracket-Rr Compt Floor. Board Riser Lower	36 thru 38 Bro-Sed,37-38 Cpe-CvBro,80-89 UCo-Rear Mount, 92-93-95 VicCpe,1939-1940 CvCpe
117488	Lamp Assy-Front Fender (Use 108076)	36 All
BO 117491	W/Strip-Door Wdo Belt-Inner	61-71 Bro-3Cpe-4Cpe,36 thru 1940 UCo-UCpe,71B,73B,88 Sed,89 Bro-Sed-Cpe,40T VicCpe-3Cpe,2Sed
BO 117493	W/Strip-Quarter Wdo Belt-Inner	36 thru 39 Bro-UCo,1940 UCo-2Sed
BO 117494	W/Strip-Rr Door Wdo Belt-Inner	36 thru 1940 Sedan
BO 117495	Tubing-W/Shield Cleaner-With Std Pump	36 thru 1947 All
BO 117498	Handle & Cyl Assy-Trunk Lid	36 Hud Bro-Sedan
BO 117499	Handle Assy- Trunk Lid-Less Cyl	36 Hud Bro-Sedan
BO 117500	Hinge-Front Door Upper-Door Half-RH	36 Bro-Sed-Comm
BO 117501	Hinge-Front Door Upper-Door-LH	36 Bro-Sed-Comm
BO 117502	Hinge-Front Door Upper-Body Half-RH	36 Bro-Sed-Comm
BO 117503	Hinge-Front Door Upper-Body Half-LH	36 Bro-Sed-Comm
BO 117506	Hinge-Front Door Lower-Door Half-RH	36 Bro-Sed-Comm
BO 117507	Hinge-Front Door Lower-Door Half-LH	36 Bro-Sed-Comm
BO 117508	Hinge-Front Door Lower-Body Half-RH	36 Bro-Sed-Comm
BO 117509	Hinge-Front Door Lower-Body Half-LH	36 Bro-Sed-Comm
BO 117515	Hinge-Rear Door Upper-Body Half-LH	36-37 Sedan
BO 117518	Hinge-Rear Door Lower-Door Half-RH-LH	36-37 Sedan
BO 117520	Hinge-Rear Door Lower-Body Half-RH-LH	36-37 Sedan
BO 117524	Pin-Door Hinge Upper	36 All,37 thru 1940 Sedan
BO 117525	Pin-Door Hinge Lower	36 All,37 thru 1940 Sedan
C 117571	WLace Assy-Frt Lock Pillar & Hdr-LH	36 Bro
C 117572	W/Lace Assy-Rr Hinge Pillar-RH	36 Bro
C 117573	W/Lace Assy-Rr Hinge Pillar-LH	36 Bro
C 117574	W/Lace Assy-Frt Lock Pillar & Hdr-RH	61 thru 65 Sedan
C 117575	W/Lace Assy-Frt Lock Pillar & Hdr-LH	61 thru 65 Sedan
C 117576	W/Lace Assy-Rr Hinge Pillar-RH	36 Sedan
C 117577	W/Lace Assy-Rr Hinge Pillar-LH	36 Sedan
C 117578	W/Lace Assy-Frt Lock Pillar & Hdr-RH	66-67 Sedan
C 117579	W/Lace Assy-Frt Lock Pillar & Hdr-LH	66-67 Sedan
BZ 117603	Spacer-Frt Fdr Dust Shield to Brace	36 All
BZ 117604	Brace-Fr Fdr Dust Shield-RH	36 All
BZ 117605	Brace-Fr Fdr Dust Shield-Lh	36 All
BZ 117607	Tie Rod-Frt Fdr Hd Lamp Support Bracket	36 All
C 117665	Panel Assy-L Frt Door Trim	62 Bro
C 117667	Trim Board Comp-Frt Door-LH	62 Sedan
C 117668	Trim Board Comp-Rear Door-RH	62 Sedan
C 117670	Trim Panel Assy-Frt Door-RH	63-64 Bro,66 Sedan
C 117671	Trim Panel Assy-Frt Door-LH	63-64 Bro,66 Sedan
C 117672	Trim Board Comp-Frt Door-RH	63-64-65 Sedan
C 117673	Trim Board Assy-Frt Door-LH	63-64-65 Sedan
C 117674	Trim Board Comp-Rear Door-RH	63-64-65 Sedan
C 117675	Trim Board Comp-Rear Door-LH	63-64-65 Sedan
C 117678	Trimboard Comp-Rear Door-RH	65-67 Sedan
C 117683	Trimstick & Trm Assy-Body Lock Pillar-LH	36 Bro-Sed
C 117684	Trimboard Assy-Center Pillar-RH	36 Hudson Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 117685	Trimboard Assy-Center Pillar-LH	36 Hudson Sedan
C 117686	Trimboard & Trim Assy-Rr Hinge Pillar & Lower Qtr-RH	36 Sedan
C 117687	Trimboard & Trim Assy-Rr Hinge Pillar & Lower Qtr-LH	36 Sedan
C 117688	Trimboard & Trim Assy-Upper Qr-RH	61 Sedan
C 117692	Trimboard & Trim Assy-Rr Hinge Pillar & Lower Qr-RH	36 Bro
C 117693	Trimboard & Trim Assy-Rr Hinge Pillar & Lower Qr-LH	36 Bro
C 117694	Trimboard & Trim Assy-Upper Qr-RH	61 Bro
C 117695	Trimboard & Trim Assy-Upper Qr-LH	61 Bro
C 117699	Trimboard & Trim Assy-Rr Wdo Center	36 Bro-Sedan
C 117700	Trimboard & Trim Assy-Rr Back Shelf	36 Bro-Sedan
BO 117702	Headlamp Comp-With Packing Bulb-En	36 All
BO 117704	Headlamp Complete-With Parking Bulb-Pr	36 All
F 117706	Lens-Headlamp	61,62
BZ 117710	Brace-Dust Shield to Dash Brace Ext-RH	61,62
BZ 117711	Brace-Dust Shield to Dash Brace Ext-LH	61,62
BZ 117713	Brace-Dust Shield to Dash Brace Ext-LH	36 Hudson
BZ 117753	Supp-Front Fender Well-LH-RHD	36 Hudson
BZ 117758	Guard Asst-Bumper Fender	61,62
BZ 117759	Guard Assy-Bumper Fender	36 Hudson
BO 117793	Escutcheon-Qr Regulator Handle	36 Sedan
C 117851	Cushion Complete-Front Seat-Cloth	36 Terr Sed
C 117852	Cushion Complete-Front Seat-Cloth	63-64-66 Sed
C 117854	Trim Assy-Frt Seat Cushion	62 Sedan
C 117857	Back Complete-Rear Seat-Cloth	36 Terr Sedan
C 117859	Trim Assy-Rr seat Back	36 Terr Bro-Sed-UCo
C 117861	Cushion Complete-Rear Seat-Cloth	36 Terr Bro-Sed-UCo
C 117862	Cushion Complete-Rear Seat-Cloth	63-64 Bro-Sed,66 Sed
C 117863	Cushion Complete-Rear Seat-Cloth	67 Sed,65 Bro-Sed
C 117864	Trim Assy-Rear Seat Cushion	36 Terr Bro-Sed-UCo
C 117870	Trim Assy-Frt Seat Back Panel	61-62 Sedan
C 117879	Trimboard Assy-Frt Door Wdo Mldg-Rr-LH	36 thru 39 Bro,66-67-76-77-87-97 Sed,61-70-80-89 UCo,10T,10P,10 UCo,18
C 117883	Trimboard Assy-F Door Window-Mldg-Frt-LH	61 thru 65 Sedan
C 117886	Trimboard Assy-F Door Wdo Mldg-Rr-RH	36 thru 39 Sed exc 66-67-76-77-87-97,10 Sed
C 117887	Trimboard Assy-F Door Wdo Mldg-Rr-LH	36 thru 39 Sed exc 66-67-76-77-87-97,10 Sed
C 117890	Trimboard Assy-F Door Wdo Mldg-Frt-RH	36 3Cpe-4Cpe
C 117894	Trimboard Assy-F Door Wdo Mldg-Rear-RH	36 thru 39 3Cpe-4Cpe,89 UCpe
C 117895	Trimboard Assy-F Door Wdo Mldg-Rear-LH	36 thru 39 3Cpe-4Cpe,89 UCpe
C 117898	Trimboard Assy-Rear Door Wdo Mldg-Frt-RH	36 thru 39 Sedan,10-18 Sed
C 117899	Trimboard Assy-Rear Door Wdo Mldg-Frt-LH	36 thru 39 Sedan,10-18 Sed
C 117902	Trimboard Assy-Rear Door-Wdo-Mldg-Rear-RH	36 thru 39 Sedan,10-18 Sed
BO 117936	Housing Assy-Head Lamp-Black En	36 All
BO 117937	Housing Assy-Head Lamp-Pr	36 All
BO 117938	Reflector Assy-Head Lamp-With Parking Bulb	36 All
BO 117940	Socket & Wires Assy-Headlamp-With Parking Bulb	36 All
BO 117941	Socket & Wires Assy-Headlamp-Without Parking Bulb	36 All
BO 117942	Use 119189	
BO 117943	Screw-Headlamp Lens Locking	36-37 All
BO 117999	Lens-Front Fender Lamp	36 All
C 118041	Back Comp-Frt Seat-Passengers-Cloth-LHD	62 Bro
C 118045	Back Comp-Frt Seat-Passengers-Cloth-LHD	36 Hudson Bro
C 118067	Trim Assy-Fr-Seat Cushion-LH-Cloth	36 Terr Bro-UCo
BO 118072	Lamp Comp-Tail & Stop-Without License	36 Terr 3 Cpe-4Cpe-CvCpe
BO 118073	Lamp Comp-Tail & Stop-Without License	36 Hud 3 Cpe-4Cpe-CvCpe
BO 118116	Welt-F Fdr to Rad Shell (Use 118117)	36 All
BZ 118117	Welt-Frt Fdr to Rad Shell-LH	36 All
BO 118141	Tail & Stop Lamp Complete-With License	36 UCo
BO 118143	Tail & Stop Lamp Complete (Use 117196)	36 UCo
BO 118147	Lock Cylinder-Blank-Spare Tire	36 thru 38 All,91 thru 97,90-98 CabPu, 90 Sta, 11-14-21-24 Station
BO 118149	Lock Cylinder & Keys Assy-Spare Tire	36 thru 38 All,91 thru 97,90-98 CabPu, 90 Sta, 11-14-21-24 Station
BZ 118150	Lock Cylinder & Keys Assy-Spare Tire	36 thru 38 All,91 thru 97,90-98 CabPu,90 Sta,11-14-21-24 Station
BO 118157	Door Assy-Locker Box	36 CvCpe-Comm
A 118171	Panel Assy-RH-Front Fender Filler	36 Hudson
BO 118173	Handle, Lock Cyl & Keys Assy-Frt Door (Use 206197)	36 All
BO 118174	Handle, Lock Cyl & Keys Assy-Rear Comp	36 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
118176	Use 206197	
BO 118224	Gasket-Windshield Cleaner Operating Control	36 thru 1940 All
C 118228	Side Plate Assy-Tire Cover Drum-Lac	36 All
BZ 118230	Clip Tire Cover Drum Side Plate	36 All
C 118238	Ring Assy-Tire Cover-Pr	63
C 118296	Reinforcement-Run Bd Molding	61,62,63,64,65
BO 118312	Cup Washer-Ornament	36 All,1939 thru 1941 Panel
C 118400	Cushion Comp-Frt Seat	61-62 3Cpe-4Cpe
C 118401	Cushion Comp-Frt Seat	63-64 3Cpe-4Cpe
C 118402	Cushion Comp-Frt Seat	65 3Cpe-4Cpe
C 118408	Back Comp-Rumble Seat	36 4Cpe-CvCpe
C 118410	Cushion Comp-Rumble Seat	36 4Cpe-CvCpe
BO 118412	Reinforcement-Headlining Cover	37 3Cpe-4Cpe
BO 118467	Crest-Radiator Ornament	36 Terr-Switzerland & Norway
BO 118498	Visor Assy-Inside	61 Bro-Sed-3Cpe-4Cpe
BO 118504	Hinge-Door Upper-Door Half-RH	36 CvCpe
BO 118505	Hinge-Door Upper-Door Half-LH	36 CvCpe
BO 118507	Hinge-Door Upper-Body Half-LH	36 CvCpe
BO 118508	Pin-Upper Hinge	36 CvCpe
BO 118516	Clamp Assy-Top Hold Down	36 thru 1947 Cv
118517	Handle-Top Hold Down Clamp (Use 118516)	36 thru 1947 Cv
C 118531	Panel & Framing Comp-Cab Back	61 Cab-CabPu
118616	Strap-Rr Door Check (Use 94915)	36 thru 1940 Sedan
BO 118636	Bumper-Locker Box Door	36 All
C 118644	Trim Panel-Front Seat Back	66 Sedan
C 118665	Channel & Brace Assy-LH Frt Door Wdo Glass	61 CvCpe-71-81-90 CvCpe-CvBro
BO 118666	W/Strip-Frt Door Wdo Glass to Rest Channel	61 CvCpe,71 CvCpe-CvBro
BO 118677	Ring-Headlamp Lens Retaining	36 All
BO 118678	Rivet-Headlamp Lens Retaining Ring	36 All
*HS 118680	Polish & Cleaner-Oil Base-Pint	All
*HS 118681	Polish & Cleaner-Oil Base-Gallon	All
*HS 118682	Cleaner & Wax-Combination-Pint	All
*HS 118683	Cleaner & Wax-Combination-Gallon	All
*HS 118684	Pre Wax Cleaner-Pint	All
*HS 118685	Pre Wax Cleaner-Gallon	All
BO 118698	Door Assy With Lock-Locker Box	62 exc Cv
BO 118699	Ornament-Rr Compt Door-Kit	36 Hudson
118705	Fender Lamp-Service Kit (Use 108076)	36 All
BO 118706	Tail Lamp Kit-Chrome Bracket-LHD	61 Bro-Sed
BO 118710	Tail Lamp Kit-Chrome Bracket-LIID	61 Coupe
BO 118712	Tail Lamp Kit-Black Bracket-LHD	61 Coupe
118732	Service Light Complete (Use 161378)	61
C 118749	Seat Complete-Drivers-Leather-LHD	36 Bro
C 118750	Seat Complete-Drivers	36 Bro
C 118751	Seat Complete-Passenger-Leather-LHD	36 Bro
C 118752	Seat Complete-Passenger-Leather-RHO	36 Bro
C 118759	Back Complete-Front Pass Seat-Leather	36 All
C 118760	Back Complete-Front Pass Seat-Leather	36 All
BO 118794	Weatherstrip-RF Door Wdo Belt-Outer Rear	36-37 Cv
BO 118796	Weatherstrip-Fr Door Wdo Belt-Outer Front	36-37 Cv
118797	Use 117387	
C 118836	Retainer Assy-Body Header Trim-RH	36-37 Cab-CabPu-Panel-Station,70 UCpe
BO 118841	Weather Seal-Rear Window	36-37 Cab-CabPu
BO 118848	Bracket-Top Hold Down Clamp	36 thru 1947 Cv
A 118858	Fender Assy-RH Rear	36 CabPu
A 118859	Fender Assy-LH Rear	36 CabPu
C 118865	Trimboard & Trim Assy-W/Shield Header	36 All
C 118899	Back Complete-Frt Seat-Drivers-Lea-LIID	36 Panel
C 118900	Back Complete-Frt Seat-Drivers-Lea-RED	36 Panel
C 118901	Cushion Complete-Frt Seat-Drivers-Lea-LHD	36 Panel
C 118902	Cushion Complete-Frt Seat-Drivers-Lea-RHD	36 Panel
C 118913	Back Complete-Frt Seat-Passenger-Lea-LHD	36 Panel
C 118914	Back Complete-Frt Seat-Passenger-Lea-RHD	36 Panel
C 118916	Cushion Complete-Frt Seat Passenger-Lea-RHD	36 Panel
C 118917	Cushion Complete-Frt Seat	36 Cab-CabPu
118934	Use 118935	
C 118935	Tacking Strip Assy-Rear Panel Belt	36 CvCpe
BO 118941	Sealer-W/Shield-6 oz Tube	36 All
BO 118948	Center Bar-Windshield Outside	36 Bro-Sed-3Cpe-4Cpe
118950	Door Assy-Rear Compartment (Use 116459)	36 Hudson Bro-Sed
118953	Use 116459	
118958	Trimboard Complete-Front Door-RH	61 CvCpe
C 118959	Trimboard Complete-Front Door-LH	61 CvCpe
C 118982	Trimboard Complete-Front Door-RH	62 CvCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 118983	Trimboard Complete-Front Door-LH	62 CvCpe
C 118984	Trimboard Complete-Front Door-RH	63-64-65 CvCpe
C 118985	Trimboard Complete-Front Door-LH	63-64-65 CvCpe
C 118986	Kick Pad Assy-Front Door-RH	62 thru 65 CvCpe
C 118987	Kick Pad Assy-Front Door-LH	62 thru 65 CvCpe
BO 119021	Clip-Body Bolt & Run Bd Mldg (10-25)	36 Hud,37 All
C 119035	Back Complete-Frt Pass Seat-LHD	62 Bro
C 119036	Back Complete-Frt Pass Seat-RHD	62 Bro
C 119037	Back Complete-Frt Pass Seat-LHD	36 Hudson Bro
C 119038	Back Complete-Frt Pass Seat-RHD	36 Hudson Bro
C 119039	Back Complete-Frt Pass Seat-Leather-LHD	36 Hud,62 Bro
C 119040	Back Complete-Frt Pass Seat-Leather-RHD	36 Hud,62 Bro
BO 119044	Hinge-Door-Lower Door Half- RH	36 CvCpe
BO 119045	Hinge-Door-Lower Door Half-LH	36 CvCpe
BO 119046	Hinge-Door-Lower Body Half	36 CvCpe
C 119056	Trimstick & Trim Assy-F Lock Pillar-RH	36 CvCpe
C 119057	Trimstick & Trim Assy-F Lock Pillar-LH	36 CvCpe
C 119060	Top-Complete-Trimmed	36 CvCpe
C 119061	Rear Curtain & Window Assy	36 CvCpe
C 119064	Back Stay Assy-Top-RH	36 CvCpe
C 119065	Back Stay Assy-Top-LH	36 CvCpe
C 119067	Top Deck & Slide Quarter Assy	36 CvCpe
C 119072	Top Strainer Assy	36 CvCpe
C 119076	Weatherseal Flap Assy-Top Side Qr-RH	36 CvCpe
C 119077	Weatherseal Flap Assy-Top Side Qr-LH	36 CvCpe
C 119078	Valance Assy-Top Rear	36 CvCpe
C 119080	Dust Boot Assy-Top	36 CvCpe
C 119081	Trimboard & Trim Assy-Frt Seat Comp Bottom	36 CvCpe
C 119082	Windlace Assy-Front Pillar-RH	36 CvCpe
C 119083	Windlace Assy-Front Pillar-LH	36 CvCpe
C 119084	Windlace Assy-Rear Pillar-RH	36 CvCpe
C 119085	Windlace Assy-Rear Pillar-LH	36 CvCpe
C 119086	Trimboard Assy-Rear Hinge Pillar-RH	36 CvCpe
C 119087	Trimboard Assy-Rear Hinge Pillar-LH	36 CvCpe
C 119088	Trimboard & Trim Assy-Frt Seat Comp Side-RH	36 CvCpe
C 119089	Trimboard & Trim Assy-Frt Seat Comp Side-LH	36 CvCpe
C 119091	Trimboard Frt Seat Compartment	36 Cpes
C 119104	Trimboard & Trim Assy-F Seat Comp-Upper.	36 CvCpe
C 119115	Back Complete-Front Seat	61 thru 65 CvCpe
C 119116	Trim Assy-Front Seat Back	61 thru 65 CvCpe
C 119117	Cushion Complete-Front Seat	61 thru 64 CvCpe
C 119118	Cushion Complete-Front Seat	65 CvCpe
C 119119	Trim Assy-Front Seat Cushion	61 thru 65 CvBro
119125	Door Assy-LH Front (Use 119585)	63 thru 65 Bro,66-67 Sed
119126	Use 119588	
119127	Door Assy-LH Front (Use 119589)	63-64-65 Sed
119129	Door Assy-LH (Use 119593)	63 thru 65 Cpe
119132	Door Assy-RH Rear (Use 119600)	63 thru 67 Sed
119133	Door Assy-LH Rear (Use 119601)	63 thru 67 Sed
BZ 119150	Clip-Bonnet Side Panel Moulding	63 thru 67,70,71,72,78,92,93,95,97
BZ 119176	Mounting Cap-Radiator Ornament Crest	36 Terr
BO 119177	Ornament & Crest Assy-Radiator	61,62
BO 119189	Gasket Assy-Head Lamp Lens	36-37 All
C 119191	Spring-Front Seat Cushion-LH	36 thru 1942 Bucket Seats
C 119220	Scuff Strip-Run Board Mldg-RH	61,62
C 119221	Scuff Strip-Run Board Mldg-LH	61,62
C 119237	Bar-Front Bumper	36 Hudson
BZ 119238	Bar Assy-Front Bumper Frame-RH	36 Hudson
BZ 119239	Bar Assy-Front Bumper Frame-LH	36 Hudson
C 119243	Bumper Bar-Rear	36 Hud Bro-Sed,36 Hud Side Mount Cpe
BO 119248	Check Strap-Front Door	36 thru 1940 All
119291	Use 210669	
BO 119299	Gasket-Tail Lamp Aux-Lens	36 Bro-Sed-UCo
BO 119404	Ash Receiver & Tray Assy-Instrument Panel	36 Hud exc CvCpe
C 119408	Panel-Front Door-RH-Twist	65 Sedan
C 119409	Panel-Front Door-LH-Twist	65 Sedan
C 119410	Panel-Front Door-RH-Mohair	65 Sedan
C 119411	Panel-Front Door-LH-Mohair	65 Sedan
119426	Use 116306	
119427	Use 116307	
119432	Use 117076	
119433	Use 117077	
119434	Use 117076-117077-116306	
F 119445	Lens-Headlamp	36 Hudson

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 119450	Door Complete-Front-RH	65 Sedan
C 119451	Door Complete-Front-LH	65 Sedan
C 119452	Door Complete-Front-RH	65 Sedan
C 119453	Door Complete-Front-LH	65 Sedan
C 119454	Trimboard Complete-Frt Door-RH	65 Sedan
C 119455	Trimboard Complete-Frt Door-LH	65 Sedan
C 119458	Back Complete-Front Seat	65 Sedan
C 119460	Back Complete-Rear Seat	61 Bro-3Cpe-4Cpe
BO 119467	Weatherstrip-Door Opening	62
BO 119468	Weatherstrip-Door Opening	62-63-64-65 Sedan
BO 119469	Weatherstrip-Door Opening	66-67 Sedan
119470	Weatherstrip-Door Opening (Use 2-119468)	36 Coml exc UCo
BO 119533	Lamp Complete-Tail & Stop	36 Hudson
119543	Lens-Headlamp (Use 120999)	61 Bro
119577	Door Assy-Front-LH (Use 119585)	61 Sed-Cab-CabPu
C 119578	Door Assy-Front-RH	61 Sed-Cab-CabPu
C 119579	Door Assy-Front-LH	63 thru 65 Bro,66-67 Sedan
C 119585	Door Assy-Front-LH	63-64-65 Bro,66-67 Sedan
C 119586	Door Assy-Front-RH	62 thru 65 Sedan
C 119588	Door Assy-Front-RH	62 thru 65 Sedan
C 119589	Door Assy-Front-LH	62 thru 65 3Cpe-4Cpe
C 119593	Door Assy-Front-LH	61 thru 65 Sedan
C 119600	Door Assy-Rear-RH	61 thru 65 Sedan
C 119601	Door Assy-Rear-LH	66-67 Sedan
C 119604	Door Assy-Rear-RH	66-67 Sedan
C 119605	Door Assy-Rear-LH	36 CvCpe
119680	Top Material (Use 115752)	36 CvCpe
BO 119682	Housing-Tail Lamp-With License	61 RHD,61 LHD Bro-Sed With Trunk,62 thru 67 All
BO 119683	Housing-Tail Lamp-Without License	36 UCo
BO 119684	Housing-Tail & Stop Lamp-With License	36 UCo LHD With Trunk,UCo-RHD
BO 119685	Housing-Tail Lamp-Without License	36 Bro-Sed-UCo
BO 119686	Wire & Terminal Assy-Tail Lamp	36 CvCpe
BO 119687	Wire & Terminal Assy- Tail Lamp	36 Panel
BO 119688	Handle-Rear Door Outside	36 Panel
BO 119689	Handle .& Lock Cyl Assy-Rr Door Outside	36 CvCpe
119725	Binding-3/4" Double Fold (Use 115753)	36 CvCpe
119726	Binding-5/8" Wire On (Use 115754)	36 Hudson
BZ 119727	Bracket Assy-Front License Plate	61 thru
C 119746	Header Assy-Body-RH	65 Sedan
C 119773	Door Complete-LH-Front	66 Sedan
BO 119791	Lens-Locker Box Door Clock	36 All
BO 119793	Lock Cylinder-Blank-For Locker Box	36 All
BO 119795	Spacer Ring-Oil & Ampere Light Socket	36 All
BO 119796	Cap Complete-Radiator Ornament Crest	36 Terr
C 119807	Spacer Board'& Trim Assy-Frt Seat Back Spring	36 Cab-CabPu
C 119820	Bracket-Seat Back Hanger	36 thru 1947 Cab-CabPu
BO 119848	Wire & Knob Assy-Carburetor Choke	61
119849	Body Wax-1 lb can (Use 111939)	All
BO 119861	Spring-Tail Lamp Lens Retaining	36 All
119865	Use 121529	
C 119870	Trimboard Assy-Hinge Pillar & Lower Qtr-RH	36 Hudson Sedan
C 119871	Trimboard Assy-Hinge Pillar & Lower Qtr-LH	36 Hudson Sedan
BO 119876	Lock Assy-Rear Door-Right-Less Handle	61 Panel
C 119884	Molding-Roof Side-RH	61 Panel
C 119885	Molding-Roof Side-LH	61 Panel
C 119886	Drip Molding-Rear Roof	61 Panel
BO 119891	Hinge-Rear Door Upper-Door Half-LH	36-37 Panel
*HS 119902	Body Hand Rubbing Compound Gal Can	All
BO 119919	Shim-Roof Bow	36 thru 1940 exc Cab-CabPu-Panel-Cv
BO 119940	Stud-Rear View Mirror	36 thru 1949 All exc Commercial
119960	Mat-Floor Universal (Use 201134)	All
119961	Lens-Headlamp (Use 120999)	36 Hudson (Export)
A 120026	Fender Assy-RH Rear	36 thru 39 CabPu,70 Station
A 120027	Fender Assy-LH Rear	36 thru 39 CabPu,70 Station
120030	Panel-Roof (Use 125030)	37 Bro-Sed,70 UCo
120031	Panel-Roof-Prime (Use 125031)	76-77-78 Sedan
C 120035	Panel-Roof-Prime	37 3Cpe-4Cpe-UCpe,71B,73B
A 120040	Dust Shield Assy-Front Fonder Side-RH	70,71,72,78
A 120041	Dust Shield Assy-Front Fender Side-LH	70,71,72,78
A 120042	Dust Shield Assy-Front Fender Side-RH	73 thru 77
A 120043	Dust Shield Assy-Front Fender Side-LH	73 thru 77
BZ 120044	Brace-F Fender Side Dust Shield to Fender Support-RH	70,71,72,78

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 120045	Brace-F Fender Side Dust Shield to Fender Support-LH	70,71,72,78
BZ 120047	Brace-F Fender Side Dust Shield to Fender Support-LH	73 thru 77
BZ 120048	Tie Rod-Frt Fender, Support Bracket	37 All
120050	Use 120054	
120051	Use 120055	
120052	Qtr Panel-RH (Use 120056)	37 Sed
120053	Use 120057	
C 120054	Panel Assy-Quarter RH	71 thru 75 Bro
C 120055	Panel Assy-Quarter LH	71 thru 75 Bro
C 120056	Panel Assy-Quarter RH	71 thru 78 Sedan
C 120057	Panel Assy-Quarter LH	71 thru 78 Sedan
C 120065	Extension-Underbody Panel LH-Pr	70 thru 75
A 120080	Guard-Rear Splash-Pr	71 thru 77,70 Co.78 Sed
C 120092	Pillar Assy-RH Center	37 thru 39 Sedan
C 120093	Pillar Assy-LH Center	37 thru 39 Sedan
BO 120096	Tapping Plate-Body Bolt and Pillar	37 thru 1940 All,1946-1947 CvBro
C 120102	Pillar Assy-RH Rear	37 thru 39 Bro-UCo,70-80 Cab-CabPu-Panel
C 120103	Pillar Assy-LH Rear	37 thru 39 Bro-UCo,70-80 Cab-CabPu-Panel
C 120106	Pillar Assy-RH Rear	37 thru 39 3Cpe-VicCpe-UCpe
C 120107	Pillar Assy-LH Rear	37 thru 39 3Cpe-VicCpe-UCpe
120120	Use 120694	
A 120123	Shield & Extension Assy-Rad Lower Tank-En	70,71,72,78,80,81,82,88
A 120124	Shield & Extension Assy-Rad Lower Tank-En	73,83
C 120129	Rear Panel-Lower-Prime	37 thru 1940 Cpe-CvBro-CvSed
BO 120154	Riser Assy-Toe Board-RH-LHD	37 All
BO 120155	Riser Assy-Toe Board-LH-LHD	37 All
C 120180	Pillar-Body Front-RH	37 thru 1940 exc Cv
C 120181	Pillar-Body Front-LH	37 thru 1940 exc Cv
BZ 120191	Support Assy-Front Fender Apron	37-38 All 91,92,93,95,97
BO 120196	Regulator Assy-Front Door Wing-RH	75 thru 77,84 thru 87,95,97,72-73-82-83-92-93 Cv
BO 120198	Rest Channel & Guide Assy-Rear Wdo Glass-RH	37 thru 1942,Sedan-CA,1946-1947 Sed
BO 120199	Rest Channel & Guide Assy-Rear Wdo Glass-LH	37 thru 1942,Sedan-CA,1946-1947 Sed
C 120210	Panel-Front Door Outside-RH-Pr	72-73-74-75 3Cpe-4Cpe
C 120211	Panel-Front Door Outside-LH-Pr	72-73-74-75 3Cpe-4Cpe
C 120240	Door Assy-Front RH-Prime	71 Bro,70 UCo,78 Sedan
C 120241	Door Assy-Front LH-Prime	71 Bro,70 UCo,78 Sedan
C 120246	Door Assy-Front RH-Prime	72-73-74-75 Bro,76-77 Sedan
C 120247	Door Assy-Front LH-Prime	72-73-74-75 Bro,76-77 Sedan
C 120252	Door Assy-Front RH-Prime	71 Sed,70-78 Cab-CabPu-Panel
C 120253	Door Assy-Front LH-Prime	71 Sed,70-78 Cab-CabPu-Panel
C 120258	Door Assy-Front RH-Prime	72-73-74-75 Sedan
C 120259	Door Assy-Front LH-Prime	72-73-74-75 Sedan
C 120264	Door Assy-RH-Prime	71 3Cpe-4Cpe,70 UCpe,71B,73B
120265	Door Assy-LH-Prime (Use 120271)	71 3Cpe-4Cpe,70 UCpe,71B,73B
C 120270	Door Assy-RH-Prime	72-73-74-75 3Cpe-4Cpe
C 120271	Door Assy-LH-Prime	72-73-74-75 3Cpe-4Cpe
C 120278	Door Assy-Rear RH-Prime	71 thru 75 Sedan
C 120279	Door Assy-Rear LH-Prime	71 thru 75 Sedan
120280	Use 123742	
BO 120284	Glass Run Channel Assy-Front Door Lock Pillar-RH	37 thru 1940 Sedan
BO 120285	Glass Run Channel Assy-Front Door Lock Pillar-LH	37 thru 1940 Sedan
120286	Lock Assy-Front Door-RH (Use 136048)	70 thru 78 exc Station
120287	Lock Assy-Front Door-LH (Use 136049)	70 thru 78 exc Station
120288	Lock Assy-Rear Door-RH (Use 1-136050 & 3-170327)	37 All Sedan
120289	Lock Assy-Rear Door-LH (Use 1-136051 & 3-170327)	37 All Sedan
*BO 120290	Remote Control Assy-RH Front Door Lock	71-74-75-81-84-85-89-95 Sed,37 thru 39 Cab-CabPu-Panel
*BO 120291	Remote Control Assy-LH Front Door Lock	71-74-75-81-84-85-89-95 Sed,37 thru 39 Cab-CabPu-Panel
120292	Remote Control Assy-RH Rr Dr Lock (Use 136060)	37-38 Sed
120293	Remote Control Assy-LH-Rr Dr Lock (Use 136061)	37-38 Sed
BO 120299	Support-Front Door Trimboard	71-89 Exc Cv,70-78-90-98 Exc Sta,71B, 73B,91 Panel
C 120300	Running Board Assy-Complete-RH	70,71,72,80,81,82
C 120308	Running Board Assy-Complete-RH	76,77
C 120309	Running Board Assy-Complete-LH	76,77
BO 120344	Bracket-Cowl Ventilator Operating Link to Deflector	37 thru 1940 All
BO 120346	Operating Link-Cowl Ventilator-Lower	37 All
BO 120347	Tension Washer	37 thru 1950 All
BO 120349	Guide-Cowl Ventilator Ratchet	37 All

Part No.	Name	Models
	120350 Knob-Cowl Vent Oper Hol (Use 140278)	37-38 All
BO	120353 Cover Assy-Cowl Ventilator	37 All
C	120356 Door Assy-Rear Compt-Less Ornament Holes	37 Bro-Sed-UCo
C	120364 Reinf Assy-Rear Compartment Opening	37-38 Bro-Sed-UCo
C	120370 Molding-Running Board-RH	73,74,75
C	120371 Molding-Running Board-LH	73-74-75
C	120372 Molding-Running Board-RH	76,77
C	120373 Molding-Running Board-LH	76,77
BO	120374 Clip-Running Board Molding-Long	73 thru 77
C	120375 Lid Assembly-Trunk-Prime	37 Bro-Sed-UCo
C	120375 Lid Assy-Trunk-Lac	37 Bro-Sed-UCo
A	120400 Grille-Radiator	71,72,70 UCo-UCpe-Station-78 Sedan
A	120401 Grille-Radiator	73 thru 77
A	120408 Shell Assy-Radiator	70,71,72,78
A	120411 Grille-Radiator-Velchrome	70 Cab-CabPu,71B
A	120429 Hood-Complete	70,71,72,78
A	120432 Side Panel-Hood RH	70,71,72,78
A	120433 Side Panel-Hood LH	70,71,72,78
A	120436 Top & Side Panel Complete-Hood RH-Pr	70,71,72,78
A	120437 Top & Side Panel Complete-Hood LH-Pr	70,71,72,78
A	120438 Panel Assy-Hood Top RH-Pr	70,71,72,78
A	120439 Panel Assy-Hood Top LH-Pr	70,71,72
A	120440 Hood Complete-Prime	73 thru 77
A	120444 Panel-Hood Side-Pr	73 thru 77
A	120445 Panel-Hood Side-Pr	73 thru 77
A	120448 Panel-Assy-Hood Top RH-Pr	73 thru 77
A	120449 Panel Assy-Hood Top LH-Pr	73 thru 77
A	120450 Top & Side Panel Complete-Hood RH-Pr	73 thru 77
A	120451 Top & Side Panel Complete-Hood LH-Pr	73 thru 77
A	120458 Hinge-Hood-Female	70,71,72,78
A	120459 Hinge-Hood-Female	73 thru 77
C	120461 Molding-Hood Side Panel Top	70,71,72,78
C	120462 Molding-Hood Side Panel-Bottom	70,71,72,78
C	120463 Molding-Hood Side Panel-Center	70,71,72,78
C	120464 Molding-Hood Side Panel-Top & Bottom	73 thru 77
C	120465 Molding-Hood Side Panel-Center	73 thru 77
BO	120466 Cover-Hood Rear Corner-RH	73 thru 77
BO	120467 Cover-Hood Rear Corner-LH	73 thru 77
BZ	120469 Crossmember-Front Fender Frame	37-38 All
BZ	120471 Brkt-Frt Fender Frame Crossmember Corner-LH.	37 All
BZ	120472 Brkt-Frt Fdr to Bumper Frame Bar Support-RH	37-38 All
BZ	120473 Brkt-Frt Fdr to Bumper Frame Bar Support-LH	37-38 All
BZ	120474 Brace-Frt Fender to Bumper Frame Bar Support-Bracket	37-38 All
C	120479 Fender Assy-LH Frt-Without Well	73 thru 77
C	120484 Reinforcement Assy-Front Body Pillar-RH	37-38 exc Cv
C	120485 Reinforcement Assy-Front Body Pillar-LH	37-38 exc Cv
BO	120496 Remote Control Assy-RH-F Dr Lock	37-38 CvCpe-CvBro,70-80 Co-Cpe,71B,73B,76-77-78-87-88 Sed,89 exc Cv
BO	120497 Remote Control Assy-LH-F Dr Lock	37-38 CvCpe-CvBro,70-80 Co-Cpe,71B,73B,76-77-78-87-88 Sed,89 exc Cv
BO	120498 Regulator Assy-Rear Door Window-RH	37 thru 1941 Sedan
BO	120499 Regulator Assy-Rear Door Window-LH	37 thru 1941 Sedan
BO	120510 Retainer-Door Dovetail Plate	37 thru 39 All,40 Panel
BO	120514 Striker Plate-Door Lock	37 thru 39 All,40 Panel
BO	120515 Tapping Plate-Door Lock Striker Plate	37 thru 39 All,40 Panel
BO	120518 Guide & Bumper Assy-Front Door Check	37 thru 1940 All
BO	120524 Hinge-Frt Door-Upper RH-Door Half	37 thru 39 All,40 Panel
BO	120525 Hinge-Frt Door-Upper LH-Door Half	37 thru 39 All,40 Panel
BO	120526 Hinge-Frt Door-Upper RH-Body Half	37 thru 39 All
BO	120527 Hinge-Frt Door-Upper LH-Body Half	37 thru 39 All
BO	120528 Hinge-Frt Door-Lower RH-Door Half	37 thru 39 All
BO	120529 Hinge-Frt Door-Lower LH-Door Half	37 thru 39 All,40 Panel
BO	120530 Hinge-Frt Door-Lower RH-Body Half	37 thru 39 All
BO	120531 Hinge-Frt Door-Lower LH-Body Half	37 thru 39 All
BO	120532 Pin-Frt Door Hinge-Upper & Lower	37 thru 1941 All,1942-1946-1947 Cab-CabPu
C	120535 Strainer Assy-Frt Door Panel	37 All
C	120544 Panel-Rear Upper	37 thru 39 CvCpe
BO	120579 Pad-Door Handle Escutcheon	37 thru 39 All,1940 Cpe-2Sed-CvSed-UCo
BO	120588 Rest Channel Assy-Frt Door Glass-RH	37-38-39 UCo-UCpe,BCpe,71-89 Bro-Cpe,78-88 Sed, 10T Cpe-2Sed,10 UCo-UCpe,18P
BO	120589 Rest Channel Assy-Frt Door Glass-LH	37-38-39 UCo-UCpe-BCpe,71-89 Bro-Cpe,78-88 Sed, 10T Cpe-2Sed,10 UCo-UCpe,18P
BO	120590 Rest Channel Assy-Frt Door Glass-RH	37-38-39 Cab-CabPu -Panel,71 -80-89-90- 10T Sed, 1941 Cab-CabPu

Part No.	Name	Models
BO 120591	Rest Channel Assy-Frt Door Glass-LH	37-38-39 Cab-CabPu-Panel,71-80-89-90-10T Sed, 1941 Cab-CabPu
120604	Cushion-Frt Door Window Glass (Use 112754)	71 Bro-Sed-3Cpe-4Cpe,70 exc Station,71B,73B,78
120606	Use 112689	
120607	Use 112689	
120608	Use 112685	
120609	Use 112685	
120610	Use 112689	
120611	Use 112689	
120622	Riser-Rear Compt Floor Board-RH	37 Bro-Sed-Cpe-CvBro-Std Tires-Rear Mount-Less Trunk
C 120623	Riser Assy-Rear Compt Floor Board-LH	37 Bro-Sed-Cpes-CvBro-Std Tires-Rear Mount-Less Trunk
C 120638	Glass & Rest Channel Assy-Rear Door Wdo-RH	71 thru 78 Sedan,1940-1941 Sed-CA
C 120639	Glass & Rear Channel Assy-Rear Door Wdo-LH	71 thru 78 Sedan,1940-1941 Sed-CA
BZ 120640	Stone Guard Support-Frt Fender-Lower-RH	37 thru 1942 exc 10 DeL
BZ 120641	Stone Guard Support-Frt Fender-Lower-LH	37 thru 1942 exc 10 DeL
BZ 120642	Stone Guard Support-Rear Fender-Lower-RH	37-38 All
BZ 120643	Stone Guard Support-Rear Fender-Lower-LH	37-38 All
BZ 120644	Stone Guard Support-Frt & Rear Fdr-Upper	37 thru 1942 Exc 10 DeL
BO 120647	Center Bar-Windshield-Inner•	37 exc Cv
BO 120648	Cover-Windshield Finish Mldg Lower Joint	37 exc 70
120649	Use 120648	
BO 120650	Ornament-Hood Top Panel-RH	37 All
BO 120651	Ornament-Hood Top Panel-LH	37 All
BO 120652	Shim-Hood to Radiator-Upper	37 All
BO 120653	Shim-Hood to Radiator-Lower	37 All
BO 120654	Molding-Rad Grille Center-Upper	70,71,72,78
BO 120655	Molding-Rad Grille Center-Upper	73 thru 77
BO 120656	Molding-Rad Grille Center-Lower	70,71,72,78
BO 120657	Molding-Rad Grille Center-Lower	73 thru 77
C 120658	Molding-Rad Grille Side-RH	70,71,72,78
C 120659	Molding-Rad Grille Side-LH	70,71,72,78
C 120660	Molding-Rad Grille Side-RH	73 thru 77
C 120661	Molding-Rad Grille Side-LH	73 thru 77
BZ 120662	Welt-Frt Fender to Radiator Shell	37 All
BO 120668	Clamp-Visor Support Rod	37 thru 1947 All,482-484-492-494-502-504 exc CvBro
BO 120669	Visor & Bracket Assy-RH	71 thru 77,78 Sed
BO 120670	Visor & Bracket Assy-LH	71 thru 77,78 Sed
BO 120671	Rod-Visor Support	37 All
BO 120672	Arm-Visor Bracket	37 thru 1947 All
BO 120676	Plate-Visor Header Hinge	37 thru 1947 All,482-492-502-484-494-504 exc CvBro
BO 120677	Clamp-Visor Header Hinge	37 thru 1947 All,482-492-502-484-494-504 exc CvBro
C 120681	Stay Rod Assy-Radiator	70,71,72,78
C 120683	Stay Rod Assy-Radiator	73 thru 77
C 120692	Glass-Windshield	37 thru 39 All
A 120694	Shield & Brkt Assy-Rad Lower Tank	74,75,76,77,84,85,87
120700	Weatherstrip-Rear Window (Use 130180)	37-38 Bro-Sed-3Cpe-VicCpe-UCo-UCpe
BO 120774	Clamp-License Plate-Front & Rear	1937 thru 1950 All
BO 120775	Bracket Assy-Rear License Plate-Prime	37-38 exc Cab-CabPu-Panel,39 Cpe-Cv
BO 120776	Bracket Assy-Rear License Plate-Prime	37 With Trunk
120777	Lamp Complete-Tail & Stop-LHD (Use 144730)	37-38 Cab-CabPu-Panel-Station
C 120783	Front End Assembly-LHD-Prime	73 thru 77 exc Cv
BO 120829	Channel Assy-Qtr Window Glass-Lower	37-38 Sedan
120839	Regulator Assy-Qtr Window Glass (1-148600 & 2-70853)	37-38 Sedan,92 thru 97 Sed,41 thru 47 Sed
C 120840	Weatherstrip-Qtr Window-Inner	37-38 Sedan
C 120842	Weatherstrip-Qtr Window-Outer-RH	37-38 Sedan
BO 120844	Felt-Qtr Window Glass Run	37 thru 39 Sedan,43 thru 47 Sed,11 thru 17 Sed Club-Cpe,10P Sed
C 120850	Quarter Panel-RH-Prime	37 3Cpe-VicCpe
C 120851	Quarter Panel-LH-Prime	37 3Cpe-VicCpe
C 120852	Panel Assy-Quarter-RH	37 VicCpe-UCpe
C 120856	Panel Assy-Quarter-RH-Prime	71 thru 75 CvCpe
C 120868	Door Assembly-Deck-Prime	37Cpe-CvBro
*BO 120876	Remote Cont Assy-RH-F Door Lock	72-73-82-83 Bro-3Cpe-VicCpe,81-89 CvCpe-CvBro
120877	Remote Cont Assy-Frt Door Lock-LH (Use 136053)	72-73-82-83 Bro-3Cpe-VicCpe,81-89 CvCpe-CvBro
*BO 120878	Remote Cont Assy-Frt Door Lock-RH	72-73-82-83 Sedan
*BO 120879	Remote Cont Assy-Frt Door Lock-LH	72-73-82-83 Sedan
BO 120894	Bolt-Visor Header Hinge Clamp	72 thru 77 Bro-Sed-3Cpe-4Cpe,78 Sed
C 120925	Ret Assy-Frt Door Hinge Pillar Trim-LH	70,71,72,80 thru 85,89,1939-1940 exc Cv,71B, 73B,78,88
C 120928	Ret Assy-Frt Door Lock Pillar Trim-RH	70,71,72,80 thru 85,89,1939-1940 exc Cv,71B, 73B,78,88

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 120929	Ret Assy-Frt Door Lock Pillar Trim-LH	70,71,72,80 thru 85,89,90 thru 98 exc Cv,71B,73B,78,88
C 120940	Ret Assy-Rear Door Hinge Pillar Trim-RH	71-72-78 Sed,38 thru 1940 Sedan
C 120952	Ret Assy-Frt Body Pillar Trim-RH	37 thru 1940 exc Cv
C 120953	Ret Assy-Frt Body Pillar Trim-LH	37 thru 1940 exc Cv
BO 120960	Reg Assy-Front Door Wing-RH	72-73-82-83 Bro-Sed-3Cpe-4Cpe,78 Sed
BO 120961	Reg Assy-Front Door Wing-LH	72-73-82-83 Bro-Sed-3Cpe-4Cpe,78 Sed
BO 120962	Bar-Windshield Center-Outer	37 CvCpe-CvBro
BO 120963	Bar-Windshield Center-Inner	37 thru 39 CvCpe-CvBro
BO 120964	Bracket-Headlamp-RH	37 All
BO 120965	Bracket-Headlamp-LH	37 All
BO 120968	Pad-Headlamp Bracket	37 All
BO 120970	Hdlmp Complete-Right-With Parking Bulb-En	70,71,72,73B,78
BO 120971	Headlamp-Left-With Parking Bulb-En	70,71,72,73B,78
120972	Headlamp-Right With Parking Bulb-Pr (Use 120984)	70,71,72,73B,78
120973	Headlamp-Left-With Parking Bulb-Pr (Use 120985)	70,71,72,73B,78
BO 120974	Headlamp-RH-With Parking Bulb-En	70,71,72,73B,78,Export
BO 120975	Headlamp-LH-With Parking Bulb-En	70,71,72,73B,78,Export
BO 120976	Headlamp-RH-Without Parking Bulb-En	70,71,72,73B,78,Export
BO 120977	Headlamp-LH-Without Parking Bulb-En	70,71,72,73B,78,Export
BO 120978	Headlamp-RH-With Parking Bulb-Pr	70,71,72,73B,78,Export
BO 120979	Headlamp-LH-With Parking Bulb-Pr	70,71,72,73B,78,Export
BO 120980	Headlamp-RH-Without Parking Bulb-Pr	70,71,72,73B,78,Export
BO 120981	Headlamp-LH-Without Parking Bulb-Pr	70,71,72,73B,78,Export
120982	Headlamp-RH-With Parking Bulb-En (Use 120984)	73 thru 77
120983	Headlamp-LH-With Parking Bulb-En (Use 120985)	73 thru 77
BO 120984	Headlamp-RH-With Parking Bulb-Pr	73 thru 77
BO 120985	Headlamp-LH-With Parking Bulb-Pr	73 thru 77
BO 120986	Headlamp-RH-With Parking Bulb-En	73 thru 77 Export
BO 120987	Headlamp-LH-With Parking Bulb-En	73 thru 77 Export
BO 120988	Headlamp-RH-Without Parking Bulb-En	73 thru 77 Export
BO 120990	Headlamp-RH-With Parking Bulb-Pr	73 thru 77 Export
BO 120991	Headlamp-LH-With Parking Bulb-Pr	73 thru 77 Export
BO 120992	Headlamp-RH-Without Parking Bulb-Pr	73 thru 77 Export
BO 120993	Headlamp-LH-Without Parking Bulb-Pr	73 thru 77 Export
F 120998	Lens-Headlamp-Domestic	70,71,72,78
BO 120999	Lens-Headlamp-Export	37 Terr
BO 121000	Housing Assy-Headlamp-Prime-RH	70,71,72,73B,78
BO 121001	Housing Assy-Headlamp-Prime-LH	70,71,72,73B,78
BO 121002	Housing Assy-Headlamp-Prime-RH	73 thru 77
BO 121003	Housing Assy-Headlamp-Prime-LH	73 thru 77
BO 121008	Sockets & Wires Assy-Headlamp-Right-With Parking Bulb	37 All
BO 121009	Sockets & Wires Assy-Headlamp-Left-With Parking Bulb	37 All
BO 121010	Choke Wire Assembly-Carburetor	70,71,71B,78
121011	Choke Wire Assy-Carburetor (Use 121010)	70,71,71B,78
BO 121012	Choke. Wire & Knob Assy-Carburetor	70,71,71B,78
BO 121014	Socket & Wires Assy-Headlamp-Right-Without Parking Bulb	37 All
BO 121018	Reflector Assy-Headlamp-With Parking Bulb	37 All
121021	Mat & Pad Assy-Front Floor-RHD (Use 201134)	70,71,78,73B
121023	Mat & Pad Assy-Front Floor-RHD (Use 201134)	72 thru 77
F 121030	Gauge Assy-Gasoline & Water Temperature	37 All
BO 121031	Glass Dial-Speedometer-Miles	37 All
BO 121033	Retainer-Speedometer Glass Dial	37 All
BO 121034	Cushion-Speedometer Glass Dial	37 All
BO 121035	Bezel-Speedometer Glass Dial	37 All
BO 121036	Glass Dial-Oil Pressure Gauge	37 All
BO 121037	Glass Dial-Water Temperature Gauge	37 All
BO 121038	Glass Dial-Gasoline Gauge	37 All
BO 121039	Glass Dial-Generator Charge Indicator	37 All
BO 121040	Trim Clip-Front Floor Mat	70,71,78,80,81,88,89,90,92,98,40 exc Sed,48,10T,10C-18 exc Panel,18P,20C,28C,1946-47 All
121041	Trim Clip-Front Floor Mat (Use 121040)	72 thru 77,82 thru 87,93,95,97,40P Sed,41 thru 47
BO 121064	Door Assy-Locker Box RH-2 Tone-LHD	71 thru 77,70 Station,78 Sed
BO 121065	Door Assy-Locker Box LH-2 Tone-LHD	71 thru 77,70 Station,78 Sed
BO 121066	Door Assy-Locker Box RH-2 Tone-RHD	71 thru 77,70 Station,78 Sed
BO 121068	Door Assy-Locker Box RH-3 Tone-LHD	73 thru 77
BO 121069	Door Assy-Locker Box LH-3 Tone-LHD	73 thru 77
BO 121074	Hinge Assembly-Locker Box Door	37 All
BO 121076	Striker Plate-Locker Box Door	37-38 All
BO 121078	Spring-Locker Box Door Hinge-RH	37-38 All,90,91,92,98

Part No.	Name	Models
BO 121079	Spring-Locker Box Door Hinge-LH	37-38 All,90,91,92,98
BO 121084	Visor Assembly-Inside-RH	72 thru 78 Bro-Sed,72 thru 75 VicCpe-3Cpe 82 Bro
M 121104	Imitation Leather-Brown	
M 121105	Imitation Leather-Blue	
M 121106	Imitation Leather-Green	
121113	Use 121117	
121114	Use 124078 for 73,124079 for 74-75-76-77	
BO 121117	Ornament & Crest Assembly-Radiator	73 thru 77 All
BO 121118	Bumper-Locker Box Door	37 thru 39 All
BO 121119	Spacer-Locker Box Door-Rubber	37 thru 39 All
BZ 121131	Tray Assembly-Battery	70,71,72,78,80,81,82,88,92
BZ 121132	Tray Assembly-Battery	73,83,93
BZ 121133	Tray Assembly-Battery	74 thru 77,84,85,87,95,97
121135	Use 128293	
121137	Use 121141	
121140	Cover Complete-Battery (Use 128293)	70,71,72
121141	Cover Complete-Battery (Use 128295)	73 thru 77
BO 121161	Crest-Radiator Ornament	73 thru 77
BO 121166	Bracket-Body Hdr to Center Pillar-Rear RH	37 thru 1941 Sedan-CA,1942 thru 1947 Sed
BO 121167	Bracket-Body Hdr to Center Pillar-Rear LH	37 thru 1941 Sedan-CA,1942 thru 1947 Sed
BO 121168	Reinforcement-Tail Lamp Fender-RH	71 RHD,70 UCo,UCpe RHD,72 thru 77,78 Sed,80 UCpe
BO 121169	Reinforcement-Tail Lamp Fender-LH	37 All,80 Cpe
BZ 121170	Grommet-Front Fender Bumper-RH	37-38 All,90,98
BZ 121171	Grommet-Front Fender Bumper-LH	37-38 All,90,98
BZ 121172	Grommet-Rear Splash Guard Bumper-RH	70 Co-Cpe,71 thru 77,78 Sedan
BZ 121173	Grommet-Rear Splash Guard Bumper-LH	70 Co-Cpe,71 thru 77,78 Sedan
BO 121174	Ornament-Compt Door,Trunk Lid,Roof Panel, Tail Gate & Fender Finish Plate	71,72,78,70 UCo-UCpe-Panel-CabPu,80 UCpe,80-88 Panel,81-82 Cpe-Cv
BO 121175	Ornament-Compt Door,Trk Lid & Fdr Fin Plate	73 thru 77,83-84-85 Cpe-Cv
C 121176	Welt-Rear Fender	37-38 All 1939-1940 Cpe-Cv-Panel-Sta
C 121185	Bar-Front Bumper	70,71,72
C 121186	Bar-Front Bumper	73 thru 77
C 121190	Frame Bar Assy-Front Bumper-RH	76,77
C 121191	Frame Bar Assy-Front Bumper-LH	76,77
C 121192	Bar-Rear Bumper	71,72,70 UCo-UCpe-Panel,78 Panel-Sedan
C 121194	Frame Bar Assembly-Rear Bumper	76,77
C 121195	Frame Bar Assembly-Rear Bumper	76,77
C 121197	Frame Bar Assy-Front Bumper-LH	70 thru 75,78
C 121198	Frame Bar Assy-Rear Bumper-RH	71 thru 75,70 UCo-UCpe-Panel
121199	Frame Bar Assy-Rear Bumper-LH (Use 124505)	71 thru 75,70 UCo-UCpe-Panel
BZ 121200	Fender Guard Assy-Bumper-Frt & Rear	70,71,72,78
BZ 121201	Fender Guard Assy-Bumper-Frt & Rear	73 thru 77,11-14-21-24
BZ 121227	Arm Assy-Tail Lamp Brkt & Lic Plate-RHD	70-78 Panel
A 121232	Fender Assy-RH Frt With Well-Pr	73 thru 77
A 121233	Fender Assy-LH Frt With Well-Pr	73 thru 77
A 121238	Well Assy-Right Frt Fender-Prime	37-38 All
A 121239	Well Assy-Left Frt Fender-Prime	37-38 All
BZ 121245	Plate-Side Carrier Column to Well-Clamp	37-38 All
BZ 121246	Grommet-Side Carrier Screw Column	37-38 All
C 121250	Reinforcement Assy-Deck Opening	37 thru 1940 Cpe-Cv
121261	Use 121262	
BO 121262	Weatherstrip-Deck Door	37 thru 1940 Cpe-Cv
BO 121263	Ash Receiver Assy-Frt Seat Back Panel	71 thru 74 Sedan,78 Sed
121264	Use 121263	
BO 121265	Ash Tray Assy-Frt Seat Back Panel	71 thru 74 Sedan,78 Sed
BO 121266	Ornament-Cowl Ventilator Cover	37 All exc 70
BO 121271	Dome Lamp Assembly	73 thru 78 Sedan
BO 121274	Escutcheon Plate-Dome Lamp Switch	73 thru 78 Sedan
BO 121275	Switch-Dome and Service Lamp	73 thru 78
BO 121276	Shim-Windshield Center Bar	37-38 All
BO 121284	Ornament-Radiator	70,71,72,78
BO 121285	Mounting-Radiator Ornament Crest	71-72 All,78 Sed
C 121295	Frame Assy-Seat Cushion	37 thru 1947 Cab-CabPu
C 121296	Frame Assy-Seat Back	37 thru 1947 Cab-CabPu
C 121315	Finish Mldg Assy-Frt Door Window-LH	72 Sedan
C 121318	Finish Mldg Assy-Frt Door Window-RH	37 thru 39 Cab-CabPu-Panel,80-90 Sed,40 Panel
C 121319	Finish Mldg Assy-Frt Door Window-LH	37 thru 39 Cab-CabPu-Panel,80-90 Sed,40 Panel
C 121324	Finish Mldg Assy-Frt Door Window-RH	37 thru 39 UCpe,89 3Cpe-VicCpe,71B,73B
BO 121380	Latch Assembly-Hood-RH	70,71,72,78
BO 121381	Latch Assembly-Hood-LH	70,71,72,78
BO 121382	Latch Assembly-Hood-RH	73 thru 77

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 121383	Latch Assembly-Hood-LH	73 thru 77
BO 121384	Bracket-Hood Latch-Front RH	37 All
BO 121385	Bracket-Hood Latch-Front LH	37 All
BO 121386	Bracket-Hood Latch-Rear RH	70,71,72,78
BO 121387	Bracket-Hood Latch-Rear LH	70,71,72,78
BO 121388	Bracket-Hood Latch-Rear RH	73 thru 77
121390	Use 124260	
BO 121394	Spring-Compartment Door Check Arm	37-38 111,39-1940 Cpe-Cv
BO 121396	Rivet-Compt Door Check Arm Spring	37-38 111,39-1940 Cpe-Cv
C 121400	Roof Bow #1	37 Bro-3Cpe-VicCpe,76-77-78 Sed,70,71B,73B
C 121401	Roof Bow #2	71 thru 75 Sed,70-78 Cab-CabPu
C 121402	Roof Bow #2	37 Bro-Sedan,70 UCo
C 121403	Roof Bow #3	70 thru 75 Bro-UCo,76-77-78 Sedan
C 121404	Roof Bow #3	71-72-73-74-75 Sedan
C 121405	Roof Bow #4	37 Bro-Sed,70 UCo
C 121422	Roof Bow Rear	37 Bro-Sedan,70 UCo
BO 121445	Track Assy-LH Frt Seat Adjusting-LHD	37 Sed-3Cpe,UCpe-BCpe
BO 121446	Track Assy-RH Frt Seat Adjusting-LHD	37-38 Sed-3Cpe,37 UCpe-BCpe
121447	Use 121446	
BO 121465	Weatherstrip-Front Door Bottom	71 thru 75-81 thru 85-89-90 thru 95 exc Sed,76-77-78-87-88-97-98 Sed,80-90 UCo-UCpe
121466	Weatherstrip-Front Door Bottom (Use 121465)	71 thru 75,80 thru 85-89-90 thru 95 Sed,37 thru 39 Cab-CabPu-Panel
121467	Weatherstrip-Rear Door Bottom (Use 121465)	37 thru 39 Sedan
121478	Use 123688	
121479	Use 123689	
C 121488	Dash Silencer & Trim Board Assy-Black-LHD	70,71,78
C 121489	Dash Silencer & Trim Board Assy-LHD	37 All
C 121490	Dash Silencer & Trim Board Assy-RHD	37 All
121493	Pad-Dash Lining (Use 1 each 121590-1)	37 All
121497	Lock Assy (Use 208599)	72 thru 77,78 Sed
BO 121502	Cylinder-Locker Box Door	37 All,90 Passenger,91,92
BO 121503	Cylinder & Key Assy-Locker Box Door Lock	37 All,90 Passenger,91,92
121504	Lock Assy (Use 208599)	
BO 121510	Bolt-Radiator Grille Mldg-Long	37 All
BO 121511	Bolt-Radiator Grille Mldg-Short	37 All
BO 121512	Spacer-Rad Grille Mldg-Bolt	37 All
BO 121513	Sleeve Nut-Rad Grille Molding Bolt	37 All
BO 121514	Clamp-Cigar Lighter Base	76,77,38 All
BO 121515	Crest-Radiator Ornament	70-71-72 Export,70-78 Exc Sed
BO 121517	Spacer-Hood Hinge Clip-Rear	37-38 All
BO 121519	Clip-Molding	37 thru 1941 All
C 121520	Molding-Instrument Panel	72 thru 77
BO 121522	Ornament-Front Fender	72
BO 121523	Ornament-Front Fender	73 thru 77
BZ 121524	Ornament-Hood Side Panel-RH	73 thru 77
BZ 121525	Ornament-Hood Side Panel-LH	73 thru 77
C 121526	Molding-Hood Top Panel Belt	73 thru 77
BZ 121527	Hole Cover-Rad Grille Starting Crank Hole	70,71,72,78
BZ 121528	Hole Cover-Rad Grille Starting Crank Hole	73 thru 77
BO 121529	Screen-Cowl Ventilator	37 thru 1940 All
BZ 121537	Welt-Rear Fender Finish Plate	37-38 All,39 3Cpe-VicCpe-Cv
121544	Tail & Stop Lamp Complete-En (Use 121545)	71,72,73B,78 Sed,70 UCo-UCpe
BO 121545	Tail & Stop Lamp Complete	71,72,73B,78 Sed,70 UCo-UCpe
121546	Tail & Stop Lamp Complete-En (Use 121545)	73 thru 77
121547	Tail & Stop Lamp Complete-Lac (Use 121545)	73 thru 77
BO 121548	Lamp Assy-Rear License Plate-En	37-38 All,39 3Cpe-VicCpe-Cv,40T Cpe
BO 121549	Lamp Assy-Rear License Plate	37-38 All,39 3Cpe-VicCpe-Cv,40T Cpe
C 121554	Frame Assembly-Front Seat Back-RH-RHD	71-72 exc Sedan,73-74 Bro-CvBro-CvCpe-VicCpe,75 CvCpeVicCpe,70UCpe
BO 121573	Pivot Pin-Frt Seat Back Support Center	37 thru 1947 With Pivot Seat
BO 121580	Stop-Rod-Frt Seat Track Adjusting	37 Bro-CvBro-CvCpe-VicCpe
BO 121584	Lever-Front Seat Adjusting Stop	37 Bro-CvBro-CvCpe-VicCpe
BO 121590	Pad-Dash Lining-RH	37 All
BO 121591	Pad-Dash Lining-LH	37 All
BO 121595	Head Assy-Speedometer-Metric	37 All
BO 121601	Cover Plate-Locker Box Clock Opening	70,71 Station,78 Sed
BO 121602	Cover Plate-Locker Box Clock Opening	72 thru 77
121603	Use 122880	
121606	Use 121609	
BO 121609	Bezel-Locker Box Door Clock-2 Tone	70 thru 78
BO 121610	Cover-Instrument Panel Radio Opening	70,71,72,78
BO 121611	Cover-Instrument Panel Radio Opening	73,74,76
BO 121614	Plaque-Door Window Finish Mldg Valance	75 Bro-Sed-3Cpe-VicCpe,87 Sedan

Part No.	Name	Models
BO 121617	Bezel-Instrument Panel Radio Dial	37 All
BO 121621	Ash Tray Assy-Instrument Panel	70,71,72,78
BO 121624	Ash Tray Assy-Instrument Panel	73 thru 77
BO 121625	Cover-Inst Panel Ash Tray Front	73 thru 77
BO 121626	Guide-Instrument Panel Ash Receiver	37 All
121628	Use 121630 & 121632	
BO 121630	Tray Assy-Arm Rest Panel Ash Receiver	75-76-77 Sed,75 Bro
BO 121632	Finish Plate-Arm Rest Panel Ash Receiver-RH	75-76-77 Sed,75 Bro
BO 121640	Lens-Rear License Plate Lamp	37-38 All,39 Cpe-Cv,40T Cpe
BO 121641	Housing-Rear License Plate Lamp Lens-Pr	37-38 All,39 Cpe-Cv,40T Cpe
BO 121642	Gasket-Rear License Plate Lamp Lens	37-38 All,39 Cpe-Cv,40T Cpe
BO 121643	Gasket-Assy-Rear License Plate Lamp Lens	37-38 All,39 Cpe-Cv,40T Cpe
121644	Ret-Rear License Plate Lamp Lens. Gasket	37-38 All,39 Cpe-Cv,40T Cpe
BO 121645	Gasket-Rear License Plate Lamp Bulb Ret	37-38 All,39 Cpe-Cv,40T Cpe
BO 121646	Base & Wires Assy-Rear Lic Plate Lamp Base	37-38 All,39 Cpe-Cv,40T Cpe
BO 121647	Body Assembly-Tail & Stop Lamp	37 thru 1940 Cab-CabPu-Panel-Station
BO 121648	Door & Lens Assy-Tail & Stop Lamp	37 thru 1940 Cab-CabPu-Panel-Sta-UCpe
BO 121649	Wires & Terminal Assy-Tail & Stop Lamp-LHD	37 thru 1940 Cab-CabPu-Panel-Station
BO 121652	Control Assy-W/Shield Cleaner	37 All
BO 121653	Spacer-Windshield Cleaner Operating Control	37-38 All
121655	Blade Assy-W/Shield Cleaner (*se 142398)	37-38 All exc Cv
BO 121656	Arm and Spring Assy-Windshield Cleaner	37 thru 39 exc Cv
BO 121657	Gasket-W/Shield Cleaner Housing Hole Cover	89,90,98,91 Panel
BO 121660	Chain Housing and Arm Assy-W/Shield Cleaner-RH-LHD	38-39 All
BO 121661	Chain Housing and Arm Assy-W/Shield Cleaner-LH-RHD	38-39 All
BO 121662	Bracket-W/Shield Cleaner Chain Housing Clamp	38-39 All
BO 121666	License Lens-Tail & Stop Lamp	37 thru 1940 Cab-CabPu-Panel-Station-UCpe
BO 121667	Gasket-Tail & Stop Lamp License Lens	37 thru 1940 Cab-CabPu-Panel-Station-UCpe
BO 121668	Lens-Tail & Stop Lamp	70,71,72,73B,78 Sed
BO 121669	Lens-Tail & Stop Lamp	73 thru 77
BO 121670	Housing-Tail & Stop Lamp-Prime	37 All
BO 121671	Ring Assy-Tail & Stop Lamp Door	37 All
BO 121672	Wire & Terminal Assy-Tail & Stop Lamp	37 All
BO 121673	Stud-Tail & Stop Lamp Mounting	37 All
BO 121674	Base, Rim & Lens Assy-Tail & Stop Lamp	70,71,72,73B,78 Sed
BO 121675	Base, Rim & Lens Assy-Tail & Stop Lamp	73 thru 77
BO 121678	Support-Front Fender Well to Apron-RH	37 thru 39 All
BZ 121688	Tapping Plate-Fender Well Support	37-38 A.11,91,92,93,95,97
BZ 121689	Screw-Side Wheel Carrier	37-38 All
BZ 121690	Lock Screw-Side Wheel Carrier Screw	37-38 All
BZ 121691	Lock Pin-Side Wheel Carrier Screw	37-38 All
BZ 121692	Column-Side Wheel Carrier Screw	37-38 All
BZ 121694	Cage Assembly-Spare Tire Lock	37-38 All
M 121701	Seat Cloth-Brown Boucle	
M 121703	Sidewall Cloth-Brown Boucle	
121704	Headlining Cloth-Brown (Use 127011)	
M 121706	Seat & Sidewall Cloth-Mishawaka Twist Taupe	
121708	Seat & Sidewall Cloth-All Wool Twist-Gray (Use 124315)	
BO 121735	Button-Upholstery-Boucle	71 Bro-Sedan-3Cpe-VicCpe
BO 121736	Button-Upholstery-Mohair	71 Bro-Sedan-3Cpe-VicCpe
BO 121738	Button-Upholstery-Boucle	72 Bro-Sedan-3Cpe-VicCpe
BO 121746	Pull to Assembly-Front Door	75 Sedan-Cloth Trim
BO 121747	Pull to Assembly-Front Door & Folding Table	75 Bro-Cpe,77 Sed
M 121753	Imitation Seat Leather-Brown	
M 121755	Top Material-Brown & White	
BO 121757	Binding-5/8" Wire On	37 CvCpe-CvBro,89 CvCpe-CvBro
BO 121764	Shim-Front Fender to Cowl Panel	70,71,72,80,81,82,88
BO 121770	Silencer-Underbody Panel-Rear	37 thru 1947 All
BO 121771	Silencer-Rear Seat Tray to Frame	37 thru 1947 All
BO 121775	Pad-Tail Lamp	37 All,80 Cpe
BO 121782	Hinge Assy-Rear Compartment Door	37 thru 1940 Cpe-Cv Sed,1942 Sed-2 Sed-UCO
BO 121785	Cap-Steering Gear Jacket Tube Bracket	37-38-39-1940 exc 90,10,11,18,20,21,28,58,178,51-53-171-173-481-483-491-493-500-501-503 Without DI
C 121790	Molding-Frt End Panel Belt-RH	73 thru 77
C 121791	Molding-Frt End Panel Belt-LH (Pkg 1-2)	73 thru 77
C 121793	Mldg-Frt Door Outside Panel Belt-LH	73-74-75 Sedan
C 121794	Mldg-Frt Door Outside Panel Belt-RH	73-74-75 exc Sed
C 121795	Mldg-Frt Door Outside Panel Belt-LH	73-74-75 exc Sed
A 121798	Fender Assy-Rear RH-Pr	37 thru 39 Panel-Cab
A 121799	Fender Assy-Rear LH-Pr	37 thru 39 Panel-Cab

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 121801	Grille-Instrument Panel W/Shield Defroster	37 thru 39 All
121814	Tail Lamp Kit-RH-En (Use 121815)	70,71
BO 121815	Tail Lamp Kit-RH-Pr	70,71
BO 121822	Escutcheon Plate-Robe Rail Bracket	37 Hudson Sedan
BO 121827	Handle Assy-Trunk Lid-Less Cylinder	37 Bro-Sed 70 UCo,89 Bro-Sed-UCo
BO 121828	Lock Cyl-Front Door & Rear Compt (Use 206196)	37 All.38 thru 1940 Panel,89 Bro-Sed-UCo,1941-1942 All
F 121830	Handle & Lock Cyl Complete-Door Outside	37 All
F 121831	Handle Assy-Door Outside-Less Lock Cyl	37 All
F 121833	Handle Assy-Door Outside-LH Front	37 exc Station
F 121834	Handle Assy-Door Outside Rear	37 Sedan
BO 121836	Handle-Door Inside'	70,71,71B,72,78
BO 121837	Handle Assy-Door & Qtr Window Regulator	70,71,718,72,78
BO 121838	Escutcheon-Inside Handle	70,71,7113,72,78,80,81,82.83.88,90,91,98,20,21,28
121839	Handle Assy-Frt Door Wing Reg (Use 126688)	74 thru 77,73 CvCpe-CvBro
BO 121840	Handle-Door Inside	37 Hudson,20,21,28
BO 121841	Handle- Assy-Door & Qtr Window Regulator	37 Hudson
BO 121842	Escutcheon-Inside Handle	37 Hudson
BO 121843	Handle Assy-Frt Door Wing Regulator	72,71-72-78 Quarter Window
BO 121844	Handle Assy-Frt Door Wing Regulator	73 All,37 Hud Sed for Qtr Window
121845	Cyl & Keys Assy-Frt Door Handle (Use 206197)	37 All,89 Bro-Sed-UCo,1941-1942 All
121846	Use 206197	
121849	Air Cleaner Assy-Body (Use 208190)	37-38 Bro-Sed-Cpes,70-80,89 UCo-UCpe
C 121870	Trim Panel-Cowl Side-RH	70,71,7313,78 Cab-CabPu-Panel,78 Sed
C 121871	Trim Panel-Cowl Side-LH	70,71,738,78 Cab-CabPu-Panel,78 Sed
C 121891	Liner Assembly-Trunk Lid	37 Bro-Sed-UCo
C 121900	Scuff Plate-RH-F Door	71 Exc Sed,70-80 Co-Cpe-Station
C 121901	Scuff Plate-LH-F Door	71 exc Sed,70-80 Co-Cpe-Station
C 121908	Scuff Plate-Front Door-RH	71-80-81-90-91 Sed,70-78-80-88 Cab-CabPu-Panel
C 121909	Scuff Plate-Front Door-LH	71-80-81-90-91 Sed,70-78-80-88 Cab-CabPu-Panel
C 121910	Scuff Plate-Front Door-RH	72 Sedan
121911	Scuff Plate-Front Door-LH (Use 121909)	72 Sedan
121912	Scuff Plate-Front Door-RH (Use 121908)	73-74-75 Sedan
121913	Scuff Plate-Front Door-LH (Use 121909)	73-74-75 Sedan
C 121917	Scuff Plate-Front Door-LH	76-77 Sedan
BO 121920	Scuff Plate-Rear Door-RH	71-80-81-90-91-98 Sedan,80 Station
BO 121921	Scuff Plate-Rear Door-LH	71-80-81-90-91-98 Sedan,80 Station
BO 121922	Scuff Plate-Rear Door-RH	72 Sedan
BO 121923	Scuff Plate-Rear Door-LH	72 Sedan
BO 121924	Scuff Plate-Rear Door-RH	73-74-75 Sedan
BO 121925	Scuff Plate-Rear Door-LH	73-74-75 Sedan
BO 121929	Scuff Plate-Rear Door-LH	76-77 Sedan
C 121995	Headlining Assembly	70-78 Panel
C 122000	Trimboard Assy-Frt Door Window Finish Mldg	71 thru 75-89-90 thru 95 Sedan
C 122004	Trimboard Assy-Frt Door Window Finish Mldg	37 3Cpe-VicCpe-UCpe
C 122047	Cardboard-Door Panel	71 Bro-Cpe,70 UCo-UCpe,78 Sed,71B,73B
BO 122059	Brkt Assy-Qtr Panel Partition Board-LH	37 thru 1940 Cpe
BO 122087	Washer-Door Lock Remote Control Link	37 thru 39 All,40 Panel
BO 122155	Lens-Front Fender Lamp	37 All
BO 122158	Wire & Terminal Assy-Frt Fender Lamp-RH	37 All
BO 122159	Wire & Terminal Assy-Frt Fender Lamp-LH	37 All
BO 122169	Spring-Seat Back to Operating Rod Anti Rattle	37 thru 1947 Pivot Type Seats
BO 122172	Retainer-Gauge Glass Dial	37 All
BO 122173	Bezel-Gauge Glass Dial	37 All
BO 122174	Cushion-Gauge Glass Dial	37 All
BO 122175	Indicator Assy-Oil Pressure Gauge Signal	37 All
BO 122176	Indicator Assy-Generator Charge Signal	37 All
BO 122190	Pad-Front Fender Lamp Bracket	37 All
122193	Use 120080	
C 122198	Roof Bow	71-72-73-74-75 Bro,70 UCo
BO 122205	Handle & Lock Cyl Comp-Rear Door Outside	37 thru 1940 Panel
BO 122206	Handle Assy-Rear Door Outside-Less Lock Cyl	37 thru 1940 Panel
BO 122218	Lower Brkt-Pass Seat Frame Support	37 thru 1942 Bucket Seats
C 122244	Header Assembly-Windshield	37 thru 1947 Cv
C 122250	Trimboard Complete-Front Door-RH	73 Bro-3Cpe-VicCpe
C 122251	Trimboard Complete-Front Door-LH	73 Bro-3Cpe-VicCpe
C 122252	Trimboard Complete-Front Door-RH	74 Bro-3Cpe-VicCpe,76 Sedan
C 122253	Trimboard Complete-Front Door-LH	74 Bro-3Cpe-VicCpe,76 Sedan
C 122254	Trimboard Complete-Front Door-RH	73 Sedan
C 122255	Trimboard Complete-Front Door-LH	73 Sedan
C 122256	Trimboard Complete-Front Door-RH	74 Sedan
C 122257	Trimboard Complete-Front Door-LH	74 Sedan
C 122258	Trimboard Complete-Rear Door-RH	73-74-76 Sedan
C 122259	Trimboard Complete-Rear Door-LH	73-74-76 Sedan

Part No.	Name	Models
C 122260	Trimboard Complete-Lower Quarter-RH	73-74 Bro
C 122261	Trimboard Complete-Lower Quarter-LH	73-74 Bro
C 122262	Trimboard Complete-Front Door-RH	71 Bro-Cpe
C 122263	Trimboard Complete-Front Door-LH	71 Bro-Cpe
C 122264	Trimboard Complete-Front Door-RH	71 Sed
C 122265	Trimboard Complete-Front Door-LH	71 Sed
C 122266	Trimboard Complete-Rear Door-RH	71 Sed
C 122267	Trimboard Complete-Rear Door-LH	71 Sed
C 122274	Trimboard Complete-Front Door-RH	75 Bro-Cpe,77 Sed
C 122275	Trimboard Complete-Front Door-LH	75 Bro-Cpe,77 Sed
C 122276	Trimboard Complete-Front Door-RH	75 Sedan
C 122277	Trimboard Complete-Front Door-LH	75 Sedan
C 122278	Trimboard Complete-Rear Door-RH	75 Sedan
C 122279	Trimboard Complete-Rear Door-LH	75 Sedan
C 122313	Back Complete-Front Seat-Cloth	71 Sedan
C 122314	Back Complete-Front Seat-Cloth	72 Sedan
C 122315	Back Complete-Front Seat-Cloth	73-74 Sedan
C 122316	Back Complete-Front Seat-Cloth	75 Sedan
C 122317	Back Complete-Front Seat-Cloth	76 Sedan
C 122318	Back Complete-Front Seat-Cloth	77 Sedan
C 122323	Cushion Complete-Front Seat	71 Sed-3Cpe,71B,73B
C 122324	Cushion Complete-Front Seat	72 Sed-3Cpe,78 Sed
C 122325	Cushion Complete-Front Seat	73-74-76 Sedan,73-74 3Cpe
C 122326	Cushion Complete-Front Seat	75-77 Sed,75 3Cpe
C 122333	Valance Assembly-Front Seat Back	71-72-78 Sed
C 122334	Back Complete-Rear Seat	71 Sedan
C 122335	Back Complete-Rear Seat	72-73-74,76 Sedan
C 122336	Back Complete-Rear Seat	75-77 Sedan
C 122340	Cushion Complete-Rear Seat	71 Sedan-Bro
C 122341	Cushion Complete-Rear Seat	72 Sedan-Bro
C 122342	Cushion Complete-Rear Seat	73-74 Sed-Bro,76 Sedan
C 122343	Cushion Complete-Rear Seat	75 Sed-Bro,77 Sed
C 122347	Back Complete-Front Seat-LHD	71 Bro-3Cpe-VicCpe
C 122351	Back Complete-Front Seat-LHD	72 thru 74 Bro-3Cpe-VicCpe
C 122352	Back Complete-Front Seat-RHD	72 thru 74 Bro-3Cpe-VicCpe
C 122353	Back Complete-Front Seat-LHD	75 Bro
C 122354	Back Complete-Front Seat-RHD	75 Bro
C 122357	Trim Assy-Front Seat Back-LH	71 Bro-3Cpe-VicCpe
C 122360	Trim Assy-Front Seat Back-RH	72 Bro,72-73-74 3Cpe-VicCpe
C 122361	Trim Assy-Front Seat Back-LH	72 Bro,72-73-74 3Cpe-VicCpe
C 122362	Trim Assy-Front Seat Back-RH	75 3Cpe-VicCpe
C 122363	Trim Assy-Front Seat Back-LH	75 3Cpe-VicCpe
C 122364	Cushion Complete-Front Seat	71 Bro-3Cpe-VicCpe,71B,73B,70 Cpe
C 122365	Cushion Complete-Front Seat	72 Bro-3Cpe-VicCpe
C 122366	Cushion Complete-Front Seat	73-74 Bro-3Cpe-VicCpe
C 122367	Cushion Complete-Front Seat	75 Bro 3Cpe-VicCpe
C 122368	Trim Assy-Front Seat Cushion	71 Bro-3Cpe-VicCpe,71B,73B
C 122369	Trim Assy-Front Seat Cushion	72 Bro-3Cpe-VicCpe
C 122370	Trim Assembly-Front Seat Cushion	73-74 Bro-3Cpe-VicCpe
C 122371	Trim Assembly-Front Seat Cushion	75 Bro-3Cpe-VicCpe
C 122372	Trim-Front Seat Back Panel-RH	71 thru 75 Bro-3Cpe-VicCpe,71B,73B
C 122373	Trim-Front Seat Back Panel-LH	71 thru 75 Bro-3Cpe-VicCpe,71B,73B
C 122376	Back Complete-Rear Seat	71 Bro
C 122377	Back Complete-Rear Seat	72-73-74 Bro
C 122378	Back Complete-Rear Seat	75 Bro
C 122382	Trimboard & Trim Assy-W/S Header	71 thru 74 exc Cv
C 122383	Trimboard & Trim Assy-W/S Header	75 exc 01,77
C 122466	Trimboard Complete-Front Door-RH	72 Bro-3Cpe,VicCpe
C 122467	Trimboard Complete-Front Door-LH	72 Bro-3Cpe,VicCpe
C 122468	Trimboard Complete-Front Door-RH	72 Sedan
C 122469	Trimboard Complete-Front Door-LH	72 Sedan
C 122470	Trimboard Complete-Rear Door-RH	72-73 Sedan
C 122471	Trimboard Complete-Rear Door-LH	72-73 Sedan
BO 122473	Windlace Assy-Frt Pillar & Side Header-LH	37 Bro,70 UCo
BO 122474	Windlace Assy-Frt Pillar & Side Header-RH	71 thru 75 Sedan
BO 122475	Windlace Assy-Frt Pillar & Side Header-LH	71 thru 75 Sedan
BO 122476	Windlace Assy-Frt Pillar & Side Header-RH	37 3Cpe-VicCpe,70 UCpe
BO 122477	Windlace Assy-Frt Pillar & Side Header-LH	37 3Cpe-VicCpe,70 UCpe
BO 122478	Windlace Assy Complete-Rear Pillar-RH	37-38 Bro,70-78 Cab-CabPu-Panel 80-89 UCo
BO 122479	Windlace Assy Complete-Rear Pillar-LH	37-38 Bro,70-78 Cab-CabPu-Panel 80-89 UCo
BO 122481	Windlace Assy Complete-Rear Pillar-LH	37 3Cpe-VicCpe,70-80 UCpe,89 VicCpe-3Cpe-UCpe
BO 122482	Windlace Assy Complete-Rear Pillar-RH	37 thru 1940 Sedan
BO 122483	Windlace Assy Complete-Rear Pillar-LH	37 thru 1940 Sedan
BO 122484	Windlace Assy-Center Pillar	37-38 Sedan
BO 122490	Carpet Assembly-Rear Floor	76 thru 78 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 122491	Back Complete-Front Seat-Passenger-LHD	71 Bro-3Cpe-VicCpe
C 122492	Back Complete-Front Seat-Passenger-RHD	71 Bro-3Cpe-VicCpe
C 122495	Back Complete-Front Seat-Passenger-LHD	72-73-74 Bro-3Cpe-VicCpe
C 122496	Back Complete-Front Seat-Passenger-RHD	72-73-74 Bro-3Cpe-VicCpe
C 122497	Back Complete-Front Seat-Passenger-LHD	75 Bro
C 122498	Back Complete-Front Seat-Passenger-RHD	75 Bro
BO 122522	Channel Assy-Door Window Glass-RH Rear	37 thru 1940 Cv
BO 122523	Channel Assy-Door Window Glass-LH Rear	37 thru 1940 Cv
BO 122524	Stop-Door Window Glass-Upper	37 thru 1947 Cv
BO 122525	Bracket-Top Hold Down Clamp Body	37 thru 1947 Cv
*SP 122528	Blade-Windshield Cleaner-Molded Type-8-1/4"	30 thru 36 All,1937 thru 1947 Cv
BO 122529	Sleeve-Windshield Cleaner Guide	37-38 All
122531	Blade Assembly-Windshield Cleaner (Use 122528).	37 thru 39 Cv
BO 122532	Arm & Spring Assy-W/Shield Cleaner	37 thru 1940 Cv
BO 122533	Tubing-Windshield Cleaner	37 thru 1940 With Comb Pump
BO 122538	Brkt-Rear Body Pillar to Underbody	1937 thru 1947 Cv
C 122554	Finish Molding-Door Window-RH	71 Cv
C 122558	Finish Molding-Door Window-RH	73 thru 75-83 thru 85-93-95 Cv
BO 122587	Bracket-Rear Compt Floor Board Riser-Front	37-38 Cpe-Rear Mount 1939-1940 Cv
122596	Door Assembly-RH (Use 122598)	71 Cv
C 122598	Door Assembly-RH	72 thru 75 Cv
BO 122612	Visor-Hinge Type-RH-Kit	37 All
BZ 122614	Ornament-Front Fender-Kit-Pair	37 All
A 122616	Finish Plate-Rear Fender-RH	37-38 All
A 122617	Finish Plate-Rear Fender-LH	37-38 All
BO 122618	Ornament-Rear Fender Finish Plate-Kit	37 Hud,83-84-85 Cpe-Cv
C 122623	Frame & Back Complete-F Seat Cushion-LHD	71 Bro-VicCpe
BO 122625	Weatherstrip-Windshield	37 thru 39 Cv
122630	Housing Assy-Hdlmp-Black En-RH (Use 121000)	70,71,72,73B,78
BO 122631	Housing Assy-Hdlmp-Black En-LH	70,71,72,73B,78
BO 122632	Housing Assy-Hdlmp-Black-En-RH	73 thru 77
BO 122633	Housing Assy-Hdlmp-Black En-LH	73 thru 77
C 122643	Frame & Back Comp-F Seat Cushion-LHD	72-73-74 Bro-VicCpe
C 122668	Back Complete-Front Seat-Leather	71-72 Sedan
C 122669	Back Complete-Front Seat-Leather	73-74 Sedan
C 122670	Back Complete-Front Seat-Leather	75 Sedan
C 122671	Back Complete-Front Seat-Leather	'76 Sedan
C 122672	Back Complete-Front Seat-Leather	77 Sedan
C 122673	Trim Assy-Front Seat Back-Leather	37 Sedan
C 122674	Cushion Complete-Front Seat-Leather	71-72-78 Sedan
C 122675	Cushion Complete-Front Seat-Leather	73 thru 77 Sedan
C 122676	Trim Assy-Front Seat Cushion-Leather	37 Sedan
C 122677	Trim Assy-Front Seat Back Panel-Leather	71 thru 75 Sedan
C 122678	Trim Assy-Front Seat Back Panel-Leather	76-77 Sedan
C 122679	Back Complete-Rear Seat-Leather	37 Sedan
C 122680	Trim Assy-Rear Seat Back-Leather	71-72 Bro-Sedan
C 122681	Cushion Complete-Rear Seat-Leather	37 Hudson Sedan-Bro
C 122682	Cushion Complete-Rear Seat-Leather	37 Hudson Sedan-Bro
C 122683	Trim Assy-Rear Seat Cushion-Leather	37 Cv,38 CvCpe
BO 122703	Brkt-Folding Top Front Corner-LH	1937 thru 1940 Cv
C 122705	Header Rail-Folding Top Front	36-37 All
BO 122709	Threaded Bushing-Headlamp Lens Locking Screw	37 thru 1940 exc Sed-Cab-CabPu-Panel
122710	Weatherstrip-Door Opening (Use 122712)	
122711	Use 122712	71 thru 75,80 thru 85,89,90 thru 95Sed,40 thru 45
BO 122712	Weatherstrip-Door Opening	Sed
122713	Use 122712	
122716	Use 123688	
122717	Use 123689	
122718	Weatherstrip-Door Opening (Use 122736)	37 thru 1940 Cab-CabPu-Panel
122719	Weatherstrip-Door Opening (Use 122736)	
C 122721	Panel Assembly-Top Front Header Rail	37 thru 1947 Cv
BO 122736	Weatherstrip-Door Opening	37 thru 39 Station,37 Panel
122737	Use 122736	
BO 122745	Bracket Assy-Rear Seat Tray Partition	70-80 UCpe,90 thru 95 3Cpe,1940 All,1941-1942 VicCpe-CvSed.1946-1947 CvBro-ClubCpe
BZ 122754	Plate-Inside Tire Carrier Clamp	37 thru 1939 UCpe,1940 thru 1947 All
BO 122756	Riser Assembly-Rear Seat Cushion	37 CvBro
BO 122758	Clip-Wiring	37 thru 1940 All
BO 122798	Weatherstrip-Body Hinge Pillar-RH	37-38 Cv
BO 122799	Weatherstrip-Body Hinge Pillar-LH	1937-1938 Cv
122828	Clamp Assy-Top Hold Down-Ends (Use 136331)	37-38 CvCpe-CvBro
BO 122829	Handle-Top Hold Down Clamp	37 thru 39 Cv
BO 122850	Pillar-Folding Top-RH	37 thru 39 Cv,1940 CvSed
BO 122851	Pillar-Folding Top-LH	37 thru 39 Cv,1940 CvSed

Part No.	Name	Models
BO 122880	Cover Plate-Locker Box Door Clock Opening	73,74,75,76,77
C 122887	Back Complete-Drivers Seat-LHD	70 UCo-UCpe
C 122889	Cushion Complete-Driver Seat-LHD	70 UCo-UCpe
C 122890	Cushion Complete-Driver Seat-RHD	70 UCo-UCpe
C 122893	Back Complete-Passenger Seat-LHD	70 UCo-UCpe
BO 122894	Back Complete-Passenger Seat-RHD	70 UCo-UCpe
C 122895	Cushion Assembly-Passenger Seat-LHD	70 UCo-UCpe
C 122896	Cushion Assembly-Passenger Seat-RHD	70 UCo-UCpe
C 122898	Back Complete-Rear Seat	70 UCo
C 122899	Cushion Complete-Rear Seat	70 UCo
C 122918	Trimboard & Trim Assy-F Door Rear Pillar-RH	70 Panel
C 122919	Trimboard & Trim Assy-F Door Rear Pillar-LH	70 Panel
BO 122920	Carpet Assy-Rear Floor	37 VicCpe
BO 122922	Clip-Carburetor Choke Wire	70,71,71B,78,89,90,91,92,98 RHD,90,98
BO 122924	Heating Element-Cigar Lighter	37-38 All
C 122925	Trimboard & Trim Assy-Rear Back Panel-Upper	70-78 Cab-CabPu
C 122926	Trimboard & Trim Assy-Rear Back Panel-RH Side	70-78 Cab-CabPu
C 122927	Trimboard & Trim Assy-Rear Back Panel-LH Side	70-78 Cab-CabPu
C 122928	Trimboard & Trim Assy-RH-Side	70-78 Cab-CabPu
C 122929	Trimboard & Trim Assy-LH-Side	70-78 Cab-CabPu
C 122930	Trimboard & Trim Assy-Rear Back Panel-Lower..	70-78 Cab-CabPu
C 122932	Back Complete-Front Seat	70-78 Cab-CabPu
C 122933	Trim Assembly-Front Seat Back	37 thru 1947 Cab-CabPu
C 122934	Cushion Complete-Front Seat	37 thru 1947 Cab-CabPu
C 122935	Trim Assembly-Front Seat Cushion	37 thru 1947 Cab-CabPu
C 122936	Windlace Assy-Frt Pillar & Side Header-RH	70-78 Cab-CabPu
C 122937	Windlace Assy-Frt Pillar & Side Header-LH	70-78 Cab-CabPu
C 122938	Trimboard Complete-F Door-Leather-RH	70-78 Cab-CabPu-Panel
C 122939	Trimboard Complete-F Door-Leather-LH	70-78 Cab-CabPu-Panel
C 122940	Door Complete-Front	70-78 Cab-CabPu-Panel
C 122941	Door Complete-Front	70-78 Cab-CabPu-Panel
C 122942	Trimstick & Trim Assy-Frt Body Plr-RH	37 Bro-Sed-3Cpe-VicCpe,70 exc Station
C 122943	Trimstick & Trim Assy-Frt Body Plr-LH	37 Bro-Sed-3Cpe-VicCpe,70 exc Station
C 122944	Door Complete-RH	70 UCo
C 122945	Door Complete-LH	70 UCo
C 122947	Door Complete-Front-LH-Cloth Trim	70 UCo
C 122948	Door Complete-Front-RH-Cloth Trim	70 UCpe,71B
C 122949	Door Complete-Front-LH	70 UCpe,71B
BO 122968	Clip-Bonnet Hinge Rear	37-38 All
BO 122969	Gasket-Speedometer	37 All
C 123009	Scat Complete-Drivers-LH	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123010	Seat Complete-Drivers-RHD	37 thru 39 Panel,80 UCo-UCpe,89 UCo
C 123011	Back Complete-Drivers Seat-LHD	37 thru 39 Panel,80 UCo-UCpe,89 UCo
C 123012	Back Complete-Drivers Seat-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123013	Cushion Complete-Drivers Seat-LHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123014	Cushion Complete-Drivers Seat-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123015	Seat Complete-Passenger -LHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123016	Seat Complete-Passenger-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123017	Back Complete-Passenger Seat-LHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123018	Back Complete-Passenger Seat-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123019	Cushion Complete-Passenger Seat-LHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123020	Cushion Complete-Passenger Seat-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123022	Trim Assy-Front Seat Back-RH-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123023	Trim Assy-Front Seat Back-LH-LHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123024	Trim Assy-Front Cushion-RH-RHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123025	Trim Assy-Front Seat Cushion-LH-LHD	37 thru 1940 Panel,80 UCo-UCpe,89 UCo
C 123026	Trim-Frt Seat Back Panel-RH-RHD	37 thru 1940 Panel,70 UCo-UCpe,89-90-40 UCo, 39 Sed-2Sed,1942 UCo
C 123027	Trim-Frt Seat Back Panel-LH-LHD	37 thru 1940 Panel,70 UCo-UCpe 89-90-40 UCo, 39 Sed-2Sed,1942 UCo
BO 123028	Cradle Assy-Frt Door Wing-RH-Includes Glass	72-73-82-83 exc Cv
BO 123029	Cradle Assy-Frt Door Wing-LH-Includes Glass	72-73-82-83 exc Cv
BO 123032	Ornament Crest-Fender Guide	37 thru 1942 exc 10 DeL,1946-1947 All
BO 123058	Cradle Assy-Complete-F Door Wing-RH	72-73-82-83 Bro-Sed-3Cpe-VicCpe
BO 123059	Cradle Assy-Complete-F Door Wing-LH	72-73-82-83 Bro-Sed-3Cpe-VicCpe
BO 123060	Mirror-Rear View External	37 thru 1940 Cab-CabPu-Panel
BO 123061	Nut-External Mirror Attaching	37 thru 1940 Cab-CabPu-Panel
BO 123075	Pull to Assembly-Frt Door-Blue Leather	75 exc Sedan,77 Sedan
BO 123077	Pull to Assembly-Frt Door-Taupe Leather	75 exc Sed,77 Sed,38 Table Equipped Sedan
BO 123078	Spacer-Running Board Panel to Frame Bracket	37 thru 39 All
BO 123083	Molding-Quarter Panel Belt	73-74-75 Cv
C 123090	Spring-Seat Cushion	37 thru 1947 Cab-CabPu
C 123091	Spring-Seat Back	37 thru 1947 Cab-CabPu
BO 123113	Mirror Assy-External Rear View-Less Arm	37 thru 1940 Cab-CabPu-Panel

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	Use 124264	
C 123128	Door Assy-Deck-Lac	70 UCpe
	123133 Weatherstrip-Deck Door (Use 121262)	37-38 Bro-Sed-UCo
BO 123135	Bezel-Locker Box Clock-3 Tone	73 thru 77
C 123202	Trimboard Complete-Frt Door-RH-Leather	71 Bro-VicCpe-3Cpe
C 123203	Trimboard Complete-Frt Door-LH-Leather	71 Bro-VicCpe-3Cpe
C 123204	Trimboard Complete-Rear Door-RH-Leather	71 Sedan
C 123206	Trimboard Complete-Frt Door-RH-Leather	72 Bro-3Cpe-VicCpe
C 123207	Trimboard Complete-Frt Door-LH-Leather	72 Bro-3Cpe-VicCpe
C 123208	Trimboard Complete-Frt Door-RH-Leather	72 Sedan
C 123209	Trimboard Complete-Frt Door-LH-Leather	72 Sedan
C 123210	Trimboard Complete-Rear Door-RH-Leather	72 Sedan
C 123211	Trimboard Complete-Rear Door-LH-Leather	72 Sedan
C 123212	Trimboard Complete-Rear Door-RH-Leather	73 Bro-3Cpe-VicCpe
C 123213	Trimboard Complete-Frt Door-LH-Leather	73 Bro-3Cpe-VicCpe
C 123214	Trimboard Complete-Frt Door-RH-Leather	73 Sedan
C 123215	Trimboard Complete-Frt Door-LH-Leather	73 Sedan
C 123216	Trimboard Complete-Rear Door-RH-Leather	73-74-75-76 Sedan
C 123217	Trimboard Complete-Rear Door-LH-Leather	73-74-75-76 Sedan
C 123218	Trimboard Complete-Front Door-RH-Leather	74 Bro-3Cpe-VicCpe,76 Sedan
C 123219	Trimboard Complete-Front Door-LH-Leather	74 Bro-3Cpe-VicCpe,76 Sedan
C 123220	Trimboard Complete-Front Door-RH-Leather	74 Sedan
C 123221	Trimboard Complete-Front Door-LH-Leather	74 Sedan
C 123222	Trimboard Complete-Front Door-RH-Leather	75 Bro-3Cpe-VicCpe,76-77 Sedan
C 123223	Trimboard Complete-Front Door-LH-Leather	75 Bro-3Cpe-VicCpe,76-77 Sedan
C 123224	Trimboard Complete-Front Door-RH-Leather	74-75 Sedan
C 123225	Trimboard Complete-Front Door-LH-Leather	74-75 Sedan
C 123226	Trimboard Complete-Rear Door-RH-Leather	71 thru 77 Sedan
C 123227	Trimboard Complete-Rear Door-LH-Leather	71 thru 77 Sedan
C 123237	Back Complete-Front Seat-Drivers-LHD	75 3Cpe-VicCpe
C 123238	Back Complete-Front Seat-Drivers-RHD	75 3Cpe-VicCpe
C 123239	Back Complete-Front Seat-Passenger-LHD	75 3Cpe-VicCpe
C 123240	Back Complete-Front Seat-Passenger-RHD	75 3Cpe-VicCpe
	123369 Lock Catch-Folding Table (Use 124416)	37 Table Equipped Sedan
	123370 Lock Assy-Folding Table & Locker Box Door (Use 208599)	37 Sed Table,70-71-78 Locker Box Door
BO 123397	Reinf-Quarter Window Curtain-Front	37 CvBro
BO 123402	Stud-Pick up Box Roller	37 thru 1940 Cpe
BO 123405	Spacer-Seat and Pick up Box	37 thru 1947 All,1948-1949-1950 exc CvBro
BO 123414	Bracket-Pick up Box	37 thru 1940 UCpe
BO 123415	Roller Assy-Pick up Box	37 thru 1940 UCpe
BO 123416	Pin-Pick up Box Lock	37 thru 39 UCpe
A 123424	Splash Guard Assy-Rear-Enamel	70 UCpe
BO 123425	Tail & Stop Lamp Complete-Six Volt	37-38 UCpe exc 89
BO 123470	Weatherseal-Folding Pillar Cover Bottom-RH	1937 thru 1947 Cv
BO 123471	Weatherseal-Folding Pillar Cover Bottom-LH	1937 thru 1947 Cv
BO 123476	Side Arm #2-Top-RH	37 thru 39 CvCpe
BO 123477	Side Arm #2-Top-LH	37 thru 39 CvCpe
C 123500	Glass & Frame Assy-Quarter Wdo-RH-Plate	37 thru 39 CvBro,1940 CvSed
C 123501	Glass & Frame Assy-Quarter Wdo-LH-Plate	37 thru 39 CvBro,1940 CvSed
C 123502	Glass & Frame Assy-Quarter Wdo-RH-Safety	37 thru 39 CvBro,1940 CvSed
C 123503	Glass & Frame Assy-Quarter Wdo-LH-Safety	37 thru 39 CvBro,1940 CvSed
BO 123514	Cushion-Front Door Wing	72-73-82-83-92-93 exc Cv,1940 thru 1942 exc Cv, 51-171 exc CvBro,53,58,173,178
BO 123520	Clock Assy-Locker Box Door	75,77
BO 123528	Headlamp Complete-Prime-RH-12 Volt	70,71,72,73
BO 123540	Lamp Assy-Front Fender-RH-12 Volt	74,75,76,77
BO 123542	Tail & Stop Lamp Complete-En-12 Volt	71,72,7313,78 Sed,70 UCo-Cpe
BO 123545	Tail & Stop Lamp Complete-Lac-12 Volt	37 Hudson
BO 123546	Lamp Assy-Rear License-En-12 Volt	37-38 All,39 CvCpe-CvBro-3Cpe-VicCpe
BO 123547	Lamp Assy-Rear License-Lac-12 Volt	37-38 All,39 CvCpe-CvBro-3Cpe-VicCpe,40T Cpe
	123548 Tail & Stop Lamp Complete (Use 144731)	37-38 Cab-CabPu-Panel-Station
BO 123552	Bracket-Tail & Stop Lamp	70-80 UCpe
BO 123553	Body Assy-Tail & Stop Lamp	37 thru 1940 UCpe
	123560 Nozzle-Defroster-RH (Use 155707)	37 All
	123561 Nozzle-Defroster-LH (Use 155708)	37 All
BO 123563	Adapter-Swinging Stop Lamp	37 All
	123568 Retainer Assy-Qtr Wdo-RH (Use 136638)	37-38 CvBro
C 123580	Bow-Roof No. 4	37 Sedan
C 123585	Back Complete-Auxiliary Seat-LHD	71 VicCpe
C 123586	Back Complete-Auxiliary Seat-RHD	71 VicCpe
C 123589	Cushion Complete-Auxiliary Seat-LHD	71 VicCpe
C 123590	Cushion Complete-Auxiliary Seat-RHD	71 VicCpe
C 123593	Back Complete-Auxiliary Seat-LHD	72-73-74-75 VicCpe

Part No.	Name	Models
C 123594	Back Complete-Auxiliary Seat-RHD	72-73-74-75 VicCpe
C 123597	Cushion Complete-Auxiliary Seat-LHD	72-73-74-75 VicCpe
C 123598	Cushion Complete-Auxiliary Seat-RHD	72-73-74-75 VicCpe
C 123601	Back Complete-Auxiliary Seat-LHD-Leather	37-38 VicCpe
C 123602	Back Complete-Auxiliary Seat-RHD-Leather	37-38 VicCpe
C 123603	Trim Assy-Aux Seat Back-LHD-Leather	37-38 VicCpe
C 123604	Trim Assy-Aux Seat Back-RHD-Leather	37-38 VicCpe
C 123605	Cushion Complete-Auxiliary Seat-LHD Leather	37-38 VicCpe
C 123606	Cushion Complete-Auxiliary Seat-RHD-Leather	37-38 VicCpe
C 123607	Trim Assy-Aux Seat Cushion-LHD-Leather	37-38 VicCpe
C 123608	Trim Assy-Aux Seat Cushion-RHD-Leather	37-38 VicCpe
C 123611	Body Assembly-LHD	71 CvBro
C 123612	Body Assembly-RHD	71 CvBro
C 123613	Body Assembly-LHD	72 CvBro
C 123614	Body Assembly-RHD	72 CvBro
C 123615	Body Assembly-LHD	73-74-75 CvBro
C 123616	Body Assembly-RHD	73-74-75 CvBro
BO 123660	Latch Assy-Rear Door Lock	70-78 Panel
C 123673	Finish Mldg Assy-F Door Wdo LH-Two Tone	73-74 Bro,76 Sedan
BO 123688	W/Strip-Front Door Opening-Lower-RH	37 thru 1940 All
BO 123689	W/Strip-Front Door Opening-Lower-LH	37 thru 1940 All
BO 123695	Bumper-Door	1937 thru 1947 Cv
C 123698	Top & Trim Assy-Folding Table	75-77 Sedan
C 123700	Top & Trim Assy-Folding Table	71-72-73-74-76 Sedan
C 123702	Back Complete-Front Seat-Cloth	75 Table Equipped Sedan
C 123704	Trim Panel-Front Seat Back	75 Table Equipped Sedan
C 123706	Back Complete-Front Seat-Cloth	77 Table Equipped Sedan
C 123708	Trim Panel-Front Seat Back	77 Table Equipped Sedan
BO 123717	Weatherstrip-Door Opening-Upper	37 thru 39 Cv
BO 123726	Trimboard & Trim Assy-Rear Compt Shelf	70 UCpe
BO 123727	Trim Assy-Rear Compt Partition	70 UCpe
C 123742	Door Assy-Rear RH	76-77-78 Sedan
BO 123747	Door Assy-Locker Box-LH	70-78 exc Station,71B,73B
BO 123751	Plate-Inside Carrier Wheel Attaching	37 thru 1942 UCpe,40T 3Cpe,1941-1942 UCpe
BO 123760	Frame-Rear Curtain Light-Inner	37 thru 1946 Cv
BO 123761	Frame-Rear Curtain Light-Outer	37 thru 1946 Cv
C 123763	Glass-Rear Curtain	1937 thru 1946 CvSed
BO 123764	Weatherstrip-Rear Curtain Light Glass	37 thru 1947 Cv,481-491-1950 CvBro
C 123769	Back Complete-Front Seat-Driver-LHD-Cloth	71B,73B,70 UCpe
C 123770	Back Complete-Front Seat-Driver-RHD-Cloth	71B,73B,70 UCpe
C 123773	Back Complete-Frt Seat-Passenger-LHD-Cloth	71B,73B,70 UCpe
C 123774	Back Complete-Frt Seat-Passenger-RHD-Cloth	71B,73B,70 UCpe
BO 123788	Pocket Assy-Control Lever Front Pillar	37 thru 39 With Elec Hand
BO 123789	Strap Assy-Control Lever Front Pillar	37 thru 39 With Elec Hand
C 123790	Trimstick Assy-Front Pillar-RH-LHD	71 thru 77 Bro-Sed-3Cpe-VicCpe
A 123803	Fender Assy-Without Lamp Holes-RHD	70-80 UCpe
C 123813	Back Complete-Front Seat-Drivers-LHD	71-72 Cv
C 123814	Back Complete-Front Seat-Drivers-RHD	71-72 Cv
C 123815	Back Complete-Front Seat-Drivers-LHD	73-74-75 Cv
C 123816	Back Complete-Front Seat-Drivers-RHD	73-74-75 Cv
C 123817	Back Complete-Front Seat-Passenger-LED	71-72 Cv
C 123818	Back Complete-Front Seat-Passenger-RHD	71-72 Cv
C 123819	Back Complete-Front Seat-Passenger-LHD	73-74-75 Cv
C 123820	Back Complete-Front Seat-Passenger-RHD	73-74-75 Cv
C 123821	Cushion Complete-Front Seat	71-72 Cv
C 123822	Trim Assy-Front Seat-RH	71-72 Cv
C 123823	Trim Assy-Front Seat-LH	71-72 Cv
C 123826	Cushion Complete Front Seat	73-74-75 Cv
C 123827	Trim Assy-Front Seat Cushion	37 Cv
C 123830	Back Complete-Rear Scat	71-72 CvBro
C 123831	Back Complete-Rear Seat	73-74-75 CvBro
C 123832	Trim Assy-Rear Seat Back	71-72 CvBro
C 123833	Trim Assy-Rear Seat Back	73-74-75 CvBro
C 123834	Cushion Complete-Rear Seat	71-72 CvBro
C 123835	Cushion Complete-Rear Seat	73-74-75 CvBro
C 123836	Trim Assy-Rear Seat Cushion	37 CvBro
C 123850	Top Complete-Trimmed	37-38 CvCpe
C 123853	Deck & Side Quarter Assy-Top	37-38 CvCpe,92-93-95 CvCpe
C 123856	Pad Assy-Top Quarter-RH	37-38 CvCpe,92-93-95 CvCpe
C 123857	Pad Assy-Top Quarter-LH	37-38 CvCpe,92-93-95 CvCpe
C 123858	Back Stay Assy-Top-RH	37-38 CvCpe,92-93-95 CvCpe
C 123859	Back Stay Assy-Top-LH	37-38 CvCpe,92-93-95 CvCpe
C 123865	Dust Boot Assy-Top	37-38 CvCpe,92-93-95 CvCpe
C 123870	Weatherseal Flap Assy-Top Side Quarter-RH	37 Cv,38 CvCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 123871	Weatherseal Flap Assy-Top Side Quarter-LH	37 Cv,38 CvCpe
C 123872	Bag Assy-Top Dust Boot	37 thru 1940 CvCpe
123924	Use 121641	
C 123960	Top Complete	37 CvBro
BO 123961	Rear Curtain & Window Complete-Top	37 CvBro
C 123963	Top Deck & Side Quarter A ssy	37 CvBro
C 123970	Stay Assy-Top Back-RH	37 CvBro
C 123971	Stay Assy-Top Back-LH	37 CvBro
C 123973	Dust Boot Assy-Top	37 CvBro
C 123974	Window & Curtain Assy-Rear Quarter-RH	37 CvBro
C 123975	Window & Curtain Assy-Rear Quarter-LH	37 CvBro
C 123976	Bag Assy-Top Dust Boot	37 CvBro
BZ 123988	Welt-Running Board to Fender	78
123989	Spring-Dr Lock Remote Control (Use 136087)	37-38 Exc Station
BO 123997	Spring-Frt Seat Track Lock Rod Anti Rattle	37-38 Sed-3Cpe-BCpe,40T 3Cpe,1939 thru
C 124025	Back Complete-Front Seat	71 Sedan With Folding Table
C 124026	Back Complete-Front Seat	72 Sedan With Folding Table
C 124027	Back Complete-Front Seat	73-74 Sedan With Folding Table
C 124028	Back Complete-Front Seat	76 Sedan With Folding Table
BO 124058	Lens-Fog Lamp	All
124059	Fastener-Grille Cover (Use 136831).	36 thru 38 All
C 124060	Trimboard Complete-Front Door-RH	71 Cv
C 124061	Trimboard Complete-Front Door-LH	71 Cv
C 124062	Trimboard Complete-Front Door-RH	72 thru 75 Cv
C 124063	Trimboard Complete-Front Door-LH	72 thru 75 Cv
C 124064	Trimboard Complete-Quarter-RH	71 CvBro
C 124065	Trimboard Complete-Quarter-LH	71 CvBro
C 124066	Trimboard Complete-Quarter-RH	72 thru 75 CvBro
C 124067	Trimboard Complete-Quarter-LH	72 thru 75 CvBro
C 124068	Door Complete-Front-RH	71 Cv
C 124069	Door Complete-Front-LH	71 Cv
C 124070	Door Complete-Front-RH	72 Cv
C 124071	Door Complete-Front-LH	72 Cv
C 124072	Door Complete-Front-RH	73-74 Cv
C 124073	Door Complete-Front-LH	73-74 Cv
C 124074	Door Complete-Front-RH	75 Cv
C 124075	Door Complete-Front-LH	75 Cv
BO 124078	Ornament & Name Plate Assy-Radiator	73
BO 124080	Catch-Locker Box Door Lock	70 thru 78,80 thru 88,90,91,92
BO 124081	Spring-Door Lock Bolt	37 thru 39 All
F 124082	Lens-Headlamp	73 thru 77
124083	Lens-Headlamp (Use 120999)	37 Hudson (Export)
C 124096	Trimboard Complete-Frt Door-RH-Leather	71 Bro-3Cpe-VicCpe
C 124097	Trimboard Complete-Frt Door-LH-Leather	71 Bro-3Cpe-VicCpe
C 124098	Trimboard Complete-Frt Door-RH-Leather	71 Sedan
C 124099	Trimboard Complete-Frt Door-LH-Leather	71 Sedan
C 124100	Trimboard Complete-Frt Door-RH-Leather	72-73 Bro-3Cpe-VicCpe
C 124101	Trimboard Complete-Frt Door-LH-Leather	72-73 Bro-3Cpe-VicCpe
C 124102	Trimboard Complete-Frt Door-RH-Leather	72-73 Sedan
C 124103	Trimboard Complete-Frt Door-LH-Leather	72-73 Sedan
C 124104	Door Complete-Frt-RH-Leather	71 Bro,78 Sed
C 124105	Door Complete-Frt-LH-Leather	71 Bro,78 Sed
C 124106	Door Complete-Frt-RH-Leather	71 3Cpe-VicCpe
C 124107	Door Complete-Frt-LH-Leather	71 3Cpe-VicCpe
C 124109	Door Complete-Frt-LH-Leather	71 Sedan
C 124110	Door Complete-Rear-RH-Leather	71-78 Sedan
C 124111	Door Complete-Rear-LH-Leather	71-78 Sedan
C 124112	Door Complete-Front-RH-Leather	72 Bro
C 124113	Door Complete-Front-LH-Leather	72 Bro
C 124114	Door Complete-Front-RH-Leather	72 3Cpe-VicCpe
C 124115	Door Complete-Front-LH-Leather	72 3Cpe-VicCpe
C 124116	Door Complete-Front-RH-Leather	72 Sedan
C 124117	Door Complete-Front-LH-Leather	72 Sedan
C 124118	Door Complete-Rear-RH-Leather	72 Sedan
C 124119	Door Complete-Rear-LH-Leather	72 Sedan
C 124120	Door Complete-Front-RH-Leather	73 Bro
C 124121	Door Complete-Front-LH-Leather	73 Bro
C 124122	Door Complete-Front-RH-Leather	73 3Cpe-VicCpe
C 124123	Door Complete-Front-LH-Leather	73 3Cpe-VicCpe
C 124124	Door Complete-Front-RH-Leather	73 Sedan
C 124125	Door Complete-Front-LH-Leather	73 Sedan
C 124126	Door Complete-Rear-RH-Leather	73-74-76 Sedan
C 124127	Door Complete-Rear-LH-Leather	73-74-76 Sedan
C 124128	Door Complete-Front-RH-Leather	74 Bro,76 Sedan

Part No.	Name	Models
C 124129	Door Complete-Front-RH-Leather	74 Bro,76 Sedan
C 124130	Door Complete-Front-RH-Leather	74 3Cpe-VicCpe
C 124131	Door Complete-Front-LH-Leather	74 3Cpe-VicCpe
C 124132	Door Complete-Front-RH-Leather	74 Sedan
C 124133	Door Complete-Front-LH-Leather	74 Sedan
C 124148	Trimboard Complete-F Door-RH	73 Sedan
C 124149	Trimboard Complete-F Door-LH	73 Sedan
C 124185	Back Complete-Rear Seat	70 UCo
C 124194	Door Complete-Front-RH-Cloth	73B
C 124195	Door Complete-Front-LH-Cloth	73B
C 124196	Door Complete-Front-RH-Leather	73B
C 124197	Door Complete-Front-LH-Leather	73B
C 124198	Door Complete-Front-RH-Leather	71B,70 UCpe
C 124199	Door Complete-Front-LH-Leather	71B,70 UCpe
C 124200	Door Complete-Front-RH-Leather	70 UCo
C 124201	Door Complete-Front-LH-Leather	70 UCo
C 124217	Cushion Complete-Rear-Seat	70 UCo
124223	Fender Assy-Frt-LH-Less Well (Use 120479)	73B
BO 124258	Spacer-Rear Body Pillar Brkt Body Bolt-Thin	37 thru 1942 Cv
BO 124259	Spacer-Rear Body Pillar Brkt Body Bolt-Thick	37 thru 1942 Cv
BO 124260	Arm Assy-Rear Compt Door Check	37-38 Bro-Sed-UCo
BO 124263	Arm-Rear Compt Door Check-Lower	37-38 Bro-Sed-UCo
BO 124264	Arm Assy-Rear Compt Door Check-RH	37 thru 1940 UCpe
BO 124267	Arm-Rear Compt Door Check-Lower-LH	37 thru 1940 Cpe,37 thru 1940 CvBro-CvSed
BO 124270	Arm-Rear Compt-Door Check-Upper	37 thru 1940 Cpe,37 thru 1940 CvBro-CvSed
124272	Use 124399	
C 124286	Door Complete-Front-RH-Complete-Cloth	75 Bro,77 Sed
C 124287	Door Complete-Front-LH-Complete-Cloth	75 Bro,77 Sed
C 124288	Door Complete-Front-RH-Complete-Cloth	75 Sedan
C 124289	Door Complete-Front-LH-Complete-Cloth	75 Sedan
C 124290	Door Complete-Front-RH-Complete-Cloth	75 3Cpe-VicCpe
C 124291	Door Complete-Front-LH-Complete-Cloth	75 3Cpe-VicCpe
C 124293	Door Complete-Rear-LH-Complete-Cloth	75-77 Sedan
C 124328	Kick Pad Assy-Front Seat-RH	73B
C 124329	Kick Pad Assy-Front Seat-LH	73B
C 124330	Kick Pad Assy-Front Seat-Center	73B
124342	Use 120106	
124343	Use 120107	
BO 124361	Bracket-Rear Compartment Partition	71 thru 75-81 thru 89 3Cpe,71B,73B
C 124366	Trimboard & Trim Assy-Auxiliary Seat Back	37 thru 39 CvCpe
C 124367	Seat Complete-Auxiliary Seat	37 thru 39 CvCpe
C 124368	Back Complete-Auxiliary Seat	37 thru 39 CvCpe
C 124369	Trim Assy-Auxiliary Seat Back	37 thru 39 CvCpe
C 124370	Cushion Complete-Auxiliary Seat	37 thru 39 CvCpe
C 124371	Trim Assy-Auxiliary Seat Cushion	37 thru 39 CvCpe
BZ 124380	Flexible Shaft Assy-Speedometer	70 thru 78
BO 124381	Core-Speedometer Flexible Shaft	70 thru 78
C 124385	Back Complete-Front Seat	71 3Cpe,71B,73B
C 124386	Back Complete-Front Seat	72-73-74 3Cpe
C 124387	Back Complete-Front Seat	75 3Cpe
C 124388	Back Assy-Front Seat	71 thru 75 3Cpe
C 124389	Trim Assy-Front Seat Back Panel-Cloth	71 thru 75 3Cpe
C 124390	Trimboard & Trim Assy-Quarter-RH-Cloth	71 thru 75 3Cpe,71B,73B
C 124391	Trimboard & Trim Assy-Quarter-LH-Cloth	71 thru 75 3Cpe,71B,73B
C 124392	Trimboard & Trim Assy-Quarter-RH-Leather	71 thru 75 3Cpe
C 124393	Trimboard & Trim Assy-Quarter-LH-Leather	71 thru 75 3Cpe
C 124394	Trimboard & Trim Assy-F Seat Compartment	71 thru 75 3Cpe-VicCpe,71B,73B
C 124395	Partition & Trimboard Assy-F Seat Compt	71 thru 75 3Cpe-VicCpe,71B,73B
C 124397	Trimboard & Trim Assy-F Seat	71 thru 74 3Cpe,71B,73B
C 124398	Trimboard & Trim Assy-Rear Wdo Header	75 3Cpe
BO 124399	Rivet-Rear Compt Door Check Arm to Bracket	37 thru 1940 All
124403	Cyl Assy-Locker Box Door Lock-Blank (Use 121503)	37 All,82 thru 87,88 Sed,90,91,92,98 Sed
BO 124416	Catch-Folding Table Top Lock	37-38 Sedan
C 124422	Back Complete-Rear Seat-Cloth	71 Bro
C 124423	Back Complete-Rear Seat-Cloth	72-73-74 Bro
C 124424	Back Complete-Rear Seat-Cloth	75 Bro
C 124425	Back Complete-Rear Seat-Leather	71 thru 75 Bro
C 124426	Back Complete-Rear Seat-Cloth	71 Sedan
C 124427	Back Complete-Rear Seat-Cloth	72-73-74-76-78 Sedan
C 124428	Back Complete-Rear Seat-Cloth	75-77 Sedan
C 124429	Back Complete-Rear Scat-Leather	71 thru 78 Sedan
C 124430	Cushion Complete-Rear Seat-Cloth	71 Bro
C 124431	Cushion Complete-Rear Seat-Cloth	72 Bro,78 Sed
C 124432	Cushion Complete-Rear Seat-Cloth	73-74 Bro-Sed,76 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 124433	Cushion Complete-Rear Seat-Cloth	75 Bro-Sed,77 Sedan
C 124434	Cushion Complete-Rear Seat-Leather	71-72 Bro-Sed,78 Sed
C 124435	Cushion Complete-Rear Seat-Leather	73-74-75 Bro-Sed,76-77 Sedan
C 124436	Back Complete-Rear Seat-Cloth	70 UCo
C 124437	Back Complete-Rear Seat-Leather	70 UCo
C 124438	Cushion Complete-Rear Seat-Cloth	70 UCo
C 124439	Cushion Complete-Rear Seat-Leather	70 UCo
124478	Use 124380	
C 124504	Bar Assy-Rear Bumper Frame-RH	70 thru 75,78
C 124505	Bar Assy-Rear Bumper Frame-LH	70 thru 75,78
BO 124508	Arm Rest Assy-Front Door-RH	73 thru 78 exc Cv,80-88 Sed,80 UCo-UCpe,81
BO 124509	Arm Rest Assy-Front Door-LH	73 thru 78 exc Cv,80-88 Sed,80 UCo-UCpe,81
C 124510	Arm Rest Assy-F Door-RH-Leather	73 thru 78,81,80-88 Sed,80 UCo-UCpe
C 124511	Arm Rest Assy-F Door-LH-Leather	73 thru 78,81,80-88 UCo-UCpe
C 124512	Molding-Hood Top Panel Belt-RH	73 thru 77
C 124528	Back Complete-Front Seat-Cloth	78 Sedan
C 124529	Back Complete-Front Seat-Leather	78. Sedan
A 124541	Hood Complete	73 thru 77
124548	Use 121922	
124549	Use 121923	
BO 124585	Cover Plate-Locker Box Door Clock Opening	73 thru 77 exc 73B
BO 124614	Lens-Locker Box Door Clock	70 thru 77
BO 124617	Socket Assy-Fender Lamp	37 All
BO 124618	Gasket-Fender	37 All
BO 124619	Retainer-Fender Lamp Lens	37 All
A 124620	Fender Assy-Rear-RH	37 thru 39 Station
A 124621	Fender Assy-Rear-LH	37 thru 39 Station
BO 124625	Retainer-Front End Panel Belt Molding	73 thru 77
C 124633	Mldg-Front Door Outside Panel Belt-LH	73-74-75 exc Sed,76-77 Sed
C 124634	Mldg-Rear Door Outside Panel Belt	73 thru 77 Sedan
C 124640	Mldg-Quarter Panel Belt-RH	73 thru 77 Sedan
C 124642	Retainer-Quarter Panel Belt Mldg-RH	73 thru 77 Sedan
BO 124649	Molding-Quarter Panel Belt-LH	73-74-75 Cv
BO 124650	Retainer-Quarter Panel Belt Molding-RH	73-74-75 Cv
BO 124658	Retainer-Headlamp Reflector	70 thru 78
BO 124659	Retainer-Headlamp Reflector Guide	70 thru 78
BO 124670	Glass Dial-Speedometer-Miles	73 thru 77
BO 124672	Retainer-Speedometer Glass Dial	73 thru 77
BO 124673	Bezel-Speedometer Glass Dial	73 thru 77
C 124674	Gauge Assy-Gas & Water Temperature	73 thru 77
BO 124684	Clock Assy-Locker Box Door-LHD-12 Volt	73 thru 77
BO 124685	Indicator Assy-Oil Pressure Signal	73 thru 77 exc 73B
BO 124686	Indicator Assy-Gen Charge Signal	73 thru 77 exc 73B
C 124712	Door Complete-Front-RH-Cloth	73 Bro
C 124713	Door Complete-Front-LH-Cloth	73 Bro
C 124714	Door Complete-Front-RH-Leather	73 Bro
C 124715	Door Complete-Front-LH-Leather	73 Bro
C 124716	Door Complete-Front-RH-Cloth	73 Sedan
C 124717	Door Complete-Front-LH-Cloth	73 Sedan
C 124718	Door Complete-Front-RH-Leather	73 Sedan
C 124719	Door Complete-Front-LH-Leather	73 Sedan
C 124720	Door Complete-Front-RH-Cloth	73 3Cpe-VicCpe
C 124721	Door Complete-Front-LH-Cloth	73 3Cpe-VicCpe
C 124722	Door Complete-Front-RH-Leather	73 3Cpe-VicCpe
C 124723	Door Complete-Front-LH-Leather	73 3Cpe-VicCpe
C 124724	Door Complete-Front-RH	73-74 Cv
C 124725	Door Complete-Front-LH	73-74 Cv
C 124726	Door Complete-Front-RH-Cloth	74 Bro,76 Sedan
C 124727	Door Complete-Front-LH-Cloth	74 Bro,76 Sedan
C 124728	Door Complete-Front-RH-Leather	74 Bro,76 Sedan
C 124729	Door Complete-Front-LH-Leather	74 Bro,76 Sedan
C 124730	Door Complete-Front-RH-Cloth	74 Sedan
C 124731	Door Complete-Front-LH-Cloth	74 Sedan
C 124732	Door Complete-Front-RH-Leather	74 Sedan
C 124733	Door Complete-Front-LH-Leather	74 Sedan
C 124734	Door Complete-Front-RH-Cloth	74 3Cpe-VicCpe
C 124735	Door Complete-Front-LH-Cloth	74 3Cpe-VicCpe
C 124736	Door Complete-Front-RH-Leather	74 3Cpe-VicCpe
C 124737	Door Complete-Front-LH-Leather	74 3Cpe-VicCpe
C 124738	Door Complete-Front-RH-Cloth	75 Bro,77 Sedan
C 124739	Door Complete-Front-LH-Cloth	75 Bro,77 Sedan
C 124740	Door Complete-Front-RH-Leather	75 Bro,77 Sedan
C 124741	Door Complete-Front-LH-Leather	75 Bro,77 Sedan
C 124742	Door Complete-Front-RH-Cloth	75 Sedan

Part No.	Name	Models
C 124743	Door Complete-Front-LH-Cloth	75 Sedan
C 124744	Door Complete-Front-RH-Leather	75 Sedan
C 124745	Door Complete-Front-LH-Leather	75 Sedan
C 124746	Door Complete-Front-RH-Cloth	75 3Cpe-VicCpe
C 124747	Door Complete-Front-LH-Cloth	75 3Cpe-VicCpe
C 124748	Door Complete-Front-RH-Leather	75 3Cpe-VicCpe
C 124749	Door Complete-Front-LH-Leather	75 Cpe-VicCpe
C 124750	Door Complete-Front-RH	75 Cv
C 124751	Door Complete-Front-LH	75 Cv
C 124752	Trimboard Complete-Front Door-RH-Cloth	73 Bro-3Cpe-VicCpe
C 124753	Trimboard Complete-Front Door-LH-Cloth	73 Bro-3Cpe-VicCpe
C 124754	Trimboard Complete-Front Door-RH-Leather	73 Bro-3Cpe-VicCpe
C 124755	Trimboard Complete-Front Door-LH-Leather	73 Bro-3Cpe-VicCpe
C 124756	Trimboard Complete-Front Door-RH-Cloth	73 Sedan
C 124757	Trimboard Complete-Front Door-LH-Cloth	73 Sedan
C 124758	Trimboard Complete-Front Door-RH-Leather	73 Sedan
C 124759	Trimboard Complete-Front Door-LH-Leather	73 Sedan
C 124760	Trimboard Complete-Front Door-RH	73-74-75 Cv
C 124761	Trimboard Complete-Front Door-LH	73-74-75 Cv
C 124762	Trimboard Complete-Front Door-RH-Cloth	74 Bro-3Cpe-VicCpe,76 Sed
C 124763	Trimboard Complete-Front Door-LH-Cloth	73 Bro-3Cpe-VicCpe,76 Sed
C 124764	Trimboard Complete-Front Door-RH-Cloth	74 Sedan
C 124765	Trimboard Complete-Front Door-LH-Cloth	74 Sedan
C 124766	Trimboard Complete-Front Door-RH-Leather	74-75 Bro-3Cpe-VicCpe,76-77 Sed
C 124767	Trimboard Complete-Front Door-LH-Leather	74-75 Bro-3Cpe-VicCpe,76-77 Sed
C 124768	Trimboard Complete-Front Door-RH-Leather	74-75 Sedan
C 124769	Trimboard Complete-Front Door-LH-Leather	74-75 Sedan
C 124770	Trimboard Complete-Front Door-RH-Cloth	75 Bro-3Cpe-VicCpe,77 Sedan
C 124771	Trimboard Complete-Front Door-LH-Cloth	75 Bro-3Cpe-VicCpe,77 Sedan
C 124772	Trimboard Complete-Front Door-RH-Cloth	75 Sedan
C 124773	Trimboard Complete-Front Door-LH-Cloth	75 Sedan
C 124778	Body Assy-Without Trunk-LHD	78 Sedan
C 124779	Body Assy-Without Trunk-RHD	78 Sedan
C 124781	Body Assy-With Trunk-LHD	78 Sedan
C 124782	Body Assy-With Trunk-RHD	78 Sedan
BO 124806	Rim-Headlamp	37 All 80,81,82,88
C 125030	Panel-Roof-Prime	82 thru 85 Bro-Sed,80 Co-Sed,89 Bro-Sed-UCo
C 125031	Panel Assy-Roof-Prime	87-88 Sedan
C 125035	Panel-Roof-Prime (Use 120035)	38-39 3Cpe-VicCpe-UCpe
C 125072	Panel-Quarter-RH	81 RHD Bro,82 Bro
C 125073	Panel-Quarter-LH	81-82 Bro
C 125074	Panel-Quarter-RH	80-89 UCo
C 125080	Panel-Quarter-RH	80-81 RHD Sed,82-88 Sed
C 125081	Panel-Quarter-LH	80-81-82-88 Sedan
C 125084	Panel Assy-Quarter-RH-Prime	83-84-85-89 Bro
C 125092	Panel Assy-Quarter-RH-Prime	80-83-84-85-87 Sedan
C 125130	Panel Assy-Quarter-RH-Prime	81-82 Bro
C 125131	Panel Assy-Quarter-LH-Prime	81-82 Bro
C 125145	Extension-Underbody Panel-LH (Use 120065)	38-39 exc Cv
A 125180	Splash Guard-Rear	81 thru 87,80 Co-Sed,88 Sed
BO 125185	Brace Assy-Front Door Hinge Pillar Glass Run Channel Belt	80,88,89 exc Cv,1939-1940 Cab-CabPu Panel,48 Sed,1940 UCo-UCpe,10T exc 3Cpe,10C exc Del,18
BO 125186	Glass Run Channel & Bracket Assy-Front Door hinge Pillar-RH	80,88,89 exc Cv,1939-1940 Cab-CabPu Panel,48 Sed,1940 UCo-UCpe,10T exc 3Cpe,10C exc Del,18
C 125280	Glass & Rest Channel Assy-F Door Wdo-RH-Plate	82-83-84-85-95 3Cpe-VicCpe
C 125281	Glass & Rest Channel Assy-F Door Wdo-LH-Plate	82-83-84-85-95 3Cpe-VicCpe
BO 125288	Hinge-Rear Door-Upper-RH-Door Half	1938 thru 1940 Sedan-CA
BO 125289	Hinge-Rear Door-Upper-LH-Door Half	1938 thru 1940 Sedan-CA
BO 125290	Hinge-Rear Door-Upper-RH-Body Half	38-39 Sedan,1940 Sed-CA
BO 125291	Hinge-Rear Door-Upper-LH-Body Half	38-39 Sedan,1940 Sed-CA
BO 125294	Hinge-Rear Door-Lower-RH-Door Half	38-39 Sedan,1940 Sed-CA
BO 125295	Hinge-Rear Door-Lower-RH-Door Half	38-39 Sedan,1940 Sed-CA
BO 125296	Hinge-Rear Door-Lower-RH-Body Half	38-39 Sedan,1940 Sed-CA
BO 125297	Hinge-Rear Door-Lower-LH-Body Half	38-39 Sedan,1940 Sed-CA
C 125314	Door Assembly-Front-RH	81-82 Bro
C 125318	Door Assembly-Front-Rh	80-89 UCo,88 Sed,89 Bro
C 125319	Door Assembly-Front-LH	80-89 UCo,88 Sed,89 Bro
C 125322	Door Assembly-Front-RH	81-82 Sedan
C 125326	Door Assembly-Front-RH	80-88-89 Cab-CabPu-Panel,80-89 Sedan
C 125334	Door Assembly-Front-RH	80-89 UCo,89 3Cpe-VicCpe
C 125335	Door Assembly-Front-LH D.N.S.	80-89 UCo,89 3Cpe-VicCpe
C 125342	Door Assembly-Front-RH (Use 125346)	83 Bro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	125343 Door Assy-Front-LH D.N.S.	83 Bro
C	125346 Door Assy-Front-RH	83-84-85 Bro,87 Sed
	125347 Door Assy-Front-LH D.N.S.	83-84-85 Bro,87 SO
	125354 Door Assy-RH-Front (Use 125358)	83 Sed
C	125358 Door Assy-Front-RH	83-84-85 Sedan
	125366 Door Assy-RH-Front (Use 125370)	83 3Cpe-VicCpe
	125367 Door Assy-LH-Front (Use 125371)	83 3Cpe-VicCpe
C	125370 Door Assy-Front-RH	83-84-85 3Cpe-VicCpe
C	125371 Door Assy-Front-LH	83-84-85 3Cpe-VicCpe
C	125374 Door Assy-RH	81-89 Cv
	125383 Door Assy-LH-Prime (D.N.S.)	83-84-85 Cv
	125386 Door Assy-Rear-RH (Use 125398)	80-81-82-89 Sedan
C	125394 Door Assy-Rear-RH	83-84-85 Sedan
C	125398 Door Assy-Rear-RH	87 Sedan
*A	125404 Shell Assy-Radiator	80,81,82,88
A	125405 Shell Assy-Radiator	84 thru 87
A	125406 Shell Assy-Radiator-Prime	83
BO	125441 Center Piece-Radiator-Lower	80,81,82,88
BO	125443 Center Piece-Radiator-Lower	83 thru 85,87
BO	125482 Cushion-F Door Window Glass	38 thru 1940 Cab-CabPu-Panel,40T Sed
BO	125484 Weatherstrip-F Door Window Belt-Outer-RH	81-82-83-90-91-92-93 Bro-3Cpe,VicCpe,1940 thru 1942 VicCpe-3Cpe-2Sed-UCo-UCo, 43, 47, 48, 17, 18P, 27 1946-1947 Bro-3Cpe-ClubCpe
BO	125485 Weatherstrip-F Door Window Belt-Outer LH	81-82-83-90-91-92-93 Bro-3Cpe-VicCpe,1940-1941-1942 VicCpe-3Cpe-2Sed-UCo-UCo, 43, 47, 48, 17, 18P, 27, 1946- 1947 Bro-3Cpe-ClubCpe
BO	125486 Weatherstrip-F Door Window Belt-Outer-RH	81-82-83-90-91-92-93-40-41-44-45 Sed,40C,48C,10P- 11-12-14-20-21-22-24-25 5Sed,1941-1942 Cab-CabPu, 1946-1947 Sed-Cab-CabPu
BO	125487 Weatherstrip-F Door Window Belt-Outer-LH	81-82-83-90-91-92-93-40-41-44-45 Sed,40C,48C,10P- 11-12-14-20-21-22-24-25 5Sed,1941-1942 Cab-CabPu, 1946-1947 Sed-Cab-CabPu
BO	125488 Weatherstrip-F Door Window Belt-Outer-RH	81-89-90 CvCpe-CvBro
BO	125489 Weatherstrip-F Door Window Belt-Outer-LH	81-89-90 CvCpe-CvBro
BO	125490 Weatherstrip-F Door Window Belt-Outer-RH	82 thru 85-95 Bro-3Cpe-VicCpc,87-97 Sed
BO	125491 Weatherstrip-F Door Window Belt-Outer-LH	82 thru 85-95 Bro-3Cpe-VicCpe,87-97 Sed
BO	125492 Weatherstrip-F Door Window Belt-Outer-RH	82 thru 85-95 Sedan
BO	125493 Weatherstrip-F Door Window Belt-Outer-LH	82 thru 85-95 Sedan
BO	125494 Weatherstrip-Rear Door Window-RH and LH	38 thru 1942 Sedan-CA,1946 Sedan
	125504 Panel Assy-Hood Top-RH (Use 129100)	1938 Sed exc 89
	125505 Panel Assy-Hood Top-LH (Use 129101)	80,81,82,88
A	125512 Panel Assy-Hood Side-RH	80,81,82,88
	125513 Panel Assy-Hood Side-LH (Use 129083)	80,81,82,88
	125522 Use 129110	
	125523 Panel Assy-Hood Top-LH (Use 129111)	83 thru 85,87
BO	125528 Ornament-Hood Top Panel-RH	83,84,85,87
BO	125529 Ornament-Hood Top Panel-LH	83,84,85,87
A	125532 Panel Assy-Hood Side-RH	83,84,85,87
A	125533 Panel Assy-Hood Side-LH	83,84,85,87
C	125565 Riser Assy-Rear Compartment Floor Board-LH	38 Bro-Sed-UCo-With Trunk 6.00 Tire
BZ	125575 Plug-Rubber-5/8"	38 thru 1941 All,1946-1947 All
BZ	125587 Bracket-Front Fender Frame Cross Member Corner-LH	38 All
BO	125596 Brace Assembly-Instrument Panel to Front End Panel-RHD	38 All
BZ	125598 Name Plate-Radiator	80,81,82,88
BZ	125599 Name Plate-Radiator	83,84,85,87
	125618 Name Plate-Radiator (Use 125598)	80-81-82-88 Export
C	125626 Running Board Assembly Complete-RH	87
C	125627 Running Board Assembly Complete-LH	87
BO	125630 Channel & Anchor Assy-F Door Glass W/Strip-RH	82 thru 85-95 Bro-3Cpe-VicCpe,87-97 Sedan
BO	125631 Channel & Anchor Assy-F Door Glass W/Strip-LH	82 thru 85-95 Bro-3Cpe-VicCpe,87-97 Sedan
BO	125635 Reinforcement Assy-Bonnet Top Panel Rear-LH	80 thru 88
BZ	125638 Bracket Assy-Radiator Shell to Hood Side Panel-RH	80 thru 88
BZ	125639 Bracket Assy-Radiator Shell to Hood Side Panel-LH	80 thru 88
BO	125656 Bracket-Hood Side Panel to Fender Dust Shield-Rear	80 thru 88
BO	125662 Bracket-Steering Gear Jacket Tube	80 thru 88,92 thru 97 with Elec Hand
BO	125664 Spacer-Steering Gear Jacket Tube Bracket	80 thru 88,92 thru 97
A	125671 Hinge-Hood Female	80,81,82,88
A	125673 Hinge-Hood Female	83 thru 87
C	125674 Support Assy-Hood Top Panel-RH	80 thru 88
C	125675 Support Assy-Hood Top Panel-LH	80 thru 88
BO	125676 Spring-Hood Top Panel Support	80 thru 88
BO	125677 Bolt-Hood Top Panel Support	80 thru 88
C	125678 Grille Assy-Hood Side Panel-RH	83,84,85,87

Part No.	Name	Models
C 125679	Grille Assy-Hood Side Panel-LH	83,84,85,87
C 125680	Molding-Running Board-RH	83,84,85,93,95
C 125681	Molding-Running Board-LH	83,84,85,93,95
C 125685	Molding-Running Board-LH	87,97
125688	Clip-Run Board Mldg-Fender (Use 128417)	83-84-85-87
BZ 125689	Clip-Running Board Molding	83 thru 89,93,95,97
C 125714	Lid Assembly-Trunk	80 thru 85,87,88
*BO 125718	Regulator Assy-Front Door Window-RH	81-82-83-90-91-92-93 Bro-Sed-3Cpe-VicCpe,98 Sed
*BO 125719	Regulator Assy-Front Door Window-LH	81-82-83-90-91-92-93 Bro-Sed-3Cpe-VicCpe,98 Sed
BO 125736	Weatherstrip-Quarter Window Belt-Outer-RH	38-39 Bro-UCo
BO 125747	Weatherstrip-Door Window Belt Outer-LH	38-39 Cv
BZ 125749	Grommet-Rear Splash Guard Bumper-LH	38 All,1939-1940 Panel
C 125757	Bar-Front Bumper	83 thru 87
C 125760	Bar Assy-Front Bumper Frame-RH	80 thru 88
C 125764	Bar Assy-Rear Bumper Frame-RH	81 thru 87,80 Co-Cpe-Sed,88 Sed
BO 125768	Clip-Radiator Shell Molding	83,84,85,87
BZ 125769	Tie Rod-Front Fender Support Bracket	38 All, 98
BZ 125771	Welt-Fender to Radiator-Shell	80 thru 89
BO 125773	Center Bar-Windshield-Outer	38-39 Bro-Sed-3Cpe-VicCpe
BO 125774	Center Bar-Windshield-Outer	38-39 Cab-CabPu-Panel-Station-UCo-UCpe
BO 125780	Knob-Cigar Lighter	83,84,85,87
BO 125785	Center Bar-Windshield-Outer	38-39 Cv
BO 125786	Retainer-Front Door Opening Weatherstrip-RH	38-39 Bro-Sed-3Cpe-VicCpe-UCo-UCpe
BO 125789	Cover Assy-Locker Box Door Clock Opening	81,82,80-90 Station,88 Sedan
BO 125790	Cover Assy-Locker Box Door Clock Opening	83,84
C 125821	Front End Assembly-LHD	83-84-85 Bro-Sed-3Cpe-VicCpe,87 Sed
BO 125838	Weatherstrip-Front Door Window Belt-Inner	81-82-83-90-91-92-93-40P-41-44-45-Bro-3Cpe-VicCpe, 98-43-47-48 Sed
BO 125839	Weatherstrip-Front Door Window Belt-Inner	81-82-83-90-91-92-93-40P-41-44-45 Sect
C 125852	Panel-Quarter-RH	81 RHD 3Cpe-VicCpe,82 3 Cpe-VicCpe
C 125853	Panel-Quarter-LH	81-82 3Cpe-VicCpe
BO 125890	Striker-Rear Compt Door Lock-Center	38 Bro-Sed-UCo
BO 125891	Striker-Rear Compt Door Lock-Center	38-39 Cpe-CvCpe,1940 Cpe-CvSed
125900	Headlamp Complete-RH-With Parking Bulb (Use 125902)	80,81,82,88
125901	Headlamp Complete-LH-With Parking Bulb (Use 125903)	80,81,82,88
BO 125902 Pr	Headlamp Complete-RH-With Parking Bulb	80,81,82,88
BO 125903 Pr	Headlamp Complete-LH-With Parking Bulb	80,81,82,88
BO 125905 Pr	Headlamp Complete-LH-With Parking Bulb- En-6 Volt-Export	80,81,82,88
BO 125906 Pr	Headlamp Complete-RH-With Parking Bulb- 6 Volt-Export	80,81,82,88
BO 125907 Pr	Headlamp Complete-LH-With Parking Bulb- 6 Volt-Export	80,81,82,88
BO 125910 Pr	Headlamp Complete-RH-Without Parking Bulb- 6 Volt-Export	80,81,82,88
BO 125912 En	Headlamp Complete-RH*With Parking Bulb	83,84,85,87
BO 125914 Pr	Headlamp Complete-RH-With Parking Bulb	83,84,85,87
BO 125920 En	Headlamp Complete-RH-Without Parking Bulb-6 Volt	83,84,85,87
BO 125921 En	Headlamp Complete-LH-Without Parking Bulb-6 Volt	83,84,85,87
BO 125923 Pr	Headlamp Complete-LH-Without Parking Bulb- 6 Volt-Export	83,84,85,87
BO 125930 Pr	Headlamp Complete-RH-Without Parking Bulb-12 Volt	80,81,82,88
BO 125931 Pr	Headlamp Complete-LH-Without Parking Bulb-12 Volt	80,81,82,88
BO 125938 Pr	Headlamp Complete-RH-Without Parking Bulb-12 Volt	83,84,85,87
BO 125939 Pr	Headlamp Complete-LH-Without Parking Bulb-12 Volt	83,84,85,87
BO 125962	Lens-Headlamp-Export	83 thru 87
F 125963	Lens-Headlamp-Domestic	83 thru 87
C 125972	Bar Assembly-Rear Bumper Frame-RH	1939-1940 Panel
C 125973	Bar Assembly-Rear Bumper Frame-LH	1939-1940 Panel
BO 125980	Wire Assembly-Carburetor Choke-RHD	80,81,88,82-83 X Engine
BO 125981	Wire Assembly-Carburetor Choke-LHD	80,81,88,82-83 X Engine
BO 125982	Wire and Knob Assembly-Carburetor Choke	80,81,88 exc Sed,82-83 X Engine
125983	Knob Assy-Locker Box Door and Folding Table (Use 208599)	80,81,82,88 exc Sed,90-98 Business Cars
125988	Cylinder-Locker Box Door-Not Coded (Use 124403)	91 Panel
BO 125990	Cyl and Key Assy-Locker Box Door Lock	82 thru 85,87-88 Sed,90 Business Car,91 Panel
125992	Lock,Cyl & Key Assy-Locker Box (Use 208599)	82,88 Sed,90 Business Car,91 Panel
125993	Lock,Cyl & Key Assy-Locker Box (Use 208599)	83 thru 87
C 126111	Body Assembly-LHD	80 UCpe
C 126112	Body Assembly-RHD	80 UCpe
C 126180	Door Assy-Deck	80 UCpe
126193	Lock Assy-LH-F Door (Use 136049)	38 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	126194 Lock Assy-RH-Rr Door (Use 136050)	38 Sed
	126195 Lock Assy-LH-Rr Door (Use 136051)	38 Sed
BO	126197 Pad-Dash Lining-LH	80 thru 85,87,88,89
BO	126220 Door Assy-Locker Box-RH-LHD	91 Panel
BO	126222 Door Assembly-Locker Box-RH-Painted-LHD	80-88 Cab-CabPU-Panel,80 Co-Cpe-Sed
BO	126224 Door Assembly-Locker Box-RH-Grained-LHD	81,80-90 Station,88 Sedan
BO	126225 Door Assembly-Locker Box-LH-Grained-LHD	81,80-90 Station,88 Sedan
BO	126228 Door Assembly-Locker Box-RH-Grained-LHD	83 thru 85,87
BO	126231 Door Assembly-Locker Box-LH-RHD	91 Panel
BO	126242 Hinge-Locker Box Door-Body Half	80 thru 89,90,91,92,98
BO	126243 Hinge Assembly-Locker Box Door	38 All,90,92,98
BO	126255 Handle-Cowl Ventilator Operating	38-39 All
BO	126258 Cover Assembly-Cowl Ventilator	38-39 All
BO	126260 Bracket-Cowl Ventilator Deflector to Hinge	38-39 All
	126263 Knob-Cowl Vent Handle (Use 140278)	38 All
BO	126265 Roller Assembly-Front Seat Track	1938 thru 1942 Bucket Seats
BO	126266 Clevis Pin-Front Seat Track Roller	1938 thru 1942 Bucket Seats
BO	126267 Spring Washer-Seat Track Roller Clevis Pin	1938 thru 1942 Bucket Seats
BO	126271 Bracket Assy-Rear License Plate-Pr	81 thru 87,80-88 Sed,80 UCo,89 Bro-Sed-UCo With Trunk
BZ	126292 Brace-Front Fender to Pillar Dash Bracket-RH	83,84,85,87
BZ	126293 Brace-Front Fender to Pillar Dash Bracket-LH	83,84,85,87
A	126314 Fender Assembly-Front-RH-With Well	80,81,82,88
BZ	126325 Bolt-Bumper Fender Guard & Center Ornament	38 All,93,95-97 Bro-Sed,90-91-92 Cpe-Cv,48 Sed,44,40T Cpe,40 UCpe,10,11,18,20,28,58,178
BO	126328 Bumper-Cowl to Hood Side Panel	38-39 All
BO	126333 Bracket-Hood Latch Rod-LH Front-RH Rear	80,81,82,88
BO	126342 Bracket-Hood Latch Rod-RH Front-LH Rear	83,84,85,87
BO	126343 Bracket-Hood Latch Rod-LH Front-RH Rear	83,84,85,87
BO	126344 Handle-Hood	83,84,85,87
BO	126352 Retainer Assy-Front Door Wing W/S-RH	81-82-83-90 Bro-Sed-3Cpe-VicCpe,98 Sed
BO	126360 Weatherstrip-Front Door Wing-RH	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe,98 Sed
BO	126361 Weatherstrip-Front Door Wing-LH	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe,98 Sed
BO	126370 Spring-Front Door Wing Clamp	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe,98-48-18 Sed,40-41-44-10-11 Sed-2Sed-3Cpe-VicCpe,10 Sp,20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178
BO	126371 Backing Plate-Front Door Wing Clamp	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe,98-48-18 Sed,40-41,44-10-11 Sed-2Sed-3Cpe-VicCpe,10 Sp,20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178
	126374 Glass & Frame Assy-Front Door Wing-RH (Use 140874)	87-82-83-90 Bro-Sed-3Cpe-VicCpe,98 Sed
	126375 Glass & Frame Assy-Front Door Wing-LH	81-82-83-90 Bro-Sed-3Cpe-VicCpe,98 Sed
	126377 Plunger-Wing Locking Handle (Use 136541)	81,82,83
BO	126378 Spring-Front Door Wing Locking Handle Plunger	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe,98-48-18 Sed,40-41-44-10-11 Sed-2Sed-3Cpe-VicCpe,20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178,481-491-500-501 exc CvBro,483,493,503
BO	126386 Plate-Front Door Wing Locking	81-82-83-90-91- Bro-Sed-3Cpe,VicCpe,98 Sed
BO	126387 Tapping Plate-Rear Compt Door Lock Link Plunger Guide	38 All,39 Cpe-Cv
BO	126406 Remote Control Assy-Front Door-Lock-RH	81-82-83-90-92-93 Bro-3Cpe-VicCpe,98 Sed
	126407 Remote Control Assy-Front Door-Lock-LH (Use 120497)	81-82-83-90-92-93 Bro-3Cpe-VicCpe,98 Sed
BO	126408 Remote Control Assy-Front Door Lock-RH	81-82-83-90-92-93-98 Sedan
BO	126409 Remote Control Assy-Front Door Lock-LH	81-82-83-90-92-93-98 Sedan
BO	126410 Safety Lock Assy-Door-Less Cyl	38-39 All,40 Panel
BO	126411 Bezel-Door Safety Lock Assy	38-39 All
	126412 Lock Assy-F Door-RH (Use 136048)	38 All
BO	126413 Cylinder Assy-Door Lock	38 thru 1940 All
BO	126414 Weatherstrip Front Door Wing Glass	81-82-83-90-92-93-40-41-43-48 Bro-Sed-3Cpe-VicCpe,40C,48C,10,11,18,10 Sp,1942-1946-1947 exc Cv
BO	126416 Stud Assembly-Front Door Wing Glass Frame	81-82-83-90-40-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed
BO	126419 Pin-Front Door Wing & Quarter Window Locking Handle	81-82-83-90-40-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed,40C,48C,10,11,18,20-21 28 exc Cv,51-171 exc CvBro, 53,58,173,178,481-491-500-501 exc CvBro,483,493,503, 1948-1949-501 thru 504 Sed
BO	126420 Motor-Windshield Cleaner	80 thru 89
BO	126421 Control Assy-Windshield Cleaner Operating	80,81,82,88,90 Business Cars
BO	126422 Control Assy-Windshield Cleaner Operating	83,84,85,87
BO	126423 Spacer-Windshield Cleaner Operating Control	38-39 All
BO	126424 Center Bar & W/Strip Assy-Front Door Glass-RH	81-82-83 Bro-Sed-3Cpe-VicCpe
BO	126425 Center Bar & W/Strip Assy-Front Door Glass-LH	81-82-83 Bro-Sed-3Cpe-VicCpe
BO	126426 Handle-Front Door Wing Locking-RH	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	126427 Handle-Front Door Wing Locking-LH (Use 136543)	81-82-83-90-91 Bro-Sed-3Cpe-VicCpe
BO	126430 Ornament-Rear Compartment Door	81-82 Bro-Sed,80 Co-Sed,88 Sed
BO	126431 Ornament-Trunk Lid	81-82 Bro-Sed,80 Co-Sed,88 Sed
BO	126432 Ornament-Rear Compartment Door	83-84-85 Bro-Sed,87 Sed,10 Del
BO	126433 Ornament-Trunk Lid	83-84-85 Bro-Sed,87 Sed
BO	126437 Washer-Door Wing Locking Handle Tension	81-82-83-90-91-40-41 Sed-2Sed-3Cpe-VicCpe,40C, 48,10,11,18,10 Sp,20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178,481-491-500-501 exc CvBro,483,493,503,1948-19491501 thru 504 Sedan
C	126446 Bow-Roof-No 2-3-4	87-88-97-98-43-47 Sed,38-39-1940 VicCpe-3Cpe-UCpe
BO	126449 Center Bar-Windshield-Inner-Prime	38-39 exc Cv
BO	126450 Molding-Radiator Shell-No 1-RH	83,84,85,87
BO	126451 Molding-Radiator Shell-No 1-LH	83,84,85,87
BO	126452 Molding-Radiator Shell-No 2-RH	83,84,85,87
BO	126453 Molding-Radiator Shell-No 2-LH	83,84,85,87
BO	126454 Molding-Radiator Shell-No 3-RH	83,84,85,87
BO	126455 Molding-Radiator Shell-No 3-LH	83,84,85,87
BO	126456 Molding-Radiator Shell-No 4-RH	83,84,85,87
BO	126457 Molding-Radiator Shell-No 4-LH	83,84,85,87
BO	126458 Molding-Radiator Shell-No 5-RH	83,84,85,87
BO	126459 Molding-Radiator Shell-No 5-LH	83,84,85,87
BO	126460 Molding-Radiator Shell-No 6-RH	83,84,85,87
BO	126461 Molding-Radiator Shell-No 6-LH	83,84,85,87
BO	126462 Molding-Radiator Shell-No 7-RH	83,84,85,87
BO	126463 Molding-Radiator Shell-No 7-LH	83,84,85,87
BO	126464 Molding-Radiator Shell-No 8-RH	83,84,85,87
BO	126465 Molding-Radiator Shell-No 8-LH	83,84,85,87
BO	126466 Molding-Radiator Shell-No 9-RH	83,84,85,87
BO	126467 Molding-Radiator Shell-No 9-LH	83,84,85,87
BO	126468 Molding-Radiator Shell-No 10-RH	83,84,85,87
BO	126469 Molding-Radiator Shell-No 10-LH	83,84,85,87
BO	126470 Molding-Radiator Shell-No 11-RH	83,84,85,87
BO	126471 Molding-Radiator Shell-No 11-LH	83,84,85,87
BO	126472 Molding-Radiator Shell-No 12-RH	83,84,85,87
BO	126473 Molding-Radiator Shell-No 12-LH	83,84,85,87
BO	126474 Molding-Radiator Shell-No 13-RH	83,84,85,87
BO	126475 Molding-Radiator Shell-No 13-LH	83,84,85,87
BO	126476 Molding-Radiator Shell-No 14-RH	83,84,85,87
BO	126477 Molding-Radiator Shell-No 14-LH	83,84,85,87
C	126482 Molding-Hood Top Panel Belt-RH	83,84,85,87
C	126485 Retainer-Hood Top Panel Belt-Molding-LH	83,84,85,87
BO	126488 Molding-Front End Panel Belt-RH	83,84,85,87
BO	126489 Molding-Front End Panel Belt-LH	83,84,85,87
C	126491 Molding-Front Door Outside Panel Belt-LH	83-84-85 Sedan
C	126492 Molding-Front Door Outside Panel Belt-RH	83-84-85 exc Sed,87 Sed
C	126493 Molding-Front Door Outside Panel Belt-LH	83-84-85 exc Sed,87 Sed
C	126494 Molding-Rear Door Outside Panel Belt-R & L	83-84-85-87 Sedan
C	126496 Retainer-Front Door Belt Molding	83-84-85 Sedan
C	126500 Molding-Quarter Panel Belt-RH	83-84-85 Bro
C	126501 Molding-Quarter Panel Belt-LH	83-84-85 Bro
C	126504 Molding-Quarter Panel Belt-RH	83,84,85,87 Sedan
C	126505 Molding-Quarter Panel Belt-LH	83-84-85-87 Sedan
C	126507 Retainer-Quarter Panel Belt Molding-LH	83-84-85-87 Sedan
C	126511 Retainer-Quarter Panel Belt Molding-LH	83-84-85 3Cpe-VicCpe
C	126518 Belt Molding-Quarter Panel-RH	83-84-85 Cv
BO	126519 Belt Molding-Quarter Panel-LH	83-84-85 Cv
BO	126520 Retainer-Quarter Panel Belt Molding-RH	83-84-85 Cv
BO	126521 Retainer-Quarter Panel Belt Molding-LH	83-84-85 Cv
C	126539 Molding-Instrument Panel	83,84,85,87
BO	126541 Ornament-Instrument Panel Center-Less Radio	80,81,82,88,90 Station
BO	126542 Ornament-Instrument Panel Center-With Radio	80,81,82,88,90 Station
BO	126546 Ornament-Instrument Panel Center-Upper-RH	83,84,85,87
BO	126548 Ornament-Instrument Panel Center-Less Radio	83,84,85,87
BO	126550 Ornament-Instrument Panel Dial-Inner	83,84,85,87
BO	126551 Ornament-Instrument Panel Dial-Outer	83,84,85,87
BO	126554 Clip-Instrument Panel Dial Ornament	83,84,85,87
C	126558 Molding-Front Door Trim Panel Belt-Upper	85 Sedan
BZ	126566 Spacer-Bumper Bar Fender Guard	80,81,82,88,89,91,92,98,40T,40C,48 Cab-CabPu-Panel
BZ	126567 Spacer-Bumper Bar Fender Guard	83,84,85,87,93,95,97
BZ	126568 Bolt-Bumper Fender Guard-Rear	80,81,82,88,98-90-92 exc Cpe,40T,40 Cab-CabPu-Panel, 12 thru 17,11,14,21 thru 27 51 thru 54,171 thru 174
BO	126569 Bracket-Speedometer Mounting	38 All,90,91,92,98
BO	126570 Ornament-Radiator	81,82,88 Sedan
BO	126572 Crest-Radiator Ornament	83,84,85,87

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 126573	Crest & Mounting Assy-Radiator Ornament	83,84,85,87
126574	Crest-Radiator Ornament (Use 126570)	80,88 Cab-CabPu Panel
BO 126580	Glass Dial-Gas & Oil Pressure Gauge	80,81,82,88,90 Station,91,92
BO 126581	Glass Dial-Gen and Water Temp Gauge	80,81,82,88,90 Station,91,92
BO 126582	Retainer-Gauge Glass Dial	80,81,82,88,90 Station,91,92
BO 126583	Gasket-Gauge Glass Dial Upper	80,81,82,88,90 Station,91,92
BO 126584	Gasket-Gauge Glass Dial Lower	80,81,82,88,90 Station,91,92
BO 126585	Mask-Gauge Glass Dial	80,81,82,88,90 Station,91,92
F 126586	Gauge Assy-Gas and Water Temperature	80,81,82,88,90 Station,91,92
BO 126587	Indicator Assy-Oil Pressure Gauge Signal	80,81,82,88,90 Station,91,92
BO 126588	Indicator Assy-Generator Gauge Signal	80,81,82,88,90 Station,91,92
BO 126589	Glass Dial-Oil Pressure Gauge	83,84,85,87
BO 126590	Glass Dial-Water Temperature Gauge	83,84,85,87
BO 126591	Glass Dial-Gasoline Gauge	83,84,85,87
BO 126592	Glass Dial-Generator Charge Indicator	83,84,85,87
BZ 126595	Ornament-Front & Rear Bumper Bar-Center	84,85,87
BO 126600	Cluster Assy-Fuel and Oil Pressure	80,81,82,88,91,92
BO 126602	Cluster Assy-Fuel and Oil Pressure	80,81,82,88
BO 126603	Cluster Assy-Water Temperature and Generator Indicator	83,84,85,87
BO 126605	Bezel-Gauge Glass Dial	83,84,85,87
BO 126606	Retainer-Gauge Glass Dial Bezel	83,84,85,87
C 126607	Gauge Assy-Gasoline & Water Temperature	83,84,85,87
BO 126608	Indicator Assy-Oil Pressure Signal	83,84,85,87
BO 126609	Indicator Assy-Generator Charge Signal	83,84,85,87
BZ 126614	Flexible Shaft Assy-Speedometer-LHD	38-39 An
BZ 126615	Flexible Shaft Assy-Speedometer-RHD	38-39 All
BO 126616	Core-Speedometer Flexible Shaft-LHD	38-39 All
BO 126617	Core-Speedometer Flexible Shaft-RHD	38-39 All
BZ 126637	Spacer-Front & Rear Bumper Bar Ornament	84,85,87
BO 126641	Ash Tray Assy-Instrument Panel	81,82,89,80-90 Station
BO 126642	Front Cover-Instrument Panel Ash Receiver	81-82,89,80-90 Station
BO 126643	Knob-Instrument Panel Ash Tray	81,82,89, 80-90 Station
BO 126644	Guide-Instrument Panel Ash Receiver	81,82,89,80-90 Station
BO 126646	Ash Tray Assy-Instrument Panel	80-88 Cab-CabPu-Panel,80 Co-Cpe-Sed
BO 126651	Ash Tray Assy-Instrument Panel	83,84,85,87
BO 126653	Knob-Instrument Panel Ash Tray	83,84,85,87
BO 126658	Ornament-Front Fender	82
BO 126659	Ornament-Front Fender	83,84,85,87,90,98
BO 126660	Ornament Kit-Front Fender	80,81,88
BO 126661	Pad-Headlamp to Radiator Shell	83,84,85,87
BO 126662	Pad-Headlamp to Radiator Shell-RH	80,81,82,88
BO 126668	Pad-Headlamp to Radiator Shell-LH	80,81,82,88
126667	Escutcheon Plate-Comelamp Switch (Use 134867)	81 thru 85-89 exc Cv,80 UCo-UCpe-Sed,88 Sed
BO 126671	Ash Receiver-Front Seat Back Panel	81,82,88 Sedan
BO 126673	Ash Receiver-Front Seat Back Panel	83,84 Sedan
BO 126674	Reflector Assy-Dome Lamp	38-39 Bro-Sed-3Cpe-VicCpe-UCo-UCpe
BO 126675	Rim and Glass Assy-Dome Lamp	81,82 Bro-Sed-3Cpe-VicCpe,80 UCo-UCpe-Sed, 89 exc Cv
126680	Handle Assy-Door,Quarter Window and Wing Regulator (Use 205334)	80-81-82-88 Doors,81-82 Bro Quarter Windows, 82 Cv Wings,89,91 Panel
126682	Handle Assy-Front Door Wing Reg (Use 204257)	82 Bro-Sed-Cpe-VicCpe
126682	Handle Assy-Qtr Window Reg (Use 204257)	80-81-82-88 Sedan
BO 126684	Handle-Door Inside	80,81,82,88,89,90-98 Bus Cars,91 Panel
BO 126686	Escutcheon-Door Inside Handle-For Cloth Trim	81,82,80-88 Sed,80 Co-Cpe
BO 126687	Handle-Door Inside	83,84,85,87
BO 126688	Handle Assy-Door Wing Regulator	83 Cv,84,85,87
BO 126689	Handle Assy-Front Door Wing Regulator	83 Bro-Sed-3Cpe-VicCpe
BO 126689	Handle Assy-Quarter Window Regulator	83-84-85-87 Sedan
126690	Handle Assy-Door & Qtr Window Reg (Use 121841)	83-84-85 Bro-3Cpe-VicCpe-CvCpe-CvBro, 82-84-85-87 Sed Doors
BO 126691	Escutcheon-Inside Handle-For Leather Trim	81,82,80-90 Co-Cpe,80-88-90-98 Sed-Cab-CabPu-Panel,83 Bro-Sed-3Cpe-VicCpe,89,91 Panel
BO 126700	Lamp Assy-Front Fender-RH-6V	80 thru 85,87,88,89
BO 126701	Lamp Assy-Front Fender-LH-6V	80 thru 89,90,98
BO 126702	Lamp Assy-Front Fender-RH-12V	80 thru 89,90,98
BO 126703	Lamp Assy-Front Fender-LH-12V	80 thru 89,90,98
BO 126704	Pad-Front Fender Lamp	80 thru 89,90,98
BO 126705	Lens-Fender Lamp	38-39 All
BO 126706	Gasket-Fender Lamp Lens	38-39 All
BO 126707	Cushion-Fender Lamp Lens-Rubber	38-39 All
BO 126708	Housing-Fender Lamp	80 thru 89,90,98
BO 126709	Screw-Fender Lamp Housing	38-39 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

103

Part No.	Name	Models
BO 126711	Base Plate Assy-Front Fender Lamp-LH	80 thru 89,90,98
BO 126721	Glass-Electric Clock & Speedometer	80,81,82,88,89,91,92
BO 126722	Glass Electric Clock	83,84,85,87
BO 126723	Bezel-Electric Clock & Speedometer Glass	80 thru 88
BO 126724	Cyl & Key Assy-Rear Compartment Lock	1938 thru 1940 All
C 126740	Roof Bow-#1	1938 thru 1940 exc Cv
C 126742	Roof Bow-#3	38 thru 1940 All
C 126743	Roof Bow-#5	80 thru 89-92-93-95 Sedan
C 126743	Roof Bow-#6 (#3 for 89-90)	87-88-97-98-90 Sed,1940 Sed
C 126745	Roof Bow-#4 & 5 (#3 for 89-90)	38 thru 1940 Bro-UCo
C 126748	Roof Bow-#4 & 5 (#3 & 4 for 89 and 39)	38 thru 1940 3Cpe-VicCpe-UCpe
C 126750	Use 126752	
BO 126751	Glass-Speedometer Dial-Kilo-First Type	83,84,85,87
BO 126752	Glass-Speedometer Dial-Miles-Second Type	83,84,85,87
BO 126754	Gasket-Speedometer Glass	80,111,82,88,89,90,91,92,98
BO 126755	Gasket-Speedometer Glass	83,84,85,87,89,90,98
BO 126762	Shim Battery Cover to Radiator	80 thru 88
BO 126763	Shim-Battery Cover Extension to Radiator	84,85,87
BO 126769	Bracket-Body Header Bow-Front	38 thru 1940 exc Cv
C 126833	Finish Mldg Assy-Rear Door Window-LH	83-84-93-95 Sedan
C 126841	Finish Mldg-Rear Window-LH	81 thru 87,80-88 Sed,80 UCo-UCpe
C 126870	Finish Mldg-Windshield-RH	81-82 exc Cv,88 Sed,80-90 Station
C 126873	Finish Mldg-Windshield-LH	83-84-85 Bro-Sed-3Cpe-VicCpe,87 Sed
BO 126886	Cover-W/S Finish Mldg Lower Joint	83,84,85,87
C 126920	Drip Molding-Roof Panel-RH	38 thru 1940 Bro-UCo
C 126921	Drip Molding-Roof Panel-LH	38 thru 1940 Bro-UCo
C 126922	Drip Molding-Roof Panel-RH	80 thru 85-90 thru 95 Sed,40-41044-45 Sed
C 126923	Drip Molding-Roof Panel-LH	80 thru 85-90 thru 95 Sed,40-41-44-45 Sed
C 126924	Drip Molding-Roof Panel-RH	87-88-97-98-43-47-48 Sedan
C 126925	Drip Molding-Roof Panel-LH	87-88-97-98-43-47-48 Sedan
C 126926	Drip Molding-Roof Panel-RH	30 thru 1940 3Cpe-VicCpe-UCpe
C 126927	Drip Molding-Roof Panel-LH	38 thru 1940 3Cpe-VicCpe-UCpe
BO 126935	Ornament-Bonnet Side Panel	83,84,85,87
BO 126936	Shim-Windshield Center Bar	38-39 All
BZ 126947	Bracket Assy-Front License Plate	80,81,82,88,89
BZ 126949	Bracket Assy-Front License Plate	83,84,85,87,90 thru 98
126950	Mat & Pad Assy-Front Floor-LHD (Use 201134)	80-81-88
126953	Mat & Pad Assy-Front Floor-RHD (Use 201134)	82,83,84,85,87
126958	Scuff Plate-Rear Door-RH (Use 121922)	82-88 Sedan
BO 126964	Scuff Plate-Rear Door-RH	83 thru 85 Sedan
BO 126965	Scuff Plate-Rear Door-LH	83 thru 85 Sedan
C 126966	Scuff Plate-Front Door-RH	87 Sedan
BO 126969	Scuff Plate-Rear Door-LH	87 Sedan
BO 126972	Door Assy-Locker Box-RH-LHD	83,84,85,87
BO 126973	Door Assy-Locker Box-LH-LHD	83,84,85,87
C 126985	Glass Run-Front Door Window Glass Center Bar	81-82-83 exc Cv,98 Sed,40P,41,43 thru 48 Sed
126986	Glass Run-Front Door Window (Use 209712)	90-91-92-93-40-41-44-45 2Sed,43-47-48-17 Sed 40 UCo, 10P-11-12-14 2Sed,1942 UCo-2Sed,27,1946 Bro
C 126988	Glass Run-Front Door Window	90-91-92-93-40-41-44-45 Sed,40C,48C,10 thru 14 Sed, 20 thru 25 Sed,1946 Sed-Cab-CabPu
C 126989	Glass Run Assy-Front Door Window	81-82-83 Sed
126990	Glass Run-Front Door Window (Use 209714)	90-92-93-40-41-44-45-10-11-12-14-15 VicCpe-3Cpe,40 UCpe,1942 ClubCpe-3Cpe-UCpe,1946 3Cpe-ClubCpe
C 126991	Glass Run Assy-Door Window	81-82-83 3Cpe-VicCpe
BO 127020	Hanger Assembly-Robe-38-1/2"	81 Sed,82 Mohair Sedan,80-88 Sed
M 127042	Headlining Cloth-Blue	81 thru 85 Bro-Sed-3Cpe-VicCpe,87-88 Sed
BO 127046	Robe Hanger Assy-Maroon-38-1/2"	81-82-88 Sedan
BO 127047	Robe Hanger Assy-Blue 38-1/2"	81-82-88 Sedan
M 127078	Cloth-Headlining-Maroon-65" Wide	
M 127083	Seat Cloth Basket Weave	85 Bro-Sed-3Cpe-VicCpe,87 Sed
M 127084	Sidewall Cloth	85 Bro-Sed-3Cpe-VicCpe,87 Sed
BO 127085	Windlace	85 Bro-Sed-3Cpe-VicCpe,87 Sed
BO 127086	Robe Hanger Assy-Basket Weave Trim	85 Bro
BO 127088	Binding-Wire on-Basket Weave Trim	85 Sed-3Cpe,87 Sed
BO 127090	Top Material-Olive Green & White Mixture	38 CvCpe-CvBro
BO 127091	Binding-3/4" Double Fold	38 CvCpe-CvBro
BO 127092	Binding-5/8" Wire on	38 CvCpe-CvBro
C 127100	Door Complete-Front-RH-Cloth	81 Bro
C 127101	Door Complete-Front-LH-Cloth	81 Bro
C 127102	Door Complete-Front-RH-Leather	81 Bro
C 127103	Door Complete-Front-LH-Leather	81 Bro
C 127104	Door Complete-Front-RH-Cloth	82 Bro
C 127105	Door Complete-Front-LH-Cloth	82 Bro
C 127106	Door Complete-Front-RH-Leather	82 Bro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 127107	Door Complete-Front-LH-Leather	82 Bro
C 127108	Door Complete-Front-RH-Cloth	83 Bro
C 127109	Door Complete-Front-LH-Cloth	83 Bro
C 127110	Door Complete-Front-RH-Leather	83 Bro
C 127111	Door Complete-Front-LH-Leather	83 Bro
C 127112	Door Complete-Front-RH-Cloth	84 Bro
C 127113	Door Complete-Front-LH-Cloth	84 Bro
C 127116	Door Complete-Front-RH-Cloth	85 Bro,87 Sed
C 127117	Door Complete-Front-LH-Cloth	85 Bro,87 Sed
C 127120	Door Complete-Front-RH-Cloth	81 Sedan
C 127121	Door Complete-Front-LH-Cloth	81 Sedan
C 127122	Door Complete-Front-RH-Leather	81 Sedan
C 127123	Door Complete-Front-LH-Leather	81 Sedan
C 127124	Door Complete-Front-RH-Cloth	82 Sedan
C 127125	Door Complete-Front-LH-Cloth	82 Sedan
C 127126	Door Complete-Front-RH-Leather	82 Sedan
C 127127	Door Complete-Front-LH-Leather	82 Sedan
C 127128	Door Complete-Front-RH-Cloth	83 Sedan
C 127129	Door Complete-Front-LH-Cloth	83 Sedan
C 127130	Door Complete-Front-RH-Leather	83 Sedan
C 127131	Door Complete-Front-LH-Leather	83 Sedan
C 127132	Door Complete-Front-RH-Cloth	84 Sedan
C 127133	Door Complete-Front-LH-Cloth	84 Sedan
C 127136	Door Complete-Front-RH-Cloth	85 Sedan
C 127137	Door Complete-Front-LH-Cloth	85 Sedan
C 127140	Door Complete-Front-RH-Cloth	80 Sedan
C 127141	Door Complete-Front-LH-Cloth	80 Sedan
C 127142	Door Complete-Front-RH-Leather	80 Sedan
C 127143	Door Complete-Front-LH-Leather	80 Sedan
C 127144	Door Complete-Front-RH-Cloth	88 Sedan
C 127145	Door Complete-Front-LH-Cloth	88 Sedan
C 127146	Door Complete-Front-RH-Leather	88 Sedan
C 127147	Door Complete-Front-LH-Leather	88 Sedan
C 127148	Door Complete-Front-RH-Cloth	81 3Cpe-VicCpe
C 127149	Door Complete-Front-LH-Cloth	81 3Cpe-VicCpe
C 127150	Door Complete-Front-RH-Leather	81 3Cpe-VicCpe
C 127151	Door Complete-Front-LH-Leather	81 3Cpe-VicCpe
C 127152	Door Complete-Front-RH-Cloth	82 3Cpe-VicCpe
C 127153	Door Complete-Front-LH-Cloth	82 3Cpe-VicCpe
C 127154	Door Complete-Front-RH-Leather	82 3Cpe-VicCpe
C 127155	Door Complete-Front-LH-Leather	82 3Cpe-VicCpe
C 127156	Door Complete-Front-RH-Cloth	83 3Cpe-VicCpe
C 127157	Door Complete-Front-LH-Cloth	83 3Cpe-VicCpe
C 127158	Door Complete-Front-RH-Leather	83 3Cpe-VicCpe
C 127159	Door Complete-Front-LH-Leather	83 3Cpe-VicCpe
C 127160	Door Complete-Front-RH-Cloth	84 3Cpe-VicCpe
C 127161	Door Complete-Front-LH-Cloth	84 3Cpe-VicCpe
C 127164	Door Complete-Front-RH-Cloth	85 3Cpe-VicCpe
C 127165	Door Complete-Front-LH-Cloth	85 3Cpe-VicCpe
C 127168	Door Complete-Front-RH	81 Cv
C 127169	Door Complete-Front-LH ,	81 Cv
C 127170	Door Complete-Front-RH	82 Cv
C 127171	Door Complete-Front-LH	82 Cv
C 127172	Door Complete-Front-RH	83-84 Cv
C 127173	Door Complete-Front-LH	83-84 Cv
C 127174	Door Complete-Front-RH	85 Cv
C 127175	Door Complete-Front-LH	85 Cv
C 127176	Door Complete-Front-RH-Cloth	80 UCo
C 127177	Door Complete-Front-LH-Cloth	80 UCo
C 127178	Door Complete-Front-RH-Leather	80 UCo
C 127179	Door Complete-Front-LH-Leather	80 UCo
C 127180	Door Complete-Front-RH-Cloth	80 UCpe
C 127181	Door Complete-Front-LH-Cloth	80 UCpe
C 127182	Door Complete-Front-RH-Leather	80 UCpe
C 127183	Door Complete-Front-LH-Leather	80 UCpe
C 127184	Door Complete-Front-RH	80-88 Cab-CabPu-Panel
C 127185	Door Complete-Front-LH	80-88 Cab-CabPu-Panel
C 127186	Door Complete-Rear-RH-Cloth	81 Sedan
C 127187	Door Complete-Rear-LH-Cloth	81 Sedan
C 127188	Door Complete-Rear-RH-Leather	81 Sedan
C 127189	Door Complete-Rear-LH-Leather	81 Sedan
C 127190	Door Complete-Rear-RH-Cloth	82 Sedan
C 127191	Door Complete-Rear-LH-Cloth	82 Sedan
C 127192	Door Complete-Rear-RH-Leather	82 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 127193	Door Complete-Rear-LH-Lcather	82 Sedan
C 127194	Door Complete-Rear-RH-Cloth	83-84 Sed
C 127195	Door Complete-Rear-LH-Cloth	83-84 Sedan
C 127198	Door Complete-Rear-RH-Cloth	85 Sedan
C 127199	Door Complete-Rear-LH-Cloth	85 Sedan
C 127202	Door Complete-Rear-RH-Cloth	87 Sedan
C 127203	Door Complete-Rear-LH-Cloth	87 Sedan
C 127206	Door Complete-Rear-RH-Cloth	80 Sedan
C 127207	Door Complete-Rear-LH-Cloth	80 Sedan
C 127208	Door Complete-Rear-RH-Leather	80 Sedan
C 127209	Door Complete-Rear-LH-Leather	80 Sedan
C 127210	Door Complete-Rear-RH-Cloth	88 Sedan
C 127211	Door Complete-Rear-LH-Cloth	88 Sedan
C 127212	Door Complete-Rear-RH-Leather	88 Sedan
C 127213	Door Complete-Rear-LH-Leather	88 Sedan
C 127214	Headlining Assy	81 thru 85 Bro
C 127215	Headlining Assy	81 thru 85 Sedan
C 127217	Headlining Assy	81 thru 85 3Cpe,80 UCpe
C 127219	Headlining Assy	38 thru 1940 Panel
C 127220	Back Complete-Rear Seat-Cloth	80-81 Sedan
C 127221	Back Complete-Front Seat-LHD-Cloth	81 Sedan Without Table
C 127222	Back Complete-Front Seat-RHD-Cloth	81 Sedan Without Table
C 127223	Trim Assy-Front Seat Back-Cloth	80-81 Sedan
C 127224	Cushion Complete-Front Seat-Cloth	81 Sedan-3Cpe,80 Sed
C 127225	Trim Assy-Front Seat Cushion-Cloth	81 Sedan-3Cpe,80 Sed
C 127226	Trim Assy-Rear Seat Back-Cloth	80-81 Sedan
C 127227	Back Complete-Front Seat-LHD-Cloth	82 Sedan Without Table
C 127228	Back Complete-Front Seat-RHD-Cloth	82 Sedan Without Table
C 127229	Trim Assy-Front Seat Back-Cloth	82 Sedan,3Cpe,88 Sed
C 127230	Cushion Complete-Front Seat-Cloth	82 Sedan,3Cpe,88 Sed
C 127231	Trim Assy-Front Seat Cushion-Cloth	82 Sedan,3Cpe,88 Sed
C 127232	Back Complete-Rear Seat-Cloth	82-88 Sedan
C 127233	Back Complete-Front Seat-LHD-Std Cloth	83-84 Sedan Without Table
C 127234	Back Complete-Front Seat-RHD-Std Cloth	83-84 Sedan Without Table
C 127235	Trim Assy-Front Seat Back-Std Cloth	83-84 Sedan-3Cpe
C 127236	Cushion Complete-Front Seat-Std Cloth	83-84 Sedan-3Cpe
C 127237	Trim Assy-Front Seat Cushion-Std Cloth	83-84 Sedan-3Cpe
C 127238	Trim Assy-Rear Seat Back-Cloth	83-88 Sedan
C 127239	Back Complete-Front Seat-LHD-Cloth	85 Sedan
C 127240	Back Complete-Front Seat-RHD-Cloth	85 Sedan
C 127241	Back Complete-Front Seat-LHD-Cloth	87 Sedan
C 127242	Back Complete-Front Seat-RHD-Cloth	87 Sedan
C 127243	Trim Assy-Front Seat Back-Cloth	85-87 Sedan,85 3Cpe
C 127244	Cushion Complete-Front Seat-Cloth	85-87 Sedan,85 3Cpe
C 127245	Trim Assy-Front Seat Cushion-Cloth	85-87 Sedan,85 3Cpe
C 127246	Back Complete-Rear Seat-Std Cloth	83-84 Sedan
C 127255	Back Complete-Front Seat-Driver-LHD-Cloth	81 Bro-VicCpe
C 127256	Back Complete-Front Seat-Driver-RHD-Cloth	81 Bro-VicCpe
C 127257	Back Complete-Front Seat-Pass LHD-Cloth	81 Bro-VicCpe
C 127258	Back Complete-Front Seat-Pass RHD-Cloth	81 Bro-VicCpe
C 127259	Back Complete-Front Seat-Drivers-LHD-Cloth	82 Bro-VicCpe
C 127260	Back Complete-Front Seat-Drivers-RHD-Cloth	82 Bro-VicCpe
C 127261	Back Complete-Front Seat-Pass LHD-Cloth	82 Bro-VicCpe
C 127262	Back Complete-Front Seat-Pass RHD-Cloth	82 Bro-VicCpe
C 127263	Back Complete-Front Seat-Drivers-LHD-Cloth	83-84 Bro-VicCpe
C 127264	Back Complete-Front Seat-Drivers-RHD-Cloth	83-84 Bro-VicCpe
C 127265	Back Complete-Front Seat-Pass-LHD-Std Cloth	83-84 Bro-VicCpe
C 127266	Back Complete-Front Seat-Pass-RHD-Std Cloth	83-84 Bro-VicCpe
C 127267	Back Complete-Front Seat-Drivers-LHD-Cloth	85 Bro
C 127268	Back Complete-Front Seat-Drivers-RHD-Cloth	85 Bro
C 127269	Back Complete-Front Seat-Pass-LHD-Cloth	85 Bro
C 127270	Back Complete-Front Seat-Pass-RHD-Cloth	85 Bro
C 127271	Trim Assy-Rear Seat Back-Std Cloth	83-84 Sedan
C 127272	Trim Assy-Front Seat Back-RH-Cloth	81 Bro-VicCpe
C 127273	Trim Assy-Front Seat Back-LH-Cloth	81 Bro-VicCpe
C 127274	Cushion Complete-Front Seat-Cloth	81 Bro-VicCpe
C 127275	Trim Assy-Front Seat Cushion-Cloth	81 Bro-VicCpe
C 127276	Trim Assy-Front Seat Back-RH-Cloth	82 Bro-VicCpe
C 127277	Trim Assy-Front Seat Back-LH-Cloth	82 Bro-VicCpe
C 127278	Cushion Complete-Front Seat-Cloth	82 Bro-VicCpe
C 127279	Trim Assy-Front Seat Cushion-Cloth	82 Bro-VicCpe
C 127282	Cushion Complete-Front Seat	83-84 Bro-VicCpe
C 127283	Trim Assy-Front Seat Cushion	83-84 Bro-VicCpe
C 127284	Trim Assy-Front Seat Back-RH-Cloth	85 Bro-VicCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 127285	Trim Assy-Front Seat Back-LH-Cloth	85 Bro-VicCpe
C 127286	Cushion Complete-Front Seat-Cloth	85 Bro-VicCpe
C 127287	Trim Assy-Front Seat Cushion-Cloth	85 Bro-VicCpe
C 127288	Back Complete-Rear Seat-Cloth	85-87 Sedan
C 127289	Trim Assy-Rear Seat Back-Cloth	85-87 Sedan
C 127290	Back Complete-Rear Seat-Cloth	81 Bro
C 127291	Trim Assy-Rear Seat Back-Cloth	81 Bro
C 127292	Back Complete-Rear Seat-Cloth	82 Bro
C 127293	Trim Assy-Rear Seat Back-Cloth	82 Bro
C 127294	Back Complete-Rear Seat-Std Cloth	83-84 Bro
C 127295	Trim Assy-Rear Seat Back-Std Cloth	83-84 Bro
C 127296	Back Complete-Rear. Seat-Cloth	85 Bro
C 127297	Trim Assy-Rear Seat Back-Cloth	85 Bro
C 127298	Cushion Complete-Rear Seat-Cloth	81 Sed-Bro,80 Sedan
C 127299	Trim Assy-Rear Seat Cushion-Cloth	81 Sed-Bro,80 Sedan
C 127300	Cushion Complete-Rear Seat-Cloth	82 Bro
C 127302	Cushion Complete-Rear Seat-Std Cloth	83-84 Sed
C 127303	Trim Assy-Rear Seat Cushion-Std Cloth	83-84 Bro-Sed
C 127304	Cushion Complete-Rear Seat-Cloth	85-87 Sedan
C 127305	Trim Assy-Rear Seat Cushion-Cloth	85-87 Sed,85 Bro
BO 127347	Braided Tape-1/8"	81 Bro-Sed-3Cpe-VicCpe
BO 127356	Visor Assy-Inside-Hinge Type-Tan Cloth	90,91,98,40T 3Cpe-4Cpe
BO 127359	Visor Assy-Maroon Leather Trim	90 Bro-Sed-3Cpe-VicCpe,98 Sed
C 127367	Silencer & Trimboard Assy-Dash-LHD-Black	80,81,88,89
C 127382	Windlace Assy-Front Pillar & Header-RH	81 thru 85-89 Bro,80-89 UCo
C 127383	Windlace Assy-Front Pillar & Header-LH	81 thru 85-89 Bro,80-89 UCo
C 127384	Windlace Assy-Front Pillar & Header-RH	80 thru 85 Sed,40-41-44 Sed
C 127385	Windlace Assy-Front Pillar & Header-LH	80 thru 85 Sed,40-41-44 Sed
C 127386	Windlace Assy-Front Pillar & Header-RH	87-88-43-47-48 Sed
C 127387	Windlace Assy-Front Pillar & Header-LH	87-88-43-47-48 Sed
C 127388	Retainer-Body Header Headlining & Windlace	38-39 3Cpe-VicCpe-UCpe,1946-1947 Bro-3Cpe-ClubCpe
C 127390	Windlace Assy-Front Pillar and Header-RH	38 3Cpe-VicCpe-UCpe,1940 VicCpe-3Cpe-2Sed
C 127391	Windlace Assy-Front Pillar and Header-LH	38 3Cpe-VicCpe-UCpe,1940 VicCpe-3Cpe-2Sed
BO 127392	Arm Rest Assembly-Quarter-RH	81 Bro
BO 127393	Arm Rest Assembly-Quarter-LH	81 Bro
C 127397	Trimboard & Trim Assy-W/ Shield Header	80 Station
C 127404	Trimstick & Trim Assy-Front Pillar-RH	80-90 Station
C 127405	Trimstick & Trim Assy-Front Pillar-LH	80-90 Station
C 127436	Headlining Assy	81 thru 85 VicCpe
BO 127498	Spacer-Dome Light Switch	1938 thru 1941 UCo-UCpe-3Cpe-VicCpe-2Sed
C 127550	Trimboard Complete-Front Door-RH-Cloth	81 3Cpe-VicCpe-Bro
C 127551	Trimboard Complete-Front Door-LH-Cloth	81 3Cpe-VicCpe-Bro
C 127552	Trimboard Complete-Front Door-RH-Cloth	82 3Cpe-VicCpe-Bro
C 127553	Trimboard Complete-F Door-LH-Cloth	82 3Cpe-VicCpe-Bro
C 127554	Trimboard Complete-F Door-RH-Cloth	83 3Cpe-VicCpe-Bro
C 127555	Trimboard Complete-F Door-LH-Cloth	83 3Cpe-VicCpe-Bro
C 127556	Trimboard Complete-F Door-RH-Cloth	84 3Cpe-VicCpe-Bro
C 127557	Trimboard Complete-F Door-LH-Cloth	84 3Cpe-VicCpe-Bro
C 127558	Trimboard Complete-F Door-RH-Cloth	85 3Cpe-VicCpe-Bro,87 Sed
C 127559	Trimboard Complete-F Door-LH-Cloth	85 3Cpe-VicCpe-Bro,87 Sed
C 127560	Trimboard Complete-F Door-RH-Cloth	81 Sedan
C 127561	Trimboard Complete-F Door-LH-Cloth	81 Sedan
C 127562	Trimboard Complete-Rear Door-RH-Cloth	80-81-88 Sedan
C 127563	Trimboard Complete-Rear Door-LH-Cloth	80-81-88 Sedan
C 127564	Trimboard Complete-F Door-RH-Cloth	82 Sedan
C 127565	Trimboard Complete-F Door-LH-Cloth	82 Sedan
C 127566	Trimboard Complete-Rear Door-RH-Cloth	82 Sedan
C 127567	Trimboard Complete-Rear Door-LH-Cloth	82 Sedan
C 127568	Trimboard Complete-F Door-RH-Cloth	83 Sedan
C 127569	Trimboard Complete-F Door-LH-Cloth	83 Sedan
C 127570	Trimboard Complete-F Door-RH-Cloth	84 Sedan
C 127571	Trimboard Complete-F Door-LH-Cloth	84 Sedan
C 127572	Trimboard Complete-Rear Door-RH-Cloth	83-84 Sedan
C 127573	Trimboard Complete-Rear Door-LH-Cloth	83-84 Sedan
C 127574	Trimboard Complete-F Door-RH-Cloth	85 Sedan
C 127575	Trimboard Complete-F Door-LH-Cloth	85 Sedan
C 127576	Trimboard Complete-Rear Door-RH-Cloth	85-87 Sedan
C 127577	Trimboard Complete-Rear Door-LH-Cloth	85-87 Sedan
C 127578	Trimboard Complete-F Door-RH-Leather	81-82-83 Bro-3Cpe-VicCpe
C 127579	Trimboard Complete-F Door-LH-Leather	81-82-83 Bro-3Cpe-VicCpe
C 127582	Trimboard Complete-F Door-RH-Leather	81-82-83 Sedan
C 127583	Trimboard Complete-F Door-LH-Leather	81-82-83 Sedan
C 127586	Trimboard Complete-Rear Door-RH-Leather	81-82-88 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 127587	Trimboard Complete-Rear Door-LH-Leather	81-82-88 Sedan
C 127588	Trimboard Complete-Front Door-RH-Cloth	80 UCo-UCpe,88 Sed
C 127589	Trimboard Complete-Front Door-LH-Cloth	80 UCo-UCpe,88 Sed
C 127590	Trimboard Complete-Front Door-RH-Leather	80 UCo-UCpe
C 127591	Trimboard Complete-Front Door-LH-Leather	80 UCo-UCpe
C 127592	Trimboard Complete-Lower Quarter-RH-Cloth	81 Bro
C 127593	Trimboard Complete-Lower Quarter-LH-Cloth	81 Bro
C 127594	Trimboard Complete-Lower Quarter-RH-Cloth	82 Bro
C 127595	Trimboard Complete-Lower Quarter-LH-Cloth	82 Bro
C 127597	Trimboard Complete-Lower Quarter-LH-Cloth	82-84 Bro
C 127598	Trimboard Complete-Lower Quarter-RH-Cloth	85 Bro
C 127599	Trimboard Complete-Lower Quarter-LH-Cloth	85 Bro
C 127600	Trimboard Complete-Lower Quarter-RH-Leather	81-82 Bro
C 127601	Trimboard Complete-Lower Quarter-LH-Leather	81-82 Bro
BO 127645	Button-Upholstery-Std Twist	82 3Cpe-VicCpe
C 127652	Trimboard & Trim Assy-Front Door-RH	85 Bro-3Cpe-VicCpe,87 Sed
C 127653	Trimboard & Trim Assy-Front Door-LH	85 Bro-3Cpe-VicCpe,87 Sed
C 127654	Trimboard & Trim Assy-Front Door-RH	85 Bro-3Cpe-VicCpe,87 Sed
C 127655	Trimboard & Trim Assy-Front Door-LH	85 Bro-3Cpe-VicCpe,87 Sed
C 127658	Trimboard & Trim Assy-Front Door-RH	85 Bro-3Cpe-VicCpe,87 Sed
C 127659	Trimboard & Trim Assy-Front Door-LH	85 Bro-3Cpe-VicCpe,87 Sed
C 127668	Trimboard & Trim Assy-Front Door-RH	85 Sedan
C 127669	Trimboard & Trim Assy-Front Door-LH	85 Sedan
C 127678	Trimboard & Trim Assy-Rear Door-RH	85-87 Sedan
C 127679	Trimboard & Trim Assy-Rear Door-LH	85-87 Sedan
BO 127683	Assist Strap Assy-Basket Weave Trim	85 Bro-Sed,87 Sedan
BO 127698	Insulator-Dome Light Switch	38 thru 1941 Bro-3Cpe-VicCpe-UCo-UCpe
C 127718	Trimboard & Trim Assy-Lower Quarter-RH	85 Bro
C 127719	Trimboard & Trim Assy-Lower Quarter-LH	85 Bro
BO 127724	Carpet Assy-Rear Floor	81 thru 85 Bro
BO 127725	Carpet Assy-Rear Floor	80 thru 85 Sedan
C 127740	Trimstick & Trim Assy-Front Pillar-RH-LHD	38-39 With Elec Hand exc Cv
C 127741	Trimstick & Trim Assy-Front Pillar-LH-LHD	38-39 With Elec Hand exc Cv
C 127742	Trimstick & Trim Assy-Front Pillar-RH-RHD	38-39 With Elec Hand exc Cv
C 127743	Trimstick & Trim Assy-Front Pillar-LH-RHD	38-39 With Elec Hand exc Cv
C 127744	Trimstick & Trim Assy-Front Pillar-RH-LHD	38-39 Cv
C 127745	Trimstick & Trim Assy-Front Pillar-LH-RHD	38-39 Cv
C 127769	Back Complete-Front Seat-Drivers-LHD	85 VicCpe
C 127770	Back Complete-Front Seat-Drivers-RHD	85 VicCpe
C 127771	Back Complete-Front Seat-Pass-LHD	85 VicCpe
C 127772	Back Complete-Front Seat-Pass-RHD	85 VicCpe
C 127773	Back Complete-Front Seat-LHD	81 3Cpe
C 127774	Back Complete-Front Seat-RHD	81 3Cpe
C 127775	Back Complete-Front Seat-LHD	82 3Cpe
C 127776	Back Complete-Front Seat-RHD	82 3Cpe
C 127777	Back Complete-Front Seat-LHD	83-84 3Cpe
C 127778	Back Complete-Front Seat-RHD	83-84 3Cpe
C 127779	Back Complete-Front Seat-LHD	85 3Cpe
C 127780	Back Complete-Front Seat-RHD	85 3Cpe
C 127781	Trimboard & Trim Assy-Folding Seat Bottom-Cloth	81 thru 85 VicCpe
C 127782	Finish Panel Assy-Center Pillar-RH-Cloth	80-81-82-88-89 Sedan
C 127783	Finish Panel Assy-Center Pillar-LH-Cloth	80-81-82-88-89 Sedan
C 127784	Finish Panel Assy-Center Pillar-RH-Leather	80,81,82,88,89,90,92,98 Sedan
C 127785	Finish Panel Assy-Center Pillar-LH-Leather	80,81,82,88,89,90,92,98 Sedan
C 127786	Trimboard Complete-Lower Quarter-RH-Cloth	80-81-82-88 Sedan
C 127787	Trimboard Complete-Lower Quarter-LH-Cloth	80-81-82-88 Sedan
C 127788	Trimboard Complete-Lower Quarter-RH-Cloth	83-84 Sedan
C 127789	Trimboard Complete-Lower Quarter-LH-Cloth	83-84 Sedan
C 127790	Trimboard Complete-Lower Quarter-RH-Cloth	85-87 Sedan
C 127791	Trimboard Complete-Lower Quarter-LH-Cloth	85-87 Sedan
C 127792	Trimboard Complete-Lower Quarter-RH-Leather	80-81-82-88 Sedan
C 127793	Trimboard Complete-Lower Quarter-LH-Leather	80-81-82-88 Sedan
C 127796	Trimboard & Trim Assy-Upper Qtr-RH-Cloth	81 thru 85 VicCpe
C 127797	Trimboard & Trim Assy-Upper Qtr-LH-Cloth	81 thru 85 VicCpe
C 127798	Trimboard & Trim Assy-Upper Qtr-RH-Leather	81 thru 85 VicCpe
C 127799	Trimboard & Trim Assy-Upper Qtr-LH-Leather	81 thru 85 VicCpe
C 127800	Trimboard-Lower Qtr-RH-LHD-Cloth	81 thru 85 VicCpe
C 127801	Trimboard-Lower Qtr-LH-RHD-Cloth	81 thru 85 VicCpe
C 127802	Trimboard-Lower Qtr-RH-LHD-Leather	81 thru 85 VicCpe
C 127803	Trimboard-Lower Qtr-LH-RHD-Leather	81 thru 85 VicCpe
C 127804	Trimboard-Lower Qtr-RH-RHD-Leather	81 thru 85 VicCpe
C 127805	Trimboard-Lower Qtr-LH-LHD-Cloth	81 thru 85 VicCpe
C 127806	Trimboard-Lower Qtr-RH-RHD-Leather	81 thru 85 VicCpe
C 127807	Trimboard-Lower Qtr-LH-LHD-Leather	81 thru 85 VicCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 127808	Trimboard & Trim Assy-Folding Seat Bottom-Leather	81 thru 85 VicCpe
C 127813	Trimboard & Trim Assy-Rear Compt Rear-LHD	81 thru 85 VicCpe
C 127814	Trimboard & Trim Assy-Rear Compt Rear-RHD	81 thru 85 VicCpe
C 127815	Trimboard & Trim Assy-Rear Compt End-LHD	81 thru 85 VicCpe
C 127816	Trimboard & Trim Assy-Rear Compt End-RHD	81 thru 85 VicCpe
C 127817	Trimboard & Trim Assy-Folding Seat Partition-LHD	81 thru 85 VicCpe
C 127818	Trimboard & Trim Assy-Folding Seat Partition-RHD	81 thru 85 VicCpe
C 127819	Trimboard & Trim Assy-Folding Seat Comp Rear-LHD	81 thru 85 VicCpe
C 127820	Trimboard & Trim Assy-Folding Seat Comp Rear-RHD	81 thru 85 VicCpe
C 127821	Trimboard & Trim Assy-Folding Seat Center LHD-Cloth	81 thru 85-92-93-95 VicCpe
C 127822	Trimboard & Trim Assy-Folding Seat Center RHD-Cloth	81 thru 85-92-93-95 VicCpe
C 127823	Trimboard & Trim Assy-Folding Seat Center LHD-Leather	81 thru 85-92-93-95 VicCpe
C 127824	Trimboard & Trim Assy-Folding Seat Center RHD-Leather	81 thru 85-92-93-95 VicCpe
C 127825	Folding Seat Complete-LHD-Cloth	81 thru 85-92-93-95 VicCpe
C 127826	Folding Seat Complete-RHD-Cloth	81 thru 85-92-93-95 VicCpe
C 127827	Folding Seat Complete-LHD-Leather	81 thru 85-92-93-95 VicCpe
C 127828	Folding Seat Complete-RHD-Leather	81 thru 85-92-93-95 VicCpe
C 127829	Trim Assy-Folding Seat-LHD-Cloth	81 thru 85-92-93-95 VicCpe
C 127830	Trim Assy-Folding Seat-RHD-Cloth	81 thru 85-92-93-95 VicCpe
C 127831	Trim Assy-Folding Seat-LHD-Leather	81 thru 85-92-93-95 VicCpe
C 127832	Trim Assy-Folding Seat-RHD-Leather	81 thru 85-92-93-95 VicCpe
C 127833	Kick Pad Assy-Front Seat Back Center-Cloth	80 thru 85 Sedan
C 127834	Kick Pad Assy-Front Seat Back-End-RH	80 thru 85 Sedan
C 127835	Kick Pad Assy-Front Seat Back-End-LH	80 thru 85 Sedan
C 127836	Kick Pad Assy-Front Seat Back-Center-Lea	80 thru 85 Sedan
C 127837	Kick Pad Assy-Front Seat Back-Cloth	81 thru 85-89 Bro-VicCpe,80-89 UCpe
C 127842	Carpet Assy-Folding Seat Compt Floor	81 thru 85-92-93-95-41-44-45 VicCpe
C 127854	Liner Assy-Trunk Lid	81 thru 85 Bro-Sed,87-88 Sed,80 Sed-Co
C 127857	Back Complete-Auxiliary Seat-LHD	81 VicCpe
C 127858	Back Complete-Auxiliary Seat-RHD	81 VicCpe
C 127860	Trim Assy-Auxiliary Seat Back-RHD	81 VicCpe
C 127861	Cushion Complete-Auxiliary Seat-LHD	81 VicCpe
C 127862	Cushion Complete-Auxiliary Seat-RHD	81 VicCpe
C 127863	Trim Assy-Auxiliary Seat Cushion-LHD	81 VicCpe
C 127864	Trim Assy-Auxiliary Seat Cushion-RHD	81 VicCpe
C 127865	Back Complete-Auxiliary Seat-LHD	82 VicCpe
C 127866	Back Complete-Auxiliary Seat-RHD	82 VicCpe
C 127868	Trim Assy-Auxiliary Seat Back-RHD	82 VicCpe
C 127869	Cushion Complete-Auxiliary Seat-LHD	82 VicCpe
C 127870	Cushion Complete-Auxiliary Seat-RHD	82 VicCpe
C 127871	Trim Assy-Auxiliary Seat Cushion-LHD	82 VicCpe
C 127872	Trim Assy-Auxiliary Seat Cushion-RHD	82 VicCpe
C 127873	Back Complete-Auxiliary Seat-LHD	83-84 VicCpe
C 127874	Back Complete-Auxiliary Seat-RHD	83-84 VicCpe
C 127875	Trim Assy-Auxiliary Seat Back-LHD	83-84 VicCpe
C 127876	Trim Assy-Auxiliary Seat Back-RHD	83-84 VicCpe
C 127877	Cushion Complete-Auxiliary Seat-LHD	83-84 VicCpe
C 127878	Cushion Complete-Auxiliary Seat-RHD	83-84 VicCpe
C 127879	Trim Assy-Auxiliary Seat Cushion-LHD	83-84 VicCpe
C 127880	Trim Assy-Auxiliary Seat Cushion-RHD	83-84 VicCpe
C 127881	Back Complete-Auxiliary Seat-LHD	85 VicCpe
C 127882	Back Complete-Auxiliary Seat-RHD	85 VicCpe
C 127883	Trim Assy-Auxiliary Seat Back-LHD	85 VicCpe
C 127884	Trim Assy-Auxiliary Seat Back-RHD	85 VicCpe
C 127885	Cushion Complete-Auxiliary Seat-LHD	85 VicCpe
C 127886	Cushion Complete-Auxiliary Seat-RHD	85 VicCpe
C 127887	Trim Assy-Auxiliary Seat Cushion-LHD	85 VicCpe
C 127888	Trim Assy-Auxiliary Seat Cushion-RHD	85 VicCpe
C 127897	Trimboard-Front Seat Back-With Table	80 thru 85 Sedan
C 127899	Trimboard-Folding Table Top	80 thru 87 Sedan
C 127900	Top & Trim Assy-Folding Table-Cloth	86-87 Sedan
C 127951	Back Complete-Front Seat-LHD	80 UC0-UCpe
C 127952	Back Complete-Front Seat-RHD	80 UC0-UCpe
C 127953	Trim Assy-Drivers Seat Back-LHD	80 UC0-UCpe
C 127954	Trim Assy-Drivers Seat Back-RHD	80 UC0-UCpe
C 127955	Cushion Complete-Drivers Seat-LHD	80 UC0-UCpe
C 127956	Cushion Complete-Drivers Seat-RHD	80 UC0-UCpe
C 127957	Trim Assy-Drivers Seat Cushion-LHD	80 UC0-UCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 127958	Trim Assy-Drivers Seat Cushion-RHD	80 UCo-UCpe
C 127963	Back Complete-Passenger Seat-LHD	80 UCo-UCpe
C 127964	Back Complete-Passenger Seat-RHD	80 UCo-UCpe
C 127965	Trim Assy-Passenger Seat Back-LHD	80 UCo-UCpe
C 127966	Trim Assy-Passenger Seat Back-RHD	80 UCo-UCpe
C 127967	Cushion Complete-Passenger Seat-LHD	80 UCo-UCpe
C 127968	Cushion Complete-Passenger Seat-RHD	80 UCo-UCpe
C 127969	Trim Assembly-Passenger Seat Cushion-LHD	80 UCo-UCpe
C 127970	Trim Assembly-Passenger Seat Cushion-RHD	80 UCo-UCpe
C 127973	Back Complete-Rear Seat	80 UCo
C 127974	Trim Assembly-Rear Seat Back	80 UCo
C 127975	Cushion Complete-Rear Seat	80 UCo
C 127976	Trim Assembly-Rear Seat Cushion	80 UCo
C 127991	Carpet Assy-Rear Compartment Floor	81-82-83-84-92-93 CvBro,1940 CvSed
BO 128008	Channel & Supp Bracket Assy-Front Door Glass-Run-RH	81-82-83-90-91-92-93 exc Cv,98 Sed
BO 128009	Channel & Supp Bracket Assy-Front Door Glass-Run-LH	81-82-83-90-91-92-93 exc Cv,98 Sed
BO 128014	Strap-Front Door Regulator to Lock Pillar	81-82-83-90-92-93 exc Cv,98 Sed
BO 128015	Strap-Rear Door Regulator to Lock Pillar	81-82-83-90-92-93 Sedan
C 128018	Arm Rest Assembly-Front Door-RH	81-90-92-93-95 Bro-Sed-3Cpe-VicCpe 80 Co-Cpe, 97-98 Sed
C 128019	Arm Rest Assembly-Front Door-LH	81-90-92-93-95 Bro-Sed-3Cpe-VicCpe 80 Co-Cpe, 97-98 Sed
128020	Arm Rest Assembly-Front Door-RH (Use 1-136586,3-71300,3-18475)	85-90-92-93-95 Bro-Sed-3Cpe-VicCpe
128021	Arm Rest Assembly-Front Door-LH (Use 1-136587,3-71300,3-18475)	85-90-92-93-95 Bro-Sed-3Cpe-VicCpe
C 128027	Seal-Front Pillar to Floor	80,85,87,88,89
BO 128048	Support Assy-Front Seat Back-Center	38 thru 1942 Bro-VicCpe-Cv-UCpe 15 3Cpe,1942 2Sed- ClubCpe-CvSed,1946-1947 Bro-ClubCpe CvBro
BO 128051	Track Assy-Front Seat Adjusting-LH-LHD	38 Sed-3Cpe
128052	Track Assy-F Seat Adj-RH-RHD (Use 128051)	80 thru 88 Sed,81 thru 85 3Cpe
C 128055	Track Assembly-Front Seat-RHD	38-39 Bro-VicCpe-Cv
BO 128056	Rod-Front Seat Track Adjusting	38 thru 1942 Bro-VicCpe-Cv,15 3Cpe,1946-1947 Bro-CvBro-ClubCpe
BO 128096	Handle-Front Seat Track Locking	38-39 Bro-Cv-VicCpe-UCpe
BO 128098	Handle-Front Seat Track Locking	80 thru 88 Sedan-3Cpe
BO 128099	Knob-Front Seat Track Locking Handle	38 All,1939-1940 2Sed-VicCpe-Cv-UCpe,48 CA,1941- 1942 5Sed,10 thru 14-20 thru 24 3Cpe,11-14-21 Station, 1946 Sed-3Cpe
BO 128103	Spring-Front Seat Track Locking Handle	38 Sed-3Cpe-UCo-UCpe-Panel,1939-1940 1941-1942 Bucket Scats
BO 128107	Spring-Front Seat Track Locking Handle	38 thru 1942 2Sed-Cv-VicCpe-UCpe,40T-15-25 3Cpe,1946-1947 Bro-CvBro-ClubCpe
BO 128120	Rest Channel & Guide Assy-Door Window-RH	81-82-83-90-92-93 Bro-3Cpe-VicCpe,98 Sed
BO 128121	Rest Channel & Guide Assy-Door Window-LH	38-39 Bro-3Cpe-VicCpe,98 Sed
BO 128130	Rest Chan & Guide Assy-Front Door Window-RH	81-82-83-91 Sedan
BO 128131	Rest Chan & Guide Assy-Front Door Window-LH	81-82-83-91 Sedan
C 128142	Glass, Frame & Rest Chan Assy-Door Window- RH-Plate	81-89-90 Cv
C 128143	Glass, Frame & Rest Chan Assy-Door Window- LH-Plate	81-89-90 Cv
BO 128166	Handle Assy-Rear Compartment Door	81,82,89,80 UCo-UCpe-Sed,88 Sed,90-92 Cpe-Cv
BO 128168	Handle Assy-Rear Compartment Door	83,84,85,87,93-95 3Cpe-VicCpe-Cv
BO 128173	Arm-Visor Bracket	82 thru 85,87-88 Sedan
BO 128174	Screw-Visor Hinge Clamp to Plate	82 thru 85,87-88 Sedan
BO 128175	Bolt-Visor Hinge Clamp	82 thru 85,87-88 Sedan
128210	Tail & Stop Lamp-Black-6 Volt (Use 128212)	83 thru 87
BO 128212	Tail & Stop Lamp-Prime-6 Volt	83 thru 87
128216	Tail & Stop Lamp Complete-12 Volt (Use 129402)	83,84,85,87
BO 128218	Tail & Stop Lamp Complete-RH-6 Volt	81-82-40T Sed-2Sed,80Sed,90-91 Bro,80-90-40 UCo
BO 128219	Tail & Stop Lamp Complete-LH-6 Volt	81-82-40TSed-2Sed,80 Sed,90-91 Bro, 80-90-40 UCo
BO 128220	Tail & Stop Lamp Complete-RH-12 Volt	81-82-40T Sed-2Sed,80 Sed,90-91 Bro,80-90-40 UCo
BO 128221	Tail & Stop Lamp Complete-LH-12 Volt	81-82-40T Sed-2Sed,80 Sed,90-91 Bro,80-90-40 UCo
BO 128222	Pad-Tail Lamp	83,84,85,87
BO 128224	Pad-Tail and Stop Lamp	81-82 Bro-Sed,80 Co-Sed,88 Sedan
BO 128225	Pad-Tail and Stop Lamp	81-82-91-92-93-95 Cpe-Cv
BO 128226	Tail & Stop Lamp Complete-RH-6 Volt	81-82-91-92-93-95 Cpe-Cv
BO 128227	Tail & Stop Lamp Complete-LH-6 Volt	81-82-91-92-93-95 Cpe-Cv
BO 128228	Tail & Stop Lamp Complete-RH-12 Volt	81-82-91-92-93-95 Cpe-Cv
BO 128229	Tail & Stop Lamp Complete-LH-12 Volt	81-82-91-92-93-95 Cpe-Cv,80 UCpe
BO 128230	Wiring Assy- Tail and Stop Lamp	83,84,85,87
128231	Lens-Tail & Stop Lamp (Use 128234)	83,84,85,87

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 128232	Housing-Tail and Stop Lamp-Black Enamel	83,84,85,87
BO 128233	Housing-Tail and Stop Lamp-Prime	83,84,85,87
BO 128234	Lens and Jewel Assy-Tail Lamp	83,84,85,87
BO 128235	Clip-Tail Lamp Lens Retaining	83,84,85,87
BO 128236	Screw-Tail Lamp Housing to Base Plate	83,84,85,87
F 128238	Handle Assy-Front Door Outside	81,82,88,91,92,80 exc Station
F 128239	Handle Assy-Rear Door Outside	80-81-82-88-90-91 Sed
F 128240	Handle Assy-Front Door Outside	83,84,85,87,92,93,95,97
F 128241	Handle Assy-Rear Door Outside	83,84,85,87,92,93,95,97
BO 128242	Escutcheon-Inside Handle	83,84,85,87 Cloth Trim
BO 128243	Insert-Inside Handle Escutcheon	83,84,85,87
BO 128255	Trim Molding Assy-Rear Door Bottom-LH	83-84-93-95 Sedan
C 128256	Top & Trim Assy-Folding Table-Cloth	83-84 Sedan
C 128257	Top & Trim Assy-Folding Table-Leather	80-81-82 Sedan
BO 128279	Cylinder Assy-Rear Compt Door Lock	38-39 All,1940 Sed-2Sed-Cpe-Cv
BO 128281	Lock & Cylinder Assy-Rear Compt Door	38-39 All,1940 Sed-2Sed-Cpe-Cv
BO 128282	Lock Assy-Rear Compt Door-Less Cyl	38-39 All,1940 Sed-2Sed-Cpe-Cv
BO 128283	Eccentric-Rear Compt Door Lock Operating	38 All,39 Cpe-CvSed
BO 128284	Link-Rear Compartment Door Lock Operating	38 All,1939-1940 Cpe-CvSed
BO 128287	Plunger Assy-Rear Comp't Door Lock Link	1938 thru 1940 All
BO 128288	Guide-Rear Comp't Door Lock Link Plunger	38 All,39-1940 Cpe-Cv,
BO 128289	Spacer-Rear Compt Door-Lock Panel Reinf	38 All,39-1940 Sed-2Sed-UCo
BO 128290	Housing-Rear Compartment Door Lock Link	38 All,39-1940 Cpe-Cv.
BZ 128291	Washer-Compartment Door Lock Operating Spring	38-39 All
A 128293	Cover Assembly-Complete-Battery	80,81,82,88
A 128295	Cover Assembly Complete-Battery	83,84,85,87
BO 128301	Bumper-Rubber	38 thru 1950 All
BO 128305	Clamp-Rear Quarter Cigar Lighter	85-87 Sed,85 Bro
BO 128307	Insert-Rear Quarter Cigar Lighter Escutcheon	85-87 Sedan,85 Bro
BO 128311	Ash Receiver Kit Complete-Rear Quarter	82 Bro
BO 28316	Anti-Rattle Spring Compt Door Lock Plunger	38 thru 1940 All
BO 128317	Housing-Rear Compartment Door Safety Lock	38 thru 1940 All
BO 128327	Bracket Assy-Pkge Compt Panel to Partition Board	81 thru 85-92-93-95 VicCpe,1940-1941 VicCpe- 3Cpe-UCpe,1942 3Cpe-UCpe,1946-1947 3Cpe
BO 128352	Stop Rod-Front Seat Track Adjusting	38-39 Bro-VicCpe-Cv
128353	Rest-Folding Seat (Use 136069)	81 thru 85-93 VicCpe
BO 128356	Weatherstrip-Front Door Bottom	80 thru 85 Sed,80-88 Cab-CabPu-Panel
BO 128357	Weatherstrip-Rear Door Bottom	80 thru 88 Sedan
BO 128373	Fender Lamps-Kit	80 thru 85,87-88,90,98
128374	Visor Kit-RH-Hinge Type (Use 134987)	80,81,82,88
BO 128401	Weather Seal-Folding Top Pillar Bottom-LH	38 thru 1940 CvSed,1940 CvCpe
BZ 28417	Clip-Molding	83,84,85,87,90,93 thru 98
BO 128427	Finish Plate-Arm Rest Panel Ash Receiver-LH	85-87 Sedan
A 128483	Panel Assembly-Instrument	80,88,85,87
BO 128487	Support-Rear Compt Floor Cross Bar Assy-Rear Mount	80-89 UCpe,89 3Cpe-VicCpe-CvCpe
C 128500	Window Assy-Quarter-RH-Crystal	1937 thru 1940 CvBro
C 128501	Window Assy-Quarter-LH-Crystal	1937 thru 1940 CvBro
C 128502	Window Assy-Quarter-RH-Safety	1937 thru 1940 CvBro
C 128503	Window Assy-Quarter-LH-Safety	1937 thru 1940 CvBro
BO 128524	Block & Tee Nut Assy-Door Arm Rest-RH	38-39 All
BO 128525	Block & Tee Nut Assy-Door Arm Rest-LH	38-39 All
BO 128554	Bolt-Top Pivot Bracket to Pillar Slat Iron	38 thru 1940 CvSed,1940 CvCpe
BO 128556	Rivet-Top #1 Link to #4 Link	38 thru 1940 CvSed
BO 128557	Spacer-Top #1 Link to #4 Link Rivet	38 thru 1941 CvSed
BO 128558	Rivet-Top #1 Link to Front Corner Bracket	38 thru 1941 CvSed,1946-1947 CvBro
BO 128566	Rivet-Top #2 Link to Front Corner Bracket	38 thru 1940 CvSed
BO 128568	Rivet-Top #2 Link to #3 Link	38 thru 1940 CvSed
BO 128569	Spacer-Top #2 Link to #3 Link	38 thru 1940 CvSed
BO 128570	Rivet-Top #3 Link to #1 Link	38 thru 1940 CvSed
BO 128571	Spacer-Top #3 Link to #1 Link	38 thru 1940 CvSed
BO 128572	Rivet-Top #3 & #4 Link to Pillar Slat Iron	38 thru 1940 CvSed,1940 CvCpe
BO 128573	Spacer-Top #3 and #4 Link to Pillar Slat Iron	38 thru 1940,CvSed,1940 CvCpe
BO 128574	Rivet-Top #3 Link to Pillar Guide Slat Iron	38 thru 1940 CvSed
BO 128584	Slat Iron-Top Pillar Guide-RH	38 thru 1940 CvSed
BO 128585	Slat Iron-Top Pillar Guide-LH	38 thru 1940 CvSed
BO 128593	Rivet-Top Rear Bow Extension to Hinge Link	38 thru 1940 CvSed
BO 128595	Rivet-Top Rear Bow Ext to Pillar Slat Iron	38 thru 1940 CvSed
BO 128597	Bolt-Top Rear Bow Extension to Auxiliary Bow	38 thru 1940 CvSed
BO 128601	Reinforcement-Quarter Window Curtain-Upper	38 thru 1940 CvSed
BO 128602	Reinforcement-Quarter Window Curtain-Lower	38 thru 1940 CvSed
BO 128604	Shim-Cowl to Bonnet-Upper	80 thru 88
C 128605	Top Complete-Trimmed	81 thru 85 CvBro
C 128606	Rear Curtain & Window Assy-Top	38-39 CvBro,1940 CvSed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 128608	Deck & Side Quarter Assy-Top	81 thru 85 CvBro
C 128612	Back Stay Assembly-Top-RH	81 thru 85-92-93-95 CvBro
C 128613	Back Stay Assembly-Top-LH	81 thru 85-92-93-95 CvBro
C 128616	Weatherseal Flap Assy-Top Side Quarter-RH	81 thru 85 CvBro
C 128617	Weatherseal Flap Assy-Top Side Quarter-LH	81 thru 85 CvBro
C 128619	Dust Boot Assembly-Top	81 thru 85 CvBro
C 128620	Window & Curtain Assy-Rear Quarter-RH	81 thru 85 CvBro,90 CvBro
C 128621	Window & Curtain Assy-Rear Quarter-LH	81 thru 85 CvBro,90 CvBro
C 128624	Bag Assembly-Top Dust Boot	81 thru 85-89-90-41-44 CvSed
BO 128633	Lock & Cyl Assembly-Door Safety	38-39 All,40 Panel
BO 128657	Weatherstrip Assy-Rear Window	38 thru 1946 Cab-CabPu
BO 128659	Tubing-Windshield Cleaner	38 thru 1940 with Std-Fuel Pump
BO 128698	Cylinder & Keys Assy-Door Safety Lock	38-39 All,1940 Cab-CabPu-Panel
C 128703	Back Complete-Front Seat-LHD-Drivers	81-82 Cv
C 128704	Back Complete-Front Seat-RHD-Drivers	81-82 Cv
C 128705	Back Complete-Front Seat-LHD-Drivers	83-84-85 Cv
C 128706	Back Complete-Front Seat-RHD-Drivers	83-84-85 Cv
C 128707	Back Complete-Front Seat-LHD-Passenger	81-82 Cv
C 128708	Back Complete-Front Seat-RHD-Passenger	81-82 Cv
C 128709	Back Complete-Front Seat-LHD-Passenger	83-84-85 Cv
C 128710	Back Complete-Front Seat-RHD-Passenger	83-84-85 Cv
C 128711	Cushion Complete-Front Seat	81-82 Cv
C 128712	Trim Assembly-Front Seat Back-RH	81-82 Cv
C 128713	Trim Assembly-Front Seat Back-LH	81-82 Cv
C 128714	Trim Assembly-Front Seat Back-RH	83-84-85 Cv
C 128715	Trim Assembly-Front Seat Back-LH	83-84-85 Cv
C 128716	Cushion Complete-Front Seat	83-84-85,Cv
C 128717	Trim Assy-Front Seat Cushion	81-82 Cv
C 128718	Trim Assy-Front Seat Cushion	83-84-85 Cv
C 128719	Back Complete-Rear Seat	81-82 Cv
C 128720	Back Complete-Rear Seat	83-84-85 CvBro
C 128722	Trim Assembly-Rear Seat Back	83-84-85 Cv
C 128723	Cushion Complete-Rear Seat	81-82 Cv
C 128724	Cushion Complete-Rear Seat	83-84-85 Cv
C 128725	Trim Assembly-Rear Seat Cushion	81-82 CvBro
BO 128731	Lock Complete-Door Safety	38-39 All,40 Panel
C 128732	Trimboard Complete-Front Door-RH	81 Cv
C 128733	Trimboard Complete-Front Door-LH	81 Cv
C 128735	Trimboard Complete-Front Door-LH	82 Cv
C 128736	Trimboard Complete-Front Door-RH	83-84-85 Cv
C 128737	Trimboard Complete-Front Door-LH	83-84-85 Cv
C 128740	Trimboard Complete-Quarter-RH	81-82 CvBro
C 128741	Trimboard Complete-Quarter-LH	81-82 CvBro
C 128742	Trimboard Complete-Quarter-RH	83-84-85 CvBro
C 128743	Trimboard Complete-Quarter-LH	83-84-85 CvBro
C 128763	Back Comp-Front Seat-Drivers-LHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 128764	Back Comp-Front Seat-Drivers-RHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 128765	Back Comp-Front Seat-Passenger-LHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 128766	Back Comp-Front Seat-Passenger-RHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 128769	Back Comp-Front Seat-Drivers-LHD- Lea	85 Bro
C 128770	Back Comp-Front Seat-Drivers-RHD-Lea	85 Bro
C 128771	Back Comp-Front Seat-Passenger-LHD-Lea	85 Bro
C 128772	Back Comp-Front Seat-Passenger-RHD-Lea	85 Bro
C 128773	Cushion Comp-Front Seat Leather	81 thru 85 Bro-VicCpe
C 128774	Trim Assy-Front Seat Back-RH-Leather	81 thru 85 Bro-VicCpe
C 128775	Trim Assy-Front Seat Back-LH-Leather	81 thru 85 Bro-VicCpe
C 128776	Trim Assy-Front Seat Cushion-Leather	81 thru 85 Bro-VicCpe
C 128777	Back Complete-Front Seat-LHD-Leather	81-82 Sed Without Table
C 128778	Back Complete-Front Seat-RHD-Leather	81-82 Sed Without Table
C 128779	Back Complete-Front Seat-LHD-Leather	83-84 Sed Without Table
C 128780	Back Complete-Front Seat-RHD-Leather	83-84 Sed Without Table
C 128781	Back Complete-Front Seat-LHD-Leather	85 Sed,81 thru 84 Sed With Table
C 128782	Back Complete-Front Seat-RHD-Leather	85 Sed,81 thru 84 Sed With Table
C 128783	Back Complete-Front Seat-LHD-Leather	87 Sedan
C 128784	Back Complete-Front Seat-RHD-Leather	87 Sedan
C 128785	Back Complete-Front Seat-LHD-Leather	88 Sedan
C 128786	Back Complete-Front Seat-RHD-Leather	88 Sedan
C 128787	Back Complete-Front Seat-LHD-Cloth	80-81 Sed With Table
C 128788	Back Complete-Front Seat-RHD-Cloth	80-81 Sed With Table
C 128805	Back Complete-Front Seat-LHD-Cloth	82 Sed With Table
C 128806	Back Complete-Front Seat-RHD-Cloth	82 Sed With Table
C 128807	Back Complete-Front Seat-LHD-Cloth	83-84 Sed With Table
C 128808	Back Complete-Front Seat-RHD-Cloth	83-84 Sed With Table
C 128809	Back Complete-Front Seat-LHD-Cloth	80 Sed Without Table

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 128810	Back Complete-Front Seat-RHD-Cloth	80 Sed Without Table
C 128811	Back Complete-Front Seat-LHD-Cloth	88 Sedan
C 128812	Back Complete-Front Seat-RHD-Cloth	88 Sedan
C 128813	Back Complete-Front Seat-LHD-Leather	81-82 Sed With Table
C 128814	Back Complete-Front Seat-RHD-Leather	81-82 Sed With Table
C 128815	Back Complete-Front Seat-LHD-Leather	83-84 Sed With Table
C 128816	Back Complete-Front Seat-RHD-Leather	83-84 Sed With Table
C 128817	Back Complete-Front Seat-LHD-Leather	81 thru 85 3Cpe
C 128818	Back Complete-Front Seat-RHD-Leather	81 thru 85 3Cpe
C 128819	Trim Assy-Front Seat Back-Leather	81 thru 85 Sed-3Cpe,87-88 Sedan
C 128820	Trim Assy-Front Seat Cushion-Leather	81 thru 85 Sed-3Cpe,87-88 Sedan
C 128821	Cushion Complete-Front Seat-Leather	81-82 Sed-3Cpe,88 Sedan
C 128822	Cushion Complete-Front Seat-Leather	83-84-85 Sed-3Cpe,87 Sedan
C 128823	Back Complete-Rear Seat-Leather	81 thru 84 Bro
C 128824	Trim Assy-Rear Seat-Back-Leather	81 thru 84 Bro
C 128825	Back Complete-Rear Seat-Leather	85 Bro-Sed,87 Sedan
C 128826	Trim Assy-Rear Seat-Back-Leather	85 Bro-Sed,87 Sedan
C 128827	Back Complete-Rear Seat-Leather	81-82-83-84-88 Sedan
C 128828	Trim Assy-Rear Seat Back-Leather	81-82-83-84-88 Sedan
C 128829	Cushion Complete-Rear Seat-Cloth	82-88 Sedan
C 128830	Trim Assy-Rear Seat Cushion-Cloth	88 Sedan
C 128831	Cushion Complete-Rear Seat-Leather	81 thru 85 Bro
C 128832	Trim Assy-Rear Seat-Cushion-Leather	81 thru 85 Bro
C 128833	Cushion Complete-Rear Seat-Leather	81 thru 88 Sedan
C 128834	Trim Assy-Rear Seat Cushion-Leather	81 thru 88 Sedan
C 128837	Back Complete-Front Seat	38 thru 1947 Cab-CabPu
C 128854	Trimboard Complete-Front Door-RH-Cloth	82 Bro-3Cpe-VicCpe
C 128855	Trimboard Complete-Front Door-LH-Cloth	82 Bro-3Cpe-VicCpe
C 128856	Trimboard Complete-Front Door-RH-Cloth	83 Bro-3Cpe-VicCpe
C 128857	Trimboard Complete-Front Door-LH-Cloth	83 Bro-3Cpe-VicCpe
C 128858	Trimboard Complete-Front Door-RH-Cloth	82 Sedan
C 128859	Trimboard Complete-Front Door-LH-Cloth	82 Sedan
C 128860	Trimboard Complete-Front Door-RH-Cloth	83 Sedan
C 128862	Trimboard Complete-Front Door-RH-Leather	82 Bro-3Cpe-VicCpe
C 128863	Trimboard Complete-Front Door-LH-Leather	82 Bro-3Cpe-VicCpe
C 128864	Trimboard Complete-Front Door-RH-Leather	82 Sedan
C 128865	Trimboard Complete-Front Door-LH-Leather	82 Sedan
C 128866	Door Complete-Front-RH-Cloth	82 Bro
C 128867	Door Complete-Front-LH-Cloth	82 Bro
C 128868	Door Complete-Front-RH-Leather	82 Bro
C 128869	Door Complete-Front-LH-Leather	82 Bro
C 128870	Door Complete-Front-RH-Cloth	83 Bro
C 128871	Door Complete-Front-LH-Cloth	83 Bro
C 128874	Door Complete-Front-RH-Cloth	82 Sed
C 128875	Door Complete-Front-LH-Cloth	82 Sed
C 128876	Door Complete-Front-RH-Leather	82 Sed
C 128877	Door Complete-Front-LH-Leather	82 Sed
C 128878	Door Complete-Front-RH-Cloth	83 Sed
C 128879	Door Complete-Front-LH-Cloth	83 Sed
C 128882	Door Complete-Front-RH-Cloth	82 3Cpe-VicCpe
C 128883	Door Complete-Front-LH-Cloth	82 3Cpe-VicCpe
C 128884	Door Complete-Front-RH-Leather	82 3Cpe-VicCpe
C 128885	Door Complete-Front-LH-Leather	82 3Cpe-VicCpe
C 128886	Door Complete-Front-RH-Cloth	83 3Cpe-VicCpe
C 128887	Door Complete-Front-LH-Cloth	83 3Cpe-VicCpe
C 128888	Door Complete-Front-RH-Leather	83 3Cpe-VicCpe
C 128889	Door Complete-Front-LH-Leather	83 3Cpe-VicCpe
C 128890	Lower Trim-Rear Window	81 thru 85 Bro-Sed,80-87-88 Sed 80 Co
C 128895	Back Complete-Front Seat-LH-Drivers-Cloth	80 UCpe
C 128896	Back Complete-Front Seat-RH-Drivers-Cloth	80 UCpe
C 128897	Back Complete-Front Seat-LHD-Drivers-Lea	80 UCpe
C 128898	Back Complete-Front Seat-RHD-Drivers-Lea	80 UCpe
C 128899	Back Complete-Front Seat-LHD-Pass-Cloth	80 UCpe
C 128900	Back Complete-Front Seat-RHD-Pass-Cloth	80 UCpe
C 128901	Back Complete-Front Seat-LHD-Pass-Leather	80 UCpe
C 128902	Back Complete-Front Seat-RHD-Pass-Leather	80 UCpe
C 128903	Cushion Complete-Front Seat-Cloth	80 UCpe
C 128904	Trim Assy-Front Seat Back-RH-Cloth	80 UCpe
C 128905	Trim Assy-Front Seat Back-LH-Cloth	80 UCpe
C 128906	Trim Assy-Front Seat Back-RH-Leather	80 UCpe
C 128907	Trim Assy-Front Seat Back-LH-Leather	80 UCpe
C 128908	Cushion Complete-Front Seat-Leather	80 UCpe
C 128909	Trim Assy-Front Seat Cushion-Cloth	80 UCpe
C 128910	Trim Assy-Front Seat Cushion-Leather	80 UCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 128915	Cushion Assy-Complete-Rear Seat-Cloth	83-84 Bro
C 128916	Cushion Assy-Complete-Rear Seat-Cloth	85 Bro
C 128928	Door Assy-Front-RH-Prime	82 Bro
C 128937	Door Assembly-Front-LH-Prime	82 3Cpe-VicCpe
BO 128938	Molding Kit-Radiator Shell	83,84,85,87
C 128966	Trimboard Complete-Front Door-RH-Leather	88 Sedan
C 128967	Trimboard Complete-Front Door-LH-Leather	88 Sedan
C 128968	Trimboard Complete-Front Door-RH-Cloth	80 Sedan
C 128969	Trimboard Complete-Front Door-LH-Cloth	80 Sedan
C 128970	Trimboard Complete-Front Door-RH-Leather	80-88 Cab-CabPu Panel
C 128971	Trimboard Complete-Front Door-LH-Leather	80-88 Cab-CabPu Panel
C 128972	Side Panel Extension & Trim Assy-Front Seat-RH-Cloth	83-84-85 Sed-3Cpe,87 Sed,80-81-82 Sedan With Table
C 128973	Side Panel Extension & Trim Assy-Front Seat-LH-Cloth	83-84-85 Sed-3Cpe,87 Sed,80-81-82 Sedan With Table
C 128974	Molding and Trim Assy-Front Seat Side Panel-RH-Cloth	85 Sed-3Cpe,87 Sed 80-81-82 Sedan With Table
C 128975	Molding and Trim Assy-Front Seat Side Panel- LH-Cloth	85 Sed-3Cpe,87 Sed,80-81-82 Sedan With Table
C 128976	Trimboard Comp-Lower Quarter-RH-Cloth	80 UCpe
C 128977	Trimboard Comp-Lower Quarter-LH-Cloth	80 UCpe
C 128978	Trimboard Comp-Lower Quarter-LH-Leather	80 UCpe
C 128979	Trimboard Comp-Lower Quarter-RH-Leather	80 UCpe
C 128980	Trimboard & Trim Assy-Upper Qtr-RH-Cloth	80 UCpe
C 128981	Trimboard & Trim Assy-Upper Qtr-LH-Cloth	80 UCpe
C 128982	Trimboard & Trim Assy-Upper Qtr-RH-Leather	80 UCpe
C 128983	Trimboard & Trim Assy-Upper Qtr-LH-Leather	80 UCpe
C 128984	Trimboard Comp-Lower Quarter-RH-Cloth	80 UCpe
C 128985	Trimboard Comp-Lower Quarter-LH-Cloth	80 UCpe
C 128986	Trimboard Comp-Lower Quarter-RH-Leather	80 UCpe
C 128987	Trimboard Comp-Lower Quarter-LH-Leather	80 UCpe
C 128988	Finish Panel Assy-Center Pillar-RH-Cloth	83,84,85,87,93,95,97 Sedan
C 128989	Finish Panel Assy-Center Pillar-LH-Cloth	83,84,85,87,93,95,97 Sedan
C 128990	Finish Panel Assy-Center Pillar-RH-Leather	83,84,85,87,93,95,97 Sedan
C 128991	Finish Panel Assy-Center Pillar-LH-Leather	83,84,85,87,93,95,97 Sedan
C 128992	Trimboard & Trim Assy-Front Seat Compartment Bottom	80 UCpe
C 128993	Trimboard & Trim Assy-Front Seat Compartment Rear	80 UCpe
C 128994	Partition & Trim Assy-Rear Compartment	80 UCpe
F 129000	Lens-Headlamp-Domestic	80,81,82,88,90 Bro-Sed,98 Sed
BO 129001	Lens-Headlamp-Export	80,81,82,88
BO 129002	Gasket Assembly-Headlamp	80,81,02,88,90 Bro-Sed,98 Sed
BO 129003	Spring Assy-Headlamp Reflector Adj Arm	83,84,85,87
BO 129004	Retainer-Headlamp Lens	83,84,85,87
BO 129005	Spring Assy-Headlamp Reflector Adj Arm	80,81,82,88
BO 129006	Spring-Headlamp Adjusting	80 thru 85,87,88
BO 129007	Rim-Headlamp	83,84,85,87
BO 129010	Gasket Assembly-Headlamp	83,84,85,87
BO 129011	Clip-Headlamp Reflector Adjusting Screw	80 thru 85,87,88
BO 129012	Bushing-Headlamp Reflector Adjusting Screw	80 thru 85,87,88
BO 129013	Reflector Assy-Headlamp-With Parking Bulb	80,81,82,88
BO 129014	Reflector Assy-Headlamp-Without Parking Bulb	80,81,82,88
BO 129015	Reflector Assy-Headlamp-Domestic	80,81,82,88,90 Bro-Sed,98 Sed
BO 129016	Reflector Assy-Headlamp-With Parking Bulb	83,84,85,87
BO 129017	Reflector Assy-Headlamp-Without Parking Bulb	83,84,85,87
BO 129018	Reflector Assy-Headlamp	83,84,85,87
BO 129019	Housing Assy-Headlamp-Reflector	83,84,85,87
BO 129020	Socket & Wires Assy-Headlamp RH-Without Parking Bulb	80,81,82,88
BO 129021	Socket & Wires Assy-Headlamp-LH-Without Parking Bulb	80 thru 85,87,88
BO 129022	Socket & Wires Assy-Headlamp-RH-Without Parking Bulb	83,84,85,87
BO 129023	Housing Assy-Headlamp Reflector	80,81,82,88
BO 129024	Socket & Wires Assy-Headlamp-RH-With Parking Bulb	80,81,82,88
BO 129025	Socket & Wires Assy-Headlamp-LH-With Parking Bulb	80 thru 88
BO 129027	Screw-Headlamp Reflector Adjusting	80 thru 88
BO 129028	Socket & Wires Assy-Headlamp-RH-With Parking Bulb	80,81,82,88
BO 129029	Socket & Wires Assy-Headlamp-LH-With Parking Bulb	80 thru 88
BO 129030	Socket & Wires Assy-Headlamp-RH-With Parking Bulb	83,84,85,87
BO 129031	Locking Screw-Headlamp Reflector Housing	80,81,82,88,90 Bro-Sed,98 Sed
BO 129032	Housing Assy-Headlamp-RH-Prime	83,84,85,87
BO 129034	Housing Assy-Headlamp-RH-En (Use 129032)	83,84,85,87
BO 129045	Housing Assy-Headlamp-LH-En	80,81,82,88
BO 129046	Housing Assy-Headlamp-RH-Prime	80,81,82,88
BO 129047	Housing Assy-Headlamp-LH-Prime	80,81,82,88

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 129048	Locking Screw-Headlamp Lens & Rim Assy	83,84,85,87
BO 129049	Bracket-Headlamp Lens Locking Screw	83,84,85,87
BO 129050	Wiring Assy-Tail & Stop Lamp	81-82-91-92-93-95 Cpe-Cv,40 UCo
BO 129051	Wiring Assy-Tail & Stop Lamp	81-82-40T Sed-2Sed,90 Bro,80-88 Sed,80-90 UCo
BO 129052	Gasket-Tail & Stop Lamp Lens	80,81,82,80-88 Sed,90-91 Bro,91 thru 95 Cpe-Cv, 40T Sed-2Sed,90-40 UCo
BO 129053	Retainer-Tail & Stop Lamp Lens	80,81,82,80-88 Sed,90-91 Bro,91 thru 95 Cpe-Cv, 40T Sed-2Sed,90-40 UCo
BO 129054	Lens-Tail & Stop Lamp-RH	81-82-40T Sed-2Sed,80-88 Sed,90-91 Bro,80-90- 40 UCo
BO 129055	Lens-Tail & Stop Lamp-LH	81-82-40T Sed-2Sed,80-88 Sed,90-91 Bro,80-90- 40 UCo
BO 129056	Lens-Tail & Stop Lamp-RH	81-82-92-93-95 VicCpe-3Cpe-Cv
BO 129057	Lens-Tail & Stop Lamp-LH	81-82-92-93-95 VicCpe-3Cpe-Cv
BO 129063	Retainer-Headlamp Reflector-Upper	80,81,82,88
A 129068	Shell Assembly-Radiator-Prime	83
A 129070	Shell Assembly-Radiator-Prime	80,81,82,88
A 129071	Shell Assembly-Radiator-Prime	84,85,87
BZ 129072	Bracket-Bonnet Side Panel to Rad Shell-RH	38-39 All
BZ 129073	Bracket-Bonnet Side Panel to Rad Shell-LH	38-39 All
BO 129074	Latch Assembly-Bonnet-RH	80,81,82,88
BO 129075	Latch Assembly-Bonnet-LH	80,81,82,88
BO 129078	Latch Assembly-Bonnet-RH	83,84,85,87
BO 129079	Latch Assembly-Bonnet-LH	83,84,85,87
129080	Bracket-RH Front-LH Rear-Bonnet Latch Rod (Use 126342)	83,84,85,87
129081	Bracket-LH Front-RH Rear-Bonnet Latch Rod (Use 126343)	83 ,84,85,87
A 129082	Panel Assembly-Bonnet Side-RH	80,81,82,88
A 129083	Panel Assembly-Bonnet Side-LH	80,81,82,88
A 129086	Panel Assembly-Bonnet Side-RH	83,84,85,87
A 129087	Panel Assembly-Bonnet Side-LH	83,84,85,87
BO 129093	Reinf Assy-Bonnet Top Panel-Front-LH	80 thru 85,87,88
BO 129097	Reinf Assy-Bonnet Top Panel-Rear-LH	80 thru 88
BO 129099	Latch Brkt-Bonnet Top Panel Reinf-LH	80 thru 88
A 129100	Panel Assembly-Bonnet Top-RH	80,81,82,88
A 129101	Panel Assembly-Bonnet Top-LH	80,81,82,88
BO 129105	Dowel-Seat Cushion	38 thru 1947 Cab-CabPu
BO 129106	Base Plate Assembly-Tail Lamp-RH	81,82,80-90-40 UCo,90-91 Bro,91-93-95 Cpe-Cv, 40T Sed-2Sed
BO 129107	Base Plate Assembly-Tail Lamp-LH	81,82,80-90-40 UCo,90-91 Bro,91-93-95 Cpe-Cv, 40T Sed-2Sed
A 129110	Panel Assembly-Bonnet Top-RH	83,84,85,87
A 129111	Panel Assembly-Bonnet Top-LH	83,84,85,87
C 129120	Arm Rest Assy-Quarter-RH-Leather	83-84 Bro
C 129121	Arm Rest Assy-Quarter-LH-Leather	83-84 Bro
C 129122	Trim Assy-Quarter Arm Rest-RH-Leather	83-84 Bro
C 129123	Trim Assy-Quarter Arm Rest-LH-Leather	83-84 Bro
C 129125	Arm Rest Assy-Quarter-RH-Leather	85 Bro
C 129124	Arm Rest Assy-Quarter-LH-Leather	85 Bro
C 129126	Trim Assy-Quarter Arm Rest-RH-Leather	85 Bro
C 129127	Trim Assy-Quarter Arm Rest-LH-Leather	85 Bro
C 129128	Arm Rest Assy-Quarter-RH-Leather	83-84 Sedan
C 129129	Arm Rest Assy-Quarter-LH-Leather	83-84 Sedan
C 129130	Trim Assy-Quarter Arm Rest-RH-Leather	83-84 Sedan
C 129131	Trim Assy-Quarter Arm Rest-LH-Leather	83-84 Sedan
C 129132	Arm Rest Assy-Quarter-RH-Leather	85-87 Sedan
C 129133	Arm Rest Assy-Quarter-LH-Leather	85-87 Sedan
C 129134	Trim Assy-Quarter Arm Rest-RH-Leather	85-87 Sedan
C 129135	Trim Assy-Quarter Arm Rest-LH-Leather	85-87 Sedan
C 129136	Door Complete-Front-RH-Leather	83 Bro-Sed
C 129137	Door Complete-Front-LH-Leather	83 Bro-Sed
C 129138	Door Complete-Front-RH-Leather	84 Bro
C 129139	Door Complete-Front-LH-Leather	84 Bro
C 129140	Door Complete-Front-RH-Leather	85 Bro,87 Sedan
C 129141	Door Complete-Front-LH-Leather	85 Bro,87 Sedan
C 129142	Door Complete-Front-RH-Leather	83 Sedan
C 129143	Door Complete-Front-LH-Leather	83 Sedan
C 129144	Door Complete-Front-RH-Leather	84 Sedan
C 129145	Door Complete-Front-LH-Leather	84 Sedan
C 129146	Door Complete-Front-RH-Leather.	85 Sedan
C 129147	Door Complete-Front-LH-Leather	85 Sedan
C 129148	Door Complete-Front-RH-Leather	83 VicCpe-3Cpe
C 129149	Door Complete-Front-LH-Leather	83 VicCpe-3Cpe
C 129150	Door Complete-Front-RH-Leather	84 VicCpe-3Cpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 129151	Door Complete-Front-LH-Leather	84 VicCpe-3Cpe
C 129152	Door Complete-Front-RH-Leather	85 VicCpe-3Cpe
C 129153	Door Complete-Front-LB-Leather	85 VicCpe-3Cpe
C 129154	Door Complete-Rear-RH-Leather	83-84-85 Sedan
C 129155	Door Complete-Rear-LH-Leather	83-84-85 Sedan
C 129156	Door Complete-Rear-RH-Leather	87 Sedan
C 129157	Door Complete-Rear-LH-Leather	87 Sedan
C 129158	Trimboard Complete-Front Door-RH-Leather	83 Bro-3Cpe-VicCpe
C 129159	Trimboard Complete-Front Door-LH-Leather	83 Bro-3Cpe-VicCpe
C 129160	Trimboard Complete-Front Door-RH-Leather	84-85 Bro-3Cpe-VicCpe,87 Sed
C 129161	Trimboard Complete-Front Door-LH-Leather	84-85 Bro-3Cpe-VicCpe,87 Sed
C 129162	Trimboard Complete-Front Door-RH-Leather	83 Sedan
C 129163	Trimboard Complete-Front Door-LH-Leather	83 Sedan
C 129164	Trimboard Complete-Front Door-RH-Leather	84-85 Sedan
C 129165	Trimboard Complete-Front Door-LH-Leather	84-85 Sedan
C 129166	Trimboard Complete-Rear Door-RH-Leather	83-84-85-87 Sedan
C 129167	Trimboard Complete-Rear Door-LH-Leather	83-84-85-87 Sedan
C 129168	Trimboard Complete-Lower Quarter-RH-Leather	83-84 Bro
C 129169	Trimboard Complete-Lower Quarter-LH-Leather	83-84 Bro
C 129170	Trimboard Complete-Lower Quarter-RH-Leather	85 Bro
C 129171	Trimboard Complete-Lower Quarter-LH-Leather	85 Bro
C 129172	Trimboard Complete-Lower Quarter-RH-Leather	83-84 Sedan
C 129173	Trimboard Complete-Lower Quarter-LH-Leather	83-84 Sedan
C 129174	Trimboard Complete-Lower Quarter-RH-Leather	85-87 Sedan
C 129175	Trimboard Complete-Lower Quarter-LH-Leather	85-87 Sedan
C 129176	Back Complete-Rear Seat-Leather	81 thru 84 Bro
C 129182	Back Complete-Front Seat-Drivers-RHD-Cloth	85 Bro
C 129184	Back Complete-Front Seat-Pass-RHD-Cloth	85 Bro
C 129185	Back Complete-Front Seat-Drivers-LHD-Cloth	85 VicCpe
C 129186	Back Complete-Front Seat-Drivers-RHD-Cloth	85 VicCpe
C 129187	Back Complete-Front Seat-Pass-LHD-Cloth	85 VicCpe
C 129188	Back Complete-Front Seat-Pass-RHD-Cloth	85 VicCpe
C 129189	Back Complete-Front Seat-LHD-Cloth	85 Sedan
C 129190	Back Complete-Front Seat-RHD-Cloth	85 Sedan
C 129191	Back Complete-Front Seat-LHD-Cloth	87 Sedan
C 129192	Back Complete-Front Seat-RHD-Cloth	87 Sedan
C 129193	Back Complete-Front Seat-LHD-Cloth	85 3Cpe
C 129194	Back Complete-Front Seat-RHD-Cloth	85 3Cpe
C 129195	Trim Assy-Front Seat Back-Cloth	85 Sedan-3Cpe,87 Sedan
C 129196	Trim Assy-Front Seat Back-RH-Cloth	85 Bro -VicCpe
C 129197	Trim Assy-Front Seat Back-LH-Cloth	85 Bro-VicCpe
C 129198	Back Complete-Rear Seat-Cloth	85 Bro
C 129199	Trim Assy-Rear Seat-Back-Cloth	85 Bro
C 129200	Back Complete-Rear Seat-Cloth	85-87 Sedan
C 129201	Trim Assy-Rear Seat Back-Cloth	85-87 Sedan
C 129202	Trim Assy-Rear Seat Back-Leather	81 thru 84 Bro
C 129207	Back Complete-Front Seat-Drivers-LHD	81-82 Cv
C 129208	Back Complete-Front Seat-Drivers-RHD	81-82 Cv
C 129209	Back Complete-Front Seat-Passenger-LHD	81-82 Cv
C 129210	Back Complete-Front Seat-Passenger-RHD	81-82 Cv
C 129211	Back Complete-Front Seat-Drivers-LHD	83-84-85 Cv
C 129212	Back Complete-Front Seat-Drivers-RHD	83-84-85 Cv
C 129213	Back Complete-Front Seat-Passenger-LHD	83-84-85 Cv
C 129214	Back Complete-Front Seat-Passenger-RHD	83-84-85 Cv
C 129215	Back Complete-Rear Seat-Leather	81-82-83-84-88 Sedan
C 129216	Trim Assembly-Front Seat Back-RH	81-82 Cv
C 129217	Trim Assembly-Front Seat Back-LH	81-82 Cv
C 129218	Trim Assembly-Front Seat Back-RH	83-84-85 Cv
C 129219	Trim Assembly-Front Seat Back-LH	83-84-85 Cv
C 129220	Trim Assembly-Rear Seat Back-Leather	81-82-83-84-88 Sedan
C 129225	Back Complete-Front Seat-Drivers-LHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 129226	Back Complete-Front Seat-Drivers-RHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 129227	Back Complete-Front Seat-Pass-LHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 129228	Back Complete-Front Seat-Pass-LHD-Lea	81 thru 84 Bro-VicCpe,85 VicCpe
C 129229	Back Complete-Front Seat-Drivers-LHD-Lea	85 Bro
C 129230	Back Complete-Front Seat-Drivers-RHO-Lea	85 Bro
C 129231	Back Complete-Front Seat-Pass-LHD-Lea	85 Bro
C 129232	Back Complete-Front Seat-Pass-RHD-Lea	85 Bro
C 129233	Back Complete-Front Seat-LHD-Leather	81-82 Sed Without Table
C 129234	Back Complete-Front Seat-RHD-Leather	81-82 Sed Without Table
C 129235	Back Complete-Front Seat-LHD-Leather	83-84 Sed Without Table
C 129236	Back Complete-Front Seat-RHD-Leather	83-84 Sed Without Table
C 129237	Back Complete-Front Seat-LHD-Leather	85 Sed,81 thru 84 Sed With Table
C 129238	Back Complete-Front Seat-RHD-Leather	35 Sed,81 thru 84 Sed With Table
C 129239	Back Complete-Front Seat-LHD-Leather	87 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 129240	Back Complete-Front Seat-RHD-Leather	87 Sedan
C 129241	Back Complete-Front Seat-LHD-Leather	88 Sedan
C 129242	Back Complete-Front Seat-RHD-Leather	88 Sedan
C 129243	Back Complete-Front Seat-LHD-Leather	81 thru 85 3Cpe
C 129244	Back Complete-Front Seat-RHD-Leather	81 thru 85 3Cpe
C 129245	Trim Assembly-Front Seat-Back-Leather	81 thru 85 Sed-3Cpe,87-88 Sed
C 129246	Trim Assembly-Front Seat Back-RH-Leather	81 thru 85 Bro-VicCpe
C 129247	Trim Assembly-Front Seat Back-LH-Leather	81 thru 85 Bro-VicCpe
C 129248	Back Complete-Rear Seat-Leather	85 Bro-Sed,87 Sedan
C 129249	Trim Assembly-Rear Seat Back-Leather	85 Bro-Sed,87 Sedan
BO 129260	Lens-Spot Light	All
BO 129261	Lens-Fog Lamp	All
BO 129262	Gasket-Fog Lamp & Spot Light	All
BO 129263	Rim-Fog Lamp & Spot Light	All
BO 129264	Screw-Fog Lamp & Spot Light Rim	All
BO 129267	Trim Molding Kit-Rear Door Bottom	38-39 Sed,40 thru 45 Sed
C 129276	Trim Panel & Trim Assy-Front Seat End-RH-Cloth	38 Bro-VicCpe-UCpe,91 Bro-VicCpe
C 129277	Trim Panel & Trim Assy-Front Seat End-LH-Cloth	38 Bro-VicCpe-UCpe,91 Bro-VicCpe
C 129278	Trim Panel & Trim Assy-Front Seat End-RH-Leather	38 Bro-VicCpe-Cv-UCpe,91 Bro-VicCpe
C 129279	Trim Panel & Trim Assy-Front Seat End-LH-Leather	38 Bro-VicCpe-Cv-UCpe,91 Bro-VicCpe
C 129304	Trimboard Complete-Lower Quarter-RH	81 Bro
C 129305	Trimboard Complete-Lower Quarter-LH	81 Bro
C 129308	Trimboard Complete-Lower Quarter-RH	82 Bro
C 129309	Trimboard Complete-Lower Quarter-LH	82 Bro
C 129310	Trimboard Complete-Lower Quarter-RH	83-84 Bro
C 129311	Trimboard Complete-Lower Quarter-LH	83-84 Bro
C 129312	Trimboard Complete-Lower Quarter-RH	85 Bro
C 129313	Trimboard Complete-Lower Quarter-LH	85 Bro
C 129314	Trimboard Complete-Lower Quarter-RH-Lea	81-82 Bro
C 129315	Trimboard Complete-Lower Quarter-LH-Lea	81-82 Bro
C 129316	Trimboard Complete-Lower Quarter-RH-Lea	83-84 Bro
C 129317	Trimboard Complete-Lower Quarter-LH-Lea	83-84 Bro
C 129318	Trimboard Complete-Lower Quarter-RH-Lea	85 Bro
C 129319	Trimboard Complete-Lower Quarter-LH-Lea	85 Bro
C 129320	Trimboard Complete-Lower Quarter-RH-Cloth	81-82-88 Sedan
C 129321	Trimboard Complete-Lower Quarter-LH-Cloth	81-82-88 Sedan
C 129322	Trimboard Complete-Lower Quarter-RH-Cloth	83-84 Sedan
C 129323	Trimboard Complete-Lower Quarter-LH-Cloth	83-84 Sedan
C 129324	Trimboard Complete-Lower Quarter-RH-Cloth	85-87 Sedan
C 129325	Trimboard Complete-Lower Quarter-LH-Cloth	85-87 Sedan
C 129326	Trimboard Complete-Lower Quarter-RH-Lea	81-82-88 Sedan
C 129327	Trimboard Complete-Lower Quarter-LH-Lea	81-82-88 Sedan
C 129328	Trimboard Complete-Lower Quarter-RH-Lea	83-84 Sedan
C 129329	Trimboard Complete-Lower Quarter-LH-Lea	83-84 Sedan
C 129330	Trimboard Complete-Lower Quarter-RH-Lea	85-87 Sedan
C 129331	Trimboard Complete-Lower Quarter-LH-Lea	85-87 Sedan
C 129342	Door Complete-RH-Front-Cloth	85 Bro,87 Sedan
C 129343	Door Complete-LB-Front-Cloth	85 Bro,87 Sedan
C 129344	Door Complete-RH-Front-Cloth	85 Sedan
C 129345	Door Complete-LH-Front-Cloth	85 Sedan
C 129346	Door Complete-RH-Cloth	85 VicCpe-3Cpe
C 129347	Door Complete-LH-Cloth	85 VicCpe-3Cpe
C 129348	Door Complete-RH-Rear-Cloth	85 Sedan
C 129349	Door Complete-LH-Rear-Cloth	85 Sedan
C 129350	Door Complete-RH-Rear-Cloth	87 Sedan
C 129351	Door Complete-LH-Rear-Cloth	87 Sedan
C 129359	Gauge Assembly-Water Temperature	80,81,82,88,92,90 Station,91
BO 129360	Temperature & Generator Indicator Assy	80,81,82,88,91,92
F 129361	Gauge Assembly-Water Temperature	83,84,85,87
BO 129362	Temperature & Generator Indicator Assy	83,84,85,87
F 129363	Gauge Kit-Water Temperature	80,81,82,88,92
F 129364	Gauge Kit-Water Temperature	83,84,85,87
129367	Use 142146	
C 129374	Spring-Rear Seat Cushion	85 Bro
BO 129392	Jewel-Assembly-Tail Lamp Lens	83 thru 87
BO 129393	Clamp-Tail Lamp Lens Jewel	83 thru 87
129394	Nut-Tail Lamp Lens Jewel (Use 71073)	83 thru 87
BO 129395	Shield-Tail Lamp Lens Jewel	83 thru 87
C 129398	Header Assembly-Body-RH	87-88 Sedan
C 129399	Header Assembly-Body-LH	87-88 Sedan
129400	Lamp Complete-Tail & Stop-6 Volt-Black En (Use 128212)	83,84,85,87
129401	Lamp Complete-Tail & Stop-6 Volt (Use 128212)	83,84,85,87
BO 129402	Lamp Complete-Tail & Stop-12 Volt-Prime	83,84,85,87

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models	
	129403	Lens & Jewel Assy-Tail & Stop Lamp (Use 128234)	83,84,85,87
BO	129404	Base Plate & Wires Assy-Tail & Stop Lamp	83,84,85,87
BO	129407	Housing Assy-Tail Lamp-Enamel	83,84,85,87
BO	129408	Housing Assy-Tail & Stop Lamp-Pr	83 ,84 ,85 ,87
BO	129409	Gasket-Tail & Stop Lamp Lens	83,84,85,87
BZ	129410	Bracket Assy-Tail & Stop Lamp	38 thru 1940 CabPu,11-14-21-178 Station,1946-1947 CabPu
F	129430	Water Temperature Gauge Kit	1936 Kit
F	129431	Water Temperature Gauge Kit-1st type	1937 All
F	129432	Water Temperature Gauge Kit-2nd type	1937 All
BO	129445	Gauge-Temperature	36 All
BO	129446	Gauge-Temperature	37 Terr
BO	129447	Gauge-Temperature	37 Hudson
C	129459	Trimboard & Trim Assy-Frt Seat Compt Bottom	80 UCpe
A	130002	Fender Assembly-Front-RH-Prime	89
BZ	130009	Support Assembly-Front Fender Apron	89,90,98
	130012	Fender Assy-RH-Rear-LHD-Without Lamp Holes (Use 133040)	89 exc UCpe
	130013	Fender Assy-LH-Rear-RHD-Without Lamp Holes (Use 133041)	89 exc UCpe
A	130014	Fender Assy-Rear-RH-RHD-With Lamp Holes	89 exc UCpe
A	130033	Panel Assy-Bonnet Top	89
A	130034	Panel Assy-Bonnet Side-RH	89
A	130035	Panel Assy-Bonnet Side-LH	89
BO	130036	Ornament-Bonnet Top Panel	89
A	130046	Panel Assembly-Instrument-Painted	89
BO	130074	Door Assy-Locker Box-RH-RHD	91 Panel
BO	130075	Door Assy-Locker Box-LH-LHD	91 Panel
BO	130077	Door Assy-Locker Box-LH-Painted	89 UCo-UCpe-Cab-CabPu-Panel
C	130078	Roof Bow #4	89 UCpe-3Cpe-VicCpe
A	130080	Shield & Bracket Assy-Radiator Lower Tank	89
A	130096	Dust Shield Assy-Front Fender Side-RH-Rear-Enamel	89
BZ	130104	Grommet-Rear Fender Bumper-RH	89,1939-1940 Cpe-Cv
BZ	130105	Grommet-Rear Fender Bumper-LH	89,1939-1940 Cpe-Cv
BZ	130109	Tray Assembly-Battery	89,90,98
BZ	130112	Brace-Front Fender Side Dust Shield to Fender-RH	89
	130121	Knob Assembly-Locker Box Door (Use 208599)	89
	130127	Center Bar-Windshield Outer (Use 125774)	89 Bro-Sed-UCo-Cpes
C	130132	BarAssy-Front Bumper Frame-RH	89
C	130133	Bar Assembly-Front Bumper Frame-LH	89
C	130134	Bar Assembly-Rear Bumper Frame-RH	89,39 Cpe-Cv
C	130136	Bar-Rear Bumper	89,90-91-92 Cpe-Cv,40T 3Cpe-VicCpe,40 UCpe
BO	130146	Bracket Assembly-Headlamp-RH	89
BO	130147	Bracket Assembly-Headlamp-LB	89
BO	130155	Cover-Inst Panel Radio Opening	89 UCo-Cpe-Cab-CabPu-Panel
	130158	Splash Guard-Rear (Use 133180)	89 exc UCpe
C	130161	Tray & Center Reinf Assy-Rear Seat	89 exc Cab-CabPu
*A	130169 Pr	Shell Assembly-Radiator	89
BO	130180	Weatherstrip-Rear Window	38 All,39 UCpe-VicCpe,1940 VicCpe-3Cpe-UCpe
BO	130182	Weatherstrip-Quarter Window	89 Sedan
	130196	Handle-Front Door Outside (Use 130580)	89
	130197	Handle Assy-Rear Door Outside (Use 130581)	89 Sedan
BO	130228 Pntd	Door Assy-Locker Box-RH-LHD	89 UCo-UCpe-Cab-CabPu-Panel
BO	130229 Pntd	Door Assy-Locker Box-LH-LHD	89 UCo-UCpe
BO	130230 En	Headlamp Complete-With Parking Bulb-Black-RH..	89,90 exc Bro-Sed.98 exc Sed
	130231	Headlamp Complete-With Parking Bulb-Enamel-LH (Use 130233)	89,90 exc Bro-Sed,98 exc Sed
	130232	Headlamp Complete-With Parking Bulb-Pr RH (Use 130230)	89,90 exc Bro-Sed 98 exc Sed
BO	130233 Pr	Headlamp Complete-With Parking Bulb-Pr-LH	89,90 exc Bro-Sed,98 exc Sed
BO	130234 En	Headlamp Complete-With Parking Bulb-RH-6 Volt-Export	89,90,98
BO	130235 En	Headlamp Complete-With Parking Bulb-LH-6 Volt-Export	89,90,98
BO	130236 Pr	Headlamp Complete-With Parking Bulb-RH-6 Volt-Export	89,90.98
BO	130237 Pr	Headlamp Complete-With Parking Bulb-LH-6 Volt-Export	89,90,98
BO	130238 Pr	Headlamp Complete-Less Parking Bulb-RH-12 Volt-Export	89,90,98
BO	130239 Pr	Headlamp Complete-Less Parking Bulb-LH-12 Volt-Export	89,90,98
BO	130240 En	Headlamp Complete-Less Parking Bulb-RH-6 Volt-Export	89,90,98

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 130241 En	Headlamp Complete-Less Parking Bulb-LH-6 Volt-Export	89,90,98
BO 130242 Pr	Headlamp Complete-Less Parking Bulb-RH-6 Volt-Export	89,90,98
BO 130243 Pr	Headlamp Complete-Less Parking Bulb-LH-6 Volt-Export	89,90,98
BO 130244	Housing Assy-Headlamp-RH-Enamel	89
130245	Housing Assy-Headlamp-LH-Enamel (D.N.S)	89
BO 130246	Housing Assy-Headlamp-RH-Prime	89
BO 130248	Ring-Headlamp Housing	89,90,98
BO 130249	Stop-Headlamp Reflector	89,90,98
130250	Spring-Headlamp Reflector (Use 109266)	89
130251	Seat-Headlamp Reflector Spring (Use 109265)	89,90,98
BO 130253	Gasket-Headlamp Lens	89,90,98
BO 130254	Bolt-Headlamp Mounting	89
BO 130255	Spring-Headlamp Lens Locking	89,90,98
BO 130256	Screw-Headlamp Lens Retaining	89,90,98
BO 130257	Nut-Headlamp Lens Retaining Screw	89,90,98
BO 130260	Wire Assembly-Carburetor Choke-RHD	89
BO 130261	Wire Assembly-Carburetor Choke-LHD	89
BO 130263	Control Assembly-Windshield Cleaner	89
BO 130266	Bracket-Steering Gear Jacket Tube-En	89,90-98 exc Cab-CabPu
BO 130268	Clamp-Windshield Cleaner Hole Cover	89,90,98,40T,40C,48
BO 130269	Hole Cover-Front End Panel Windshield Cleaner ..	89,90,98
130270	Panel Assy-Quarter-RH-Prime (Use 125084)	89 Bro
130271	Panel Assy-Quarter-LH-Prime (D.N.S.)	89 Bro
BO 130331	Mat and Pad Assy-Front Floor-LHD	89
BO 130349	Track Assy-Front Seat-LH-LHD	89 Sed-3Cpe
BO 130352	Spring-Front Seat Track Locking Handle	89 Sed-3Cpe
BO 130365	Hinge-Hood To Panel	89,90 thru 98
BO 130366	Pin-Hood Top Panel Hinge	89,90 thru 98
130367	Bracket-Hood Top Panel Hinge (Use 133596)	89,91,92,93,95,97
BO 130400	Instrument Cluster Assembly-Miles	89,90-98 Commercial
BO 130401	Instrument Cluster Assembly-Metric	89,90-98 Commercial
F 130404	Gauge Assembly-Gasoline	89
F 130405	Gauge Assembly-Water Temperature	89
BO 130406	Instrument Cluster Complete-Miles	89
BO 130408	Bezel-Instrument Cluster and Clock	89,90-98 Commercial
BO 130409	Glass-Instrument Cluster	89,90,98
BO 130410	Backing Plate-Instrument Cluster Glass	89
BZ 130420	Support-Rear Fender Stone Guard-Lower-RH	89,39 Cpe-CvBro-Cab-CabPu-Panel,Station,1940 CabPu-Panel
BO 130424	Brace-Rad Shell Headlamp to Fender Tie Rod	89,90,98
C 130430	Support Assembly-Hood Top Panel	89,90,98
BO 130434	Bracket-Hood Top Panel Brkt-Supp Rod-RH	89,90,98
BO 130435	Bracket-Hood Top Panel Brkt-Supp Rod-LH	89,90,98
BO 130436	Spring-Hood Top Panel Support-RH	89,90,98
BO 130437	Spring-Hood Top Panel Support-LH	89,90,98
BO 130439	Handle-Hood	89
C 130442	Rod Assembly-Hood Latch	89
BO 130444	Clamp-Hood-Latch	89
BO 130446	Lever-Hood Latch Handle-RH	89
BO 130447	Lever-Hood Latch Handle-LH	89
BO 130448	Bracket-Hood Latch Rod-RH	89
BO 130455	Bolt-Hood Latch Clamp	89
BO 130460	Body Assembly-Oil Lamp	89,90-98 Commercial
BO 130461	Body Assembly-Ampere Lamp	89,90-98 Commercial
BO 130462	Weatherstrip-Front Door Window Belt-LH	89-40T 2Sed-Cpe,38 thru 1941 UCo-UCpe,48P,18P
BO 130463	Weatherstrip-Front Door Window Belt-RH	89-40T 2Sed-Cpe,38 thru 1941 UCo-UCpe,48P,18P
BO 130464	Weatherstrip-Front Door Window Belt-RH	89-40T-10T Sed,1940-1941 Cab-CabPu-Panel
BO 130465	Weatherstrip-Front Door Window Belt-LH	89-40T-10T Sed,1940-1941 Cab-CabPu-Panel
BO 130466	Name Plate-Hood Top Panel	89
BO 130467	Mldg-Radiator Center Piece	89
130468	Bolt-Radiator Center Piece Mldg (Use 133694)	89
BO 130479	Silencer-Hood Top Panel Center Reinf	89
BO 130480	Silencer-Hood Top Panel Rear Reinf	89,90 thru 98
BO 130494	Cover Assy-Locker Box Door Clock Opening	89 UCo-UCpe-Panel,90-98 Cab-CabPu-Panel
BO 130495	Cover Assy-Locker Box Door Clock Opening	89 exc Commercial
130500	Use 130501	
BO 130501 Pr	Lamp Complete-Tail & Stop-6 Volt	89 exc UCpe,90 3Cpe-VicCpe-Cv
BO 130503	Lamp Complete-Tail & Stop-Pr-12 Volt	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
BO 130504	Pad-Tail and Stop Lamp	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
BO 130505	Lens-Tail and Stop Lamp	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
BO 130506	Ring-Tail and Stop Lamp Lens Retaining	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 130507	Gasket-Tail and Stop Lamp Lens	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
130508	Base Assy-Tail Lamp-Black (Use 130509)	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
BO 130509	Base Assy-Tail Lamp-Prime	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
BO 130510	Wire & Terminal Assy-Tail & Stop Lamp	89 exc UCpe,90 3Cpe-VicCpe-Cv-TrCpe
BO 130511	Lamp Complete-Tail & Stop Lamp-6 Volt	89-1939-1940 UCpe
BO 130512	Lamp Complete-Tail & Stop Lamp-12 Volt	89-1939-1940 UCpe
BO 130513	Wires & Terminal Assy-Tail & Stop Lamp	89-1939-1940 UCpe
BO 130520	Spring-Hood Latch	89
BO 130521	Rivet-Hood Latch Spring	89
BO 130535	Shim-Hood to Cowl	89,1939 thru 1947 All
BO 130559	Cover Assy-Locker Box Clock Opening	89 Bro-Sed-3Cpe-VicCpe-Cv
130561	Adapter-Locker Box Door Clock (Use 136311)	89
F 130580	Handle Assembly-Front Door Outside	89,90-98 exc Station,91,92
F 130581	Handle Assembly-Rear Door Outside	89,90-91-92-98 Sedan
130584	Cigar Lighter Kit-Automatic (Use 142140)	89
130585	Cigar Lighter-Automatic (Use 142140)	89
BO 130586	Windshield Cleaner Auxiliary Kit-RH-LHD	89 exc Cv
BO 130587	Windshield Cleaner Auxiliary Kit-LH-RHD	89 exc Cv
130590	Tail Lamp Kit (Use 130501)	89 exc UCpe,90 TrCpe
BO 130600	Socket & Wires Assy-Headlamp-RH	89,90,98
BO 130601	Socket & Wires Assy-Headlamp-LH	89,90,98
BO 130603	Socket & Wires Assy-Headlamp-LH-With Parking Bulb-Export	90,98
BO 130604	Socket & Wires Assy-Headlamp-RH-Less Parking Bulb-Export	90,98
BO 130605	Socket & Wires Assy-Headlamp-LH-Less Parking Bulb-Export	90,98
BO 130606	Reflector-Headlamp	89,90,98
BO 130607	Reflector-Headlamp-With Parking Bulb-Export	90,98
BO 130608	Reflector-Headlamp-Less Parking Bulb-Export	90,98
F 130609	Lens-Headlamp	89,90,98
BO 130610	Lens-Headlamp-Export	89,90,98
BO 130640	Brkt-Tail & Stop Lamp	89-1939-1940 UCpe
BO 130649	Door Assembly-Locker Box-LH-RHD	89 Bro-Sed-3Cpe-VicCpe-Cv
130660	Clock Assy-Locker Boox Door Mechanical (Use 136310)	89
BZ 130670		89 CabPu,92,93,95,97,90-11 Sta
BZ 130675	Cage Assembly-Spare Tire Carrier Lock Plate-Inside Tire Carrier Clamp	89-90-91-98 Panel,90 thru 98 Bro-Sed-3Cpe-VicCpe,90 UCo,1940 Panel
BO 130678	Gauge Assy-Water Temperature	89
F 130679	Gauge Kit-Water Temperature	89
F 130681	Gauge Assy-Water Temperature	89,90 UCo-UCpe-Sta,90-98 Cab-CabPu-Panel
BO 130682	Instrument Cluster Complete-Miles	89
BZ 130691	Spacer Block-Spare Tire	89-90-98 CabPu
M 130700	Seat Cloth-Brown Boucle	89
130702	Headlining Cloth (Use 214402)	89
BO 130706	Carpet Assembly-Rear Floor	89 Sedan
BO 130707	Carpet Assembly-Rear Floor	89 Bro
C 130710	Headlining Assembly	8.9 Sedan
C 130711	Headlining Assembly	89 Bro-UCo
C 130712	Headlining Assembly	89 VicCpe
BO 130714	Arm Rest Assy-Complete-Quarter-RH-Cloth	89 Sedan
BO 130715	Arm Rest Assy-Complete-Quarter-LH-Cloth	89 Sedan
BO 130716	Arm Rest Assy-Complete-Quarter-RH-Cloth	89 Bro-UCo
BO 130717	Arm Rest Assy-Complete-Quarter-LH-Cloth	89 Bro-UCo
BO 130718	Arm Rest Assy-Quarter-RH-Cloth	89 Bro-Sed
BO 130719	Arm Rest Assy-Quarter-LH-Cloth	89 Bro-Sed
BO 130720	Trim Assy-Quarter Arm Rest-RH-Cloth	89 Bro-Sed-UCo
BO 130721	Trim Assy-Quarter Arm Rest-LH-Cloth	89 Bro-Sed-UCo
C 130724	Door Complete-Front-RH-Cloth	89 Bro-UCo
C 130725	Door Complete-Front-LH-Cloth	89 Bro-UCo
C 130726	Door Complete-Front-RH-Cloth	89 Sed
C 130727	Door Complete-Front-LH-Cloth	89 Sed
C 130728	Door Complete-Front-RH-Cloth	89 VicCpe-3Cpe-UCpe
C 130729	Door Complete-Front-LH-Cloth	89 VicCpe-3Cpe-UCpe
C 130730	Door Complete-Rear-RH-Cloth	89 Sedan
C 130731	Door Complete-Rear-LH-Cloth	89 Sedan
C 130732	Trimboard Complete-Front Door-RH-Cloth	89 Bro-VicCpe-3Cpe-UCpe
C 130733	Trimboard Complete-Front Door-LH-Cloth	89 Bro-VicCpe-3Cpe-UCpe
C 130734	Trimboard Complete-Front Door-RH-Cloth	89 Sedan-UCo
C 130735	Trimboard Complete-Front Door-LH-Cloth	89 Sedan-UCo
C 130736	Trimboard Complete-Rear Door-RH-Cloth	89 Sedan
C 130737	Trimboard Complete-Rear Door-LH-Cloth	89 Sedan
C 130738	Trimboard Complete-Lower Quarter-RH-Cloth	89 Bro-UCo
C 130739	Trimboard Complete-Lower Quarter-LH-Cloth	89 Bro-UCo

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 130742	Back Complete-Front Seat-Drivers-LHD-Cloth	89 Bro-VicCpe
C 130743	Back Complete-Front Seat-Drivers-RHD-Cloth	89 Bro-VicCpe
C 130744	Back Complete-Front Seat-Pass-LHD-Cloth	89 Bro-VicCpe
C 130745	Back Complete-Front Seat-Pass-RHD-Cloth	89 Bro-VicCpe
C 130746	Trim Assy-Front Seat Back-RH-Cloth	89 Bro-VicCpe-UCpe
C 130747	Trim Assy-Front Seat Back-LH-Cloth	89 Bro-VicCpe-UCpe
C 130748	Cushion Complete-Front Seat-Cloth	89 Bro-VicCpe-UCpe
C 130749	Trim Assy-Front Seat Cushion-Cloth	89 Bro-VicCpe
C 130750	Valance Assy-Front Seat-RH-Cloth	89 Bro-VicCpe
C 130751	Valance Assy-Front Seat-LH-Cloth	89 Bro-VicCpe
C 130752	Back Complete-Front Seat-Cloth	89 Sedan
C 130753	Trim Assembly-Front Seat Back-Cloth	89 Sedan-3Cpe
C 130754	Cushion Complete-Front Seat-Cloth	89 Sedan-3Cpe
C 130755	Trim Assembly-Front Seat Cushion-Cloth	89 Sedan-3Cpe
C 130756	Valance Assembly-Front Seat-Cloth	89 Sedan-3Cpe
C 130757	Back Complete-Rear Seat-Cloth	89 Bro
C 130758	Trim Assembly-Rear Seat Back-Cloth	89 Bro
C 130759	Cushion Complete-Rear Seat-Cloth	89 Bro-Sedan
C 130760	Trim Assembly-Rear Seat Cushion-Cloth	89 Bro-Sedan
C 130781	Trim Panel-Rear Seat Back Shelf	89 Bro-Sedan
C 130801	Back Complete-Auxiliary Seat-LHD	89 VicCpe
C 130802	Back Complete-Auxiliary Seat-RHD	89 VicCpe
C 130804	Trim Assembly-Auxiliary Seat-RHD	89 VicCpe
C 130805	Cushion Complete-Auxiliary Seat-LHD	89 VicCpe
C 130806	Cushion Complete-Auxiliary Seat-RHD	89 VicCpe
C 130807	Trim Assembly-Auxiliary Seat Cushion-LHD	89 VicCpe
C 130808	Trim Assembly-Auxiliary Seat Cushion-RHD	89 VicCpe
C 130816	Back Complete-Rear Seat-Cloth	89 Sedan
C 130817	Trim Assembly-Rear Seat Back-Cloth	89 Sedan
C 130827	Trim Panel-Package Compt-Bottom	89-90 VicCpe
C 130828	Trim Panel-Rear Compt Partition	89-90 VicCpe
C 130830	Trimboard Complete-Lower Quarter-RH-LHD	89 VicCpe
C 130831	Trimboard Complete-Lower Quarter-LH-RHD	89 VicCpe
C 130832	Trimboard Complete-Lower Quarter-RH-RHD	89 VicCpe
C 130833	Trimboard Complete-Lower Quarter-LH-LHD	89 VicCpe
C 130836	Headlining Assembly	89 3Cpe
C 130837	Back Complete-Front Seat	89 3Cpe
C 130840	Trimboard Complete-Quarter-RH	89 3Cpe
C 130841	Trimboard Complete-Quarter-LH	89 3Cpe
C 130848	Trim Panel-Front Seat Back	89 3Cpe
C 130851	Trimboard-Front Seat Compartment	89 3Cpe
C 130853	Trimboard-and Trim Assy-Front Seat Compt	89 3Cpe
C 130857	Trim Panel-Rear Compartment	89 3Cpe
C 130858	Partition & Trim Assy-Rear Compartment	89 3Cpe
C 130875	Partition & Trim Assy-Rear Compartment Lea	89 3Cpe
C 130876	Trimboard Complete-Quarter-RH-Leather	89 3Cpe
C 130877	Trimboard Complete-Quarter-LH-Leather	89 3Cpe
C 130886	Trim Assy-Wheelhouse Panel-RH-Leather	89 Bro-Sedan-UCo
C 130887	Trim Assy-Wheelhouse Panel-LH-Leather	89 Bro-Sedan-UCO
C 130888	Trimboard Comp-Lower Quarter-RH-LHD-Lea	89 VicCpe
C 130889	Trimboard Comp-Lower Quarter-LH-RHD-Lea	89 VicCpe
C 130890	Trimboard Comp-Lower Quarter-RH-RHD-Lea	89 VicCpe
C 130891	Trimboard Comp-Lower Quarter-LH-LHD-Lea	89 VicCpe
C 130892	Door Complete-Front-RH-Leather	89 Bro
C 130893	Door Complete-Front-LH-Leather	89 Bro
C 130894	Door Complete-Front-RH-Leather	89 VicCpe-3Cpe
C 130895	Door Complete-Front-LH-Leather	89 VicCpe-3Cpe
C 130896	Door Complete-Front-RH-Leather	89 Sedan
C 130897	Door Complete-Front-LH-Leather	89 Sedan
C 130898	Door Complete-Rear-RH-Leather	89 Sedan
C 130899	Door Complete-Rear-LH-Leather	89 Sedan
C 130900	Trimboard Complete-Front Door-RH-Leather	89 Bro-3Cpe-VicCpe
C 130901	Trimboard Complete-Front Door-LH-Leather	89 Bro-3Cpe-VicCpe
C 130902	Trimboard Complete-Front Door-RH-Leather	89 Sedan
C 130903	Trimboard Complete-Front Door-LH-Leather	89 Sedan
C 130904	Trimboard Complete-Rear Door-RH-Leather	89 Sedan
C 130905	Trimboard Complete-Rear Door-LH-Leather	89 Sedan
C 130906	Trimboard Complete-Lower Quarter-RH-Lea	89 Sedan
C 130907	Trimboard Complete-Lower Quarter-LH-Lea	89 Sedan
C 130908	Trimboard Complete-Lower Quarter-RH-Lea	89 Bro
C 130909	Trimboard Complete-Lower Quarter-LH-Lea	89 Bro
C 130912	Back Complete-Front Seat-Leather	89 Sedan
C 130913	Back Complete-Front Seat-Leather	89 3Cpe
C 130914	Trim Assy-Front Seat Back-Leather	89 Sedan-3Cpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 130917	Back Comp-Front Seat-Drivers-LHD-Lea	89 Bro-VicCpe
C 130918	Back Comp-Front Seat-Drivers-RHD-Lea	89 Bro-VicCpe
C 130919	Back Comp-Front Seat-Passenger-LHD-Lea	89 Bro-VicCpe
C 130920	Back Comp-Front Seat-Passenger -RHD- Lea	89 Bro-VicCpe
C 130921	Cushion Comp-Front Seat	89 Bro-VicCpe
C 130922	Trim Assy-Front Seat Back-RH-Lea	89 Bro-VicCpe
C 130923	Trim Assy-Front Seat Back-LH-Lea	89 Bro-VicCpe
BO 130924	Valance Assy-Front Seat-RH-Leather	89 Bro-VicCpe-Cv-UCpe
BO 130925	Valance Assy-Front Seat-LH-Leather	89 Bro-VicCpe-Cv-UCpe
C 130926	Trim Assy-Front Seat Cushion-Leather	89 Bro-VicCpe
C 130927	Cushion Complete-Front Seat-Leather	89 Sed-3Cpe
C 130928	Trim Assy-Front Seat Cushion-Leather	89 Sed-3Cpe
BO 130929	Valance Assy-Front Seat-Leather	89 Sed-Cpe
C 130932	Back Complete-Rear Seat-Leather	89 Sedan
C 130933	Trim Assy-Rear Seat Back-Leather	89 Sedan
C 130934	Back Complete-Rear Seat-Leather	89 Bro
C 130935	Trim Assy-Rear Seat Back-Leather	89 Bro
C 130936	Cushion Complete-Rear Seat-Leather	89 Bro-Sedan
C 130937	Trim Assy-Rear Seat Cushion-Leather	89 Bro-Sedan
C 130938	Back Complete-Auxiliary Seat-LHD-Lea	89-90-91 VicCpe
C 130939	Back Complete-Auxiliary Seat-RHD-Lea	89-90-91 VicCpe
C 130940	Trim Assy-Aux Seat Back-LHD-Leather	89-90-91 VicCpe
C 130941	Trim Assy-Aux Seat Back-RHD-Leather	89-90-91 VicCpe
C 130942	Cushion Complete-Auxiliary Seat-LHD-Lea	89-90-91 VicCpe
C 130943	Cushion Complete-Auxiliary Seat-RHD-Lea	89-90-91 VicCpe
C 130944	Trim Assy-Aux Seat Cushion-LHD-Leather	89-90-91 VicCpe
C 130945	Trim Assy-Aux Scat Cushion-RHD-Leather	89-90-91 VicCpe
C 130947	Trim Panel-Rear Compartment Partition	89 CvBro
C 130950	Trim Panel-Rear Seat Back Frame	89 CvBro
C 130957	Back Complete-Rear Seat-Cloth	89 Bro
C 130958	Trim Assembly-Rear Seat Back-Cloth	89 Bro
C 130959	Back Complete-Rear Seat-Cloth	89 Sedan
C 130960	Weatherstrip Assy-Front Pillar-RH	89-90-1940 Cv,1941 CvSed,1946-1947 CvBro
C 130966	Door Complete-Front-RH	89 Cv
C 130967	Door Complete-Front-LH	89 Cv
C 130968	Trimboard Complete-Front Door-RH	89 Cv
C 130969	Trimboard Complete-Front Door-LH	89 Cv
C 130970	Trimboard Complete-Quarter-LH	89 CvBro
C 130971	Trimboard Complete-Quarter-RH	89 CvBro
C 130972	Trim Assembly-Front Seat Back-RH	89 Cv
C 130973	Trim Assembly-Front Seat Back-LH	89 Cv
C 130974	Cushion Complete-Front Seat	89 Cv
C 130977	Back Complete-Front Seat-Drivers-LHD	89 Cv
C 130978	Back Complete-Front Seat-Drivers-RHD	89 Cv
C 130979	Back Complete-Front Seat-Passengers-LHD	89 Cv
C 130980	Back Complete-Front Seat-Passengers-RHD	89 Cv
C 130981	Trim Assembly-Front Seat Cushion	89 Cv
C 130982	Back Complete-Rear Seat	89 CvBro
C 130983	Trim Assembly-Rear Seat Back	89 CvBro
C 130984	Cushion Complete-Rear Seat	89 CvBro
C 130985	Trim Assembly-Rear Seat Cushion	89 CvBro
C 130986	Partition and Trim Assy	89 CvBro
130987	Trim Pnl & Trim Assy-Rr Seat Back Frame (Use 130950)	89 CvBro
C 130988	Trim Panel & Trim Assy-Rear Side Panel-RH	89 CvBro
C 130989	Trim Panel & Trim Assy-Rear Side Panel-LH	89 CvBro
C 130990	Top Complete	89-90-1940 CvSed
C 130992	Reinforcement Assy-Top-RH	89-90-1940 CvSed
C 130993	Reinforcement Assy-Top-LH	89-90-1940 CvSed
C 130994	Dust Boot Assembly-Top	89-90 CvBro
C 130998	Reinforcement Assembly-Top-RH	89-90-1940 CvSed
C 130999	Reinforcement Assembly-Top-LH	89-90-1940 CvSed
C 131000	Dust Boot Assembly-Top	89-90-1940 CvSed
C 131005	Trim Panel Assy-Rear Compt Partition	89 CvCpe
C 131008	Trim Panel Assy-Quarter-RH	89 CvCpe
C 131009	Trim Panel Assy-Quarter-LH	89 CvCpe
C 131010	Partition and Trim Assy	89-90 CvCpe
C 131016	Trimboard Complete-Lower Quarter-RH	89 Sedan
C 131017	Trimboard Complete-Lower Quarter-LH	89 Sedan
131020	Back Stay Assembly-Top-RH	89-90-1940 CvCpe
131021	Back Stay Assembly-Top-LH	89-90-1940 CvCpe
131022	Back Stay Assembly-Top-RH	89-90-1940 CvSed
131023	Back Stay Assembly-Top-LH	89-90-1940 CvSed
BO 131032	Carpet Assembly-Rear Floor	89 UCo

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 131035	Door Complete-Front-LH	89 UCo
C 131036	Door Complete-Front-RH	89 UCpe
C 131037	Door Complete-Front-LH	89 UCpe
C 131038	Trimboard Complete-RH-Leather	89 UCo
C 131039	Trimboard Complete-LH-Leather	89 UCo
BZ 131044	Hole Cover-Brake Pedal	89 Cab-CabPu
C 131058	Trimboard Complete-Quarter-RH-Cloth	89 UCpe
C 131059	Trimboard Complete-Quarter-LH-Cloth	89 UCpe
C 131060	Trimboard Complete-Quarter-RH-Leather	89 UCpe
C 131061	Trimboard Complete-Quarter-LH-Leather	89 UCpe
C 131062	Valance Assy-Top-Rear Curtain	38 CvBro,90 CvBro,1940 CvSed
C 131063	Seat Complete-Drivers-LHD-Cloth	89 UCo,39 Bucket Seats
C 131064	Seat Complete-Drivers-RHD-Cloth	89 UCo,39 Bucket Seats
C 131065	Seat Complete-Pass-LHD-Cloth	89 UCo,39 Bucket Seats
C 131066	Seat Complete-Pass-RHD-Cloth	89 UCo,39 Bucket Seats
C 131067	Back Complete-Drivers Seat-LHD-Cloth	89-90 UCo,1939 thru 1942 Bucket Seats
C 131068	Back Complete-Drivers Seat-RHD-Cloth	89-90 UCo,1939 thru 1942 Bucket Seats
C 131069	Back Complete-Pass-LHD-Cloth	89-90 UCo,1939 thru 1942 Bucket Seats
C 131070	Back Complete-Pass-Seat-RHD-Cloth	89-90 UCo,1939 thru 1942 Bucket Seats
C 131073	Trim Assy-Pass Seat Back-LHD-Cloth	89-90 UCo,1939 thru 1942 Bucket Seats
C 131074	Trim Assy-Pass Seat Back-RHD-Cloth	89-90 UCo,1939 thru 1942 Bucket Seats
C 131075	Cushion Complete-Drivers Seat-LHD-Cloth	89-90 UCo,1939-1940 Bucket Seats
C 131076	Cushion Complete-Drivers Seat-RHD-Cloth	89-90 UCo,1939-1940 Bucket Seats
C 131077	Cushion Complete-Pass Seat-LHD-Cloth	89-90 UCo,1939-1940 Bucket Seats
C 131078	Cushion Complete-Pass Seat-RHD-Cloth	89-90 UCo,1939-1940 Bucket Seats
C 131080	Trim Assy-Drivers Seat Cushion-RHD-Cloth	89-90 UCo
C 131081	Trim Assy-Pass Seat Cushion-LHD-Cloth	89-90 UCo,39 Bucket Seats
C 131082	Trim Assy-Pass Seat Cushion-RHD-Cloth	89-90 UCo,39 Bucket Seats
C 131083	Back Complete-Rear Seat Cloth	89 UCo
C 131084	Back Complete-Rear Seat-Leather	89 UCo
C 131085	Trim Assy-Rear Seat Back-Cloth	89 UCo
C 131086	Trim Assy-Rear Seat Back-Leather	89 UCo
C 131087	Cushion Complete-Rear Seat-Cloth	89 UCo
C 131088	Cushion Complete-Rear Seat-Leather	89 UCo
C 131089	Trim Assy-Rear Scat Cushion-Cloth	89 UCo
C 131090	Trim Assy-Rear Seat Cushion-Leather	89 UCo
C 131091	Valance Assy-Top Rear Curtain	38 CvCpe,90 CvCpe,1940 CvCpe
C 131092	Back Complete-Front Seat	89 UCpe
C 131093	Back Complete-Front Seat	89 UCpe
C 131094	Back Complete-Front Seat-RH-Leather	89 UCpe
C 131095	Back Complete-Front Seat-LH-Leather	89 UCpe
C 131096	Trim Assy-Front Seat Back-RH-Leather	89 UCpe
C 131097	Trim Assy-Front Seat Back-LH-Leather	89 UCpe
C 131098	Cushion Complete-Front Seat-Leather	89 UCpe
C 131099	Trim Assy-Front Seat Cushion-Leather	89 UCpe
C 131106	Door Complete-Front-RH	89 Cab-CabPu-Panel
C 131107	Door Complete-Front-LH	89 Cab-CabPu-Panel
C 131108	Trimboard Complete-Front Door-RH	89 Cab-CabPu-Panel
C 131109	Trimboard Complete-Front Door-LH	89 Cab-CabPu-Panel
C 131110	Trim Assembly-Rear Seat Back-Cloth	89 Sedan
C 131115	Back Complete-Drivers Seat-LHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131116	Back Complete-Drivers Seat-RHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131117	Back Complete-Pass Seat-LHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131118	Back Complete-Pass Seat-RHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131119	Trim Assy-Drivers Seat Back-LHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131120	Trim Assy-Drivers Seat Back-RHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131121	Trim Assy-Pass Seat Back-LHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131122	Trim Assy-Pass Seat Back-RHD-Leather	80-90 UCo-UCpe,1939 thru 1942 Bucket Seats
C 131123	Cushion Complete-Drivers Seat-LHD-Leather	80-90 UCo-UCpe,1939-1940 Bucket Seats
C 131124	Cushion Complete-Drivers Seat-RHD-Leather	80-90 UCo-UCpe,1939-1940 Bucket Seats
C 131125	Cushion Complete-Pass Seat-LHD-Leather	80-90 UCo-UCpe,1939-1940 Bucket Seats
C 131126	Cushion Complete-Pass Seat-RHD-Leather	80-90 UCo-UCpe,1939-1940 Bucket Seats
C 131127	Trim Assy-Drivers Seat Cushion-LHD-Lea	80 UCo-UCpe,90 UCo
C 131128	Trim Assy-Drivers Seat Cushion-RHD-Lea	80 UCo-UCpe,90 UCo
C 131129	Trim Assy-Pass Seat Cushion-LHD-Leather	80 UCo-UCpe,90 UCo,39 Bro-Sed
C 131130	Trim Assy-Pass Seat Cushion-RHD-Leather	80 UCo-UCpe,90 UCo,39 Bro-Sed
C 131136	Cushion Complete-Rear Seat-Cloth	89 Bro-Sed
C 131158	Trim Panel-Rear Side Panel-RH	89 CvBro
C 131159	Trim Panel-Rear Side Panel-LH	89 CvBro
C 131173	Door Complete-Front-LH-Cloth	89 Sedan
C 131174	Door Complete-Rear-RH-Cloth	89 Sedan
C 131175	Door Complete-Rear-LH-Cloth	89 Sedan
C 131176	Trimboard Complete-Front Door-RH	89 Sedan
C 131177	Trimboard Complete-Front Door-LH	89 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 131178	Trimboard Complete-Rear Door-RH	89 Sedan
C 131179	Trimboard Complete-Rear Door-LH	89 Sedan
C 131184	Back Complete-Front Seat	89 Sedan
C 131198	Back Complete-Front Seat-Drivers-LHD	89 Bro-VicCpe
C 131199	Back Complete-Front Seat-Drivers-RHD	89 Bro-VicCpe
C 131200	Back Complete-Front Seat-Passenger-LHD	89 Bro-VicCpe
C 131201	Back Complete-Front Seat-Passenger-RHD	89 Bro-VicCpe
C 131202	Door Complete-Front-RH-Cloth	89 Bro
C 131203	Door Complete-Front-LH-Cloth	89 Bro
C 131204	Door Complete-Front-RH-Cloth	89 3Cpe-VicCpe
C 131205	Door Complete-Front-LH-Cloth	89 3Cpe-VicCpe
C 131206	Trimboard Complete-Front Door-RH	89 3Cpe-UCpe
C 131207	Trimboard Complete-Front Door-LH	89 3Cpe-UCpe
C 131218	Back Complete-Front Seat-Drivers-LHD-Cloth	89 Bro-VicCpe
C 131219	Back Complete-Front Seat-Drivers-RHD-Cloth	89 Bro-VicCpe
C 131220	Back Complete-Front Seat-Pass-LHD-Cloth	89 Bro-VicCpe
C 131221	Back Complete-Front Seat-Pass-RHD-Cloth	89 Bro-VicCpe
C 131222	Trim Assy-Front Seat Back-RH-Cloth	89 Bro-VicCpe
C 131224	Cushion Complete-Front Seat-Cloth	89 Bro-VicCpe-UCpe
C 131225	Trim Assy-Front Seat-Cloth	89 Bro-VicCpe-UCpe
C 131226	Back Complete-Front Seat-Cloth	89 Sedan
C 131227	Back Complete-Front Seat-Cloth	89 3Cpe
C 131228	Trim Assy-Front Seat Back-Cloth	89 Sed-3Cpe
C 131229	Cushion Complete-Front Seat-Cloth	89 Sed-3Cpe
C 131230	Trim Assy-Front Seat Cushion	89 Sed-3Cpe
BO 131231	Ash Tray Assy-Instrument Panel	89 exc Commercial
BO 131232	Ash Receiver Assy-Instrument Panel	89 exc Commercial
C 131242	Back Complete-Front Seat-RH	89 UCo
C 131243	Back Complete-Front Seat-LH	89 UCo
C 131244	Back Complete-Rear Seat	89 UCo
C 131245	Trim Assy-Rear Seat Back	89 UCo
C 131246	Cushion Complete-Rear Seat	89 UCo
C 131247	Trim Assy-Rear Scat Cushion	89 UCo
BO 131255	Hinge-Rear Door Lower and Center	38-39-40 Panel
BO 131256	Hinge-Rear Door-Center-Female	38-39-40 Panel
BO 131257	Hinge-Rear Door-Lower LH-Female	38-39-40 Panel
BO 131258	Hinge-Rear Door-Lower RH-Female	38-39-40 Panel
BO 131259	Hinge-Rear Door-Upper LH-Male	38-39-40 Panel
BO 131260	Hinge-Rear Door-Upper RH-Male	38-39-40 Panel
BO 131261	Hinge-Rear Door-Upper LH-Female	38-39-40 Panel
BO 131262	Hinge-Rear Door-Upper RH-Female	38-39-40 Panel
C 133000	Panel Assy-Front End	90,98
*A 133022 Pr	Fender Assy-Rear-RH	92-93-95 Bro-Sed,90-91-97-98 Sedan
*A 133023 Pr	Fender Assy-Rear-LH	92-93-95 Bro-Sed,90-91-97-98 Sedan
*A 133024 Pr	Fender Assy-Rear-RH	90 Bro-UCo,91 Bro
*A 133025 Pr	Fender Assy-Rear-LH	90 Bro-UCo,91 Bro
C 133030 Pr	Panel-Roof	90 thru 95 Bro-Sed,90 UCo
*A 133040 Pr	Fender Assy-Rear-RH	91-92-93-95 3Cpe-VicCpe-Cv
*A 133041 Pr	Fender Assy-Rear-LH	91-92-93-95 3Cpe-VicCpe-Cv
A 133042	Fender Assy-Rear-RH	90 3Cpe-VicCpe-Cv,RHD UCpe,91 UCpe
A 133043	Fender Assy-Rear-LH	90 3Cpe-VicCpe-Cv
133044	Fender Assy-Rear-RH (Use 133042)	90 UCpe
133165	Use 140155	
A 133180	Splash Guard-Rear	39 Cpe-CvBro
BZ 133193	Support Assy-Rear Fender Apron-Enamel	90 thru 98 Bro-Sed,90 UCo,40T,40P,41, 43 thru 47 Sed-2Sed
C 133238	Finish Molding-Windshield-RH	93-95 Bro-Sed-3Cpe-VicCpe,97 Sed
C 133248	Finish Molding-Qtr Window-RH-Cloth Trim	93-95 Sed,41-43-44-47 Sed
C 133249	Finish Molding-Qtr Window-LH-Cloth Trim	93-95 Sed,41-43-44-47 Sed
C 133293	Finish Molding-Windshield-LH	90-91-92 Bro-3Cpe-VicCpe,90-91-92-98 Sed
C 133400	Grille Assy-Radiator	90,98
*A 133412 Pr	Shell Assy-Radiator	91,92
*A 133413 Pr	Shell Assy-Radiator	93
*A 133414 Pr	Shell Assy-Radiator	95,97
A 133419 Pr	Shell Assy-Radiator	90,98
BZ 133446	Spacer-Radiator Lower Shield to Support & Shell to Crossmember	39 All
BZ 133451	Crossmember-Frt Fender Frame (1st Type Frame)	90,98
A 133462 Pr	Fender Assy-RH-With Well	93,95,97
A 133463 Pr	Fender Assy-LH-With Well	93,95,97
BZ 133473	Support-Front Fender Well-LH	91,92
BZ 133476	Brace-Front Fender Well Support-RH	93,95,97
BZ 133478	Bolt-Spare Tire Carrier Lock	91,92,93,95,97
BO 133521	Trim Retainer Assy-Rear Door Bottom	90 thru 98 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 133522	Trim Retainer Assy-Front Door Bottom-RH	1939 thru 1941 Cpe-2Sed-Cv-UCo-CA,97-98-43-47-48-17-18 Sed
C 133524	Trim Retainer Assy-Front Door Bottom-RH	90 thru 95-40 thru 45-10 thru 14 Sed, 1939 thru 1941 Cab-CabPu-Panel
C 133525	Trim Retainer Assy-Front Door Bottom-LH	90 thru 95-40 thru 45-10 thru 14 Sed, 1939 thru 1941 Cab-CabPu-Panel
A 133538	Fender Assy-F-RH-Without Well	90,98
A 133539	Fender Assy-F-LH-Without Well	90,98
A 133542 Pr	Fender Assy-F-RH-Without Well	93,95,97
A 133558 Pr	Side Panel Assy-Bonnet-RH	93
A 133560 Pr	Side Panel Assy-Bonnet-RH	95,97
A 133561 Pr	Side Panel Assy-Bonnet-LH	95,97
BO 133567	Spacer-Bonnet Top Panel Support Lower Spring	91,92,93,95,97
133568	Use 133567	
BO 133569	Spring-Bonnet Top Panel Support-Lower	91,92,93,95,97
A 133570 Pr	Top Panel Assy-Bonnet	91,92
BO 133576	Bracket-Bonnet Top Panel Support-RH	92,95,97
BO 133577	Bracket-Bonnet Top Panel Support-LH	92,95,97
BO 133580	Silencer-Bonnet Top Panel Center Reinf	39 All
BO 133596	Bracket-Bonnet Top Panel Hinge	90,98
A 133602 Pr	Panel Assy-Bonnet Side-RH	90,98
A 133603 Pr	Panel Assy-Bonnet Side-LH	90,98
A 133605 Pr	Panel Assy-Bonnet Top-RH	90,98
C 133626	Running Board Assy-Complete-RH	97
C 133628	Running Board Assy-Complete-RH	98
C 133629	Running Board Assy-Complete-LH	98
BZ 133638	Tie Rod-Rad Shell to Shock Abs Plate	92,93,95,97
C 133650	Grille-Side-Radiator-RH	91,92,93,95,97
C 133651	Grille-Side-Radiator-LH	91,92,93,95,97
C 133652	Grille-Radiator Center	91,92,93,95,97
BO 133663	Clock Assy-Locker Box-Less Wire	93,95,97
BO 133666	Wire Assy-Clock-LHD	93,95,97
BO 133668	Clip-Locker Box Door Wiring	93,95,97
133691	Use 136558	
BO 133692	Clip-Molding	93,95,97
BO 133693	Clip-Molding	91,92
BO 133694	Bolt-Molding	91,92,1940-1941 All,21 Station
BO 133695	Bolt-Belt Molding	93-95 Bro-Sed-3Cpe-VicCpe,97 Sed,1940 Cpe-Cv
133714	Lid Assy-Trunk (Use 133717)	92-93-95 Bro-Sed,97 Sedan,1940 Sed-2Sed-UCO
C 133717	Door Assy-Rear Compt	90-91 Bro-Sed-UCO,98 Sedan
BO 133719	Plug-Rubber-for 1-2" Hole	1939 thru 1948 All
133730	Mat & Pad Assy-Front Floor-LHD (Use 201134)	90,98
133732	Mat & Pad Assy-Frt Floor-LHD (Use 201134)	90,98
133733	Mat & Pad Assy-Frt Floor-RHD (Use 201134)	90,98
BO 133735	Mat & Pad Assy-Frt Floor-RHD-Handy Shift	93,95,97
133736	Mat & Pad Assy-Frt Floor-LHD-Electric Hand (Use 201134)	93,95,97
133738	Mat & Pad Assy-Frt Floor-LHD-Handy Shift- (Use 201134)	91,92
133740	Mat & Pad Assy-Frt-LHD-Electric Hand (Use 201134)	91,92
BO 133741	Mat & Pad Assy-Frt Floor-RHD-Electric Hand	91,92
BO 133744	Hole Cover-Frt Floor Mat Steering Gear-Rubber	91,92 With Handy-Shift,40,47,48,1946-1947 All
BO 133751	Weatherstrip-Rear Compartment Door	39 Bro-Sed-UCO
C 133760	Bow-Roof	92 thru 98,43 thru 47 Sed,41 Sed
C 133762	Bow-Roof #4	90-91-40-48 Sedan
C 133763	Bow-Roof #5	90-91-40-48 Sedan
C 133764	Bow-Roof	1939-1940 Bro-UCO
C 133765	Bow-Roof	1939-1940 Bro-UCO
C 133771	Bar-Rear Bumper	90-92-Bro-Sed,98 Sed,90 UCo,20T,28
C 133772	Frame Bar Assy-Rear Bumper-RH	39 Bro-Sed-UCO
C 133776	Bar-Rear Bumper	93-95 Bro-Sed,97 Sed
C 133777	Bar-Rear Bumper	93-95 3Cpe-VicCpe-CvCpe-CvBro
C 133787	Frame Bar Assy-Front Bumper	90,98
C 133794	Bar-Front Bumper	93,95,97
BO 133886	Finish Molding-Windshield Lower Joint Cover	93,95,97 Sedan
BO 133887	Finish Molding-Windshield Lower Joint Cover	90 exc Cab-CabPu-Panel-Sta,92,98 Sed,91
BO 133897	Headlamp Assy	93,95,97
BO 133898	Reflector Assembly-Headlamp	93,95,97
BO 133899	Headlamp Assembly-12 Volt	91,92,93,95,97
BO 133900	Headlamp Assembly	91,92
BO 133901	Housing & Reflector Assy-Headlamp-6 Volt	91,92,93,95,97
BO 133902	Reflector Assy-Headlamp-Domestic	91,92
BO 133903	Reflector Assy-Headlamp-Export	91,92,93,95,97
F 133904	Lens-Headlamp-Domestic	91,92,93,95,97

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 133905	Lens-Headlamp-Export	91,92,93,95,97
BO 133906	Rim & Seat Assy-Headlamp Lens	91,92
BO 133907	Gasket-Headlamp Lens to Housing	91,92,93,95,97
BO 133908	Gasket-Headlamp Housing to Fender	91,92,93,95,97
133909	Clip-Nut-Headlamp Housing to Fender (Use 70795)	91,92,93,95,97
BO 133910	Rim & Seal Assy-Headlamp Lens-Pr	93,95,97
BO 133911	Housing Assy-Headlamp	91,92,93,95,97
BO 133913	Gasket-Headlamp Wire Conduit Retainer	91,92,93,95,97,1940 All
BO 133914	Adjusting Screw-Headlamp Reflector	91,92,93,95,97
BO 133915	Spring-Reflector Adjusting Arm	91,92,93,95,97
BO 133916	Spring-Reflector Friction	91,92,93,95,97
BO 133917	Spring-Lens Retaining-Upper	91,92,93,95,97
BO 133918	Sockets & Wires Assy-Headlamp	91,92
BO 133919	Sockets & Wires Assy-Headlamp	93,95,97
BO 133920	Sockets & Wires Assy-Headlamp-Export	91,92,93,95,97
BO 133921	Clip-Headlamp Lens Retaining-Lower	91 thru 97
BO 133922	Arm Assy-Headlamp Adjusting	91 thru 97
BO 133923	Yoke Assy-Headlamp Adjusting	91 thru 97
BO 133924	Washer-Headlamp Yoke & Arm Rivet-Outer	91 thru 97
BO 133927	Clinch Nut-Headlamp Housing Flange	91 thru 97
BO 133928	Socket & Retainer Assy-Headlamp ParkingBulb	91 thru 97
BO 133929	Lens-Inst Cluster-Miles	91 thru 97
BO 133931	Lens-Clock Cluster	91 thru 97
BO 133932	Lens-Radio Cluster	91 thru 97
BO 133960	Regulator Assy-Front Door Wing-RH	92-93 Bro-Sed-3Cpe-VicCpe
BO 133961	Regulator Assy-Front Door Wing-LH	92-93 Bro-Sed-3Cpe-VicCpe
133966	Use 136236	
BO 133974	Plate-Inst Cluster Ornament-Without Radio	93,95,97
BO 133976	Bezel Assy-Locker Box Door Inst Cluster-Miles	93,95,97
BO 133982	Bezel Assy-Locker Box Door Clock	93,95,97
133983	Use 1 each 133985-133666	
BO 133985	Clock & Bezel Assy-Locker Box Door	93,95,97
F 133986	Gauge Assy-Water Temperature	93,95,97
F 133987	Gauge Assy-Gasoline	93,95,97
BO 134141	Eccentric-Rear Compt Door Lock Operating	1939-1940 2Sed-Sed-3Cpe-VicCpe-UCo-UCpe,1940 Cv
BO 134142	Link-Rear Compt Door Lock Operating	1939-1940 2Sed-Sed-3Cpe-VicCpe-UCo-UCpe,1940 Cv
BO 134143	Guide-Rear Compt Lock Operating Link Plunger	39 2Sed-Sed-3Cpe-VicCpe-UCo-UCpe,1940 Sed-2Sed-UCo-CA
BZ 134145	Ornament & Name Plate Assy-Frt Bumper Center	93
BZ 134146	Ornament & Name Plate Assy-Frt Bumper Center	95,97
BO 134147	Ornament & Name Plate Assy-Radiator	91,92,93,95,97
BO 134148	Ornament & Name Plate Assy-Radiator	91,92,93,95,97
C 134150	Molding-Hood Side Panel-RH	90,98
C 134151	Molding-Hood Side Panel-LH	90,98
BZ 134154	Ornament-Front Bumper Center	93,95,97
BZ 134155	Name Plate-Front Bumper Center Ornament	93
BZ 134156	Name Plate-Front Bumper Center Ornament	95,97
BO 134158	Ornament-Hood Top Panel-Top	90,98
BO 134159	Ornament-Hood Top Panel-Top	91,92
BO 134161	Ornament-Hood Top Panel-Front	91,92
BO 134162	Ornament-Hood Top Panel-Front	93,95,97
BO 134163	Ornament-Radiator	91,92,93,95,97
BO 134165	Molding-Radiator Shell-Lower-Long	91,92,93,95,97
BO 134166	Molding-Radiator Shell-Lower-Short	91,92,93,95,97
BO 134167	Insert-Hood Top Panel Ornament	93,95,97
BO 134170	Ornament Assembly-Hood Side Panel	93,95,97
C 134171	Molding-Hood Side Panel	93,95,97
BO 134172	Bracket-Headlamp Mounting-RH-Prime	90,98
BO 134173	Bracket-Headlamp Mounting-LH-Prime	90,98
BO 134174	Ornament-Front Fender	93,95,97
BO 134175	Spacer-Hood Top Panel Ornament-Front	92,93,95,97
BO 134176	Clip-Locker Box Door Ornament & Hood Mldg	91,92,93,95,97
BZ 134178	Name Plate-Radiator-Domestic	91,92,93,95,97
BZ 134179	Name Plate-Radiator-Export	91,92,93,95,97
BZ 134181	Jack Clip-Rear Seat Tray	39 Bro-Sed-3Cpe,90 VicCpe-UCo,1940 Sed-2Sed-UCo-CA,1941 All
C 134182	Pillar Assy-Rear Body-RH	1939-1940 Sod
C 134183	Pillar Assy-Rear Body-LH	1939-1940 Sed
C 134193	Cross Bar Assy-Rear Compt Floor	1939-1940 CvCpe exc 6.00 or 7.00 tires
C 134194	Cross Bar Assy-Rear Compt Floor	1939-1940 CvCpe
134199	Use 140936	
BO 134200	Hinge-Rear Compt Door-RH	1939-1940 Sed-2Sed-UCo-CA
BO 134201	Hinge-Rear Compt Door-LH	1939-1940 Sed-2Sed-UCo-CA

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 134202	Bracket-Rear Compt Door Hinge-RH	90-91-92-93-95 Bro-Sed,97-98 Sed,90 UCo, 1940 Sed-2Sed-UCo-CA
BZ 134216	Grommet-Front Bumper-RH	91,92,93,95,97
BZ 134217	Grommet-Front Bumper-LH	91,92,93,95,97
BZ 134218	Grommet-Rear Bumper-RH	1939-1940 exc Cpe-Cv
BZ 134219	Grommet-Rear-Bumper-LH	1939-1940 exc Cpe-Cv
BO 134222	Frame-Front Door Wing Glass-RH	92-93-12-14-15-17-22 thru 27 exc Cv, 52,172,54-174 exc CvBro
BO 134223	Frame-Front Door Wing Glass-LH	92-93-12-14-15-17-22 thru 27 exc.Cv, 52,172,54-174 exc CvBro
BO 134224	Glass & Frame Assy-Front Door Wing-RH	92-93-43-45-47-12-14-15-17-22 thru 27 exc Cv,52,172,54-174 exc CvBro
BO 134225	Glass & Frame Assy-Front Door Wing-LH	92-93-43-45 Sed-2Sed,3Cpe,VicCpe,43-47 Sed,52,172,54-174 exc CvBro
134226	Weatherstrip-Front Door Wing-RH (Use 142252)	92-93-42-45 Sed-2Sed-3Cpe-VicCpe,43-47 Sed
BO 134227	Weatherstrip-Front Door Wing-LH	92-93-42-45 Sed-2Sed-3Cpe-VicCpe,43-47 Sed
BO 134230	Center Bar & Weatherstrip Assy-Frt Door-RH	90-91-92-93-40-41-44-45 Sed-2Sed-3Cpe-VicCpe,98- 43-47-48 Sed,1941-1942 exc Cv,51-171 exc CvBro, 53,58,173,178
BO 134231	Center Bar & Weatherstrip Assy-Frt Door-LH	90-91-92-93-40-41-44-45 Sed-2Sed-3Cpe-VicCpe, 98-43-47-48 Sed,1941-1942 exc Cv,51-171 exc CvBro,53,58,173,178
BO 134232	Retainer Assy-Frt Door Wing Weatherstrip-RH	90-81-92-93 Sed-2Sed-3Cpe-VicCpe,98 Sed
BO 134233	Retainer Assy-Frt Door Wing Weatherstrip-LH	90-91-92-93 Sed-2Sed-3Cpe-VicCpe,98 Sed
BO 134236	Glass & W/S Retainer Assy-Complete-Front Door Wing-RH	92-93 Bro-Sed-3Cpe-VicCpe
BO 134237	Glass & W/S Retainer Assy-Complete-Front Door Wing-LH	92-93 Bro-Sed-3Cpe-VicCpe
BO 134257	Bracket-Steering Gear Jacket Tube	91,92,93,95,97
BO 134258	Bracket-Steering Gear Jacket Tube	90-98 exc Cab-CabPu
BO 134259	Bracket-Steering Gear Jacket Tube	90-98 Cab-CabPu,98 Sed
BZ 134264	Support-Rear Fender Stone Guard-Upper	1939-1940 2Sed-Sed-UCo
BZ 134268	Stone Guard-Rear Fender	1939-1940 2Sed-Sed-UCo
BO 134269	Stone Guard-Kit-Rear Fender	90-91 Bro-Sed-UCo,98 7 Sed
A 134270	Dust Shield Assy-Frt Fender Side-RH-En	90,98
A 134272	Dust Shield Assy-Frt Fender Side-RH-En	91,92
A 134273	Dust Shield Assy-Frt Fender Side-LH-En	91,92
A 134274	Dust Shield Assy-Frt Fender Side-RH-En	93,95,97
A 134277	Dust Shield Assy-Frt Fender Side-LH-En	95,97
BO 134287	Control Assy-Windshield Cleaner	92,90 Bro-Sed-3Cpe-VicCpe-CvCpe-CvBro,98 Sed
BO 134288	Control Assy-Windshield Cleaner	93,95,97
BO 134292	Weatherstrip-Quarter Window Glass-Inner	92 thru 97 Sedan,41 thru 47 Sed
BO 134293	Lens-Road Lamp	38 thru 1940 All
BO 134295	Weatherstrip-Quarter Window Glass-Outer-LH	92 thru 97 Sedan,41 thru 47 Sed
BO 134296	Clip-Molding	93,95,97,1941-1942-1946-1947 All
BO 134311	Fastening Plate Assy-Qtr Window	20P-21 thru 27 SSed,23-27 7Sed,21-22-24-25 Cpe,1946-1947 Sed,52-54-172-174 ClubCpe
BO 134322	Weatherstrip-Quarter Window	90-98 Sedan
BO 134326	Channel Assy-Quarter Window Glass	92 thru 98-41 thru 47 Sed,10P Sed,11 thru 17 Sed
BO 134329	Felt-Quarter Window Glass Run-Bottom	92 thru 98-41 thru 47 Sed,10P Sed,11 thru 17 Sed
BZ 134330	Bracket-Rear Compt Tire Clamp	1939-1940 Sed-2Sed,1941-1942-1946-1947 All
134331	Use 134330	
*BZ 134333	Bracket Assy-Rear Compt Spare Tire Clamp	1939-1940 3Cpe-VicCpe
BO 134335	Bolt-Rear Compt Spare Tire Clamp	90-91-92-93-95 Bro-Sed-3Cpe-VicCpe,90 UCo, 98 Sed,1940 UCo-2Sed-3Cpe-VicCpe,1941-1942- 1946-1947 All
BO 134336	Pad-Tail and Stop Lamp	90 Bro-UCo,40T Sed-2Sed,40 UCo
C 134351	Front End Assembly-LHD	90 UCo-UCpe
C 134352	Front End Assembly-RHD	90 UCo-UCpe
C 134355 Pr	Front End Assembly-LHD	90 Bro-Sed-3Cpe-VicCpe,98 Sed
C 134356 Pr	Front End Assembly-RHD	90 Bro-Sed-3Cpe-VicCpe,98 Sed
134364	Use 134376	
C 134368 Pr	Front End Assembly-RHD	90 Cv
C 134370 Pr	Front End Assembly-RHD	92 Cv
C 134372 Pr	Front End Assembly-RHD	93-95 Cv
C 134373	Front End Assembly-LHD	93-95 Bro Sed-3Cpe-VicCpe,97 Sed
C 134374	Front End Assembly-RHD	93-95 Bro-Sed-3Cpe-VicCpe,97 Sed
C 134376	Front End Assembly-AHD	93-95 Bro-Sed-3Cpe-VicCpe,97 Sed
A 134387	Panel Assy-Instrument	90 Bro-Sed-3Cpe-VicCpe-Cv,98 Sed
A 134388	Panel Assy-Instrument	91,92
A 134389	Panel Assy-Instrument	93,95,97
134393	Panel Assy-Instrument	93,95,97-Export
C 134429	Finish Molding-Windshield-LH	93-95 Cv
BO 134460	Cluster & Ornament Assy-Inst-Use with Radio	93,95,97

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	134475 Handle-Hood Lock (Use 136378)	39 All
BO 134476	Bolt-Hood Lock Handle	1939 thru 1947 All
BO 134477	Bracket-Hood Lock Handle	1939 thru 1947 All
BO 134478	Tie Bar-Hood Lock Handle Bracket to Dash	1939 thru 1947 All
BO 134479	Link-Hood Lock Handle	1939 thru 1947 All
BO 134480	Rivet-Hood Lock Handle Link	1939 thru 1947 All
BO 134486	Bracket & Tie Bar Assy-Hood Lock Handle	1939 thru 1947 All
BO 134487	Spacer-Bonnet Lock Handle	1939 thru 1946 All
BO 134489	Weatherseal-Bonnet Lock Handle Link	1939 thru 1947 All
	134490 Use 203238	
	134491 Cross Shaft Assy-Bonnet Lock-LHD (Use 140238)	1939-1940 All
C 134507	Door Assembly-Front-LH-Prime	90-98 Cab-CabPu-Panel,40 Panel
	134515 Use 134639	
	134518 Use 134642	
	134519 Use 134643	
	134522 Use 134646	
	134523 Use 134659	
	134531 Use 134575	
	134559 Use 134651	
	134562 Use 134654	
	134563 Use 134655	
	134567 Use 134659	
C 134574 Pr	Door Assembly-Rear-RH	91-92-93-95 Sedan
C 134575 Pr	Door Assembly-Rear-LH	91-92-93-95 Sedan
C 134578 Pr	Door Assembly-Rear-RH	97 Sedan
C 134583 Pr	Door Assembly-Front-LH	95 Bro,97 Sedan
C 134586 Pr	Door Assembly-Front-RH	95 Sedan
C 134587 Pr	Door Assembly-Front-LH	95 Sedan
BO 134592	Bumper Assembly-Door Lock Bolt	1939 thru 1941 All
C 134593	Robe Rail Assembly	93-95 Sedan,43-47-17-18 Sed
BO 134594	Bracket-Robe Rail-Outer	93-95 Sedan,43-47-17-18 Sed
C 134600	Belt Molding-Frt Door Outside Panel-RH	93-95 Bro-3Cpe-VicCpe-Cv,97 Sed
C 134601	Belt Molding-Frt Door Outside Panel-LH	93-95 Bro-3Cpe-VicCpe-Cv,97 Sed
C 134602	Belt Molding-Frt Door Outside Panel-RH	93-95 Sedan
C 134603	Belt Molding-Frt Door Outside Panel-LH	93-95 Sedan
C 134604	Belt Molding-Frt Door Outside Panel-RH	91-92 Bro-3Cpe-VicCpe-Cv
C 134605	Belt Molding-Frt Door Outside Panel-LH	91-92 Bro-3Cpe-VicCpe-Cv
C 134606	Belt Molding-Frt Door Outside Panel-RH	91-92 Sedan
C 134607	Belt Molding-Frt Door Outside Panel-LH	91-92 Sedan
C 134608	Belt Molding-Rear-Door Outside Panel	93-95-97 Sedan
C 134609	Belt Molding-Rear Door Outside Panel	91-92 Sedan
BO 134610	Belt Molding-Front End Panel-RH	93,95,97
BO 134611	Belt Molding-Front End Panel-LH	93,95,97
BO 134612	Belt Molding-Front End Panel-RH	91,92
BO 134613	Belt Molding-Front End Panel-LH	91,92
BO 134615	Belt Molding-Quarter Panel-LH	93-95 Cv
C 134620	Belt Molding-Quarter Panel-RH	91-92 Sed
C 134621	Belt Molding-Quarter Panel-LH	91-92 Sed
C 134623	Belt Molding-Quarter Panel-LH	93-95 Bro
C 134624	Belt Molding-Quarter Panel-RH	93-95-97 Sed
C 134627	Belt Molding-Quarter Panel-LH	91-92 3Cpe-VicCpe
C 134629	Belt Molding-Quarter-Panel-LH	93-95 3Cpe-VicCpe
C 134639 Pr	Door Assy-Front-LH	90 Bro,98 Sedan
C 134642 Pr	Door Assy-Front-RH	90 Sedan
C 134643 Pr	Door Assy-Front-LH	90 Sedan
C 134646 Pr	Door Assy-Front-RH	90 VicCpe-3Cpe
	134647 Door Assy-Front-LH. (Use 134659)	90 VicCpe-3Cpe
C 134654 Pr	Door Assy-Front-RH	91-92-93 Sedan.
C 134655 Pr	Door Assy-Front-LH	91-92-93 Sedan
C 134659 Pr	Door Assy-Front-LH	91-92-93 VicCpe-3Cpe
BO 134661	Check Arm Assy-Rear Compartment Door	1939-1940 Sed-2Sed-UCo-CA
BO 134662	Bracket-Rear Compt Door Check Arm-Body Half	1939-1940 Sed-2Sed-UCo-CA
BO 134633	Bolt-Rear Compt Door Check Body Bracket	1939 thru 1942 All,51,52,53,54,171 thru 174
BO 134671	Check Arm Assy-Deck Door	1939 VicCpe-3Cpe-Cv,41-44 VicCpe-3Cpe-Cv
C 134678	Door Assy-Deck	39 VicCpe-3Cpe-Cv
BO 134689	Handle Assy-Deck Door	1939-1940 Cpe-CvSed
F 134690	Indicator Assy-Oil Pressure	90 Bro-Sed-3Cpe-VicCpe-Cv,98 7Sed
F 134691	Indicator Assy-Generator Charge	90 Bro-Sed-3Cpe-VicCpe-Cv,98 7Sed
C 134702	Panel Assy-Underbody-Prime	90 UCo
BO 134728	Weatherstrip-Quarter Window	90,91,98 Sed
BO 134729	Lens-Oil Pressure Indicator	90,98 Sed
BO 134730	Lens-Generator Charge Indicator	90,98 Sed
BO 134731	Gasket-Oil & Generator Lens	90,98 Sed
BO 134732	Bezel-Oil & Generator Lens	90,98 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 134735	Trim Molding-Arm Rest	93 Bro-Sed,95 Bro-Sed-Spec Trim
BO 134737	Trim Molding-Arm Rest	95 Bro-Sed,97 Sed,93 Bro-Sed-Spec Trim 92,90,91 Bro
BO 134742	Handle Assy-Window Regulator (Use 205334)	Quarter Wdo.,90-91 Bro-Sed-3CpeVicCpe-Cv,98 Sed
BO 134743	Handle Assy-Window Regulator	93-95-97 Sed,93 Bro-Sed-3Cpe-VicCpe
BO 134744	Handle Assy-Front Door Wing	93 Cv,97 Sed,95 Bro-Sed-3Cpe-VicCpe-Cv,40T 2Sed
134745	Handle-Door Inside (Use 126684)	90 Bro-Sed-3Cpe-VicCpe-Cv,91,92,98
134746	Handle-Door Inside (Use 126687)	93-95 Bro-Sed-3Cpe-VicCpe-Cv,97 Sedan,40T
BO 134747	Handle Assy-Quarter Window Regulator	93-95 Bro-3Cpe-VicCpe,Cv,93-95-97 Sed
134748	Handle Assy-Window Regulator (Use 134743)	92 Bro-Sed-3Cpe-VicCpe
BO 134749	Escutcheon-Qtr Window Regulator Handle	93-95 Bro-Sed-3Cpe-VicCpe-Cv,97 Sedan,40T
BO 134750	Insert-Qtr Window Reg Handle Escutcheon	93-95 Bro-Sed-3Cpe-VicCpe-Cv,97 Sedan,40T 2Sed
BZ 134752	Bracket Assy-Rad Side Grille Attaching	91,92,93,95,97
BZ 134754	Bracket Assy-Rad Side Grille Attaching	91,92,93,95,97
BZ 134755	Flexible Shaft Assy-Speedometer-LHD	1939-1940 All
BZ 134756	Core-Speedometer Flexible Shaft-LHD	1939-1940 All
BO 134757	Grommet-Rubber-For 3/4" hole	1939 thru 1950 All
BO 134758	Bezel-Door Safety Lock Assy	1939 thru 1942 All exc Station-Del,1946-1947 All
BO 134766	Door Assy-Locker Box-RH-LHD	93,95,97
BZ 134771	Welt-Front Fender to Shell	90,98
C 134774	Welt-Rear Fender	1939-1940 Sed-2Sed-UCo
BZ 134777	Welt-Front Fender	91,92
BO 134828	Door Assy-Locker Box-RH-LHD	90,98 exc Station
BO 134830	Door Assy-Locker Box-RH-RHD	90,98 exc Station
BO 134831	Door Assy-Locker Box-LH-RHD	90,98 exc Station
BO 134832	Cover Assy-Locker Box Door Clock Opening	90 UCo-UCpe•
BO 134833	Cover-Instrument Panel Radio Opening	90 UCo-UCpe
BO 134834	Choke Wire & Tube Assy-Carburetor-RHD	90 UCo-UCpe-Cab-CabPU-Panel-Station
BO 134835	Choke Wire & Tube Assy-Carburetor-LHD	39 UCo-UCpe-Cab-CabPu-Panel-Station
BO 134836	Choke Wire & Knob Assy-Carburetor	39 UCo-UCpe-Cab-CabPu-Panel-Station
BO 134838	Choke Wire Assy-Carburetor-RHD	90 Pass,91,92,98 Sed
BO 134840	Cluster Assy-Instrument-Miles	90 Pass,98 Sed
BO 134841	Cluster Assy-Instrument-Metric	90 Pass,98 Sed
134844	Bezel-Inset Cluster-Clock-Speed (Use 130408)	90 Pass,91,92,98 Sed
BO 134847	Head Assy-Speedometer-Metric	91,92
BO 134848	Ornament-Inst Panel-Center-Without Radio	90 Pass,98 Sed
BO 134849	Ornament-Inst Panel-Center-With Radio	90 Pass,98 Sed
BO 134850	Ornament-Instrument Panel-Side	90 Pass,98 Sed
BO 134852	Ash Receiver Assy-Inst Panel	90 Pass,91,92,98 Sed
BO 134853	Ash Tray Assy-Instrument Panel	90 Pass,91,92,98 Sed
BO 134854	Cover-Instrument Panel Ash Tray Front	90 Pass,91,92,98 Sed
BO 134857	Ornament-Inst Panel Center	91-92 Without Radio
BO 134860	Molding-Instrument Panel Upper	93,95,97
BO 134861	Molding-Instrument Panel Lower	93,95,97
BO 134862	Molding-Locker Box Door	93,95,97
BO 134864	Rim & Glass Assembly-Domelamp	93-95 Bro-Sed-3Cpe-VicCpe,97 Sed
134866	Rim & Glass-Domelamp (Use 134864)	90-91-92 Bro-Sed-3Cpe-VicCpe,98 Sed
BO 134867	Escutcheon Plate-Domelamp Switch	1939 thru 1947 exc Cab-CabPu-Panel-Sta,Cv, 482-484- 492-494-502-594 Sed-ClubCpe
BZ 134868	Bracket Assembly-Rear License Plate	1939 thru 1941 Sed-2Sed-UCo-UCpe-Cv
134869	Lic Lamp & Brkt Assy-Use Without Trunk (Use 134898 & 134996)	92-93-95 Bro-Sed,97 Sed
134870	Lic Lamp & Brkt Assy-Use With Trunk (Use 134996 & 134898)	92-93-95 Bro-Sed,97 Sed
BO 134874	Weatherseal-Rear Compt or Trunk Door Lamp	92 thru 97 Bro-Sed,40T Sed-2Sed
134875	Ornament-Rear Compt Door (Use 134995 & 134898)	92-93-95 Bro-Sed,97 Sed,40T Sed-2Sed,40 UCo
134876	Ornament-Trunk Lid (Use 134898 & 134996)	92-93-95 Bro-Sed,97 Sed,1940 Sed-3Sed-UCo
BO 134877	Ornament-Rear Compt Door Panel-Upper	92-93-95 Bro-Sed,97 Sed,1940 Sed-3Sed-UCo
BO 134879	Ornament-Deck Door Panel	39 Cpe-CvBro
BO 134881	Ornament-Instrument Cluster	91,92
BO 134882	Ornament-Locker Box Door Panel-Outer-Upper-RH	91,92
BO 134882	Ornament-Locker Box Door Panel-Outer-Lower-LH	91,92
BO 134883	Ornament-Locker Box Door Panel-Outer-Lower-RH	91,92
BO 134884	Ornament-Locker Box Door Panel-Inner-Upper-RH	91,92
BO 134884	Ornament-Locker Box Door Panel-Inner-Lower-LH	91,92
BO 134890	Door Assy-Locker Box-RH-LHD	91,92
BO 134893	Door Assy-Locker Box-LH-RHD	91,92
134895	Lock Cylinder & Keys Assy-Locker Box Door (Use 208599)	91,92,90 Pass
BO 134896	Choke Wire Assy-Carburetor-LHD	91,92
134897	Choke Wire & Knob Assy (Use 134836)	91,92
BO 134898	Weatherseal-Rear Compt or Trunk Door Lamp	90 Bro-Sed-UCo 98 Sed
BO 134899	Spacer-Headlamp Mounting Bolt	90-98 exc Bro-Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
134900	Headlamp Comp-RH-Black En-With Parking Bulb-(Use 134902)	90 Bro-Sed 98 Sedan
134901	Headlamp Comp-LH-Black En-With Parking Bulb (Use 134903)	90 Bro-Sed 98 Sedan
BO 134902 Pr	Headlamp Comp-RH With Parking Bulb	90 Bro-Sed 98 Sedan
BO 134903 Pr	Headlamp Comp-LH With Parking Bulb	90 Bro-Sed 98 Sedan
BO 134915	Handle-Rear Compt Door	39 Bro-Sed
BO 134923	Clock Assy-Locker Box Door-LHD	91,92
BZ 134924	Name Plate-Radiator-Shell Half-Export	90,98
BO 134927	Name Plate-Radiator-Bonnet Half (Use 134924)	90,98
BO 134943	Ash Tray Assy-Instrument Panel	93,95,97
BO 134945	Knob-Instrument Panel Ash Tray	93,95,97
BO 134946	Ash Tray Assy-Instrument Panel	90 thru 97 exc Commercial
BO 134947	Use 140278	
C 134950	Panel-Deck Door Outside-Prime	39 VicCpe-3Cpe-Cv
BO 134958	Gasket-Rear Compt or Trunk Door Lamp	90-91-40P-41 thru 45 Sed-2Sed-UCo,98-48 Sed
BO 134959	Gasket-Rear Compt Door Lamp	92-93-95-40T Sed-2Sed,97 Sed
BO 134963	Hinge Assy-Locker Box Door	93,95,97
BO 134964	Spring-Locker Box Door Hinge	93,95,97
BO 134966	Seal Washer-Front Fender Ornament	93,95,97
BO 134967	Seal Washer-Rear Compt & Trunk Lid Ornament-Upper	1939-1940 Sed-2Sed-UCo,52-54-172-174 Belt Mldg Bolts,1948,1949,501 thru 504
BO 134968	Seal Washer-Rear Compt Door Ornament & Lamp	1939-1940 Sed-2Sed-UCo,1941-1942-1946-1947 All
BO 134969	Bracket-Rear Window Opening Reinf Dome lamp	39 Bro-Sed-UCo
BO 134975	Weatherstrip-Rear Window	39 Bro-Sed-UCo
BO 134985	Screw-Visor Bracket Arm to Clamp	92,93,95,97,43,47,45,12,14,15,17,22,24,25,27,52,54,172,174,482,492,502,484-494-504 exc CvBro
BO 134986	Bolt-Visor Header Hinge Clamp	92-93-95-97,43,47,45,12,14,15,17,22,24,25,27,52,54,172,174
BO 134992	Weatherseal-Dash Hole Cover Plate	39 All
F 134993	Gauge Assy-Gasoline	90 Bro-Sed-3Cpe-VicCpe-Cv,98 Sed
F 134994	Gauge Assy-Water Temperature	90 Bro-Sed-3Cpe-VicCpe-Cv,98 Sed
BO 134995	Ornament-Rear Compartment Door Panel	90-91 Bro-Sed-UCo,98 Sedan
BO 134996	Ornament-Trunk Lid	90-91 Bro-Sed-UCo,98 Sedan
M 135006	Cloth-Seat & Side Wall-Light Taupe Cashmere	
C 135021	Liner-Rear Compartment Door	39 Bro-UCo,39 Sed exc 97,40T Sed-2Sed
M 135030	Cloth-Headlining-Printed Broadcloth Finish	
BO 135033	Assist Strap Assy-Taupe-For Cashmere Cloth Trim	93-95 Bro
BO 135049	Plate-Assist Strap Attaching	93-95-97 Sedan,47 7Sed
BO 135051	Strap Assy-Assist-Cashmere Cloth	93-95 Sedan
BO 135052	Strap Assy-Assist-Gray Bedford Cloth	97 Sedan
BO 135064	Binding-Wire On-Seats-Maroon Leather	92 Sedan-3Cpe
M 135074	Top Material-Black	90 thru 95 Cv
C 135202	Back Comp-Frt Seat-Drivers-LHD-Cloth	90-91 Bro-VicCpe
C 135203	Back Comp-Frt Seat-Drivers-RHD-Cloth	90-91 Bro-VicCpe
C 135204	Back Comp-Frt Seat-Pass-LHD-Cloth	90-91 Bro-VicCpe
C 135205	Back Comp-Frt Seat-Pass-RHD-Cloth	90-91 Bro-VicCpe
C 135206	Trim Assy-Front Seat Back-RH-Cloth	90 Bro-VicCpe
C 135207	Trim Assy-Front Seat Back-LH-Cloth	90 Bro-VicCpe
C 135208	Cushion Comp-Frt Seat-Cloth	90-91-92 Bro-VicCpe
C 135209	Trim Assy-Front Seat Cushion-Cloth	90-92 Bro-VicCpe
C 135212	Back Comp-Frt Seat-Drivers-LHD-Cloth	92 Bro-VicCpe
C 135213	Back Comp-Frt Seat-Drivers-RHD-Cloth	92 Bro-VicCpe
C 135214	Back Comp-Frt Seat-Pass-LHD-Cloth	92 Bro-VicCpe
C 135215	Back Comp-Frt Seat-Pass-RHD-Cloth	92 Bro-VicCpe
C 135216	Trim Assy-Front Seat Back-RH-Cloth	92 Bro-VicCpe
C 135217	Trim Assy-Front Seat Back-LH-Cloth	92 Bro-VicCpe
C 135218	Cushion Comp-Front Seat-Cloth	92 Bro-VicCpe
C 135219	Trim Assy-Front Seat Cushion-Cloth	92 Bro-VicCpe
C 135222	Back Comp-Frt Seat-Drivers-LHD-Cashmere	93 Bro-VicCpe
C 135223	Back Comp-Frt Seat-Drivers-RHD-Cashmere	93-95 Bro-VicCpe
C 135224	Back Comp-Frt Seat-Pass-LHD-Cashmere	93-95 Bro-VicCpe
C 135225	Back Complete-Frt Seat Pass-RHD-Cashmere	93-95 Bro-VicCpe
C 135226	Trim Assy-Frt Seat Back-RH-Cashmere	93-95 Bro-VicCpe
C 135227	Trim Assy-Frt Seat Back-LH-Cashmere	93-95 Bro-VicCpe
C 135228	Cushion Complete-Front Seat-Cashmere	93-95 Bro-VicCpe
C 135229	Trim Assy-Frt Seat Cushion-Cashmere	93-95 Bro-VicCpe
C 135232	Back Complete-Frt Seat-Drivers-LHD-Cloth	95 Bro
C 135233	Back Complete-Frt Seat-Drivers-RHD-Cloth	95 Bro
C 135234	Back Complete-Frt Seat-Pass-LHD-Cloth	95 Bro
C 135235	Back Complete-Frt Seat-Pass-RHD-Cloth	95 Bro
C 135238	Back Complete-Frt Seat-Drivers-LHD-Cloth	93-95 VicCpe-Bro
C 135239	Back Complete-Front Seat-Drivers-RHD-Cloth	93-95 VicCpe-Bro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 135240	Back Complete-Frt Seat-Pass-LHD-Cloth	93-95 VicCpe-Bro
C 135241	Back Complete-Frt Seat-Pass-RHD-Cloth	93-95 VicCpe-Bro
C 135242	Trim Assy-Front Seat Back-RH-Cloth	93-95 Bro-VicCpe,93 Bro-VicCpe Mohair
C 135243	Trim Assy-Front Seat Back-LB-Cloth	93-95 Bro-VicCpe,93 Bro-VicCpe Mohair
C 135244	Cushion Complete-Front Seat-Cloth	93-95 Bro-VicCpe,93 Bro-VicCpe Mohair
C 135245	Trim Assy-Front Seat Cushion-Cloth	93-95 Bro-VicCpe,93 Bro-VicCpe Mohair
C 135246	Back Complete-Front Seat-LHD-Cloth	90-91 Sedan
C 135247	Back Complete-Front Seat-RHD-Cloth	90-91 Sedan
C 135248	Back Complete-Front Seat-LHD-Cloth	90-91 3Cpe
C 135249	Back Complete-Front Seat-RHD-Cloth	90-91 3Cpe
C 135250	Trim Assy-Front Seat-Back-Cloth	90-91 Sed-3Cpe,98 Sedan
C 135251	Cushion Complete-Front Seat-Cloth	90-91-92 Sed-3Cpe,98 Sedan
C 135252	Trim Assy-Front Seat Cushion-Cloth	90-91-92 Sed-3Cpe,98 Sedan
C 135253	Back Complete-Front Seat-LHD-Cloth	92 Sedan
C 135254	Back Complete-Front Seat-RHD-Cloth	92 Sedan
C 135255	Back Complete-Front Seat-LHD-Cloth	92 3Cpe
C 135256	Back Complete-Front Seat-RHD-Cloth	92 3Cpe
C 135257	Trim Assy-Front Seat Back-Cloth	92 Sed-3Cpe
C 135258	Cushion Complete-Front Seat-Cloth	92 Sed-3Cpe
C 135259	Trim Assy-Front Seat Cushion-Cloth	92 Sed-3Cpe
C 135260	Back Complete-Front Seat-LHD-Cashmere	92-95 Sedan
C 135261	Back Complete-Front Seat-RHD-Cashmere	93-95 Sedan
C 135262	Back Complete-Front Scat-LHD-Cashmere	93-95 3Cpe
C 135263	Back Complete-Front Seat-RHD-Cashmere	93-95 3Cpe
C 135264	Trim Assy-Front Seat-Back-Cashmere	93-95 Sedan-3Cpe
C 135265	Cushion Complete-Front Seat-Cashmere	93-95 Sedan-3Cpe
C 135266	Trim Assy-Front Seat Cushion-Cashmere	93-95 Sedan-3Cpe
C 135267	Back Complete-Front Seat-LHD-Cloth	93-95 Sedan
C 135268	Back Complete-Front Seat-RHD-Cloth	93-95 Sedan
C 135269	Back Complete-Front Seat-LHD-Cloth	93-95 3Cpe
C 135270	Back Complete-Front Seat-RHD-Cloth	93-95 3Cpe
C 135271	Back Complete-Front Seat-LHD-Cord	97 Sedan
C 135272	Back Complete-Front Seat-RHD-Cord	97 Sedan
C 135273	Trim Assembly-Front Seat Back	93-95 Sed-3Cpe Cloth,97 Sed Mohair
C 135274	Cushion Complete-Front Seat	93-95 Sed-3Cpe Cloth,97 Sed Mohair
C 135275	Trim Assy-Front Seat-Cushion	93-95 Sed-3Cpe Cloth,97 Sed Mohair
C 135276	Back Complete-Rear Seat-Cloth	90-91 Bro-Sed,98 Sed,90 UCo
C 135277	Trim Assy-Rear Seat Back-Cloth	90-91 Bro-Sed,98 Sed,90 UCo
C 135278	Cushion Complete-Rear Seat Back-Cloth	90-91 Bro-Sed,98 Sed
C 135279	Trim Assy-Rear Seat Cushion-Cloth	90-91 Bro-Sed,98 Sed
C 135280	Back Complete-Rear Seat-Cloth	92 Bro-Sed
C 135281	Trim Assy-Rear Seat Back-Cloth	92 Bro-Sed
C 135282	Cushion Complete-Rear Seat-Cloth	92 Bro-Sed
C 135283	Trim Assy-Rear Seat Cushion-Cloth	92 Bro-Sed
C 135284	Back Complete-Rear Seat-Cashmere	93-95 Bro-Sed
C 135285	Trim Assy-Rear Seat Back-Cashmere	93-95 Bro-Sed
C 135286	Cushion Complete-Rear Scat-Cashmere	93-95 Bro
C 135287	Trim Assy-Rear Seat Cushion-Cashmere	93-95 Bro
C 135288	Cushion Complete-Rear Seat-Cashmere	93-95 Sedan
C 135289	Trim Assy-Rear Seat Cushion-Cashmere	93-95 Sedan
C 135290	Cushion Complete-Rear Seat	93-95 Sed-Cloth,93-97 Sed-Mohair
C 135291	Trim Assy-Rear Seat Cushion	93-95 Sed-Cloth,93-97 Sed-Mohair
C 135292	Back Complete-Rear Seat	93-95 Bro-Sed Cloth,93 Bro-Sed-97 Sed
C 135293	Trim Assy-Rear Seat Back	93-95 Bro-Sed Cloth,93 Bro-Sed-97 Sed
C 135294	Cushion Complete-Rear Seat	93-95 Bro-Cloth,93 Bro-Mohair
C 135295	Trim Assy-Rear Seat Cushion	93-95 Bro-Cloth,93 Bro-Mohair
C 135296	Back Complete-Rear Seat-Bedford Cord	97 Sedan
C 135297	Trim Assy-Rear Seat Back-Bedford Cord	97 Sedan
C 135298	Cushion Complete-Rear Seat-Bedford Cord	97 Sedan
C 135299	Trim Assy-Rear Seat Cushion-Bedford Cord	97 Sedan
C 135305	Cushion Complete-Front Seat-Cloth Trim	90 UCpe
C 135306	Back Complete-Front Seat-RH-Cloth Trim	90 UCpe
C 135307	Back Complete-Front Seat-LH-Cloth Trim	90 UCpe
C 135311	Trimboard Assy-Rear Compartment	90-92-40-41-44 Sed-2Sed,98 Sed,48 5Sed
C 135313	Trim Assy-Frt Seat Back-LH-Cloth Trim	90 UCpe
C 135314	Back Complete-Frt Seat-RH-Leather Trim	90 UCpe
C 135315	Back Complete-Frt Seat-LH-Leather Trim	90 UCpe
C 135344	Trim Panel-Cowl Side-RH-Fawn Gray	39 All
C 135345	Trim Panel-Cowl Side-LH-Fawn Gray	39 All
C 135352	Trim Assy-Front Seat Back-RH-Lea Trim	90 UCpe
C 135353	Trim Assy-Frt Seat Back-LH-Lea Trim	90 UCpe
C 135354	Cushion Complete-Front Seat-Lea Trim	90 UCpe
C 135355	Trim Assy-Frt Seat Cushion-Lea Trim	90 UCpe
C 135356	Headlining Assy	90 Bro-UCo,91 Bro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 135357	Headlining Assy	92-93-95 Bro
C 135358	Headlining Assy	90-91 Sedan
C 135359	Headlining Assy	92-93-95 Sedan
C 135360	Headlining Assy	97 Sedan
C 135361	Headlining Assy	39 3Cpe-UCpe
C 135362	Headlining Assy	39 VicCpe
C 135363	Headlining Assy	98 Sedan
BO 135364	Carpet Assy-Rear Floor	39 Bro
BO 135365	Carpet Assy-Rear Floor	90-91-92 Sedan
BO 135366	Carpet Assy-Rear Floor	97 Sedan
C 135371	Drain Trough Assy-Quarter Window-LH	92-93-95-97-43-45-47 Sed
BZ 135387	Hole Cover-Steering Column	92,93,95,97,1940 thru 1947 All
135390	Pull to Assembly-Front Door-Cloth (Use 135393)	97 Sedan
BO 135391	Pull to Assembly-Front Door-Maroon Leather	97 Sedan
135392	Use 135393	
BO 135393	Pull to Assembly-Front Door-Tan Leather	97 Sedan
BO 135409	Carpet Assy-Rear Floor	93-95 Sed
C 135411	Trimboard & Trim Assy-Rear Seat Back Shelf	39 Bro-Sed-UCo
C 135414	Trimboard Complete-Lower Quarter-RH-Cloth	92-93-95 Sedan
C 135415	Trimboard Complete-Lower Quarter-LH-Cloth	92-93-95 Sedan
C 135416	Trimboard Complete-Lower Quarter-RH-Lea	92-93-95 Sedan
C 135417	Trimboard Complete-Lower Quarter-LH-Lea	92-93-95 Sedan
C 135418	Trimboard Complete-Lower Quarter-RH-Cloth	97 Sedan
C 135419	Trimboard Complete-Lower Quarter-LH-Cloth	97 Sedan
C 135420	Trimboard Complete-Lower Quarter-RH-Lea	97 Sedan
C 135421	Trimboard Complete-Lower Quarter-LH-Lea	97 Sedan
C 135424	Trimboard & Trim Assy-Upper Quarter-RH-Cloth	92-93-95-97 Sedan
C 135425	Trimboard & Trim Assy-Upper Quarter-LH-Cloth	92-93-95-97 Sedan
C 135426	Trimboard & Trim Assy-Upper Qtr-RH-Leather	92-93-95-97 Sedan
C 135427	Trimboard & Trim Assy-Upper Qtr-LH-Leather	92-93-95-97 Sedan
C 135440	Trim Assy-Front Seat Back-Cord	97 Sedan
C 135441	Cushion Complete-Front Seat-Cord	97 Sedan
C 135442	Trim Assy-Front Seat Cushion-Cord	97 Sedan
C 135443	Back Complete-Front Seat-LHD-Cloth	98 Sedan
C 135444	Back Complete-Front Seat-RHD-Cloth	98 Sedan
C 135445	Back Complete-Front Seat-LHD-Mohair	93 Sedan
C 135446	Back Complete-Front Seat-RHD-Mohair	93 Sedan
C 135447	Back Complete-Front Seat-LHD-Mohair	97 Sedan
C 135448	Back Complete-Front Seat-RHD-Mohair	97 Sedan
C 135457	Floor Covering Assy-Rear Compartment	39 3Cpe-VicCpe,40-41-44 3Cpe,40 VicCpe
C 135538	Trimboard Complete-Front Door-RH-Cloth	90 Bro-3Cpe-VicCpe,98 Sed
C 135539	Trimboard Complete-Front Door-LH-Cloth	90 Bro-3Cpe-VicCpe,98 Sed
C 135540	Trimboard Complete-Front Door-RH-Cloth	90 Sedan
C 135541	Trimboard Complete-Front Door-LH-Cloth	90 Sedan
C 135542	Trimboard Complete-Rear Door-RH-Cloth	90-98 Sedan
C 135543	Trimboard Complete-Rear Door-LH-Cloth	90-98 Sedan
C 135544	Trimboard Complete-Front Door-RH-Mohair	92 Bro-3Cpe-VicCpe
C 135545	Trimboard Complete-Front Door-LH-Mohair	92 Bro-3Cpe-VicCpe
C 135546	Trimboard Complete-Front Door-RH-Cloth	92 Sedan
C 135547	Trimboard Complete-Front Door-LH-Cloth	92 Sedan
C 135548	Trimboard Complete-Rear Door-RH-Cloth	92 Sedan
C 135549	Trimboard Complete-Rear Door-LH-Cloth	92 Sedan
C 135550	Trimboard Complete-Front Door-RH-Cashmere	93 Bro-3Cpe-VicCpe
C 135551	Trimboard Complete-Front Door-LH-Cashmere	93 Bro-3Cpe-VicCpe
C 135552	Trimboard Complete-Front Door-RH-Cashmere	93 Sedan
C 135553	Trimboard Complete-Front Door-LH-Cashmere	93 Sedan
C 135554	Trimboard Complete-Rear Door-RH-Cashmere	93 Sedan
C 135555	Trimboard Complete-Rear Door-LH-Cashmere	93 Sedan
C 135556	Trimboard Complete-Front Door-RH-Mohair	93 Bro-3Cpe-VicCpe
C 135557	Trimboard Complete-Front Door-LH-Mohair	93 Bro-3Cpe-VicCpe
C 135558	Trimboard Complete-Front Door-RH-Mohair	93 Sedan
C 135559	Trimboard Complete-Front Door-LH-Mohair	93 Sedan
C 135560	Trimboard Complete-Rear Door-RH-Mohair	93 Sedan
C 135561	Trimboard Complete-Rear Door-LH-Mohair	93 Sedan
C 135562	Trimboard Complete-Front Door-RH-Cloth	95 Bro-3Cpe-VicCpe
C 135563	Trimboard Complete-Front Door-LH-Cloth	95 Bro-3Cpe-VicCpe
C 135564	Trimboard Complete-Front Door-RH-Cloth	95 Sedan
C 135565	Trimboard Complete-Front Door-LH-Cloth	95 Sedan
C 135566	Trimboard Complete-Rear Door-RH-Cloth	95 Sedan
C 135567	Trimboard Complete-Rear Door-LH-Cloth	95 Sedan
C 135568	Trimboard Complete-Front Door-RH-Bedford Cord	97 Sedan
C 135569	Trimboard Complete-Front Door-LH-Bedford Cord	97 Sedan
C 135570	Trimboard Complete-Rear Door-RH-Bedford Cord	97 Sedan
C 135571	Trimboard Complete-Rear Dr-LH-Bedford Cord	97 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C	135572 Trimboard Complete-Front Door-RH-Mohair	97 Sedan
C	135573 Trimboard Complete-Front Door-LH-Mohair	97 Sedan
C	135574 Trimboard Complete-Rear Door-RH-Mohair	97 Sedan
C	135575 Trimboard Complete-Rear Door-LH-Mohair	97 Sedan
C	135576 Trimboard Complete-Front Door-RH-Cloth	90 UCo-UCpe
C	135577 Trimboard Complete-Front Door-LH-Cloth	90 UCo-UCpe
C	135578 Trimboard Complete-Lower Quarter-RH-Cloth	90-98 Sedan
C	135579 Trimboard Complete-Lower Quarter-LH-Cloth	90-98 Sedan
C	135580 Trimboard Complete-Lower Quarter-RH-Lea	90-98 Sedan
C	135581 Trimboard Complete-Lower Quarter-LH-Lea	90-98 Sedan
C	135582 Trimboard Complete-Lower Quarter-RH-Cloth	90 Bro
C	135583 Trimboard Complete-Lower Quarter-LH-Cloth	90 Bro
C	135584 Trimboard Complete-Lower Quarter-RH-Cloth	92 Bro
C	135585 Trimboard Complete-Lower Quarter-LH-Cloth	92 Bro
C	135586 Trimboard Complete-Lower Quarter-RH-Cloth	93-95 Bro
C	135587 Trimboard Complete-Lower Quarter-LH-Cloth	93-95 Bro
C	135588 Trimboard Complete-Lower Quarter-RH-Mohair	93-95 Bro
C	135589 Trimboard Complete-Lower Quarter-LH-Mohair	93-95 Bro
C	135590 Trimboard Complete-Lower Quarter-RH-Cloth	90 UCo
C	135591 Trimboard Complete-Lower Quarter-LH-Cloth	90 UCo
C	135592 Trimboard Complete-Lower Quarter-RH-Cloth	90-98 Sedan
C	135593 Trimboard Complete-Lower Quarter-LH-Cloth	90-98 Sedan
C	135594 Trimboard Complete-Lower Quarter-RH-Cloth	90 Bro
C	135595 Trimboard Complete-Lower Quarter-LH-Cloth	90 Bro
C	135596 Trimboard Complete-Lower Quarter-RH-Cloth	90 UCo
C	135597 Trimboard Complete-Lower Quarter-LH-Cloth	90 UCo
C	135598 Trim Assy-Wheelhouse Panel-RH-Cloth	90 Bro-Sed-UCo,98 Sedan
C	135599 Trim Assy-Wheelhouse Panel-LH-Cloth	90 Bro-Sed-UCo,98 Sedan
C	135670 Back Complete-Rear Seat-Leather Trim	90-91 Bro-Sedan,98 Sedan
C	135671 Trim Assy-Rear Seat-Back-Leather Trim	90-91 Bro-Sedan,98 Sedan
C	135672 Cushion Complete-Rear Seat-Leather Trim	90-91 Bro-Sed,98 Sedan
C	135673 Trim Assy-Rear Seat Cushion-Leather Trim	90-91 Bro-Sedan,98 Sedan
C	135674 Back Complete-Rear Seat-Leather Trim	92-93-95 Bro-Sed,97 Sed
C	135675 Trim Assy-Rear Seat Back-Leather Trim	92-93-95 Bro-Sed,97 Sed
C	135676 Cushion Complete-Rear Seat-Leather Trim	92 Bro-Sedan
C	135677 Trim Assy-Rear Seat Cushion-Leather Trim	92 Bro-Sedan
C	135694 Trimboard-Package Compartment	39 3Cpe
C	135732 Trimboard & Trim Assy-Front Seat Back-Cloth	90-91-92 Sedan
C	135733 Trimboard & Trim Assy-Frt Seat Back-Cashmere	93-95 Sedan
C	135734 Trimboard & Trim Assy-Frt Seat Back	93-95 Cloth,93 Mohair
C	135735 Trimboard & Trim Assy-Frt Seat Back-Bedford	97 Sedan
C	135736 Trimboard & Trim Assy-Frt Seat Back-Mohair	97 Sedan
C	135737 Trimboard & Trim Assy-Frt Seat Back-Cloth	98 Sedan
C	135738 Extension & Trim Assy-Frt Scat Side Panel-RH-Cloth	90-92 Sed-3Cpe,98 Sedan
C	135739 Extension & Trim Assy-Frt Seat Side Panel-LH-Cloth	90-92 Sed-3Cpe,98 Sedan
C	135740 Extension & Trim Assy-Frt Seat Side Panel-RH-Cloth	93-95 Sed-3Cpe,97 Sedan
C	135741 Extension & Trim Assy-Frt Seat Side Panel-LH-Cloth	93-95 Sed-3Cpe,97 Sedan
C	135799 Trim Panel & Curtain Bag Assy-Rear Seat Back	92-93-95 CvBro
C	135804 Cushion Complete-Rear Seat-Leather	92-93-95 Bro-Sedan
C	135805 Back Complete-Aux Seat-LHD-Cloth	39 VicCpe
C	135806 Back Complete-Aux Seat-RHD-Cloth	39 VicCpe
C	135809 Cushion Complete-Auxiliary Seat-LHD-Cloth	39 VicCpe
C	135810 Cushion Complete-Auxiliary Seat-RHD-Cloth	39 VicCpe
C	135813 Back Complete-Auxiliary Seat-LHD-Lea	92-93-95 VicCpe
C	135814 Back Complete-Auxiliary Seat-RHD-Lea	92-93-95 VicCpe
C	135817 Cushion Complete-Auxiliary Seat-LHD-Lea	92-93-95 VicCpe
C	135818 Cushion Complete-Auxiliary Seat-RHD-Lea	92-93-95 VicCpe
C	135821 Trim Assy-Rear Seat Cushion-Leather Trim	93-95 Bro
C	135822 Cushion Complete-Rear Seat-Leather Trim	93-95-97 Sedan
C	135823 Trim Assy-Rear Seat Cushion-Leather Trim	93-95-97 Sedan
C	135824 Cushion Complete-Rear Seat-Cloth Trim	90 UCo
C	135825 Trim Assy-Rear Seat Cushion-Cloth Trim	90 UCo
C	135826 Back Complete-Rear Seat-Leather Trim	90 UCo
C	135827 Trim Assy-Rear Seat Back-Leather Trim	90 UCo
C	135828 Cushion Complete-Rear Seat-Leather Trim	90 UCo
C	135829 Trim Assy-Rear Seat Cushion-Leather Trim	90 UCo
C	135840 Trimboard & Trim Assy-Rear Side Panel-RH	92-93-95 CvBro,40-41-44 CvCpe
C	135841 Trimboard & Trim Assy-Rear Side Panel-LH	92-93-95 CvBro,40-41-44 CvCpe
C	135842 Trimboard Complete-Quarter-RH	92-93-95 CvBro
C	135843 Trimboard Complete-Quarter-LH	92-93-95 CvBro
C	135844 Trimboard Complete-Quarter-RH	90 CvBro
C	135845 Trimboard Complete-Quarter-LH	90 CvBro
BO	135850 Carpet Assy-Rear Floor	90 UCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 135863	Back Complete-Front Seat-Drivers-LHD	90 Cv
C 135864	Back Complete-Front Seat-Drivers-RHD	90 Cv
C 135865	Back Complete-Front Seat-Passenger-LED	90 Cv
C 135866	Back Complete-Front Seat-Passenger-RHD	90 Cv
C 135869	Back Complete-Front Seat-Drivers-LHD	92-93-95 Cv
C 135870	Back Complete-Front Seat-Drivers-RHD	92-93-95 Cv
C 135871	Back Complete-Front Seat-Passengers-LED	92-93-95 Cv
C 135872	Back Complete-Front Seat-Passengers-RHD	92-93-95 CV
C 135873	Cushion Complete-Front Seat	39 Cv
C 135874	Trim Assy-Front Seat Cushion	39 Cv
C 135875	Back Complete-Rear Seat	90 CvBro
C 135876	Trim Assy-Front Seat Back-RH	90 Cv
C 135877	Trim Assy-Front Seat Back-LH	90 Cv
C 135878	Trim Assy-Front Seat Back-RH	92-93-95 Cv
C 135879	Trim Assy-Front Seat Back-LH	92-93-95 Cv
C 135880	Trim Assy-Rear Seat Back	90 CvBro
C 135881	Back Complete-Rear Seat	92-93-95 CvBro
C 135882	Trim Assy-Rear Seat Back	92-93-95 CvBro
C 135883	Cushion Complete-Rear Seat	39 CvBro
C 135884	Trim Assy-Rear Scat Cushion	39 CvBro
C 135885	Top Complete-Trimmed	92-93-95 CvCpe
C 135886	Flap Assy-Top Side Quarter Weatherseal-RH	92-93-95 CvCpe
C 135887	Flap Assy-Top Side Quarter Weatherseal-LH	92-93-95 CvCpe
C 135888	Flap Assy-Top Side Quarter Weatherseal-RH	92-93-95 CvBro,1940 CvSed
C 135889	Flap Assy- Top Side Qtr Weatherseal-LH	92-93-95 CvBro,1940 CvSed
C 135890	Top Completed-Trimmed	92-93-95 CvBro
C 135891	Top Deck & Side Quarters Assy	92-93-95 CvBro
C 135892	Quarter Window & Curtain Assy-RH	92-93-95 CvBro,1940 CvSed
C 135893	Quarter Window & Curtain Assy-LH	92-93-95 CvBro,1940 CvSed
C 135894	Dust Boot Assy- Top	92-93-95 CvBro
C 135897	Back Comp-Frt Seat-Drivers-LHD-Lea	90-91 Bro-VicCpe
C 135898	Back Comp-Frt Seat-Drivers-RHD-Lea	90-91 Bro-VicCpe
C 135899	Back Comp-Frt Seat-Pass-LHD-Lea	90-91 Bro-VicCpe
C 135900	Back Comp-Frt Seat-Pass-RHD-Lea	90-91 Bro-VicCpe
C 135901	Cushion Complete-Front Seat Leather Trim	90-91 Bro-VicCpe
C 135902	Trim Assy-Frt Seat Back-Leather Trim-RH	90-91 Bro-VicCpe
C 135903	Trim Assy-Frt Seat Back-Leather Trim-LH	90-91 Bro-VicCpe
C 135904	Trim Assy-Frt Seat Cushion-Leather	90-91 Bro-VicCpe
C 135907	Back Comp-Frt Seat-Drivers-LHD-Leather	92-93-95 Bro-VicCpe
C 135908	Back Comp-Frt Seat-Drivers-RHD-Leather	92-93-95 Bro-VicCpe
C 135909	Back Comp-Frt Seat-Pass-LHD-Leather	92-93-95 Bro-VicCpe
C 135910	Back Corrip-Frt Seat-Pass-RHD-Leather	92-93-94 Bro-VicCpe
C 135911	Cushion Complete-Front Seat-Leather	92 Bro-VicCpe
C 135912	Trim Assy-Frt Seat Back-Leather-RH	92-93-95 Bro-VicCpe
C 135913	Trim Assy-Frt Seat Back-Leather-LH	92-93-95 Bro-VicCpe
C 135914	Cushion Complete-Frt Seat-Leather	92-93-95 Bro-VicCpe
C 135915	Trim Assy-Frt Seat Cushion-Leather	92-93-95 Bro-VicCpe
C 135916	Trim Assy-Frt Seat Back Leather	90-91 Sed-3Cpe,98 Sedan
C 135917	Back Complete-Frt Seat-LHD-Leather	90-91 Sedan
C 135918	Back Complete-Frt Seat-RHD-Leather	90-91 Sedan
C 135919	Back Complete-Frt Seat-LHD-Leather	90-91 3Cpe
C 135920	Back Complete-Frt Seat-RHD-Leather	90-91 3Cpe
C 135921	Cushion Complete-Front Seat-Leather	90-91 Sed-3Cpe,98 Sedan
C 135922	Trim Assy-Front Seat-Cushion	90-91 Sed-3Cpe,98 Sedan
C 135923	Back Complete-Front Seat-LHD-Leather	92 Sedan
C 135924	Back Complete-Front Seat-RHD-Leather	92 Sedan
C 135925	Back Complete-Front Seat-LHD-Leather	92 3Cpe
C 135926	Back Complete-Front Seat-RHD-Leather	92 3Cpe
C 135927	Back Complete-Front Seat-LHD-Leather	93-95 Sedan
C 135928	Back Complete-Front Seat-RHD-Leather	93-95 Sedan
C 135929	Back Complete-Front Seat-LHD-Leather	93-95 3Cpe
C 135930	Back Complete-Front Seat-RED-Leather	93-95 3Cpe
C 135931	Back Complete-Front Scat-LHD-Leather	97 Sedan
C 135932	Back Complete-Front Seat-RHD-Leather	97 Sedan
C 135933	Back Complete-Front Seat-LHD-Leather	98 Sedan
C 135934	Back Complete-Front Seat-RHD-Leather	98 Sedan
C 135935	Cushion Complete-Front Seat-Leather	92 Sed-3Cpe
C 135936	Trim Assy-Front Seat Back-Leather	9?-93-95 Sed-3Cpe,97 Sedan
C 135937	Cushion Complete-Front Seat-Leather	92-93-95 Sed-3Cpe,97 Sedan
C 135938	Trim Assy-Front Seat Cushion-Leather	92-93-95 Sed-3Cpe,97 Sedan
C 135948	Trimboard Complete-Front Door-RH-Lea	90 Bro-3Cpe-VicCpe,98 Sedan
C 135949	Trimboard Complete-Front Door-LH-Lea	90 Bro-3Cpe-VicCpe,98 Sedan
C 135950	Trimboard Complete-Front Door-RH-Lea	90 Sedan
C 135951	Trimboard Complete-Front Door-LH-Lea	90 Sedan
C 135952	Trimboard Complete-Rear Door-RH-Lea	90-98 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 135953	Trimboard Complete-Rear Door-LH-Lea	90-98 Sedan
C 135954	Trimboard Complete-Front Door-RH-Leather	92 Bro-3Cpe-VicCpe
C 135955	Trimboard Complete-Front Door-LH-Leather	92 Bro-3Cpe-VicCpe
C 135956	Trimboard Complete-Front Door-RH-Leather	92 Sedan
C 135957	Trimboard Complete-Front Door-LH-Leather	92 Sedan
C 135958	Trimboard Complete-Rear Door-RH-Leather	92 Sedan
C 135959	Trimboard Complete-Rear Door-LH-Leather	92 Sedan
C 135960	Trimboard Complete-Front Door-RH-Leather	93 Bro-3Cpe-VicCpe
C 135961	Trimboard Complete-Front Door-LH-Leather	93 Bro-3Cpe-VicCpe
C 135962	Trimboard Complete-Front Door-RH-Leather	93 Sedan
C 135963	Trimboard Complete-Front Door-LB-Leather	93 Sedan
C 135964	Trimboard Complete-Rear Door-RH-Leather	93 Sedan
C 135965	Trimboard Complete-Rear Door-LB-Leather	93 Sedan
C 135966	Trimboard Complete-Front Door-RH-Leather	95 Bro-3Cpe-VicCpe
C 135967	Trimboard Complete-Front Door-LH-Leather	95 Bro-3Cpe-VicCpe
C 135968	Trimboard Complete-Front Door-RH-Leather	95 Sedan
C 135969	Trimboard Complete-Front Door-LH-Leather	95 Sedan
C 135970	Trimboard Complete-Rear Door-RH-Leather	95 Sedan
C 135971	Trimboard Complete-Rear Door-LH-Leather	95 Sedan
C 135972	Trimboard Complete-Front Door-RH-Leather	97 Sedan
C 135973	Trimboard Complete-Front Door-LH-Leather	97 Sedan
C 135974	Trimboard Complete-Rear Door-RH-Leather	97 Sedan
C 135975	Trimboard Complete-Rear Door-LH-Leather	97 Sedan
C 135976	Trimboard Complete-Front Door-RH-Leather	90 UCo-UCpe
C 135977	Trimboard Complete-Front Door-LH-Leather	90 UCo-UCpe
C 135978	Trimboard Complete-Front Door-RH-Leather	90-98 Cab-CabPu,91 Panel
C 135979	Trimboard Complete-Front Door-LH-Leather	90-98 CabCabPu-Panel,91 Panel
C 136001	Track Assy-Front Seat-LHD	39 Sed-3Cpe
BO 136010	Clamp-Front Seat Adjusting Track	1939 thru 1947 Sed-3Cpe,48-18 Carryall, 11-14-21-178 Station
BO 136011	Pad-Frt Seat Adjusting Track Clamp-Rubber	1939 thru 1947 Sed-3Cpe,48-18 Carryall, 11-14-21 -178 Station
BO 136012	Washer-Front Seat Adjusting Track Clamp-Rubber	1939 thru 1947 Sed-3Cpe-CA,11-14-21- 178 Station,1948,1949,1950
BO 136013	Spacer-Frt Seat Adjusting Track Assy	1939 thru 1947 Sed-3Cpe-CA,11-14-21- 178 Station
136032	Knob-Front Seat Adj Handle (Use 209664)	39 Sed-3Cpe
BO 136033	Handle-Front Seat Adj	39 Sed-3Cpe
BO 136034	Backing Plate-Frt Seat Adj Handle Escutcheon	39 Sed-3Cpe,1940-1941 All
BO 136035	Spring-Front Seat-Adj Handle	39 Sed-3Cpe
BO 136036	Spring-Front Seat-Adj Track Return	1939 thru 1947 Sed-3Cpe,11-14-21-178 Station,1948,1949,1950
BO 136037	Bracket-Frt Seat-Adj Track Return Spring	1939 thru 1947 Sed-3Cpe,11-14-21-178 Station,1948-1949-1950
C 136041	Back Comp-Rear Seat-Leather	92 Bro-Sed,98 7Sed
C 136042	Cushion Comp-Rear Seat-Leather-Std	98 7 Sed
C 136043	Cushion Comp-Rear Seat-Leather-Airfoam	98 7 Sed
*BO 136048	Lock Assy-Front Door-RH	39 exc Station,40 Panel
*BO 136049	Lock Assy-Front Door-LH	39 exc Station,40 Panel
*BO 136050	Lock Assy-Rear Door-RH	39 Sedan
*BO 136051	Lock Assy-Rear Door-LH	39 Sedan
136052	Remote Control Assy-Front Door Lock-RH(Use 120876)	90-91-92-93 Bro-3Cpe-VicCpe,90 Cv,98 Sed
BO 136053	Remote Control Assy-Front Door Lock-LH	90-91-92-93 Bro-3Cpe-VicCpe,90 Cv,98 Sed
136054	Remote Control Assy-Front Door Lock-RH(Use 120878)	90-91-92-93 Sedan
136055	Remote Control Assy-Front Door Lock-LH(Use 120879)	90-91-92-93 Sedan
136056	Remote Control Assy-Front Door Lock-RH(Use 120290)	95 Sed,90-98 Cab-CabPu-Panel,91 Panel
136057	Remote Control Assy-Front Door Lock-LH(Use 120291)	95 Sed,90-98 Cab-CabPu-Panel,91 Panel
136058	Remote Control Assy-Front Door Lock-RH(Use 120496)	92-93-95 Cv,95 Bro-3Cpe-VicCpe,97 Sed,90 UCo-UCpe
136059	Remote Control Assy-Front Door Lock-LH(Use 120497)	92-93-95 Cv,95 Bro-3Cpe-VicCpe,9 7 Sed,90 UCo-UCpe
BO 136060	Remote Control Assy-Rear Door Lock-RH	39 Sedan
BO 136061	Remote Control Assy-Rear Door Lock-LH	39 Sedan
BO 136067	Escutcheon-Front Seat Adjusting Handle	1939 Bro-Sed-Cpe-Cv,1940 5Sed
BO 136068	Silencer-Rear Seat Tray	90-92,93-95 3Cpe-VicCpe-Cv
BO 136069	Rest-Folding Seat	92-93-95-41-44 VicCpe,1940 CvCpe
BO 136070	Lamp Complete-Tail & Stop-6Volt	92-93-95 Bro-Sed,90-91-97-98 Sedan
BO 136071	Lamp Complete-Tail & Stop- 12 Volt	92-93-95 Bro-Sed,90-91-97-98 Sedan
BO 136072	Pad-Tail & Stop Lamp	92-93-95 Bro-Sed,90-91-97-98 Sedan
BO 136073	Lens-Tail & Stop Lamp	92-93-95 Bro-Sed,90-91-97-98 Sedan
BO 136074	Rim-Tail & Stop Lamp	92-93-95 Bro-Sed,90-91-97-98 Sedan
BO 136075	Gasket-Tail & Stop Lamp	92-93-95 Bro-Sed,90-91-97-98 Sedan
136078	Pad-Tail & Stop Lamp (Use 136072)	92-93-95 Bro-Sed,90-97-98 Sedan
BO 136085	Door Assy-Locker Box-LH-RHD-Painted	90-98 Cab-CabPu-Panel
BO 136086	Spring-Door Lock Bolt	1939-1940 All
BO 136087	Spring-Door Lock Remote Control	1939 thru 1947 All

Part No.	Name	Models
BO 136090	Handle Assy-Cowl Ventilator Operating	1939-1940 All
BO 136093	Base Plate Assy-Tail Lamp	39 Bro-Sed
BO 136094	Retainer-Front Door W/Strip-RH	1939-1940 Sed-2Sed-3Cpe-VicCpe-UCo-IJCpe
BO 136095	Retainer-Front Door W/Strip-LH	1939-1940 Sed-2Sed-3Cpe-VicCpe-UCo-IJCpe
BO 136114	Riser Assy-Toe Board-RH-LHD	92,93,95,97
BO 136115	Riser Assy-Toe Board-LH-LHD	92,93,95,97
BO 136116	Riser Assy-Toe Board-RH-RHD	92,93,95,97
BO 136117	Riser Assy-Toe Board-LH-RHD	92,93,95,97
BO 136118	Lens-Rear Compt License Lamp	90-91 Bro-Sed-UCo,98 Sedan
BO 136119	Gasket-Rear Compt License Lamp Lens	90-91 Bro-Sed-UCo,98 Sedan
BO 136121	Ornament-Door Trim Panel-LB	93-95 exc Cv
BO 136122	Ornament-Door Trim Panel	93-95 exc Cv
BO 136128	Lens-Rear Compt & License Lamp	92-93-95 Bro-Sed 97 Sedan,1940 Sed-2Sed-UCo
BO 136129	Gasket-Rear Compt License Lamp Lens	92-93-95 Bro-Sed 97 Sed,1940 Sed-2Sed-UCo
BO 136130	Lens-Rear Compt License Lamp Keyhole	92-93-95 Bro-Sed,97 Sed,1940 Sed,2Sed-UCo
BO 136138	Heating Element-Rear Quarter Cigar Lighter-12 Volt	39 All
BO 136159	Retainer Assy-Arm Rest Ash Receiver-Tray	93-95 Bro-Sed,97 Sedan
BO 136162	Tray & Knob Assy-Arm Rest Ash Receiver-RH	93-95 Bro-Sed
BO 136163	Tray & Knob Assy-Arm Rest Ash Receiver-LH	93-95 Bro-Sed
BO 136166	Tray & Knob Assy-Arm Rest Ash Receiver-RH	93-95 Bro-Sed,97 Sedan
BO 136167	Tray & Knob Assy-Arm Rest Ash Receiver-LH	93-95 Bro-Sed,97 Sedan
BO 136168	Retainer-Arm Rest Ash Receiver Tray-RH	93-95-41-44-45 Sed-2Sed,43-47-97 5Sed
BO 136169	Retainer-Arm Rest Ash Receiver Tray-LH	93-95-41-44-45 Sed-2Sed,43-47-97 5Sed
C 136177	Trim Molding Assy-Front Door Bottom	93-95 Sedan
BO 136179	Escutcheon-Rear Quarter Cigar Lighter	97-43-47 Sed
136190	Use 136191	
BO 136191	Heating Element Only-Cigar Lighter	39 All
BO 136192	Base Assembly-Cigar Lighter	39 All
BO 136194	Cigar Lighter Assy-Rear Quarter-6 Volt	97 Sedan
BO 136196	Clamp-Rear Quarter Cigar Lighter Base	97 Sedan
BO 136206	Tray & Cover Assy-Rear Quarter Ash Receiver	90-91 Bro-Sed,98 Sedan,92 Bro
BO 136207	Ash Receiver Assy-Instrument Panel	90 Pass,98 Sed
BO 136208	Ash Tray & Cover Assy-Instrument Panel	90 Pass,98 Sed
136214	Scuff Plate-Rear Door-RH (Use 121928)	92-93-95 Sedan
BO 136215	Scuff Plate-Rear Door-LH	92-93-95 Sedan
BO 136218	Scuff Plate-Rear Door-RH	97 Sedan
BO 136219	Scuff Plate-Rear Door-LH	97 Sedan
C 136225	Rubber Pad-Front Seat Cushion Spring	39 Sed-3Cpe,1939 thru 1942 7Sed
BZ 136233	Spacer-Bumper Bar Fender Guard.	90 thru 98
136234	Use 136233	
BO 136239	Wires Assy-Tail Lamp	92-93-95 Bro,39-1940 Sed,1940 Cpe-Cv-2Sed
C 136253	Spring-Rear Seat Cushion	90 UCo
BO 136261	Cover-Instrument Panel Cluster Radio Hole	93,95,97
BO 136295	Screw-Windshield Header Roof Dowel	1939 thru 1942 CvCpe-CvSed,1936-1947 CvBro
BO 136303	Cylinder-Locker Box Door Lock-Not Coded	93,95,97,1940 All
BO 136304	Cylinder & Key Assy-Locker Box Door Lock	93,95,97,1940 All
BO 136305	Lock Cylinder & Key Assy-Locker Box Door	93,95,97
BO 136306	Sleeve-Locker Box Door Lock Retaining	93,95,97
BO 136308	Mat-Rear Compartment Floor-Rear Tire Mount	93-95 Bro-Sed,97 Sedan
BO 136311	Adapter-Locker Box Door Clock	90 exc Cab-CabPu-Panel,98 Sedan
BZ 136312	Bolt-Bumper Fdr Guard-Rear 7/ 16"-14 x 2-1/4"	93-95 3Cpe-VicCpe-Cv,1940 All
BO 136313	Seal-Headlamp Lens Rim-Sponge Rubber	92,93,95,97
BO 136331	Clamp Assy-Top Hold Down	1939 thru 1947 Cv
BO 136332	Spring-Top Hold Down Clamp	1939 thru 1947 Cv
BO 136333	Handle-Top Hold Down Clamp	1939 thru 1947 Cv
BO 136347	Choke Wire Assy-Carburetor-LHD	90 Bro-Sed-3Cpe-VicCpe-Cv,98 Sed
136348	Choke Wire & Knob Assy (Use 134836)	90 Bro-Sed-3Cpe-VicCpe-Cv,98 Sed
BO 136363	Filler-Top Header Rail & Rear Bow Molding	39 Cv
BO 136367	Filler-Molding-Brown	1939 thru 1946 Cv
BO 136368	Filler-Molding-Maroon	1939 thru 1947 Cv
BO 136373	Filler-Top Front Header Rail Molding	39 Cv
BO 136375	Switch-Fog Lamp	1939-1940 All
BO 136378	Handle Assy-Bonnet Lock	1939 thru 1947 All
136381	Anti Freeze-Windshield Washer (Use 209976)	All
136401	Use 123032	
BO 136407	Windshield Cleaner Kit-RH-LHD	90 exc Cv,91 Panel
BO 136418	Nozzle Kit-Windshield Washer	Models Previous to 1939
136421	Use 170528	
BO 136434	Bracket Assy-Rad Side Grille Attaching-Upper-RH	91,92,93,95,97
BO 136435	Bracket Assy-Rad Side Grille Attaching-Upper-LH	91,92,93,95,97
BO 136442	Windshield Cleaner Kit-RH	90 Cv
BO 136443	Glass-Hood Side Panel Ornament	93,95,97
BO 136444	Gasket-Hood Side Panel Ornament Glass	93,95,97
BO 136445	Glass-Instrument Cluster-Service Package	93,95,97

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 136446	Cluster Assy-Fuel & Oil-Less Gauge	80,81,82,88,90 Station,91,92 80,81,82,88,90 Station,91,92
BO 136447	Cluster Assy-Temp & Generator-Less Gauge	93,95,97
BO 136448	Base Plate-Hood Side Panel Ornament	90 Cv
BO 136448	Windshield Cleaner Kit-LH	37 thru 1942 exc Cv,1946-1947 exc CvBro
*SP 136456	Blade-Windshield Cleaner-Carton of 21	90-98 exc Cv,91 Panel
BO 136457	Windshield Cleaner Kit-LH	90-91-92 Bro-VicCpe
C 136520	Cushion Complete-Frt Seat-Airfoam-Cloth	90-91-92 Bro-VicCpe
C 136521	Trim Assy-Frt Seat Cushion-For Airfoam	90-91 Bro-VicCpe
C 136522	Cushion Complete-Front Seat-Airfoam-Lea	90-91-92 3Cpe-Sed,98 Sedan
C 136523	Cushion Complete-Front Seat-Airfoam-Cloth	90-91 Sedan-3Cpe,98 Sedan
C 136525	Cushion Complete-Frt Seat-Airfoam-Lea	90-91-92 Bro-Sed,98 Sedan
C 136526	Cushion Complete-Rear Seat-Airfoam-Cloth	90-91-92 Bro-Sed,98 Sedan
C 136527	Trim Assy-Rear Seat-Airfoam-Cloth	90-91 Bro-Sed,98 Sedan
C 136528	Cushion Complete-Rear Seat-Airfoam-Lea	92-93-95 VicCpe,1939-1940 Cv,1940 VicCpe-3Cpe
BZ 136540	Silencer-Rear Compartment Jack	1939 thru 1941 With Friction Ventilator
BO 136541	Plunger-Door Wing Locking Handle	90-91-40-41-44-45 Sed-2Sed-3Cpe-VicCpe,98-48 Sed, 10,11,18,20-21-28 exc Cv,51-171 exc CvBro, 53,58, 173,178,481-491-500-501 exc CvBro,483,493,503
BO 136542	Handle-Front Door Wing Locking-RH	90-91-40-41-44-45 Sed-2Sed-3Cpe-VicCpe,98-48 Sed, 10,11,19,20-21-28 exc Cv,51-171 exc CvBro,53,58, 173, 178,481-491-500-501 exc CvBro,483,493,503
BO 136543	Handle-Front Door Wing Locking-LH	90-91-40-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed,40C, 48C,10,11,18,20-21-28 exc Cv,CvBro,53,58,173,178
BO 136548	Plate-Front Door Wing Locking	90 Bro-Sed,98 Sed
BO 136550 En	Housing Assy-Headlamp-RH	90 Bro-Sed,98 Sed
BO 136551 En	Housing Assy-Headlamp-LH	90 Bro-Sed,98 Sed
BO 136552 Pr	Housing Assy-Headlamp-RH	90 Bro-Sed,98 Sed
BO 136553 Pr	Housing Assy-Headlamp-LH	90 Bro-Sed,98 Sed
BO 136554	Housing Assy-Headlamp Reflector	93,95,97
BO 136558	Clip-Hood Top Panel-Front-#2	1939 All
136586	Arm Rest Assy-Frt Door-RH	1939 All
136587	Arm Rest Assy-Frt Door-LH	90 UCo
C 136603	Trimboard Assy-Rear Compartment	97 Sedan,1940 thru 1942 Sed-2Sed-UCo,1946 Bro-Sed, 171-173
C 136614	Breakover & Trim Assy-Rear Seat Back	Bro-Sed
C 136615	Breakover & Trim Assy-Rear Seat Back	98 Sed,90 Bro,1940-1941 Sed-2Sed
C 136618	Trim Panel & Arm Rest Assy-Rear Compt-Taupe	90 VicCpe
C 136619	Trim Panel & Arm Rest Assy-Rear Compt-Maroon	90 VicCpe
C 136620	Trim Panel & Arm Rest Assy-Rear Compt-Tan	90 VicCpe
BO 136636	Base Plate-License Lamp Socket Mtg	90-91 Bro-Sed,90 UCo,98 Sedan
BO 136637	Spring-License Lamp Lens Retaining	90-91 Bro-Sed,90 UCo,98 Sedan
C 136638	Retainer-Curtain Assy-Top Quarter Window-RH	39 CvBro
C 136639	Retainer-Curtain Assy-Top Quarter Window-LH	39 CvBro
BO 136647	Dovetail-Rear Door-Male	1938 thru 1940 Panel
BO 136668	Molding-Radiator Shell-RH	90,98
BO 136669	Molding-Radiator Shell-LH	90,98
BO 136670	Molding-Radiator Grille	90,98
136671	Clip-Radiator Shell Molding (Use 125768)	90,98
BO 136672	Clip-Radiator Grille Molding	90,98
C 136678	Trim Assy-Rear Seat Back Compt-RH	1939-1940 Sed-2Sed-UCo
BO 136694	Carpet Assy-Rear Floor-LHD	90 thru 95 Sed With Bucket Seats
C 136714	Front End Assy-RHD	90 Bro-Sed-3Cpe-VicCpe
C 136715	Front End Assy-LHD	90 UCo-UCpe
C 136716	Front End Assy-RHD	90 UCo-UCpe
C 136718	Front End Assy-RHD	90 Cv
BO 136728	Door Assy-Locker Box-RH-LHD	90 exc Cab-CabPu-Panel-Station.98 Sedan
BO 136735	Adapter-Locker Box Door Clock	90 exc Cab-CabPu-Panel-Station
BO 136739	Bracket-w/s Washer Tank Mounting	1938 thru 1940 All
C 136750	Trimboard Complete-Lower Quarter-RH-Cloth	92 Sedan
C 136751	Trimboard Complete-Lower Quarter-LH-Cloth	92 Sedan
C 136752	Trimboard Complete-Lower Quarter-RH-Lea	92 Sedan
C 136753	Trimboard Complete-Lower Quarter-LH-Lea	92 Sedan
BO 136755	Carpet Assy-Rear Floor-LHD	39 Bro With Bucket Seats
BO 136762	Seal Washer-Rubber	1941-1942 All exc Del,1946-1947 All
BO 136775	Glass-Mechanical Clock	89,90,98
BO 136814	Lamp Assy-Front Fender-6 Volt	91,92,93,95,97
BO 136818	Base Assy-Front Fender-Lamp	91,92,93,95,97
BO 136820	Housing-Front Fender Lamp	91,92,93,95,97
BO 136821	Pad-Front Fender Lamp	91,92,93,95,97
C 136822	Grille-Front Fender-RH	90,98
C 136823	Grille-Front Fender-LH	90,98
BO 136831	Fastener-Radiator Grille Cover	1939-1940 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 136840	Plunger-Wing Locking Handle	90-91-40-41-45 Sed-2Sed-3Cpe-VicCpe,98-48 Sed,40C,48C,10,11,18,20-21 exc Cv,51-171 exc CvBro,53,58,173,178,481-491-500-501 exc CvBro,483,493,503
BO 136841	Knob-Wing Locking Handle Plunger	90-91-40-41-44-45 Sed-2Sed-3Cpe-VicCpe,98-48 Sed,40C,48C,10,11,18,20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178,481-491-500-501 exc CvBro,483,493,503
BO 136842	Frame Assy-F Door Wing Glass-RH	90-91-40P-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed
BO 136843	Frame Assy-F Door Wing Glass-LH	90-91-40P-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed
BO 136844	Glass & Frame Assy-Door Wing-RH	90-91-40P-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed
136845	Glass & Frame Assy-Door Wing-LH (Use 140875)	90-91-40P-41-44 Sed-2Sed-3Cpe-VicCpe,98-48 Sed
BO 136846	Retainer Assy-Door Wing W/Strip-RH	90-91 Bro-Sed-3Cpe-VicCpe,98 Sed
BO 136847	Retainer Assy-Door Wing W/Strip-LH	90-91 Bro-Sed-3Cpe-VicCpe,98 Sed
BO 136848	Retainer Assy-Door Wing W/Strip-RH	90-91 Bro-Sed-3Cpe-VicCpe,98 Sed
BO 136849	Retainer Assy-Door Wing W/Strip-LH	90-91 Bro-Sed-3Cpe-VicCpe,98 Sed
C 136851	Trimboard Assy-Rear Seat Back Spring	97 7Sed
C 136853	Trimboard Assy-Rear Seat Back Spring	97 7Sed
BO 136902	Headlamp Complete-RH	90,98 Sed-Cab-CabPu-Panel
C 136903	Headlamp Complete-LH	90,98 Sed-Cab-CabPu-Panel
BO 136926	Housing Assy-Headlamp-RH	90,98 Sed-Cab-CabPu-Panel
BO 136927	Housing Assy-Headlamp-LH	90,98 Sed-Cab-CabPu-Panel
BO 136928	Bolt-Headlamp Mounting	90,98 Sed-Cab-CabPu-Panel
C 136930	Door Complete-Front-RH-Spec Trim	93 Bro
C 136931	Door Complete-Front-LH-Spec Trim	93 Bro
C 136932	Door Complete-Front-RH-Spec Trim	93 Sed
C 136933	Door Complete-Front-LH-Spec Trim	93 Sed
C 136934	Door Complete-Front-RH-Spec Trim	93 VicCpe-3Cpe
C 136935	Door Complete-Front-LH-Spec Trim	93 VicCpe-3Cpe
C 136936	Door Complete-Rear-RH-Spec Trim	93 Sedan
C 136937	Door Complete-Rear-LH-Spec Trim	93 Sedan
C 136938	Door Complete-Front-RH-Spec Trim	95 Bro
C 136939	Door Complete-Front-LH-Spec Trim	95 Bro
C 136940	Door Complete-Front-RH-Spec Trim	95 Sedan
C 136941	Door Complete-Front-LH-Spec Trim	95 Sedan
C 136942	Door Complete-Front-RH-Spec Trim	95 3Cpe-VicCpe
C 136943	Door Complete-Front-LH-Spec Trim	95 3Cpe-VicCpe
C 136944	Door Complete-Rear-RH-Spec Trim	95 Sedan
C 136945	Door Complete-Rear-LH-Spec Trim	95 Sedan
C 136946	Trimboard Complete-Front Door-RH-Spec Trim	93 Bro-3Cpe-VicCpe
C 136947	Trimboard Complete-Front Door-LH-Spec Trim	93 Bro-3Cpe-VicCpe
C 136948	Trimboard Complete-Front Door-RH-Spec Trim	93 Sedan
C 136949	Trimboard Complete-Front Door-LH-Spec Trim	93 Sedan
C 136950	Trimboard Complete-Rear Door-RH-Spec Trim	93 Sedan
C 136951	Trimboard Complete-Rear Door-LH-Spec Trim	93 Sedan
C 136952	Trimboard Complete-Front Door-RH	95 Bro-3Cpe-VicCpe
C 136953	Trimboard Complete-Front Door-LH	95 Bro-3Cpe-VicCpe
C 136954	Trimboard Complete-Front Door-RH	95 Sed
C 136955	Trimboard Complete-Front Door-LH	95 Sed
C 136956	Trimboard Complete-Rear Door-RH	95 Sed
C 136957	Trimboard Complete-Rear Door-LH	95 Sed
136966	Carpet Assy-Rear Floor	97 7Sed
136967	Use 137324	
136968	Use 137325	
136969	Use 137324	
136970	Use 137325	
136971	Use 137324	
136972	Use 137325	
C 136975	Back Complete-Front Seat-Cord	97 7Sed
C 136976	Cushion Complete-Front Seat-Cord	97 7Sed
136978	Use 137271	
136979	Use 137272	
136980	Use 137271	
136981	Use 137272	
136982	Use 137273	
136983	Use 137274	
136984	Use 137273	
136985	Use 137274	
136986	Use 137273	
136987	Use 137274	
C 137009	Back Complete-Rear Seat-With Container	90 CvBro
BO 137011	Floor Board-Rear Compartment	1939-1940 7Sed
C 137016	Top Complete-Trimmed	90 CvBro,1940 CvSed
C 137017	Top Deck & Side Quarter Assy	90 CvBro,1940 CvSed
C 137018	Trim Panel & Curtain Bag Assy-Rear Seat Back	90 CvBro
C 137019	Back Complete-Rear Seat	90 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 137030	Back Complete-Rear Seat-Cloth	97 7Sed
C 137031	Cushion Complete-Rear Seat-Cloth	97 7Sed
C 137036	Back Complete-Rear Seat-Cloth	98 7Sed
C 137037	Cushion Complete-Rear Seat-Cloth	98 7Sed
C 137039	Cushion Complete-Rear Seat-Airfoam	98 7Sed
BO 137080	Adaptor-Locker Box Door Clock	90 exc Cab-CabPu-Panel-Station,91
137098	Covering Assy-Rear Compt Floor	91 VicCpe
137100	Mat & Pad Assy-Front Floor (Use 201134)	33 thru 39 All
C 137115	Back Complete-Front Seat-Drivers-LHD	90 Cv
C 137116	Back Complete-Front Seat-Drivers-RHD	90 Cv
C 137117	Back Complete-Front Seat-Pass-LHD	90 Cv
C 137118	Back Complete-Front Seat-Pass-RHD	90 Cv
C 137121	Back Complete-Front Seat-Driver-LHD	92-93-95 Cv
C 137122	Back Complete-Front Seat-Driver-RHD	92-93-95 Cv
C 137123	Back Complete-Front Seat-Pass-LHD	92-93-95 Cv
C 137124	Back Complete-Front Seat-Pass-RHD	92-93-95 Cv
BO 137136	Socket Assy-Headlamp Main Bulb	91,92,93,95,97
BO 137137	Socket Assy-Headlamp Main Bulb	90,98
137139	Use 137324	
137140	Use 137324	
C 137142	Back Comp-Front Seat-Mohair	97 7Sed
C 137143	Cushion Comp-Front Seat-Mohair	97 7Sed
137145	Use 137272	
137148	Use 137271	
137149	Use 137272	
C 137150	Back Complete-F Seat-Mohair	98 7Sed
C 137151	Cushion Complete-F Seat-Mohair	98 7Sed
137152	Seat Complete-Aux-RH-Mohair (Use 137271)	97 7Sed
137153	Seat Complete-Aux-LH-Mohair (Use 137272)	97 7Sed
C 137154	Back Complete-Rear Seat-Mohair	97 7Sed
C 137155	Cushion Complete-Rear Seat-Mohair	97 7Sed
C 137156	Trim Assy-Rear Seat Cushion Mohair	97 7Sed
C 137158	Trim Panel & Trim Assy-F Seat End-RH	39 VicCpe-3Cpe-Cv
C 137159	Trim Panel & Trim Assy-F Seat End-LH	39 VicCpe-3Cpe-Cv
BO 137169	Corner Brkt-F Seat Frame-Upper	1939 thru 1942 7Sed
BO 137170	Brkt-F Seat Frame Corner-RH	1939 thru 1942 7Sed
BO 137171	Brkt-F Seat Frame Corner-LH	1939 thru 1942 7Sed
A 137201	Panel Assy-Instrument	92
BO 137219	Carpet Assy-F Seat Back Kick	97-98-43-47-48-17-18 7Sed
C 137230	Cover Assy-F Seat Cushion Rubber Pad	97-98 7Sed
137232	Use 1 each 137271-2	
137233	Use 137273-4	
137234	Use 1 each 137271-2	
137235	Use 1 each 137273-4	
C 137244	Trim Assy-F Seat Partition-Front-Cloth	97-98-17-18 7Sed
C 137245	Trim Assy-F Seat Partition-Front-Leather	97-98-17-18 7Sed
C 137246	Trim Assy-F Seat Partition-Rear-Cloth	97-98-17-18 7Sed
C 137247	Trim Assy-F Seat Partition-Rear-Leather	97-98-17-18 7Sed
C 137271	Seat Complete-Auxiliary-RH-Cloth	1939-1940 7Sed
C 137272	Seat Complete-Auxiliary-LH-Cloth	1939-1940 7Sed
C 137273	Seat Complete-Auxiliary-RH-Leather	1939-1940 7Sed
C 137274	Seat Complete-Aux-LH-Leather	1939-1940 7Sed
BO 137291	Door Assy-Locker Box-LH-LHD	93,95,97
BO 137292	Door Assy-Locker Box-RH-RHD	93,95,97
BO 137293	Door Assy-Locker Box-LH-RHD	93,95,97
BO 137295	Ash Tray & Cover Assy-Inst Panel	93,95,97
C 137324	Back Complete-Front Seat-Std Trim	1939-1940 7Sed
C 137325	Cushion Complete-Front Seat-Std Trim	1939 thru 1942 7Sed
137351	Mat & Pad Assy-F Floor-LHD (Use 201134)	91 Panel Without Handy Shift
137353	Mat & Pad Assy-F Floor-LHD (Use 201134)	91 Panel With Handy Shift
C 140002	Panel-Cowl-RH	40
C 140003	Panel-Cowl-LB	40
140004	Panel-Cowl-RH (Use 146004)	41 thru 48
140005	Panel-Cowl-LH (Use 146005)	41 thru 48
C 140028	Panel Assy-Dash-LHD	1940 All
*A 140030	Fender-Rear-RH-Use With R/Board	40T,40P,41,43,44,45,47
*A 140031	Fender-Rear-LH-Use With R/Board	40T,40P,41,43,44,45,47
*A 140032	Fender-Rear-RH-Use less R/Board	40T,40P,41,43,44,45,47,40 UCo
*A 140033	Fender-Rear-LH-Use Less R/Board	40T,40P,41,43,44,45,47,40 UCo
*A 140039	Fender-Rear-LH-Use With R/Board	40T 3Cpe
*A 140040	Fender-Rear-RH-Use With R/Board	1940 3Cpe-VicCpe-Cv
*A 140041	Fender-Rear-LH-Use With R/Board	40P-41-44 3Cpe-VicCpe-Cv,40T VicCpe
*A 140042	Fender-Rear-RH-Use Less R/Board	1940 3Cpe-VicCpe-Cv
*A 140043	Fender-Rear-LH-Use Less R/Board	40P-41-44 3Cpe-VicCpe-Cv,40T VicCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 140044	Fender-Rear-RH-LHD	40 Ucpe
A 140045	Fender-Rear-LH-LHD	40 Ucpe
A 140046	Fender-Rear-RH-RHD	40 UCpe
A 140047	Fender-Rear-LH-RHD	40 Ucpe
A 140049	Fender-Rear-LH-Use Less R/Board	40T 3Cpe
C 140065	Panel-Roof	1940 3Cpe-VicCpe-UCpe
C 140073	Floor Cover-Transmission Opening-RHD	1940 All
BO 140080	Bracket-Windshield Header Domelamp	1940 thru 1942 exc Cv,1946-1947 exc CvBro
BO 140086	Bracket-Center Pillar to Underbody	1940 thru 1942 Sed-Carryall,1946 Sed
C 140091	Pillar Assy-Center	1940-1941 Sed-Carryall
C 140131	Header Assy-Windshield	1940 exc Cv
C 140132	Support-Rear Fender Apron	40-41-48 CabPu
*A 140136	Fender Assy-Rear-RH	40-41-48 CabPu
*A 140137	Fender Assy-Rear-LH	40-41-48 CabPu
C 140155	Extension Assy-Rear Scat Tray	1940 Sed-2Sed-UCo-Carryall
C 140160	Brkt & Toe Board Riser Assy-F Body Pillar to Dash-RH-LHD	41,43,44,45,47,48
C 140161	Brkt & Toe Board Riser Assy-F Body Pillar to Dash-LH-LHD	41,43,44,45,47,58
C 140166	Pillar Assy-Rear Body-RH	1940 2Sed-UCo
C 140167	Pillar Assy-Rear Body-LH	1940 2Sed-UCo
C 140168	Pillar Assy-Rear Body-RH	1940 3Cpe-VicCpe-UCpe
C 140169	Pillar Assy-Rear Body-LH	1940 3Cpe-VicCpe-UCpe
BO 140175	Tapping Plate-Door Lock Striker	1940 thru 1942 Cpe-CvSed-Sed-2Sed-Uco-Cab-CabPu-Panel,1946-1947 All
C 140180	Tire Well-Rear Seat Tray	1940 Sed-2Sed-UCo-VicCpe,40P-41-44-3Cpe,1941 All
C 140188	Pillar Assy-Rear Body-RH	40-48 CabPu-Cab-Panel
C 140189	Pillar Assy-Rear Body-LH	40-48 CabPu-Cab-Panel
*A 140202	Hood Assy	41 thru 48
*A 140212	Hood Assy	40
BO 140217	Spring-Hood Lock Return	1940 All
BO 140218	Pivot Bolt-Hood Supp Arm	1940 thru 1947 All
140224	Use 140233	
C 140225	Reinforcement & Bracket Assy-Hood-Center	1940 thru 1947 All
BO 140230	Rivet-Hood Supp Arm Spring	1940 thru 1947 All
BO 140231	Rivet-Hood Supp Arm Lower Pivot	1940 thru 1947 All
BO 140232	Bolt-Hood Supp Arm Upper Pivot	1940 thru 1949 All
BO 140233	Bracket-Hood Rear Reinf Rear Hood Lock	1940 thru 1942 All,1946 exc DeL
A 140235	Reinforcement & Brkt Assy-Hood Rear	10,20
A 140236	Reinforcement Assy-Hood-Rear	41 thru 48,11 thru 18,21 thru 28,1946-1947 All
C 140238	Cross Shaft Assy-Hood Lock-LHD	1940-1941 All
140239	Cross Shaft Assy-Hood Lock-RHD (Use 203238)	1940-1941 All
C 140260	Extension-Underbody Panel-RH	1940 UCo-3Cpe-VicCpe-UCpe-Cv,40-41-44-45 Sed, 40 Cab-CabPu-Panel
C 140261	Extension-Underbody Panel-LH	1940 UCo-3Cpe-VicCpe-UCpe-Cv,40-41-44-45 Sed, 40 Cab-CabPu-Panel
C 140262	Extension-Underbody Panel-RH	43-47-48 Sed,48 Cab-CabPu-Panel
C 140263	Extension-Underbody Panel-LH	43-47-48 Sed,48 Cab-CabPu-Panel
BO 140272	Bracket-Cowl Vent Deflector to Hinge-RH	1940 All
BO 140273	Bracket-Cowl Vent Deflector to Hinge-LH	1940 All
*BO 140274	Cover Assy-Cowl Ventilator	1940 All
BO 140275	Operating Rod-Cowl Ventilator	1940 All
BO 140276	Guide-Cowl Ventilator Operating Handle	1940 All
BO 140278	Knob-Cowl Ventilator Handle	1940 All
BO 140281	Washer-Cowl Vent Cyr & Deck Door Check Arm Rivet.	1940 thru 1942 All
BZ 140291	Support Assy-Front Fender Apron	1940 thru 1947 All
*A 140311	Louver Panel Assy-Radiator	1940 All
A 140312	Shield-Radiator Lower Tank	40,48
A 140313	Shield-Radiator Lower Tank	41,43,48
A 140314	Shield-Radiator Lower Tank	44,45,47
C 140332	Reinforcement Assy-F Body Pillar-RH	1940-1942 2Sed-Sed-3Cpe-VicCpe-UCo-Ucpe-Panel, 1946-1947 All exc CvBro
C 140333	Reinforcement Assy-F Body Pillar-LH	1940-1942 2Sed-Sed-3Cpe-VicCpe-UCo-UCpe-Panel, 1946-1947 All exc CvBro
BO 140349	Clip-Wire	1940 thru 1950 All
A 140356	Cover Assy-F Fender Side Dust Shield Hole	1940 thru 1946 All
140364	Use 146315	
BO 140369	Bracket-Hood Hinge Cross Shaft Adjusting	1940-1941 All
BO 140370	Frame Bracket-Hood Hinge Cross Shaft-RH	1940-1941 All
BO 140371	Frame Bracket-Hood Hinge Cross Shaft-LH	1940-1941 All
BZ 140435	Bracket-F Fender Brace Rod-LH	1940 All
BZ 140436	Rod-F Fender to Frame Crossmember Brace	1940 All
BZ 140438	Bracket-Battery Hold Down-Rear	14,15,17,1942 thru 1947 All
BO 140468	Shim-F Fender Side Dust Shield to Frame	1940 thru 1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 140469	Hood Guide-F Fender Side Dust Shield-Front	1940 thru 1947 All
140470	Hood Guide-F Fdr Side Dust Shield-Center & Rear (Use 211106)	1940-1941 All
BO 140471	Speed Nut-Fender Dust Shield Hood Guide	1940 thru 1947 All
C 140481	Reinforcement Assy-Rear Comp Opening	1940 Sed-2Sed-UCo
C 140484	Carrier Assy-Inside Tire	40-10-11-12-14-20-21-22-24 3Cpe,40-10-20 UCpe
C 140501	Panel-F Door Outside-LH	40-41-44-45 2Sed,43-47-48 Sed,40 UCo,48 Carryall
C 140504	Panel-F Door Outside-RH	40-41-44-45 Sed,1940 Cab-CabPu-Panel
C 140505	Panel-F Door Outside-LH	40-41-44-45 Sed,1940 Cab-CabPu-Panel
C 140506	Panel-F Door Outside-RH	40T Sed,1940 Cab-CabPu-Panel
C 140507	Panel-F Door Outside-LH	40T Sed,1940 Cab-CabPu-Panel
C 140508	Panel-F Door Outside-RH	40-41-44-45 3Cpe-VicCpe-UCpe
C 140509	Panel-F Door Outside-LH	40-41-44-45 3Cpe-VicCpe-UCpe
C 140510	Panel-F Door Outside-RH	40T 3Cpe-VicCpe,40 UCpe
C 140511	Panel-F Door Outside-LH	40T 3Cpe-VicCpe,40 UCpe
C 140514	Panel-Rear Door Outside-RH	1940 Sed
C 140540	Panel Assy-F Door Outside-RH	40T 2Sed,40C UCo,48 Sed
C 140541	Panel Assy-F Door Outside-LH	40T 2Sed,40C UCo,48 Sed
BO 140559	Bracket Assy-Rear License Plate	1940 Cpe-CvSed
C 140568	Front End Assy-LHD	41-44-45 exc Cv,43-47-48 Sed
C 140569	Front End Assy-RHD	41-44-45 exc Cv,43-47-48 Sed
C 140604	Running Board Kit-For Cars Without R/Boards	40
C 140612	Running Board Complete-RH	43,47,48
C 140613	Running Board Complete-LH	43,47,48
BO 140663	Bracket-F Seat Riser to Cushion Frame	1941-1942 Sed-3Cpe
140667	Bracket-F Seat Side Panel to Cushion Frame (Use 203807)	40-41-44-45 Sed,48 5Sed,41-44 3Cpe,1941 3Cpe- 2Sed,18 Sed
BO 140669	Pivot Pin-F Seat Back Panel Hinge Bracket	1940 thru 1942 2Sed,VicCpe-Cv,40T-10-11-12-14-15 3Cpe,40-10-20 UCpe,1946-1947 Bro- ClubCpe,CvBro
140670	Use 140682	
140671	Use 140683	
BO 140682	Hinge Bracket Assy-F Seat Back Panel-RH	1940 thru 1942 VicCpe-Cv-2Sed,40T-10-11-12-14-15 3Cpe,40-10-20 UCpe,1946-1947 Bro-ClubCpe-CvBro
BO 140690	Weatherstrip-Quarter Window	40T-48 Sed
C 140704	Panel Assy-Underbody	40-41-44-45 Sed
BZ 140756	Brkt-F Fdr Side Dust Shield Hole Cvr to Frame-RH	1940 thru 1947 All
BZ 140757	Brkt-F Fdr Side Dust Shield Hole Cvr to Frame-LH	1940 thru 1947 All
BZ 140758	Brace-F Fdr Side Dust Shield Hole Cvr to Fr Brkt- Frt	1940 thru 1947 All
BZ 140759	Brace-F Fdr Side Dust Shield Hole Cvr to Fr Brkt- Rear	1940 thru 1947 All
BZ 140760	Nut-F Fdr Side Dust Shield Retainer Bolt	40,48,10,20
BO 140763	Plate-F Seat Track Adjusting	40 thru 48 5Sed,40P-41-44 3Cpe
C 140764	Frame Assy-Front Seat Back	40-41-44-10-11-12-14 3Cpe,40-41-44-45-10-11-12- 14 Sed,48 5Sed
BO 140808	Air Stop Block-Lower W/Shield Finish Mldg	1940 thru 1947 All
C 140809	Glass Run-F Door Window Center Bar	1940 thru 1942 exc 40T-40C-10T-10C-48-18-All Cv, 51-171 exc CvBro,53,58,173,178
BO 140812	Frame-Door Wing Glass-RH	1940 thru 1947 Cv
BO 140813	Frame-Door Wing Glass-LH	1940 thru 1947 Cv
BO 140817	Cradle-Door Wing-LH	1940 Cv
BO 140820	Track Assy-Front Door-RH	1940 Cv
BO 140824	Channel & Brkt Assy-F Door Glass Run-RH	1940 thru 1942 exc 40T-40C-10T-10C-48-18-All Cv, 1946-1947 exc CvBro
BO 140825	Channel & Brkt Assy-F Door Glass Run-LH	1940 thru 1942 exc 40T-40C-10T-10C-48-18-All Cv, 1946-1947 exc CvBro
BO 140830	Remote Control Assy-F Door Lock-RH	1940 2Sed-3Cpe-VicCpe-CvCpe-CvSed-UCo,43-47- 48 Sed,1941 CvSed
BO 140831	Remote Control Assy-F Door Lock-LH	1940 2Sed-3Cpe-VicCpe-Cv-UCo,43-47-48 Sed,1941 CvSed
140832	Remote Control Assy-F Door Lock-RH (Use 148172)	40T-40P-41-44-45 Sed,10C exc UCo-UCpe,18C
BO 140833	Remote Control Assy-F Door Lock-LH	40T-40P-41-44-45 Sed,10C exc UCo-UCpe,18C
BO 140834	Remote Control Assy-Rear Door Lock-RH	1940-1941 Sed-CA
BO 140835	Remote Control Assy-Rear Door Lock-LH	1940-1941 Sed-CA
BO 140842	Guide-Door Wing Glass Frame	1940 Cv,1941-1942 Sed-1946-1947 CvBro
BO 140844	Glass & Frame Assy-Door Wing-RH	40-41-44 Cv,1941-1942 CvSed 1946-1947 CvBro
BO 140845	Glass & Frame Assy-Door Wing-LH	40-41-44 Cv,1941-1942 CvSed 1946-1947 CvBro
BZ 140869	Bracket & Arm Assy-Rear License Plate	1940 Sed-2Sed-UCpe
BO 140874	Glass & Frame Assy-F Door Wing-RH	40-41-44-45 Sed-2Sed-3Cpe,VicCpe,40C,48,10,11, 18,20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178
BO 140875	Glass & Frame Assy-F Door Wing-LH	40-41-44-45 Sed-2Sed-3Cpe-VicCpe,40C,48,10,11,18, 20-21-28 exc Cv,51-171 exc CvBro,53,58,173,178
140880	Use 146880	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
140881	Fender Assy-Front-LH (Use 146881)	40,41,44,45;48
140882	Fender Assy-Front-RH (Use 146880)	43,45.47
140883	Fender Assy-Front-LH (Use 146881)	43.45,47
BO 140891	Lamp Kit-Mechanical Clock-LHD-6 Volt	40.41,44.45,48
BZ 140931	Support-Rear Fender Apron	1940 Panel
BO 140936	Lock Plate-Rear Compt Door Latch	1940 Scd-2Sed-UCo
BO 140948	Spring-F Seat Track Locking Handle	1940 Sedan
BZ 140950	Support-Rear Fender Stone Guard-Lower-RH	1940 Scd-2Sed,40 IJCo
BZ 140951	Support-Rear Fender Stone Guard-Lower-LH	1940 Sed-2Sed,40 UCo
BZ 140952	Support-Rear Fender Stone Guard-Lower-RH	40 thru 44 Cpe-CvSed,40 UCpe
BZ 140953	Support-Rear Fender Stone Guard-Lower-LH	40 thru 44 Cpe-CvSed,40 UCpe
BO 140964	Center Bar-Windshield	1940 thru 1947 exc Cv
BO 140965	Center Bar-W/Shield-Inner	1940-1941-1942 exc Cv,1946-1947 exc CvBro
BO 140966	Ornament-Deck Door Panel	1940 3Cpe-VicCpe-Cv-Cpe
140967	Seal Washer-Ornament (Use 136762)	1940 3Cpe-VicCpe-Cv-UCpe,1941 All
BO 140968	Molding-Deck Door Panel	1940 3Cpe-VicCpe-Cv-UCpe
BO 140969	Center Bar-Windshield-Outer	1940-1941-1942-1946-1947 Cv
C 140971	Molding-F Door Trim Panel	40P-45 Sed-CvSed,40T Leather Trim Sed
C 140972	Molding-Quarter Trim Panel-Cloth Trim	40P-45 2Sed
C 140972	Molding-F Door Trim Panel-#5	43-47-48 Sed
C 140973	Molding-Rear Door Trim Panel-#1-2-3	40-43-45-47-48 Sod
C 140974	Molding-Rear Qtr Trim Panel-Cloth Trim	40P 3Cpe-VicCpe-CvCpe
C 140974	Molding-Rear Door Trim Panel-#4	43-47 Sed
C 140975	Molding-Qtr Trim Panel-Cloth Trim	40P Sed
C 140975	Molding-Rear Door Trim Panel-#5	43-47 Sed
C 140978	Molding-Front Door Trim Panel	40P-45 2Sed-3Cpe-VicCpe-Cv,43-47-48 5Sed
BO 140979	Center Bar-Windshield-Inner-Prime	1940 Cv,1941-1942 CvSed,1946-1947 CvBro
C 140980	Molding-Hood Side-Long	40
BO 140981	Molding-Hood Side-Short	40
C 140982	Molding-Hood Belt	40
C 140983	Molding-Hood Belt	41 thru 48
C 140985	Molding-F Fender-Upper	43,45,47
BO 140986	Molding-F Fender-Lower	43,45,47
BO 140987	Trim Molding-F Fender-Used Less R/Board	1940 All
C 140988	Trim Molding-Underbody Panel Extension	40
C 140989	Trim Molding-Underbody Panel Extension	41,44,45
140990	Use 140991	
C 140991	Trim Molding-Underbody Panel Extension	43,47,48
BO 140992	Bolt-Underbody Extension Trim Molding (Pkg 10)	1940 .111
BO 140993	Clip-Hood Side Molding	40
BZ 140994	Clip-Running Board	43,47.48
BO 140995	Molding-Front Door Trim Panel-Upper	43-47 Sed
BO 140996	Molding-Rear Door Trim Panel-Upper	43-47 Sed
BO 140997	Molding-Quarter Arm Rest	43-47 Sed
C 140998	Panel Assy-Underbody	40 Panel
141178	Tubing-W/Shield Cleaner-Std Pump (Use 117495)	1940 All
C 141179	Welt-Rear Fender	1940 VicCpe-3Cpe-CvCpe-CvSed-UCpe-Panel
141196	Gauge-Gasoline-Dash Unit-First Type (Use 142136)	1940 All
141197	Gauge-Temperature-Dash Unit (Use 142137)	1940 All
A 141202	Panel Assy-Instrument-LHD	1940 Export
A 141203	Panel Assy-Instrument-RHD	1940 Export
A 141204	Panel Assy-Instrument-LHD	40-48 Cab-CabPu-Panel,45-47 Sed
A 141205	Panel Assy-Instrument-RHD	40-48 Cab-CabPu-Panel,43-47 Sed
A 141206	Panel Assy-Instrument-LHD-Grained	40 thru 48 exc Cab-CabPu-Panel
C 141213	Finish Mldg-Rear Window Reveal-With Clips-LH ..	1940 Sed-2Sed
C 141214	Finish Mldg-Rear Window Reveal-Without Clips-RH	1940 Sed-2Sed
C 141215	Finish Mldg-Rear Window Reveal-Without Clips-LH	1940 Sed-2Sed
BO 141216	Weatherstrip-Rear Window	40P thru 47 2Sed-Sed
C 141221	Body Assy-LHD	40
C 141222	Body Assy-RHD	40
141236	Safety Lock Assy-Door-Less Cylinder (Use 204012)	1941 thru 1942 exc Station-DeL,1946 All
141238	Safety Lock Complete-Door (Use 204014)	1941 thru 1942 exc Station-DeL,1946 All
BO 141239	Plunger-Rear Compt Door Operating Link	1940 Sed-2Sed-UCo
BO 141249	Weatherstrip-Rear Compt Door	1940 Sed-2Sed-Uco
141255	Rim-Headlamp Lens (Use 206499)	
BO 141256	Cylinder Assy-Door Safety Lock	1941 thru 1942 exc Station,1946-1947 All
BO 141258	Cap-Steering Gear Jacket Tube Bracket	40 thru 48,10-11-18-20-21-28-51-53-171-173-481-483-491-493-500-501-503 With DI
C 141265	Trim Retainer Assy-Rear Door Lock Pillar-LH	1940 Sed,10,15,17,18
C 141266	Trim Retainer Assy-Rear Body Pillar-RH	1940-1941 2Sed,UCo-Cab-CabPu-Panel,1946 Cab-CabPu
C 141267	Trim Retainer Assy-Rear Body Pillar-LH	1940 thru 1942 2Sed-UCo-Cab-CabPu-Panel,1946-1947 Bro-Cab-CabPu
C 141268	Trim Retainer Assy-Rear Body Pillar-RH	1940-1941 3Cpe-VicCpe-UCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 141276	Cylinder & Keys Assy-Door Safety Lock	1940 thru 1947 All
BO 141277	End-Robe Rail	43-47-17-18 5Sed
C 141280	Scuff Plate-Front Door-RH	40-10-20 2Sed-UCe-Cpe-Cv,48P,18P,28P
C 141281	Scuff Plate-Front Door-LH	40-10-20 2Sed-UCo-Cpe-Cv,48P,18P,28P
C 141282	Scuff Plate-Front Door-RH	41-44-45-11-12-14-15-21-22-24-25 exc Sed,43,47,17,27
C 141283	Scuff Plate-Front Door-LH	41-44-45-11-12-14-15-21-22-24-25 exc Sed,43,47,17,27
C 141284	Scuff Plate-Front Door-RH	40-10-20 Sed
C 141285	Scuff Plate-Front Door-LH	40-10-20 Sed
C 141286	Scuff Plate-Front Door-RH	41-44-45-11-12-14-21-22-24-25 Sed-Station
C 141287	Scuff Plate-Front Door-LH	41-44-45-11-12-14-21-22-24-25 Sed-Station
141288	Scuff Plate-Rear Dopr-RH (Use 141290)	40T-40P Sed
BO 141289	Scuff Plate-Rear Door-LH	40T-40P Sed
BO 141290	Scuff Plate-Rear Door-RH	41-44-45 Sed
BO 141291	Scuff Plate-Rear Door-LH	41-44-45 Sed
141292	Scuff Plate-Rear Door-RH (Use 141294)	48 Sed
141293	Scuff Plate-Rear Door-LH (Use 141295)	48 Sed
BO 141295	Scuff Plate-Rear Door-LH	43-47 Sed
BO 141301	Speedometer Assy-Miles	1940 All
BO 141303	Speedometer Assy-Metric	1940 All
141305	Use 142890	
F 141311	Cluster Assy-Oil & Generator	1940 All
BO 141316	Key-Mechanical Clock Winding	1940 All
BO 141319	Dial-Inst Cluster & Speedometer-Miles-LHD	43,47
BO 141320	Dial-Inst Cluster & Speedometer-Metric-LHD	43,47
BO 141321	Dial-Inst Cluster & Speedometer-Miles-RED	43,47
BO 141322	Dial-Inst Cluster & Speedometer-Metric-RHD	43,47
BO 141323	Dial-Inst Cluster & Clock-LHD	43,47
BO 141324	Dial-Inst Cluster & Clock-RHD	43,47
141329	Use 142388	
BO 141330	Lens-Inst Cluster & Clock	1940 All
BO 141331	Bezel-Inst Cluster & Clock	1940 All
BO 141340	Regulator Assy-F Door Wing-RH	1940 thru 1942 Cv,43,47,22,24,25,27,51-171 CvBro, 52,54,172,174
BO 141341	Regulator Assy-F Door Wing-LH	1940 thru 1942 Cv,43,47,22,24,25,27,51-171 CvBro, 52,54,172,174
BO 141342	Regulator Assy-F Door Window-RH	1940 thru 1942 exc Cv-De1,1946-1947 exc CvBro
BO 141343	Regulator Assy-F Door Window-LH	1940 thru 1942 exc Cv-De1,1946-1947 exc CvBro
BO 141345	Wick-Door Lock Striker	1940-1941-1942-1946-1947 All
BO 141351	Track Assy-Front Door	1940 thru 1947 exc Cv
BO 141353	Window Stop-Front Door Track	1940 thru 1947 exc Cv
BO 141354	Guide-Front Door Window Roller-RH	1940 thru 1947 exc Cv
BO 141355	Guide-Front Door Window Roller-LH	1940 thru 1947 exc Cv
BO 141356	Pilot-F Door Window Roller Guide to Track	1940 thru 1947 exc Cv
BO 141357	Friction Washer-F Door Window Guide to Pilot	1940 thru 1947 exc Cv
BO 141360	Channel & Roller Guide Supp Brkt Assy-F Door Window Glass-RH	40-41-44-45-10-11-12-14-15-20-21-22-24 Sed,1940-1941 Cab-CabPu-Panel,1946-1947 Sed-Cab-CabPu
BO 141361	Channel & Roller Guide Supp Brkt Assy-F Door Window Glass-LH	40-41-44-45-10-11-12-14-15-20-21-22-24 Sed,1940-1941 Cab-CabPu-Panel,1946-1947 Sed-Cab-CabPu
BO 141362	Channel & Roller Guide Supp Brkt Assy-F Door Window Glass-RH	40-41-44-10T Sed-3Cpe-ClubCpe,40-10 UCo-UCpe,43,47,48P-18P,1941 ClubCpe-3Cpe-2Sed,27,1946-1947 Bro-3Cpe-ClubCpe
BO 141363	Channel & Roller Guide Supp Brkt Assy-F Door Window Glass-LH	40-41-44-10T Sed-3Cpe-ClubCpe,40-10 UCo-UCpe,43,47,48P,18P,1941 ClubCpe-3Cpe-2Sed,27,1946-1947 Bro-3Cpe-ClubCpe
BO 141365	Shim-F Door Track to Crossmember	1940 thru 1947 exc Cv
BO 141366	Shim-F Door Regulator to Crossmember	1940 thru 1942 exc Cv,1946-1947 Bro-3Cpe-ClubCpe
C 141371	Frame Assy-Quarter Window-LH	1940 2Sed-UCo
141382	Bar-Front-Bumper-Outside (Use 1-141383 & 2-141721)	40T,40C ,48C ,10T,10C ,18
C 141383	Bar-Front Bumper-Outside	43,47
C 141384	Frame Bar-Front Bumper-RH	40 thru 48,10,11,18
C 141385	Frame Bar-Front Bumper-LH	40 thru 48,10,11,18
141389	Bar-Rear Bumper Outside (Use 206961 & 206223)	43-47 Sed
C 141390	Frame Bar Assy-Rear Bumper-RH	1940 Sed-2Sed-UCo
C 141391	Frame Bar Assy-Rear Bumper-LH	1940 Sed-2Sed-UCo
C 141395	Bar-Rear Bumper Outside	40P-41-44-45 VicCpe-CvCpe-3Cpe-CvSed
C 141396	Frame Bar Assy-Rear Bumper-RH	1940 3Cpe-VicCpe-UCpe-CvCpe-CvSed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 141397	Frame Bar Assy-Rear Bumper-LH	1940 3Cpe-VicCpe-UCpe-CvCpe-CvSed
BZ 141398	Bolt-Rear Bumper to Frame-Front	1940 exc Comm,1941-1942 All,51 thru 54,171 thru 174,178 Station
BZ 141406	Spacer-Bumper Fender Guard	40P,41,42,44,45,48,10,11,18,20,28,58,178
BZ 141407	Spacer-Bumper Fender Guard	40,43,45,47,21 thru 27
C 141409	Trim Molding-Running Board	43,47,48
C 141420	Louver-Radiator-Upper-RH	1940 All
C 141421	Louver-Radiator-Upper-LH	1940 All
C 141422	Louver-Radiator-Lower-RH	1940 All
C 141423	Louver-Radiator-Lower-LH	1940 All
141426	Use 205426	
BO 141427	Reflector Assy-W/S Header Domelamp	43-47-48 Sed,48 CA,10 exc Cab-CabPu-Del,11 thru 17,20,28P
C 141430	Stone Guard-Rear Fdr-RH-Use Less R/Boards	1940 All
C 141431	Stone Guard-Rear Fdr-LH-Use Less R/Boards	1940 All
141432	Spring-Hood Top Panel Support (Use 204180)	40,10 exc Del
141433	Spring-Hood Top Panel Support (Use 204180)	41 thru 48,11 thru 18,20
BO 141434	Grille-Instrument Panel	1940 All
BO 141436	Ornament-Inst Panel Grille	1940 All
BO 141438	Grille-Instrument Panel	44,45,47
BO 141514	Retaining Bar-Radio Grille-Painted	40-48 Cab-CabPu-Panel,43-47 5Sed
BO 141515	Retaining Bar-Radio Grille	40 thru 48 exc Cab-CabPu-Panel
BO 141518	Name Plate Kit-Inst Panel Grille	44,47
BO 141519	Name Plate-Inst Panel Grille	44,45,47
141528	Door Assy-Locker Box-RH-LHD (Use 141532)	40T,40P,41,44,45,48P,40C uco-ucpe
BO 141529	Door Assy-Locker Box-LH-LHD	40T,40P,41,44,45,48P,40C UCo-UCpe
BO 141532	Door Assy-Locker Box-RH-LHD	43,47
BO 141544	Use 1 each 141555-141557	
BO 141545	Use 1 each 141555-141557	
BO 141546	Hinge Locker Box Door-Body Half	1940 All
BO 141547	Hinge & Pin Assy-Locker Box Door-Body Half	1940 All
BO 141550	Molding-Locker Box Door	43,47
BO 141551	Lock Assy-Locker Box Door-Less Cyl	1940 All
BO 141552	Cylinder & Keys Assy-Locker Box Door Lock	1940 All
BO 141553	Retaining Sleeve-Locker Box Door Lock	1940 All
141554	Use 1 each 141547-141555	
BO 141555	Door Hinge-Locker Box-Door Half	1940 All
141556	Hinge Assy-Locker Box Door (Use 141547 & 141555)	1940 All
BO 141557	Pin-Locker Box Door Hinge	1940 All
BO 141558	Striker Plate-Locker Box Door Lock	1940 All
BO 141559	Spring-Locker Box Door	1940 All
BO 141586	Brkt-F Scat Cush Retainer to Underbody	1940 Sed-2Sed
BO 141589	Dial-Inst Cluster & Speedometer-Miles-LHD	40,41,44,45,48
BO 141591	Dial-Inst Cluster & Speedometer-Miles-RHD	40,41,44,45,48
BO 141593	Dial-Inst Cluster & Clock-LHD	40,41,44,45,48
BO 141594	Dial-Inst Cluster & Clock-RHD	40,41,44,45,48
BO 141598	Bracket-Steering Gear Jacket Tube	40 thru 48 exc 7Sed-Cab-CabPu,10 Del
BO 141599	Bracket-Steering Gear Jacket Tube	40-41-48 Cab-CabPu.43,47,48 7Sed
BO 141608	Shim-F Fender to Cowl Panel	1940 thru 1947 All
BO 141610	Retainer Assy-Door Wing W/Strip-RH	1940 thru 1942 exc Cv-Del,1946-1947 exc CvBro
BO 141611	Retainer Assy-Door Wing W/Strip-LH	1940 thru 1942 exc Cv-Del,1946-1947 exc CvBro
BO 141619	Clamp Assy-F Door Wing	40-41-44 Sed-2Sed-3Cpe-VicCpe,48 Sed,40C,48C 10,11,18,20-21-28 exc Cv,51-171 exc CvBro, 53,58,173,178
141622	Use 144914	
141630	Use 144932	
141631	Use 144933	
141638	Use 144926	
141639	Use 144927	
141640	Use 144928	
141641	Use 144929	
141644	Use 144936	
141648	Use 144906	
141649	Use 144907	
141654	Use 144900	
141655	Use 144901	
141656	Use 144902	
141657	Use 144903	
141660	Use 144938	
141661	Use 144939	
BZ 141664	Splash Apron-Front Fender	1941-1942
BZ 141665	Bracket-Front Fender Splash Apron	1941-1942
141666	Splash Apron Assy-F Fender (Use 203190)	1940-1941 All
BO 141669	Molding-Radiator Louver Panel	43,47
BO 141670	Ornament-Hood Top-Domestic	40,41,44,45,48

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 141671	Ornament-Hood Top-Domestic	43,45,47
C 141672	Ornament-Extension-Hood Top-Rear	43,47,12,14,15,17
BO 141673	Ornament-Extension-Hood Top-Front	43,47
C 141674	Ornament-Hood Side Panel-RH	41 thru 48
C 141675	Ornament-Hood Side Panel-LH	41 thru 48
141676	Use 147424	
C 141677	Ornament Extension-Hood Panel-Top-Rear	40,10-20 exc Del
C 141678	Ornament Extension-Hood Panel-Top-Long Rear	41,44,45,48,11,18,21,28
C 141680	Belt Molding-F Door Outside Panel-RH	40P exc Sed,40 UCo-UCpe,48 Sed
C 141681	Belt Molding-F Door Outside Panel-LH	40P exc Sed,40 UCo-UCpe,48 Sed
C 141682	Belt Molding-F Door Outside Panel-RH	40 Sed,40 Cab-CabPu-Panel
C 141683	Belt Mldg-F Door Outside Panel-LH	40 Sed,40 Cab-CabPu-Panel
C 141684	Belt Mldg-F Door Outside Panel-Upper-RH	41 thru 45 exc Sed,43 47,48P
C 141687	Belt Mldg-F Door Outside Panel-Lower-LH	41 thru 45 exc. Sed,43,47,48P
C 141688	Belt Mldg-F Door Outside Panel-Upper-RH	41-44-45 Sed,48 Cab-CabPu-Panel
C 141689	Belt Mldg-F Door Outside Panel-Upper-LH	41-44-45 Sed,48 Cab-CabPu-Panel
C 141690	Belt Mldg-F Door Outside Panel-Lower-RH	41-44-45 Sed,48 Cab-CabPu-Panel
C 141691	Belt Mldg-F Door Outside Panel-Lower-LH	41-44-45 Sed,48 Cab-CabPu-Panel
C 141692	Belt Mldg-Rear Door Outside Panel	40 Sed
C 141693	Belt Mldg-Rear Door Outside Panel	41 thru 48 Sed
BO 141694	Clip-Belt Molding	40
BO 141696	Belt Molding-Front End Panel-RH	40
BO 141697	Belt Molding-Front End Panel-LH	40
BO 141698	Belt Molding-Front End Panel-Upper-RH	41 thru 48
BO 141699	Belt Molding-Front End Panel-Upper-LH	41 thru 48
BO 141700	Belt Molding-Front End Panel-Lower-RH	41 thru 48
BO 141701	Belt Molding-Front End Panel-Lower-LH	41 thru 48
C 141702	Belt Molding-Quarter Panel	40 2Sed-UCo
C 141703	Belt Molding-Quarter Panel	40 Sed
C 141704	Belt Molding-Quarter Panel-RH	40 3Cpe-VicCpe-UCpe
C 141705	Belt Molding-Quarter Panel-LH.	40 3Cpe-VicCpe-UCpe
C 141709	Belt Molding-Quarter Panel-Lower	41 thru 48 Sed
BO 141710	Belt Molding-Quarter Panel-Upper-RH	41 thru 44 3Cpe-VicCpe
BO 141711	Belt Molding-Quarter Panel-Upper-LH	41 thru 44 3Cpe-VicCpe
BO 141712	Belt Molding-Quarter Panel-Lower-RH	41 thru 44 3Cpe-VicCpe
BO 141714	Belt Molding-Quarter Panel	40 Cv
BO 141715	Belt Molding-Quarter Panel-Upper	41-44 Cv
BO 141716	Belt Molding-Quarter Panel-Lower	41-44 Cv
BO 141717	Clip-Belt & Hood Molding	1940 All
141720	Fender Guard-Front Bumper (Use 147993)	40P,41,44,48P,20P
BZ 141721	Fender Guard-Front Bumper	43,45,47
BO 141730	Lock Assy-Door-Front-RH	1940 All
*BO 141731	Lock Assy-Door-Front-LH	1940 All
BO 141732	Lock Assy-Door-Rear-RH	1940 Sed-CA
BO 141733	Lock Assy-Door-Rear-LH	1940 Sed-CA
BO 141734	Dovetail-Door-Male	1940 thru 1942 exc Cv-Station-Del,1946-1947 exc CvBro
BO 141735	Dovetail-Door-Male	1940 thru 1947 Cv
141736	Use 148344	
141737	Use 148345	
BO 141738	Bumper-Door-Upper	1940 thru 1947 Cv
BO 141739	Tapping Plate-Door Bumper-Upper	1940 thru 1947 Cv
141742	Use 144930	
141743	Use 144931	
BO 141750	Support Assy-Hood-RH	40 thru 48,1941-1942 exc Del,1946-1947 All
BO 141751	Support Assy-Hood-LH	40 thru 48,1941-1942 exc Del,1946-1947 All
BO 141752	Arm-Hood Support-Upper	40 thru 48,1941-1942 exc Del,1946-1947 All
BO 141753	Arm-Hood Support-Lower	40 thru 48,1941-1942 exc Del,1946-1947 All
BO 141754	Bracket-Hood Support-Upper	40 thru 48,1941-1942 exc Del,1946-1947 All
BO 141755	Bracket-Hood Support-Lower	40 thru 48,1941-1942 exc Del,1946-1947 All
BO 141758	Pad-Door Outside Handle Escutcheon	40 thru 44,48 Sed
BO 141759	Ornament-Qtr and Door Trim Panel	40 2Sed,40P Sed-Cpe
BO 141762	Ornament-Tail Lamp-RH	43,45,47
BO 141763	Ornament-Tail Lamp-LH	43,45,47
BO 141764	Ornament-Hood Top-Export	40,41,44,45,48
BZ 141766	Name Plate-Hood Top Panel Ornament-Domestic	43,44,47
BO 141770	Tail Lamp Complete-RH-6 Volt	1940 2Sed-Sed-UCo
BO 141771	Tail Lamp Complete-LH-6 Volt	1940 2Sed-Sed-UCo
BO 141772	Tail Lamp Complete-RH-6 Volt	1940 VicCpe-3Cpe-Cv
BO 141773	Tail Lamp Complete-LH-6 Volt	1940 VicCpe-3Cpe-Cv
BO 141774	Ornament & Lic Lamp-Rear Compt Door	40P-40C-41-43-44-45-47-48 Sed-2Sed-UCo
BO 141775	Ornament & Lic Lamp-Rear Compt Door	1940 3Cpe-VicCpe-Cv
BO 141780	Weatherseal-Ornament & Lic Lamp	1940 Sed-2Sed-UCo
BO 141784	Shim-Windshield Center Bar	1940 thru 1947 All
C 141786	Finish Mldg-W/Shield-Lower	1940 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
141787	Finish Mldg-W/Shield-Lower (Use 141786)	43-47 5Sed
C 141792	Finish Mldg-W/Shield-Upper-RH	1940 exc Cv
C 141793	Finish Mldg-W/ Shield-Upper-LH	1940 exc Cv
C 141794	Finish Mldg-W/Shield-Upper-RH-Painted	43-47 5Sed
C 141795	Finish Mldg-W/Shield-Upper-LH-Painted	43-47 5Sed
BO 141800	Chain Hsg & Conn Arm Assy-W/Shield Cleaner-RH	1940 All
BO 141801	Chain Hsg & Conn Arm Assy-W/Shield Cleaner-LH	1940 All
BO 141803	Bracket-W/S Cleaner Chain Housing Clamp	1940 thru 19.47 All
BO 141804	Gasket-W/S Cleaner Chain Hsg and Hole Cover	1940 thru 1947 All
BO 141805	Control Assy-W/Shield Cleaner	1940 All
BO 141806	Control Assy-W/Shield Cleaner-Black Knob	43-47 5Sed
BO 141809	Spacer-W/Shield Cleaner Control	1940 All
BO 141810	Arm & Spring Assy-W/Shield Cleaner	1940 exc Cv
BO 141815	Kit-W/ Shield Cleaner-LH-RHD	40T,40C,48
*SP 141819	Blade Assy-W/ Shield Cleaner	1930 thru 1947 Cv
141824	Use 142759	
BZ 141825	Knob-Rear Bmpr F Guard Locking Spring	'1940 All
141827	Bar-Front Bumper (Use 206704 & 206222)	40P,41,44,45 Sed-2Sed,48P,10P,11
141829	Bar-Rear Bumper (Use 206961 & 206223)	40P,41,44,45 Sed-2Sed,48P,10P,11
BZ 141832	Fender Guard Assy-Rear Bumper-RH	43,45,47
BZ 141833	Fender Guard Assy-Rear Bumper-LH	43,45,47
BO 141840	Spring-Rear Bumper Guard Locking	1940 All
BO 141841	Shaft & Brkt Assy-Door Wing Glass	40-41-44-45 Sed-2Sed-3Cpe-VicCpe,40C,48,10, 11,18,20-21 exc Cv,28,51-171 exc CvBro,53,78,11 73,178,481-491-500-501 exc CvBro,483,493,503
BO 141842	Frame Assy-Door Wing Glass-RH	40-41-44-45 Sed-2Sed-3Cpe-VicCpe,40C,48,10,11,18, 20-21 exc Cv,28,51-171 exc CvBro,53,58,173,178
BO 141843	Frame Assy-Door Wing Glass-LH	40-41-44-45 Sed-2Sed-3Cpe-VicCpe,40C,48,10,11,18, 20-21 exc Cv,28,51-171 exc CvBro,53,58,173,178
C 141844	Finish Mldg-W-Shield-Upper-RH	1940 CvCpe-CvSed
C 141845	Finish Mldg-W/Shield-Upper-LH	1940 CvCpe-CvSed
BO 141849	Rubber Bumper-Rear Fender Guard Hinge	43,47
*SP 141850	Headlamp Sealed Beam Assy-6 Volt-Domestic	1940 thru 1950 All
141853	Retainer-Headlamp Sealed Beam Assy (Use 206263)	1940 thru 1942 All
BO 141854	Housing Assy-Headlamp	1940 All
BO 141855	Mtg Ring-Headlamp Sealed Beam	1940 thru 1947 All
BO 141856	Mtg Ring-Headlamp Sealed Beam-Export	1940 thru 1946 All
BO 141857	Retaining Spring-Headlamp Sealed Beam Assy	1940 thru 1950 All
BO 141858	Screw-Headlamp Adjusting	1940 thru 1950 All
141859	Nut-Headlamp Adjusting (Use 208524)	1940-1941 All
BO 141863	Connector & Wire Assy-Headlamp	1940 All
141865	Screw-Headlamp Sealed Beam Ret (Use 171396)	1940 thru 1947 All,1948
BO 141866	Socket & Wires Assy-Headlamp-Export	1940 All
BO 141870	Headlamp Complete-6 Volt-Domestic	1940 All
BO 141871	Headlamp Complete-6 Volt-Export	1940 All
BO 141872	Headlamp Complete-12 Volt-Export	1940 All
BO 141875	Reflector-Headlamp-Export	1940 thru 1946 All
BO 141876	Retaining Spring-Headlamp Reflector-Export	1940 thru 1946 All
BO 141877	Gasket-Headlamp Reflector to Lens-Export	1940 thru 1946 All
BO 141878	Lens-Headlamp-Export	1940 thru 1946 All
141882	Use 144912	
C 141893	Drain Trough Assy-Quarter Window-LH	1940 UCo-2Sed
BO 141894	Glass Run & Channel Assy-Frt Door Lock Pillar-RH.	1940-1941-1942 2Sed-UCo-CA,17-18-27 Sed,1946 Bro
BO 141895	Glass Run & Channel Assy-Frt Door Lock Pillar-LH.	1940 2Sed-UCo-CA
BO 141896	Glass Run & Channel Assy-Frt Door Lock Pillar-RH.	40-41-44-45-10-11-12-14-15-20-21-22-24 Sed,1940 Cab-CabPu-Panel,1941-1942 Cab-CabPu,1946 Sed-Cab-CabPu
BO 141897	Glass Run & Channel Assy-Frt Door Lock Pillar-LH	40-41-44-45 Sed,1940 Cab-CabPu-Panel
BO 141898	Glass Run & Channel Assy-Frt Door Lock Pillar-RH	1940-1941-1942,VicCpe-3Cpe-UCpe,1946 3Cpe-ClubCpe
BO 141899	Glass Run & Channel Assy-Frt Door Lock Pillar-LH	40-41-44-45 VicCpe-3Cpe-UCpe
BO 141902	Weatherstrip Retainer & Glass-Frt Door Wing-RH	40-41-44-45 Sed-2Sed-3Cpe-VicCpe,40C,48,10,11,18,10 Sp,51P exc CvBro,53,58,171 exc CvBro,173,178
BO 141903	Weatherstrip Retainer & Glass-Frt Door Wing-LH	40-41-44-45 Sed-2Sed-3Cpe-VicCpe,40C,48,10,11,18,10 Sp,20-21 exc Cv,28,1942 Station,51 P exc CvBro, 53,58, 171 exc CvBro,173,178
BO 141906	Retainer Assy-F Door Wing-RH	43,47,12,14,15,17,22 thru 27,52,172,54-174 exc CvBro
BO 141907	Retainer Assy-F Door Wing-LH	43,47,12,14,15,17,22 thru 27,52,172,54-174 exc CvBro
141912	Door Assy-Front-RH (Use 141936)	40T 2Sed,40UCo,48 Sed
141913	Door Assy-Front-LH (Use 141937)	40T 2Sed,40 UCo,48 Sed
141916	Door Assy-Front-RH (Use 141936)	48 Sed
141917	Door Assy-Front-LH (Use 141937)	48 Sed
141921	Door Assy-Front-LH (Use 141945)	40T Sed,40 Cab-CabPu-Panel
141925	Door Assy-Front-LH (Use 141945)	48 Cab-CabPu-Panel
141932	Door Assy-Front (Use 141956)	1941 3Cpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 141936	Door Assy-Front-RH	40 2Sed,48 Sed,40 UCo
C 141937	Door Assy-Front-LH	40 2Sed,48 Sed,40 UCo
141941	Door Assy-Front-LH (Use 141947)	41-44-45 2Sed,43-47-48 Sed
C 141945	Door Assy-Front-LH	40 Sed-Cab-CabPu-Panel
141949	Door Assy-Front-LH (Use 141945)	4145 Sed,48 Cab-CabPu-Panel
C 141956	Door Assy-Front-RH	41-44 3Cpe-VicCpe
C 141957	Door Assy-Front-LH	41-44 3Cpe-VicCpe
C 141969	Door Assy-Rear-LH	40T-40P Sed
C 141980	Door Assy-Rear-RH	43-47 Sed,48 Sed
C 141993	Glass & Rest Channel Assy-F Door Window-LH	40-41-44-45 Sed
C 142002	Track Assy-F Seat-LHD	1940 2Sed-VicCpe-CvCpe-CvSed
BO 142004	Handle-F Seat Track'Locking	1940 2Sed-VicCpe-CvCpe-CvSed,1940 UCpe,40T 3Cpe
142005	Knob-Front Seat Track Locking Handle (Use 209665)	1940-1941 VicCpe-CvCpe-CvSed-2Sed-UCpe,40T-10 thru 15 3Cpe,1946 Bro-ClubCpe-CvBro
BO 142009	Handle-Door Inside	1940 2Sed-Cpes-CvSed-Cab-CabPu-Panel
142010	Handle-Door Inside (Use 142009)	43-47 Sed
BO 142011	Handle Assy-Quarter Window Regulator	41-43-44-45-47 Sed
BO 142011	Handle Assy-Door Wing Regulator	43,44 CvCpe-CvSed
BO 142012	Handle Assy-Quarter Window Regulator	1940 2Sed-UCo
BO 142012	Handle Assy-Door Window Regulator	40T,40P,40C-UCo-UCpe,41,44,45
BO 142013	Escutcheon-Door & Window Reg & Handle.	40T,40P,40C-UCo-UCpe,41,44,45,1940 Cab-CabPu-Panel,1941 All,482,484,492,494,502,504
BO 142014	Escutcheon-Door Window Regulator	43-47 Sed
BO 142015	Handle-Rear Compt Door	1940 Sed-2Sed-UCo
142016	Handle Assy-Door Window Regulator (Use 142012)	43-47 Sed
BO 142017	Handle Assy-Quarter Window & Door Wing Reg	43-47 Sed
F 142020	Handle Assy-F Door Outside	40,41,44,48
F 142021	Handle Assy-Rear Door Outside	40-41-44-48P
F 142022	Handle Assy-Rear Door Outside	43-47 Sed,45
F 142023	Handle Assy-Front Door Outside	43-47 Sed,95
BO 142026	Safety Plate-Door Lock Pillar-RH	1940 All
BO 142027	Safety Plate-Door Lock Pillar-LH	1940 All
C 142030	Finish Mldg-W/Shield Reveal-RH	1940-1941 exc Cv,19 Sp,1946-1947 exc CvBro Cab-CabPu
C 142031	Finish Mldg-W/Shield Reveal-LH	1940-1941 exc Cv, 10 Sp,1946-1947 exc CvBro Cab-CabPu
C 142036	Use 141216	
BO 142040	Weatherstrip-Windshield-RH	40T,40C,48,10T,10C,18,20T,20C,28,58,178
BO 142041	Weatherstrip-Windshield-LH	40T,40C,48,10T,10C,18,20T,20C,28,58,178
BO 142042	Weatherstrip-Windshield-RH	40P-41 thru 47-10P-11 thru 17 exc Cv,10 Sp,20P-21 thru 27 exc Cv,1946-1947 exc Cab-CabPu
BO 142043	Weatherstrip-Windshield-LH	40P-41 thru 47-10P-11 thru 17 exc Cv,10,SP,20P-21 thru 27 exc Cv,1946-1947 exc Cab-CabPu
C 142048	Finish Mldg-Windshield Reveal-RH	1940 CvCpe-CvSed,1941-1942 CvSed,1946-1947 CvBro
C 142049	Finish Mldg-Windshield Reveal-LH	1940 CvCpe-CvSed,1941-1942 CvSed,1946-1947 CvBro
142050	Use 1-147850,2-147852,2-170523	
BO 142051	Ornament-Cowl Ventilator Cover	43,47
142052	Knob-Door Lock Release Rod (Use 209661)	1940 All
BO 142053	Screen-Inst Panel Grille	1940 All
*BZ 142055	Brkt Assy-F License Plate	1940 All,11 Station
BO 142072	Gasket-Headlamp Housing to Fender (Pkg 1-5)	1940 thru 1949 All
142073	Bracket-Rear View Mirror (Use 204177)	1940 thru 1942 exc Cv
BO 142074	Name Plate-Hood Side Panel	43,47
BO 142078	Escutcheon-F Seat Side Panel Handle	1940 thru 1942 All exc Cab-CabPu-Panel, 1946-1947 All exc Cab-CabPu
BO 142080	Ash Receiver Assy-Arm Rest-RH	41-44-45 Sed-2Sed,43-47 Sed
BO 142981	Ash Receiver Assy-Arm Rest-RH	41-44-45 Sed,2Sed,43-47 Sed
BO 142082	Tray & Knob Assy-Arm Rest Ash Receiver-RH	41 thru 47 Sed-2Sed
BO 142083	Tray & Knob Assy-Arm Rest Ash Receiver-LH	41 Sed-2Sed,44-45 2Sed,43 thru 47 Sed
BO 142084	Knob-Arm Rest Ash Receiver	41 Sed-2Sed,44-45 2Sed,43 thru 47 Sed
BO 142087	Cover Plate-Arm Rest Ash Receiver	40P-41-44-45 Sed-2Sed,40 UCo
BO 142088	Gasket-Arm Rest Ash Receiver Plate	40P-41-44-45 Sed-2Sed,40 UCo
BO 142091	Knob-Inst Panel Ash Receiver	40P-41-44-45 Sed-2Sed,40 UCo
BO 142093	Joint Cover-W/Shield Finish Mldg-Upper	40-48-10-18 Cab-CabPu-Panel,1942-1946-1947 Cab-CabPu
BO 142101	Ash Receiver-Inst Panel Center	1940 All
BO 142102	Ash Tray Assy-Inst Panel Center	1940 All
BO 142105	Ash Receiver Assy-Inst Panel	1940 All
142106	Ash Tray & Cover Assy-Inst Panel (Use 142105)	1940 All
BO 142107	Cover Plate-Inst Panel Ash Receiver	1940 All
BO 142113	Housing-Hood Side Lamp	41,43,44,45,47,48
BO 142114	Lens-Hood Side Lamp-RH	41,43,44,45,47,48
BO 142115	Lens-Hood Side Lamp-LH	41,43,44,45,47,48
BO 142116	Gasket-Hood Side Lamp Lens	41,43,44,45,47,48

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 142117	Gasket-Hood Side Lamp Lens	40
BO 142118	Lens-Hood Side Lamp-RH	40
BO 142119	Lens-Hood Side Lamp-LH	40
BO 142120	Housing-Hood Side Lamp	40
BO 142121	Knob-Inst Panel Ash Receiver-Black	43,47
BO 142128	Light Baffle-Fuel & Water Temp Cluster	1940 All
142130	Mat & Pad Assy-Front Floor-LHD (Use 201134)	43,45,47
142134	Mat & Pad Assy-Front Floor-LHD (Use 201134)	41,44,40P Sed
F 142136	Gauge Assy-Fuel-Inst Panel Unit-2nd type	1940 All
F 142137	Gauge Assy-Gasoline-Inst Panel Unit-2nd type	1940 All
BO 142138	Cover-F Floor Mat Steering Hole	41 thru 47,40P Sed
142144	Element & Knob Assy-Cigar Lighter (Use 144774)	43,47
*HA 142146	Heating Element-Cigar Lighter-6 Volt	1940 thru 1950 All
BO 142127	Heating Element-Cigar Lighter-12 Volt	1940 thru 1947 All
BO 142152	Insulator-Cigar Lighter Terminal	1940 thru 1942 All
BO 142154	Weatherstrip-F Door Window Belt-Inner-RH	1940-1941-1942 CvSed,1946-1947 CvBro
BO 142155	Weatherstrip-F Door Window Belt-Inner-LH	1940-1941-1942 CvSed,1946-1947 CvBro
BO 142156	Weatherstrip-Quarter Window Belt-Inner-RH	1940 2Sed-UCo
BO 142157	Weatherstrip-Quarter Window Belt-Inner-LH	1940 2Sed-UCo
C 142188	Glass and Rest Channel Assy-Qtr-Wdo-RH-Crystal	45 2Sed
C 142189	Glass and Rest Channel Assy-Qtr-Wdo-LH-Crystal	45 2Sed
BO 142197	Extension & Name Plate Assy-Hood Top	43-47 Domestic
BO 142198	Extension & Name Plate Assy-Hood Top	43-47 Export
142200	Glove Box Assy-LHD (Use 142248 & 142364)	1940 All
BO 142201	Glove Box Assy-RHD	1940 All
BO 142202	Stop Rod-F Seat Track Adjusting	1940-1941-1942 2Sed-VicCpe-CvCpe-CvSed,1941-1942 3Cpe,1946-1947 Bro-ClubCpe-CvBro
BO 142203	Spacer-F Seat Assy-Front	1940-1941-1942 2Sed-VicCpeCvCpe-CvSed,1941-3Cpe,1942 UCo-2Sed,1946-1947 Bro
BO 142214	Bumper-Door	1940-1941-1942 exc CvSed,1946-1947 exc CvBro
BO 142217	Bumper-Glove Box Door-Outer	1940 thru 1947 All
142218	Bumper-Glove Box Door-Inner (Use 212547)	1940 thru 1947 All
BO 142234	Number Plate-Hood Side Panel	47,14,15,17,24,25,27
BO 142235	Name Plate-Hood Side Panel	44,45
BO 142238	Door Lock-F Seat Compartment	43-47 5Sed
BO 142239	Lock,Cyl & Key Assy-F Seat Compt Door	43-47 5Sed
BO 142243	Pad-Tail Lamp	40-41-44-45 Sed-2Sed,43-47-48 Sed,40 UCo
BO 142245	Block Assy-Front Door Arm Rest	40P,41,44
BO 142246	Pad-Front Door Arm Rest Cover	40P,41,44
BO 142248	Locker Box-Cardboard	1940 exc Del
BO 142250	W/Strip-Front Door Wing-RH	40P-41-44-45-10-11-18-20-21-29 exc Cv,10 Sp,51-171 exc CyBro,53,58,173,178
BO 142251	W/Strip-Front Door Wing-LH	40P-41-44-45-10-11-18-20-21-28 exc Cv,10 Sp,51-171 exc CyBro,53,58,173,178
BO 142252	W/Strip-Front Door Wing-RH	43,47,15,17,12-14-22 thru 27 exc Cv,52,172,54-174 exc CvBro
BO 142253	W/Strip-Front Door Wing-LH	43,47,15,17,12-14-22 thru 27 exc Cv,52,172,54-174 exc CvBro
BO 142254	Weatherstrip-Windshield-RH	1940 CvCpe-CvSed,1941-1942 CvSed,1946-1947 CvBro
BO 142255	Weatherstrip-Windshield-LH	1940 CvCpe-CvSed,1941-1942 CvSed,1946-1947 CvBro
C 142258	Glass-Windshield	1940 thru 1947 CvBro
C 142270	Mldg-F Seat Back Top	43-47 5Sed
BZ 142272	Flexible Shaft Assy-Speedometer-LHD	1940 All
BZ 142274	Flexible Shaft Assy-Speedometer-RHD	1940 All
BZ 142276	Flexible Shaft Assy-Speedometer-RHD	1940 All
BO 142277	Choke Wire Assy-Carburetor-For X Engine-LHD	40,41,10,11,12
142280	Fender-Rear-RH-Use With R/Board (Use 140030)	40T Sed-2Sed,40 UCo
A 142282	Fender-Rear-RH-Use less R/Board	40T Scd-2Sed
142283	Fender-Rear-LH-Use less R/Board (Use 140033)	40T Sed-2Sed
BO 142289	Bumper-Cowl Panel to Hood	1940-1941-1942-1946-1947 All
BO 142296	Joint Cover-Rear Wdo-Reveal Finish Mldg	40P-41-44-45 Sed-2Sed,43-47 Sed
BO 142311	Bracket-F Door Pull to Handle	43,47,15,17
BO 142312	Handle-F Door Pull to	93,47,15,17,25,27
BO 142336	Lock-F Seat Compt-Less Cyl-Black	43-47 5Sed
C 142341	Spring-F Seat Back	40-41-44-45-48 5Sed,40P-41-44 3Cpe,10-11-12-14 3Cpe-SSed
BO 142364	Spacer-Locker Box to Cowl Panel	41 thru 48
BO 142386	Name Plate Kit-Hood Side	44
142387	Name Plate Kit-Hood Side (Use 142234)	47
BO 142388	Lens-Odometer-In Locker Box Door	1940 thru 1947 All
BO 142390	Mldg Extension-Hood Side-Lower	40
BO 142391	Mldg Extension-Hood Side	41 thru 48
C 142392	Mldg-Hood Side-Long-Lower	40
C 142393	Mldg-Hood Side	41 thru 48

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 142394	Clip-Quarter Panel Belt Mldg	40 UCo-2Sed, 40T Sed
BO 142396	Rubber Protector-Rear Fender Guard Cross Bar	
*SP 142398	Blade Assy-Windshield Cleaner	1940 thru 1942 exc Cv, 1946-1947 exc CvBro
C 142420	Panel Assy-Quarter-RH-Prime	40T-40P-41-44-45 Sed, 43-47-48 5Sed
C 142422	Panel Assy-Quarter-RH-Prime	43-47-48 7Sed
C 142423	Panel Assy-Quarter-LH-Prime	43-47-48 7Sed
C 142452	Panel Assy-Quarter-RH	40-41-44 VicCpe
BO 142554	Hinge-F Door Upper RH-Door Half	1940 All
BO 142555	Hinge-F Door Upper LH-Door Half	1940 All
BO 142556	Hinge-F Door-Upper RH-Body Half	1940 All
BO 142557	Hinge-F Door-Upper LH-Body Half	1940 All
BO 142558	Hinge-F Door-Lower RH-Door Half	1940 All
BO 142559	Hinge-F Door-Lower-LB-Door Half	1940 All
BO 142560	Hinge-F Door-Lower-RH-Body Half	1940 All
BO 142561	Hinge-F Door-Lower LH-Body Half	1940 All
142580	Floor Mat-Rear Compartment (Use 136308)	45 Sed-2Sed, 43-47 5Sed
C 142582	Welt-Rear Fender	1940 Sed-2Sed-UCo
BO 142584	Housing Assy-Tail Lamp-RH	1940 Sed-2Sed-UCo
BO 142585	Housing Assy-Tail Lamp-LH	1940 Sed-2Sed-UCo
BO 142586	Lens-Tail Lamp-RH	1940 Sed-2Sed-UCo
BO 142587	Lens-Tail Lamp-LH	1940 Sed-2Sed-UCo
BO 142588	Bezel-Tail Lamp Lens-RH	1940 Sed-2Sed-UCo
BO 142589	Bezel-Tail Lamp Lens-LH	1940 Sed-2Sed-UCo
BO 142590	Housing Assy-Tail Lamp	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142591	Housing Assy-Tail Lamp	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142592	Lens-Tail Lamp-RH	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142593	Lens-Tail Lamp-LH	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142594	Bezel-Tail Lamp Lens-RH	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142595	Bezel-Tail Lamp Lens-LH	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142596	Gasket-Tail Lamp Lens-RH	1940 Sed-2Sed-3Cpe-VicCpe-Cv-UCo
BO 142597	Gasket-Tail Lamp Lens-LH	1940 Sed-2Sed-3Cpe-VicCpe-Cv-UCo
142598	Housing-Rear License Lamp (Use 141774)	1940 Sed-2Sed-UCo
BO 142599	Base Plate-Rear License Lamp	1940 Sed-2Sed-UCo
BO 142600	Lens-Rear License Lamp	1940 Sed-2Sed-UCo
BO 142601	Gasket-Rear License Lamp Lens	1940 Sed-2Sed-UCo
BO 142602	Retaining Spring-Rear License Lamp Lens	1940 Sed-2Sed-UCo
BO 142603	Deck Door-License Lamp	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142604	Base Plate-Deck Door License Lamp	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142605	Lens-Deck Door License Lamp	1940 3Cpc-VicCpe-CvCpe-CvSed
BO 142606	Gasket-Deck Door License Lamp	1940 3Cpe-VicCpe-CvCpe-CvSed
BO 142607	Clip-Deck Door License Lamp	1940 3Cpe-VicCpe-CvCpe-CvSed
C 142630	Strap & Wheel Retainer Assy-Spare Tire Carrier	1940 thru 1947 CabPu, 1941 Del
BZ 142631	Tie Rod-Frame to Spare Tire Carrier Strap	1940 thru 1947 CabPu, 1941 Del
C 142632	Spacer Block-Frame to Tire-For Carrier	1940 thru 1947 CabPu, 1941 Del
BZ 142640	Fender Guard Assy-Rear Bumper-RH	40, 41, 44, 45, 48
BZ 142641	Fender Guard Assy-Rear Bumper-LH	40, 41, 44, 45, 48
142644	Use 142759	
BO 142679	Glass Run Channel & Plate Assy-F Door Lock Pillar-LH	1940 thru 1946 exc Cv, 178
BO 142683	Glass Run & Channel Assy-F Door Lock Pillar-LH	1946 Bro
BO 142685	Glass Run & Channel Assy-F Door Lock Pillar-LH	1946 Sed Cab-CabPu
BO 142687	Glass Run & Channel Assy-F Door Lock Pillar-LH	1946 3Cpe-Club Cpe
BO 142688	Glass Run Channel Assy-Rear Door Lock Pillar-RH	1940 thru 1942 Sed-CA, 1946-1947 Sed
BO 142689	Glass Run Channel Assy-Rear Door Lock Pillar-LH	1940 thru 1942 Sed-CA, 1946-1947 Sed
BO 142694	Cradle Complete-Door Wing-Domestic	1940 CvCpe-CvSed
BO 142699	Front Corner Bracket-Folding Top-LH	1940 CvCpe
BO 142710	Link #4-Folding Top-RH	1940 CvCpe
BO 142711	Link #4-Folding Top-LH	1940 CvCpe
BO 142713	Extension-Top Rear Bow-LH	1940 CvCpe
BO 142714	Link-Top Rear Bow Hinge	1940 CvCpe
BO 142715	Slat Iron-Folding Top Pillar	1940 CvCpe
BO 142719	Bolt-Rear Bow Extension to Auxiliary Bow	1940 CvCpe
BO 142721	Pivot Bolt-Top Link #1 to #2 and #3 and #4	1940 CvCpe
BO 142723	Spring Washer-Top Link #1 to #2 and #3 Pivot Bolt	1940 CvCpe
BO 142724	Pivot Bolt-Top Link #2 and #3 to Pillar Slat Iron	1940 CvCpe
BO 142725	Spring Washer-Top Pivot Bolts	1940 CvCpe
BZ 142759	Clamp-Front & Rear Bumper Fender Guard Cross Bar	1940 All
*C 142788	Tail Gate Assy-Pickup Box	1940 thru 1947 CabPu
BO 142790	Lock Brkt-Pickup Box Tail Gate-RH-Tail Gate Half	1940 thru 1947 CabPu
BO 142791	Lock Brkt-Pickup Box Tail Gate-LH-Tail Gate Half	1940 thru 1947 CabPu
BO 142792	Lock Brkt-Pickup Box Tail Gate-RH-Body Half	1940 thru 1947 CabPu
BO 142793	Lock Brkt-Pickup Box Tail Gate-LH-Body Half	1940 thru 1947 CabPu
BO 142794	Chain & Cover Assy-Pickup Box Tail Gate-RH	1940 thru 1947 CabPu
BO 142795	Chain & Cover Assy-Pickup Box Tail Gate-LH	1940 thru 1947 CabPu
BO 142796	Bushing-Tail Gate Hinge	1940 thru 1947 CabPu

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 142797	Bracket-Pickup Box Tail Gate Hinge	1940 thru 1947 CabPu
C 142798	Skid Strip-Pickup Box	40 CabPu
C 142801	Pickup Box Assy	48 CabPu
BO 142804	Stake Pocket-Pickup Box-Front	40-48 CabPu,1946-1947 CabPu
BO 142806	Stake Pocket-Pickup Box-Rear-RH	40-48 CabPu,1946-1947 CabPu
BO 142807	Stake Pocket-Pickup Box-Rear-LH	40-48 CabPu,1946-1947 CabPu
142841	Bolt-Bumper Fender Guard (Use 136312)	40T,40C,48C
BZ 142850	Fender Guard Assy-Front Bumper-RH	43,45,47
BZ 142851	Fender Guard Assy-Front Bumper-LH	43,45,47
BZ 142860	Fender Guard Assy-Front Bumper-RH	40P,41,44,45,48P
BZ 142861	Fender Guard Assy-Front Bumper-LB	40P,41,44,45,48P
C 142871	Cross Bar-Front Bumper Fender Guard	1940 All
BO 142880	Spring Rod-Rear Compartment Latch	1940 Sed-2Sed-UCo
BO 142881	Base Assy-Rear Compartment Latch	1940 Sed-2Sed-UCo
BO 142883	Plunger-Rear Compt Door Lock Operating Link	1940 Sed-2Sed-UCo-Cpe-Cv
BZ 142885	Clamp Bolt-F Bumper Guard Extension	1940 All
BO 142890	Cluster Assy-Fuel and Temperature	1940 All
BO 142895	Protector-Underbody Seat Reinforcement	48 Carryall
BO 142905	Mtg Brkt-Rear Compt Center Floor Board	48-18 Carryall
BZ 142940	Bracket-Rear Compt Spare Tire Clamp	48-18 Carryall
A 142999	Fender-Rear-LH	40-48 Panel
BO 143051	Binding-Wire on-Brown	
BO 143055	Binding-Wire on-Taupe Leather	
BO 143059	Binding-Wire on-Mohair Trim	10,10 Sp
BO 143061	Binding-Wire on-Green	11-12-14 Sed-2Sed-ClubCpe,12-14 3Cpe
BO 143065	Binding-Wire on-Light Tan	10P CvSed,10T,18P
BO 143069	Binding-Wire on-Maroon	10P,11 thru 17,1946-1947 CvBro
BO 143071	Binding-5/8" Wire on-Gunpowder	
BO 143072	Binding-5/8" Wire on-Sage Green	
143102	Seat Cloth-Boucle (Use 143103)	
M 143103	Sidewall Cloth-Boucle	
M 143117	Seat Cloth-Gray Wool Twist	
143118	Use 143117	
143121	Headlining Cloth-Light Brown (Use 149106)	
BO 143140	Robe Hanger Assy-Cloth Trim	40 P Sed
BO 143142	Robe Hanger Assy-Mohair-Taupe or Brown Leather	41-44-45 Sed
BO 143160	Robe Hanger Assy-Tan Leather	40P-41-44-45 Sedan
M 143181	Sidewall Cloth-Brown Wool	
M 143182	Seat & Sidewall Cloth-Taupe Mohair	
M 143184	Osnaburg Material	
M 143185	Seat Cloth-Green Gray	
M 143197	Seat and Sidewall Cloth	
C 143202	Door Complete-Front-RH	40P 2Sed
C 143203	Door Complete-Front-LH	40P 2Sed
C 143206	Door Complete-Front-RH	40P Sed
C 143207	Door Complete-Front-LH	40P Sed
C 143210	Door Complete-Front-RH	40P 3Cpe-VicCpe
C 143211	Door Complete-Front-LH	40P 3Cpe-VicCpe
C 143214	Door Complete-Rear-RH	40P Sod
C 143215	Door Complete-Rear-LH	40P Sed
C 143216	Trimboard Complete-F Door-RH	40T Co-Cpe,40 UCo-UCpe
C 143217	Trimboard Complete-F Door-LH	40T Co-Cpe,40 UCo-UCpe
C 143220	Trimboard Complete-F Door-RH	40T Sed
C 143221	Trimboard Complete-F Door-LH	40T Sed
C 143224	Trimboard Complete-Rear Door-RH	40T Sed
C 143225	Trimboard Complete-Rear Door-LH	40T Sed
C 143228	Headlining Assy	1940 2Sed-UCo
C 143229	Headlining Assy	40-41-44 Sed
C 143230	Headlining Assy	40P-44 Sed
C 143231	Headlining Assy	43-47 Sed
C 143232	Headlining Assy	48P Sed
C 143233	Headlining Assy	1940 3Cpe-UCpe
C 143234	Headlining Assy	1940 VicCpe
C 143239	Carpet-Rear Compartment Floor	1940 UCo
C 143246	Trimboard Complete-F Door-RH	40P Sed
C 143247	Trimboard Complete-F Door-LH	40P Sed
C 143252	Trimboard Complete-F Door-RH	40P 2Sed-3Cpe-VicCpe,48P Sed
C 143253	Trimboard Complete-F Door-LH	40P 2Sed-3Cpe-VicCpe,48P Sed
C 143254	Trimboard Complete-Rear Door-RH	40P-48P Sed
C 143255	Trimboard Complete-Rear Door-LH	40P-48P Sed
C 143262	Trimboard Complete-F Door-RH	41-44 Sed
C 143263	Trimboard Complete-F Door-LH	41-44 Sed
C 143264	Trimboard Complete-Rear Door-RH	41-44 Sed,43-47 Sed
C 143265	Trimboard Complete-Rear Door-LH	41-44 Sed,43-47 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 143268	Trimboard Complete-F Door-RH	41-44 2Sed-3Cpe-VicCpe
C 143269	Trimboard Complete-F Door-LH	41-44 2Sed-3Cpe-VicCpe
C 143274	Trimboard Complete-F Door-RH-Two Color	43-47 Sed
C 143275	Trimboard Complete-F Door-LH-Two Color	43-47 Sed
C 143276	Trimboard Complete-F Door-RH-Mohair	43-47 Sed
C 143277	Trimboard Complete-F Door-LH-Mohair	43-47 Sed
C 143282	Trimboard Complete-Rear Door-RH-Two Color	43-47 Sed
C 143283	Trimboard Complete-Rear Door-LH-Two Color	43-47 Sed
C 143288	Trimboard & Trim Assy-Rear Seat Back Shelf	40 thru 48 5Sed
C 143304	Trimboard & Carpet Assy-F Seat Foot Rest End-RH	40-41-44-45-10-11-12-14 Sed
C 143305	Trimboard & Carpet Assy-F Seat Foot Rest End-LH	40-41-44-45-10-11-12-14 Sed
BO 143312	Carpet Assy-Rear Floor	48 5Sed
C 143313	Carpet Assy-Rear Floor	40-41-44-45 Sed
C 143314	Carpet Assy-Rear Floor	43-47-48 5Sed
C 143315	Carpet Assy-Rear Floor-LHD	1940 2Sed
C 143316	Carpet Assy-Rear Floor-RHD	1940 2Sed
C 143317	Carpet Assy-Rear Floor	43-47 7Sed
C 143318	Carpet Assy-Rear Floor	48 7Sed
C 143319	Carpet Assy-Rear Floor	1940 3Cpe-UCpe
C 143321	Carpet Assy-Rear Floor-LHD	1940 VicCpe
C 143322	Carpet Assy-Rear Floor-RHD	1940 VicCpe
C 143325	Carpet Assy-Rear Floor	1940 CvCpe
C 143327	Carpet Assy-Rear Floor-LHD	1940 CvSed
C 143328	Carpet Assy-Rear Floor-RHD	1940 CvSed
C 143330	Carpet Assy-F Seat Side Floor-RH	43-47-48-18 7Sed
C 143331	Carpet Assy-F Seat Side Floor-LH	43-47-48-18 7Sed
BO 143342	Windlace Assy-RH-Rear Pillar	1946-1947 Bro
BO 143343	Windlace Assy-LH-Rear Pillar	1946-1947 Bro
BO 143344	Windlace Assy-Rear Pillar-RH	1940 thru 1942 3Cpe-VicCpe-UCpe,1946-1947 3Cpe
BO 143345	Windlace Assy-Rear Pillar-LH	1940 thru 1942 3Cpe-VicCpe-UCpe,1946-1947 3Cpe
BO 143349	Spring-Front Seat Back Pocket	41-44-45-15-17-20P-21-22-24 Sed,1946-1947 Sed,1948 thru 1950 Sed-CvBro,501 thru 504 Bro-Club Cpe
BO 143352	Arm Rest Assy-RH	40T 2Sed,40 UCo
BO 143353	Arm Rest Assy-LH	40T 2Sed,40 UCo
BO 143360	Arm Rest Assy-RH	40P 2Sed
BO 143361	Arm Rest Assy-LH	40P 2Sed
BO 143364	Arm Rest Assy-RH	40P Sed
BO 143365	Arm Rest Assy-LH	40P Sed
BO 143368	Arm Rest Assy-RH	41-44 2Sed
BO 143369	Arm Rest Assy-LH	41-44 2Sed
BO 143372	Arm Rest Assy-RH	41-44 Sed
BO 143373	Arm Rest Assy-LH	41-44 Sed
BO 143376	Arm Rest Assy-RH	43-47 5Sed
BO 143377	Arm Rest Assy-LH	43-47 5Sed
C 143381	Airfoam Pad-F Seat Cushion-Cloth Trim	41-44-45-10-11-18 Sed-3Cpe,43-47 5Sed
C 143382	Airfoam Pad-F Seat Cushion-Cloth Trim	40T 2Sed-3Cpe,40P 2Sed-VicCpe,40T VicCpe,40 UCpe
C 143383	Airfoam Pad-F Seat Cushion-Cloth Trim	41-44 VicCpe,10-11 ClubCpe,45-10-11 2Sed,10 UCpe
C 143385	Airfoam-Pad-Rear Seat Cushion	41-44-45-10-11-18 Sed-2Sed,43-47 5Sed,18 7Sed
C 143389	Back Complete-F Seat-LHD-Cloth	40T Sed
C 143390	Back Complete-F Seat-RHD-Cloth	40T Sed
C 143391	Trim Assy-F Seat Back-Cloth	40T Sed
C 143392	Cushion Complete-F Seat-Cloth	40T Sed
C 143393	Trim Assy-F Seat Cushion-Cloth	40T Sed
C 143395	Back Complete-F Seat-LHD-Cloth	48 5Sed
C 143397	Back Complete-F Seat-Cloth	40P Sed
C 143398	Back Complete-F Seat-RHD-Cloth	40P Sed
C 143399	Back Complete-F Seat-LHD-Cloth	40P 3Cpe
C 143400	Back Complete-F Seat-RHD-Cloth	40P 3Cpe
C 143401	Trim Assy-F Seat Back-Cloth	40P Sed-3Cpe
C 143402	Cushion Complete-F Seat-Cloth	40P Sed-3Cpe
C 143403	Trim Assy-F Seat Cushion-Cloth	40P Sed-3Cpe
C 143405	Back Complete-F Seat-LHD-Cloth	41-44-45 Sed
C 143406	Back Complete-F Seat-RHD-Cloth	41-44-45 Sed
C 143407	Back Complete-F Seat-LHD-Cloth	41-44 3Cpe
C 143408	Back Complete-F Seat-RHD-Cloth	41-44 3Cpe
C 143409	Trimboard & Pocket Assy-F Seat-Back-Cloth	40P-44-45 Sed
C 143410	Trim Assy-F Scat Back-Cloth	41-44 3Cpe,45 Sed
C 143411	Cushion Complete-F Seat-Cloth	41-44-45 Sed
C 143412	Trim Assy-F Seat Cushion-Cloth	41-44 3Cpe,45 Sed
C 143413	Back Complete-F Seat-LHD-Cloth	43-47 5Sed
C 143414	Back Complete-F Seat-RHD-Cloth	43-47 5Sed
C 143415	Trim Assy-F Seat Back-Cloth	43-47 5Sed
C 143416	Cushion Complete-F Seat-Cloth	43-47 5Sed
C 143417	Trim Assy-F Seat Cushion-Cloth	43-47 5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 143419	Board & Trim Assy-F Seat Back-Cloth	43-47 5Sed
C 143420	Lid & Trim Assy-F Seat Back Compt-Cloth	43-47 5Sed
C 143423	Back Complete-F Seat-Drivers-LHD	40T 2Sed-VicCpe
C 143424	Back Complete-F Seat-Drivers-RHD	40T 2Sed-VicCpe
C 143425	Back Complete-F Seat-Pass-LHD	40T 2Sed-VicCpe
C 143426	Back Complete-F Seat-Pass-RHD	40T 2Sed-VicCpe
C 143429	Trim Assy Seat Riser-Cloth	40T 2Sed-3Cpe-VicCpe
C 143430	Back Complete-F Seat-RH-Cloth	40T 3Cpe,40 UCpe
C 143431	Back Complete-F Seat-LH-Cloth	40T 3Cpe,40 UCpe
C 143432	Trim Assy-F Seat Back Panel-RH-Cloth	40T 3Cpe
C 143433	Trim Assy-F Seat Back Panel-LH-Cloth	40T 3Cpe
C 143434	Trim Assy-F Seat Back-RH-Cloth	40T 2Sed-3Cpe
C 143435	Trim Assy-F Seat Back-LH-Cloth	40T 2Sed-3Cpe
C 143436	Cushion Complete-F Seat-Cloth	40T 2Sed-3Cpe-VicCpe,40UCpe
C 143437	Trim Assy-F Seat Cushion-Cloth	40T 2Sed-3Cpe-VicCpe,40UCpe
C 143438	Trim Assy-F Seat Riser-Cloth	40P-41-44 2Sed-VicCpe,45 2Sed
C 143441	Back Complete-F Seat-Drivers-LHD-Cloth	40P 2Sed-VicCpe
C 143442	Back Complete-F Seat-Drivers-RHD-Cloth	40P 2Sed-VicCpe
C 143443	Back Complete-F Seat-Pass-LHD-Cloth	40P 2Sed-VicCpe
C 143444	Back Complete-F Seat-Pass-RHD-Cloth	40P 2Sed-VicCpe
C 143445	Cushion Complete-F Seat-Cloth	40P 2Sed-VicCpe
C 143446	Trim Assy Seat Back-RH-Cloth	40P 2Sed-VicCpe
C 143447	Trim Assy Seat Back-LH-Cloth	40P 2Sed-VicCpe
C 143448	Trim Assy Seat Cushion-Cloth	40P 2Sed-VicCpe
C 143451	Back Complete-F Seat-Drivers-LHD	41-44 2Sed-VicCpe,45 2 Sed
C 143452	Back Complete-F Seat-Drivers-RHD	41-44 2Sed-VicCpe,45 2Sed
C 143453	Back Complete-F Seat-Pass-LHD	41-44 2Sed-VicCpe,45 2Sed
C 143454	.Back Complete-F Seat-Pass-RHD	41-44 2Sed-VicCpe,45 2Sed
C 143455	Cushion Complete-F Seat-Cloth	41-44 2Sed-VicCpe,45 2Sed
C 143456	Trim Assy-F Seat Back-RH-Cloth	41-44 2Sed-VicCpe,45 2Sed
C 143457	Trim Assy-F Seat Back-LH-Cloth	41-44 2Sed-VicCpe,45 2Sed
C 143458	Trim Assy-F Seat Cushion-Cloth	41-44 2Sed-VicCpe,45 2Sed
BO 143476	Windlace Assy-Center Pillar	51 thru 54 Sed,171 thru 174 Sed
BO 143477	Screw-Assist Strap Bracket	1940 thru 1942 Sed-2Sed-ClubCpe,1946-1947 Bro-Sed-ClubCpe
BO 143478	Bracket-Assist Strap	1940 thru 1942 Sed-2Sed-ClubCpe,1946-1947 Bro-Sed-ClubCpe
BO 143481	Assist Strap Assy-Taupe Leather Or Brown Wool	40P-41-44-45 Sed-2Sed,43-47 Sed
BO 143482	Assist Strap Assy	41-44-45 Sed-2Sed
BO 143483	Assist Strap Assy-Maroon Leather	1940 thru 1942 Sed-2Sed,1941-1942 ClubCpe
BO 143485	Assist Strap Assy-Mohair Trim	40P-41-44 Sed-2Sed,43-47 Sed
C 143505	Trim Assy-Front Seat Back	43-47 5Sed
BO 143520	Visor Assy-RH	
C 143551	Silencer-Cowl Panel	1940 thru 1947 All
C 143569	Trim Panel-Cowl-LH	1940 All
C 143574	Back Complete-Rear Seat-Cloth	40T Sed-2Sed
C 143575	Trim Assy-Rear Seat Back-Cloth	40T Sed-2Sed,40 UCo
C 143576	Cushion Complete-Rear Seat-Cloth	40T Sed-2Sed
C 143577	Trim Assy-Rear Seat Cushion-Cloth	40T Sed-2Sed
C 143578	Retainer & Trim Assy-Rear Seat Cushion-Cloth	40T Sed-2Sed
C 143579	Back Complete-Roar Seat-Cloth	40P Sed-2Sed
C 143580	Trim Assy-Rear Seat Back-Cloth	40P Sed-2Sed
C 143581	Cushion Complete-Rear Seat-Cloth	401, Sed-2Sed
C 143582	Trim Assy-Rear Seat Cushion-Cloth	40P Sed-2Sed
C 143583	Cushion Retainer & Trim Assy-Rear Seat-Cloth	40P-41-44-45 Sed-2Sed,43-47 5Sed
C 143584	Back Complete-Rear Seat-Cloth	41-44-45 Sed-2Sed
C 143585	Trim Assy-Rear Seat Back-Cloth	41 -44-Sed-2Sed
C 143586	Cushion Complete-Rear Seat-Cloth	41-44-45 Sed-2Sed
C 143587	Trim Assy-Rear Seat Cushion-Cloth	41-44 Sed-2Sed
C 143588	Back Complete-Rear Seat-Cloth	43-47 5Sed
C 143589	Trim Assy-Rear Seat Back-Cloth	43-47 5Sed
C 143590	Cushion Complete-Rear Seat-Cloth	43-47 5Sed
C 143591	Trim Assy-Rear Seat Cushion-Cloth	43-47 5Sed
C 143592	Trim Panel-F Seat Compt	43-47 5Sed
143611	Use 202665	
143614	Use 202668	
143615	Use 202668	
C 143628	Skirt Assy-F Seat Compt Door Button-Cloth	43-47 5Sed
C 143630	Trimboard & Carpet Assy-F Seat Foot Rest End RH	1940 2Sed-VicCpe-CvCpe-CvSed,1941 2Sed
C 143631	Trimboard & Carpet Assy-F Seat Foot Rest End-LH	1940 2Sed-VicCpe-CvCpe-CvSed,1941 2Sed
BO 143632	Reinforcement-Front Door Arm Rest Cardboard	40P,41,43,44,47
BO 143637	Arm Rest Assy-Front Door-Leather Trim	40P-41-44-45-Sed-2Sed-3Cpe-VicCpe-Cv
C 143640	Trimboard & Carpet Assy-F Seat Foot Rest End-RH	43-47 5Sed
C 143641	Trimboard & Carpet Assy-F Seat Foot Rest End-LH	43-47 5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 143643	Cushion Complete-F Seat-Airfoam	40PSed-3Cpe,40T Sed
C 143644	Trim Assy-F Seat Cushion-Cloth-Use with Airfoam	40T Sed,40P Sed-3Cpe
C 143646	Cushion Complete-F Seat-Airfoam	40 2Sed-VicCpe-UCpe,40T 3Cpe
C 143647	Trim Assy-F Seat Cushion-Cloth-Use with Airfoam	40 2Sed-VicCpe-UCpe,40T 3Cpe
C 143649	Cushion Complete-Rear Seat-Cloth-Airfoam	40 Sed-2Sed
C 143650	Trim Assy-Rear Seat Cushion-Cloth-Use with Airfoam	40 Sed-2Sed
BO 143652	Arm Rest Assy-Door	44-45 2Sed
C 143729	Cushion Complete-Rear Seat	1940 CvCpe
C 143730	Trim Assy-Rear Seat Cushion	1940 CvCpe
BO 143731	Rubber Pad-Arm Rest	43-47-17 7Sed
C 143732	Arm Rest CompleterRear Seat Center-Cloth	43-47 5Sed
C 143733	Trim Assy-Rear Seat Center Arm Rest-Cloth	43-47 5Sed
C 143736	Trim Assy-Rear Seat Back-RH	47 5Sed
C 143737	Trim Assy-Rear Seat Back-LH	47 5Sed
C 143763	Back Complete-Aux Seat-LHD-Cloth	40P VicCpe
C 143764	Back Complete-Aux Seat-RHD-Cloth	40P VicCpe
C 143765	Trim Assy-Aux Seat Back-LHD-Cloth	40P VicCpe,40T VicCpe
C 143766	Trim Assy-Aux Seat Back-RHD-Cloth	40P VicCpe,40T VicCpe
C 143767	Cushion Complete-Aux Seat-LHD-Cloth	40P VicCpe
C 143768	Cushion Complete-Aux Seat-RHD-Cloth	40P VicCpe
C 143769	Trim Assy-Aux Seat Cushion-LHD-Cloth	40P VicCpe,40T VicCpe
C 143770	Trim Assy-Aux Seat Cushion-RHD-Cloth	40 VicCpe-40T VicCpe
C 143771	Back Complete-Aux Seat-LHD-Cloth	41-44 VicCpe
C 143772	Back Complete-Aux Seat-RHD-Cloth	41-44 VicCpe
C 143773	Trim Assy-Aux Seat Back-LHD-Cloth	41-44 VicCpe
C 143774	Trim Assy-Aux Seat Back-RHD-Cloth	41-44 VicCpe
C 143775	Cushion Complete-Aux Seat-LHD-Cloth	41-44 VicCpe
C 143776	Cushion Complete-Aux Seat-RHD-Cloth	41-44 VicCpe
C 143777	Trim Assy-Aux Seat Cushion-LHD-Cloth	41-44 VicCpe
C 143778	Trim Assy-Aux Seat Cushion-RHD-Cloth	41-44 VicCpe
C 143779	Back Complete-Aux Seat-LHD-Leather	41-44 VicCpe
C 143780	Back Complete-Aux Seat-RHD-Leather	41-44 VicCpe
C 143781	Trim Assy-Aux Seat Back-LHD-Leather	41-44 VicCpe
C 143782	Trim Assy-Aux Seat Back-RHD-Leather	41-44 VicCpe
C 143783	Cushion Complete-Aux Seat-LHD-Leather	41-44 VicCpe
C 143784	Cushion Complete-Aux Seat-RHD-Leather	41-44 VicCpe
C 143785	Trim Assy-Aux Seat Cushion-LHD-Leather	41-44 VicCpe
C 143786	Trim Assy-Aux Seat Cushion-RHD-Leather	41-44 VicCpe
BO 143787	Strap Assy-F Seat Compt Door	43-47 5Sed
C 143789	Seat Complete-Folding-LED-Cloth	41-44 VicCpe
C 143790	Seat Complete-Folding-RHD-Cloth	41-44 VicCpe
C 143791	Seat Complete-Folding-LHD-Leather	41-44 VicCpe
C 143792	Seat Complete-Folding-RHD-Leather	41-44 VicCpe
C 143793	Trim Assy-Folding Seat-LHD-Cloth	41-44 VicCpe
C 143794	Trim Assy-Folding Seat-RHD-Cloth	41-44 VicCpe
C 143795	Trim Assy-Folding Seat-LHD-Leather	41-44 VicCpe
C 143796	Trim Assy-Folding Seat-RHD-Leather	41-44 VicCpe
C 143797	Trimboard & Trim Assy-Folding Seat-Center-LHD-Cloth	41-44 VicCpe
C 143798	Trimboard & Trim Assy-Folding Seat Center-RHD-Cloth	41-44 VicCpe
C 143799	Trimboard & Trim Assy-Folding Seat Center-LHD-Leather	41-44 VicCpe
C 143800	Trimboard & Trim Assy-Folding Seat Center-RHD-Leather	41-44 VicCpe
C 143804	Door Complete-Front-RH	41-44 2Sed
C 143805	Door Complete-Front-LH	41-44 2Sed
C 143806	Door Complete-Front-RH	41-44 Sed
C 143807	Door Complete-Front-LH	41-44 Sed
C 143808	Door Complete-Front-RH	41-44 3Cpe-VicCpe
C 143809	Door Complete-Front-LH	41-44 3Cpe-VicCpe
C 143810	Door Complete-Rear-RH	41-44 Sed
C 143811	Door Complete-Rear-LH	41-44 Sed
C 143812	Door Complete-Front-RH	43-47 Sed
C 143813	Door Complete-Front-LH	43-47 Sed
C 143814	Door Complete-Rear-RH	43-47 Sed
C 143815	Door Complete-Rear-LH	43-47 Sed
C 143816	Door Complete-Front-RH	40P CvCpe-CvSed
C 143817	Door Complete-Front-LH	40P CvCpe-CvSed
C 143818	Door Complete-Front-RH	41-44 CvCpe-CvSed
C 143819	Door Complete-Front-LH	41-44 CvCpe-CvSed
BO 143918	Weatherseal Assy-Cowl Panel	1940 thru 1947 All
C 143921	Back Complete-F Seat-Drivers-LHD-Leather	40P-41-44 VicCpe-2Sed,45 2Sed
C 143922	Back Complete-F Seat-Drivers-RHD-Leather	40P-41-44 VicCpe-2Sed,45 2Sed
C 143923	Back Complete-F Seat-Passenger-LHD-Leather	40P-41-44 VicCpe-2Sed,45 2Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 143924	Back Complete-F Seat-Passenger-RHD-Leather	40P-41-44 VicCpe-2Sed,45 2Sed
C 143925	Cushion Complete-Front Seat-Leather	40P VicCpe-2Sed
C 143930	Cushion Complete-F Seat	41-44 VicCpe-2Sed,45 2Sed
C 143931	Back Complete-F Seat-LHD-Leather	40P-41-44-45 Sed
C 143932	Back Complete-F Seat-RHD-Leather	40P-41-44-45 Sed
C 143933	Back Complete-F Seat-LHD-Leather	40P-41-44-3Cpe
C 143934	Back Complete-F Seat-RHD-Leather	40!-41-44-3Cpe
C 143936	Cushion Complete-F Seat-Leather	40P Sed-3Cpe
C 143939	Cushion Complete-F Seat-Leather	41-44 3Cpe-Sed,45 Sed
C 143940	Back Complete-F Seat-LHD-Leather	43-47 5Sed
C 143941	Back Complete-F Seat-RHD-Leather	43-47 5Sed
C 143943	Cushion Complete-F Seat-Leather	43-47 5Sed
C 143947	Compt Lid & Trim Assy-F Seat Back-Leather	43-47 5Sed
C 143948	Back Complete-Rear Seat-Leather	40P-41-44-45 Sed-2Sed
C 143950	Cushion Complete-Rear Seat-Leather	40P, Sed-2Sed
C 143952	Cushion Complete-Rear Seat-Leather	41-44-45 Sed-2Sed
C 143953	Back Complete-Rear Scat	43-47 5Sed
C 143956	Cushion Complete-Rear Seat	43-47 5Sed
C 143973	Carpet Assy-Rear Floor-LHD-Bucket Seats	1940 2Sed
C 143974	Carpet Assy-Rear Floor-RHD-Bucket Seats	1940 2Sed
C 143975	Carpet Assy-Rear Floor-LHD-Bucket Seats	40-41-44-45 Sed
C 143976	Carpet Assy-Rear Floor-RHD-Bucket Seats	40-41-44-45 Sed
C 143977	Carpet Assy-Rear Floor-LHD-Bucket Seats	43-47 5Sed
C 143978	Carpet Assy-Rear Floor-RHD-Bucket Seats	43-47 5Sed
C 143989	Back Complete-F Seat-Drivers-LHD-Leather	40 CV,40T VicCpe-2Sed,40 UCpe
C 143990	Back Complete-F Seat-Drivers-RHD-Leather	40 CV,40T VicCpe-2Sed,40 UCpe
C 143991	Back Complete-F Seat-Pass-LHD-Leather	40 Cv,40T VicCpe-2Sed
C 143992	Back Complete-F Seat-Pass-RHD-Leather	40 Cv,40T VicCpe-2Sed
C 143993	Cushion Complete-F Seat	40P-41-44 Cv,40T VicCpe-3Cpe-2Sed
C 143999	Back Complete-F Seat-Drivers-LHD	41-44 CvCpe-CvSed
C 194000	Back Complete-F Seat-Drivers-RHD	41-44 CvCpe-CvSed
C 149001	Back Complete-F Seat-Pass-LHD	41-44 CvCpe-CvSed
C 144002	Back Complete-F Seat-Pass-RHD	41-44 CvCpe-CvSed
C 144003	Back Complete-Rear Seat-Cloth	40 UCo
C 144006	Back Complete-Rear Seat.	40 CvSed
C 144007	Back Complete-Rear Seat	40 CvSed Without quarter windows
C 144009	Back Complete-Rear Seat	41-44 CvSed
C 144011	Cushion Complete-Rear Seat	40-41-44 CvSed
C 144015	Cushion Complete-Rear Seat-Cloth	40 UCo
BO 144018	Weatherseal Pad-Underbody Panel	1940-1941 Sed-CA,1946-1947 Sed
BO 144025	Spacer-Visor Bracket	1940 thru 1942 CvCpe-CvSed,1946-1947 CvBro
C 144031	Back Complete-Aux Seat-LHD-Cloth	40T VicCpe
C 144032	Back Complete-Aux Seat-RHD-Cloth	40T VicCpe
C 144033	Cushion Complete-Aux Seat-LHD	40T VicCpe
C 144034	Cushion Complete-Aux Seat-RHD	1940 CvCpe-CvSed
C 144060	Back Complete-F Seat-Optional Cloth	43-47-48 7Sed
C 144061	Trim Assy-F Seat Back-Optional Cloth	1940 thru 1942 7Sed
C 144062	Cushion Complete-F Seat-Optional Cloth	1940 thru 1942 7Sed
C 144064	Back Complete-Rear Seat-Cloth	43-47 7Sed
C 144065	Trim Assy-Rear Seat Back-Cloth	43-47 7Sed
C 144066	Cushion Complete-Rear Seat-Cloth	43-47 7Sed
C 144067	Trim Assy-Rear Seat Cushion-Cloth	43-47 7Sed
C 144068	Back Complete-Rear Seat-Leather	43-47 7Sed
C 144069	Trim Assy-Rear Seat Back-Leather	43-47 7Sed
C 144070	Cushion Complete-Rear Seat-Leather	43-47 7Sed
C 144071	Trim Assy-Rear Seat Cushion-Leather	43-47 7Sed
C 144072	Back Complete-Rear Seat-Cloth	48 7Sed
C 144073	Trim Assy-Rear Seat Back-Cloth	48 7Sed
C 144074	Cushion Complete-Rear Seat-Standard-Cloth	48 7Sed
C 144075	Trim Assy-Rear Seat Cushion-Standard-Cloth	48 7Sed
C 144076	Cushion Complete-Rear Seat-Airfoam-Cloth	48 7Sed
C 144077	Trim Assy-Rear Seat Cushion-Airfoam-Cloth	48 7Sed
C 144114	Trimboard & Trim Assy-Package Compt	40-41-44 3Cpe
C 144131	Back Complete-Rear Seat-Leather Trim	40-41-44-45 Sed-2Sed
C 144132	Back Complete-Rear Seat-Leather Trim	43-47 5Sed
BO 144133	Spacer-Seat Back Spring Trimboard	43-47-17 5Sed,15 ClubCpe
C 144134	Back Complete-Rear Seat-Leather Trim	43-47 7Sed
C 144135	Back Complete-Rear Seat-Leather Trim	41-44 2Sed
C 144152	Cushion Complete-Front Seat-Cloth	43-47 5Sed
C 144154	Cushion Complete-Rear Seat-Cloth	43-47 5Sed
C 144175	Pad-Folding Seat Cushion	40-41 -44-CvCpe
C 144180	Seat Complete-Folding	40-41-44 CvCpe
C 144182	Trim Assy-Folding Seat	40-41-44 CvCpe
144189	use 202665	
144191	Weatherstrip Assy-Front Door Bottom-LH(Use 202667)	40 thru 45-10-11 exc Sed-Cab-CabPu-Panel
144192	Weatherstrip Assy-Rear Door Botton (Use 202668)	1940 Sedan
C 144194	Dust Boot Assy-Top	1940 CvSed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 144195	Top Complete-Trimmed	1940 CvCpe
C 144196	Reinforcement Assy-Top-RH	1940 CvCpe
C 144197	Reinforcement Assy-Top-LH	1940 CvCpe
C 144198	Top Deck & Side Quarter Assy	1940 CvCpe
C 144199	Rear Curtain & Window Assy-Top	1940 CvCpe
C 144204	Dust Boot Assy- Top	1940 CvCpe
C 144205	Bag Assy-Top Dust Boot	1940 CvCpe
BO 144206	Carpet-Rear Compt Wheelhouse-RH	1940 CvCpe
BO 144207	Carpet-Rear Compt Wheelhouse-LH	1940 CvCpe
C 144208	Carpet Assy-Rear Compt Floor	1940 CvCpe
C 144209	Carpet Assy-Rear Floor Riser	1940 CvCpe
BO 144210	Slide Fastener Assy-Top Rear Curtain-RH	1940 CvCpe
BO 144211	Slide Fastener Assy-Top Rear Curtain-LH	1940 CvCpe
C 144252	Cushion Complete-Front Seat-Leather	40T VicCpe-3Cpe-2Sed,40 UCpe
C 144253	Back Complete-Front Seat-LHD-Leather	40T Sed
C 144254	Back Complete-Front Seat-RHD-Leather	40T Sed
C 144256	Cushion Complete-Front Seat-Leather-Std	40T Sed
C 144257	Cushion Complete-Front Seat-Leather-Airfoam	40T Sed
C 144267	Back Complete-Aux Seat-LHD-Leather	40T VicCpe
C 144268	Back Complete-Aux Seat-RHD-Leather	40T VicCpe
C 144271	Cushion Complete-Aux Seat-LHD-Leather	40T VicCpe
C 144272	Cushion Complete-Aux Seat-RHD-Leather	40T VicCpe
C 144275	Back Complete-Rear Seat-Leather Trim	40T Sed-2Sed
C 144276	Back Complete-Rear Seat-Use with Leather Headlining	40T Sed-2Sed
C 144278	Cushion Complete-Rear Seat-Leather-Std	40T Sed-2Sed
C 144279	Cushion Complete-Rear Seat-Leather-Airfoam	40T Sed-2Sed
C 144281	Back Complete-Rear Seat-Leather Trim	48 7Sed
C 144282	Back Complete-Rear Seat-Use with Leather Headlining	48 7Sed
C 144284	Cushion Complete-Rear Seat-Leather-Std	48 7Sed
C 144285	Cushion Complete-Rear Seat-Leather-Airfoam	48 7Sed
C 144287	Retainer-Rear Wdo Seaming Welt	1940 Sed-2Sed
C 144289	Seaming Welt & Retainer Assy-Rear Window	1940 Sed-2Sed-UCo
144290	Use 143325	
BO 144308	Arm Rest Kit-Front Door-Cloth Trim	1940 All
BO 144309	Arm Rest Kit-Front Door-Leather Trim	1940 All
BO 144317	Arm Rest Kit-Front Door-Cloth	41-44-45 Sed-2Sed-3Cpe-VicCpe
C 144356	Retainer & Curtain Assy-Quarter Window-RH	1941 CvCpe-CvSed
C 144357	Retainer & Curtain Assy-Quarter Window-LH	1940 CvCpe-CvSed
C 144358	Back Complete-Rear Seat-Leather	1940 UCo
C 144359	Cushion Complete-Rear Seat-Leather	1940 UCo
C 144372	Trim Assy-Seat Back Compt Lid-Cloth	43-47 5Sed
C 144374	Back Complete-Front Seat	48 Carryall
C 144376	Cushion Complete-Front Seat	48 Carryall
C 144378	Trimboard & Trim Assy-F Seat Back Trim Frame	48 Carryall
C 144381	Back Complete-Center Seat	48 Carryall
C 144383	Cushion Complete-Center Seat	48 Carryall
C 144385	Trimboard & Trim Assy-Center Seat Back Trim Frame	48 Carryall
C 144387	Back Complete-Rear Seat	48 Carryall
C 144389	Cushion Complete-Rear Seat	48 Carryall
C 144390	Trim Assy-Rear Seat Cushion	48 Carryall
C 144391	Foot Rest Assy-Front Seat	48 Carryall
BO 144408	Slide Fastener Assy-Rear Curtain-RH	1940 CvSed
BO 144409	Slide Fastener Assy-Rear Curtain-LH	1940 CvSed
C 144410	Curtain & Window Assy-Rear	1940 CvSed
C 144413	Top Complete-With Quarter Windows	1940 CvSed
C 144414	Top Deck & Side Qtr Assy-With Quarter Windows	1940 CvSed
C 144415	Top Complete-Without Quarter Windows	1940 CvSed
C 144422	Cushion Complete-Front Seat-Mohair	41-44 Sed-3Cpe.43-45-47 5Sed
C 144425	Back Complete-Front Seat-LHD-Mohair	41-44-45 Sed
C 144426	Back Complete-Front Seat-RHD-Mohair	41-44-45 Sed
C 144427	Back Complete-Front Seat-LHD-Mohair	41P-44 3Cpe
C 144428	Back Complete-Front Seat-RHD-Mohair	41P-44 3Cpe
C 144431	Back Complete-Front Seat-Driver-LHD-Mohair	41-44 VicCpe-2Sed,45 2Sed
C 144432	Back Complete-Front Seat-Driver-RHD-Mohair	41-44 VicCpe-2Sed,45 2Sed
C 144433	Back Complete-Front Seat-Pass-LHD-Mohair	41-44 VicCpe-2Sed,45 2Sed
C 144434	Back Complete-Front Seat-Pass-RHD-Mohair	41-44 VicCpe-2Sed,45 2Sed
C 144435	Cushion Complete-Front Seat-Mohair	41-44 VicCpe-2Sed,45 2Sed
C 144439	Back Complete-Rear Seat-Mohair	41-44-45 Sed-2Sed
C 144441	Cushion Complete-Rear Seat-Mohair	41-44-45 Sed-2Sed,43-47 5Sed
C 144442	Trim Assy-Rear Seat Cushion	41 2Sed
C 144443	Back Complete-Auxiliary Seat-LHD-Mohair	41-44 VicCpe
C 144444	Back Complete-Auxiliary Seat-RHD-Mohair	41-44 VicCpe
C 144447	Cushion Complete-Auxiliary Seat-LHD-Mohair	41-44 VicCpe
C 144448	Cushion Complete-Auxiliary Seat-RHD-Mohair	41-44 VicCpe
C 144451	Back Complete-Front Seat-LHD-Mohair	43-47 5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 144452	Back Complete-Front Seat-RHD-Mohair	43-47 5Sed
C 144456	Back Complete-Rear Seat-Mohair	43-47 5Sed
C 144457	Back Complete-Rear Seat-Mohair	43-47 7Sed
C 144459	Cushion Complete-Rear Seat-Mohair	43-47 7Sed
C 144530	Trimboard & Trim Assy-Rear Compt Partition-LHD-Mohair	41-44 VicCpe
C 144531	Trimboard & Trim Assy-Rear Compt Partition-RHD-Mohair	41-44 VicCpe
C 144534	Seat Complete-Folding-LHD-Mohair	41-44 VicCpe
C 144535	Seat Complete-Folding-RHD-Mohair	41-44 VicCpe
C 144536	Center Trimboard & Trim Assy-Folding Seat-LHD-Mohair	41-44 VicCpe
C 144537	Center Trimboard & Trim Assy-Folding Seat-RHD-Mohair	41-44 VicCpe
C 144558	Trimboard Complete-F Door-RH	45 Sedan
C 144559	Trimboard Complete-F Door-LH	45 Sedan
C 144560	Trimboard Complete-Rear Door-RH	45 Sedan
C 144561	Trimboard Complete-Rear Door-LH	45 Sedan
C 144613	Seat Complete-Folding-LH	40-41-44 CvCpe
C 144615	Trimboard Assy-F Seat Back Trim Frame	48-18 CA
C 144618	Side Trimboard Assy-F Seat Back Frame-RH	43-47 5Sed,18 CA
C 144619	Side Trimboard Assy-F Seat Back Frame-LH	43-47 5Sed,18 CA
C 144620	Frame-Back Complete-F Seat Cushion	43-47 5Sed,18 CA
C 144621	Cushion Frame & Back Complete-F Seat	1940-1941 Carryall
C 144622	Trim Assy-F Seat Back	43-47 5Sed,18 CA
C 144623	Cushion Complete-F Seat	43-47 5Sed,18 CA
C 144624	Trim Assy-F Seat Cushion	43-47 5Sed,18 CA
C 144628	Pad-Aux Seat Back	18 CA
C 144629	Pad-Aux Seat Cushion	18 CA
C 144631	Trim Assy-Aux Seat Back	43-47 5Sed,18 CA
C 144632	Back Complete-Aux Scat-RH	48 CA
C 144633	Back Complete-Aux Seat-LH	48 CA
C 144634	Trim Assy-Aux Seat Back-RH	48 CA
C 144635	Trim Assy-Aux Seat Back-LH	48 CA
C 144636	Trimboard Assy-Aux Seat Cushion Bottom-RH	48 CA
C 144637	Trimboard Assy-Aux Seat Cushion Bottom-LH	48 CA
C 144638	Back Complete-Rear Seat	48 CA
C 144639	Trim Assy-Rear Seat Back	48 CA
C 144640	Cushion Complete-Rear Seat	48 CA
C 144641	Trim Assy-Rear Seat Cushion	48 CA
C 144643	Carpet Assy-Rear Floor	1940 7Sed
C 144651	Carpet-F Floor-LHD-Blue or Green	43-47 5Sed
C 144652	Carpet-F Floor-RHD-Blue or Green	43-47 5Sed
C 144653	Pad-F Floor Carpet-LHD-Blue or Green Trim	43-47 5Sed
C 144656	Back Complete-F Seat-LHD-Blue or Green	43-47 5Sed
C 144657	Back Comp-F Seat-RHD-Blue or Green	43-47 5Sed
C 144658	Trim Assy-F Seat Back-Blue or Green	43-47 5Sed
C 144659	Cushion Comp-F Seat-Blue or Green	43-47 5Sed
BO 144682	Arm Rest Assy-Qtr-RH-Green or Blue Trim	43-47 5Sed
BO 144683	Arm Rest Assy-Qtr-LH-Green or Blue Trim	43-47 5Sed
C 144688	Trim Assy-F Seat Cushion-Green or Blue	43-47 5Sed
C 144689	Trim Assy-F Seat Side & Riser-Green or Blue	43-47 5Sed
C 144690	Board & Trim Assy-F Seat Back-Green or Blue	43-47 5Sed
C 144691	Lid & Trim Assy-F Seat Back Comp-Green or Blue	43-47 5Sed
C 144692	Trim Assy-F Seat Comp Lid-Green or Blue	43-47 5Sed
C 144693	Back Complete-Rear Seat-Green or Blue	43-47 5Sed
C 144694	Trim Assy-Rear Seat Back-RH-Green or Blue	43-47 5Sed
C 144695	Trim Assy-Rear Seat Back-LH-Green or Blue	43-47 5Sed
C 144698	Cushion Comp-Rear Seat-Blue or Green	43-47 5Sed
C 144699	Trim Assy-Rear Seat Cushion-Blue or Green	43-47 5Sed
C 144706	Filler-Underbody Panel-Rear-RH	1940 7Sed-CA
C 144707	Filler-Underbody Panel-Rear-LH	1940 7Sed-CA
C 144708	Trim Panel-F Seat Compt-Blue or Green	1940 7Sed-CA
C 144709	Trim Panel-F Seat Compt-Blue or Green	1940 7Sed-CA
BO 144725	Knob-Heater Valve & Cowl Vent-Black	43-47 5Sed
BO 144727	Spacer Assy-Rear Comp Door Latch to Panel Reinforcement	1940 All
BO 144729	Bracket-Body Header Bow-LH	1940 All
BO 144730	Tail Lamp Complete-6 Volt	1940 thru 1942 Cab-CabPu-Panel,58,178 Cab-CabPu
BO 144731	Tail Lamp Complete-12 Volt	1940 thru 1942 Cab-CabPu-Panel,58,178 Cab-CabPu
BO 144732	Body Assy-Tail Lamp	1940 thru 1942 Cab-CabPu-Panel,58,178 Cab-CabPu
BO 144734	Wire Assy-Tail Lamp	1940 thru 1942 Cab-CabPu-Panel,58,178 Cab-CabPu
BO 144735	Lens-Tail Lamp	1940 thru 1942 Cab-CabPu-Panel,1941-1942 Sta,58,178
BO 144736	Rim-Tail Lamp Lens	1940 thru 1942 Cab-CabPu-Panel,1941-1942 Sta,58,178

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 144737	Spring-Tail Lamp Lens Retaining	1940 thru 1942 Cab-CabPu-Panel,1941-1942 Sta,58,178
BO 144738	License Lens-Tail Lamp	1940 thru 1942 Cab-CabPu-Panel,1941-1942 Sta,58,178
BO 144739	Gasket-Tail Lamp Lens	1940 thru 1942 Cab-CabPu-Panel,1941-1942 Sta,58,178
BO 144740	Clip-Tail Lamp Lens	1940 thru 1946 Cab-CabPu-Panel,1941-1942 Sta,58,178
BO 144742	Cap-Steering Gear Jacket-Tube Brkt-Nickel Plated	43,47,14,15,17,22 thru 27,52-54-172-174 With DI
BO 144745	Ash Receiver-Inst Panel Side-Painted	43-47 5Sed Blue-Green
BO 144749	Brkt-Steering Gear Jacket Tube-Nickel Plate	43-47 5Sed Blue-Green
BO 144752	Tray and Knob Assy-Arm Rest Receiver-RH	43-47 5Sed Blue-Green
144758	Knob-Door Lock Release Rod-Black (Use 209661)	43-47 5Sed Blue-Green
BO 144759	Handle-Door Wdo Regulator-Black	43-47 5Sed Blue-Green
BO 144760	Handle-Door Wing Regulator-Black	43-47 5Sed Blue-Green
BO 144761	Escutcheon-Inside Handle & Reg-Black	43-47 5Sed Blue-Green
BO 144762	Escutcheon-Door Wing Handle-Black	43-47 5Sed Blue-Green
BO 144763	Escutcheon-Qtr Wdo Regulator-Black	43-47 5Sed Blue-Green
BO 144770	Screen-Radio Grille-Painted	43-47 5Sed Blue-Green
BO 144772	Cigar Lighter Assy-6 Volt-RHD-Black	43-47 5Sed Blue-Green
144773	Cigar Lighter Assy-6 Volt-RHD-Black	43-47 5Sed Blue-Green
BO 144774	Heating Element & Knob Assy-6 Volt	43-47 5Sed Blue-Green
BO 144784	Door Assy-Locker Box-RH-LHD-Blue Gray	43-47 5Sed
BO 144790	Knob-Inst Panel Center Ash Receiver-Gray	40 thru 47
C 144818	Back Complete-Rear Seat-RH-Cloth	1940 UCo-Sed-2Sed with Split Rear Seat
C 144819	Back Complete-Rear Seat-LH-Cloth	1940 UCo-Sed-2Sed with Split Rear Seat
C 144822	Cushion Complete-Rear Seat-RH-Cloth	1940 UCo-Sed-2Sed with Split Rear Seat
C 144823	Cushion Complete-Rear Seat-LH-Cloth	1940 UCo-Sed-2Sed with Split Rear Seat
C 144826	Back Comp-Rear Seat-RH-Leather	43-47 5Sed
C 144827	Back Comp-Rear Seat-LH-Leather	43-47 5Sed
C 144830	Cushion Comp-Rear Seat-RH-Leather	43-47 5Sed
C 144831	Cushion Comp-Rear Seat-LH-Leather	43-47 5Sed
BO 144873	Strap-Rear Seat Back-Lower	1940-1941 Sed-2Sed-UCo with Split Rear Seat
BZ 144880	Guard-Front Bumper-For Custom Kit	1940,10P,11
BZ 144881	Spacer-Front Bumper Guard-For Custom Kit	1940,10P,10C,11
C 144882	Extension-F Bumper Guard-RH-For Custom Kit	1940,10P,11
C 144883	Extension-F Bumper Guard-LH-For Custom Kit	1940,10P,11
BZ 144884	Spacer-F Bumper Guard Extension-For Custom Kit	1940,10P,11
C 144885	Cross Bar-F Bumper Guard-For Custom Kit	1940,10P,11
BZ 144886	Retainer-F Bumper Bar Ext & Cross Bar- For Custom Kit	1940,10P,11
C 144900	Finish Mldg-W/Strip Assy-Qtr Wdo-RH	40 2Sed-UCo
C 144901	Finish Mldg-W/Strip Assy-Qtr Wdo-LH	40 2Sed-UCo
C 144902	Finish Mldg-& W/Strip Assy-Qtr Wdo-RH	41-44 2Sed
C 144903	Finish Mldg & W/Strip Assy-Qtr Wdo-LH	41-44 2Sed
C 144906	Finish Mldg & W/Strip Assy-Rear Door Wdo-RH	40 Sed,48 Sed-Carryall
C 144907	Finish Mldg & W/Strip Assy-Rear Door Wdo-LH	40 Sed,48 Sed-Carryall
C 144912	Finish Mldg & W/Strip Assy-Rear Door Wdo-RH	43-47 5Sed
C 144914	Finish Mldg & W/Strip Assy-F Door Wdo-RH	40T 2Sed.48P
C 144927	Finish Mldg & W/Strip Assy-F Door Wdo-LH	40 5Sed,40-48 Cab-CabPu-Panel
C 144928	Finish Mldg & W/Strip Assy-F Door Wdo-RH	41-44 Sed
C 144929	Finish Mldg & W/Strip Assy-F Door Wdo-LH	41-44 Sed
C 144930	Finish Mldg & W/Strip Assy-F Door Wdo-RH	45 Sed
C 144931	Finish Mldg & W/Strip Assy-F Door Wdo-LH	45 Sed
C 144932	Finish Mldg & W/Strip Assy-F Door Wdo-RH	40T 3Cpe-VicCpe,40 UCpe
C 144933	Finish Mldg & W/Strip Assy-F Door Wdo-LH	40T 3Cpe-VicCpe,40 UCpe
C 144936	Finish Mldg & W/Strip Assy-F Door Wdo-RH	41-44 3Cpe-VicCpe
C 144938	Finish Mldg & W/Strip Assy-F Door Wdo-RH	1940-1941 CvCpe-CvSed
C 144939	Finish Mldg & W/Strip Assy-F Door Wdo-LH	1940-1941 CvCpe-CvSed
C 146002	Panel-Cowl-RH	10 exc Panel
C 146003	Panel-Cowl -LH	10 exc Panel
C 146004	Panel-Cowl-RH-Prime	11,12,14,15,17,18
C 146005	Panel-Cowl-LH-Prime	11,12,14,15,17,18
C 146006	Panel-Front End-Prime	10 thru 18,20,21,28,51,53,58,171,173,178
BO 146024	Dash Bracket-Radiator Stay Rod	1941-1942 exc Del,1946-1947 All
BO 146026	Cover-Voltage Regulator	1941 All
*A 146030	Fender-Rear-RH-Used with Running Board	10T,10P.11 thru 17,10 UCo-UCpe,18P
*A 146031	Fender-Rear-LH-Used With Running Boards	10T,10P,11 thru 17,10 UCo-UCpe.18P
146032	Fender-Rear-RH-Used Without Running Boards (Use 146030)	10T,10P,11 thru 17,10 UCo-UCpe,18P
146033	Fender-Rear-LH-Used Without Running Boards (Use 146031)	10T,10P,11 thru 17,10 UCo-UCpe.18P
*C 146061	Panel-Roof-Prime.	1941-1942 Sed-2Sed-UCo,51-53-171-173 Bro-Sed
C 146062	Panel Assy-Roof-Prime	17,18P,27
C 146066	Panel-Roof-Prime	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 Club Cpe-3Cpe
146067	Panel-Roof Prime (Use 209622)	1941-1942-1946 Cab-CabPu
C 146073	Floor Cover-Trans Opening-RHD	1941-1942 exc Del ,1946-1947 All
C 146074	Floor Cover & Acc Brkt Assy-Trans Opening-LHD	1941-1942 exc Del,1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 146081	Bracket-Rear Dome Lamp	12 thru 18 Sedan,52-54-172-174 Sed
C 146091	Pillar Assy-Center	1941 Sedan-Carryall
C 146098	Pillar Assy-Rear-RH	1941-1942 CvSed,1946-1947 CvBro
C 146099	Pillar Assy-Rear-LH	1941-1942 CvSed,1946-1947 CvBro
C 146102	Gusset-RH-R Pillar to Wheelhouse	1941 thru 1947 Sed
C 146103	Gusset-LH-R Pillar to Wheelhouse	1941 thru 1947 Sed
C 146112	Header Assy-Body-RH	1941-1942 2Sed-UCo,1946-1947 Bro
C 146113	Header Assy-Body-LH	1941-1942 2Sed-UCo,1946-1947 Bro
BO 146115	Hole Cover-Steering Column-LHD	1941 thru 1947 All
C 146118	Header Assy-Body-RH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 146119	Header Assy-Body-LH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 146131	Header Assy-Windshield	1941-1942 exc CvSed,1946-1947 exc CvBro
C 146151	Tray and Center Reinf Assy-Rear Seat	1941 Sed-2Sed
C 146156	Brkt and Toe Board Riser Assy-F Pillar to Dash-RH-LHD	10,20
C 146158	Brkt and Toe Board Riser Assy-F Pillar to Dash-RH-RHD	10,20
C 146160	Brkt and Toe Board Riser Assy-F Pillar to Dash-RH-LHD	11 thru 18,21 thru 28,1946-1947 All
C 146162	Brkt and Toe Board Riser Assy-F Pillar to Dash-RH-RHD	11 thru 18,21 thru 28,1946-1947 All
C 146166	Pillar Assy-Rear-RH	1941-1942 2Sed-UCo,1946-1947 Bro
C 146167	Pillar Assy-Rear-LH	1941-1942 2Sed-UCo,1946-1947 Bro
C 146168	Pillar Assy-Rear-RH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 146169	Pillar Assy-Rear-LH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 146186	Pillar Assy-Rear-RH	1941 thru 1947 Cab-CabPu
C 146187	Pillar Assy-Rear-LH	1941 thru 1947 Cab-CabPu
BO 146188	Bracket-Rear Pillar to Body Header-RH	1941 thru 1947 Cab-CabPu
BO 146189	Bracket-Rear Pillar to Body Header-LH	1941 thru 1947 Cab-CabPu
C 146192	Pillar Assembly-Front-RH	1941 exc Cv,11-14 Station,1942-1946-1947 Cab-CabPu
C 146193	Pillar Assembly-Front-LH	1941 exc Cv,11-14 Station,1942-1946-1947 Cab-CabPu
146212	Door Assy-Rear Compt (Use 206761)	10-11 2Sed-Sed,10C UCo,18P Sed-CA
146213	Door Assy-Rear Compt (Use 206761)	12-14 2Sed-Sed,17 Sed
*A 146222	Hood Assy	10 exc Del
*A 146232	Hood Assembly	11 thru 18
146248	Weatherstrip-Deck Door (Use 203073)	1941-1942 3Cpe-ClubCpe-CvSed-11Cpe
146249	Weatherstrip-Rear Compt Door (Use 203072)	1941-1942 Sed-2Sed-UCo-Carryall
C 146256	Extension-Underbody Panel-RH	1941 thru 1947 Cab-CabPu
C 146257	Extension-Underbody Panel-LH	1941 thru 1947 Cab-CabPu
C 146258	Header Assy-Body-RH	1941 thru 1947 Cab-CabPu
C 146259	Header Assy-Body-LH	1941 thru 1947 Cab-CabPu
C 146260	Extension-Underbody Panel-RH	10T,10P,11,12,14,15,10 UCo-UCpe,10-18 Cab-CabPu,1942 Station
C 146261	Extension-Underbody Panel-LH	10T,10P,11,12,14,15,10 UCo-UCpe-10-18 Cab-CabPu,1942 Station
C 146263	Extension-Underbody Panel-LH	17,18P,178 Station
C 146272	Pillar Assembly-Rear-RH	1941-1942 Sed-Carryall,1946-1947 Sed
C 146273	Pillar Assembly-Rear-LH	1941-1942 Sed-Carryall,1946-1947 Sed
C 146280	Reinforcement-Rear Compartment Door Panel	1941,1942 2Sed-Sed,1946-1947 Bro-Sed
C 146282	Stiffener-RH-Rear Compartment Door Panel Reinf	1941-1942 2Sed-Sed,1946-1947 Bro-Sed
C 146283	Stiffener-LH-Rear Compartment Door Panel Reinf	1941-1942 2Sed-Sed,1946-1947 Bro-Sed
*C 146300	Panel-Rear Seat Back Shelf	1946-1947 Bro-Sed
*A 146311	Panel Assy-Radiator Louver-Prime	1941 exc Del
C 146315	Arm & Cross Shaft Assy-Bonnet Hinge	1941 exc Del
BO 146346	Brkt-Riser Panel to Cushion Frame-Center	1941-1942 ClubCpe-3Cpe-UCpe-2Sed,Cv,1946-1947 Bro-Sed-3Cpe
BO 146347	Brkt-Side Panel to Cushion Frame	17 5Sed
BO 146348	Brkt-Riser Panel to Cushion Frame-Corner-RH	1941-1942-Sed-2Sed-UCpe-3Cpe,1946-1947 Bro-Sed-3Cpe
BO 146349	Brkt-Riser Panel to Cushion Frame-Corner-LH	1941-1942 Sed-2Sed-UCpe-3Cpe,1946-1947 Bro-Sed-3Cpe
C 146352	Riser Panel & Brkt Assy-Front Seat	1941 5Sed-3Cpe
C 146356	Riser Panel & Brkt Assy-Front Seat	1941-1942 ClubCpe-CvSed,15 3Cpe,1946-1947 ClubCpe-CvBro
C 146359	Bracket-F Seat Riser Panel to Cushion Frame	1946-1947 ClubCpe-CvBro
C 146362	Riser Panel & Brkts Assy-F Seat	1941 2Sed-UCpe-3Cpe,1942 2Sed,1946-1947 Bro
BO 146363	Plate-Seat Track Adjusting	1941-1942 ClubCpe-CvSed,15 3Cpe,1946-1947 ClubCpe-CvBro
C 146370	Panel-Rear Compt Shelf	1941 thru 1947 3Cpe-ClubCpe,1941-1942 UCpe
BO 146376	Support-Qtr Panel Trim Strip	1941-1946-1947 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 146377	Shield & Clip Assy-Radiator Lower Tank	10T,10P,10C exc Del,20
A 146378	Shield & Clip Assy-Radiator Lower Tank Enamel	11,12,18,21,22,28,51,52,58,171,172,178
A 146379	Shield & Clip Assy-Radiator Lower Tank	14,15,17,24,25,27,53,54,173.174
146382	Use 146423	
C 146398	Hinge Reinf Assy-Cowl Panel-RH	1941-1942-1946-1947 All
C 146399	Hinge Reinf Assy-Cowl Panel-LH	1941-1942-1946-1947 All
C 146423	Partition Assembly-Rear Compartment	1941-1942 3Cpe-UCpe,1946-1947 3Cpe
BO 146424	Bracket-Rear Pillar Folding Top-RH	1941-1942 CvSed,1946-1947 CvBro
BO 46425	Bracket-Rear Pillar Folding Top-LH	1941-1942 CvSed,1946-1947 CvBro
BO 146428	Pivot Bracket-Folding Top-RH	1941-1942 CvSed,1946-1947 CvBro
BO 146429	Pivot Bracket-Folding Top-LH	1941-1942 CvSed,1946-1947 CvBro
C 146480	Side Reinf-Rear Compt Opening-RH	1941-1942 Sed-2Sed-UCo,1941 CA,1946-
C 146481	Side Reinf-Rear Compt Opening-LH	1947Bro-Sed
C 146482	Reinforcement-Rear Compt Opening-RH	1941-1942 Sed-2Sed-UCo,1941 CA,1946-
A 146490	Fender Assy-Rear-RH	1947Bro-Sed
A 146491	Fender Assy-Rear-LH	1941-1942 Sed-2Sed-UCo,1941 CA,1946-
A 146500	Fender Assy-Rear-RH	1947Bro-Sed
A 146501	Fender Assy-Rear-LH	11-14 Station
BZ 146509	Support-Rear Fender Apron	11-14 Station
BO 146522	Weatherstrip-Qtr Window-Outer-RH	1941-1942-1946-1947 CabPu
BO 146523	Weatherstrip-Qtr Window-Outer-LH	1941-1942-1946-1947 CabPu
BO 146526	Retainer Assy-Qtr Window Glass Weatherstrip-RH	1941-1942 Cab-CabPu-Station,1946-1947 CabPu
BO 146527	Retainer Assy-Qtr Window Glass Weatherstrip-LH	11-12-14-15 ClubCpe,52-54-172-174 ClubCpe
BO 146546	Weatherstrip-Quarter Window Glass-Outer-RH	11-12-14-15 ClubCpe,52-54-172-174 ClubCpe
BO 146547	Weatherstrip-Quarter Window Glass-Outer-LH	11-12-14-15 ClubCpe
C 146550	Retainer Assy-Qtr Wdo W/Strip-RH	11-12-14-15 ClubCpe
C 146551	Retainer Assy-Qtr Wdo W/Strip-LH	10P-11-12-14-17 5Sed-7Sed,1946-1947 Sed
C 146559	Frame and Bracket Assy-Qtr Window-LH	10P-11-12-14-17 5Sed-7Sed,1946-1947 Sed
C 146568	Rest Channel Assy-Qtr Window Glass	10P-11-12-14-15-17 Sed
C 146571	Glass Run-Quarter Window	10P-11-12-14-15-17 Sed
*C 146574	Frame Assy-Quarter Window-RH	10P-11-12-14-15-17 5Sed-7Sed
*C 146575	Frame Assy-Quarter Window-LH	1941-1942 2Sed-UCo,1946-1947 Bro
BO 146582	Brace-Quarter Window Reg Panel to Drain Trough	1941-1942 2Sed-UCo,1946 Bro
BO 146584	Regulator-Quarter Window-RH	1941 2Sed-UCo,1946-1947 Bro
BO 146585	Regulator-Quarter Window-LH	1941 2Sed-UCo,1946-1947 Bro
BO 146591	Weatherstrip-Qtr Window-Inner-LH	1941 UCo-2Sed,1946-1947 Bro
BZ 146594	Bracket-Front Fender Brace Rod-RH	1941 UCo-2Sed,1946-1947 Bro
BZ 146595	Bracket-Front Fender Brace Rod-LH	1941 UCo-2Sed.1946-1947 Bro
C 146596	Rod-F Fender to Frame Brace-RH	11-12-14-15 ClubCpe
C 146597	Rod-F Fender to Frame Brace-LH	1941 thru 1947 All
C 146600	Panel-F Door Outside-RH-Wing Type Window	1941 thru 1947 All
C 146601	Panel-F Door Outside-LH-Wing Type Window	1941 thru 1947 All
C 146604	Panel-F Door Outside-RH-Wing Type Window	1941 thru 1947 All
C 146610	Panel-F Door Outside-RH-Sliding Window	10P-11-12-14 2Sed,18P
C 146611	Panel-F Door Outside-LH-Sliding Window	10P-11-12-14 2Sed,18P
C 146614	Panel-Rear Door Outside-RH	10P-11-12-14 Sed
146624	Use 200348 for model 11, 200354 for models 12-14-15-17	10T 3Cpe-ClubCpe,10 UCpe 10T 3Cpe-ClubCpe,10 UCpe
BO 146626	Door Assy-Locker Box-RH-RHD-Painted Gray	10P-11-12-14-17 Sed
BO 146627	Door Assy-Locker Box-LH-RHD-Painted Gray	
146628	Use 200344 for model 11, 200350 for models 12-14-15-17	11 thru 17
BO 146630	Door Assy-Locker Box-RH-RHD-Grained	11 thru 17
146632	Use 200346 for model 11, 200352 for models 12-14-15-17	
146633	Use 200347 for model 11, 200353 for models 12-14-15-17	10T,10P,11 thru 17,10 UCo-UCpe,18P
C 146662	Panel-Front Door Outside-RH	10T-10P-10 Sp 3Cpe-ClubCpe,10 UCpe,10 Sp
C 146663	Panel-Front Door Outside-LH	10T-10P-10 Sp 3Cpe-ClubCpe,10 UCpe,10 Sp
*C 146667	Panel-Rear Door Outside-LH-Prime	10-11 Sed,10-18 Cab-CabPu
*BO 146686	Cradle-Door Wing-RH	1941-1942 CvSed,1946-1947 CvBro
*BO 146687	Cradle-Door Wing-LH	1941-1942 CvSed,1946-1947 CvBro
BO 146692	Channel Assy-Door Glass Run-RH-Rear	1941-1942 CvSed,1946-1947 CvBro
BO 146693	Channel Assy-Door Glass Run-LH-Rear	1941-1942 CvSed,1946-1947 CvBro
C 146740	Air Duct Assy-Cowl Vent	1941 thru 1947 All
BO 146752	Brkt-Cowl Ventilator Air Duct	1941 thru 1947 All
BO 146753	Brkt-Cowl Ventilator Operating Handle	1941-1946-1947 All
BO 146758	Bolt-Cowl Vent Handle	1941-1942 exc Del
BO 146759	Retainer-Cowl Vent Rod Grommet	1941-1942 exc Del,1946-1947 All
BO 146762	Bracket-Cowl Ventilator Hinge-RH	1941-1942 exc Del,1946-1947 All
BO 146763	Bracket-Cowl Ventilator Hinge-LH	1941-1942 exc Del,1946-1947 All
BO 146764	Brkt-Cowl Vent Hinge Link-RH	1941-1942 exc Del,1946-1947 All
BO 146765	Brkt-Cowl Vent Hinge Link-LH	1941-1942 exc Del,1946-1947 All
BO 146768	Link & Rod Assembly-Cowl Vent Hinge	1941-1942 exc Del,1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	Rod-Cowl Vent Operating	
BO 146769	Lever-Cowl Vent Hinge Rod	1941-1942 exc Del,1946-1947 All
BO 146770	Spring-Cowl Vent Hinge Rod Anti Rattle	1941-1942 exc Del,1946-1947 All
BO 146771	Rivet-Cowl Vent Brkt to Hinge Link	1941-1942 exc Del,1946-1947 All
BO 146772	Rivet-Cowl Vent Link to Pivot Bracket	1941-1942 exc Del,1946-1947 All
BO 146773	Silencer-Cowl Vent Air Duct to Dash	1941-1942 exc Del,1946 thru 1950 All
BO 146774	Drain Hose-Cowl Vent Air Duct	1941-1942 exc Del,1946-1947 All
BO 146775	Weatherseal-Cowl Vent Air Duct Drain Tube	1941-1942 exc Del,1946-1947 All
BO 146776	Cover Assy-Cowl Ventilator	1941-1942 exc Del,1946-1947 All
*BO 146780	Bracket-Pillar Check Strap	1941-1942 exc Del,1946-1947 All
BO 146796	Cradle Complete-Door Wing-RH	1941-1942 exc Del,1946-1947 All
BO 146804	Cradle Complete-Door Wing-LH	1941-1942 CvSed,1946-1947 CvBro
BO 146805	Running Board Complete-LH-With Mldg Holes	1941-1942 CvSed,1946-1947 CvBro
C 146817	Running Board Complete-With Molding Holes-RH	17,18
C 146838	Running Board Complete-With Molding Holes-LH	10
C 146839	Brkt-Running Board Supp-Center	10
BZ 146842	Fender Assy-Front-RH-Without Lamp Holes	1941 All,20C,28,1946-1947 CabPu-Station
*A 146880	Fender Assy-Front-LH-Without Lamp Holes	10,11,18
*A 146881	Fender Assy-Front-RH-With Lamp Holes (Use 146880)	10,11,18
146882	146880)	1941 All
146883	Fender Assy-Front-LH-With Lamp Holes(Use 146881)	1941 All
*C 146934	Panel Assy-Rear-Lower	1941-1942 All,51 thru 54,171 thru 174
C 146941	Reinforcement Assy-Rear Window Opening	1941-1942 exc Cab-CabPu-Panel-Cv,52-54-172-174Sed
A 146950	Stone Guard & Apron Support-Rear Fender-RH	1941 thru 1947 exc Cab-CabPu-Sta
A 146951	Stone Guard & Apron Support-Rear Fender-LH	1941 thru 1947 exc Cab-CabPu-Sta
C 146995	Retainer Assy-Rear Seat Cushion	12-14-17 5Sed-2Sed,10-11-18 Leather Trim 5Sed-2Sed, 1942 Sed-2Sed,1946-1947 Bro-Sed
146997	Use 147753	
BO 146998	Brkt-Rear Cushion Retainer to Seat Tray	1941-1942 2Sed-5Sed-UCo-ClubCpe-CvSed,1946-1947 exc 3Cpe-Cab-CabPu
C 147050	Trim Molding-Underbody Extension-RH	10T,10P,10 UCo
C 147051	Trim Molding-Underbody Extension-LH	10T,10P,10 UCo
C 147052	Trim Molding-Underbody Extension-RH	11,12,14 exc Station,15
C 147053	Trim Molding-Underbody Extension-LH	11,12,14 exc Station,15
C 147055	Trim Molding-Underbody Extension-LH	17,18P
BO 147056	Trim Molding-RH-Front Fender	10T,10P,11 thru 17,18P,10 UCo-UCpe
BO 147057	Trim Molding-LH-Front Fender	10T,10P,11 thru 17,18P,10 UCo-UCpe
BZ 147065	Bonnet Guide-F Fender Side Dust Shield	1941 thru 1950 All
BO 147089	Cover Plate-Weathermaster Tube Dash Hole	1941-1942-1946-1947 All
A 147105	Panel Assy-Instrument-RHD-Painted	11,12,15,17
147118	Handle Assy-Door Outside-RH Front-LH Rear (Use 204142)	11 Sedan,18P
147118	Handle Assy-Door Outside-RH (Use 204142)	11 2Sed-3Cpe-ClubCpe-CvSed,18C
147119	Handle Assy-Door Outside-LH (Use 204143)	11 2Sed-3Cpe-ClubCpe,CvSed,18C
147119	Handle Assy-Door Outside (Use 204143)	11 Sedan,18P
147120	Use 204140	
147121	Use 204141	
147122	Handle Assy-Door Outside-RH Front-LB Rear (Use 204144)	12,14,15,17
147123	Handle Assy-Door Outside-LH Front-RH Rear (Use 204145)	12,14,15,17
C 147125	Panel-Rear-Upper	10-18-20-28 Cab-CabPu,1946 Cab-CahPu
C 147128	Side Panel-Rear Lower-RH	10-18-20-28-58-178 Cab-CabPu
C 147129	Side Panel-Rear Lower-LH	10-18-20-28-58-178 Cab-CabPu
C 147130	Reinf-Rear Panel Lower	10-18-20-28-58-178 Cab-CabPu
C 147132	Panel Assy-Rear Lower-Prime	10-18-20-28-58-178 Cab-,CabPu
C 147133	Panel-Rear Inner-Prime	10-18-20-28-58-178 Cab-CabPu
C 147134	Brace-Rear Panel Inner to Upper	10-18-20-28-58-178 Cab-CabPu
BO 147136	Backing Plate-Rear Panel Seat Retainer	10-18-20-28-58-178 Cab-CabPu
BO 147148	Weatherstrip-Quarter Wdo Belt-Inner-RH	1941-1942 2Sed-UCo,1946-1947 Bro
BO 147149	Weatherstrip-Quarter Wdo Belt-Inner-LH	1941-1942 2Sed-UCo,1946-1947 Bro
BO 147150	Brace-Inst Panel to Front Pillar-RH	1941 thru 1947 All
BO 147151	Brace-Inst Panel to Front Pillar-LH	1941 thru 1947 All
BO 147202	Ornament-F Door Valance-Rear	11-12-14 Sedan
BO 147202	Ornament-Rear Door Valance	11-12-14 Sedan
C 147208	Reinforcement-RH-Qtr Wdo	1941 thru 1947 3Cpe-ClubCpe
C 147209	Reinforcement-LH-Qtr Wdo	1941 thru 1947 3Cpe-ClubCpe
BO 147212	Drain Trough-Quarter Window-RH	1941-1942 2Sed-UCo-3Cpe-ClubCpe-UCpe,1946-1947 Bro-3Cpe-ClubCpe
BO 147213	Drain Trough-Quarter Window-LH	1941-1942 2Sed-UCo-3Cpe-ClubCpe,UCpe,1946-1947 Bro-3Cpe-ClubCpe
BO 147220	Retaining Clip-Locker Box Door	1941 thru 1947 All
BO 147221	Spring-Glove Box Door	1941 thru 1947 All
BO 147222	Striker Plate-Glove Box Door Lock	1941 thru 1947 All
BO 147223	Lock Assy-Glove Box Door-Less Cylinder	1941 thru 1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 147224	Lock, Cylinder & Keys Assy-Glove Box Door	1941 thru 1947 All
BO 147226	Cylinder-Glove Box Door Lock-Not Coded	1941 thru 1947 All
BO 147227	Cylinder & Key Assy-Glove Box Door Lock	1941 thru 1947 All
BO 147228	Retaining Sleeve-Glove Box Door Lock	1941-1946-1947 All
147233	Name Plate-Hood Side-Rear (Use 208771)	11,21
147235	Name Plate-Hood Side-Rear (Use 208739)	12,14,15,17,22,24,25,27
C 147236	Finish Molding-Windshield-Lower-Grained	10T,10P,11 thru 17,18P,10-18 Cab-CabPu
C 147237	Finish Molding-Windshield-Lower-Painted	11 thru 17,20 thru 27
C 147240	Finish Molding-Windshield-Upper-RH-Grained	10T,10P,11 thru 17 exc Cv,18P,10-18 Cab-CabPu
C 147241	Finish Molding-Windshield-Upper-LH-Grained	10T,10P,11 thru 17 exc Cv,18P,10-18 Cab-CabPu
C 147242	Finish Molding-Windshield-Upper-RH-Painted	11 thru 17 exc CvSed,20 thru 27
C 147243	Finish Mldg-Windshield-Upper-LH-Painted (Use 204691)	11 thru 17 exc CvSed 20 thru 27
C 147249	Finish Molding-Windshield-Upper-LH-Grained	10 CvSed
C 147256	Finish Mldg-Door Window-RH	1941 CvSed
C 147257	Finish Mldg-Door Window-LH	1941 CvSed
BO 147262	Ornament Assy-F Door Finish Mldg Valance-Front	12-14 2Sed-3Cpe-ClubCpe
BO 147263	Ornament Assy-F Door Finish Mldg Valance-Front	12-14 Sed
BO 147264	Ornament Assy-F Door Finish Mldg Valance-Rear	12-14 2Sed-3Cpe-ClubCpe
BO 147265	Orn Assy-F Door Finish Mldg Valance-Rear & Rear Door	12-14 Sed
BO 147266	Clip-Molding	10,1942-1946-1947 All
BO 147267	Clip-Molding	11 thru 18,21 thru 28,52,54,172,174
BO 147268	Escutcheon Assy-Inside Handle	12-14 2Sed,12 thru 17 Sed-ClubCpe
BO 147268	Escutcheon Assy-Door Inside Handle	12,14,15,17
BO 147268	Escutcheon Assy-Door Window Reg Handle	12-14-17 Sed
BO 147268	Escutcheon Assy-Door Wing Reg Handle	15
147269	Use 209661	
BO 147270	Handle Assy-Quarter Window Reg	12 thru 17 Sed-ClubCpe
BO 147270	Handle Assy-Door Wing Regulator	12,14,15,17
BO 147271	Handle-Door Inside (Use 204250)	12,14,15,17
147272	Handle Assy-Qtr Window Reg (Use 204254)	12-14 2Sed
147272	Handle Assy-Door Window Reg (Use 204254)	12,14,15,17
BO 147274	Handle Assy-Quarter Window Regulator	10P-11 5Sed,11 ClubCpe
147274	Handle Assy-Door Wing Regulator (Use 204259)	10P-11 CvSed
BO 147275	Handle-Door Inside	10,11,18,20,21,28,51,53,58,171,173,178
BO 147276	Handle Assy-Quarter Window Regulator	10-11 2Sed,10 UCc
BO 147276	Handle Assy-Door Window Regulator	10-11-18 exc Sed
BO 147278	Pin-Door Inside & Window Reg Handle	1941 thru 1950 All exc 484-494-502-504 CvBro
BO 147279	Shim-Regulator Handle	12-14 exc CvSed,10-11CvSed,482,484,492,494,502,504
BO 147279	Spacer-Radio Antenna Control Knob Escutcheon	1948-1949-1950 with Radio
BO 147292	Brkt-Compt Panel to Seat Tray	1941 CvSed
BO 147296	Knob-Handy Shift Lever	12,14,15,17
BO 147297	Knob-Handy Shift Lever	10,11,18
BO 147297	Knob-Bonnet Lock Handle	10 thru 18
147305	Door Assy-Deck (Use 206763)	10-11 3Cpe-ClubCpe-CvSed-UCcpe
147307	Door Assy-Deck (Use 206763)	12-14-15 3Cpe-ClubCpe-CvSed
C 147313	Extension Assy-Rear Compt Panel Shelf	1941-1942 3Cpe-UCcpe,1946-1947 3Cpe
C 147327	Panel Assy-Underbody-Prime	1941-1942-1946-1947 Cab-CabPu
C 147328	Panel Assy-Underbody-Prime	1941 3Cpe-UCcpe
C 147330	Panel Assy-Underbody-Prime	1941 ClubCpe
C 147390	Reinforcement-R Panel Corner	51 thru 54,171 thru 174
BO 147394	Handle Assy-Rear Compt Door-Less Cylinder	1941-1942-1946-1947 All
BO 147401	Hinge-Locker Box Door-Door Half-Inner	1941 thru 1947 All
BO 147402	Hinge-Locker Box Door-Door Half-Outer	1941 thru 1947 All
*BO 147403	Hinge & Pin Assy-Locker Box Door-Body Half	1941 thru 1947 All
BO 147404	Bracket-Locker Box Door Support	1941 thru 1947 All
BO 147409	Rivet-Cowl Ventilator Operating Handle	1941 thru 1950 All
147411	Handle Assy-Cowl Ventilator Operating (Use 204411)	1941 All
C 147420	Louver-Radiator Upper-RH	1941 exc Del
C 147421	Louver-Radiator Upper-LH	1941 exc Del
*C 147422	Louver-Radiator Lower-RH	1941 All
*C 147423	Louver-Radiator Lower-LH	1941 All
BO 147424	Extension-Hood Top Ornament	10,11,18
C 147430	Stone Protector-Rear Fender-RH-Used Without Running Boards	1941 All
C 147431	Stone Protector-Rear Fender-LH-Used Without Running Boards	1941 All
BO 147434	Grille-Instrument Panel	1941 All
*BO 147435	Grille-Instrument Panel-Second Type	10,11,18
BO 147440	Screen-Inst Panel Grille-For Grained Panel	1941 All
BO 147442	Screen-Inst Panel Grille-For Green Panel	1941 All
BO 147445	Locker Box Assembly-LHD	1941 thru 1947 All
BO 147446	Locker Box Assembly-RHD	1941-1942 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 147489	Silencer-Hood Rear Reinf	1941-1942 exc Del,1946-1947 All
BO 147490	Check-Front Door	1941 All
BO 147491	Bumper-Front Door Check	1941-1942-1946-1947 All
BO 147495	Door Check-Rear	1941-1942 Sed-Carryall,1942-1946-1947 Front All
147499	Rim-Headlamp Lens-Second Type (Use 206499)	10 thru 18,20,21,28,1946 All
BO 147500	Ash Receiver Assy-Inst Panel-Grained	10T,10P,11,18P,10C,18C,14 Station
147501	Ash Receiver Assy-Inst Panel-Painted (Use 208646)	11 thru 17
BO 147513	Bumper-Ash Receiver Cover	1941-1942-1946-1947 All
BO 147514	Retainer-Ash Receiver Knob	1941-1942-1946-1947 All
BO 147515	Knob-Inst Panel Ash Receiver	1941 All
BO 147532	Gasket-Rear Compt Door Hinge-Body Half	10 thru 17,18P
BO 147533	Gasket-Rear Compt Door Hinge-Door Half	1941-1942 All,51,52,53,54,171 thru 174
147537	Silencer-Underbody Panel-Center	1946-1947 All
147541	Name Plate-Rear Compt Door (Use 147542)	14,15,17,24,25,27
BO 147542	Name Plate-Rear Compt Door	12,22
BO 147543	Name Plate-Rear Compt Door	10P,11,18P,10C,UCo-UCpe
C 7545	Panel-Rear-Upper-Prime	1941-1942 CvSed,1946-1947 CvBro
BO 147554	Hinge & Cover Plate Assy-Front Door-Body Half Upper-RH	1941 exc Del,1942 Cab-CabPu,58,178
BO 147555	Hinge & Cover Plate Assy-Front Door-Body Half Upper-LH	1941 exc Del,1942 Cab-CabPu,58,178
BO 147558	Hinge-Front Door-Door Half Upper-RH	1941 exc Del,1942 Cab-CabPu,58,178
BO 147559	Hinge-Front Door-Door Half Upper-LH	1941 exc Del,1942 Cab-CabPu,58,178
BO 147562	Hinge-Front Door-Body Half Lower-RH	1941 exc Del,1942-1946-1947 Cab-CabPu
BO 147563	Hinge-Front Door-Body Half Lower-LH	1941 exc Del,1942-1946-1947 Cab-CabPu
BO 147564	Hinge-Front Door-Door Half Lower-RH	1941 exc Del,1942-Cab-CabPu,58,178
BO 147565	Hinge-Front Door-Door Half Lower-LH	1941 exc Del,1942 Cab-CabPu,58,178
147568	Hinge-Rear Door-Body Half Upper-RH (Use 204568)	1941 Sed-Carryall
BO 147569	Hinge-Rear Door-Body Half Upper-LH	1941 Sed-Carryall
BO 147570	Hinge-Rear Door-Door Half Upper-RH	1941-1942 Sed-Carryall,1946-1947 Sed
BO 147571	Hinge-Rear Door-Door Half Upper-LH	1941-1942 Sed-Carryall,1946-1947 Sed
BO 147576	Hinge & Cover Plate Assy-Rear Door-Body Half Lower-RH (Use 203576)	1941 Sed-Carryall
147577	Hinge & Cover Plate Assy-Rear Door-Body Half Lower-LH (Use 203577)	1941 Sed-Carryall,1946 Sed
BO 147580	Hinge-Rear Door-Door Half Lower-RH	1941-1942 Sed-Carryall,1946-1947 Sed
BO 147581	Hinge-Rear Door-Door Half Lower-LH	1941-1942 Sed-Carryall,1946-1947 Sed
BO 147582	Tapping Plate-F Door Hinge-Door Half Upper	1941 exc Del,1946-1947 All
BO 147583	Tapping Plate-Rear Door Hinge-Door Half Upper	1941-1942 Sed-Carryall,1946-1947 Sed
C 147592	Floor Board-CabPu-Outer-RH	10-20 CabPu
C 147593	Floor Board-CabPu-Outer-LH	10-20 CabPu
C 147594	Floor Board-CabPu-Outer-RH	18-28 CabPu,58 CabPu
C 147595	Floor Board-CabPu-Outer-LH	18-28 CabPu,58 CabPu
C 147596	Floor Board-CabPu-Center	10-20 CabPu
C 147598	Skid Strip-Pickup Box	10-20 CabPu
C 147599	Skid Strip-Pickup Box	18-28 CabPu,58 CabPu
C 147617	Cross Sill Assy-Rear	1941-1942-1946 CabPu
BO 147630	Friction Spring-RH Rear Door	1941-1942 Sedan
BO 147631	Friction Spring-LH Rear Door	1941-1942 Sedan
C 147640	Finish Mldg Assy-Front Door Window-RH-Wing Ventilator	10T 5Sed,10P Sed With Tan Trim 10Sp
C 147641	Finish Mldg Assy-Front Door Window-LH-Wing Ventilator	10T 5Sed,10P Sed With Tan Trim,10Sp
C 147642	Finish Mldg Assy-Front Door Window-RH-Sliding Window	10T Sedan
C 147643	Finish Mldg Assy-Front Door Window-LH-Sliding Window	10T Sedan
C 147652	Finish Mldg Assy-Door Window-RH-With Gray Trim	10T 3Cpe-ClubCpe
C 147653	Finish Mldg Assy-Door Window-LH-With Gray Trim	10P 3Cpe-ClubCpe
C 147658	Finish Mldg Assy-Rear Door Window-RH	10 Sed
C 147659	Finish Mldg Assy-Rear Door Window-LH	10 Sed
C 147660	Finish Mldg Assy-Rear Door Window-RH	15-17 Sed
C 147661	Finish Mldg Assy-Rear Door Window-LH	15-17 Sed
C 147665	Finish Mldg Assy-Rear Door Window-LH-With Gray Trim	10P Sedan
C 147670	Finish Mldg-Quarter Window-RH	12-14-17 Sedan
C 147672	Finish Mldg-Quarter Window-RH-With Tan Trim	10P 5Sed
C 147680	Finish Mldg-Quarter Window-RH-With Gray Trim	10P 2Sed
C 147681	Finish Mldg-Quarter Window-LH-With Gray Trim	10P 2Sed
C 147690	Finish Mldg-Quarter Window-RH	12-12-14 Club Cpe
*C 147699	Pickup Box Assy-RHD	18-28-58-178 CabPu
C 147700	Pickup Box Assembly	10-20 CabPu
*C 147701	Pickup Box Assembly-LHD	18-28-58-178 CabPu
C 147704	Side Panel-Pickup Box-RH	18-28-58-178 CabPu
C 147705	Side Panel-Pickup Box-LH	18-28-58-178 CabPu

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 147710	Molding-F Door Window Reveal-RH	1941-1942 2Sed,17-27 Sed,1946-1947 Bro
C 147711	Molding-F Door Window Reveal-LH	1941-1942 2Sed,17-27 Sed,1946-1947 Bro
C 147712	Molding-F Door Window Reveal-RH	1941-1942-1946-1947 Sed exc 17-27
C 147713	Molding-F Door Window Reveal-LH	1941-1942-1946-1947 Sed exc 17-27
C 147714	Molding-Rear Door Window-RH	1941-1942-1946-1947 Sed
C 147715	Molding-Rear Door Window-LH	1941-1942-1946-1947 Sed
C 147716	Molding-Qtr Window Reveal-RH	1941-1942-1946-1947 Sed
C 147717	Molding-Qtr Window Reveal-LH	1941-1942-2Sed-UCo,1946-1947 Bro
C 147718	Molding-Qtr Window Reveal-RH	1941-1942 2Sed-UCo,1946-1947 Bro
C 147719	Molding-Qtr Window Reveal-LH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 147720	Molding-Door Window Reveal-RH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 147721	Molding-Door Window Reveal-LH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 147722	Molding-Quarter Window Reveal-RH	1941-1942 3Cpe-ClubCpe-UCpc,1946-1947 3Cpe-ClubCpe
C 147723	Molding-Quarter Window Reveal-LH	10,21 thru 28
147724	Clip-Molding (Use 134296)	
147725	Use 134296	
BO 147726	Check Arm Assy-Rear Compt Door	1941-1942 All,51,52,53,54,171 thru 174
BO 147728	Brkt-Compt Door Check Arm-Body Half	1941-1942 All,51,52,53,54,171 thru 174
147730	Lock Assy-Front Door-RH (Use 204730)	1941 All
BO 147731	Lock Assy-Rear Door-LH	1941 Sed-Carryall
147733	Lock Assy-Front Door-LH-Rear Door-RH(Use 204733)	1941 All
C 147738	Cover Plate-Box to Running Board-RH	18-28 CabPu,58 CabPu
C 147739	Cover Plate-Box to Running Board-LH	18-28 CabPu,58 CabPa
BO 147744	Scuff Plate-Rear Door-RH	10-20 Sed
147745	Scuff Plate-Rear Door-LH (Use 147747)	10-20 Sed
BO 147746	Scuff Plate-Rear Door-RH	11-12-14-21-22-24 Sed-Station
BO 147747	Scuff Plate-Rear Door-LH	11-12-14-21-22-24 Sed-Station
BO 147750	Scuff Plate-Rear Door-RH	17-27 Sed
BO 147751	Scuff Plate-Rear Door-LH	17-27 Sed
BO 147753	Brkt-Rear Cushion Retainer to Underbody	1941-1942 Sed-2Sed-UCo-ClubCpe-CvSed, 1946-1947 exc 3Cpe-Cab-CabPu
BO 147754	Bolt-Rear Compartment Tire Clamp	1941-1942-1946-1947 All
BO 147759	Link-Rear Compt Door Latch	1941-1942 Sed-2Sed-UCo-CA,1946-1947 Bro-Sed
BO 147760	Link-Rear Compt Door Latch	1941-1942 ClubCpe-3Cpe-UCpe-CvSed,1946-1947 3Cpe-ClubCpe-CvBro
BO 147761	Lever-Rear Compt Door Latch Operating	1941-1942 All,51,52-53-54,171 thru 174
BO 147762	Rivet-Compt Door Latch Clamping Lever	1941-1942 All
BO 147763	Bracket-Rear Compt Door Latch Clamp	1941-1942 All,51,52,53,54,171 thru 174
147766	Clamping Lever & Brkt Assy-Compt Door Latch-RH (Use 203766)	
147767	Clamping Lever & Brkt Assy-Compt Door Latch-LH (Use 203767)	1941-1942 All
BO 147770	Reinforcement-Rear Compt Door Lamp	1941-1942-1946-1947 All
BO 147774	Weatherstrip-Quarter Window	10T-20T Sed,18P,28P
BO 147786	Suppressor-Distributor	1941 All
BO 147790	Weatherstrip-Quarter Window	1941-1942-1946-1947 3Cpe,10-20 ClubCpe-UCpe-UCpe,51-53-171-173 ClubCpe
147801	Speedometer Assy-Miles (Use 209020)	1941-1942 All
BO 147802	Speedometer Assy-Metric	1941-1942 All
F 147803	Gauge. Assy-Fuel	1941-1942 All
F 147804	Gauge Assy-Water	1941-1942 All
F 147811	Indicator Assy-Oil and Generator	1941 All
BO 147812	Clock Assy-Locker Box Door-Mechanical	10,11,18
BO 147813	Clock Assy-Locker Box Door-Electric	12,14,15,17
BO 147814	Clock Assy-Locker Box Door-Electric	10,11,18
BO 147816	Dial-Inst Panel Grille	11
BO 147817	Backing Plate-Inst Panel Grille Dial	1941 All
BO 147819	Dial-Instrument & Speedometer-LHD-Miles	10,11,18
BO 147821	Dial-Inst & Clock-LHD	10,11,18
BO 147822	Dial-Inst & Clock-RHD	10,11,18
BO 147823	Dial-Inst & Speedometer-RHD-Miles	10,11,18
BO 147824	Dial-Inst & Speedometer-RHD-Metric	10,11,18
BO 147825	Dial-Inst & Speedometer-LHD-Miles	12,14,15,17
BO 147826	Dial-Inst & Speedometer-LHD-Metric	12,14,15,17
BO 147827	Dial-Inst & Speedometer-RHD-Miles	12,13,15,17
BO 147829	Dial-Instrument & Clock-LHD	12,14,15,17
BO 147830	Dial-Instrument & Clock-RHD	12,14,15,17
BO 147831	Dial-Instrument Panel Grille	12
BO 147832	Dial-Instrument Panel Grille	14,15,17
BO 147833	Hole Plug-Speedometer,Clock and Inst Bezel	10,11,18
147834	Use 200416	
147835	Use 200417	
BO 147838	Bracket-Starter & Lighting Switch Push Button	1941-1942 exc Del,1946-1947 All
BO 147839	Pin-Starter & Lighting Switch Push Button	1941-1942 exc Del,1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 147840	Bracket-Steering Gear Jacket Tube	10T,10P,11,10 UCo-UCpe,20T,20P,53,171,173,178 Station
BO 147841	Bracket-Steering Gear Jacket Tube	12,14,17-27 5Sed,22,24,52,54,172,174
BO 147842	Bracket-Steering Gear Jacket Tube-Lac	10-18-20-28 Cab-CabPu,18 7Sed-Carryall, 1946-
BO 147843	Bracket-Steering Gear Jacket Tube	1947 Cab-CabPu
BO 147845	Cap-Jacket Tube Bracket-Use Without Indicator	17-27 7Sed
147846	Push Button-Starter Switch (Use 204846)	12,14,22,24,52,54,172,174
147847	Push Button-Lighting Switch (Use 204847)	1941 exc Del.
BO 147850	Ornament-Cowl Vent Cover	1941 exc Del
BO 147851	Ornament-Cowl Vent Cover	10,11,18,20,21,28,1946-1947 All
BO 147852	Seal Washer-Cowl Vent Cover Ornament	12,14,15,17,22,24,25,27
147858	Use 147861	1941-1942 All
147859	Welt-Rear Fender-Chrome (Use 147861)	14,15,17,11-21 Station
C 147861	Welt-Rear Fender-Rubber	10T,10P,12,18P,10 UCo,11 exc Station,21 Station
BZ 147864	Bracket and Arm Assy-Rear License	10T,10P,11,18P,10 UCo-UCpe
BZ 147869	Bracket and Arm Assy-Rear License Plate-Enamel	10T,10P,11,18P,10 UCo-UCpe,1946-1947 All
BO 147870	Ornament-Hood Top	10 exc Del,11,18
147871	Ornament-Hood Top-Export (Use 147870)	10 exc Del,11,18
BO 147872	Ornament-Hood Top-Lower	12,14,15,17
BO 147873	Ornament-Hood Top-Lower-Export	12,14,15,17
BO 147874	Ornament-Hood Top-Upper	12,14,15,17
BO 147879	Center Molding-Radiator Louver Panel	10 exc Del,11,18
BO 147880	Finish Plate-Lnst & Speedometer Dial-LHD	12,14,15,17
BO 147881	Finish Plate-Lnst & Speedometer Dial-RHD	12,14,15,17
BO 147882	Finish Plate-Inst & Clock Dial-LHD	12,14,15,17
C 147890	Finish Mldg Assy-Front Door Window-RH-Upper	11-12-14 2Sed
C 147891	Finish Mldg Assy-Front Door Window-LH-Upper	11-12-14 2Sed
C 147893	Finish Mldg Assy-F Door Wdo-Upper-LH	12-14 2Sed
147896	Finish Mldg Assy-F Door Wdo-RH-Upper (Use 147898)	11-12-14 Sed
C 147898	Finish Mldg Assy-F Door Wdo-Upper-RH	12-14 Sed
C 147899	Finish Mldg Assy-F Door Wdo-Upper-LH	12-14 Sed
C 147902	Finish Mldg Assy-Door Window-RH-Upper	11-12-14 3Cpe-ClubCpe
C 147908	Finish Mldg Assy-Rear Door Window-RH-Upper	11-12-14 Sed
C 147909	Finish Mldg Assy-Rear Door Window-LH-Upper	11-12-14 Sed
C 147910	Finish Mldg Assy-Rear Door Wdo-Upper-RH	12-14 Sed
BZ 147917	Guard-Front License Plate	10P,11 exc Station
BZ 147918	Guard-Front License Plate	11,12,14,15,17
BZ 147919	Retainer-Front License Plate Guard Bolt	10P,11 thru 17
C 147920	Drip Molding-Roof Panel-RH	1941-1942 UCo-2Sed,1946-1947 Bro
C 147921	Drip Molding-Roof Panel-LH	1941-1942 UCo-2Sed,1946-1947 Bro
C 147922	Drip Molding-Roof Panel-RH	1941-1942 Sed exc 17-27,1946-1947 Sed
C 147923	Drip Molding-Roof Panel-LH	1941-1942 Sed exc 17-27,1946-1947 Sed
C 147924	Drip Molding-Roof Panel-RH	17-18-27 Sed,18 Carryall
C 147925	Drip Molding-Roof Panel-LH	17-18-27 Sed,18 Carryall
C 147926	Drip Molding-Roof Panel-RH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
C 147927	Drip Molding-Roof Panel-LH	1941-1942 3Cpe-ClubCpe-UCpe,1946-1947 3Cpe-ClubCpe
BO 147930	Cover Assy-Inst Panel Radio Hole	11,12,14,15,17
BO 147931	Escutcheon Assy-Inst Panel Radio	11,12,14,15,17
BO 147932	Cover-Lnst Panel Radio Hole	10T,10P,11 thru 17,18P,10C exc Del
BO 147933	Escutcheon Assy-Inst Panel Radio	10T,10P,11 thru 17,18P,10C exc Del
BZ 147937	Guard Assy-Front License Plate	10P,11 exc Station
BZ 147938	Guard Assy-Front License Plate	11 thru 17
BZ 147939	Clamp-Front License Plate Guard	12 thru 17
147942	Stone Guard Assy-Rear Bumper (Use 208941)	12,15,17,22,24,25,27,11-14-21 exc Station,51,53,171,173
BZ 147944	Support-Stone Guard to Frame Bar	1941-1942 exc Cab-CabPu-Del-Station,51 thru 54,171 thru 17
*C 147946	Stone Guard Assy-Rear Bumper	10,11,18P,20
BZ 147947	Bumper-F License Plate Bracket Support	11 thru 17
BZ 147949	Brkt & Clamp Assy-Front License Plate	11 thru 17
147951	Bumper Bar-Front-Outside (Use 206704 & 206222)	11,12,14
C 147952	Frame Bar Assy-Front Bumper-RH	11 thru 17
C 147953	Frame Bar Assy-Front Bumper-LH	11 thru 17
147954	Bumper Bar-Front Outside (Use 206704 & 206222)	12,14,15,17
C 147959	Fender Guard & Cross Bar Kit-Rear Bumper	12,11-14 exc Station
147961	Bumper Bar-Rear-Outside (Use 206961 & 206223)	11-12-14-21 thru 27 exc Station,
147962	Frame Bar Assy-Rear Bumper-RH (Use 206962)	11 thru 17-21 thru 27 exc Station
147963	Frame Bar Assy-Rear Bumper-LH (Use 206963)	11 thru 17-21 thru 27 exc Station
147964	Bumper Bar-Rear-Outside (Use 206961)	15,17
C 147966	Frame Bar Assy-Rear Bumper-RH	10T,10P,10 UCo-UCpe,11,18P,20
C 147967	Frame Bar Assy-Rear Bumper-LH	10T,10P,10 UCo-UCpe,11,18P,20

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 147969	Clamp-F Bumper License Plate Guard	10P,11
BZ 147970	Wing-Front and Rear Bumper Bar-RH	11 thru 17,21 thru 27
BZ 147971	Wing-Front and Rear Bumper Bar-LH	11 thru 17,21 thru 27
BZ 147974	Guard-Front RH and Rear LH Bumper	11 thru 17,21 thru 27
BZ 147975	Guard-Front LH and Rear RH Bumper	11 thru 17,21 thru 27
BZ 147976	Guard Assy-Front RH and Rear LH Bumper	12,14 exc Station,15,17,11
BZ 147977	Guard Assy-Front LH and Rear RH Bumper	12,14 exc Station,15,17,11
C 147983	Cross bar-F Bumper Fender Guard	10T,10C11 thru 18
C 147984	Crossbar-Rear Bumper Fender Guard	12,15,17,11-14 exc Station
C 147985	Crossbar-Rear Bumper Fender Guard	10T,10P,11,10 UCo-UCpe,18P,20
BZ 147987	Clamp-Bumper Fender Guard Crossbar	10P,11 thru 17,10T,10C,18
BZ 147990	Bracket Assy-Front License Plate	11 thru 17
BZ 147991	Bolt-Bumper Fender Guard	11 thru 17,21 thru 27
BZ 147992	Spacer-Bumper Fender Guard	11 thru 17,21 thru 27
BZ 147993	Guard-Bumper-Front	10P,11,10 Del
BZ 147994	Guard Assy-Rear Bumper-RH	10P,11
BZ 147995	Guard Assy-Rear Bumper-LH	10P,11
BZ 147997	Guard-Front Bumper	10T,10C,18,20T,20C,28,58,178
BO 148136	Gasket-Spot Light Lens	1941 All
BO 148138	Reflector-Spot & Fog Light	1941 All
BO 148140	Rim-Spot & Fog Light	1941 All
BO 148141	Screw-Spot & Fog Light Rim	1941 All
BO 148142	Lens-Fog Light-Amber & Clear	1941 All
BO 148143	Gasket-Fog Light Lens	1941 All
BO 148144	Brkt Assy-Fog Light	1941 All
BO 148146	Grip-Spot Light Reflector Spring	1941 All
BO 148149	Pad-F Door Arm Rest Cover	10P,11,12,14,18 Sedan,20,21,22,24,1946-1947 CvBro-Cab-CabPu
148151	Use 148728	
BO 148152	Chain Hsg & Arm Assy-W/S Cleaner-RH	1941 All,1946 exc Cab-CabPu
BO 148153	Chain Hsg & Arm Assy-W/S Cleaner-LH	1941 All,1946 exc Cab-CabPu
BO 148154	Motor Assy-W/Shield Cleaner	1941-1942-1946 All
148155	Control Assy-Windshield Cleaner (Use 204175)	10 thru 18
BO 148159	Gasket-Windshield Cleaner Control	1941 thru 1947 All
BO 148160	Link-Windshield Cleaner Control	1941-1942 All
148162	Use 148729	
BO 148163	Tubing-W/Shield Cleaner-Use With Vacuum Pump	1941 thru 1947 All
BZ 148166	Guard Kit-Front License Plate	10P,11
BZ 148167	Guard Kit-Front License Plate	11,12,14,15,17
BO 148170	Remote Control Assy-F Door Lock-RH	1941 2Sed-3Cpe-ClubCpe-UCo-UCpe,17,18P
BO 148171	Remote Control Assy-F Door Lock-LH	1941 2Sed-3Cpe-ClubCpc-UCo-UCpe,17,18P
BO 148172	Remote Control Assy-F Door Lock-RH	10-11-12-14-18 Sed 10-18 Cab-CabPu
BO 148173	Remote Control Assy-F Door Lock-LH	10-11-12-14-18 Sed,10-18 Cab-CabPu
BO 148176	Remote Control Assy-Rear Door-RH	1941 Sed-Carryall
BO 148177	Remote Control Assy-Rear Door-LH	1941 Sed-Carryall
BO 148178	Brkt-Spot Light Outside-RH Mtg	1941 All
BO 148179	Brkt-Spot Outside-LH Mtg	1941 All
BO 148180	Lens-Speedometer, Clock & Instrument-RH	1941 All
BO 148181	Lens-Speedometer, Clock & Instrument-LH	1941 All
BO 148182	Bezel-Speedometer, Clock & Instrument-RH	1941 All
BO 148183	Bezel-Speedometer, Clock & Instrument-LH	1941 All
BO 148184	Lens-Instrument Panel Grille	1941 All
BO 148185	Clip-Instrument Panel Grille	1941 All
BO 148189	Clamp-Cigar Lighter Base	1941-1942 exc Del
BO 148193	Knob-Cigar Lighter	1941 exc Del
BO 148197	Wire Assy-Cigar Lighter	1941-1942 exc Del
BO 148200	Molding-Front End Panel Belt-RH	10T,10P,10C exc Del,20P,53,58,171,173,178
BO 148201	Molding-Front End Panel Belt-LH	10T,10P,10C exc Del,20P,53,58,171,173,178
BO 148202	Molding-Front End Panel Belt-RH	11 thru 18,21 thru 28,52,54,172,174
BO 148203	Molding-Front End Panel Belt-LH	11 thru 18,21 thru 28,52,54,172,174
C 148204	Molding-Quarter Panel Belt-RH	10-20 UCo-2Sed
C 148205	Molding-Quarter Panel Belt-LH	10-20 UCo-2Sed
C 148206	Molding-Quarter Panel Belt-RH	10-20 Sedan
C 148207	Molding-Quarter Panel Belt-LH	10-20 Sedan
C 148208	Molding-Quarter Panel Belt-RH	10-20 ClubCpe-3Cpe-UCpe,51-53-171-173,3Cpe-ClubCpe
C 148209	Molding-Quarter Panel Belt-LH	10-20 ClubCpe-3Cpe-UCpe,51-53-171-173,3Cpe-ClubCpe
C 148210	Molding-Quarter Panel Belt-RH	11-12-14-21-22-24 2Sed
C 148211	Molding-Quarter Panel Belt-LH	11-12-14-21-22-24 2Sed
C 148212	Molding-Quarter Panel Belt-RH	11 thru 18-21 thru 28 Sed,18 Carryall
C 148213	Molding-Quarter Panel Belt-LH	11 thru 18-21 thru 28 Sed,18 Carryall
C 148214	Molding-Quarter Panel Belt-RH	11 thru 15-21 thru 25 3Cpe-ClubCpe,52-54-172-174 3Cpe-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 148215	Molding-Quarter Panel Belt-LH	11 thru 15-21 thru 25 3Cpe-ClubCpe,52-54-172-174 3Cpe-ClubCpe
BO 148216	Retainer-Belt Mldg	20P-20D,51,53,58,171,173,178
BO 148217	Retainer-Belt Molding	10T,10P,10C exc Del
148218	Use 148217	
148219	Retainer-Qr Panel Belt Mldg-Rear (Use 148217)	10 3Cpe-ClubCpe-UCpe-CvSed
148222	Use 200176	
148223	Use 200177	
C 148224	Belt Molding-Front Door-RH	10T-10P-20T-20P exc Sed,10C UCo-UCpe,51-53-171-173 exc Sed
C 148225	Belt Molding-Front Door-LH	10T-10P-20T-20P exc Sed,10C UCo-UCpe,51-53-171-173 exc Sed
C 148226	Belt Molding-Front Door-RH	11 thru 15-21 thru 25 exc Sed,17,18P,27,52-54-172-174 exc Sed
C 148227	Belt Molding-Front Door-LH	11 thru 15-21 thru 25 exc Sed,17,18P,27,52-54-172-174 exc Sed
C 148228	Belt Molding-Front Door-RH	10-20 Sed-Cab-CabPu,51-53-171-173 Sed,58,178
C 148229	Belt Molding-Front Door-LH	10-20 Sed-Cab-CabPu,51-53-171-173 Sed,58,178
C 148230	Belt Molding-Front Door-RH	11-12-14-21-22-24-25 Sed,18-28 Cab-CabPu,52-54-172-174 Sed
C 148231	Belt Molding-Front Door-LH	11-12-14-21-22-24-25-Sed,18-28 Cab-CabPu,52-54-172-174 Sed
C 148232	Belt Molding-Rear Door-RH	10 Sed
C 148233	Belt Molding-Rear Door-LH	10 Sed
C 148234	Belt Molding-Rear Door-RH	11-12-14-17 Sed,18P
C 148235	Belt Molding-Rear Door-LH	11-12-14-17 Sed,18P
148236	Use 148238	
148237	Retainer-Quarter Panel Belt Mldg-Rear(Use 148238)	11-12-13-15 3Cpe-ClubCpe,11-12-14 CvSed
BO 148238	Retainer-Belt Molding	11 thru 17,18P,18 Cab-CabPu
BO 148244	Brkt-Front Door Pull to Handle	15,17,25,27
BO 148246	Screen-Cowl Ventilator	1941-1942 All exc Del,1946-1947 All
BO 148247	Trimstick-Rear Body Pillar	1941-1942 CvSed,1946-1947 CvBro
BO 148248	Molding-Quarter Panel Belt-RH	10-20 CvSed,51-171 CvBro
BO 148249	Molding-Quarter Panel Belt-LH	10-20 CvSed,51-171 CvBro
BO 148250	Lamp Assembly-Tail-RH-6 Volt	10-11 Sed-2Sed,10 UCo,18P
BO 148251	Lamp Assembly-Tail-LH-6 Volt	10-11 Sed-2Sed,10 UCo,18P
BO 148254	Lamp Assembly-Tail-RH-6 Volt	10-11 ClubCpe-3Cpe-CvSed,10 UCpe
BO 148255	Lamp Assembly-Tail-LH-6 Volt	10-11 ClubCpe-3Cpe-CvSed,10 UCpe
BO 148258	Molding-Quarter Panel Belt-RH	11-12-14-21-22-24 CvSed,54-174 CvBro
BO 148259	Molding-Quarter Panel Belt-LH	11-12-14-21-22-24 CvSed,54-174 CvBro
BO 148260	Lamp Assembly-Tail-RH-6 Volt	12-14-15 Sed-2Sed,13-17 Sed
BO 148261	Lamp Assembly-Tail-LH-6 Volt	12-14-15 Sed-2Sed,13-17 Sed
BO 148262	Wires Assy-Tail Lamp	1941-1942 Sed-2Sed-UCo-Carryall,1946-1947 Bro-Sed
BO 148263	Wires Assy- Tail Lamp	1941-1942 ClubCpe-3Cpe-CvSed,UCpe,1946-1947 3Cpe-ClubCpe-CvBro
BO 148264	Lamp Assy-Tail-RH-6 Volt	12-14-15 ClubCpe-3Cpe-CvSed
BO 148265	Lamp Assy- Tail-LH-6 Volt	12-14-15 ClubCpe-3Cpe-CvSed
BO 148270	Lens-Tail Lamp-RH	10T,10P,11,18P,10 UCo-UCpe
BO 148271	Lens-Tail Lamp-LH	10T,10P,11,18P,10 UCo-UCpe
BO 148272	Gasket-Tail Lamp Lens	10T,10P,11,18P,10 UCo-UCpe
148273	Gasket-Tail Lamp Lens-LH (Use 148272)	10T,10P,11,18P,10 UCo-UCpe
BO 148274	Gasket-Tail Lamp Base-RH-Black	10-11 Sed-2Sed,UCo,18P
148275	Gasket-Tail Lamp Base-LH-Black (Use 148274)	10-11 Sed-2Sed,UCo,18P
BO 148276	Gasket-Tail Lamp Base-RH-Red	10-11 3Cpe-ClubCpe-UCpe-CvSed
148277	Gasket-Tail Lamp Base-LH-Red (Use 148276)	10-11 3Cpe-ClubCpe-UCpe-CvSed
BO 148278	Lens-Tail Lamp-RH	12 thru 17
BO 148279	Lens-Tail Lamp-LH	12 thru 17
BO 148280	Gasket-Tail Lamp Lens-RH	12 thru 17
148281	Gasket-Tail Lamp Lens-LH (Use 148280)	12 thru 17
BO 148282	Gasket-Tail Lamp Base-RH-Black	12 thru 17 Sed-2Sed
BO 148283	Gasket-Tail Lamp Base-LH-Black	12 thru 17 Sed-2Sed
BO 148284	Gasket-Tail Lamp Base-RH-Red	12-14-15 3Cpe-ClubCpe-12-14 CvSed
BO 148285	Gasket-Tail Lamp Base-LH-Red	12-14-15 3Cpe-ClubCpe-12-14 CvSed
BO 148286	Bezel-Tail Lamp Lens-RH	10-11 Sed-2Sed,10 UCo,18P
BO 148287	Bezel-Tail Lamp Lens-LH	10-11 Sed-2Sed,10 UCo,18P
BO 148288	Bezel-Tail Lamp Lens-RH	10-11 3Cpe-ClubCpe-UCpe-CvSed
BO 148289	Bezel-Tail Lamp Lens-LH	10-11 3Cpe-ClubCpe-UCpe-CvSed
148290	Use 148576	
148291	Use 148577	
BO 148292	Bezel-Tail Lamp Lens-RH	12 thru 17 Sed-2Sed
BO 148293	Bezel-Tail Lamp Lens-LH	12 thru 17 Sed-2Sed
BO 148294	Bezel-Tail Lamp Lens-RH	12-14-15 3Cpe-ClubCpe-CvSed
BO 148295	Bezel-Tail Lamp Lens-LH	12-14-15 3Cpe-ClubCpe-CvSed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
148296	Use 148578	
148297	Use 148579	
BO 148298	Screw-Tail Lamp Base	1941 exc Cab-CabPu-Del
BO 148299	Stud-Tail Lamp Lens Bezel	1941 exc Cab-CabPu-Del
BO 148302	Terminal-Tail Lamp Wire-Socket End	1941-1942 All,1946-1947 All Pass Cars
148304	Name Plate-Hood Side-RH (Use 200469)	10 exc Del
148305	Name Plate-Hood Side-LH(Use 200469)	10 exc Del
BO 148306	Housing-Hood Side Lamp	10 exc Del
BO 148307	Gasket-Hood Side Lamp Lens	10 exc Del
BO 148308	Lens-Hood Side Lamp-RH	10 exc Del
C 148310	Molding-Hood Belt-RH	10 exc Del
C 148311	Molding-Hood Belt-LH	10 exc Del
C 148312	Molding-Hood Side-RH	10 exc Del
C 148313	Molding-Hood Side-LH	10 exc Del
BO 148315	Center Molding-Louver Panel	14,15,17
BO 148316	Center Molding-Louver Panel	12
BO 148317	Gasket-Hood Lamp Lens	11 thru 18
BO 148318	Housing-Hood Lamp-RH	11 thru 18
BO 148319	Housing-Hood Lamp-LH	11 thru 18
BO 148320	Lens-Hood Lamp-RH	11 thru 18
BO 148321	Lens-Hood Lamp-LH	11 thru 18
C 148322	Molding-Hood Belt-RH	11 thru 18
C 148323	Molding-Hood Belt-LH	11 thru 18
C 148324	Molding-Hood Side-Upper-RH	11 thru 18
C 148325	Molding-Hood Side-Upper-LH	11 thru 18
C 148326	Molding-Hood Side-Lower-RH	11 thru 18
C 148327	Molding-Hood Side-Lower-LH	11 thru 18
BO 148328	Clip-Hood Side Molding	11 thru 18
BO 148330	Ornament-Hood Side Molding-RH	11 thru 18
BO 148331	Ornament-Hood Side Molding-LH	11 thru 18
148338	Trim Clip-Front Floor Mat-Tan (Use 121040)	1941-1942 All
BO 148339	Trim Clip-Front Floor Mat-Gray	1941-1942 All
148340	Trim Clip-Front Floor Mat-Green (Use 121040)	1941-1942 All
BO 148344	Striker Assy-Door Lock-RH Front-LH Rear	1941 thru 1947 All
BO 148345	Striker Assy-Door Lock-LH Front-RH Rear	1941 thru 1947 All
BO 148347	Retainer-Front End Panel Belt Mldg	11 thru 18,21 thru 28,52,54,172,174
148350	License Lamp Assy-Rear Compt Door(Use 211087)	1941-1942-1946-1947 exc Cab-CabPu-Del
148351	Housing-License Lamp (Use 211087)	1941-1942-1946-1947 exc Cab-CabPu-Del
BO 148352	Lens-License Lamp	1941-1942 exc Cab-CabPu-Del,51 thru 54,171 thru 174,481,483,491,493,500
BO 148353	Gasket-License Lamp Lens	1941-1942 exc Cab-CabPu-Del,51 thru 54,171 thru 174,481,483,491,493,500
BO 148354	Retainer-License Lamp Lens	1941-1942 exc Cab-CabPu-Del,51 thru 54,171 thru 174,481,483,491,493,500
BO 148355	Screw-License Lamp Lens Retainer	1941-1942 exc Cab-CabPu-Del,51 thru 54,171 thru 174
BO 148356	Gasket-License Lamp Housing	1941-1942 exc Cab-CabPu-Del,51 thru 54,171 thru 174,481,483,491,493
C 148371	Roof Bow #1	1941-1942 Sed-2Sed-CA-UCo-Cab-CabPu,1946-1947 Bro-Sed-Cab-CabPu
C 148372	Roof Bow #2	10-11-12-14-20-21-22-24 Sed,1941-1942-1946-1947 Cab-CabPu-Sed
C 148373	Roof Bow #3	10-11-12-14-20-21-22-24 Sed,1946-1947 Sed
C 148374	Roof Bow #3 (#4 for 2Sed-UCo)	1941-1942 3Cpe-ClubCpe-UCpe-2Sed-UCo,1946-1947 Bro-3Cpe-ClubCpe
C 148375	Roof Bow #5 (#4 & 5 for 11-12-14-15 ClubCpe)	10T 5Sed,18P,11-12-14-15-21 thru 25 ClubCpe
C 148380	Roof Bow #4	10-11-12-14-20-21-22-24 Sed,1946-1947 Sed
C 148381	Roof Bow #5-#6	10P,11 thru 17 Sedan,1942 UCo-2Sed,20P-21 thru 27 Sed,1946-1947 Bro-Sed
C 148382	Roof Bow #6	10T Sed,18P
C 148383	Roof Bow #2	1941-1942 2Sed-UCo,1946-1947 Bro
C 148384	Roof Bow #3	1941-1942 2Sed-UCo,1946-1947 Bro
BO 148386	Tray & Cover Assy-Arm Rest Ash Receiver	10P-11 Sed-2Sed
BO 148388	Gasket-Arm Rest Ash Receiver Cover Plate	10P-11-12-14 Sed-2Sed
BO 148390	Guide-Arm Rest Ash Receiver Tray	10P-11 Sed-2Sed
BO 148391	Handle-Arm Rest Ash Receiver	10P-11 Sed-2Sed
C 148392	Trim Molding-Running Board-Top #1	10
C 148394	Trim Molding-Running Board-Top #2	10
C 148396	Trim Molding-Running Board-Top #3	10
C 148398	Trim Molding-Running Board-Top #4	10
BO 148400	Name Plate-Hood Side-RH	11 thru 18
BO 148401	Name Plate-Hood Side-LH	11 thru 18
BO 148402	Name Plate Assy-Hood Side-RH	11 thru 18
BO 148403	Name Plate Assy-Hood Side-LH	11 thru 18

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
		11 thru 18
BO 148404	Ornament-Hood Side Name Plate-RH	11 thru 18
BO 148405	Ornament-Hood Side Name Plate-LH	11 thru 18
BO 148406	Letter "H"-Hood Side Name Plate	11 thru 18
BO 148407	Letter "U"-Hood Side Name Plate	11 thru 18
BO 148408	Letter "D"-Hood Side Name Plate	11 thru 18
BO 148409	Letter "S"-Hood Side Name Plate	11 thru 18
BO 148410	Letter "O"-Hood Side Name Plate	11 thru 18
BO 148411	Letter "N"-Hood Side Name Plate	10
C 148412	Trim Molding-Running Board-Top-Outer	10
C 148414	Trim Molding-Running Board-Side	17,18
C 148420	Trim Molding-Running Board-Side-RH	17,18
C 148421	Trim Molding-Running Board-Side-LH	11,12,14,15,21 Station
C 148422	Trim Molding-Running Board Top-Outer-RH	11,12,14,15,21 Station
C 148423	Trim Molding-Running Board Top-Outer-LH	17,18
C 148424	Trim Molding-Running Board Top-Outer-RH	17,18
C 148425	Trim Molding-Running Board Top-Outer-LH	11,12,14,15,21 Station
C 148426	Trim Molding-Running Board Top-#1	17,18
C 148428	Trim Molding-Running Board Top-#1	11,12,14,15,21 Station
C 148430	Trim Molding-Running Board Top-#2	17,18
C 148432	Trim Molding-Running Board Top-#2	11,12,14,15,21 Station
C 148434	Trim Molding-Running Board Top-#3	17,18
C 148436	Trim Molding-Running Board Top-#3	11,12,14,15,21 Station
C 148438	Trim Molding-Running Board Top-#4	17,18
C 148440	Trim Molding-Running Board Top-#4	10 thru 18,21 Station
BO 148442	Clip-Running Board Trim Molding-Side	10 thru 18,21 Station
BO 148444	Clip-Running Board Trim Molding-Top #1-2-3-4	10T 2Sed,10 UCo,18P
C 148452	Door Assy-Front-RH	10T 2Sed,10 UCo,18P
148453	Door Assy-Front-LH (Use 148497)	10T Sed,10-18 Cab-CabPu
148456	Door Assy-Front-RH (Use 148500)	10T Sed,10-18 Cab-CabPu
148457	Door Assy-Front-LH (Use 148501)	10T 3Cpe-ClubCpe,10 UCpe
*C 148460	Door Assy-Front-RH	10T 3Cpe-ClubCpe,10 UCpe
*C 148461	Door Assy-Front-LH	10P-11-12-14 2Sed,18P
148464	Door Assy-Front-RH (Use 148496)	10P-11-12-14 2Sed,18P
148465	Door Assy-Front-LH (Use 148497)	10P-11-12-14 Sed
148468	Door Assy-Front-RH (Use 148500)	10P-11-12-14 Sed
148469	Door Assy-Front-LH (Use 148501)	10P-11-12-14-15 3Cpe-ClubCpe
148472	Door Assy-Front-RH (Use 148504)	10P-11-12-14-17 Sed
148481	Door Assy-Rear-LH (Use 148489)	10-11 Sed,18P
*C 148488	Door Assy-Rear-RH	10-11 Sed,18P
*C 148489	Door Assy-Rear-LH	
148493	Use 148489	10-11 2Sed,10 UCo,18P,10Sp 2Sed
*C 148496	Door Assy-Front-RH	10-11 2Sed,10 UCo,18P,10 SP 2Sed
*C 148497	Door Assy-Front-LH	10T Sed,10-18 Cab-CabPu,10 SP 5Sed
*C 148500	Door Assy-Front-RH	10T Sed,10-18 Cab-CabPu,10 SP 5Sed
*C 148501	Door Assy-Front-LH	10T-10P-10 Sp 3Cpe-ClubCpe,10 UCpe
*C 148504	Door Assy-Front-RH	10T-10P-10 Sp 3Cpe-ClubCpe,10 UCpe
*C 148505	Door Assy-Front-LH	1941-1942 All
BO 148510	Cover-F Floor Mat Steering Hole-Green	10T,18P,10C exc Del,18C
148511	Mat & Pad Assy-Front Floor-LHD (Use 201134)	10T,18P,10C exc Del,18C
148512	Mat & Pad Assy-Front Floor-RHD (Use 208601)	10T,11,10UCo-UCpe
148513	Mat & Pad Assy-Front Floor-LHD- Tan (Use 201134)	10P,11,10UCo-UCpe
148514	Mat & Pad Assy-Front Floor-RHD- Tan (Use 208601)	10P,11
C 148515	Mat & Pad Assy-Front Floor-LHD-Gray	10P,11
C 148516	Mat & Pad Assy-Front Floor-RHD-Gray	10P,11
148517	Mat & Pad Assy-Front Floor-LHD-Green (Use 207915)	12,14
148519	Mat & Pad Assy-Front Floor-LHD-Tan (Use 207921)	12,14
148521	Mat & Pad Assy-Front Floor-LHD-Gray (Use 207921)	12,14
148522	Mat & Pad Assy-Front Floor-RHD-Gray (Use 207922)	12,14
148523	Mat & Pad Assy-Front Floor-LHD-Green (Use 207921)	12,14
148524	Mat & Pad Assy-Front Floor-RHD-Green (Use 207924)	12,14,22,24,52,54,172,174
BO 148525	Insert-F. Floor Mat Carpet-RH	17-27 Sedan
BO 148535	Wire Assy-Qtr Cigar Lighter	11-12-14 Sed-2Sed,10-17-18 5Sed with Leather
BO 148542	Molding-Quarter Arm Rest	Trim
C 148546	Trim Retainer Assy-Body Header-RH	10-11-12-14 Sedan,1942 UCo-2Sed,1946-1947 Bro
C 148547	Trim Retainer Assy-Body Header-LB	10-11-12-14 Sedan,1942 UCo-2Sed,1946-1947 Bro
C 148550	Trim Retainer Assy-Front Pillar-RH	1941-1942 exc CvSed,1946-1947 exc CvBro
C 148551	Trim Retainer Assy-Front Pillar-LH.	1941-1942 exc CvSed,1946-1947 exc CvBro
C 148552	Trim Retainer Assy-Front Pillar-RH.	1941-1942 CvSed,1946-1947 CvBro
C 148553	Trim Retainer Assy-Front Pillar-LH	1941-1942 CvSed,1946-1947 CvBro
C 148556	Trim Retainer Assy-Rear Pillar-RH	1941-1942 Sedan-Carryall,1946-1947 Sed
C 148557	Trim Retainer-Rear Pillar-LH	1941-1942 Sedan-Carryall,1946-1947 Sed
C 148558	Trim Retainer Assy-Body Header-RH	10-11-12-14-20-21-22-24 Sed,1946 Sed
C 148559	Trim Retainer Assy-Body Header-LH	10-11-12-14-20-21-22-24 Sed,1946 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 148566	Trim Retainer Assy-Body Header-RH	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 ClubCpe-3Cpe
C 148567	Trim Retainer Assy-Body Header-LH	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 ClubCpe-3Cpe
BO 148568	Latch Assy-Locker Box Door	10 Del
BO 148576	Base Plate Assy-Tail Lamp-RH	10T,10P,11,10 UCo-UCpe,18P
BO 148577	Base Plate Assy-Tail Lamp-LH	10T,10P,11,10 UCo-UCpe,18P
BO 148578	Base Plate Assy-Tail Lamp-RH	12,14,15,17
BO 148579	Base Plate Assy-Tail Lamp-LH	12,14,15,17
BO 148580	Base Assy-Tail Lamp-RH	10T-10P-11 Sed-2Sed,10 UCo,18P
BO 148581	Base Assy-Tail Lamp-LH	10T-10P-11 Sed-2Sed,10 UCo,18P
BO 148582	Base Assy-Tail Lamp-RH	10T-10P-11 ClubCpe-3Cpe-CvSed,10 UCpe
BO 148583	Base Assy-Tail Lamp-LH	10T-10P-11 ClubCpe-3Cpe-CvSed,10 UCpe
BO 148584	Base Assy-Tail Lamp-RH	12 thru 17 Sed-2Sed
BO 148585	Base Assy-Tail Lamp-LH	12 thru 17 Sed-2Sed
BO 148586	Base Assy-Tail Lamp-RH	12-14-15 3Cpe-ClubCpe-CvSed
BO 148587	Base Assy-Tail Lamp-LH	12-14-15 3Cpe-ClubCpe-CvSed
BZ 148594	Support-F License Plate Brkt Clamp	10T-18P,10C-18C exc Del
BZ 148597	Brkt & Arm Assy-F License Plate	10,11,18
BZ 148598	Clamp Support-F License Plate Brkt	10P,10 Del,11
BZ 148599	Brkt & Clamp Assy-Front License Plate	10P,11
BO 148600	Regulator Assy-Quarter Window	10P-11-12-14-17 Sed,11-12-14-15 ClubCpe
BO 148602	Regulator Assy-F Door Wing-RH	10-11 CvSed,12,14,15,17
BO 148603	Regulator Assy-F Door Wing-LH	10-11 CvSed,12,14,15,17
BO 148604	Regulator Assy-F Door Window-RH (Use 200520)	10T,10C,18
BO 148605	Use 200521	
BO 148606	Regulator Assy-Rear Door Window-RH	1941-1942 Sedan-CA,1946-1947 Sed
BO 148607	Regulator Assy-Rear Door Window-LH	1941-1942 Sedan-CA,1946-1947 Sed
BO 148608	Regulator Assy-F Door Window-RH	1941-1942 CvSed,1946-1947 CvBro
BO 148609	Regulator Assy-F Door Window-LH	1941-1942 CvSed,1946-1947 CvBro
BO 148610	Regulator Assy-Quarter Window	10 thru 17 Sed,11-12-14-15 ClubCpe
BO 148611	Socket Assy-Tail Lamp	1941-1942 exc Cab-CabPu-Station-Del, 51 thru 54,171 thru 174
C 148614	Door Assy-RH	1941 CvSed
BO 148615	Door Assy-LH	1941 CvSed
C 148618	Molding-Quarter Trim Panel-Long	10P-11-15 ClubCpe
BO 148619	Molding-Quarter Trim Panel-Short	10P-11-22-24-25 ClubCpe,1942 CvSed,1946-1947 CvBro
C 148620	Finish Molding-Rear Window Reveal-RH	1941-1942-1946-1947 Sed-Bro-3Cpe-ClubCpe
C 148621	Finish Molding-Rear Window Reveal-LH	1941-1942-1946-1947 Sed-Bro-3Cpe-ClubCpe
BO 148622	Joint Cover-Rear Window Reveal Molding	1941 thru 1950 Sed-Bro-3Cpe-ClubCpe
C 148626	Weatherstrip-Rear Window	1941-1942 exc Cab-CabPu-Del-CvSed,1946-1947 exc Cab-CabPu-CvBro
BO 148631	Molding-F Door Trim Panel-Short #1-2	15 ClubCpe-3Cpe-17,#3 for 17
C 148633	Molding-Quarter Trim Panel	10-20 thru 27 Sed-2Sed,1946-1947 Sed
C 148634	Molding-Rear Door Trim Panel-Upper	10T-10P Sed,18P,22 thru 27 Sed
C 148634	Molding-Rear Door Trim Panel	17-22-24 Sedan
C 148634	Molding-Quarter Trim Panel	10T ClubCpe
C 148635	Molding-F Door Trim Panel-Long #1-2-3	15 3Cpe-ClubCpe,17
C 148636	Molding-F Door Trim Panel-Upper	10P 5Sed,10T Leather Trim Sed-ClubCpe,1941 CvSed,22-24-25 Sed-ClubCpe,1942-CvSed,1946-1947 CvBro
C 148637	Molding-F Door Trim Panel-Lower	10P-22024 5Sed,10T Leather Trim Sed
C 148638	Molding-F Door Trim Panel-Upper (10T Leather Only)	10-22-24 2Sed-3Cpe-ClubCpe-CvSed,18P,11-12-14-20-21-22-24 Cv,1946-1947 CvBro
C 148638	Molding-F Door Trim Panel #4-5	17 Sedan,22-24-25 ClubCpe-3Cpe-2Sed,27
C 148639	Molding-F Door Trim Panel-Lower (10T Leather Only)	10-22-24 2Sed-3Cpe-ClubCpe-CvSed,18P,11-12-20-21-22-24 Cv,1946-1947 CvBro
C 148639	Molding-Quarter Trim Panel-Upper	10-22-24 2Sed,10T Leather Trim 2Sed
148648	Lamp Assy-Front Fender-RH-6 Volt (Use 206514)	1941 with DI
148649	Use 206515	
148650	Use 201050	
148651	Use 201051	
148652	Use 206510	
148653	Use 206511	
148654	Use 201054	
148655	Use 201055	
148656	Base, Socket & Wire Assy-F Fender Lamp-RH (Use 206510)	1941 All
148657	Use 206511	
BO 148658	Lens-Front Fender Lamp	1941 thru 1947 All
BO 148659	Gasket-Front Fender Lamp-Rear	1941 thru 1947 All
BO 148660	Gasket-Front Fender Lamp-Lower	1941 thru 1947 All
BO 148661	Pad-Front Fender Lamp	1941 thru 1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
148664	Use 206510	
148665	Use 206511	
148666	Housing-F Fender Lamp-RH (Use 206510)	1941 All
BO 148667	Housing-F Fender Lamp-LH	1941 All
BO 148668	Wire-Front Fender Lamp-RH	1941 All
BO 148669	Wire-Front Fender Lamp-LH	1941 All
148670	Ornament-Front Fender Lamp (Use 1-206670 & 3-170367)	1941-1942-1946 All
C 148673	Molding-Top Rear Bow	1941-1942 CvSed,1946-1947 CvBro
C 148674	Molding-Top Front Header Rail	1941-1942 CvSed,1946-1947 CvBro
*C 148675	Header Rail-Folding Top	1941-1942 CvSed,1946-1947 CvBro
BO 148676	Corner Bracket-Folding Top Front-RH	1941-1942 CvSed,1946-1947 CvBro
BO 148677	Corner Bracket-Folding Top Front-LH	1941-1942 CvSed,1946-1947 CvBro
C 148694	Rear Bow-Folding Top	1941-1942 CvSed,1946-1947 CvBro
BO 148722	Weatherseal-Folding Top Pillar Bottom-RH	1941-1942 CvSed,1946-1947 CvBro
BO 148723	Weatherseal-Folding Top Pillar Bottom-LH	1941-1942 CvSed,1946-1947 CvBro
BO 148724	Reinforcement-Rear Curtain Bottom	1941-1942 CvSed,1946-1947 CvBro
C 148725	Molding-Rear Door Trim Panel-Lower	10P-22-24 Sed,10T Sed,18P
*SP 148728	Arm Assy-W/Shield Cleaner	1941-1942 exc CvSed,1946-1947 exc CvBro
*SP 148729	Arm Assy-W/Shield Cleaner	1941-1942 CvSed,1946-1947 CvBro
C 148730	Window Assy-Quarter-RH-Safety Glass	1941-1942 CvSed,1946-1947 CvBro
C 148731	Window Assy-Quarter-LH-Safety Glass	1941 CvSed,1946-1947 CvBro
C 148732	Window Assy-Quarter-RH-Crystal Glass	1941 CvSed
C 148733	Window Assy-Quarter-LH-Crystal Glass	1941 CvSed
C 148734	Frame-Qtr Wdo-RH	1941-1942 CvSed,1946-1947 CvBro
C 148735	Frame-Qtr Wdo-LH	1941-1942 CvSed,1946-1947 CvBro
C 148736	Retainer-Qtr Wdo Glass-RH	1941-1942 CvSed,1946-1947 CvBro
C 148737	Retainer-Qtr Wdo Glass-LH	1941-1942 CvSed,1946-1947 CvBro
BO 148741	W/Strip-Qtr Wdo Glass	1941-1942 CvSed,1946-1947 CvBro
BO 148742	Weatherstrip-Quarter Window Belt-RH	1941-1942 CvSed,1946-1947 CvBro
BO 148743	Weatherstrip-Quarter Window Belt-LH	1941-1942 CvSed,1946-1947 CvBro
BO 148744	Weatherstrip-Quarter Window Frame	1941-1942 CvSed,1946-1947 CvBro
BO 148748	Cover-Inst Panel Radio Dial Hole-Gray Plastic	1941 All
BO 148749	Colt-Running Board Top Outer Molding	1941 All
BO 148750	Trim Retainer Assy-Rear Door Bottom	1941 Sedan-Carryall
C 148753	Trim Retainer Assy-F Door Hinge Pillar-LH	10-14 exc Cv,17,18
C 148757	Trim Retainer Assy-F Door Lock Pillar-LH	11-12-14 exc Cv
C 148760	Trim Retainer Assy-F Door Hinge-RH	11-12-14 exc Cv
C 148761	Trim Retainer Assy-F Door Hinge-LH	11-12-14 exc Cv
C 148774	Trim Retainer-Rear Door Lock Pillar-RH	11-12-14 Sed
C 148775	Trim Retainer-Rear Door Lock Pillar-LH	11-12-14 Sed
BO 148782	Escutcheon-Inst Panel Steering Column Hole-LHD-Inner	1941-1942 exc 7Sed-Cab-CabPu,51 thru 54, 171 thru 174,178 Station
BO 148783	Escutcheon-Inst Panel Steering Column Hole-LHD-Outer	1941-1942 exc 7Sed-Cab-CabPu,51 thru 54, 171 thru 174,178 Station
BO 148784	Escutcheon-Inst Panel Steering Column Hole-RHD-Outer	1941-1942 exc 7Sed-Cab-CabPu,51 thru 54, 171 thru 174
BO 148785	Escutcheon-Inst Panel Steering Column Hole-RHD-Inner	1941-1942 exc 7Sed-Cab-CabPu,51 thru 54,171 thru 174
BO 148790	Escutcheon-Inst Panel Steering Column Hole-LHD-Inner	1941-1942 CA-7Sed-Cab-CabPu,1946-1947 Cab-CabPu
BO 148791	Escutcheon-Inst Panel Steering Column Hole-LHD-Outer	1941-1942 CA-7Sed-Cab-CabPu,1946-1947 Cab-CabPu
BO 148792	Escutcheon-Inst Panel Steering Column Hole-RHD-Outer	1941-1942 CA-7Sed-Cab-CabPu,1946-1947 Cab-CabPu
BO 148793	Escutcheon-Inst Panel Steering Column Hole-RHD-Inner	1941-1942 CA-7Sed-Cab-CabPu,1946-1947 Cab-CabPu
BO 148799	Retainer-Steering Column Hole Escutcheon	1941 thru 1947 All
148800	Track Assy-F Seat-LHD (Use 1-200340, 1-200341 & 1-200342)	1941-1942 5Sed-Station-3Cpe,1946-1947 3Cpe-Sed, 1947 Station
C 148801	Track Assy-F Seat-RHD	1941-1942 5Sed-Station-3Cpe,1946-1947 Sed-3Cpe
C 148802	Track Assy-F Seat-LHD	1941 thru 1942 2Sed-ClubCpe-CvSed,15-25 3Cpe,1946-1947 Bro-ClubCpe-CvBro
C 148803	Track Assy-F Seat-RHD	1941 thru 1942 2Sed-ClubCpe-CvSed,15-25 3Cpe,1946-1947 Bro-ClubCpe-CvBro
C 148804	Locking Handle-F Seat Track	1941 thru 1942 ClubCpe-CvSed-2Sed-3Cpe- UCpe, 1946-1947 Bro-ClubCpe-CvBro
BO 148805	Clip-Door Trim Retainer-Upper	1941 All
C 148806	Cushion Frame Assy-Front Seat-LHD	1941-1942 2Sed,1946-1947 Bro
C 148807	Cushion Frame Assy-Front Seat-RHD	1941-1942 2Sed,1946-1947 Bro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 148816	Frame Assy-Front Seat Cushion-LHD	1941-1942 ClubCpe-CvSed,15-25 3Cpe,1946-1947 ClubCpe-CvBro
C 148824	Locking Handle-Front Seat	1946-1947 Sed-3Cpe,178 Station
C 148826	Front End Assy-RHD-Prime	10 cxc Del-CvSed
C 148837	Front End Assy-LHD-Painted Panel-Prime (Use 148835)	11 thru 17 exc CvSed
BO 148869	Mirror Assy-External-RHd	1941 thru 1947 Cab-CabPu
BO 148870	Mirror Assy-External Rear View-LHD	1941-1942 Cab-CabPu-Del,58,178
BO 148871	Mirror-External Rear View	1941-1942 Cab-CabPu-Del,58,178
BO 148872	Arm-External Rear View Mirror	1941-1942 Cab-CabPu-Del,58,178
BO 148873	Gasket Outer-External Rear View Mirror	1941-1942 Cab-CabPu-Del,58,178
BO 148874	Gasket Inner-External Rear View Mirror	1941-1942 Cab-CabPu-Del,58,178
BO 148875	Plate-Mirror to Door Panel Reinforcing	1941-1942 Cab-CabPu-Del,58,178
*C 148878	Panel Assy-Quarter-RH-Without Reveal Mldg Holes	10-11 2Sed-UCp
*C 148879	Panel Assy-Qtr-LH-Without Reveal Mldg Holes	10-11 2Sed-UCo
C 148880	Use 148878	
C 148881	Use 148879	
*C 148882	Panel Assy-Qtr-RH-Without Reveal Mldg Holes	10T-10P-11 5Sed
*C 148883	Panel Assy-Qtr-LH-Without Reveal Mldg Holes	10T-10P-11 5Sed
C 148888	Panel Assy-Qtr-RH-Without Reveal Mldg Holes	10-11 3Cpe-UCpe
C 148889	Panel Assy-Qtr-LH-Without Reveal Mldg Holes	10-11 3Cpe-UCpe
C 148890	Panel Assy-Qtr-RH-With Reveal Mldg Holes	10P-11 thru 14 2Sed
C 148891	Panel Assy-Qtr-LH-With Reveal Mldg Holes	10P-11 thru 14 2Sed
C 148896	Panel Assy-Qtr-RH-With Reveal Mldg Holes (Use 148882)	10P-11 thru 18 5Sed
C 148897	Panel Assy-Qtr-LH-With Reveal Mldg	10P-11 thru 18 5Sed
C 148902	Panel Assy-Qtr-RH-With Reveal Mldg Holes	10P-11-12-14-15 ClubCpe-3Cpe
C 148903	Panel Assy-Qtr-LH-With Reveal Mldg Holes	10P-11-12-14-15 ClubCpe-3Cpe
C 148916	Finish Mldg & W/Strip Assy-F Door Wdo-RH-With Wing Vent-Grained	10 2Sed,10UCo,18P
C 148917	Finish Mldg & W/Strip Assy-F Door Wdo-LH-With Wing Vent-Grained	10 2Sed,10 UCo,18P
C 148920	Finish Mldg & W/Strip Assy-F Door Wdo-RH	17,28,22-24 2Sed,1946-1947 Bro
C 148921	Finish Mldg & W/Strip Assy-F Door Wdo-LH	17,28,22-24 2Sed,1946-1947 Bro
C 148928	Finish Mldg & W/Strip Assy-F Door-RH	22-24-25 Sed,52-54-172-174 Sed
C 148929	Finish Mldg & W/Strip Assy-F Door-LH	22-24-25 5Sed,52-54-172-174 Sed
C 148930	Finish Mldg & W/Strip Assy-F Door Window-RH- Sliding Window-Lac	10T 3Cpe-ClubCpe,UCpe
C 148932	Finish Mldg & W/Strip Assy-F Door Window-RH- With Wing Vent-Grained	10P-10T 3Cpe-ClubCpe,10 UCpe
C 148936	Finish Mldg & W/Strip Assy-F Door Window-RH- Chrome	15-22-24-25 3Cpe-ClubCpe,52-54-172-174 3Cpe-ClubCpe
C 148937	Finish Mldg & W/Strip Assy-F Door Window-LH- Chrome	15-22-24-25 3Cpe-ClubCpe,52-54-172-174 3Cpe-ClubCpe
C 148938	Finish Mldg & W/Strip Assy-F Door Window-RH	1941-1942 CvSed,1946-1947 CvBro
C 148939	Finish Mldg & W/Strip Assy-F Door Window-LH	1941-1942 CvSed,1946-1947 CvBro
C 148940	Finish Mldg & W/Strip Assy-Rear Door Window- RH-Grained	10 Sed,18P
C 148941	Finish Mldg & W/Strip Assy-Rear Door Window- LH-Grained	10 Sed,18P
C 148944	Finish Mldg & W/Strip Assy-Rear Door Window- RH-Chrome	17-22 thru 27 Sedan,52-54-172-174 Sed
C 148945	Finish Mldg & W/Strip Assy-Rear Door Window- LH-Chrome	17-22 thru 27 Sedan,52-54-172-174 Sed
C 148948	Finish Mldg & W/Strip Assy-Qtr Window-RH- Chrome	10P-11-12-14 2Sed
C 148950	Finish Mldg & W/Strip Assy-Qtr Window-RH	12-14-22-24 2Sed,52-54-172-174 Bro
C 148951	Finish Mldg & W/Strip Assy-Qtr Window-LH	12-14-22-24 2Sed,52-54-172-174 Bro
C 148952	Finish Mldg Valance & W/Strip Assy-F Door Wdo-RH-Tan Trim-Grained	11 3Cpe-ClubCpe-2Sed
C 148956	Finish Mldg Valance & W/Strip Assy-F Door Wdo-RH-Tan Trim-Grained	12-14 3Cpe-ClubCpe-2Sed
C 148957	Finish Mldg Valance & W/Strip Assy-F Door Wdo-LH-Tan Trim-Gained	12-14 3Cpe-ClubCpe-2Sed
C 148970	Finish Mldg Valance & W/Strip Assy-R Door Wdo-RH-Gray-Green Trim	11-12-14 Sedan
C 148974	Finish Mldg & W/Strip Assy-F Door Window- RH-Grained	10T-10P Sed with Wing Ventilator
C 148975	Finish Mldg & W/Strip Assy-F -Door Window- LH-Grained	10T-10P Sed with Wing Ventilator
C 148983	Frame-Door Window Glass	1941-1942 CvSed,1946-1947 CvBro
C 148984	Wdo Glass,Frame & Rest Channel Assy-RH-Door	1941-1942 CvSed,1946-1947 CvBro
C 148985	Wdo Glass,Frame & Rest Channel Assy-LH-Door	1941-1942 CvSed,1946-1947 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 148992	Track Assy-Door-RH	1941 CvSed,1946-1947 CvBro
BO 148993	Track Assy-Door-LH	1941 CvSed,1946-1947 CvBro
BO 148994	Support Assy-Front Door Track-R & L	1941 CvSed,1946-1947 CvBro
BO 148998	Bracket-Door Track Support	1941 CvSed,1946-1947 CvBro
M 149050	Seat Cloth-Boucle	
M 149051	Sidewall Cloth-Boucle	
M 149053	Seat and Sidewall Cloth-Mohair	
BO 149069	Bracket-Robe Hanger	12-14-22-24 Sed-2Sed,17-20-21-27 Sed
BO 149072	Robe Hanger Assy-Gray	12-14 Sedan
M 149099	Cloth-Seat and Sidewall-Mohair	
M 149100	Seat Cloth-Tan Broadcloth-Heavy	
M 149101	Seat Cloth-Tan Broadcloth-Light	
M 149102	Sidewall Cloth-Tan	
BO 149105	Robe Hanger Assy-Tan	10P Sed
149108	Use 127356	
M 149110	Seat Cloth-Heavy Tan Tweed	
M 149111	Seat Cloth-Light Tan Tweed	
BO 149112	Windlace-Tan	10P,11 thru 17
BO 149113	Seaming Lace-Tan	10P,12 thru 17,51-53-171-173 Cloth Trim
M 149120	Seat Cloth-Heavy Tan Twill	
M 149121	Seat Cloth-Light Tan Twill	
M 149123	Imitation Leather-Tan	
BO 149126	Assist Strap Assy-Tan	12-14 Sed-2Sed-ClubCpe
149128	Visor Assy (Use 143520)	
149129	Visor Assy (Use 143521)	
149130	Visor Assy-RH (Use 143520)	10,11,12,14,18
149131	Visor Assy-LH (Use 143521)	10,11,12,14,18
149132	Visor Assy-Hinge Type (Use 127356)	10,11,18
C 149157	Silencer & Trimboard Assy-Dash-RHD-Gray	10 thru 17,18P
C 149164	Trim Panel-Cowl-RHBrown	1941 All
C 149165	Trim Panel-Cowl-LHBrown	1941 All
C 149166	Trim Panel-Cowl-RH-Gray	
C 149167	Trim Panel-Cowl-LH-Gray	
C 149168	Trim Panel-Cowl-RH-Green	10 thru 17
C 149169	Trim Panel-Cowl-LH-Green	10 thru 17
M 149170	Seat Cloth-Heavy Tan Bedford Cord	
BO 149182	Assist Strap Assy-With Mohair Trim	10T 5Sed 18 7Sed,10 Sp
BO 149183	Assist Strap Assy-With Leather Trim	10T 5Sed,18 7Sed
BO 149195	Binding-3/4" Double Edge-Maroon	1941-1942 CvSed,1946-1947 CvBro
M 149200	Seat Cloth-Heavy Gray Broadcloth	
M 149201	Seat Cloth-Light Gray Broadcloth	
M 149202	Sidewall Cloth-Gray	
M 149203	Headlining Cloth-Gray	
149205	Robe Hanger Assy-Gray (Use 207205)	10P Sed
M 149210	Seat Cloth-Heavy Gray Tweed	
M 149211	Seat Cloth-Light Gray Tweed	
BO 149212	Windlace-Gray	10P,11 thru 17
M 149214	Carpet Material	
BO 149215	Robe Hanger Assy-Gray	11 Sedan
BO 149216	Assist Strap Assy-Gray	10 thru 17 Sed-2Sed-ClubCpe
M 149220	Seat Cloth-Heavy Gray Twill	
M 149224	Imitation Leather-Gray	
BO 149226	Assist Strap Assy-Gray	12-14 Sed-2Sed-ClubCpe
BO 149229	Visor Assy-Swivel Type-LH	10,11,12,14,18
M 149241	Seat Cloth-Tan Stripe-Heavy	
M 149244	Seat Cloth-Gray Stripe-Light	
BO 149248	Laminated Fibre Flex Binding	1940-1941-1942-1946 Pass Cars
BO 149252	Rohe Hanger Assy-Gray	10P-11-12-14-17 5Sed
BO 149253	Robe Hanger Assy-Green	10P-11-12-14-17 5Sed
BO 149254	Robe Hanger Assy-Tan	15 ClubCpe-3Cpe
BO 149256	Robe Hanger Assy-Green	15 ClubCpe-3Cpe,12-14 2Sed-ClubCpe
BO 149257	Robe Hanger Assy-Tan Leather Trim	10P-11 thru 17 Sed,20P-21 thru 27 Sed
BO 149258	Robe Hanger Assy-Maroon Leather Trim	12-14 2Sed-ClubCpe,15 ClubCpe-3Cpe,22-24 2Sed
M 149271	Seat Cloth-Light Gray Bedford Cord	
M 149282	Top Material-Sage Green	
BO 149286	Binding-3/4" Double Fold-Sage Green	1941 CvSed
M 149302	Sidewall Cloth-Green	
M 149303	Headlining Cloth-Green	11 exe CvSed
BO 149308	Visor Assy-Hinge Type-Green	
M 149310	Seat Cloth-Heavy Green Tweed	
M 149311	Seat Cloth-Light Green Tweed	
BO 149312	Windlace-Green	
BO 149313	Seaming Lace-Green	10P,11 thru 17
M 149314	Carpet Material	10P,11 thru 17

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 149316	Assist Strap Assy-Green	10P thru 17 Sed-2Sed-ClubCpe
149320	Seat Cloth-Heavy Green Twill (Use 149321)	
TC 149321	Seat Cloth-Light Green Twill	
BO 149328	Visor Assy-Swivel Type-RH	10,11,12,14,18
BO 149329	Visor Assy-Swivel Type-LH	10,11,12,14,18
C 149351	Trim Assy-Rear Seat Cushion Retainer-Cloth	11 Sed-2Sed
C 149352	Back Complete-Rear Seat-Cloth	12-14 Sed-2Sed
C 149353	Trim Assy-Rear Seat Back-Cloth	12-14 Sed-2Sed
C 149354	Cushion Complete-Rear Seat-Cloth	12-14 Sed-2Sed
C 149355	Trim Assy-Rear Seat Cushion-Cloth	12-14 Sed-2Sed
C 149356	Retainer & Trim Assy-Rear Seat Cushion-Cloth	12-14 Sed-2Sed
C 149357	Trim Assy-Rear Seat Cushion Retainer-Cloth	12-14 Sed-2Sed
C 149358	Cushion Complete-Rear Seat-Cloth	17 5Sed
C 149359	Back Complete-Rear Seat-Cloth	17 5Sed
C 149360	Trim Assy-Rear Seat Back-RH-Cloth	17 5Sed
C 149361	Trim Assy-Rear Seat Back-LH-Cloth	17 5Sed
C 149362	Trim Assy-Rear Seat Cushion-Cloth	17 5Sed
C 149363	Retainer & Trim Assy-Rear Seat Cushion-Cloth	17 5Sed
C 149364	Trim Assy-Rear Seat Cushion Retainer-Cloth	17 5Sed
C 149366	Trim Assy-Rear Seat Back-Cloth	10T ClubCpe
C 149367	Cushion Complete-Rear Seat-Cloth-Std	10T ClubCpe
C 149368	Trim Assy-Rear Seat Cushion-Cloth-Std	10T ClubCpe
BO 149369	Tape Assy-Rear Seat Cushion Upholstery Button	10T ClubCpe
M 149370	Seat Cloth-Heavy Green Bedford Cord	
M 149371	Seat Cloth-Light Green Bedford Cord	
C 149380	Cushion Complete-Rear Seat-Airfoam	10T-ClubCpe
C 149381	Trim Assy-Rear Seat Cushion-Airfoam	10T ClubCpe
C 149382	Retainer & Trim Assy-Rear Seat Cushion	10T ClubCpe
C 149383	Trim Assy-Rear Seat Cushion Retainer	10T ClubCpe
C 149384	Back Complete-Rear Seat	10-11 ClubCpe
C 149385	Trim Assy-Rear Seat Back	10-11 ClubCpe
C 149386	Cushion Complete-Rear Seat-Std	10-11 ClubCpe
C 149387	Trim Assy-Rear Seat Cushion-Std	10-11 ClubCpe
C 149388	Cushion Complete-Rear Seat-Airfoam	10-11 ClubCpe
C 149389	Trim Assy-Rear Seat Cushion-Airfoam	10-11 ClubCpe
C 149390	Back Complete-Rear Seat-Cloth	12-14 ClubCpe
C 149391	Trim Assy-Rear Seat-Back-Cloth	12-14 ClubCpe
C 149392	Cushion Complete-Rear Seat-Cloth	12-14 ClubCpe
C 149393	Trim Assy-Rear Seat Cushion-Cloth	12-14 ClubCpe
C 149394	Retainer & Trim Assy-Rear Seat Cushion-Cloth	12-14 ClubCpe
C 149395	Trim Assy-Rear Seat Cushion Retainer-Cloth	12-14 ClubCpe
C 149396	Retainer & Trim Assy-Rear Seat Cushion-Cloth	10-11 ClubCpe
C 149397	Trim Assy-Rear Seat Cushion Retainer-Cloth	10-11 ClubCpe
C 149398	Retainer & Trim Assy-Rear Seat Cushion-Cloth	11 ClubCpe
C 149399	Trim Assy-Rear Seat Cushion Retainer-Cloth	11 ClubCpe
C 149532	Trim Assy-Rear Seat Back-RH-Cloth	15 ClubCpe
C 149533	Trim Assy-Rear Seat Back-LH-Cloth	15 ClubCpe
C 149534	Back Complete-Rear Seat-Cloth	15 ClubCpe
C 149535	Cushion Complete-Rear Seat-Cloth	15 ClubCpe
C 149536	Trim Assy-Rear Seat Cushion-Cloth	15 ClubCpe
C 149537	Retainer & Trim Assy-Rear Seat Cushion-Cloth	15 ClubCpe
C 149538	Trim Assy-Rear Seat Cushion Retainer-Cloth	15 ClubCpe
149540	Weatherstrip Assy-Rear Door (Use 202668)	1941 Sedan-Carryall
C 149567	Cushion Frame & Back Complete-F Seat-LHD	10T 5Sed
C 149568	Cushion Frame & Back Complete-F Seat-RHD	10T 5Sed
C 149569	Trim Assy-Front Seat Back	10T 5Sed-3Cpe
C 149570	Cushion Complete-Front Seat	10T 5Sed-3Cpe
C 149571	Trim Assy-Front Seat Cushion	10T 5Sed-3Cpe
C 149572	Cushion Complete-Front Seat-Airfoam	10T 5Sed
C 149574	Side & Riser Trim Assy-F Seat	10T 5Sed
C 149577	Back Complete-Front Seat-Drivers-LHD	10T-10P-11 2Sed
C 149578	Back Complete-Front Seat-Drivers-RHD	10T-10P-11 2Sed
C 149579	Back Complete-Front Seat-Passenger-LHD	10T-10P-11 2Sed
C 149580	Back Complete-Front Seat-Passenger-RHD	10T-10P-11 2Sed
C 149581	Trim Assy-F Seat Riser Panel	10T 2Sed,10 UCpe
C 149582	Trim Assy-F Seat Back-RH	10T-10P-11 Sed,10 UCpe
C 149583	Trim Assy-F Seat Back-LH	10T-10P-11 Sed,10 UCpe
C 149584	Cushion Complete-Front Seat	10T 2Sed,10 UCpe
C 149586	Cushion Complete-Front Seat-Airfoam	10T 2Sed 10 UCpe
C 149587	Trim Assy-Front Seat Cushion-Airfoam	10T 2Sed,10 UCpe
C 149588	Back Complete-Rear Seat	10T 2Sed 5Sed
C 149589	Trim Assy-Rear Seat Back	10T 2Sed,5Sed,10 UCp
C 149590	Cushion Complete-Rear Seat	10T 2Sed-5Sed
C 149591	Trim Assy-Rear Seat Cushion	10T 2Sed-5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 149592	Cushion Complete-Rear Seat-Airfoam	10T 2Sed-5Sed
C 149595	Carpet Assy-F Seat Foot Rest	1941 ClubCpe,15 3Cpe,1946 ClubCpe-CvBro
C 149596	Cushion Retainer & Trim Assy-Rear Seat	10T 2Sed-5Sed,10 UCo
C 149597	Trim Assy-Rear Seat Cushion Retainer	10T 2Sed-5Sed,10 UCo
C 149601	Cushion Frame & Back Complete-Front Seat-LHD	10P 5Sed
C 149602	Cushion Frame & Back Complete-Front Seat-RHD	10P 5Sed
C 149603	Trim Assy-F Seat Back	10P 5Sed,11 Sed-3Cpe,10T 5Sed-3Cpe
C 149604	Cushion Complete-Front Seat	10P 5Sed,11 Sed-3Cpe,10T 5Sed-3Cpe
C 149605	Trim Assy-F Seat Cushion	10P 5Sed,11 Sed-3Cpe,10T 5Sed-3Cpe
C 149606	Cushion Complete-Front Seat-Airfoam	10P 5Sed,11 Sed-3Cpe,10T 5Sed-3Cpe
C 149607	Trim Assy-F Seat Cushion-Airfoam	1013 5Sed,11 Sed-3Cpe,10T 5Sed-3Cpe
C 149608	Trim Assy-F Seat Side and Riser	1013 5Sed,10T-11 5Sed-3Cpe
C 149611	Cushion Complete-Front Seat	10-11 2Sed,10 UCpe
C 149612	Trim Assy-Front Seat Cushion	10-11 2Sed,10 UCpe
C 149613	Cushion Complete-Front Seat-Airfoam	10-11 2Sed,10 UCpe
C 149614	Trim Assy-F Seat Cushion-Airfoam	10-11 2Sed,10 UCpe,10 Sp 2Sed
C 149615	Trim Assy-F Seat Riser Panel	10 2Sed,11 2Sed With Mohair Trim,10 UCpe
C 149616	Back Complete-Rear Seat	10-11 2Sed-5Sed
C 149617	Trim Assy-Rear Seat Back	10-11 2Sed-5Sed 10 UCo
C 149618	Cushion Complete-Rear Seat	10-11 2Sed-5Sed
C 149619	Trim Assy-Rear Seat Cushion	10-11 2Sed-5Sed
C 149620	Cushion Complete-Rear Seat-Airfoam	10-11 2Sed-5Sed
C 149621	Trim Assy-Rear Seat Cushion-Airfoam	10-11 2Sed-5Sed,10 Sp 5Sed
C 149626	W/Lace Assy-F Pillar & Header-RH	1941 2Sed-3Cpe-ClubCpe,1946-1947 Bro-3Cpe-ClubCpe
C 149627	W/Lace Assy-F Pillar & Header-LH	1941 2Sed-3Cpe-ClubCpe,1946-1947 Bro-3Cpe-ClubCpe
C 149630	W/Lace Assy-F Pillar & Header-RH	10-11-12-14 Sed,1946-1947 Sed
C 149631	W/Lace Assy-F Pillar & Header-LH	10-11-12-14 Sed,1946-1947 Sed
C 149632	Windlace Assy-F Pillar & Header-RH	17-18P-27 Sed
C 149633	Windlace Assy-F Pillar & Header-LH	17-18P-27 Sed
C 149636	W/Lace Assy-Rear Pillar-RH	1941-1946-1947 Sed
C 149637	W/ Lace Assy-Rear Pillar-LH	1941-1946-1947 Sed
C 149678	Arm Rest Assy-Qtr-RH	10T Sed
C 149679	Arm Rest Assy-Qtr-LH	10T Sed
C 149684	Retainer & Trim Assy-Rear Seat Cushion	10-11 5Sed-2Sed,10 UCo
C 149685	Trim Assy-Rear Seat Cushion Retainer	10-11 5Sed-2Sed,10 UCo
C 149686	Trimboard Complete-Front Door-RH-Cloth	10T 3Cpe-ClubCpe-2Sed,10 UCo-UCpe
C 149687	Trimboard Complete-Front Door-LH-Cloth	10T 3Cpe-ClubCpe-2Sed,10 UCo-UCpe
C 149688	Trimboard Complete-Front Door-RH-Cloth	10T Sed
C 149689	Trimboard Complete-Front Door-LH-Cloth	10T Sed
C 149694	Trimboard Complete-Rear Door-RH-Cloth	10T Sed
C 149695	Trimboard Complete-Rear Door-LH-Cloth	10T Sed
C 149696	Trimboard Complete-Front Door-RH-Cloth	10P 2Sed-3Cpe-ClubCpe
C 149697	Trimboard Complete-Front Door-LH-Cloth	10P 2Sed-3Cpe-ClubCpe
C 149698	Trimboard Complete-Front Door-RH-Cloth	10P Sed
C 149699	Trimboard Complete-Front Door-LH-Cloth	10P Sed
C 149700	Trimboard Complete-Rear Door-RH-Cloth	10P Sed
C 149701	Trimboard Complete-Rear Door-LH-Cloth	10P Sed
C 149702	Trimboard Complete-Front Door-RH-Cloth	11-12-14 2Sed-3Cpe-ClubCpe
C 149703	Trimboard Complete-Front Door-RH-Cloth	11-12-14 2Sed-3Cpe-ClubCpe
C 149704	Trimboard Complete-Front Door-RH-Cloth	11-12-14 Sed
C 149705	Trimboard Complete-Front Door-LH-Cloth	11-12-14 Sed
C 149706	Trimboard Complete-Rear Door-RH-Cloth	11-12-14 Sed
C 149707	Trimboard Complete-Rear Door-LH-Cloth	11-12-14 Sed
C 149708	Trimboard Complete-Front Door-RH-Cloth	12-14 2Sed-3Cpe-ClubCpe
C 149709	Trimboard Complete-Front Door-LH-Cloth	12-14 2Sed-3Cpe-ClubCpe
C 149710	Trimboard Complete-Front Door-RH-Cloth	12-14 Sedan
C 149711	Trimboard Complete-Front Door-RH-Cloth	12-14 Sedan
C 149712	Trimboard Complete-Rear Door-RH-Cloth	12-14 Sedan
C 149713	Trimboard Complete-Rear Door-RH-Cloth	12-14 Sedan
C 149714	Trimboard Complete-Front Door-RH-Cloth	15 3Cpe-ClubCpe,17 Sed
C 149715	Trimboard Complete-Front Door-LH-Cloth	15 3Cpe-ClubCpe,17 Sed
C 149716	Trimboard Complete-Rear Door-RH-Cloth	17 Sed
C 149717	Trimboard Complete-Rear Door-LH-Cloth	17 Sed
C 149723	Cushion Complete-Drivers Seat-LHD-Cloth	1941 Sed-2Sed-UCo,20 UCo
C 149724	Cushion Complete-Drivers Seat-RHD-Cloth	1941 Sed-2Sed-UCo,20 UCo
C 149725	Cushion Complete-Drivers Seat-LHD-Leather	1941 Sed-2Sed,UCo,20 UCo
C 149726	Cushion Complete-Drivers Seat-RHD-Leather	1941 Sed-2Sed-UCo,20 UCo
C 149727	Trim Assy-Drivers Seat Cushion-LHD-Cloth	1941 Sed-2Sed-UCo,20 UCo
C 149728	Trim Assy-Drivers Seat Cushion-RHD-Cloth	1941 Sed-2Sed-UCo,20 UCo
C 149729	Trim Assy-Drivers Seat Cushion-LHD-Leather	1941 Sed-2Sed-UCo,20 UCo
C 149730	Trim Assy-Drivers Seat Cushion-RHD-Leather	1941 Sed-2Sed-UCo,20 UCo
C 149735	Cushion Complete-Passenger Seat-LHD-Cloth	1941 Sed-2Sed-UCo,20 UCo
C 149736	Cushion Complete-Passenger Seat-RHD-Cloth	1941 Sed-2Sed-UCo,20 UCo

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 149737	Cushion Complete-Passenger Seat-LHD-Leather	1941 Sed-2Sed-UCo,20 UCo
C 149738	Cushion Complete-Passenger Seat-RHD-Leather	1941 Sed-2Sed,UCo,20 UCo
C 149739	Trim Assy-Passenger Seat Cushion-LHD-Cloth	1941 Sed-2Sed,UCo,20 UCo
C 149740	Trim Assy-Passenger Seat Cushion-RHD-Cloth	1941 Sed-2Sed-UCo,20 UCo
C 149741	Trim Assy-Passenger Seat Cushion-LHD-Lea	1941 Sed-2Sed-UCo,20 UCo
C 149742	Trim Assy-Passenger Seat Cushion-RHD-Lea	1941-1942 All,1946
C 149750	Silencer-Roof Panel	1941-1942 Sed-2Sed-UCo-Carryall,1946-1947 Bro-Sed
C 149753	Silencer-Rear Compt Door Panel	1941 3Cpe-ClubCpe,1946-1947 3Cpe-ClubCpe
C 149760	Trimboard Assy-Rear Compt Shelf-Rear	1941 All
BO 149789	Reinforcement-F Door Arm Rest Cardboard	1941 All
BO 149790	Arm Rest Assy-F Door-Cloth	1941 All
BO 149792	Arm Rest Assy-F Door-Leather	1941 CabPu
BO 149794	Arm Rest Assy-F Door-Tan	17 5Sed
C 149800	Air Cleaner Assy-Rear Seat Tray (Use 208190)	1941 All
C 149801	Cushion Frame & Back Complete-F Seat-LHD-Cloth	11 Sed
C 149802	Cushion Frame & Back Complete-F Seat-RHD-Cloth	11 Sed
C 149803	Cushion Frame & Back Complete-F Seat-LHD-Cloth	11 3Cpe
C 149804	Cushion Frame & Back Complete-F Seat-RHD-Cloth	11 3Cpe
C 149805	Side & Riser Trim Assy-F Seat-Cloth	11-12-14 Sed-3Cpe
C 149806	Trim Assy-Front Seat Riser Panel	12-14 20P-21 2Sed,1946-1947 Bro
C 149811	Baek Complete-Front Seat-Drivers-LHD-Cloth	10T-10P-11 ClubCpe
C 149812	Back Complete-Front Seat-Drivers-RHD-Cloth	10T-10P-11 ClubCpe
C 149813	Back Complete-Front Seat-Passenger-LHD-Cloth..	10T-10P-11 ClubCpe
C 149814	Back Complete-Front Seat-Passenger-RHD-Cloth	10T-10P-11 ClubCpe
C 149815	Trim Assy-Front Seat Riser Panel-Cloth	11-12-14-20P-21 ClubCpe,1946-1947 ClubCpe
C 149816	Trim Assy-Front Seat Back-RH Cloth	10T-10P-11 ClubCpe
C 149817	Trim Assy-Front Seat Back-LH-Cloth	10T-10P-11 ClubCpe
C 149818	Cushion Complete-Front Seat-Cloth-Standard	10-11 ClubCpe,10-11 UCpe-2Sed
C 149819	Trim Assy-Front Seat Cushion-Cloth-Standard	10-11 ClubCpe,10-11 UCpe-2Sed
C 149820	Cushion Complete-Front Seat-Cloth-Air Foam	10-11 ClubCpe,10-11 UCpe-2Sed
C 149821	Trim Assy-Front Seat Cushion-Cloth-Air Foam	10-11 ClubCpe,10-11 UCpe-2Sed
C 149822	Trim Assy-Front Seat Side & Riser	17 5Sed
C 149823	Cushion Frame & Back Complete-Front Seat-LHD-Cloth	12-14 Sed
C 149824	Cushion Frame & Back Complete-Front Seat-RHD-Cloth	12-14 Sed
C 149825	Cushion Frame & Back Complete-Front Seat-LHD-Cloth	12-14 3Cpe
C 149826	Cushion Frame & Back Complete-Front Seat-RHD-Cloth	12-14 3Cpe
C 149827	Trim Assy-F Seat Baek Cloth	12-14 Sed-3Cpe
C 149828	Cushion Complete-Front Seat-Cloth	12-14 Sed-3Cpe
C 149829	Trim Assy-Front Seat Cushion-Cloth	12-14 Sed-3Cpe
C 149830	Cushion Complete-Front Seat-Cloth	12-14 2Sed
C 149833	Back Complete-Front Seat-Drivers-LHD-Cloth	12-14 2Sed
C 149834	Back Complete-Front Seat-Drivers-RHD-Cloth	12-14 2Sed
C 149835	Back Complete-Front Seat-Passenger-LHD-Cloth	12-14 2Sed
C 149836	Back Complete-Front Seat-Passenger-RHD-Cloth...	12-14 2Sed
C 149837	Trim Assy-Front Seat Cushion-Cloth	12-14 2Sed
C 149838	Trim Assy-Front Seat Back-RH Cloth	12-14 2Sed
C 149839	Trim Assy-Front Seat Back-LH-Cloth	12-14 2Sed
C 149843	Back Complete-Front Seat-Drivers-LED-Cloth	12-14 ClubCpe
C 149844	Baek Complete-Front Seat-Drivers-RHD-Cloth	12-14 ClubCpe
C 149845	Back Complete-Front Seat-Passenger-LHD-Cloth	12-14 ClubCpe
C 149846	Back Complete-Front Seat-Passenger-RHD-Cloth	12-14 ClubCpe
C 149847	Cushion Complete-Front Seat	12-14 ClubCpe-2Sed
C 149848	Trim Assy-Front Seat Back-RH Cloth	12-14 ClubCpe
C 149849	Trim Assy-Front Seat Back-LH-Cloth	12-14 ClubCpe
C 149850	Trim Assy-Front Seat Cushion-Cloth	12-14 ClubCpe-2Sed
C 149853	Frame & Back Complete-F Seat Cushion-LHD-Cloth	17 5Sed
C 149854	Frame Si Back Complete-F Seat Cushion-RHD-Cloth	17 5Sed
C 149855	Board & Trim Assy-F Seat Back-Cloth	17 5Sed
C 149856	Trim & Pocket Assy-F Seat Back-Cloth	17 5Sed
C 149859	Cushion Complete-Front Seat-Cloth	17 5Sed
C 149860	Trim Assy-Front Seat Back-RH-Cloth	17 5Sed
C 149861	Trim Assy-Front Seat Back-LH-Cloth	17 5Sed
C 149862	Trim Assy-Front Seat Cushion	17 5Sed
C 149863	Center Arm Rest Complete-F Seat Back	17 5Sed
C 149864	Trim Assy-F Seat Center Arm Rest	17 5Sed
C 149865	Valanee Assy-F Seat Center Arm Rest	17 5Sed
C 149866	Cushion Complete-Front Seat	15 ClubCpe
C 149869	Back Complete-Front Seat-Drivers-LHD-Cloth	15 3Cpe-ClubCpe
C 149870	Back Complete-Front Seat-Drivers-RHD-Cloth	15 3Cpe-ClubCpe
C 149871	Back Complete-Front Seat-Passenger-LHD-Cloth	15 3Cpe-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 149872	Back Complete-Front Seat-Passenger-RHD-Cloth	15 3Cpe-ClubCpe
C 149873	Trim Assy-Front Seat Cushion-Cloth	15 3Cpe-ClubCpe
C 149874	Trim Assy-Front Seat Back-RH Cloth	15 3Cpe-ClubCpe
C 149875	Trim Assy-Front Seat Back-LH Cloth	15 3Cpe-ClubCpe
C 149876	Trim Assy-Front Seat Riser Panel-Cloth	15 3Cpe-ClubCpe
C 149879	Cushion Complete-Front Seat	10T ClubCpe-2Sed,10 UCpe
C 149880	Back Complete-Front Seat-RH Cloth	10 UCpe
C 149881	Back Complete-Front Seat-LH-Cloth	10 UCpe
C 149882	Trim Assy-Front Seat Cushion Cloth	10T ClubCpe-2Sed,10 UCpe
C 149885	Cushion Complete-Front Seat-Air Foam	10T ClubCpe-2Sed,10 UCpe
C 149886	Trim Assy-Front Seat Cushion-Air Foam	10T ClubCpe-2Sed,10 UCpe
C 149887	Trim Assy-Front Seat Riser Panel-Cloth	10T ClubCpe
C 149888	Trim Assy-Front Seat Riser Panel-Cloth	10-11 ClubCpe
C 149889	Frame & Back Complete-F Seat Cushion-LHD-Cloth	10-11 3Cpe
C 149890	Frame & Back Complete-F Seat Cushion-RHD-Cloth	10-11 3Cpe
C 149891	Clip-Door Trimboard Retaining (Use 202252)	11,12,14
C 149899	Airfoam Pad-Front Seat Cushion	12-14 Sed-3Cpe
C 149900	Airfoam Pad Assy-F Seat Cushion	17 5Sed-TownSed
C 149976	Airfoam Pad Assy-F Seat Cushion	15 ClubCpe-3Cpe,12-14 CvSed,54-174 CvBro
BO 149992	Filler-Drip Mldg-28"	11-14-21 Station
C 150009	Cyl & Pistons Assy	61X
BZ 150038	Shaft Assy-Acc Cross	36 LHD,RHD Less VD
BZ 150046	Rod Assy-Acc Cross Shaft to Manifold	61-62-63 LHD,RHD With VD
150048	Rod Assy-Acc Cross Shaft to Manifold (Use 155468)	61-62-63 LHD,RHD With VD
150054	Carrier & Gear Set Assy-Diff-4-1/9-1 (Use 166333)	36 Hud-Terr
C 150059	Housing Complete-R/A-Less Brake Shoes	61,62,63
C 150060	Housing Complete-R/A-Less Brake Shoes	36 Hudson 8
BX 150064	Cap Assy-Wheel Bearing Adjustment	1936 thru 1950 All
F 150066	Oil Seal-Wheel Bearing Adjustment Cap	1936 thru 1950 All
F 150067	Shaft Assy-Drive	36-37 Hud-Terr
150069	Oil Seal Assy-Drive Shaft (Use 166224)	36-37 All,80 thru 88,91 thru 98,89-89 Cab-CabPu- Panel-Sta,40C,41 thru 48,10C,10-20 With L engine, 11 thru 18,21 thru 28,20C,20 UCo-UCpe
*F 150072	Case & Stud Assy-Differential	36 thru 38 Hud-Terr,90
F 150086	Gasket-Cyl Head-High Compression	36 thru 39 Hudson 8
F 150087	Valve-Inlet	36-37 Hud 6-Terr
F 150088	Valve-Exhaust	36-37 Hud 6-Terr
F 150089	Valve-Inlet	36-37 Hudson 8
F 150090	Valve-Exhaust	36-37 Hudson 8
F 150091	Guide-Inlet-Valve	36-37 Hudson-Terr
F 150092	Guide-Exhaust Valve	36-37 Hud-Terr
BM 150093	Seat-Valve Spring	36-37 Hud-Terr
BT 150096	Shift Rail-Low & Reverse	36-37 Hud-Terr,1940 All
BT 150097	Shift Rail-Second & High	36-37 Hud-Terr
150098	Companion Flange-Rear Axle (Use 157753)	36-37 Hud-Terr
150100	Flywheel Assy-Includes Ring (Use 160220)	36-37 Hud 6-Terr 81,89,80 Co-Cpe
150102	Use 151694	
150103	Use 151696	
150104	Use 151699	
150105	Drag Link Assy (Use 151700)	36 Hud
150106	Use 151694	
150107	Use 151696	
C 150108	Drag Link & Plugs Assy-LHD	36 Hudson
150109	Drag Link & Plugs Assy-RHD (Use 151700)	36 Hudson
*C 150118	Tank Assy-Gasoline	36 Bro-Sedan
C 150119	Tank Assy-Gasoline	36 CvCpe-3Cpe-VicCpe
C 150120	Tank Assy-Gasoline	61 thru 67
BZ 150124	Neck Assy-Gas Tank Filler	36 Bro-Sedan
BZ 150125	Neck Assy-Gas Tank Filler	36 CvCpe-3Cpe-VicCpe
150128	Cap Assy-Gas Tank (Use 155298)	36-37 All
150130	Gauge Assy-Gas Tank (Use 159110)	36 thru 38
ZF 150131	Gasket-Gas Tank Gauge	36 thru 1950 All
BZ 150134	Outlet Unit-Gas Tank	36-37 Hud-Terr
BZ 150136	Silencer-Gas Tank to Strap	36 thru 1940 All
BZ 150137	Strap-Gas Tank	36 Hud-Terr
150138	Use 155519	
F 150142	Main Shaft Assy-Trans	36-37 Hud-Terr
150143	Use 150142	
F 150144	Gear-Trans M/S Low & Reverse	36-37 Hud-Terr
*F 150146	Countershaft-Transmission	36-37 Hud-Terr
150148	Use 154553	
BT 150149	Bushing-Countershaft-Rear	36 thru. 1940 All
BZ 150153	Bracket-Tail Pipe-Front	36 Hud-Terr
BZ 150154	Bracket-Tail Pipe-Rear	36 Hud-Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
CF 150155	Tail Pipe Assy	61,62
CF 156157	Tail Pipe Assy	63,64,65
CF 150159	Tail Pipe Assy	66,67
BT 150161	Cap Assy-Countershaft	36 thru 39 All,1940 Without OD
F 150163	Gear-Countershaft Drive	36-37 Hud-Terr
BT 150164	Thrust Washer Assy-C/S Drive Gear	36 thru 1940 All
CF 150166	Gear-Countershaft Low & Reverse	36-37 Hud-Terr
C 150170	Shaft Assy-Propeller	61,62,63
C 150172	Prop-Shaft & Universal Joint Assy	61,65
150174	Prop-Shaft & Universal Joint Assy (Use 150180)	66,67
150176	Use 150178	
C 150178	Shaft Assy-Propeller	61 thru 65
C 150180	Shaft Assy-Propeller	66,67
150182	End Assy-Prop Shaft-Front (Use 165790)	61 thru 65,70 thru 75,80 thru 85,89,90 thru 95
BZ 150183	End Assy-Prop Shaft-Front	66,67,76,77,78,87,88,97,98
F 150184	Yoke Assy-Propeller Shaft Sleeve	61 thru 65,70 thru 75,80 thru 85,89,90 thru 95,41,42,44,45,11 thru 15,10 with L Engine,10 with Std Engine-17-18 with OD,1942 with OD,20 with Engine
F 150185	Yoke Assy-Propeller Shaft Sleeve	66,67,76,77,78,87,88,97,98,43,47,48,17-18-27-28 Without OD,58.178
150186	Use 150184	
150187	Use 150185	
150188	Use 150190	
C 150190	Prop Shaft & Joint Assy-Rear	61 thru 65
150194	Journal Assy-Universal Joint (Use 164369)	36 thru 39 All
CF 150197	Gear-Reverse-Sliding	36 thru 1940 All
BT 150198	Cap-Reverse Gear Shaft	36 thru 1940 All,1940 Without OD
BT 150199	Shifter-Reverse Gear	36 thru 1940 All
150202	Fulcrum-Rev Gear Shift Lever (Use 44203)	36 thru 39 All
150204	Fork Assy-Low & Reverse Shifter (Use 159540)	36 thru 39 All
BT 150208	Companion Flange-Prop Shaft End	36 thru 39 All
F 150209	Sleeve-M/S Second & High Shift	36-37 All
150213	Use 166284	
BM 150214	Pump Assy-Qater	62 thru 67,72,74,75,76,77
BM 150215	Body Assy-Water Pump	61,70,71,73B,71X,80,81,82X,83X,88,89,90,92,93X,98,40,41,44,45,48,10,11,12,14,18,20,21,22,24,14,18,20,21,22,24,28,51,52,53.58,171,172,173,178
BM 150217	Body Assy-Water Pump	62 thru 67,72,thru 77
F 150219	Gasket-Water Pump Body	36 thru 1947 All
BM 150220	Housing Assy-Water Pump Impeller	36 thru 1947 All
F 150222	Gasket-W/P Impeller Housing	36 thru 1947 All
150224	Impeller-Water Pump (Use 158938)	36 thru 39 All
BM 150225	Cup-Water Pump Impeller	36 thru 1947 All
150226	Hub Assy-W/P Shaft & Pulley (Use 166281)	35 thru 38 Hud 8-Terr,90,92,95,97,98,1940 thru 1942 All
F 150228	Bushing-Water Pump Shaft	35 thru 1947 All
150230	Seal-Water Pump Shaft (Use 155290)	35-36-37 Hud-Terr
F 150231	Spring-W/P Shaft Seal Tension	35-36-37 Hud-Terr
150232	Thrust Washer-W/P Shaft Seal (Use 166298)	35 thru 1942 All
F 150233	Spring-W/P Shaft Seal	35 thru 1947 All
150234	Washer-W/Pump Seal Comp Spring (Use 157895)	
F 150235	Spring-W/P Shaft Seal Retaining	35 thru 1947 All
BM 150236	Pulley Assy-Water Pump	35 thru 1947 All
BM 150241	Extension-Water Pump Pulley	35 thru 37 Hud,6,83,93
F 150242	Fan Belt-Water Pump (Pkg 50)	36 thru 1947 All
150243	Hose-Rad Inlet & W/P Outlet (Use 166283)	36 thru 1942 All
F 150244	Hose-Water Pump By-Pass	62 thru 67,72 thru 77,82 thru 87,92M,93,95,97,43,45,47,15,17,25,27,54,174
A 150245	Guard-Engine-RH-Rear	61,62,63
A 150248	Guard-Engine-LH	61,62
BT 150251	Cover Assy-Transmission	36 Hud-Terr
BT 150257	Switch-Electric Hand Circuit Breaker	36-37 Hud-Terr
BT 150258	Rubber Spacer-Electric Hand Unit to Brkt	36 thru 38 Hud-Terr,92,93,95,97
BT 150259	Rubber Washer-Electric Hand Unit to Brkt	36 thru 38 Hud-Terr,92-93-95,97
C 150270	Center-Front Axle	36 Hud-Terr
150273	Use 150272	
BM 150276	Coil Complete-Ignition-With Lock-Export	36 Hud 8
BO 150278	Coil Assy-Ignition-Includes Bracket	64 thru 67
150282	Use 302599	
150283	Switch Assy-Lighting (Use157048)	'36 Hud-Terr
150284	Nut-Light & Starter Switch Mounting (Use 170553)	36 Hud-Terr
BO 150285	Knob Assy-Lighting Switch	36 Hud-Terr
BO 150286	Switch & Wire Assy-Starter Button	36 Hud-Terr
150290	Horn & Brkt Assy-RH (Use 150786)	62-63-64-66

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
150291	Horn & Brkt Assy-LH (Use 150786)	62-63-64-66
BO 150294	Horn & Brkt Assy-RH	65,67
BO 150295	Horn & Brkt Assy-LH	65,67
BZ 150299	Rod-VD Lever to Acc Shaft	36 All
BZ 150304	Frame Assy	61,62
C 150305	Frame Assy	63
BZ 150330	Bumper-Frame Front Axle	36 Hud-Terr ,89
BZ 150338	Brkt-Frame Frt Stabilizer-RH	36 Hud-Terr
BZ 150339	Brkt-Frame Frt Stabilizer-LH	36 Hud-Terr
BZ 150340	Brkt-Frame Rr Shock Absorbers-RH	36 Hud-Terr
BZ 150341	Brkt-Frame Rr Shock Absorbers-LH	36 Hud-Terr
BZ 150344	Brkt-Frame Front Spring-Front	61,62
BZ 150345	Brkt-Frame Front Spring-Front	63 thru 67
BZ 150346	Brkt-Frame Front Spring-Rear	61,62
BZ 150348	Brkt-Frame Rr Spring-Front-RH	36 Hud-Terr
BZ 150349	Brkt-Frame Rr Spring-Front-LH	36 Hud-Terr
BZ 150350	Brkt-Frame Rr Spring-Rear-RH	36 Hud-Terr
BZ 150351	Brkt-Frame Rr Spring-Rear-LH	36 Hud-Terr
BZ 150358	Bracket-Run Board	61,62
BZ 150359	Bumper-Frame to Rear Axle	36 Hud-Terr
BZ 150364	Washer-VD Cyl Swivel Pin	36 Hud-Terr
150366	Head Assy-Cyl (Use 165534)	61 thru 62
150367	Head Assy-Cyl (Use 165534)	61 thru 62
150368	Head Assy-Cyl (Use 152611)	64 thru 67
C 150376	Head Assy-Cylinder-Export	61X,71X,89X
F 150378	Gasket-Cylinder Head	34-35-36 6Cyl
150379	Gasket-Cylinder Hd Water Outlet (Use 166273)	36 thru 1942 All
BM 150380	Stud-Cylinder Head-Short	36 thru 1947 6 Cyl
BM 150382	Stud-Cylinder Head-Short	36 thru 1947 6 Cyl
150384	Stud-Cylinder Head-Long (Use 170894)	36 thru 38-1941-1942-1946 6 Cyl
150386	Stud-Cylinder Head-Short (Use 301772)	36 thru 1947 Hud 8
BM 150388	Stud-Cylinder Head-Long	36 thru 1950 Hud 8
150390	Outlet-Cyl Head Water (Use 166271)	61,1937 6 Cyl
BM 150391	Outlet-Cylinder Head Water	62 thru 67,72 thru 77 exc 73B
C 150394	Manifold Assy-Exhaust	64 thru 67
BM 150404	Stud-Carb to Manifold-Drilled	36 All,70,71.71X,73B,80,81,88,89,90,92,98,40,48
C 150405	Manifold Assy-Intake	61,62,63
150406	Thermostat-Cyl Hd Water Outlet (Use 166272)	62 thru 67,72 thru 77,82 thru 87,92M,93,95,97,43-45, 47,17,18,25,27
BZ 150407	Lever Assy-Brake Pedal-LHD	36 Hud-Terr
BZ 150409	Shaft Assy-Pedal Lever-RHD	36 Hud-Terr
BZ 150412	Lever-Pedal Lever Shaft End-RHD	36 All
150415	Cover Assy-Cyl Water Jacket (Use 166265)	61 thru 63,70 thru 73,78,80 thru 83,88;90,92,93,98,40 thru 43,48,10,11,12,18,20,21,28
150418	Cover Assy-Cyl Water Jacket (Use 166266)	36 thru 1942 Hudson 8
150421	Shock Abs Assy-Front (Use 159205)	61,62
150422	Shock Abs Assy-Front (Use 159205)	63 thru 67
150423	Shock Abs Assy-Rear (Use 159204)	35G-GU,61,62
150424	Shock Abs Assy-Rear (Use 166137)	36 Hudson
BZ 150425	Brkt-Front Shock Absorbers-Upper-RH	61 thru 67
BZ 150426	Brkt-Front Shock Absorbers-Upper-LH	61 thru 67
150431	Wheel Assy-Steel-16 x 4.00 (Use 166486)	61 thru 67
F 150433	Hub Cap-Wheel-Outer	61,62
F 150434	Hub Cap-Wheel-Outer	63,40-41-10-11-12-18 Export
F 150435	Hub Cap-Wheel-Outer	64,66
150437	Use 151764	
150438	Use 151765	
C 150440	Rear Hub Complete-With Dust Shield	36-37 6 Cyl,80,81,82,83-88,92,93,98,89-90 Cab- CabPu-Panel-Sta,40C,41,48C ,48 7Sed
C 150441	Rear Hub Complete-With Dust Shield	36 thru 39 Hudson 8,43,44,45,47,10C
150442	Use 150440	
150443	Use 150441	
*BZ 150449	Dust Shield-Brake Drum	36-37 6 Cyl,80,81,82,83,88,92,93,98,89-90 Cab- CabPu-Panel-Sta 40C,41,48C,48 7Sed
BZ 150450	Dust Shield-Brake Drum	36 thru 39 Hudson 8,43,44,45,47,10C
BZ 150451	Cover-Brake Drum Insp Hole	36 thru 1940 All,10C
BZ 150468	Cover-Front Spring Seat Center Bolt	36 Hud-Terr,71 thru 77 exc 71B,81 thru 85-87,90 thru 97
BZ 150469	Plate-Rear Spring Clip-RH	36 All
BZ 150470	Plate-Rear Spring Clip-LH	36 All
BZ 150471	Clip-Front Spring	36 All
BZ 150473	Seal-Front Spring Seat Hole	36 thru 38 Hudson-Terr 91 thru 97
F 150474	Shackle-Front Spring-Rear	36 Hud-Terr
F 150475	Bushing Assy-F Spring Shackle	36 Hud-Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 150477	Spring Assy-Front	61-62-63 exc Comm
C 150478	Spring Assy-Front	64 thru 67
CF 150479	Spring Assy-Rear	36 Sedan
150481	Spring Assy-Rear (Use 150479)	36 Bro-3Cpe-VicCpe
BZ 150487	Piston-Rear Shock Absorber	36 Hud-Domestic
EX 150488	Lock-Diff Bearing Adjusting Nut	36 thru 1950 All
BZ 150494	Cross Shaft & Brkt Assy-Cl Cont-LHD	36 Hud-Terr
BZ 150498	Pull Rod Assy-Brake Pedal	36 Hud-Terr
BZ 150500	Push Rod-Brake Pedal-LHD	36 Hud-Terr
BZ 150501	Push Link-Brake Pedal-RHD	36 Hud-Terr
BZ 150504	Brkt Comp-Bke Pedal Link Lever Mtg-RHD	36 Hud-Terr
BZ 150509	Rod-Bke Pedal Link Lever Pull-RHD	36 Hud-Terr
BZ 150510	Lever Assy-Brake Control-LHD	36 Hud-Terr
BZ 150511	Lever Assy-Brake Control-RHD	36 Hud-Terr
BZ 150514	Brkt & Pivot Pin Assy-Brake Control	36 Hud-Terr
BZ 150519	Toggle-Brake Control Lever Cable	36 thru 39 All
BZ 150520	Lever-Hand Brake Cable-LHD	62 thru 67 Without Electric Hand
BZ 150521	Lever-Hand Brake Cable-RHD	36 Hudson-Terr
BZ 150522	Spring-Hand Brake Lever-LHD	62 thru 67 Without Electric Hand
BZ 150529	Brkt-Brke-Cont Master Cyl Mounting-LHD	36 Hud-Terr
BZ 150530	Brkt-Brke-Cont Master Cyl Mounting-RHD	36 Hud-Terr
BZ 150531	Lever Assy-Master Brake Cyl-Operating	36 Hud-Terr
F 150533	Bushing-Master Cyl Oper Lever	36 thru 1947 All
F 150534	Pin-Master Cyl Oper Lever Pivot	36 thru 1947 All
A 150535	Radiator Assy-Include-Shell	61,62
A 150536	Radiator Assy-Includes Shell	63
A 150537	Radiator Assy-Includes Shell	64 thru 67
C 150541	Core Assy-Radiator	61,62
C 150542	Core Assy-Radiator	63
150543	Core Assy-Radiator (Use 165740)	64 thru 67
BZ 150544	Shim-Rad Mtg-Rubber Thin	36 Hud-Terr
F 150545	Cap-Radiator Filler	36 Hud-Terr
F 150547	Hose-Radiator Inlet	36 Hud 8-Terr
BZ 150548	Pipe-Rad Inlet Hose Connecting	63
150550	Hose-Radiator Outlet (Use 166220)	36 thru 39 exc 63-73-83-93,1940 thru 1942 6 cyl
F 150551	Hose-Radiator Outlet	63,73,83,93
BZ 150552	Pipe-Rad Outlet Hose Connecting	63
EM 150553	Element-Cyl Hd Temp Indicator	62 thru 67,37-38 All
C 150555	Arm-Front Axle to Frame	63 thru 67
BZ 150557	Bolt-F/A to Frame Arm Yoke to Axle Pivot	36 Hud-Terr
BZ 150558	Bolt-F/A to Frame Arm to Yoke-Upper	36 Hud-Terr
BZ 150559	Bolt-F/A to Frame Arm to Yoke-Lower	36 Hud-Terr-
BZ 150560	Bolt-F/A to Frame Arm	36 thru 39 exc 89-90-98
BZ 150561	Grommet-F/A to Frame Arm	36 thru 39 exc 89-90-98
BZ 150563	Lock-F/A to Frame Arm to Yoke Bolt-Upper	36 Hud-Terr
BZ 150564	Spacer-F/A to Frame Arm to Yoke Caster Angle	36 Hudson
150565	Gear-Camshaft (Use 165907)	
150566	Gear-Crankshaft (Use 165907)	36 thru 1940 All
150567	Use 153046	
150568	Use 153048	
BZ 150570	Spindle-RH Steering	36 Hud-Terr
BZ 150571	Spindle-LH-Steering	36 Hud-Terr
BZ 150572	Washer-Steering Spindle	36 thru 1950 All
BZ 150583	Valve & Pendulum Assy-VD	36 Hud-Terr
BZ 150587	Brkt Assy-VD Cyl Mtg	36-37 Hudson 8
BZ 150590	Clevis-VD Piston Rod	36-37 Hud-Terr
BZ 150591	Bellcrank Assy-VD	36-37 Hud-Terr
BZ 150594	Rod-VD Bellcrank to Lever	36 Hud-Terr
BZ 150595	Link-VD Bellcrank to Lever Rod	36 thru 1950 All
BZ 150596	Rod Assy-VD Valve	36 Hud-Terr
BZ 150602	Service Kit-Vacumotive Drive-LHD	61,62,63
BZ 150606	Rod Assy-Throttle Cont-Manifold to Carb	61,62,63,70,71,73B,80,81,88,89,90,92,98,40X,41X
BZ 150607	Rod Assy-Throttle Cont-Manifold to Carb	36 Hudson 8
BZ 150608	Brkt-Frame Brake Tube-Front	36 Hud-Terr
BZ 150611	Tool Box Complete	36 Hudson 6
150622	Use 1 Each 153401 and 151578	
EM 150626	Retainer-Valve Spring Seat	36-37 Hud-Terr
EM 150627	Pump & Extension Assy-Water	63,73
150630	Spring Assy-Front-Export (Use 150631)	61,62,63
C 150631	Spring Assy-Front-Export	36 Hudson 8
C 150632	Spring Assy-Rear-Export	36 Sedan
BZ 150651	Rod Assy-Hand Bke Grip & Ratchet	62 thru 67 LHD,61 RHD,61 LHD with Electric Hand, 70 thru 78,80 thru 88,91 thru 97,42 thru 47,12 thru 17,22 thru 27,52,54,172,174

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

179

Part No.	Name	Models
BZ 150652	Grip-Hand Brake-Dash Type	36 thru 39 All exc 89-90-98,43 thru 47,12 thru 17,22
BZ 150653	Brkt Assy-Hand Brake Mounting-Dash Type	thru 27,52,54,172.174,482,484,492,494,502,504
BZ 150654	Brkt-Hand Brke Mounting-Enamel-Dash Type	36 thru 39 exc 89-90-98
BZ 150656	Support-Hand Brake Mtg Brkt-Dash Type	36 thru 1947 All
BZ 150657	Rod-Hand Brake Ratchet	36-37 Hud-Terr
150658	Spring-H/B Ratchet Rod Lock (Use 160084)	36 thru 1947 All
BZ 150659	Housing-Hand Brake Ratchet Rod	36 thru 38 All
BZ 150660	Stabilizer-H/B Ratchet Rod-Inner	36 thru 1947 All
BZ 150661	Stabilizer-H/B Ratchet Rod-Outer	36 thru 1948 All
BZ 150662	Spring-H/B Ratchet Rod Stabilizer-LHD	36 thru 1947 All
CF 150665	Cable & Conduit Assy-Hand Brake	36 thru 1949 All
BZ 150666	Retainer-Brake Cable to Dash	36 Hud,61 LHD with Electric Hand 62,61 RHD
BZ 150667	Bracket-Brake Cable Support	36 thru 1950 All
BO 150670	Switch-Dimmer-LHD	36 thru 1950 All
BO 150672	Knob-Light & Starter Switch	36 Hud-Terr
BO 150673	Spring-Light & Starter Knob Retaining	36 Hud-Terr
BO 150674	Set Screw-Light & Starter Switch Knob	36 Hud-Terr
BZ 150681	Yoke-Brake Pedal Push Rod Adjusting-LHD	36 Hud-Terr
150684	Use 150697	36 Hud-Terr
150685	Use 150698	
150686	Use 150697	
150687	Use 150698	
BO 150688	Antenna & Lead In Wire Assy-Radio-LHD	36 Hud-Terr
BZ 150696	Button-Horn-Ivory	36 Hudson
BZ 150697	Seat & Cap Assy-F Spring-RH	36 Hud-Terr
BZ 150698	Seat & Cap Assy-F Spring-LH	36 Hud-Terr
150702	Bushing-Stabilizer Torsion Bar (Use 165486)	36 Cpe,70 thru 77,81 thru 87,92 thru 97
BZ 150703	Bracket-Stabilizer Torsion Bar Mounting	36 thru 38 Hud-Terr.92,93,95,97
BZ 150704	Connector Assy-Rr Spring Stabilizer	36 Hudson-Terr
150707	Plug-Stabilizer Connector End Adj (Use 154739)	36 Hud-Terr
BZ 150708	Grommet-Stabilizer Connector	36 Hud-Terr
BO 150709	Switch Assy-Service Light	62 thru 67
BZ 150710	Pedal Complete-Ace-Brown-Gray-LHD	36 Hud-Terr
BZ 150713	Spring Clip-Wheel Disc-For Hub Cap	36 Hud-Terr
BT 150717	Rod Assy-"off-on" Switch Operating	36 Hud-Terr
BT 150718	Rod-Circuit Breaker	36-37 Hud-Terr
BT 150719	Sleeve-"off-on" Switch Operating Rod	36-37 Hud-Terr
F 150723	"U" Bolt-Prop Shaft	36 thru 1950 All
F 150724	Lock-Prop Shaft "U" Bolt Nut	36 thru 1950 All,73-83-93 Water Pump
150725	Wheel-Steering-Boxwood Brown (Use 1 each 48595-47627-40784-6)	36 Terr
150726	Use 1 each 48595-47627-40784-6	
150727	Use 151743	
150728	Use 151748	
C 150737	Tube & Bushing Assy-Steering Gear	36 Hud-Terr With Electric Hand
BZ 150749	5/8" Loom-Gen-Horn & Head Lamp Wires	61,62
CF 150752	Hub Cap-Wheel Outer-Large	61,62
150753	Hub Cap-Wheel Outer-Large (Use 150754)	63
CF 150754	Hub Cap-Wheel Outer-Large	64 thru 67
BZ 150755	Spring-Acc Cross Shaft Anti-Rattle	36 RHD With VD
BT 150756	Breather Plug-Speed Gear Housing	36 thru 39 All,1940 Without OD
150757	Use 157204	
150758	Use 157204	
150761	Master Cyl Assy-HYD Brake Control (Use 166276)	36 thru 38 All
BZ 150762	Insulator-Battery Clamp Bolt	36 Hud-Terr
SP 150763	Battery Assy-19 Plate-type 3L-S-115	1936 thru 1947 8 Cyl
150768	Use 153473	
150769	Use 155004	
150770	Use 155005	
150771	Use 159783	
150772	Use 159784	
150777	Use 1 each 152158-152159	
150778	Use 1 each 152158-152159	
150784	Clamp-Tie Rod (Use 153500)	36 Hud 6-Terr
150798	Use 160343	
F 150818	Cable Assy-Battery-Neg to Starter Wire	36 Hud-Terr
BO 150831	Wire Assy-Strg Conn to R Frt Conn-Horn	65,66
BO 150865	Wire Assy-Starter Sw to Frt Conn	63,64,66
BO 150917	Wire Assy-Stop Sw to Tail Lamp	36 Bro-Sed Without Trunk
BO 150923	Wire Assy-Coil Lock to Circuit Breaker Sw	36 Hud-Terr
C 150941	Engine Assy-Std Head	61
BX 150976	Backing Plate Assy-Front Brake-LH	61,62,63
BX 150977	Backing Plate Assy-Rear Brake-RH	36-37 6 Cyl,80,81,82,83,89-90 Cab-CabPu-Panel, Station,40C,41,48

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	
BX 150979	Backing Plate Assy-Front Brake-RH	64 thru 67
BX 150980	Backing Plate Assy-Front Brake-LH	64 thru 67
BX 150981	Backing Plate Assy-Rear Brake-RH	36 thru 39 Hud 8,43 thru 47,10C
BX 150982	Backing Plate Assy-Rear Brake-LH	36 thru 39 Hud 8,43 thru 47,10C
BX 150995	Cap-Backing Plate Conduit Abutment	36-37 All,80 thru 88,92 thru 98,89-90 Cab-CabPu- Panel-Sta,40C,41 thru 48,1941 thru 1950 All
150996	Use 163506-RH, 152174-LH	
150997	Shoes Assy-Brake (Use 163508)	36 thru 38 Hud 8
151010	Lining-Brake-Pkg (Use 2-163507)	36 thru 38 Hud 8-Terr exc 89
151011	Lining-Brake-Pkg (Use 2-163509)	36 thru 38 Hud 8
BX 151012	Pin & Shoe Guide Assy-Brake Anchor	36 Hud-Terr
BX 151014	Washer-Brake Anchor Pin	36-37 All,80 thru 88,89 Cab-CabPu-Panel Sta,40C, 41 thru 48,1941 thru 1950 All
BX 151015	Lever-Brake Shoe Cable-RH	36-37 6 Cyl,80 thru 83,92,93,98,89-90 Cab-CabPu- Panel-Sta,40C,41 thru 48, 1941 thru 1950 All
BX 151016	Lever-Brake Shoe Cable-LH	36-37 6 Cyl,80 thru 83,92,93,98,89-90 Cab-CabPu Panel-Sta,40C,41 thru 48
151017	Lever-R Brake Shoe Cable-RH (Use 154716-8)	36-37 Hud 8
151018	Lever-L Brake Shoe Cable-LH (Use 154717-8)	36-37 Hud 8
BX 151019	Pin-Brake Shoe Cable Lever to Shoe	36-37 6 Cyl,80 thru 83,92,93,98,89-90 Cab-CabPu- Panel-Station,40C,41,48 Sed
BX 151020	Pin-Brake Shoe Cable Lever to Shoe	36 thru 39 Hud 8,10C
151021	Spring-Brake Shoe Cable Lever to Shoe	36-37 6 Cyl,80,81,82,83,88,89 Comm,90,92,93-98,40C, 41 thru 48,1941-1942 6 Cyl,51,52,171,172
BX 151022	Strut-Brake Shoe Cable Lever	36-37 6 Cyl,80,81,82,83,88,89 Comm,90,92,93-98,40C, 41,48,1941-1942 6 Cyl,51,52,171,172
BX 151023	Strut-Brake Shoe Cable Lever-RH	36 thru 39 Bud 8,43 thru 47,10C
BX 151024	Strut-Brake Shoe Cable Lever-LH	36 thru 39 Hud 8,43 thru 47,10C
151025	Spring-Bke Shoe Cable Lever Strut to Shoe	36-37 6 Cyl,80,81,82,83,88,92,93,98,89-90 Comm,40C, 41 thru 48,1941-1942 6 Cyl,51,52,171,172
151026	Spring-Brake Shoe to Anchor Pin	36-37 6 Cyl,80,81,82,83,88,92,93,98,89-90 Comm,40C, 41 thru 48,1941-1942 6 Cyl,51,52,171,172
151027	Spring-Brake Shoe to Anchor Pin	36 thru 39 Hud 8,43 thru 47,10C,14,15,17,24,25,27, 53,54,58,173,174,178,1948 thru 1950 All
151028	Spring-Brake Shoe to Anchor Brkt	36-37 6 Cyl,80,81,82,83,88,92,93,98,89-90 Comm,40C, 41,48
BX 151029	Spring-Brake Shoe to Anchor Brkt	36 thru 39 Hud 8,43 thru 47,10C
151030	Link-Brake Cyl to Shoe (Use 300747)	36 Hud-Terr
BZ 151031	Cyl Assy-RF-Wheel Brake Control	36 thru 38 exc 89,92 thru 98,90 Cab-CabPu-Panel- Sta,40C,41 thru 48,1941-1942-1946-1947 All
BZ 151032	Cyl Assy-LF-Wheel Brake Control	36 thru 38 exc 89,92 thru 98,90 Cab-CabPu-Panel- Sta,40C,41 thru 48,1941-1942-1946-1947 All
BZ 151035	Tube Assy-Master Cyl to LF Hose-LHD	36 Terr
BZ 151037	Tube Assy-Master Cyl to LF Hose-LHD	36 Hud
BZ 151039	Tube Assy-Master Cyl to RF Hose-LHD	36 Terr
BZ 151041	Tube Assy-Master Cyl to RF Hose-LHD	36 Hud 6
BZ 151043	Tube Assy-Master Cyl to RF Hose-LHD	36 Hud 8
BZ 151045	Tube Assy-Brake Control Hyd-LHD	36 Terr
BZ 151047	Tube Assy-Master Cyl to Stop Sw Tee-LHD	66,67
BZ 151049	Tube Assy-Stop Light Sw to Rr Hose	36 Hud-Terr
BZ 151051	Tube Assy-Rr Axle Tee to L Rr Wheel	36 Hud-Terr
BZ 151053	Tube Assy-Rr Axle Tee to F Rt Wheel	36 Hud-Terr
151057	Filler Cap Assy-Master Cyl	36 thru 1940 All,1948 thru 1950
151059	Gasket-Master Cyl Filler Cap	36 thru 1940 All
151064	Head-Master Cyl	36 thru 1940 All
BZ 151065	Gasket-Master Cyl Head	36 Hud-Terr
BZ 151066	Fitting-Master Cyl Head Outlet	36 thru 39 All
BZ 151067	Gasket-Master Cyl Head Outlet & Hill-Hold	36 thru 1950 All
BZ 151068	Bolt-Master Cyl Head Outlet Fitting	36 thru 39 All,1948,1949,501 thru 504 LHD
BZ 151069	Gasket-Master Cyl Hd Outlet Fitting Bolt & Hill-Hold	36 thru 1950
151070	Piston Complete-Master Cyl (Use 301878)	36 thru 1947 All
F 151073	Piston Cup-Master Cyl-Primary	36 thru 1950 All
BO 151075	Piston Cup-Master Cyl-Secondary	36 thru 1947 All
F 151077	Plate-Master Cyl Piston Stop	36 thru 1950 All
F 151078	Lock Wire-Master Cyl Piston Stop Plate	36 thru 1950 All
F 151079	Spring Assy-Master Cyl Piston	36 thru 1941 All
F 151082	Valve Assy-Master Cyl Check	36 thru 1941 All
F 151083	Cup-Master Cyl Check Valves	36 thru 1941 All
151084	Retainer-Master Cyl Check Valve Cup (Use 151082)	36 thru 1941 All
F 151085	Seat-Master Cyl Check Valve	36 thru 1940 All
F 151086	Push Rod Assy-Master Cyl Piston	36 thru 1947 All
F 151089	Guard-Master Cyl Push Rod	36 thru 1947 All
F 151090	Strap-Small-B/C Cyl Push Rod Guard	36 thru 1947 All
F 151091	Strap-Large-B/C Cyl Push Rod Guard	36 thru 1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

181

Part No.	Name	Models
F 151094	Piston-Wheel Cylinder	36 thru 38 exc 89,92 thru 98,90 Cab-CabPu- Panel-Sta,1940 thru 1947 exc 40T-40P
F 151095	Cup-Wheel Cyl Piston	36 thru 1947 All
F 151097	Guard-Wheel Cyl End	36 thru 38 exc 89,32 thru 98,90 Cab-CabPu- Panel-Sta,1940 thru 1950 exc 40T-40P
BZ 151098	Screw-Wheel Cyl Bleeder	36 thru 1948 All
F 151099	Fitting-Wheel Cyl Tube-Rear-Brass	36 thru 1946 All
F 151100	Gasket-Wheel Cyl Tube Fitting	36 thru 1950 All
151101	Hose Assy-Wheel Cyl to Frame (Use 166279)	36 thru 1942 All
BZ 151102	Tee-Tube-Mounts on Rear Axle-Brass	36 thru 1947 All
BZ 151103	Tee-Stop Light Sw Conn	36 Hud & Terr
*SP 151105	Hydraulic Fluid #21-1 pint.	1948-1949-1950 CvBro
BM 151133	Washer-VD Cylinder Mtg Stud	1948 thru 1950 with VD-HDM or SMD
BZ 151146	Felt Assy-VD Cylinder Piston	36 thru 1941 All,1942 thru 1950 with VD-HDM or SMD
BZ 151149	Packing-VD Cylinder Piston	36 thru 1941 All,1942 thru 1950 with VD-HDM or SMD
BZ 151150	Ring-VD Cylinder Piston Packing	36 thru 1941 All,1942 thru 1950 with VD-HDM or SMD
BZ 151181	Tube Assy-Master Cyl to Stop Sw-LHD	63,64,65
BT 151184	Shaft-Reverse Gear-Stationary	36 thru 1940 All
BM 151187	Coupling-Carb Choke Cont Heat Box Tube	72,77,82 thru 85,87,81M,39 thru 1950 All
BM 151188	Nut-Carb Choke Cont Heat Box Tube Coupling	72,77,82 thru 85,87,81M,39 thru 1950 All
CF 151193	Cable Assy-RH-Rear Brake	61 thru 65
CF 151194	Cable Assy-LH-Rear Brake	61 thru 65
C 151195	Cable Assy-RH-Rear Brake	66,67
C 151196	Cable Assy-LH-Rear Brake	66,67
151197	Bracket Assy-Horn (Use 42836)	61
BZ 151211	Cover Assy-Frt Spring-Half Cover	62 thru 67
BZ 151212	Cover Assy-Rear Spring-Front	62 thru 67
BZ 151213	Cover Assy-Rear Spring-Rear	62 thru 67
BO 151214	Cover Kit-Spring	61
BT 151236	Interlock-Trans-Service Kit	32-33K,33KU
BZ 151242	Bracket-Running Board	36 Hudson
BZ 151243	Bracket-Frame to Dust Shield-RH	36 Hudson
BZ 151244	Bracket-Frame to Dust Shield-LH	36 Hudson
BZ 151246	Bracket-Frame to Dust Shield-RH	36 Terr
BZ 151247	Bracket-Frame to Dust Shield-LH	36 Terr
BT 151248	Selector & Wires Assy-Electric Hand	36 Hud-Terr
BZ 151270	Valve-Shock Abs-Front Unit-Monroe	36 Terr
151279	Use 166333	
BZ 151286	Cover-F Spring Center Bolt	36 Comm,70,71B,78,80,88
151288	Bushing Assy-Front Spring-.020 O/S (Use 159180)	36 Hud-Terr exc Comm
BZ 151290	Clip-Front Spring	36 Hud-Terr exc Comm
BO 151315	Capacitor-Radio-Adjustable	36 Hud-Terr
BO 151334	Coil-Radio Antenna	36 Hud-Terr
BO 151336	Coil-Radio Frequency	36 Hud-Terr
BO 151338	Coupling-Radio Condenser Coupling-Short	36 Hud-Terr
BO 151339	Coupling-Volume Control Drive-Long	36 Hud-Terr
BO 151340	Filter-Radio Antenna	36 Hud-Terr
BO 151344	Plug Complete-Radio Brkt & Speaker	36 Hud-Terr
BO 151376	Control-Radio Volume	36 Hud-Terr
BO 151385	Shaft Assy-Tuning Condenser Drive	36 Hud-Terr
BO 151386	Shaft Assy-Vol Control-Flexible	36 Hud-Terr
BO 151387	Shaft-Vol Control-In Head	36 Hud-Terr
BO 151391	Vibrator Complete-Radio	36 Hud-Terr
BO 151393	Cone-Radio Speaker	36 Hud-Terr
BO 151395	Stud Assy-Speaker Mounting	36 Hud-Terr
BO 151397	Knob-Radio Tone Control	36 Hud-Terr,37 6 Tube Radio
BO 151398	Knob-Radio Tuning Control	36 Hud-Terr
BO 151399	Suppressor-Distributor	36 thru 1941 All
BT 151400	Lever-Rev Gear Shifter Pick-Up	36 thru 1940 All
BO 151402	Capacitor-Gas Gauge	36 thru 1942 All
BZ 151404	Radiator Hose-1-5/16" x 36"	30 thru 33 Hud,32-33 Terr
BZ 151405	Radiator Hose-1-3/8" x 36"	33 Hud 6,32-33 Terr
BZ 151406	Radiator Hose-1-1/2" x 36"	24 thru 29 Hud,31 thru 36 Hud,34 thru 36 Terr,1946-1947 All
BZ 151407	Radiator Hose-1-9/16" x 36"	34-35 Hud-Terr,36 Hud 6
BZ 151408	Radiator Hose-1-5/8" x 36"	36 Hud-Terr,1946-1947 All,1950 All
151414	Use 151586	
BO 151416	Bracket Assy-Air Horn-RH	61 thru 67
BO 151417	Bracket Assy-Air Horn-LH	61 thru 67
BZ 151422	Bracket Assy-VD Cyl Mounting	36-37 Hud 6-Terr
BT 151425	Clip-Hyd Brake Control-Tube	36 thru 1947 All
BZ 151430	Tool Bag Assy-Less Tools	36 All,40C,48C,20C,28C,20T, UCpe,1946-1947-1948 All
151431	Jack-Car (Use 1 each of 157668 & 164593)	36-37 Hud-Terr

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
151475	Clamp-Heater Hose (Use 159080)	36 Hud-Terr
151476	Hose-Heater (Use 157031)	All Models
BX 151479	Spacer-F/A to Fr Arm to Yoke Caster Angle- .062	36 Hud-Terr
151480	Rheostat-Instrument Light (Use 160092)	36 Hud-Terr
BT 151491	Segment-Elec Hand Selector Switch	36 Hud-Terr
BT 151492	Lever Assy-Elec Hand Selector	36 Hud-Terr
BT 151494	Spring-Elec Hand Selector Lever	36 Hud-Terr
BT 151496	Spring-Elec Hand Sel Sw Rotor Retaining	36 Hud-Terr
BT 151497	Screw-Elec Hand Selector Cut Out Switch	36 thru 39 All
BT 1498	Plate-Elec Hand Selector Cut Out Switch Cover	36 thru 39 All
BT 151500	Wires Assy-Elec Hand Selector-Lower	36 Hud-Terr
151501	Spring-Hand Brake Cable Lever (Use 162011)	36 Hud-Terr
151521	Guard-VD Cyl Piston Rod (Use 48256)	36-37 Hud-Terr
151526	Shock Abs Assy-Rear (Use 166137)	36 Hud
151527	Use 151788	
F 151528	Hub Assy-Water Pump Shaft & Pulley	35-36 Hud-Terr,73,83
C 151538	Tank Assy-Gasoline	36 Station-Cab-CabPu-Panel
BZ 151539	Filler Neck-Gas Tank	36 Station-Cab-CabPu-Panel
BZ 51540	Extension-Gas Tank Filler Neck	36 Station-Cab-CabPu-Panel
151544	Ball Arm-Steering Gear-LHD (Use 151740 and 151743)	36 Hudson
151545	Ball Arm-Steering Gear-RHD (Use 151748)	36 Hudson
151547	Spring-Drag Link-Rear End•(Use 42899)	36 Terr
BZ 151548	Spacer-Drag Link Ball Seat-Rear End	36 Terr
151549	Shock Absorber Assy-Rear (Use 166138)	36 Hudson
BZ 151554	Tube Assy-Master Cyl to L F Hose-RHD	36 Hud 8
BZ 151558	Tube Assy-Master Cyl to R F Hose-RHD	36 Hud
BZ 151568	Spring-Radiator Outlet Hose Reinf	61,70,71,80,81,88,89,90,91,92,95,97,98, 1940 thru 1947 All
BO 151575	Loom-1/4"-Starter Sw to Relay Wire	36 Hud-Terr
BZ 151578	Crank-Starting	36 thru 1942 All
BZ 151578	Crank-Jack Handle	1946 Cab-CabPu
151580	Cover Assy-Timing Gear (Use 166307)	36 thru 38 AU,39 thru 1942 8 Cyl
BZ 151583	Spacer-Axle to Frame Arm	36 Terr
BM 151585	Brace-Carb Air Cleaner	36 All 6 Cyl
BM 151586	Brace-Carb Air Cleaner	36 Hud 8
151591	Cover Assy-Rear Spring-Front (Use 151212)	62 thru 67 Export
151592	Cover Assy-Rear Spring-Rear (Use 151213)	62 thru 67 Export
151597	Zerk-W/Pump Body (Use 160969)	35-36 Hud-Terr
151598	Use 1 each 151212-151214	
CF 151628	Pipe Assy-Exhaust	61-62 CvCpe
CF 151632	Pipe Assy-Exhaust	64-65 CvCpe
BO 151642	Core-Hot Water Heater	36 DeLuxe Heater
F 151649	Rebushing Kit-Front Axle	34 thru 36 Hud,32 thru 36 Terr
C 151694	Drag Link Assy-Complete-LHD	61,62
C 151695	Drag Link Assy-LHD	61,62
C 151696	Drag Link Assy-Complete-RHM	61,62
C 151697	Drag Link Assy-RHD	61,62
151698	Drag Link Assy-Complete-LHD (Use 151699)	36 Hudson
C 151699	Drag Link Assy-LHD	36 Hudson
C 151700	Drag Link Assy-Complete-RHD	36 Hudson
BZ 151706	Ball Seat-Drag Link-Rear End	36 thru 1950 exc 89-90-98
BZ 151707	Dust Cover-Drag Link-Inner-LHD	36 Hud-Terr
BZ 151708	Dust Cover-Drag Link-Outer-LHD	36 Hud-Terr
BZ 151709	Dust Cover-Drag Link-Inner-RHD	36 Hud-Terr
BZ 151710	Dust Cover-Drag Link-Outer-RHD	36 Hud-Terr
BO 151726	Ferrule-Radio Control Light Socket	36-37 Hud-Terr
C 151728	Shaft-Steering Gear-LH	36 Hud-Terr
C 151729	Shaft-Steering Gear-RH	36 Hud-Terr
C 151732	Column & Worm Assy-Steering Gear-LH	36 Hud-Terr
C 151733	Column & Worm Assy-Steering Gear-RH	36 Hud-Terr
BZ 151738	Thrust Washer-Strg Gear Worm Brg Adj	36 Hud-Terr
BZ 151739	Tube Assy-Steering Gear Housing Cover Grease Retainer	36 Hud-Terr,1946-1947 6 Cyl
BX 151740	Spacer-Frt Axle to Fr Arm to Yoke Caster .020	36 Hud-Terr
151741	Use 151743	
151742	Use 151743	
BZ 151743	Ball Arm-Steering Arm-LHD	36 Hud-Terr
151744	Use 151743	
151745	Use 151743	
151746	Use 151748	
151747	Use 151748	
BZ 151748	Ball Arm-Steering Gear-RHD	36 Hud-Terr
151749	Use 151748	
151750	Use 151748	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

183

Part No.	Name	Models
C 151764	Hub Complete-Front	36-37 6 Cyl Cpe,80 thru 83,88,91,92,93,98,89-90 Cab-CabPu-Panel-Sta,40C,41,48
C 151765	Hub Complete-Front	64 thru 67,74 thru 77,84,85,87,95,97,43, thru 47,10C
151767	Relay-Elec Air Horns (Use 160343)	36 All,38 With Dash Type Horns
C 151781	Torsion Bar-Spring Stabilizer-7/8"	36 Hud-Terr
BZ 151782	Bushing-Spring Stabilizer Torsion-7/8"	36-37 Hud-Terr
BX 151786	Bolt-Front Axle to Frame Arm Yoke to Axle	36 Hud-Terr
BO 151787	Screw-Trans Control Cover Fulcrum	36 thru 39 All With Elec Hand
*F 151788	Reverse Gear-Stationary & Shaft Rotating Assy	36 thru 1940 All
BZ 151790	Spring Clip-1/32-Two Piece-Service	36 thru 39 All
151791	Spring Clip-23/32-Two Piece-Service (Use 151804).	36 All,38 Springs 153750-3-4
BZ 151792	Spring Clip-25/32-Two Piece-Service	36 thru 39 All
BZ 151793	Spring Clip-29/32-Two Piece-Service	36 Hud-Terr
BZ 151794	Spring Clip-17/32-Two Piece-Service	36 thru 39 All
BZ 151795	Spring Clip-17/32-Two Piece-Service	36 thru 39 All
BZ 151796	Spring Clip-1-13/32-Two Piece-Service	36 Hud-Terr
BZ 151797	Spring Clip-1-17/ 32-Two Piece-Service	36 thru 39 All
BZ 151798	Spring Clip-1-21/32-Two Piece-Service	36 thru 39 All,43-45-47 Sed,48P
151799	Spring Clip-1-23/32-Two Piece-Service (Use 151798)	36 thru 39 All
BZ 151800	Spring Clip-1-27/32-Two Piece-Service	36 thru 39 All
BZ 151801	Spring Clip-1-31/ 32- Two Piece-Service	36 Hud-Terr,1940 Springs No 159683-4-5-7-160161
BZ 151802	Spring Clip-Two Pieces-19/32"	36 Springs No 150477-150478
BZ 151803	Spring Clip-Two Pieces-11/16"-Export	36 thru 39 All
BZ 151804	Spring Clip-Two Pieces-3/4"	36 Springs No 150632,150480-81-82,37 Springs No 153762-3-5,154505-8-10-11-12-13
BZ 151805	Spring Clip-Two Pieces-1-3/16"-Export	36 thru 39 All
BZ 151806	Spring Clip-Two Pieces-1-1/32"	36 Springs No 150477-8,38-39 Springs No 157081-2-3
BZ 151807	Spring Clip-Two Pieces-1-5/32" Export	36 Spring No 150630
BZ 151808	Spring Clip-Two Pieces-1-19/32" Export	36 thru 39 All
BZ 151809	Spring Clip-Two Pieces-1-25/32"-Export	36 Spring No 150634,1940 Springs No 161165-6-7-8
BZ 151810	Spring Clip-Two Pieces-1-7/8"-Export	36 thru 39 All,1940 Springs No 161165-6-7-8
BZ 151819	Base Assy-Jack	36-37 Hud-Terr
F 151820	Gasket-Master Cyl Head	36 thru 1940 All
BZ 151823	Grommet-Muffler & Tail Pipe	36 Hud-Terr
151825	Extension-Starting Crank (Use 153401)	36 Terr
BZ 151827	Extension-Starting Crank	36 Hud 8
BZ 151828	Expansion Plug-.602-Brass	36 thru 39 All
C 151847	Leaf-Spring-Main	36 Springs #150479-80-150481-150633-150634
C 151856	Leaf-Spring-Main	36 Springs #150630-31
C 151866	Leaf-Spring #2	36 Spring #150631
C 151867	Leaf-Spring-Main	36 Spring #48000-151283-150632-150635
151883	Bolt-Spring Center (Use 151885)	36 Spring #150477,38-39 Springs #153750-53
151884	Bolt-Spring Center (Use 151886)	36 Spring #150479-80-81
BZ 151885	Bolt-Spring Center	36 Spring #150630-31,37 thru 39 Springs #153754-6-7
BZ 151886	Bolt-Spring Center	36 Spring #150632-35,1940 thru 1947 All
BZ 151887	Bolt-Spring Center	36 Spring #150633-34
BZ 151893	Clip-Spring	36 Springs #150479-80-81
BZ 151896	Plate Assy-Front Spring Spacer	36 thru 39 All
C 151897	Main & Wrapper Leaf Assy-F Spring	36 All
BZ 151901	Guide-Shock Abs Piston Rod-Delco	35-36 Hudson
BZ 151902	Guide & Oil Seal Assy-Shock Abs Piston Rod-Delco	35-36 Hudson
BZ 151903	Screw-Shock Abs Base Oil Filler	36 Hudson
BZ 151904	Gasket-Shock Abs Base Oil Filler Screw	36 Hudson
BZ 151914	Disc-Sh Abs Piston Valve Plate	36 Hudson
F 151932	Water Pump Assy	34-35 exc KU-GH
*F 151933	Water Pump Assy	35 Hud 6
BM 151934	Body Assy-Water Pump	35 Hud-Terr
BM 151937	Impeller-Water Pump	35 Hud-Terr
151953	Center Bolt-Rear Spring (Use 154890)	36 Springs #151284-85
BZ 151959	Clip-Spring-7/8" Two Piece #1	36 thru 39 All
151960	Clip-Spring-1-5/8" Two Piece (Use 151808)	36 Springs #151283,1940 Springs #159683-4-5-7-160161
*SP 151962	Hudsonite Clutch Compound-Gal Can	All Models
*SP 151963	Hudsonite Clutch Compound-5 Gal Can	All Models
*SP 151964	Shock Absorber Oil-Quart Can	All Models
*SP 151965	Shock Absorber Oil-Gal Can	All Models
*SP 151967	Hyd Brake Fluid #21-Quart Can	All Models
*SP 151968	Hyd Brake Fluid #21-Gal Can	All Models
BZ 151974	Center Bolt-Rear Spring	36 Spring-#151283
BO 151975	Projector & Grille Assy-Horn	36 Twin Vibrator Horns
BO 151976	Projector & Grille Assy-Horn	36 Air Electric Horns
BO 151979	Power Plant Assy-RH Horn-High Pitch	36 Twin Vibrator Horns
BO 151980	Power Plant Assy-LH Horn-Low Pitch	36 Twin Vibrator Horns
BO 151982	Power Plant Assy-LH-Hrn-Low Pitch	36 Air Electric Horns
BO 151984	Cap-Horn Power Plant	36 Air Electric Horns

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 51986	Screw-Horn Power Plant Cap	36 All
BO 151987	Bridge-Horn Power Plant-Cap Screw	36 All
BO 151988	Contact Point Assy-Horn Power Plant	36 All
BO 51989	Stud-Horn to Bracket	36 Twin Vibrator Horns
BO 151990	Stud-Horn to Bracket	36 Air Electric Horns
BO 151991	Nut-Horn to Bracket Stud	36 Twin Vibrator Horns
BO 151993	Lock Washer-Horn to Bracket Stud	37 Hud-Terr
151995	Nut-Horn Terminal (Use 12790)	36 Hud-Terr
BM 152005	Drip-Pipe-Intake Manifold-Service Kit	36 All
BM 152008	Ball Check-Intake Manifold-Drip Pipe	36 thru 38 All
BZ 152009	Pedal Complete-Accelerator-RHD	36 thru 1940 All
BZ 152012	Link-Ace Pedal to Shaft Operating-RHD	36 thru 38 All
152020	Use 1 each 152154-152156	
BO 152021	Capacitor-Water Temperature Gauge	36 thru 1946 All
BO 52022	Capacitor-Generator	36 thru 1942 All
BO 152031	Anchor Clip-Radio Antenna	36 thru 39 All
BO 152043	Lock Cylinder-Blank	36 thru 1950 All
152044	Crankshaft Assy (Use 166205)	36 thru 38 6Cyl exc 89
152045	Crankshaft Assy (Use 166337)	36 thru 1942 8 Cyl
152046	Use 155001	
152047	Use 159782	
152049	Use 155005	
152051	Use 159784	
BZ 152061	Base & Tubes Assy-Front Shock Absorber	35-36 Terr-Comm exc UCo
BZ 152063	Spring-Wheel Cylinder Piston Cup	36 thru 1950 All
BO 152073	Capacitor	36 Model CB6 Radio,37 Model DB37 Radio
BO 152074	Capacitor	36 Model CB6 Radio
BO 152075	Capacitor	36 Model CB6 Radio,37 Radio
BO 52076	Capacitor	36 Model CB6 Radio,37 Model DB37 Radio
BO 152077	Capacitor	36 Model CB6 Radio,37 Radio
BO 152079	Coil-Choke	36 Model CB6 Radio,37 Radio
BO 152086	Filter-Antenna	36 Model CB6 Radio,37 Radio
BO 52090	Reactor-Filter-Iron Core	36 Model CB6 Radio,37 Model SA 37 Radio
BO 152100	Resistor-Insulated	36 Model CB6 Radio,37-38 Radio
BO 152102	Resistor-Carbon Type	36 Model C136 Radio,37 Radio
BO 152104	Resistor-Insulated	36 Model CB6 Radio,37 Radio
BO 152108	Socket-Radiotrom-8 Contact	36 Model CB6 Radio,37 Radio
BO 152109	Socket-Radiotrom-6 Contact	36 Model CB6 Radio,37 Radio
BO 152111	Socket-Vibrator-6 Contact	36 CB6 Radio,37 Radio,38 DB38 Radio
BO 152115	Transformer-Second Intermediate	36 Model CB6 Radio,37 Radio
BO 152118	Vibrator-Complete	36 CB6 Radio,37 Radio,38 DB38 Radio
BO 152119	Volume Control	36 Model CB6 Radio,37 Model DB37 Radio
BO 152121	Control Box Complete-Less Cables	36 Model CB6 Radio
152122	Cover and Switch-Control Box (Use 159184)	36 Model CB6 Radio
BO 152126	"A" Lead & Brkt Complete with Male Conn	36 Model CB6 Radio
BO 152127	"A" Lead-Complete With Female Connector	36 Model CB6 Radio,37 Radio
BO 152143	Lead-Antenna-Chassis End	36 Model CB6 Radio,37 Radio
BO 152147	Socket-3 Contact-Reproducer Cable	36 Model CB6 Radio,37 Model DB37 Radio
BO 152148	Tone Control	36 Model CB6 Radio,37-38 Radio
BO 152152	Connector-Speaker-3Contact Male	36 Model CB6 Radio,37 Model DB37 Radio
BO 152154	Speaker Complete-Less Mounting Stud	36 Model CB6 Radio
BO 152156	Stud Assy-Speaker Mounting	36 Model CBS Radio,37 Model DB37 Radio
BX 152158	Dust Seal-Rubber-Outer-Tie Rod End	36-37 Hud-Terr
BX 152159	Dust Seal Insert-Outer-Tie Rod End	36-37 Hud-Terr
152164	Use 151748	
BZ 152165	Bushing-Steering Gear Shaft	34LL,35 HHU
BZ 152170	Plate-Shock Absorber Piston Valve Light	36 Hud
152173	Brake Shoe Assy-RH (Use 163506)	36 All,1937 6 Cyl,80 thru 83,88
152174	Brake Shoe Assy-LH (Use 163506)	36 All,1937 6 Cyl,80 thru 83,88
BO 152191	Washer-Spark Plug-Aluminum	36 Hud-Terr
BX 152192	Zerk Fitting-Pivot Pin Upper	36-37 Hud-Terr
BX 152193	Zerk Fitting-Pivot Pin Lower	36 Hud-Terr
F 152199	Stop Lamp Switch Assy-Mechanical-LHD	36 Hud-Terr
152201	Use 157204	
152202	Tie Rod Assy (Use 157204)	36 Hud 8
F 152217	Guide Assy-Brake Anchor Pin & Shoe	36-37 All,80 thru 88,91 thru 98,89-90 Cab-CabPU-Panel-Station,40C,41 thru 48 10C
BX 152219	Link-Brake Cylinder to Shoe	36 thru 38 All,91 thru 98,90 Cab-CabPu-Panel Station
BT 152220	Cover Assy-Transmission-Elec Hand	36 Hud-Terr
BT 152225	Grommet-Power Unit Mounting Bracket	36 thru 38 All,91,92,93,95,97,1942-1946-1947 with HDM
BT 152226	Switch & Wires Assy-Electric Hand	36 Hud-Terr
BT 152227	Selector Wires Assy-Electric Hand	36 Hud-Terr
BO 152240	Capacitor-Ignition Coil	37 thru 39 All
BT 152243	Power Cyl Assy-Electric Hand	36 thru 39 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 152248	End Plate & Neutral Sw Assy-Elec Hand Cyl	36 thru 39 All
BT 152249	End Plate Assy-Power Cyl	36 thru 39 All
152251	End Plate-Power Cyl (Use 152249)	36 thru 39 All
BT 152253	Gasket-Power Cyl End Plate to Cyl	36 thru 39 All,1942 thru 1950 with HDM
BT 152254	Piston Assy-Power CA.	36 thru 39 All
BT 152255	Piston Plate-Power Cyl	36 thru 39 All,1942 thru 1950 with HDM
BT 152256	Piston Plate-Power Cyl-Center	36 thru 39 All
BT 152257	Packing-Power Cyl Piston	36 thru 39 All,1942 thru 1950 with HDM
BT 152258	Ring-Power Cyl Piston Pack	36 thru 39 All,1942 thru 1950 with HDM
BT 152259	Felt Assy-Power Cyl Piston	36 thru 39 All,1942 thru 1950 with HDM
BT 152261	Retainer-Power Cyl Piston Felt'	36 thru 39 All,1942 thru 1950 with HDM
BT 152262	Rod-Power Cyl Piston	36 thru 39 All
BT 152264	Neutral Sw & Wires Assy-Cyl End Plate	36 thru 39 All
152265	Neutral Sw Assy (Use 152264)	36 thru 39 All
BT 152266	Gasket-Neutral Sw to End Plate	36 thru 39 All
BT 152266	Gasket-Neutral Sw Terminal Cover	36 thru 39 All
BT 152268	Guard-Neutral Sw Terminal Cover	36 thru 39 All
BT 152269	Wire Assy-Neutral Sw to Selector Valve	36 thru 39 All
BT 152270	Lever Assy-Neutral Sw Operating	36 thru 39 All
BT 152273	Lever-Neutral Sw Operating	36 thru 39 All
BT 152274	Spring-Neutral Sw Operating Lever Return	36 thru 39 All
BT 152278	Spring-Neutral Sw Pick Up Lever	36 thru 39 All
BT 162281	Diaphragm Assy-Cross Shift	36-37 Hud-Terr
BT 152282	Diaphragm-Cross Shift	36 thru 39 All,1942 thru 1950 with HDM or SMD
BT 152283	Plate-Cross Shift Diaphragm	36 thru 39 All,1942 thru 1950 with HDM or SMD
BT 152284	Flanged Plate-Cross Shift Diaphragm	36 thru 39 All,1942 thru 1950 with HDM or SMD
BT 152285	Hsg Assy-Cross Shift Diaphragm Rod End	36-37 Hud-Terr,1942-1946-1947 with HDM
BZ 152286	Hsg-Lower-Diaphragm Cyl	1942 thru 1949 with HDM,501 thru 504 with HDM or SMD
BT 152287	Hsg Assy-Cross Shift Diaphragm Pipe End	36 thru 39 All,1942 thru 1950 with HDM or SMD
BT 152292	Valve Assy-Selector	36 thru 39 All,1942 with HDM
BT 152296	Tube Complete-Elec Hand Valve to Cyl Stud end	36 thru 39 All
BT 152299	Tube Comp-Elec Hand Vlv to Cyl-Piston End	36 thru 39 All
BZ 152311 C	Rivet-Brake Cyl to Shoe Link	36 thru 38 All,92 thru 98,90 Cab-CabPu-Panel-Station
BM 152312	Cover-Exhaust Pipe-Front	36 Hud-6-Terr
BM 152313	Cover-Exhaust Pipe-Rear	36 Hud 6-Terr
152315	Tie Rod Ends Complete (Use 159782)	36 Hud 8
152320	Use 155004	
152321	Use 155005	
152322	Use 159783	
152323	Use 159784	
BX 152343	Ball Arm-Steering Gear-LHD	36 Hud
152362	Shock Abs (Use 159218)	
152372	Switch & Wires Assy-Stop Lamp Hydraulic (Use 302599)	36 Hud-Terr
BM 152385	Bracket-Electric Fuel Pump	36 Hud-Terr
C 152509	Cylinder & Pistons Assy	70 thru 73 with 71X Engine
F 152530	Gasket-Intake to Exhaust Manifold	1937 thru 1950 8 Cyl
C 152534	Manifold Assy-Intake	70,71,73B
C 152535	Manifold Assy-Intake	72,73,71M,82,83,81M,92M,93,41,43
C 152536	Manifold Assy-Intake	74 thru 77,84,85,87,95,97,44,45,47
F 152537	Gasket-Intake Manifold to Cyl-Small	1937 thru 1950 8 Cyl
F 152538	Gasket-Intake Manifold to Cyl-Large	1937 thru 1950 8 Cyl
F 152539	Gasket-Intake Manifold to Cyl-Large	37 thru 1947 6 Cyl
BM 152540	Tube Assy-Windshield Cleaner-Copper	71M,72 thru 77,73B,84,85,87
152541	Use 152540	
152546	Zerk Kitting-W/P Body Pres Relief Type (Use 166335)	37-38 All
BX 152547	Seal-Frt Axle Steering Spindle Pivot Pin Key	37 thru 1948 All
A 152549 Pr	Radiator Assy-Includes Shell-Prime	73
A 152549 Lac	Radiator Assy-Includes Shell-Lac	73
152551	Core Assy-Radiator (Use 165530)	70,71,72
152552	Core Assy-Radiator (Use 165530)	73
152553	Core Assy-Radiator (Use 165531)	74 thru 77
F 152554	Filler Cap-Radiator	37 thru 1949 All,500
152555	Hose-Radiator Inlet (Use 166228)	37 thru 39 All,1940 thru 1942 6 Cyl
BZ 152557	Pipe-Rad Outlet Hose Connection	37 All,83,93
BZ 152558	Shim-Radiator Mounting-Rubber	37 thru 1947 All
BZ 152559	Shim-Radiator Mounting-Steel	37 thru 1947 All
BZ 152561	Cross Shaft & Brkt Assy-Clutch Control-LHD	37 thru 1940 All
BZ 152563	Cross Shaft Brkt-Clutch Control-LHD	37 thru 1940 All
BZ 152564	Cross Shaft Brkt-Clutch Control-RHD	37 thru 1940 All
152565	Cross Shaft & Lever Assy-(Use 152561)	37 thru 1940 All
BZ 152570	Coupling Lever-Cl Cont Cross Shaft-LHD	37 thru 1950 All
BZ 152571	Coupling Lever-Cl Cont Cross Shaft-RHD	37 thru 1949 All,501 thru 504
BZ 152572	Pad-Clutch Control Cross Shaft Coupling Lever	37 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	152573 Link Assy-Clutch Control & Brake Pedal (Use 45235)	37 thru 194Q All,1941 RHD
BZ	152575 Push Rod-Brake Pedal to Control Lever	37-38 All
BZ	152576 Adj Yoke & Nut Assy-Brake Pedal Push Rod	37-38 All
BZ	152578 Lever Assy-Brake Control-LHD	37 thru 39 All
BZ	152582 Pivot Pin & Brkt Assy-Brake Cont Lever-LHD	37 thru 39 All
BZ	152586 Spacer-Brake Control Lever Pivot Pin	37 thru 39 All
BZ	152587 Return Spring-Hand Brake Cable Lever	37 thru 39 All
BZ	152588 Lever-Hand Brake Cable-LHD	37 thru 39 All
CF	152594 Cable Assy-Rr Ark-RH-LHD,LH-RHD	70 thru 75,80 thru 85,91,92,93,95,89-90 Comm
CF	152595 Cable Assy-Rr Brk-LH-LHD,RH-RHD	70 thru 75,80 thru 85,91,92,93,95,89-90 Comm
C	152596 Cable Assy-Rr Brk-RH-LHD,LH-RHD	76,77
C	152597 Cable Assy-Rr Brk-LH-LHD,RH-RHD	76,77
BZ	152598 Mounting Brkt-Rear Brake Cable-RH	70 thru 75,80 thru 85,89,90 thru 95,40-41-44 45,1941 thru 1947 exc 17,18,27,28,58,178
BZ	152599 Mounting Brkt-Rear Brake Cable-LH	70 thru 75,80 thru 85,89,90 thru 95,40-41-44 45,1941 thru 1947 exc 17,18,27,28,58,178
BZ	152600 Mounting Brkt-Rear Brake Cable-RH	76-77-78,87,88,97,98,43-47-48-17-18-27-28,58,178
BZ	152601 Mounting Brkt-Rear Brake Cable-LH	76-77-78,87,88,97,98,43-47-48-17-18-27-28,58,178
F	152602 Operating Lever Assy-Brake Cont Master Cyl	37 thru 1940 All
BM	152606 Front Support Plate Assy-Cylinder	74 thru 77,84,85,87,95,97
	152609 Cylinder Head Assy (Use 165534)	70,71,72
C	152610 Cylinder Head Assy	73
C	152611 Cylinder Head Assy	74 thru 77,84,85,87
	152612 Gasket-Cyl Head (Use 166201)	37 thru 1942 6 Cyl
	152613 Gasket-Cyl Head (Use 166240)	37 thru 1942 8 Cyl
	152614 Gauge Assy-Oil Level (Use 162520)	70,71,72,73,78,40,41,43,48
	152615 Gauge Assy-Oil Level (Use 162521)	74 thru 77
	152618 Use 1 each 43114-44540-155852-155857	
	152619 Wheel Assy (Use 166486)	
	152620 Use 154471	
BX	152630 Backing Plate Assy-Right Front	70 thru 73,78,80 thru 83,88,92,93,98, 80-90 Comm 40C,41,48
BX	152631 Backing Plate Assy-Left Front	70 thru 73,78,80 thru 83,88,92,93,98, 80-90 Comm,40C,41,48
BX	152632 Backing Plate Assy-Right Front	74 thru 77,84,85,87,95,97,43,44,45,47,10C
BX	152633 Backing Plate Assy-Left Front	74 thru 77,84,85,87,95,97,43,44,45,47,10C
BT	152642 Coupling Lever-Cl Shifter Yoke Shaft-LHD	37 All
BT	152643 Coupling Lever-Cl Shifter Yoke Shaft-RHD	37 thru 1947 exc 89
C	152644 Camshaft	37 thru 39 6 Cyl
	152645 Camshaft (Use 166221)	37 thru 1942 8 Cyl
	152646 Tappet-Valve (Use 166233)	35 thru 1942 All
BM	152647 Cover Assy-Valve Chamber	37 thru 1947 6 Cyl
F	152649 Gasket-Valve Chamber Cover	37 thru 1947 6 Cyl
	152652 Use 1-154344, 2-154597	
	152655 Carrier & Gear Set Assy-Differential-4-1/9-1 (Use 166333)	37-38 All,90
	152656 Rear Axle Assy-3-1/9 to 1-LHD (Use 1-154348)	70 thru 73,78
	152657 Use 1-154350, 2-154597	
	152658 Use 1-154352, 2-154597	
C	152662 Carrier & Gear Seat Assy-Differential-4-5/9-1	37-38 All,90
	152671 Use 1-154375,2-154597	
	152672 Use 1-154376,2-154597	
	152677 Pinion Assy-Differential (Use 166225)	37 thru 1942 All
F	152685 Hub Cap-Outer-For Steel Wheels & Tire Covers	70,71,72,78
	152686 Hub Cap-Outer-For Steel Wheels & Tire Covers (Use 157543)	73 thru 77
C	152687 Trim Ring-Wheel Rim 15" Diameter	37 thru 1942 All
BT	152689 Bolt-Transmission Bumper-Long	37 thru 39 exc 89,1940 Without OD
	152690 Oil Pan Assy (Use 156641)	70 thru 73,78,80 thru 83,88
	152692 Oil Pan Assy (Use 159513)	74 thru 77,84,85,89
	152694 Suction Pipe-Oil Pan (Use 164736)	37 thru 1942 6 Cyl
BM	152695 Suction Pipe-Oil Pan	37 thru 1942 8 Cyl
F	152696 Shifter Assy-Low & Reverse	35 thru 38 All,39 exc RHD Handy Shift,1940 All
BT	152698 Shifter Fork-Second & High	37 thru 1940 All
BZ	152699 Stud-Throttle Cont Ret Spring-Intake Manifold	73 thru 77,81M,82 thru 85,87
C	152707 Axle Assy-Front-RHD	74 thru 77
	152714 Center Assy-F/A (Use 1-155258,2-170057,2-171427, 2-170006)	71 thru 77
BX	152718 Expansion Plug-Front Axle Center	37 All
	152719 Steering Spindle-RH (Use 155263)	37 All
	152720 Steering Spindle-LH (Use 155264)	37 All
	152721 Thrust Washer & Ball Cup Assy-Steering Spindle Pivot Pin (Use 166262)	37 thru 1942 All
	152722 Use 154490	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
F 152723	Pivot Pin Bushing-Steering Spindle	37 thru 1950 All
152726	Oil Seal-Steering Spindle Pivot Pin (Use 155266)	37 All
152727	Shim-Steering Spindle Pivot Pin-Thin (Use 152728)	37 All
BX 152728	Shim-Steering Spindle Pivot Pin-Mead	37 All
C 152730	Arm-Front Axle to Frame	37 Terr
C 152731	Arm-Front Axle to Frame	37 Hudson
BX 152732	Bolt-Front Axle to Frame Arm-Upper	37-38 exc 89,91 thru 97
BX 152733	Bolt-Front Axle to Frame Arm-Lower	37 All
152735	Use 1 each 154930-170050-170051	
152736	Use 1 each 154931-170050-170051	
152737	Use 1 each 154932-170050-170051	
152738	Use 1 each 154933-170050-170051	
C 152742	Propeller Shaft Assy	70 thru 75
C 152744	Propeller Shaft Assy	76,77,78,87,88,97,98
C 152748	Propeller Shaft	70 thru 75
C 152750	Propeller Shaft	76,77,78,87,88,97,98
152754	Propeller Shaft & Rear Joint Assy (Use 152748)	70 thru 75
C 152756	Propeller Shaft & Rear Joint Assy	76,77,78,87,88,97,98
152759	Use 150435	
152760	Drag Link Assy-LHD (Use 155231)	70,71,72
152761	Drag Link Assy-LHD (Use 155281)	70,71,72
152763	Drag Link Assy-LHD (Use 152764)	73 thru 77,83,84,85,87,93,95,97
C 152764	Drag Link and Plugs Assy-LHD	73 thru 77,83,84,85,87,93,95,97
152766	Drag Link Assy-RHD (Use 155234)	70,71,72
152767	Drag Link Assy-RHD (Use 155234)	70,71,72
152769	Drag Link Assy-RHD (Use 152770)	73 thru 77,83,84,85,87,93,95,97
C 152770	Drag Link and Plugs Assy-RHD	73 thru 77,83,84,85,87,93,95,97
152772	Dust Cover-Drag Link-Inner-LHD	
	(Use 160034 & 160035)	37 thru 1940 All
152773	Dust Cover-Drag Link-Inner-LHD (Use 160034-5)	37 thru 1940 All
BZ 152774	Dust Cover-Drag Link-Outer-RHD	37 thru 1940 All
BZ 152775	Dust Cover-Drag Link-Outer-RHD	37 thru 1940 All
BZ 152776	Boot Assy-Drag Link-Front	37 thru 39 All
BZ 152779	Return Spring-Brake Pedal Lever	37 thru 1947 All
BZ 152782	Pedal Assy-Brake	37 All
BZ 152783	Pedal Assy-Clutch-LHD	37 All
BZ 152791	Lever Assy-Clutch Pedal-RI-ID	37 All
BZ 152792	Lever-Clutch Pedal-LHD	37 All
BZ 152794	Bushing-Clutch and Brake Pedal	37 thru 1947 All
BZ 152795	Lever Assy-Brake Pedal-LHD	36 All
152809	Use 1-155410 & 1-154597	
152810	D.N.S.	
152811	D.N.S.	
C 152812	Frame Assy	76,77
152813	Use 1-154313, 2-154597	
152814	Use 1-154314, 2-154597	
C 152838	Cross Member Assy-Frame Front	70,71,72,81,82,91,92
C 152841	Cross Member Assy-Frame Front	73 thru 77,83,84,85,87,93,95,97
C 152845	Brace-Front Cross Member to Side Member-LH	70,71,71B,72,78,80,81,82,88,92
C 152847	Brace-Front Cross Member to Side Member-LH	73 thru 77,83 thru 87,93,95,97
C 152853	Reinf Assy-Frame Side Member-LH	71-72-81-82-91-92 CvCpe-CvBro
C 152854	Reinf Assy-Frame Side Member-RH	74-75-84-85-95 CvCpe-CvBro
BZ 152864	Cross Member-Frame Radiator Support	73,83,93
BZ 152867	Brace-Fr Side Mem Reinf Frt Engine Sup-RH	71,72,73,78,80,81,82,88,91,92
BZ 152868	Brace-Fr Side Mem Reinf Frt Engine Sup-LH	71,72,73,78,80,81,82,88,91,92
BZ 152869	Bracket-Frame Battery Tray	37 thru 39 All
C 152872	Cross Member Assy-Engine Support-Rear	37 thru 39 exc 89-90-98
C 152878	Front Member-Frame Brace-RH	37 thru 39 CvCpe-CvBro
C 152879	Front Member-Frame Brace-LH	37 thru 39 CvCpe-CvBro
C 152883	Rear Member-Frame Brace-RH	70 thru 73 exc Cv
C 152884	Rear Member-Frame Brace-LH	70 thru 75 exc Cv
C 152885	Rear Member-Frame Brace-RH	76,77
C 152886	Rear Member-Frame Brace-LH	76,77
C 152887	Rear Member-Frame Brace-RH	37 CvCpe-CvBro
C 152888	Rear Member-Frame Brace-LH	37 CvCpe-CvBro
BZ 152889	Brkt-Frame Running Board-Front	73 thru 78,83 thru 88
C 152894	Cross Member Assy-Frame Rear Axle	37 thru 39 exc 89-90
BZ 152896	Shock Absorber Brkt-Frame Rear Axle	37 All
BZ 152897	Shock Absorber Brkt-Frame Rear Member-LH	37 All
C 152900	Cross Member-Frame Rear	37 thru 1940 All
BZ 152901	Brkt-Frame Rear Axle Cr Mbr Brake Tube	37 thru 1947 All
BZ 152905	Brkt-Front Axle to Frame Arm-RH	71 thru 77,81 thru 87,91 thru 97
BZ 152906	Brkt-Front Axle to Frame Arm-LH	71 thru 77,81 thru 87,91 thru 97
BZ 152907	Pedal Complete-Accelerator-LHD	37 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 152911	Mounting-Frame Front Spring-Front	37 thru 39 All
BZ 152911	Mounting-Frame Rear Spring-Rear	1940 thru 1950 All
BZ 152912	Rear Brkt-Frame Front Spring-RH	71,72,81,82,92
BZ 152913	Rear Brkt-Frame Front Spring-LH	71,72,81,82,92
BZ 152914	Rear Brkt-Frame Front Spring-RH	70,71B,78,80,88
BZ 152915	Rear Brkt-Frame Front Spring-LH	70,71B,78,80,88
BZ 152916	Rear Brkt-Frame Front Spring-RH	73 thru 77,83 thru 87,93,95,97
BZ 152917	Rear Brkt-Frame Front Spring-LH	73 thru 77,83 thru 87,93,95,97
BZ 152918	Rear Brkt-Frame Running Board	37 thru 39 All
BZ 152921	Brace-Frame Side Mbr Rein Frt Engine Sup-RH	74,75,76,77,84,85,87,95,97
BZ 152922	Brace-Frame Side Mbr Rein Frt Engine Sup-LH	74,75,76,77,84,85,87,95,97
BZ 152923	Frt Brkt-Frame Rear Spring-RH	70 thru 75
BZ 152924	Frt Brkt-Frame Rear Spring-LH	70 thru 75
BZ 152925	Frt Brkt-Frame Rear Spring-RH	76,77
BZ 152926	Frt Brkt-Frame Rear Spring-LH	76,77
152934	Bracket-Frame Run Bd-Front (Use 152889)	70,71,72,80,81,82,89
BZ 152936	Bumper-Frame Rear Axle	1937 thru 1947 All exc 1941
BZ 152937	Bumper-Frame Rear Axle Differential Carrier	37 thru 1941 exc 90-40-10
152939	Support Assy-Frame Frt Fdr-RH (Use 158589)	37 thru 39 exc 89-90-98
BZ 152940	Support Assy-Frame Frt Fdr-LH	37-38 exc 89
152941	Shock Abs Assy Front (Use 159206)	70,71,72,78,80,81,82,88 with Light Scale Springs
152942	Shock Abs Assy-Rear (Use 166573)	
152943	Shock Abs Assy-Front (Use 166478)	73 thru 77 Light Scale Springs
152944	Shock Abs Assy-Rear (Use 166573)	73 thru 77
BZ 152948	Bolt-Shock Absorber Bracket Bolt	37 thru 1950 All
BZ 152952	Shaft Assy-Pedal Lever-LHD	37-38 All
BZ 152954	Shaft-Pedal Lever-RHD	37 thru 1947 All
BZ 152956	Bracket Assy-Pedal-LHD	37 thru 1940 All
BZ 152959	Spring-Clutch Pedal Lever Return-LHD & RHD	37 thru 1947 All
BZ 152968	Link-Accelerator Pedal to Bell Crank-LHD	37 All
152969	Bell Crank-Acc Pedal Link (Use 156305)	37 All
BZ 152970	Rod-Acc Pedal Bell Crank to Cr Shaft-LHD	37 All
152971	Use 154925	
BZ 152978	Bracket-Accelerator Cross Shaft-LHD	37 thru 1940 exc 89
BZ 152979	Bracket-Accelerator Cross Shaft-RHD	37 thru 1947 All
BZ 152980	Anti Rattle Spring-Accelerator Cross Shaft	37 LHD, RHD With VD
BZ 152982	Rod Assy-Acc Cross Shaft to Manifold Bell Crank	70 thru 73,71M,73B
BZ 152985	Rod Assy-Acc Cross Shaft to Carb Bell Crank	74,75,76,77
BZ 152987	Return Spring-Throttle Control	37 thru 1941 All,1942-1946-1947 RH1?
BM 152989	Stud-Carburetor to Manifold-Plain	72 thru 77,71M,81M,82 thru 87,92M thru 97,41,43 thru 47
BM 152990	Stud-Carburetor to Manifold-Driller	72 thru 77,71M,81M,82 thru 87,92M thru 97,41,43 thru 47
F 152991	Gasket-Carburetor to Manifold	72 thru 77,71M,81M,82 thru 87,92M thru 97,41,42,43,11,12,10-20 with L Engine 21,22, 1946-1947 6 Cyl
152995	Carburetor Assy (Use 158306)	70,71,73B
BM 152997	Carburetor Assy	72 thru 77,71M
*C 153005	Tank Assy-Gasoline	37-38 Bro-Sed-UCo
*C 153006	Tank Assy-Gasoline	37-38 CvCpe-CvBro-3Cpe-VicCpe
*C 153007	Tank Assy-Gasoline	70-80 exc UCo-Sedan
BZ 153008	Filler Neck Assy-Gasoline Tank	37-38 Bro-Sed-UCo
BZ 153009	Filler Neck Assy-Gasoline Tank	37-38 CvCpe-CvBro-3Cpe-VicCpe
BZ 153012	Filler Neck-Gasoline Tank	70-80 exc Sed-UCo
BZ 153013	Extension Assy-Gasoline Tank Filler Neck	70-80 exc Sed-UCo
BZ 153017	Strap-Gasoline Tank	37-38 All,90-98 Business,1940 Cab-CabPu
C 153024	Cable & Conduit Assy-Hand Brake-Dash Type	37 All LHD
BZ 153027	Outlet Unit-Gasoline Tank	37 thru 1941 All,1942 Cab-CabPu-Station, 58,178
153031	Pad-Tank to Rear Seat Tray (Use 1 yd of 149753)	37-38 All,91 thru 97,1940 All,11 thru 17,21 thru 27,18P,10-18-20-28 Cab-CabPu,1946-1947 All
BT 153046	Control Assy-Transmission-Conventional	37 All
BT 153048	Lever Assy-Trans Control-Conventional	37 All
C 153052	Wires & Jacket Tube Assy-Elec Hand	37 All
C 153056	Muffler Assy	70,71,72
153057	Muffler Assy (Use 160004)	73 thru 77
BZ 153058	Clamp-Muffler-Front	37 thru 39 exc 89-90-98,14,15,17,24,25,27,53,54, 173,174,1948,1949,1950
153059	Clamp-Muffler & Trail Pipe-Rear (Use 156845)	70,71,72
BZ 153063	Clamp-Muffler & Trail Pipe-Rear	73 thru 77,38 thru 1947 8 Cyl
153064	Clamp-Tail Pipe Front (Use 160026)	70,71,72
153065	Clamp-Tail Pipe Front (Use 160026)	73,74,75,84,85,97
BZ 153066	Clamp-Tail Pipe Front	76,77,78,87,97,47
153067	Support Assy-Tail Pipe Clamp (Use 157773)	37-38 All
153968	Use 157773	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 153069	Fabric-Tail Pipe Clamp-Front Support	37 thru 39 All,48,1940 thru 1947 6 Cyl
BZ 153070	Bracket-Tail Pipe Rear	37 thru 1947 All
CF 153073	Tail Pipe	70,71,72
CF 153074	Tail Pipe	73,74,75
CF 153075	Tail Pipe	76,77
CF 153076	Exhaust Pipe Assy	70,71,72
CF 153078	Exhaust Pipe Assy	73
CF 153080	Exhaust Pipe Assy	74 thru 77,84 thru 87,95,97
BZ 153082	Bracket-Exhaust Pipe	37 thru 39 exc 89-90-98
BZ 153083	Support-Exhaust Pipe Bracket	37 thru 39 exc 89-90-98
EM 153084	Cover-Exhaust Pipe-Front	70 thru 73-78,80 thru 83,88,92
EM 153085	Cover-Exhaust Pipe-Rear	70 thru 73-78,80 thru 83,88,92
EM 153086	Cover-Exhaust Pipe-Front	74 thru 77,84 thru 87,95,97
EM 153087	Cover-Exhaust Pipe-Rear	74 thru 77,84 thru 87,95,97
EM 153088	Use 154582	
BT 153089	Shaft Assy-Transmission Control	37 thru 39 With Electric Hand
A 153092	Engine Guard-Front	37 thru 39 Hud 8
A 153095	Engine Guard-RH-Front	37 thru 39 Hud 8
A 153106	Engine Guard-Rear	37 thru 1947 All
A 153112	Engine Guard Assy-Front	73,83,93
153116	Engine Guard Assy-RH Front (Use 153095)	37 thru 39 Hud 8
153117	Engine Guard Assy-RH Rear (Use 153118)	70,78,80,88
A 153118	Engine Guard Assy-RH Rear	71,72,73,81,82,83,92,93
A 153119	Engine Guard Assy-RH Rear	37 thru 39 Hud 8
A 153120	Engine Guard Assy-LH	70,78,80,88
A 153122	Engine Guard Assy-LH	73,83,93
A 153123	Engine Guard Assy-LH	37 thru 39 Hud 8
*BM 153137	Air Cleaner-Carburetor-Dry Type	70-71-7-3B-78-80-81-88-90-91-92-94 Without Elec Hand,40,48,10,18,11X,12X,20 With Std Engine,28
*BM 153138	Air Cleaner-Carburetor-Dry Type	72 thru 77,82 thru 87,81M,92M,93,95,97,92,Without Elec Hand,41 thru 47,11 thru 17,10-20 with L Engine,21 thru 27,1946-1947 Without HDM
*BM 153139	Air Cleaner-Carburetor-Dry Type	70,71,73B,78,80,81,88,91,92,With Elec Hand
153140	Air Cleaner-Carburetor-Dry Type (Use 153142-3-4-71384-6440-70708-9665)	72 thru 77,82 thru 87,81M,92M,93,95,97,82, With Elec Hand
EM 153141	Air Cleaner-Carburetor-Oil Bath	70,71,73B
EM 153142	Air Cleaner-Carburetor-Oil Bath	71M,72 thru 77
EM 153143	Brace-Carb Air Clnr-For Oil Bath Type	71M,72,73
EM 153144	Brace-Carb Air Clnr-For Oil Bath Type	74 thru 77,84 thru 87,95,97
C 153147	Manifold Assy-Exhaust	72,73,82,83,92M,93,92,41,43,10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
C 153148	Manifold Assy-Exhaust	74 thru 77
C 153150	Manifold & Damper Assy-Exhaust	72 thru 77,71M,71X,41,43
C 153152	Manifold Assy-Exhaust	70,71,73B,78,80,81,88,89,90,91,92,98, 1940 X Engine
*C 153153	Manifold Assy-Exhaust	37-38 X Engine,40C,48,10,18,20,28
153155	Gasket-Exhaust Manifold-Front (Use 163793)	70 thru 73,78,80 thru 83,81M,88,89
153156	Gasket-Exhaust Manifold-Center (Use 163793)	70 thru 73,78,80 thru 83,81M,88,89
153157	Gasket-Exhaust Manifold-Rear (Use 163793)	70 thru 73,78,80 thru 83,81M,88,89
F 153158	Gasket-Exhaust Manifold-End	37 thru 1950 8 Cyl
F 153159	Gasket-Exhaust Manifold-Intermediate	37 thru 1950 8 Cyl
F 153160	Gasket-Exhaust Manifold-Center	37 thru 1950 8 Cyl
EM 153161	Exhaust Damper	70,71,78,73B,80,81,81M,88,89,37 thru 1941 X Engine,90,91,92,98,40,48,10,18,20,28
EM 153162	Gasket-Exhaust Damper	70,71,78,73B,80,81,81M,88,89,37 thru 39 X Engine,90,92,98,40,48,10,18,20,28
EM 153163	Retainer-Exhaust Damper	70,71,78,73B,80,81,81M,88,89,37 thru 39 X Engines 90,91,92,98
EM 153165	Damper & Shaft Assy-Exhaust	72 thru 77,82 thru 87,92,93,95,97,41 thru 47,10-20 With L Engine,11 thru 17,21 thru 27,1946-1947 All,1948 thru 1950 8 Cyl
EM 153168	Stud-Exhaust Damper Spring-Top	74 thru 77,84 thru 87,95,97,41 thru 47,10-20 With L Engine 11 thru 17,21 thru 27,1946-1947 All,1948 thru 1950 8 Cyl
EM 153169	Cover Assy-Exhaust Damper	72 thru 77,82 thru 87,92,93,95,97,41 thru 47,10-20 with L Engine,11 thru 17,21 thru 27,1946-1947,1948 thru 1950 8 Cyl
153170		
F 153171	Use 153169	
	Gasket-Exhaust Damper Cover	72 thru 77,82 thru 87,92,93,95,97,41 thru 47,10-20 with L Engine,11 thru 17,21 thru 27,1946-1947 All,1948 thru 1950 8 Cyl
BZ 153173	Clip-Wheel Disc-For Hub Cap	37 thru 1950 All
BZ 153179	Rivet-Brake Drum Wheel Pilot	37 thru 1940 All,10C
EM 153181	Distributor Complete	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*BM 153182	Distributor Complete	37 thru 1947 Hud 8
BO 153186	Generator Assy-Use Without Radio	70,71,73B,80 Co-Cpe-Sed
BO 153187	Generator Assy-Includes Pulley	70-71-73B With Radio,72 thru 77,78 Sed
EM 153192	Bracket-Generator Support	37 thru 39 All,40,41X,48,10-20 With Std Engine,18,28,1946-1947 12V,58-178 6V
153194	Charge Regulator-Generator (Use 301484)	70-71-73B With Radio,72 thru 78
153196	Ignition Coil Complete-Includes Lock (Use 157657)	70 thru 73
BO 153200	Switch Assy-Starter	37 All
BO 153201	Collar-Starter & Lighting Switch Mtng	37 thru 1942 All
BO 153202	Knob Assy-Clutch Starter & Lighting Switch	37 All
BO 153203	Knob-Clutch,Starter & Lighting Switch	37 All
BO 153204	Ret Spring-Str Lighting Sw & Radio Cont Knob	37 thru 1947 All
BO 153205	Set Scr-Starter,Light Sw & Radio Knob	37 thru 1947 All
F 153208	Switch Assy-Lighting	37 All
BT 153209	Gasket-VD Shf Rail Sw	37 with Vacuum Clutch
153212	Switch-Dimmer-LHD & RHD (Use 150670)	37 thru 39 All
153213	Switch Assy-Stop Lamp (Use 160090)	37-38 All
BZ 153216	Cyl Valve & Pend Assy-VD	37 with 6 Volt System
BZ 153218	Rod-VD Bellcrank to Cplg Lever	37 All
BZ 153219	Bell Crank VD Valve	37 All
F 153221	Shackle-Front Spring Rear-LH	70 Co,71B,71,72,81,82,91,92
F 153222	Shackle-Front Spring Front-RH	70,7B,78,80,88
F 153223	Shackle-Front Spring Front-LH	70,71B,78,80,88
F 153224	Shackle-Front Spring Front-RH	70 Co,71B,71 thru 77,81 thru 87,89,90 thru 98
F 153225	Shackle-Front Spring Front-LH	70 Co,71B,71 thru 77,81 thru 87,89,90 thru 98
153226	Shackle-RH-Rear Spring Rear (Use 161006)	37-38 All
153227	Shackle-LB-Rear Spring Rear (Use 161005)	37-38 All
BZ 153228	Seat & Cap Assy-Front Spring -	71 thru 77,81 thru 87,91 thru 97
F 153231	Threaded Bushing Assy-Spring Shackle	37 thru 1950 All
F 153232	Threaded Bushing Assy-Spring Shackle	37 thru 1950 All
F 153235	Threaded Bushing Assy-Spring Shackle	37 All,81 thru 85,87,89,90 thru 97
F 153237	Pivot Bolt-Front Spring Rear	70,7113,78,80,88,89,90,98
F 153238	Pivot Bolt-Rear Spring Front	37 thru 39 All
BZ 153239	Bushing-Rear Spring Frt Pivot Bolt	37 thru 39 All
BZ 153240	Plate-Rear Spring Clip-Right	37 thru 39 exc 89
BZ 153241	Plate-Rear Spring Clip-Left	37 thru 39 exc 89
BZ 153246	Brkt-VD Valve Bell Crank	37 All
BZ 153247	Rod Assy-VD Valve	37 All
C 153252	Torsion Bar-Front Spring Stabilizer	37 All
BZ 153254	Mtg Brkt-Frt Stabilizer Torsion Bar-RH	71 thru 77,78 Sec'
BZ 153255	Mtg Brkt-Frt Stabilizer Torsion Bar-LH	71 thru 77,78 Sed
BZ 153256	Connector Assy-Spring Stabilizer	37-38 All
BO 153259	Switch-VD Governor	37 All
BT 153264	Adapter-VD Governor Switch	37 thru 39 All,1940 Without OD
BO 153265	Switch-Vacuum Control Shift Rail	37 All Models
153270	Fuel Pump Assy-RHD (Use 166216)	37 thru 1942 exc 3" x 4-1/8" Engine
EM 153273	Spacer-Fuel Pump to Oil Baffle	37 thru 1947 exc 3" x 4-1/8" Engine
EM 153274	Baffle-Fuel Pump	37 thru 1947 exc 3" x 4-1/8" Engine
EM 153275	Gasket-Fuel Pump	37 thru 1947 exc 3" x 4-1/8" Engine
EM 153276	Spacer-Comb Fuel Pump to Cyl	37 thru 39 exc 89
BT 153277	Cap-Trans ControlLever-Lower-Black	70,71,738,78,80,81,88,91,92
BO 153278	Knob Assy-Radio Control	Model DB37-SA37
153280	Use 154472	
BZ 153282	Drip Pan Assy-Battery	37 thru 1947 6 Cyl
BZ 153283	Drip Pan Assy-Battery	37 thru 1947 Hud 8
153284	Drain Tube-Battery Drip Pan-Rubber (Use 160286).	37 thru 39 All
BZ 153285	Bolt-Battery Clamp	37 thru 39 All
BZ 153286	Insulator-Battery Clamp Bolt	37 thru 39 All
BO 153292	Control Assy-Radio 6 Volt	37 All
BO 153293	Collar-Radio Control Mounting	37 All
BO 153294	Support Assy-Radio Antenna-Front	37 thru 39 All
BO 153297	Support Assy-Radio Antenna-Rear	37 thru 39 All
BO 153303	Horn Assy-Vibrator Type	70,71,78,80,81,88
BO 153304	Bracket Assy-Horn-For Vibrator Type	70,71,78,80,81,88
BO 153310	Plate-Horn Bracket to Dash Bolt	37-38 All,90,91,92,98
153311	Horn & Brkt Assy-RH (Use 155801)	37 All
153312	Horn & Brkt Assy-LH (Use 155802)	37 All
153313	Horn Assy-RH (Use 155801)	37 All
153314	Horn Assy-LH (Use 155802)	37 All
BO 153315	Brkt Assy-Horn-Dash Mount	37-38 All
BO 153319	Relay-Horn-For Air Type Horn	37-38 All
C 153320	Steering Wheel-Black	70,71
153321	Steering Wheel-Tenite (Use 155588)	37 All
C 153324	Steering Gear Assy-RHD	37 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 153325	Ball Arm-Steering Gear-LHD	37 All
BZ 153326	Ball Arm-Steering Gear-RHD	37 All
C 153328	Jacket Tube & Bracket Assy-Steering Gear	70 thru 78 Without Electric Hand
C 153331	Jacket Tube & Bushing Assy-Steering Gear	37 with Electric Hand
BZ 153334	Bushing-Steering Gear Jacket Tube	37 thru 1940 exc 89-90-98
BZ 153335	Cover-Steering Gear Jacket Tube-Oil Hole	37 thru 1947 exc 89-90-98
BZ 153336	Clamp Assy-Steering Gear Jacket Tube	37 thru 1947 exc 89-90-98.1948
BZ 153337	Clamp-Steering Gear Jacket Tube	37 thru 1947 exc 89-90-98
BZ 153338	Horn Button-Black	70,71
153339	Use 155008	
BZ 153340	Cup & Spring Assy-Horn Button	37 All
BZ 153343	Silencer-Horn Button Contact Cup-Rubber	37 All
BZ 153344	Retainer-Horn Button	37 All
BZ 153345	Spring-Horn Button Tension	37 All
BZ 153346	Trim-Ring-Steering Wheel Hub	70,71
BZ 153347	Wire Assy-Horn Button to Connection	37 All
BZ 153349	Insulating Wash-Horn Wire Term Fibre	37 All
BZ 153350	Seat-Horn Button Wire Term Ins Washer	37 All
BZ 153351	Spring-Horn Button Contact	37 All
EM 153353	Pump Assy-Combination Fuel & Vacuum	37-38 exc 89
C 153354	Heat Deflector Assy-Muffler	37 All,84,85,87,95,97
BZ 153356	Strap-Muffler Heat Deflector	37 All,84,85,87,95,97
BZ 153362	Tool Kit Complete	37 thru 39 Cab-CabPu-Panel-Station
153400	Extension-Starting Crank (Use 153401)	70,71,72,78,80,81,82,88,90,91,92,98.40,10-20 Cab-CabPu
BZ 153401	Extension-Starting Crank	73,83,93.41,43,48,11,12,18C,28C,1946-1947 Cab-CabPu
BZ 153402	Extension-Starting Crank	74,75,84,85,87,95,97,44,45,47,14,15,17
BZ 153403	Extension-Starting Crank	76,77,89
BZ 153432	Shaft & Roller Tooth Assy-Steering Gear-LHD	37 thru 39 exc 89-90-98
BZ 153433	Shaft & Roller Tooth Assy-Steering Gear-RHD	37 thru 39 exc 89-90-98
BZ 153437	Cover-Steering Gear Shaft Housing	37 thru 39 All,40,41,44,45,48,10,11,12,18,20,21,28,1946-1947 6 Cyl
BZ 153438	Gasket-Steering Gear Shaft Housing Cover	37 thru 39 All,40,41,44,45,48,10,11,12,18,20,21,28,1946-1947 6 Cyl
BZ 153439	Thrust Washer-Steering Gear Shaft	37 thru 1947 All
BZ 153440	Adjusting Screw-Steering Gear Shaft	37 thru 1950 All
BZ 153441	Lock Plate-Steering Gear Shaft Adj Screw	37 thru 1950 All
BZ 153442	Lock Nut-Steering Gear Shaft Adj Screw	37 thru 1950 All
C 153444	Main Col & Worm Assy-Strg Gear-LHD	37 All
C 153445	Main Col Tube-Steering Gear	37 All
BT 153448	Selector & Wires Assy-Electric Hand	37 All
BT 153451	Gear-Trans Speedometer-4 1/9-1	37 thru 1940 with VD-Without OD
BT 153452	Pinion-Trans Speedometer-4 1/9-1	37 All
153453	Use 153451	
BT 153454	Pinion-Transmission Speedometer-4 5/9-1	37 All
BT 153455	Gear-Trans Spdo-3 8/9-1 & 3 5/9 to 1	37-38 All exc 89
BT 154356	Pinion-Transmission Speedometer 3 8/9-1	74,75
153457	Use 153455	
BT 153458	Pinion-Transmission Speedometer-3 5/9-1	74,75
EM 153459	Pipe Assy-Oil Pump to Cyl	37 thru 1950 8 Cyl
EM 153461	Suction Pipe Assy-Oil Pump	37 thru 1947 8 Cyl
C 153464	Main Col & Worm Assy-Steering Gear-RHD	37 All
BM 153465	Tube Assy-Ignition Cable	70 thru 73
EM 153466	Tube Assy-Ignition Cable	74 thru 77
153471	Use 157204	
153472	Use 157204	
C 153473	Tie Rod	70 thru 73,78
153474	Tie Rod (Use 157205)	70 thru 78,80 thru 88
153475	Use 155001	
153476	Use 159782	
153477	Tie Rod End Complete-RH-Kit (Use 155004)	70 thru 73,78
153478	Tie Rod End Complete-LH-Kit (Use 155005)	70 thru 73,78
153480	Tie Rod End Complete-LH-Kit (Use 159784)	74 thru 77
153481	Use 155004	
153482	Use 155005	
153483	Use 159783	
153484	Use 159784	
F 153497	Grease Fitting-Spindle Supp Arm Lower Bolt & Handy Shift Bellcrank	1940 thru 1950 All
BX 153498	Dust Seal-Tie Rod End-Rubber	37 All
BX 153500	Clamp-Tie Rod	70 thru 73,78
BX 153502	Clamp-Tie Rod	74 thru 77,38 thru 1950 All
153512	Engine Assy (Use 164815)	72

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	153513 Engine Assy (Use 164815)	73
	153516 Engine Assy (Use 164820)	74 thru 77
	153527 Engine Assy (Use 164815)	70,71
BZ	153530 Tube Assy-Master Cyl to L Front Hose-LHD	70,71,72,78,80,81,82,88
BZ	153532 Tube Assy-Master Cyl to L Front Hose-RHD	70,71,72,78,80,81,82,88,91,92
BZ	153534 Tube Assy-Master Cyl to L Front Hose-LHD	37-38 Hudson
	153536 Use 153538	
BZ	153538 Tube Assy-Master Cyl to L Front Hose-RHD	37-38 Hud,93,95,97
BZ	153540 Tube Assy-Master Cyl to R Front Hose-LHD	70,71,72,78,80,81,82,88
BZ	153542 Tube Assy-Master Cyl to R Front Hose-RHD	70,71,72,78,80,81,82,88,91,92
BZ	153544 Tube Assy-Master Cyl to R. Front Hose-LHD	73,83
BZ	153546 Tube Assy-Master Cyl to R Front Hose-RHD	37-38 Hudson,93,95,97
BZ	153548 Tube Assy-Master Cyl to R. Front Hose-LED	74 thru 77,84 thru 87
	153550 Use 154593 for 71 to 75 exc Cv	
BZ	153552 Tube Assy-Master Cyl to Rr Ax Hose-RHD	70 thru 75-80 thru 85
	153554 Use 154595	
	153556 Tube Assy-Master Cyl to Rr Ax Hose-RHD (Use 157146)	76,77,78,87,88
BO	153558 Loom-Hood Lamp Wire	1941 All
BZ	153559 Screen-Gas Tank Outlet Unit	37 thru 1947 All,480 Series
BZ	153560 Clip-Frt Spring-Front Light Scale Springs	71 thru 77,81 thru 87,91 thru 97
BZ	153561 Clip-Front Spring-Rear-Light Scale Springs	71 thru 77,81 thru 87,91 thru 97
BM	153582 Spring-Exhaust Damper Anti-Rattle	72 thru 77,82 thru 87,91,92,93,95,97,11 thru 17, 10-20 With L Eng,21 thru 27.1946-1947 All,1948 thru 1950 8 Cyl
BO	153588 Horn & Bracket Assy-Right-Elec Air Type Fender Mount	37-38 exc 89
BO	153589 Horn & Bracket Assy-Left-Elec Air Type Fender Mount	37-38 exc 89
BO	153594 Trumpet Assy-Horn-Air Type for Fender	37-38 exc 89
	153595 Brkt-RH-Air Type Horn Mtg-Fender (Use 157228)	37-38 exc 89
	153596 Brkt-LH-Air Type Horn Mtg-Fender (Use 157229)	37-38 exc 89
BO	153598 Reinf-Horn Mtg Bracket-For Fender Mount	37-38 exc 89
BO	153599 Plate Horn to Brkt Bolt-For Fender Mount	37-38 exc 89
BO	153622 Connector Assy-Wire-Single	37 thru 1950 All
BO	153623 Connector Assy-Wire-Double	37 thru 1950 All
BO	153624 Loom-3/8"-For Generator Wires	70,71,72,73
BO	153625 Loom-3/8"-For Generator Wires	74 thru 77
BO	153626 Loom-3/4"	37 thru 39 All
F	153627 Cable Assy-Battery to Starter Solenoid	37-38 exc LHD 89,91,92,93,95,97,90-98 RHD
F	153629 Connection-Battery to Ground	70,71,72,78,80 thru 83,88,90,91,92,98
F	153630 Connection-Battery to Ground	74 thru 77,80 thru 88,93,95,97,40 thru 48
BO	153667 Wire Assy-Headlamp-Toe Board to Front Conn	70 thru 78,80 thru 88
	153669 Wires & Sockets Complete-Instrument Lamps (Use 153670)	37 With 6 Volt System
BO	153670 Wires & Socket Assy-Instrument Lamp	37 All
BO	153672 Wires & Socket Assy-Oil Tell-Tale Lamp	37 All
BO	153674 Wires & Socket Assy-Gen Tell-Tale Lamp	37 All
BO	153675 Socket Assy-Instrument & Speedometer Lamp	37 thru 1950 All
BO	153676 Washer-Terminal	37 thru 1950 All
BO	153677 Spring-Terminal Washer	37 thru 1946 All
	153678 Spring-Terminal Washer (Use 164910)	37 thru 1949 All
BO	153679 Socket Assy-Generator Tell-Tale Lamp	37 thru 1941 All
BO	153680 Socket-Lamp	37 thru 1940 All
BO	153685 Wire Assy-Temperature Gauge to Clutch Switch	37 All
BO	153687 Wire Assy-Clutch Switch to Solenoid	37 All
BT	153703 Wire Assy-Elec Hand Switch to Starter	37 All
BZ	153712 Clip-Cable and Pipe	37 All,39 RHD
EM	153714 Wire Assy-Coil to Dist-High Tension	74 thru 77
BZ	153718 Pipe Assy-Clutch Vacuum Control	70-71 With Electric Hand,73B
BZ	153720 Pipe Assy-Clutch Vacuum Control	72-73 With Electric Hand,71M
BT	153727 Pipe Assy-Power Unit Vacuum-Long	70-71-73B With Electric Hand
BT	153729 Pipe Assy-Power Unit Vacuum-Long	72-73 With Electric Hand
BT	153733 Hose-Power Unit Vacuum	37 thru 39 With Electric Hand
BT	153734 Spring-Power Unit Vacuum Hose Reinforcement	37 thru 39 With Electric Hand
BT	153735 Pipe-Power Unit Intake-Long	37 thru 39 6 Cyl With Electric Hand
BT	153736 Pipe-Power Unit Intake-Long	37 thru 39 Hud 8 With Electric Hand
	153737 Use 48603	
BT	153739 Hose-Power Unit Intake	37 thru 39 With Electric Hand
BT	153743 Pipe Assy-Power Unit Intake-Short	37 thru 1940 With Electric Hand or VD,14,15,17,24, 25,27,1946-1947 8 Cyl
BZ	153745 Tube Assy-Rear Axle Tee to Left Rr Wheel	37 All
BZ	153747 Tube Assy-Rear Axle Tee to Right Rr Wheel	37 All
C	153750 Spring Assy-Front	70 Co,71,71B,81,82,92 With Rear Tire Mount
C	153751 Spring Assy-Front	73-83-93 With Rear Tire Mount

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

193

Part No.	Name	Models
C 153752	Spring Assy-Front	37 thru 39 Hud 8 Rear Mt,73-83-93 Side Mt
153753	Spring Assy-Front (Use 154704)	70 Co,71,71B,72,81,82,92 Side Tire Mount
CF 153754	Spring Assy-Front	37 thru 39 Hud 8 With Side Tire Mount
C 153755	Spring Assy-Front-Heavy Scale	71-72-81-82-92 Export Rear Mount
C 153756	Spring Assy-Front-Heavy Scale	73-83-93 Export-Rear Mount
C 153757	Spring Assy-Front-Heavy Scale	37 thru 39 Hud 8,73,83,93
C 153758	Spring Assy-Front	70,71B,78,80,88
CF 153760	Spring Assy-Rear-Light Scale	37 Bro
153761	Spring Assy-Rear-Light Scale (Use 154501)	71 thru 77 Sedan
C 153762	Spring Assy-Rear-Heavy Scale	37 Bro
C 153763	Spring Assy-Rear-Heavy Scale	37 Sedan
153764	Spring Assy-Rear-Light Scale (Use 154501)	76-77 Sedan
BZ 153774	Relief Valve-Rear Shock Abs Piston Valve	70,71,72,78,83 thru 87,91,92
EM 153776	Pipe Assy-Fuel Pump to Carburetor	70,71,73B
EM 153778	Pipe Assy-Fuel Pump to Carburetor	72,73,71M
EM 153780	Pipe Assy-Fuel Pump to Carburetor	74 thru 77
EZ 153782	Pipe Assy-Gas Tank to Fuel Pump	70,71,72,73,80,81,82,83,74-75-84-85 RHD
BZ 153784	Pipe Assy-Gas Tank to Fuel Pump-LHD	74,75,84,85
BO 153801	Core-Hot Water Heater	37-38 Std Heater
BO 153809	Fan Assy-Hot Water Heater	37 DeLuxe Heater #152622
BO 153810	Fan Assy-Hot Water Heater	37 Custom Heater #152623
BO 153812	Motor-Hot Water Heater	37 DeLuxe-Custom Heaters #152622-3
BO 153815	Hose Connection Assy-Hot Water Heater	37 All Heaters,38 Std.Heater
BO 153816	Defroster Knob-Hot Water Heater	37 DeLuxe-Custom Heaters #152622-3
BO 153827	Capacitor-1000 Mmfd	37 Radio-Model DB37-SA37
BO 153828	Capacitor-1100 Mmfd	37 Radio-Model DB37-SA37
BO 153829	Capacitor- .25 Mfd	37 Radio.38 Radio DB38
BO 153830	Coil-Antenna-Includes Shield	37 Radio-Model DB37-SA37
BO 153832	Coil-Oscillator-Less Shield	37 Radio-Model DB37-SA37
BO 153836	Reactor-Filter	37 Radio-Model DB37
BO 153841	Resistor-1 Megohm-1/4 Watt	37-38 Radio
BO 153849	Cover-Control Box Back	37 Radio-Model DB37-SA37
BO 153850	Crystal-Station Selector Dial	37 Radio-Model DB37-SA37
BO 153851	Dial-Station Selector	37 Radio-Model DB37-SA37
BO 153861	Flexible Shaft-Tuning Control-16 3/4" Long	37 Radio-Model DB37-SA37
BO 153862	Flex Shaft-Volume Control-20 3/4" Long	37 Radio-Model DB37-SA37
BO 153863	Shaft-Volume Control-Includes Switch Oper Pin	37 Radio-Model DB37-SA37
BO 153867	Switch-Off & On Operating	37 Radio-Model DB37-SA37
BO 153873	Cable-Reproducer 3 Conductor Shielded	37 Radio-Model DB37
BM 153881	Drip Pipe Assy-Intake Manifold	70,71,73B,72-73 With 71X Eng,78,80,81,88
BO 153900	Capacitor-.005 Mfd	37 Radio-Model SA37,38 Radio
BO 153904	Coil-Radio Frequency-Less Shield	37 Radio-Model SA37
BO 153912	Volume Control	37 Radio-Model SA37
BZ 153938	Cover Assy-Front Spring-LH	72,82,92
BZ 153939	Cover Assy-Front Spring-RH	37-38 Hud,93,95,97
BZ 153941	Cover Assy-Rear Spring-Front-RH	71 thru 77 Bro-Sed-Cpe-CvBro
BZ 153942	Cover Assy-Rear Spring-Front-LH	71 thru 77 Bro-Sed-Cpe-CvBro
BZ 153943	Cover Assy-Rear Spring-Rear-RH	71 thru 77 Bro-Sed-Cpe-CvBro
BZ 153944	Cover Assy-Rear Spring-Rear-LH	71 thru 77 Bro-Sed-Cpe-CvBro
153945	Twin Horn Kit-Dash Mtg (Use 155805)	37 All
BO 153946	Twin Horn Kit-Fender Mount	37 All,80,81,82,88
BZ 153949	Loom-Stop Light Wires-5/16" I D	37 thru 39 All
BT 153950	Housing-Electric Hand Selector Switch	37 All
BT 153952	Shaft Assy-Selector Switch	37 All
BT 153955	Spring-Selector Switch Shaft Return	37 thru 39 All
BT 153963	Segment-Elec Hand Selector Switch (H Plate)	37 thru 39 All
BT 153964	Lever Assy-Electric Hand Selector Switch	37 thru 39 All
BT 153966	Base & Wires Assy-Elec Hand Selector Switch	37 thru 39 All
BT 153968	Rotor Assy-Elec Hand Selector Switch	37 thru 39 All
BT 153970	Spring-Electric Hand Sel Sw Rotor Return	37 thru 39 All
BT 153971	Wires Assy-Selector Switch-Upper	37 All
BT 153973	Conn Assy-Selector Switch Wires-Male Half	37 All
BT 153974	Conn Assy-Selector Switch Wires-Female Half	37 All
BT 153977	Cap-Selector Switch Wires Connector	37-38 All,91,92,93,95
BT 153979	Lower Harness-Elec Hand	37 All
BT 153981	Wires Assy-Selector Switch Lower	37 All
BO 153992	Antenna Kit-Radio-LHD	37 All
BT 153996	Plate Assy-Selector Valve	37-38 All,1942 With HDM
BT 153998	Cover Assy-Transmission	37 thru 39 All
BT 154042	Square Drive Shaft-Governor Switch	37 thru 1940 All
BZ 154043	Circuit Breaker-VD Gov	37 thru 1940 All
BZ 154044	Gasket-Governor Switch	37 thru 1941 All
BZ 154066	Spring-VD Governor Contact	37 thru 1940 All
BZ 154067	Valve Assy-VD	37-38 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 154072	Cover-VD Accelerator Valve	1937 All
BZ 154076	Coil & Hsg Assy-VD Valve Solenoid	37 All
BZ 154082	Gasket-VD Valve Solenoid Hdg	37 All
BZ 154087	Plunger-VD Valve Solenoid	37 with VD
BZ 154090	Pendulum Assy-VD Cyl	37 All
BO 154112	Extension-Tire Tube Valve	37-38 With Fender Well & Cover
*BZ 154133	Shaft Assy-Pedal Lever	37 With Hill Hold,38 thru 1940 All
154145	Wire Assy-Relay (H) to Front Conn (Use 155976)	37 With Twin Fender Horns
BT 154158	Wire Assy	37 All
154184	Pump Assy-Fuel-RHD (Use 166217)	37 thru 1942 8 Cyl
EM 154186	Pipe Assy-Fuel Pump to Carburetor-RHD	74 thru 77,84 thru 87
EM 154192	Sleeve Comb-Fuel Pump to Cyl Bolt	37 thru 1950 exc 3" x 4 1/8" Engine
EM 154193	Washer-Fuel Pump to Cyl Bolt	37 thru 1950 exc 3" x 4 1/8" Engine
BO 154199	Switch-Rear Door Dome Lamp	75,77,85,87,97,43,47,17
BO 154195	Nut-Rear Door Dome Lamp Switch	75,77,85,87,97,43,47,17
BX 154199	Spacer-Front Axle to Frame Arm Caster Angle	71 thru 77,81 thru 87,91 thru 97
BT 154200	Power Unit Assy-Elec Hand	37 with 6 Volt System
BZ 154209	Washer-Shock Abs Piston Support-Monroe	70,71,72,78,80,81,82,88,89,90,91,92,98,10T, 10P,11,12,10 UCo-UCpe
BZ 154210	Valve-Shock Abs Piston Intake-Monroe	70,71,72,78,80,81,82,88,89,90,91,92,98,10T, 10P,11,12,10 UCo-UCpe,20 thru 25,51,171
BZ 154211	Spring-Shock Abs Piston Intake Valve-Monroe	70,71,72,78,80,81,82,88,89,90,91,92,98,10T, 10P,11,12,10 UCo-UCpe,20 thru 25,51,171
BZ 154212	Valve Spring-Rear Shock Abs Compression-Monroe	70,71,72,78,80,81,82,88
BZ 154217	Gasket-Shock Abs Seal Tube-Lea-Monroe	70,71,72,78,80,81,82,88,89,90,91,92,98
BZ 154218	Spring-Shock Abs Seal Tube Gasket-Monroe	70,71,72,78,80,81,82,88,89,90,91,92,98
BZ 154219	Washer-Shock Abs Seal Tube Gasket-Monroe	70,71,72,78,80,81,82,88,89,90,91,92,98
159220	Retainer Washer-Shock Abs Seal Tube Gasket-Monroe (Use 157407)	70,71,72,78,80,81,82,88,89,90,91,92,98
BZ 154221	Ring-Shock Abs Seal Tube Gasket Support	70,71,72,78,80,81,82,88,89,90,91,92,98
BZ 154235	Clip-Front Spring Front	71 thru 77,83 thru 87,93,95,97
BZ 154236	Clip-Front Spring Rear	71 thru 77,83 thru 87
BZ 154237	Clip-Rear Spring	70 thru 78,80 thru 85-87-88-89-90-98 Cab-CabPu- Panel,91 Panel
BZ 154238	Washer-Horn Button to Conn Wire Terminal-Upper	37 All
BT 154239	Sleeve Transmission Speedometer Pinion	37 thru 39 All,1940 Without OD
HZ 154246	Screw-Shock Absorber Base Oil Filler	73 thru 77,83 thru 87,93,95,97
154251	Piston-Shk Abs-Delco (Use 154988)	73 thru 77
BZ 154253	Guide-Shock Abs Piston Rod-Delco	73 thru 77,83 thru 87,93,95,97
BZ 154255	Ret-Shock Abs Piston Rod Guide Gskt-Delco	73 thru 77,83 thru 87,93,95,97,43 thru 47,14-22-24 exc
BZ 154257	Plate-Shock Abs Piston Valve-Delco	Cpe,27,21 Station,1946-1947 All
BZ 154258	Spring-Shock Abs Piston Valve Plate-Delco	73 thru 77,83 thru 87,93,95,97,43 thru 47,14-22-24 exc Cpe,27,21 Station,1946-1947 All
BZ 154275	Pressure Tube-Front Shock Abs-Delco	73 thru 77,83 thru 87,93,95,97,43 thru 47,14-22-24 exc Cpe,27,21 Station,1946-1947 All
BZ 154280	Shield Tube-Front Shock Abs-Delco	73 thru 77,83 thru 87,93,95,97,43 thru 47,14-22-24 exc Cpe,27,21 Station,1946-1947 All
154293	Nut-Generator (F) Terminal Post (Use 71073)	37 thru 1946 All
BZ 154299	Bracket-Frame Body Bolt #4	37 thru 1942 CvCpe-CvSed,18,10-20 Cab-CabPu,11- 21 Station,28C,1946-1947 CvBro-Cab-CabPu
154309	Use 155410	
C 154313	Frame Assy	71-72-81-82-92 Cv
C 154314	Frame Assy	73-83-93 CvCpe-CvBro
154328	Brkt-Frame Rear Spring-Front (Use 154702 or 154703 LH)	70 thru 78
BZ 154329	Reinforcement-Rear Spring F Bracket	1937 thru 1942 exc Cv & Comm,51 thru 54-171 thru 174 exc CvBro
154330	Use 154329	
154331	Propeller Shaft Assy (Use 157845)	
154333	Use 157845	
154335	Use 157845	
C 154344	Axle Assy-Rear-LHD-4 1/9 to 1	76,77
C 154348	Axle Assy-Rear-LHD-4 5/9 to 1	70 thru 73
C 154350	Axle Assy-Rear-LHD-4 5/9 to 1	74,75
C 154352	Axle Assy-Rear-LHD-4 5/9 to 1	76,77
C 154375	Housing Complete-Rear Axle-Less Brake Shoes	70 thru 73,78
C 154376	Housing Complete-Rear Axle-Less Brake Shoes	74 thru 77
BO 154384	Wire & Loom Assy-Generator	70-71-78 exc Radio
BO 154385	Wire & Loom Assy-Generator	70-71 With Radio,72,73,78 Sedan
BO 154386	Wire & Loom Assy-Generator	74,75,76,77
154406	Relay Assy-12 Volt (Use 159105)	70,78,80,81,88 exc Sed
BO 154416	Horn Assy-Vibrator Type-12 Volt	70,71

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 154417	Horn & Bracket Assy-RH-Air Type-12 Volt	37 All
BO 154419	Horn Assy-Air Type-Dash Mount-12 Volt	37-38 All
154421	Use 155869	
154432	Shock Absorber Assy-Front (Use 166477)	70,71,72,80,81,82,88 with Heavy Scale Springs
154433	Shock Abs Assy-Rear (Use 166573)	
154434	Shock Abs Assy-Front (Use 166477)	73 thru 77
154435	Shock Abs Assy (Use 166575)	
BZ 154447	Bolt-Brake Master Cyl Head Outlet Fitting	37 thru 1940 With Hill Hold,1942 All
BZ 154447	Bolt-Hill Hold to Master Cyl	1941 thru 1946 All
BZ 154448	Protector-Master Cyl Head Outlet Fitting Bolt	37 thru 1940 With Hill Hold,1941 All
C 154454	Cable Assy-Rear Brake-RH-LHD,LH-RHD	76,77,78,87,88,97,98
C 154455	Cable Assy-Rear Brake-LH-LHD,RH-AHD	76,77,78,87,88,97,98
F 154460	Spring-Brake Shoe to Anchor Pin-Secondary	70 thru 73,78,80 thru 83,88,92,93,98,89-90 Business Cars ,40C,48C .41.48 Sed
EX 154461	Spring-Brake Shoe to Anchor Pin-Secondary	74 thru 77,84 thru 87,95,97,43 thru 47,10C
BM 154462	Oil Baffle Assy-Combination Fuel Pump	37-38 exc 89
154469	Wheel Assy-Steel-16x 4.00 (Use 166486)	71,72,73
154470	Wheel Assy-Steel-16x 4.00 (Use 166486)	74 thru 78,70
CF 154471 Pr	Wheel Assy-Steel-15 x 5.00	71 thru 77
C 154472	Finish Ring-Wheel Disc	37 With 16" Wheels
154482	Clip-Wire (Use 161137)	37 thru 1941 All
BZ 154483	Clip-Battery to Starter Solenoid Cable	37 thru 1947 exc LHD 89-90-98
EX 154488	Relief Valve Assy-Front Axle Center Expan	1937 thru 1950 All
EX 154489	Expansion Plug-Front Axle Center-Tapped	1937 thru 1950 All
F 154490	Pivot Pin-Front Axle Steering Spindle	37 thru 39 All
BZ 154497	Screw-Jack	36-37 All
BZ 154499	Damper-Shock Abs Piston Valve Spring	73 thru 77,83 thru 87
CF 154500	Spring Assy-Rear-Light Scale	71 thru 75 Bro-Sedan
CF 154501	Spring Assy-Rear-Light Scale	71 thru 78 Sedan
154502	Use 154501	
CF 154504	Spring Assy-Rear-Light Scale	73 thru 75 CvCpe-3Cpe-VicCpe,37 CvBro
C 154506	Spring Assy-Rear	70-78-80-88-98 CabPu-Station
C 154507	Spring Assy-Rear	70,78,80,88,98 Cab-Panel,91 Panel
C 154508	Spring Assy-Rear	70 UCpe
154510	Spring Assy-Rear-Heavy Scale (Use 154511)	71 thru 75 Bro,73 thru 75 CvBro-3Cpe-VicCpe
C 154511	Spring Assy-Rear-Heavy Scale	37 Sedan
154519	Spring Assy-Rear-Light Scale (Use 154504)	71 thru 75 Bro-CvBro,73-74-75 Cpe,73B
154520	Spring Assy-Rear-Light Scale (Use 154504)	71-72 CvCpe-3Cpe-VicCpe,71B
C 154549	Case Assy-Transmission	37 All
*F 154551	Countershaft-Transmission	37 All
BT 154553	Bushing-trans Countershaft-Front	37 thru 1940 All
F 154554	Drive Gear-Trans Countershaft	37 All
BZ 154567	Cushion-Front Stabilizer Connector	71 thru 77
BZ 154568	Bearing-Front Stabilizer Connector Cushion	71 thru 77,81 thru 87,78-80-88 Sedan
BM 154574	Piston Assy	37 thru 1941 X Engine
BM 154576	Ring-Piston Compression	37 thru 1941 X Engine
BM 154578	Ring-Piston Oil	37 thru 39 X Engine
BM 154580	Pin-Piston Ring	37 thru 1940 X Engine
154581	Fabric-Tail Pipe Clamp to Support-Short (Use 153069)	37-38 All
BZ 154582	Fabric-Tail Pipe Clamp-Rear	37-38 All.39 thru 1942 Cab-CabPu-Panel,58,178
154585	Resistor Assy-Inst Panel Cigar Lighter-12 Volt (Use 156198)	75,77
BZ 154586	Clip-Front Springs-Front	71B,80-88 Sedan
BT 154588	Drive Shaft-Governor Switch Adapter	37 thru 1940 All
BZ 154593	Tube Assy-Master Cyl to Rear Axle Hose	70 thru 75,80 thru 85 exc Cv
BZ 154595	Tube Assy-Master Cyl to Rear Axle Hose	76,77,78.87,88
BZ 154597	Tapered Shim-Rear Axle Housing Spring Seat	37 All
BM 154599	Pump Assy-Water	71B,73B
154613	Flywheel Complete (Use 160221)	70 3xc Co-Cpe,80 exc Co-Cpe-Sed,78,82,83,88
CF 154617	Tail Pipe Assy	78
154623	Engine Assy (Use 164815)	78
BZ 154629	Spring-Hydraulic Hill Hold	37 thru 1940 exc 89
C 154641	Rear Axle Assy-4 1/9 to 1-RHD	78
C 154642	Rear Axle Assy-4 5/9 to 1-LHD	78
C 154643	Rear Axle Assy-4 5/9 to 1-RHD	78
EX 154652	Grease Fitting-Tie Rod End Cover-45°	37 thru 1940 All
C 154657	Torsion Bar Assy-Front Stabilizer	71 thru 77 All,78 Sed
BZ 154702	Bracket-Frame Rear Spring Front-RH	37 thru 39 exc 89-90
BZ 154703	Bracket-Frame Rear Spring. Front-LH	37 thru 39 exc 89-90
C 154704	Spring Assy-Front-Heavy Scale	71,72,81,82,91,92,Side Mount
C 154705	Spring Assy-Front-Heavy Scale	74 thru 77,84 thru 87.95,97 Side Mount
154707	Shock Abs Assy-Rear (Use 166573)	70 Co-Cpe 71,72,78,80,81,82,88 Sedans
154708	Shock Abs Assy-Rear (Use 166139)	73 thru 77
154709	Shock Abs Assy-Rear (Use 166573)	70 Co-Cpe,71,72,78,80,81,82,88 Sedans

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	154710 Shock Abs Assy-Rear (Use 166140)	73 thru 77
C	154715 Cable & Conduit Assy-Hand Brake-RHD	70 thru 78
BX	154716 Lever-Brake Shoe Cable-RH	74 thru 77,84 thru 87,95,97,43 thru 47,10C
BX	154717 Lever-Brake Shoe Cable-LH	74 thru 77,84 thru 87,95,97,43 thru 47,10C
BX	154718 Spring Washer-Brk Shoe Cable Lev to Shoe Pin	74 thru 77,84 thru 87,95,97,43 thru 47,10C,14,15,17,24,25,27,53,54,58,173,174,178,1948 thru 1950 All
BZ	154719 Rod-Hyd Hill Hold Valve	37 thru 1940 All
BZ	154720 Connector-Hyd Hill Hold Valve Rod	37 thru 1940 All
BZ	154721 Guide Assy-Hyd Hill Hold Valve Lever & Rod	37 thru 1940 All
BZ	154723 Plug-Hyd Hill Hold Valve Body	37 thru 1947 All
BZ	154724 Gasket-Hyd Hill Hold Valve Body Plug	37 thru 1947 All
BZ	154725 Plug-Hyd Hill Hold Valve Body	37 thru 1947 All
BZ	154726 Gasket-Hyd Hill Hold Valve Body Plug	37 thru 1947 All
BZ	154728 Screw-Hill Hold Valve Lever Clamp	37 thru 1947 All
BZ	154729 Fitting-Hyd Hill Hold Outlet	37-38 All
BZ	154730 Ball & Cage Assy-Hyd Hill Hold	37 thru 1947 All
BZ	154731 Spring-Hyd Hill Hold Ball Cage	37 thru 1947 All
BZ	154732 Camshaft-Hyd Hill Hold	37 thru 1940 All
BZ	154733 Washer-Hyd Hill Hold Camshaft Sealing	37 thru 1947 All
BZ	154734 Spring-Hyd Hill Hold Camshaft Sealing	37 thru 1947 All
EM	154736 Brace-Carburetor Air Cleaner	37 Models (Oil Bath Cleaner & Single Carb)
BZ	154737 Spring-Throttle Control Return-Carb	71M,72,73
BZ	154738 Seat-Frt Stabilizer Connector Cushion-Inner	71 thru 77,81 thru 87,78-80-88 Sedan
BZ	154739 Plug-Front Stabilizer Connector Adjusting	71 thru 77,81 thru 87,78-80-88 Sedan
EM	154740 Stud-C/Shaft Brg Stud-3 1/2" long-No 2 Brg	37 thru 1947
EM	154741 Stud-Crankshaft Bearing Stud-3 1/4" Long	37 thru 1947 All,1948 thru 1950 8 Cyl
EM	154742 Stud-Crankshaft Bearing Stud-4 1/8" Long	37 thru 1947 All,1948 thru 1950 8 Cyl
C	154745 Reinforcement Assy-Frame Side Member-RH-Front	73-83-93 CvCpe-CvBro
C	154746 Reinforcement Assy-Frame Side Member-LH-Front	73-83-93 CvCpe-CvBro
BO	154749 Cover-Horn Power Unit-Air Elec-Fender Mount	37-38 All
C	154754 Carrier & Gear Set Assy-5 1/8 to 1	70,78,80,88
BX	154756 Drive Gear-5 1/8 to 1	70,78,80,88
BX	154757 Drive Pinion-5 1/8 to 1	70,78,80,88
BT	154769 Gear-Trans Speedometer-5 1/8 to 1	37-38 All
BZ	154774 Spring-Clip-Two Piece-No 1 & No 4	37 thru 39 All
BZ	154775 Spring Clip-Two Piece-No 4	37 Springs No 153760-1-4-154500-1-2-3-4
BZ	154776 Spring Clip-Two Piece-No 4	37 thru 39 All
BZ	154777 Spring Clip-Two Piece-No 2 & No 3	37 thru 39 All
BZ	154778 Spring Clip-Two Piece-No 2 & No 3	37 thru 39 All
BZ	154779 Spring Clip-Two Piece-No 2 & No 3	37 thru 39 All
BZ	154780 Spring Clip-Two Piece	37 thru 39 All
BZ	154781 Spring Clip-Two Piece-No 2 & No 3	37 thru 39 All,1941 Springs No 161165-6-7-8
BZ	154782 Spring Clip-Two Piece-No 2	37 thru 39
BZ	154782 Spring Clip -Two Piece-No 3	37 Springs No 153760-1-4,154501-2-3-4
BZ	154783 Spring Clip-Two Piece-No 3	37 thru 39 All,1940 Spring No 159686
BZ	154784 Spring Clip-Two Piece-No 3	37 thru 39 All
C	154788 Leaf-Spring-Rebound	37 thru 39 Spring No 153753
C	154789 Leaf-Spring-Rebound	37 thru 39 Spring No 153750
C	154792 Leaf-Spring-No 3	37 thru 39 Springs No 153750 & 153753
C	154796 Leaf-Spring-No 4	37 thru 39 Spring No 153750
C	154825 Leaf-Spring-No 2	37 thru 39 Springs No 153756-153757
C	154844 Leaf-Spring-No 1	37-38 Springs No 153756-153757
C	154845 Leaf-Spring-No 1	37-38 Spring No 153758
C	154851 Leaf-Spring-Rebound	37 Springs No 153760-1-2-3-4,154500-1-2-3-4-5-8-10-11-12-13-38 Springs 155550-1-2-3,155570-1-2-3,155577-8,39 Springs No 155550-1-2-70-1-3 157593-4-5-6-7-8-9
C	154853 Leaf-Spring-No 3	37 Springs No 153760-1-4,154500-1-2-3-4-38-39 Springs 155550-1-2-3,39 Springs No 157593-4-5
C	154864 Leaf-Spring-No 1	37 Springs No 154500-1-2-3-4,153760,1-4,38-39 Springs 155550-1-2-3
C	154865 Leaf-Spring-No 2	37 Springs No 153762-3,154510-11-12-13,38-39 Springs,155570-1-2-3,39 Springs No 157596-7-8-9
C	154868 Leaf-Spring-No 1	37 Springs No 153762-3-5-6-7,1545-5-6-7-8-10-11-12-13,38-39 Springs 155570-1-2-3,154506-7,155577-8
BZ	154890 Bolt-Spring Center	37 thru 39 Springs No 154506-7,1940 Springs No 162030-1
BZ	154891 Bolt-Spring Center	37 Springs No 154500-1-2-3-4,154760-1-4,38 Springs 155550-1-2-3,39 Springs No 155550-1-2-157593-4-5, 1941 Springs No 162446-7-163661
	154892 Bolt-Spring Center (Use 151886)	37 Springs 153762-3,154510-11-12-13,1938 155570-1-2-3
	154893 Bolt-Spring Center (Use 151885)	37 Springs No 153751-5,154704,38-39 Springs 153751-2,153755,154704

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 154894	Bolt-Spring Center	37 Springs No 154505-8,153765,38 Springs 155577-8
BZ 154895	Bolt-Spring Center	37 Springs No 153750-38 Springs 154705,156901-2-3, 39 Spring No 154105
BZ 154896	Spacer-Spring Clip Bolt	37 Spring No 154506-7,153766-7,1940 All Springs
BO 154910	Reproducer-Less Cable,Plug & Stud	37 Radio DB37-12 Volt
BZ 154911	Clip-Spring-No 2 Tapped	37 Spring No 154506-7
BZ 154912	Clip-Spring-No 3 Plain	37 Spring No 154506-7
BZ 154925	Cross Shaft Assy-Accelerator-LHD	37 All
C 154929	Rear Stabilizer Kit	71 thru 77,81 thru 87
BX 154930	Arm-F Axle Steering-RH-9/16"-18 Thread	37 thru 39 LHD
BX 154931	Arm-F Axle Steering-LH-9/16"-18 Thread	37 thru 39 LHD exc 89-90-98
BX 154932	Arm-F Axle Steering-RH-9/16"-18 Thread	37 thru 39 RHD exc 89-90-98
BX 154933	Arm-F Axle Steering-LH-9/16"-18 Thread	37 thru 39 RHD
BZ 154946	Rod-Rear Shock Absorber Piston	71,72,70 Co-Cpe,81-82-80 Co-Cpe,80-88 Sed
BZ 154951	Metering Washer-Shock Absorber Piston	34 K-KU-KS,35 G-GU,61,62,70,71,72,80,81,82,88,89, 90,92,98 Sed
C 154952	Main & Wrapper Leaf Assy-Front Spring	37 thru 39 Springs No 153750 & 153753
C 154953	Main & Wrapper Leaf Assy-Front Spring	37 thru 39 Springs No 153751-2-153754
C 154954	Main & Wrapper Leaf Assy-Front Spring	37 thru 39 Springs No 153755 & 154704
BZ 154970	Lever & Shaft Assy-Clutch Pedal	37-38-39 With Hill Hold
BO 154971	Dial-Station Selector Dial Scale	37 All
EM 154977	Tube Assy-Intake Manifold W/S Cleaner	37 thru 1950 All
BO 154984	Control Assy-Radio Model DB37-6V (Golden Brown Scale)	73 thru 77
154986	Dial-Radio Dial Scale (Golden Brown) (Use 153851)	73 thru 77
BZ 154988	Piston-Shock Absorber-Delco	73 thru 77,83 thru 87
154990	Tie Rod Assy (Use 157204)	70 thru 78,80 thru 85,87,88
154991	Tie Rod Ends Complete-R & L Boxed (Use 159782)	34 All,35 exc G,36-37 Hud 8,37 6 Cyl With 7/8 Rod, 38 All
154994	Tie Rod End Assy-RH (Use 159783)	34 All,35 exc G,36-37 Hud 8,37 6 Cyl With 7/8 Rod, 38 All
154995	Tie Rod End Assy-LH (Use 159784)	34 All,35 exc G,36-37 Hud 8,37 6 Cyl With 7/8 Rod, 38 All
EX 155000	Dust Cover-Tie Rod End-Steel	34 thru 38 All
F 155001	Tie Rod Ends Complete-R & L-Boxed	35G,61,62,63,70,71-72-73 With 3/4" Rod
F 155004	Tie Rod End Assy-RH	35G,61,62,63,71,72,73 With 3/4" Rod
F 155005	Tie Rod End Assy-LH	35G,61,62,63.71-72-73 With 3/4" Rod
BZ 155008	Button Assy-Horn-Tenite	72 thru 77
F 155013	Intermediate Gear Assy-Trans Mainshaft	38-39 All,41 thru 48
F 155015	Retainer-Trans Mainshaft Inter Gear	38 thru 1940 All
155016	Shaft Assy-Propeller-3" (Use 157845)	70 thru 75,80 thru 85,89
155018	Shaft-Propeller-3" (Use 157845)	70 thru 75,80 thru 85,89
BT 155023	Shaft-Trans Low and Reverse Shifter	37 thru 1940 All
155030	Shaft & Rear Joint Assy-Prop 3" Shaft (Use 157845)	70 thru 75,80 thru 85,89
155032	Shock Absorber Assy-Rear (Use 301770)	37 thru 39 Cab-CabPu-Panel-Station
C 155205	Cylinder and Pistons Assy	38-39 X Engine
155206	Cylinder and Piston Assy (Use 166264)	84,85,87
EM 155210	Water Outlet-Cylinder Head	82 thru 85,87,92M,93,95,97,43,45,47,15,17,25,27,54,174
155223	Clutch Assembly (Use 160696)	84,85,87,95,97,44,45,47 Without OD
TF 155224	Spring-Clutch Engaging-Inner	81,84,85,87,80 Co-Cpe-Sed,89,1939 thru 1950 All
BZ 155225	Support-Hand Brake Mounting Bracket	38 thru 1947 All
BZ 155226	Tube Assy-Brake-Rear Axle Tee to Left Rear Wheel	38 thru 1940 All
BZ 155228	Tube Assy-Brake-Rear Axle Tee to Right Rear Wheel	38 thru 1940 All
155230	Drag Link Assy-LHD (Use 155231)	80,81,82,88,91,92
C 155231	Drag Link and Plugs Assy-LHD	80,81,82,88
155233	Drag Link Assy-RHD (Use 155234).	80,81,82,88,91,92
C 155234	Drag Link and Plugs Assy-RHD	80,81,82,88
F 155237	Hub Cap-Wheel-Outer	80,81,82,88
155238	Hub Cap-Wheel-Outer (Use 157543)	83,84,85,87
BZ 155242	Cover-Eng Guard-Right-Frame Arm Brkt Hole	71,72,81,82,91,92
C 155258	Center Assy-Front Axle	81 thru 85,87
EX 155260	Oil Seal-Steering Spindle Pivot Pin	38 thru 1950 All
155261	Arm-Front Axle to Frame (Use 152730)	81,82,92
155262	Arm-Front Axle to Frame (Use 152731,152733 & 170006)	83 thru 85,87,93,95,97
EX 155263	Spindle-Steering-RH	81,82,83,89
EX 155264	Spindle-Steering-LH	81,82,83,89
F 155269	Rebushing Kit-Front Axle	38-39 All
C 155270	Manifold Assy-Intake	80,81,88,90,91,92,98,40C,41,48
C 155274	Tank Assy-Gasoline-Enamel	80 UCo,38 thru 1940 Cab-CabPu-Panel-Sta
BZ 155277	Neck-Gas Tank Filler	38 UCpe,38 thru 1940 Cab-CabPu-Panel-Sta
BZ 155278	Extension Assy-Gas Tank Filler Neck	38 UCpe,38 thru 1940 Cab-CabPu-Panel-Sta
155284	Pump Assy-Water (Use 166284)	80,81,82P,88,89
155285	Pump Assy-Water (Use 166285)	82,84,85,87

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 155286	Pump Assy-Water	83-93 X Engine
155287	Pump Assy-Water (Use 158936)	83
BM 155288	Body Assy-Water Pump	82 thru 85,87,93,95,97,43,47,15,17,25,27,54,174
F 155290	Seal-Water Pump Shaft	80 thru 85,87,88,89
C 155292	Manifold Assy-Exhaust	84,85,87,95,97
BZ 155297	Hose-Gas Tank Filler Neck	38 thru 1940 UCpe-Cab-CabPu-Panel-Sta,40T 3Cpe
F 155298	Cap Assy-Gasoline Tank	38 thru 1947 All
155350	Hsg Complete-R/A (Less Shoes) (Use 159620)	80,81,82,83,88
155351	Hsg Complete-R/A (Less Shoes) (Use 159621)	84,85,87,95,97
155355	Shaft Assy-Rear Axle Drive (Use 166191)	38 thru 1942 exc 3" x 4 1/8" eng,38 thru 1942 Comm
155357	Valve-Inlet (Use 166330)	38 thru 1942 6 Cyl
155358	Valve-Inlet (Use 166308)	38 thru 1942 8 Cyl
155359	Guide-Inlet Valve (Use 166199)	38 thru 1942 All
155360	Valve-Exhaust (Use 166331)	38 thru 1942 6 Cyl
155361	Valve-Exhaust (Use 166311)	38 thru 1942 8 Cyl
155362	Guide-Exhaust Valve (Use 166200)	38 thru 1941 All
BM 155363	Seat-Valve Spring	38 thru 1947 All,1948 thru 1950 8 Cyl
155366	Clamp-Tail Pipe Front (Use 162748)	80,81,82,83
BZ 155367	Clamp-Tail Pipe Front	85,98,43,48
CF 155368	Tail Pipe	80,81,82,83,91 Panel
155373	Muffler Assy (Use 162635)	80,81,82,83,88
155374	Muffler Assy (Use 160004)	84,85,87
BZ 155375	Clamp-Muffler and Tail Pipe Rear	38 thru 1947 6 Cyl
F 155384	Oil Seal-Rear Axle Drive Pinion	35 thru 1940 All
155385	Companion Flange-Rear Axle (Use 157753)	38 All
BZ 155396	Pad Assembly-Brake Pedal	80 thru 88,91 thru 97
BZ 155397	Pad Assembly-Clutch Pedal-LHD	80 thru 88,91 thru 97
BZ 155398	Pad Assembly-Clutch Pedal-RHD	80 thru 88,91 thru 97
BZ 155401	Lever Assy-Clutch Pedal-RHD	80 thru 88,91 thru 97
BZ 155402	Lever-Clutch Pedal-LHD	80 thru 88,91 thru 97
BZ 155404	Lever Assy-Brake-Pedal-LHD	80 thru 88,91 thru 97
BZ 155405	Lever Assy-Brake-Pedal-RHD	80 thru 88,91 thru 97
BZ 155408	Bracket-Pedal-RHD	38 thru 1940 All
C 155410	Frame Assy	80
BZ 155421	Cover-Frame Steering Gear Hole	38-39 All
BZ 155426	Bracket-Frame Crossmember Shock Abs-RH	38-39 exc 89-90
BZ 155427	Bracket-Frame Crossmember Shock Abs-LH	38-39 exc 89-90
BZ 155432	Gusset-Frame Rear Spring Front Brkt-RH-Lower	80,88,98,91 Panel,40 Cab-CabPu-Panel-Station,48C
C 155434	Torsion Bar Assy-Frt Stabilizer-Second type	81 thru 85,87,80-88 Sedan
A 155435 Pr	Radiator Assy	80,88 exc Sed
A 155436 Pr	Radiator Assy	81,82,88 Sedan
A 155438 Pr	Radiator Assy	83
A 155439 Pr	Radiator Assy	84,85,87
155446	Pedal Complete-Accelerator-Taupe-LHD (Use 165816 & 166623)	38 thru 1940 All
BZ 155448	Bracket-Accelerator Pedal Anchor	38 thru 1940 All,1941-1942-1946-1947 RHD
BZ 155450	Link-Accelerator Pedal Shaft to B/C-LHD	38-39 All,1940 Without OD
BZ 155451	Bellcrank-Accelerator Pedal Link	38-39 All,40,41,43,48,44-45-47 RHD
BZ 155452	Bracket-Accelerator Pedal Link Bellcrank	38 thru 1941 All,1942-1946-1947 RHD
BZ 155453	Rod-Acc Pedal Link B/C to Cross Shaft-LHD	38-39 All,1940 Without OD
BZ 155454	Rod-Ace Pedal Link B/C to Cross Shaft-RHD	38 thru 1940 All
*BZ 155455	Cross Shaft Assy-Accelerator-LHD	38 thru 1940 All
BZ 155456	Cross Shaft Assy-Accelerator-RHD	38 thru 1940 All
BZ 155461	Spring-Accelerator Cross Shaft Compression	38 thru 1946 All
BZ 155462	Spring-Accelerator Cross Shaft Anti Rattle	38 thru 1940 All
BZ 155463	Lever-Throttle Control Pull-LHD	38 thru 1940 All
BZ 155464	Rod-Ace Cross Shaft to Pull Lever-LHD	38-39 All
BZ 155465	Rod Assy-Throttle Control	80,81,82,83,88,89,90,91,92,93,93X,98,40-48 Without OD
155467	Ball Joint-Throttle Control Pull Lever to Manifold Bellcrank Rod (Use 45175)	80,81,88,89,90,91,92,93X,98,40,48
155467	Ball Joint-Throttle Control Pull Lever to Carburetor Bellcrank Rod (Use 45175)	81M,82 thru 87,91,92,93,95,97
BZ 155468	Rod Assy-Throttle Control Pull Lever to Carburetor Bellcrank	84,85,87,95,97,44,45,47
155470	Clutch Assy (Use 160996)	82,83,88,80 exc Co-Cpe-Sed
155471	Disc Complete-Clutch (Use 301246)	82 thru 85,87,88,80 exc CoCpe-Sed
BT 155474	Transmission Control Assy-Conventional	38 All
BT 155476	Lever Assy-Trans Cont Conventional	38 All
155478	Fan Pulley-Vibration Dampener (Use 301935)	38 thru 1942 All
155479	Hub-Vibration Dampener (Use 166300)	38 thru 1942 All
155480	Vibration Dampener Assy (Use 166301)	38 thru 1942 All
BM 155481	Facing-Vibration Dampener	38 thru 1950 All
BX 155482	Spindle-Front Axle Steering-RH	38-39 All
BX 155483	Spindle-Front Axle Steering-LH	38-39 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	155486 Carburetor Assy (Use 158306)	80,81,88,91,92,98 exc Sed
	155487 Carburetor Assy (Use 157608)	All P Engines
EM	155488 Brace-Carburetor Air Cleaner	80,81,88,89,All X Engines,92,98 exc Sed
EM	155489 Brace-Carburetor Air Cleaner	81M,82,83,91,92,93
CF	155493 Pipe Assy-Exhaust	80,81,82,88,91,92
CF	155495 Pipe Assy-Exhaust	83,93
C	155499 Housing Assy-Clutch	38 exc 89,91,92,93,95,97,91 Panel-90-98 With VD
BT	155502 Coupling Lever-Clutch Shifter Yoke Shaft	38-39 exc 89
C	155505 Torsion Bar Assy-Frt Stabilizer-Third Type	81 thru 85,80-87 Sedan
	155506 Torsion Bar-Front Stabilizer (Use 155505)	81 thru 85,80-87-88 Sedan
BZ	155507 Bushing-Front Stabilizer Bar-Rubber	81 thru 85,80-87-88 Sedan
BZ	155508 Bracket-Front Stabilizer Bar Bushing	81 thru 85,80-87-88 Sedan
C	155513 Cable & Conduit Assy-Hand Brake-LHD	38-39 All
C	155514 Cable & Conduit Assy-Hand Brake-RHD	38-39 All
	155516 Carburetor Assy-Duplex (Use 159654)	82 thru 85,81M-87
	155517 Water Outlet-Cylinder Head (Use 166271)	80,81,88,89,90,91,92,98,40,41,44,45,48,10,11,12,14, 18,20,21,22,24,28
C	155519 Case Assy-Transmission	80 thru 85,87,88,91 thru 97
F	155524 Mainshaft Assy-Transmission	38-39 All,1940 Without OD
	155526 Shift Sleeve-M/Shaft Second High (Use 160584)	1938-1939 All
F	155527 Gear-Mainshaft Low and Reverse'	38-39 All,1940 Without OD
*F	155529 Countershaft-Transmission	38 thru 1940 All
*F	155533 Drive Gear-Countershaft	38-39 All,41 thru 48
BT	155534 Gear-Countershaft Intermediate	38-39 All,41 thru 48
F	155535 Gear-Countershaft Low and Reverse	38 thru 1940 All
	155536 Companion Flange-Front End of Prop Shaft (Use 157754)	38-39 All
BT	155538 Bumper-Transmission Side	80 thru 85,87,88,91 thru 97,90-98 With Handy Shift, 40 thru 48
BT	155539 Bolt-Transmission Side Bumper	80 thru 85,87,88,92 thru 97,90-98 With Handy Shift
BZ	155549 Bumper-Accelerator Toe Plate	38 thru 1941 All
CF	155550 Spring Assembly-Rear-Light Scale	81 thru 85-93-95 Bro-CvBro,83-84-85-93,95 Cpe
CF	155551 Spring Assembly-Rear-Light Scale	80 thru 85-93-95 Sedan
	155557 Body,Shaft & Impeller Assy-W/P (Use 166284)	80,81,88,89
	155558 Body,Shaft & Impeller Assy-W/P (Use 158936)	83
	155559 Body,Shaft & Impeller Assy-W/P (Use 166285)	82,84,85,87,92M,95,97
C	155560 Core Assy-Radiator	80,81,82,88
C	155561 Core Assy-Radiator	83
	155562 Core Assy-Radiator (Use 165533)	84,85,87
	155563 Wheel Assy-16 x 4 (Use 166486)	81,82,80 Sed-Co-Cpe
	155565 Wheel Assy-15 x 5 (Use 302427)	80 thru 85,87,88,89-90 Cab-CabPu-Panel Sta,91 thru 98,90 UCo-UCpe
BZ	155569 Wrench-Wheel Hub Bolt	80 thru 89,90 thru 98,40T-10T-3Cpe,40-10 UCpe
	155571 Spring Assy-Rear-Heavy Scale (Use 154511)	80 thru 85-87-88-93-95-97-98 Sedan
C	155577 Spring Assy-Rear-Heavy Scale	80 UCo
	155580 Tool Bag Assy-Less Tools (Use 151430)	1938 thru 1950 All
	155585 Wheel-Steering-Black (Use 153320)	80,88,89,39 Cab-CabPu-Panel-Station-UCo-UCpe
	155586 Wheel-Steering-Painted (Use 153320)	81
C	155587 Wheel-Steering-Tenite	80,81,82,88
C	155588 Wheel-Steering-Tenite	83,84,85,87
C	155593 Steering Gear Assy-LHD	80 thru 88,91 thru 97
C	155594 Steering Gear Assy-RHD	80 thru 88,91 thru 97
C	155595 Steering Gear Assy-RHD	81-84-87 London "B"
BZ	155596 Ball Arm-Steering Gear-LHD	80 thru 88,91 thru 97
BZ	155597 Ball Arm-Steering Gear-RHD	80 thru 88,91 thru 97
BZ	155606 Button-Horn-Black	80,88,89,39 UCo-UCpe-Cab-CabPu-Panel-Sta
	155607 Button-Horn-Painted (Use 155606)	81
	155608 Button Assy-Horn-Tenite (Use 159112)	80,81,82,88
	155609 Button Assy-Horn-Tenite (Use 159112)	83,84,85,87
BZ	155610 Trim Ring-Horn Button	80,81,88,89,90,98,97 7Sed,91 Panel
BZ	155611 Retainer-Horn Button	38-39 All,40,41,44,48,43-47-17 7Sed,10,11,18,20,28, 51,53,58,171,173,178,481,483,491,493,500,501,503
HZ	155612 Lock Wire-Horn Button	38-39 All,40,41,44,48,43-47-17 7Sed,10,11,18,20,28, 51,53,58,171,173,178 ,481 ,483 ,491,493,500 ,501,503
	155613 Cup-Horn Button Contact (Use 160809)	38 All
BZ	155614 Spring-Horn Button Contact	38 thru 1940 All,10 Del
	155615 Wire Assy-Horn Button to Conn (Use 163449)	38 All
BZ	155616 Insulating Washer-Horn Button Wire Terminal	38 thru 1940 All
	155617 MainCol & Worm Assy-SteeringGear-LHD(Use 164559)	38-39 exc 89-89-98
	155617 Main Col & Worm Assy-Steering Gear-RHD (Use 164559)	1940 exc 43-47,10,11,12,18
	155618 MainCol & Worm Assy-SteeringGear-RHD(Use 164558)	80 thru 88,91 thru 97
	155618 Main Col & Worm Assy-Steering Gear-LHD (Use 164558)	40,41,44,45,48,10,11,12,18
C	155620 Main Col Tube-Steering Gear	80 thru 88,91 thru 97,40,41,44,45,48,10,11,12,18
BT	155622 Control Lever Assy-Transmission-Upper	38 All
BT	155624 Bellcrank Assy-Electric Hand Cross Shift	38-39 With Elec Hand

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 155626	Switch-Electric Hand Circuit Breaker	38-39 With Elec Hand
C 155628	Selector & Jacket Tube Assy-Elec Hand-6 V	38-39 With Elec Hand
BT 155630	Selector & Wires Assy-Elec Hand-6 V Black	38-39 With Elec Hand
BT 155632	Connector Assy-Electric Hand Wires-Male	38-39 With Elec Hand
BT 155633	Connector Assy-Electric Hand Wires-Female	38-39 With Elec Hand
BT 155637	Switch-Shift Rail	38-39 With Elec Hand,1940 With VD
BZ 155638	Gasket-Shift Rail Switch	38-39 With Elec Hand,1940-1941 With VD
155648	Corm Rod & Cap Assy-RH (Use 166241)	80 thru 88,89P
155649	Conn Rod & Cap Assy-LH (Use 166242)	80 thru 88,89P
BM 155655	Bolt-Connecting Rod	38 thru 1947 All,1948 thru 1950 8 Cyl
BM 155656	Nut-Connecting Rod & Flywheel Bolts	38 thru 1950 All
BZ 155657	Spring-Throttle Control Return-At Dash	38 thru 1940 All
155660	Generator Complete-Includes Pulley (Use 157747)	80,81,88 exc Sed,Without Radio or Elec Hand
155661	Generator Complete-Includes Pulley (Use 157654)	38-39 All
BO 155666	Pulley-Generator	38 thru 1947 All
BO 155667	Charge Regulator-Generator	80-81-88-89-90 With Radio,82 thru 87,91 thru 97
BM 155669	Charge Regulator Kit-Generator	80,81,90,88,98 exc Sed
155670	Ignition Coil Complete-Incl Lock-6 Volt (Use 157656)	80 thru 83,88-89
155671	Ignition Coil Complete-Incl Lock-6 Volt (Use 157657)	84,85,87,95,97
BO 155678	Knob Comp-Starter, Light and Cl Control	83,84,85,87
BO 155679	Switch Assembly-Starter	80 thru 88,91 thru 97,89-98 RHD,10 Del
BO 155680	Knob Assy-Starter, Light and Cl Cent Switch	80,81,82,88,90-98 Bus Cars,91 Panel
BO 155681	Knob-Starter, Lighting and Clutch Switch	80,81,82,88,90-98 Bus Cars,91 Panel
BO 155682	Knob Assy-Starting and Lighting Switch	83 thru 87
155684	Switch Assy-Service & Dome Lamp (Use 160091)	38 Bro-Sed-3Cpe-VicCpe-UCo-UCpe
F 155685	Switch Assy-Lighting	38-39 All
155686	Fuse Block Assy (Use 160088)	38 All
BO 155690	Horn & Bracket Assy-LH-Fender Type-6 V	83,84,85,87
155694	Brkt-Horn Mtg-RH-Fender Type (Use 157230)	83 thru 85,87,88
155695	Brkt-Horn Mtg-LH-Fender Type (Use 157231)	83 thru 85,87,88
BO 155698	Horn Assy-Vibrator Type-6 Volt	80,81,88,90,98
155704	Flexible Hose-W/Shield Defroster (Use 164236)	38 All
BO 155705	Tee-Windshield Defroster	38-39 All
BO 155707	Nozzle-Windshield Defroster-RH	38-39 All
BO 155708	Nozzle-Windshield Defroster-LH	38-39 All
BO 155709	Thermostat-Cyl Head Water Outlet	80,81,88,89,90,91,92,98,40,41,44,45,48,10,11,12,14, 18, 20,21,22,24,28,1946,1947 exc 54-174
BO 155710	Switch-Hot Water Heater-Illuminated	38-39 All
BZ 155716	Bracket Assy-VD-Cyl Mounting	83,93
BZ 155718	Bracket Assy-VD-Cyl Mounting	38 thru 1947 8 Cyl
BZ 155720	Bracket Assy-VD-Bell Crank	38 thru 1947 6 Cyl
BZ 155722	Bracket Assy-VD-Bell Crank	38 thru 1947 8 Cyl
BZ 155725	Rod-VD-Bellcrank to Coupling Lever	38 thru 1940 All
BZ 155726	Rod Assy-VD Valve Lever Threaded Sleeve	38 thru 1940 All
BZ 155727	Rod-VD Valve Lever Threaded Sleeve	38 thru 1940 All
BZ 155728	Threaded Sleeve-VD Valve Lever Cam	38 thru 1950 All
BZ 155729	Screw-VD Valve Lever Cam Adj & Accel C/S	38 thru 1948 All
BZ 155730	Spring-VD Valve Lever Cam Adj Screw	38 thru 1947 All
BZ 155731	Rod-VD Threaded Sleeve Rod Bellcrank Operating	38 thru 1940 All
BO 155732	Switch-VD Dash	38 thru 1941 All
BO 155733	Rod-VD Dash Switch to Acc Lever	38 thru 1940 All
155735	Switch-VD Governor (Use 153259)	38 All
BO 155736	Switch-Instrument Panel	38 thru 1942 All
BT 155737	Wire Harness-Vacumotive Drive	38-39 All
BZ 155738	Bellcrank-VD Sleeve Rod	38 thru 1940 All
BZ 155739	Bracket Assy-VD Cyl Mounting	38 thru 1947 6 Cyl
BM 155742	Tension Washer-VD Bellcrank Shaft	38 thru 1949 All
BX 155743	Grease Fitting-Pivot Pin-Upper-90°	80 thru 85,87,88,91 thru 97,40 thru 48,14,15,17,24,25,27,53,54
155744	Jack Assy (Use 1 each 166079 & 166080)	81 thru 85,87,80 Co-Cpe-Sed-Del,88 Sed-Del
BZ 155746	Base-Jack	81 thru 85,87,80-88 Co-Cpe-Sed-Panel
BM 155747	Air Cleaner-Carburetor-Oil Bath	80,81,88,89,90,91,92,98
BM 155748	Air Cleaner-Carburetor-Oil Bath	81M,82 thru 87,91,92,93,95,97
BM 155749	Pad-Gas Tank to Support	89,90,98,40,10,20
155750	Head Assy-Cylinder (Use 165534)	80 thru 83,88
BM 155753	Element-Carburetor Air Cleaner-Dry Type	38 thru 1942 6 Cyl
BT 155754	Shift Rail-Transmission Low and Reverse	38-39 All
BT 155755	Shift Rail-Transmission Second and High	38 thru 1940 All
155756	Gauge Assy-Oil Level (Use 162520)	80,81,82,83,88,89,90,91,92,93,98
BM 155757	Gauge Assy-Oil Level	84,85,87,95,97
155758	Distributor Comp-With Resistor (Use 157652)	80,81,90,88-98 exc Sed
BM 155759	Distributor Comp-Less Resistor	80,81,90,88-98 exc Sed,92,93
BZ 155760	Rod-Acc Cross Shaft to Pull Lever-RHD	38 thru 1940 With VD
BZ 155761	Rod Assy-Accelerator Cross Shaft-RHD	38 thru 1940 With VD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	Rod-Acc Cross Shaft-Short to Long-RHD	38 thru 1940 With VD
EM 155763	Holder Assy-Ignition Cable-Front	38-39 exc 83-93,1940 thru 1950 8 Cyl
EM 155764	Holder Assy-Ignition Cable-Front	83,93
BO 155766	Support-Weather Control to Water Pump Hose	481,482,491,492,50T,500,501,502
	155769 Bracket-Ignition Cable-Side (Use 161002)	80 thru 88,95,97,44,45,47
EM 155770	Holder Assy-Ignition Cable-Rear	80,81,82,83,88,89,90,92,93,98
BZ 155776	Connection-Clutch Housing to Ground	38 thru 1947 All
BT 155777	Housing-Speedometer Gear	38 thru 1940 All
BO 155778	Charge Regulator Assy-Generator-12 Volt	80,81,88,98 exc Sed Without Radio,89-90 With Radio
BO 155779	Knob Assy-Radio Control	80,81,82,88,39 Business Cars
EM 155786	Grommet-Cylinder Head Cover Hole	83,93
EM 155787	Nut-Hex-3/8"-16 x 11/16"	83,80,81,82,88,89,90,91,92,98
BO 155788	Knob-Hot Water Heater Switch	38 All
BO 155801	Horn Assy-RH-Dash Mount-6 Volt	38 All,90,98,91 Panel
BO 155802	Horn Assy-LH-Dash Mount-6 Volt	38 All,90,98,91 Panel
BO 155805	Twin Horn Kit-Dash Mount	38 All,90,98
BO 155821	Strap Assy-Ground-Engine to Dash	38 thru 1941 All
BO 155822	Strap Assy-Ground-Muffler Bracket to Frame	38-39 All
BO 155829	Bracket Assy-Horn-RH	80 thru 88,89,90,98,91 Panel
BZ 155838	Center Bolt-Spring	37 Springs No 154506-154507
BZ 155839	Tension Spring-VD Cylinder	38 thru 1940 With VD
BO 155848	Bracket Assy-Horn	80,81,88,90,98,91 Panel
BO 155849	Bracket Assy-Horn-LH	82,83,84,85,97,89,90,98,91 Panel
BT 155850	Pinion-Transmission Speedometer-4-1/9 to 1	38-39 Less VD,1940 Without OD
BT 155851	Pinion-Transmission Speedometer-4-1/9 to 1	38-39 With VD,1940 Without OD
BT 155852	Pinion-Transmission Speedometer-4-5/9 to 1	38 thru 1940 Without VD
	155853 Pinion-Trans Spdo-4-5/9 to 1 (Use 155895)	80 thru 85,87,88 With VD
BT 155854	Pinion-Trans Speedometer-5-1/8 to 1	80-88-89 Cab-CabPu-Panel
BT 155855	Pinion-Trans Speedometer-3-8/9 to 1	81 thru 85,87
BT 155857	Sleeve-Trans Speedometer-Pinion	38-39 All,1940 Without OD
BT 155861	Pipe Assy-VD Vac-Manifold	38 thru 1947 6 Cyl
BT 155863	Pipe Assy-VD Vacuum-Valve End	38 thru 1947 6 Cyl
BT 155866	Pipe Assy-VD Vac-Manifold End	84,85,87,95,97
BT 155868	Hose-VD Vacuum Pipe	84,85,87,92,93,95,97,1940 thru 1949 All,501 thru 504
BT 155869	Relay-Horn-12 Volt	38 thru 1940 With Air Horns
BT 155874	Pipe Assy-Electric Hand Power Unit-Long	80,81,82,83,91,92,93
C 155878	Jacket Tube & Bushing Assy-Steering Gear	38-39 Without Electric Hand
C 155879	Jacket Tube & Bushing Assy-Steering Gear	38-39 With Electric Hand
EM 155880	Pipe Assy-Fuel Pump to Carburetor	80,81,88,91,92,93X,98 exc 5Sed
EM 155882	Pipe Assy-Fuel Pump to Carburetor	81M,82,33,91,92,93
EM 155884	Pipe Assy-Fuel Pump to Carburetor-LHD	84,85,87,95,97,44,45,47
EM 155888	Pipe Assy-Comb Pump to Manifold Vac	82,83
	155892 Pinion-Trans Spdo-4-1/9 to 1 (Use 155850 155857)	81 thru 85-87-89 Without VD
	155893 Pinion-Trans Spdo-4-1/9 to 1 (Use 155851 & 155857).	81 thru 85-87 With VD
BT 155894	Pinion-Trans Speedometer-4-5/9 to 1	80 thru 85-87-89 Without VD
BT 155895	Pinion-Trans Speedometer-4-5/9 to 1	38-39 With VD,1940 Without OD
	155896 Pinion-Trans Spdo-5-1/9 to 1 (Use 155854)	80-88 exc Co-Cpe-Sed
	155897 Pinion-Trans Spdo-3-3/9 to 1 (Use 155855)	81 thru 85,87
EZ 155899	Wire Harness-Clutch Vac Control-Upper and Electric Hand-Lower	38-39 All
	155937 Washer-VD Valve Lever (Use 162868)	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
EM 155944	Wire Assy-Distributor to No 1 Spark Plug	38-39 All
EM 155956	Wire Assy-Dist to No 2 Spark Plug	38 thru 1947 8 Cyl
EM 155958	Wire Assy-Dist to No 4 & No 8 Plugs	38 thru 1947 8 Cyl
EM 155960	Wire Assy-Dist to No 7 Spark Plugs	38 thru 1947 8 Cyl
	155962 Use 155958	
EM 155964	Wire Assy-Coil to Distributor-High Tension	38 All
BO 155968	Harness-Instrument Wire	80 thru 85,87,88
BO 155969	Loom-3/8"-Generator Wires	38 thru 1941 6 Cyl
BO 155970	Loom-3/8"-Generator Wires	38 thru 1941 8 Cyl
BO 155976	Wire Assy-Horn Relay to Front Connection-Fender Horns	38 All
	155984 Wire Assy-Fuse Block to Cigar Lighter	80 thru 88
BT 155993	Thrust Washer-Transmission Countershaft	38 thru 1940 All
BT 155994	Selectir Wires Assy-Electric Hand Lower	38 All,91 thru 97,44,45,47
BO 155996	Wires & Socket Assy-Service Lamp-RHO	38-39 All,1940 Cv
EM 156065	Wire Assy-Generator to Charge Control	80,81,82,83,88,91
BO 156093	Wires & Socket Assy-Speedometer Lamp-LHD	80 thru 85,87,88,90,91,92,98
BO 156094	Wires & Socket Assy-Speedometer Lamp-RHD	80 thru 85,87,88,90,91,92,98
BZ 156097	Gasket-Master Cyl or Hill Hold Outlet Fitting	38 thru 1947 All
BZ 156114	Outlet Fitting-Master Cylinder Head	38-39 exc 89,1940 thra 1947
BZ 156119	Tube Assy-Brake Cont Frame Tee to LF Hose	80,81,82,88,92,91
BZ 156121	Tube Assy-Brake Cont Frame Tee to LH Hose	83,84,85,87,93,95,97
BZ 166123	Tube Assy-Brake Cont Frame Tee to RF Hose	80,81,82,88,92,91

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	Tube Assy-Brake Cont Frame Tee to RF Hose	83,93
BZ 156127	Tube Assy-Brake Cont Frame Tee to RF Hose	84,85,87,95,97
BZ 156129	Tube Assy-Brake Cont Frame Tee to Rear Axle Hose	80 thru 85,91,92,93,95
BZ 156133	Tube Assy-Brake Cont Frame Tee to Rear Axle Hose	87,88,97,98
BZ 156135	Tube Assy-Brake Cont Master Cyl to Frame Tee-Without Hill Hold	38-39 exc 89,90,98
BZ 156140	Tee Brake Cont Tube-on Side Member Reinf	38 thru 1947 All
BO 156143	Wire Assy-Inst Harness to Service Lamp	1940 All
BZ 156150	Pipe Assy-Comb Pump to Manifold Vacuum	80,81,88
BO 156152	Hose-Defroster-21 -1/ 2 "-RH	37 With 38 Heaters
156155	Wheel Assy-16 x 4.50 (Use 162831)	80,84,85,87,88
156159	Grease Fitting-Water Pump Body (Use 166335)	82,83,84,85,87,92M,93,95,97,43,45,47
156183	Shock Absorber-Front-Light Control (Use 159206)	83,84,85,87
156184	Shock Absorber-Rear-Light Control (Use 162551)	83,84,85,87
156185	Shock Absorber-Front-Heavy Control (Use 159206)	83,84,85,87
156186	Shock Absorber-Rear-Heavy Control (Use 166575)	83,84,85,87
BZ 156187	Wires & Loom Assy-Generator	80-81-88 Without Radio exc 88 Sedan
BO 156188	Wires & Loom Assy-Generator	80-81-88 With Radio exc 88 Sedan,82,83,88 Sed
BO 156189	Wires & Loom Assy-Generator	84,85,87
BO 156193	Resistor Assy-Gas and Temp Gauge-12 Volt	38-39 All
EM 156199	Replacement Element-Carburetor Air Cleaner	82 thru 85,87,91 thru 97,41 thru 47,10-20 with L Eng,11 thru 17,21 thru 27,1946-1947 All
156214	Engine Assy-Std Compression (Use 164815)	81 All,80 Co-Cpe-Sed
156215	Engine Assy-Std Compression (Use 164815)	80 Cab-CabPu-Panel-Sta,88 All
156217	Engine Assy-Std Compression (Use 164815)	82
156218	Engine Assy-Std Compression (Use 164815)	83
156219	Engine Assy-Std Compression (Use 164820)	84,85,87
156239	Engine Assy-Std Compression (Use 164815)	89
EM 156243	Grease Fitting-Front Spring Shackle Threaded Bushing	89-90 exc Cab-CabPu-Panel-Sta,98 Sed
BZ 156244	Clip-#2 Spring	80 UCpe,1940 Springs No 159683-4-5-7-160161
156248	Wheel-Steering-Red Brown (Use 153320)	81
156249	Button-Horn-Red Brown (Use 155606)	81
EM 156251	Metering Rod Package-Carburetor	X Engine
EM 156254	Metering Rod-Carburetor-1st Leaner	80-81-88-89 exc X & 81M,91,92,98 exc Sed
EM 156256	Metering Rod-Carburetor-Std	X Engine
EM 156257	Metering Rod-Carburetor-1st Leaner	X Engine
EM 156258	Metering Rod-Carburetor-2nd Leaner	X Engine
C 156273	Trim Ring-Wheel-For 16" Wheels	84,85,87,1939 thru 1947 All
156277	Disc-Shock Absorber Piston Valve Spring (Use 160902)	83,84,85,87,93,95,97
EM 156287	Fuel & Vacuum Pump Kit-Combination	80,81,88
EM 156288	Fuel & Vacuum Pump Kit-Combination	82,83
BZ 156304	Link-Accelerator Pedal to Bellcrank-RHD	38 thru 1940 All
BZ 156305	Bellcrank-Accelerator Pedal Link-RHD	38 thru 1940 All
156323	Thermostat-Heater-Hose Type (Use 48841)	All
BO 156342	Capacitor Pack-2 Sections Each 8 Mfd	Models DB38 - SA38 Radio
BO 156375	Crystal-Daft	Models DB38 - SA38 Radio
BO 156376	Dial Scale,Drum and Gear Assy	Models DB38 - SA38 Radio
BO 156390	Switch-On-Off Operating	Models DB38 - SA38 Radio
BO 156398	Wing Nut Assy-Receiver Mounting	Models DB38 - SA38 Radio
BO 156402	Coil-Speaker	Model DB38 Radio
BO 156419	Volume Control-Less Gear	Model SA38 Radio
BO 156423	Speaker Complete	Model SA38 Radio
*BT 156425	Cylinder & Interlock Switch Assy-Electric Hand Cross Shift Dia	38-39 All
*BT 156426	Diaphragm Assy-Electric Hand Cross Shift	38-39 All
BT 156428	Rod-Electric Hand Cross Shift Diaphragm	38-39 All
BT 156429	Rivet-Elec Hand Cross Shift Diaphragm Rod	38-39 All
BT 156432	Sleeve-Cross Shift Diaphragm Rod	38-39 All
BT 156433	Rod-Cross Shift Diaphragm Rod to Camshaft	38-39 All
BT 156434	Housing-Electric Hand Cross Shift Diaphragm & Interlock Switch	38-39
BO 156435	Bracket-Receiver Mounting	Models DB38 and SA38 Radio
BT 156436	Interlock Switch-Cross Shaft Diaphragm	38-39 All
BT 156437	Gasket-Electric Hand Cross Shift Diaphragm Interlock Switch	38-39 All
BT 156438	Camshaft-Elec Hand Cr Shift Dia Interlock Sw	38-39 All
BT 156441	Spring-Electric Hand Cross Shift Dia Interlock Switch Camshaft	38-39 All
BT 156442	Spacer-Electric Hand Cross Shift Dia Interlock Switch Camshaft	38-39 All
BT 156446	Shaft,Lever & Segment Assy-Electric Hand Selector Switch	38-39 All
	Shaft Assy-Electric Hand Selector Switch	38-39 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 156455	Base and Wires Assy-Upper-Electric Hand Selector Switch	38-39 All
BT 156463	Solenoid Assy-Electric Hand Selector Switch-6 Volt	38-39 All
BT 156473	Wires Assy-Elec Hand Selector Switch-Upper	38-39 All
BZ 156475	Cyl Assy-VD Less Valve	38 thru 1941 All,1942-1946-1947 With VD or HDM
BZ 156478	End Plate Assy-VD-Cylinder	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156487	Retainer-VD-Cylinder Piston Felt	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BT 156491	Seal-Vd-Cylinder Piston Rod	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BT 156493	Spring-Vacuum Cyl Piston Rod Seal Lock	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BT 156494	Felt Washer-VD-Cylinder Piston Rod	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BT 156495	Retainer-VD-Cyl Piston Rod Felt	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BT 156496	Guard-Clutch Vacuum Cylinder Piston Rod	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156500	Valve & Rod Assy-VD-Piston	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BT 156502	Rod-VD-Piston Valve	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156506	Bellcrank & Bushing Assy-VD	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156511	Belt-VD-Bellcrank Pivot	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156512	Shaft Assy-VD-Valve Compensator Lever	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156516	Spring-Compensator Lever Check Valve	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156517	Trip Lever Assembly-VD-Valve Compensator	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
156520	Washer-VD-Valve Compensator Trip Lever Shaft (Use 162868)	38 thru 1941 All
BZ 156521	Lever Assy-VD-Valve	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156525	Bushing-VD-Lever Eccentric	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156526	Pin-VD-Valve Lever Eccentric Bushing	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
156528	Link Assy-VD-Valve Lever to Trunion (Use 157094)	38 thru 1940 All
BZ 156531	Cam-VD-Valve Lever	38 thru 1941 All,1942-1946-1947 With VD or HDM
BZ 156532	Spring-VD-Valve Lever Cam	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156533	Spacer-VD-Valve Lever	38 thru 1941 All,1942- thru 1950 With VD-HDM or SMD
BZ 156534	Spacer-VD-Valve Lever-Flanged	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156535	Washer-VD-Valve Lever Cam Screw	38 thru 1941 All,1942-1946 With VD or HDM
BZ 156536	Swivel-VD-Valve Lever Cam	38 thru 1940 All,1942 thru 1950 With VD-HDM or SMD
BZ 156537	Solenoid Valve Assy-VD	38 thru 1941 All,1942-1949 With VD or HDM
156541	Coil and Hsg Assy-VD-Solenoid-(Use 164882)	38 thru 1941 All
BZ 156551	Gasket-VD-Solenoid Housing	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156552	Plunger & Disc Assy-VD Throttle Lock Solenoid	1938 thru 1949
156554	Plunger-VD-Solenoid (Use 156552)	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 156562	Spring-VD-Valve Compensator Lever	39 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
156566	Button Assy-Horn (Use 159112)	83,84,85,87
156577	Shock Absorber-Front-Light Control (Use 156206)	80,81,82,88
156578	Shock Absorber-Rear (Use 162551)	81,82,80-88 Sed
156579	Ignition Wires-Kit (Use 46439)	80,81,82,83,88,89,90,91,92,93,98
156580	Ignition Wires-Kit (Use 43538)	84,85,87,95,97
BZ 156582	Valve-Front Shock Abs Piston Pressure Relief	80,81,82,88,90,91,92,98
BZ 156583	Valve-Rear Shock Abs Piston Pressure Relief	81,82,89,80-88 Sed,90,91,92,98
BT 156590	Clevis-Cross Shift Diaphragm Rod	80 thru 85,87,88,91,92,93,95,97
BM 156592	Air Cleaner-Carburetor-Oil Bath Type	89,90,98 Sed,40-48 Cab-CabPu-Panel Sta,10-18 Cab-CabPu
BX 156606	Steering Arm-LH-LHD	89,90,98
156607	Steering Arm-RH-RHD (Use 154932)	89,90,98
156616	Conn Rod & Cap Assy-RH (Use 166238)	89
156617	Conn Rod & Cap Assy-LH (Use 166239)	89
156627	Cylinder Head Assy-Std Compression (Use 162776 & 130679)	89
156630	Clutch Assy (Use 166245)	89 Exc Cab-CabPu-Panel,90,98 Sed, 40-41X-10-20 Without OD
156633	Housing Assy-Clutch (Use 155499)	89,90,98
BT 156636	Coupling Lever-Clutch Shifter Yoke Shaft-LHD	89
156641	Oil Pan Assy (Use 166306)	38 thru 1942 6 Cyl
156644	Tray Assy-Oil Pan (Use 157877)	89
156652	Drag Link Assy-LHD (Use 157701)	89
156653	Drag Link & Plugs Assy-LHD (Use 157701)	89
156655	Drag Link Assy-RHD (Use 157704)	89
156656	Drag Link and Plugs Assy-RHD (Use 157704)	89,90,98
BZ 156658	Spring-Drag Link-Front & Rear Ends	89,90,98
BZ 156659	Seat-Drag Link Spring-Front & Rear Ends	89,90,98
BZ 156660	Plug-Drag Link-Front & Rear Ends	89,90,98
BZ 156661	Ball Seat-Drag Link-Front & Rear Ends	89,90,98
C 156662	Case Assy-Transmission	89,90,98,91 Panel,1940 Without OD
C 156668	Tank Assy-Gasoline-Enamel	89 Bro-Sed-UCo
C 156669	Tank Assy-Gasoline-Enamel	89 Cpe-Cv
C 156670	Tank Assy-Gasoline-Enamel	89 Cab-CabPu-Panel-UCpe
C 156676	Pipe Assy-Gas Tank to Fuel Pump	89,90
BM 156678	Cover-Valve Chamber	89,90,92P,98 Sed,40,41X,10-20 With Std Eng
BO 156679	Escutcheon Plate-Radio	89,39 Cab-CabPu-Panel-UCo-UCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
T 156683	Knob-Transmission Control Lever	89-90-91-98 Comm
BZ 156689	Pad Assy-Brake Pedal	89,90,98,1940 thru 1947 All
BZ 156690	Pad Assy-Clutch Pedal-LHD	89,90,98,1940 All
BZ 156691	Pad Assy-Clutch Pedal-RHD	89,90,98,1940 thru 1947 All
BZ 156695	Lever Assy-Clutch Pedal-RHD	89,90,98,1940 thru 1947 All
	156696 Lever-Clutch Pedal-LHD (Use 158908)	89,90,98
BZ 156698	Lever Assy-Brake Pedal-LHD	89,90,98,1940 All
BZ 156699	Lever Assy-Brake Pedal-RHD	89,90,98,1940 All
EM 156703	Fuel Pump Assy-Standard	89,90,92X,98 Sed,40,41X,48P,10-20 With Std Eng
EM 156704	Gasket-Fuel Pump to Cylinder	89,90,92X,98 Sed,40,41X,48P,10-20 With Std Eng
EM 156709	Core Assy-Radiator	89,90,98
	156712 Carburetor Assy (Use 157989)	89
BZ 156728	Tube Assy-Master Cyl to L Front Hose-RHD	89,90,98
BZ 156730	Tube Assy-Master Cyl to R Front Hose-RHD	89,90,98
EM 156732	Tube Assy-Brake-Tee to L Front Hose-LHD	89,90,98
BZ 156736	Tube Assy-Brake-Tee to Rear Axle	89,90
F 156754	Drive Shaft Assy-Rear Axle	89-90 exc Cab-CabPu-Panel-Station,40-10-20 With Std Engine
F 156756	Oil Seal Assy-Rear Axle Drive Shaft	89-90 exc Cab-CabPu-Panel-Station,40-10-20 With Std Engine
	156761 Wheel Assy-16 x 3.50 (Use 159937)	89
F 156763	Hub Cap-Wheel-Outer	89
C 156764	Hub Complete-Front	89-90 Pass,40T,40P
	156765 Hub Assy-Front-With Brake Drum (Use 156764)	89
C 156767	Hub Complete-Rear	89-90 Pass,40T,40P
	156768 Hub Assy-Rear-With Brake Drum (Use 156767)	89
BZ 156776	Tube Assy-Master Cylinder to Frame Tee	89,90,98
	156778 Shock Absorber-Front (Use 166478)	89
	156779 Shock Absorber-Rear-(Use 166573)	89
C 156785	Steering Gear Assy-LHD	89,90,98
	156786 Steering Gear Assy-RHD (Use 158640)	89,90,98
BZ 156787	Ball Arm-Steering Gear-LHD	89,90,98
BZ 156788	Ball Arm-Steering Gear-RHD	89,90,98
C 156790	Jacket Tube and Bracket Assy-Steering	89,90,98
BZ 156793	Dust Shield-Brake Drum	89,90 exc Cab-CabPu-Panel-Station,40T,40P,48 5Sed
CF 156796	Cable Assy-Rear Brake-RH-For LHD	89,90 exc Cab-CabPu-Panel-Station
CF 156797	Cable Assy-Rear Brake-LH-For LHD	89,90 exc Cab-CabPu-Panel-Station
F 156798	Piston-Brake Control Wheel Cylinder	89,90 exc Cab-CabPu-Panel-Station,40T,40P
F 156799	Guard-Brake Control Wheel Cylinder End	89,90 exc Cab-CabPu-Panel-Station,40T,40P
C 156816	Crossmember Assy-Frame Engine Supp-Rear	89,90,98
BZ 156821	Bracket-Frame Rear Axle Cross Member Shock Absorber-RH	89,90,1940 thru 1947 All
BZ 156822	Bracket-Frame Rear Axle Crossmember Shock Absorber-LH	89,90,1940 thru 1947 All
BZ 156823	Support Assy-Frame Front Fender-RH	89
BZ 156824	Support Assy-Frame Front Fender-LH	89,90,98
BZ 156833	Bracket-Frame Front Spring Rear-RH	89,90,98
BZ 156834	Bracket-Frame Front Spring Rear-LH	89,90,98
BZ 156835	Reinf-Frame Front Spring Rear Bracket-RH	89,90,98
	156839 Bracket-Frame Rear Spring Front -(Use 164129)	89,90
BZ 156840	Bracket-Frame Running Board-Front	80,81,82,89,90,91,92
BZ 156841	Bracket-Frame Muffler Support	89,90,98
C 156844	Muffler Assy	89,90,98
BZ 156845	Clamp-Muffler Front	89,90,98
BZ 156846	Fabric-Muffler Clamp Support-Front	89,90,98,1940 All,10 Cab-CabPu-Del,20C,28,58,178
BZ 156848	Clamp-Tail Pipe-Front	89
CF 156849	Tail Pipe	89,98 Cab-CabPu,90 Panel
CF 156850	Pipe Assy-Exhaust	89,90,98
EM 156852	Cover-Exhaust Pipe-Front	89,90,98
EM 156853	Cover-Exhaust Pipe-Rear	89,90,98
BO 156858	Starting Switch-Foot Type-LHD	89,90,98,91 Panel
BO 156859	Knob Assy-Starter & Lighting Switch	89
BO 156860	Knob-Starter & Lighting Switch	89
BO 156861	Extension Rod-Starting Switch-LHD	89,90,98
BZ 156864	Bumper-Frame Rear Axle Carrier	89,90,40
A 156865	Guard-Engine-Front	89,90,98
A 156866	Guard Assy-Engine-RH	89
A 156872	Guard-Engine-LH	89,90,98
BO 156873	Knob Assy-Radio Control	89,90-98 UCo-UCpe-Cab-CabPu-Panel,91 Panel
BT 156876	Pinion-Transmission Speedometer-4-1/9 to 1	89,90,40
BO 156878	Pinion-Transmission Speedometer-4-5/9 to 1	89,90 1940 All
BZ 156886	Ratchet Rod Assy-Hand Brake Grip	89,90,91,98,40,41,44,45,48,10,11,18,20,21,28,51,53, 58,171,173,178

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 156887	Grip-Hand Brake	89,90,91,98,40,41,44,45,48,10,11,18,20,21,28,51,53,58,171,173,178,481,483,491,493,500,501,503
BZ 156894	Cylinder-Wheel Brake-RH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BZ 156895	Cylinder-Wheel Brake-LH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BZ 156898	Spring Clip-Hub Cap	89-90 exc Cab-CabPu-Panel-Station,40T,40P,10T,40-10 UCo-UCpe,20T
156900	Spring Assy-Front-Light Scale-RH (Use 157247)	89
156901	Spring Assy-Rear-Light Scale (Use 157081)	89 Bro-CvBro
156902	Spring Assy-Rear-Light Scale (Use 157082)	89 Sedan
156903	Spring Assy-Rear-Light Scale (Use 157083)	89 CvCpe-3Cpe-VicCpe
BZ 156910	Clip-Rear Spring-Light Scale	89
BZ 156911	Plate-Rear Spring Clip	89,90
156912	Clip-Front Spring-Front (Use 154586)	89 With Stabilizer
156913	Clip-Front Spring	80,88,89,90,98
BX 156914	Backing Plate Assy-Brake-RH & LH Front	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156915	Backing Plate Assy-Brake-RH-Rear	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156916	Backing Plate Assy-Brake-LH-Rear	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156920	Abutment Cap-Backing Plate-RH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156921	Abutment Cap-Backing Plate-LH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
156926	Shoes Assy-Brake (Use 163504)	89-90 exc Cab-CabPu-Panel-Station
156932	Brake Lining-Package (Use 2-163505)	89
F 156933	Spring-Brake Adjusting Screw	89-90 exc Cab-CabPu-Panel-Station,40T,40P
F 156934	Eccentric-Brake	89-90 exc Cab-CabPu-Panel-Station,40T,40P
F 156935	Link-Brake Anchor	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156936	Lever-Brake Shoe Cable-RH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156937	Lever-Brake Shoe Cable-LH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156938	Strut-Brake Shoe Cable Lever-RH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
BX 156939	Strut-Brake Shoe Cable Lever-LH	89-90 exc Cab-CabPu-Panel-Station,40T,40P
F 156940	Spring-Brake Shoe to Anchor Pin	89-90 exc Cab-CabPu-Panel-Station,40T,40P
156946	Bracket-Generator Support (Use 153192)	89
BO 156953	Harness-Instrument Wire	89,91 Panel
F 156955	Cable Assy-Battery to Starter Switch-LHD	89,90,98,91 Panel
BZ 156957	Cable Assy-Starter Switch to Starter-LHD	89,90,98,91 Panel
BZ 156959	Terminal-Battery to Starter Switch Cable-LHD	89,90,98
BO 156983	Wire & Socket Assy-Speedometer Lamp-LHD	89
BO 156984	Wire & Socket Assy-Speedometer Lamp-RHD	89
BO 156990	Wires & Loom Assy-Generator	89 Without Radio
BO 156991	Wire & Loom Assy-Generator	89 With Radio
BO 156996	Body Assy-Lamp Socket-Oil & Amp Lamps	89
BT 156998	Spring-VD-Pipe Hose Reinforcing	38 thru 1950 All
CF 157000	Spring Assy-Front	89-90-98 Cab-CabPu-Panel,90 Sts,98 Sed
BO 157014	Core Assy-Heater	38-39 DeLuxe Heater
BO 157023	Motor Assy-Heater	38-39 Custom Heater
BO 157024	Fan and Wheel Assy-Heater	38-39 DeLuxe Heater
BO 157025	Fan and Wheel Assy-Heater	38-39 Custom Heater
BO 157027	Knob-Heater Defroster Control	38-39 Custom Heater
BO 157031	Hose-Heater-6 Ft Length	38-39 DeLuxe & Custom Heaters
A 157037 Pr	Radiator Assy-Less Lamps	80,88 exc Sedan
A 157038 Pr	Radiator Assy-Less Lamps	81,82,88 Sedan
A 157039 Pr	Radiator Assy-Less Lamps	83
A 157040 Pr	Radiator Assy-Less Lamps	84,85,87
BZ 157041	Bracket-Frame Running Board-Front	83,84,85,87,88,93,95,97,98
BO 157042	Rod-Heater Door Hinge-RH	38-39 Custom Heater
BO 157043	Rod-Heater Door Hinge-LH	38-39 Custom Heater
BO 157044	Knob-Hot Water Heater Door	38-39 Custom Heater
157046	Clamp-Hot Water Hose (Use 159080)	38-39 All
157047	Pipe Nipple-3/8" Pipe x 2-1/2" (Use 159081)	38-39 Heaters-Cyl Head Connection
F 157048	Switch Assy-Lighting	36 All
157050	Spring Assy-Front-LH (Use 157248)	89
*SP 157052	Spark Plug Complete-C7-For Std Head	30 to 32 Hud-Essex
*SP 157053	Spark Plug Complete-al	32 Terr With Std Head,32 Hud-Essex With Hi-Comp Head,1946 All
*SP 157054	Spark Plug Complete-J7	33 Hud 6-Terr,34 thru 1950 All
*SP 157055	Spark Plug Complete-H10-For HC Head	36 thru 39 All,1946 thru 1950 With Alum Hd
*SP 157056	Spark Plug Complete-A7-For Std Head	33 Hudson 8
C 157073	Cable Assy-Rear Brake-RH-RHD	89-90 exc Cab-CabPu-Panel-Station
C 157074	Cable Assy-Rear Brake-LH-RHD	89-90 exc Cab-CabPu-Panel-Station
BZ 157075	Shim-Shock Absorber Piston Metering Washer	80,81,82,88
C 157079	Tube Assy-Master Cyl to Rear Axle	80 thru 85,89,90,91,92,93,95
CF 157081	Spring Assy-Rear	80-90 Bro-CvBro-UCpe
CF 157082	Spring Assy-Rear	89-90 Sed-UCo
CF 157083	Spring Assy-Rear	89-90 3Cpe-VicCpe-CvCpe
BZ 157084	Retainer-Rear Spring Clip Cushion	89-90 exc Cab-CabPu-Panel

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 157092	Center Bolt-Rear Spring	89-90 Pass;1941 Springs 162442-3-4-163554,164018-19-20-21
BZ 157094	Trunion-Vac Cyl Piston Valve Rod	1939 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
BZ 157095	Link Assy-Vac Coot Valve Lever to Trunion	38 thru 1941 All,1942 thru 1950 With VD-HDM or SMD
157110	Housing Assy-Steering Gear-RHD (Use 158641)	89,90,98
BZ 157113	Shaft & Roller Tooth Assy-Steering Gear-LHD	89,90,98
BZ 157114	Shaft & Roller Tooth Assy-Steering Gear-RHD	89,90,98
C 157117	Main Column & Worm Assy-Steering Gear-LHD	89,90,98
C 157118	Main Column & Worm Assy-Steering Gear-RHD	89,90,98
C 157119	Tube-Steering Gear Main Column	89,90,98
157141	Control Assy-Transmission (Use 155474)	89,90-98 Comm,91 Panel
157142	Lever Assy-Trans Control (Use 155476)	89,90-91-98 Comm
157145	Tube Assy-Master Cyl to R/A Hose (Use 157989)	87,88
BZ 157146	Tube Assy-Master Cyl to Rear Axle Hose	87,88,97,98
157150	Main & Wrapper Leaf-Front Spr (Use 158868)	89
C 157160	Leaf-Rear Spring Main	89,90 Pass
157161	Leaf-No. 2-Rear Spring (Use 158858)	89
157165	Leaf-Rear Spring Rebound (Use 158846)	89,90 Pass
157174	Screw Assy-Jack (Use 164593)	89,90,98,91 Panel,40T,40P,40-10 UCo-UCpe-Panel,48 Panel,10T,10P,18P
C 157175	Base-Jack	89,90,98,91 Panel,40T,40P,40-10 UCo-UCpe-Panel,48 Panel,10T,10P,18P,20T
BX 157178	Washer-Brake Anchor Link Spring	89,90 exc Cab-CabPu-Panel,40T,40P
157179	Center Bolt-Spring (Use 151886)	89,93 thru 97,98 Sed
157181	Shock Abs Assy-Front-Light Control (Use 166477)	83,84,85,87
157182	Shock Abs Assy-Rear-Light Control (Use 162551)	83,84,85,87
157183	Shock Abs Assy-Front-Heavy (Use 166477)	83,84,85,87
BZ 157184	Shock Absorber Assy-Rear-Heavy Control	83,84,85,87
BZ 157196	Clip-#4-Spring	89,90 Pass
BZ 157197	Clip-#1-Spring	89,92
BZ 157198	Clip-#2-Spring	81 thru 87,80-88 Sedan,1940 Springs 161115-6-7-8
BZ 157199	Clip-#2-Spring	89
C 157204	Tie Rod Assy-Front Axle	89,90 thru 98
C 157205	Tie Rod-Front Axle	89,90 thru 98
157206	Use 159782	
157207	Use 159783	
157208	Use 159784	
157216	Use 159788	
BX 157219	Clamp Bolt-Tie Rod End	89,1939 thru 1950 All
BX 157220	Grease Fitting-Tie Rod End Cover	89,90 thru 98,1942-1946-1947 All
BO 157228	Bracket Assy-Horn Mounting-Fender Type-RH	80,81,82,88
BO 157229	Bracket Assy-Horn Mounting-Fender Type-LH	80,81,82,88
BO 157230	Bracket Assy-Horn Mounting-Fender Type-RH	83,84,85,87
BO 157231	Bracket Assy-Horn Mounting-Fender Type-LH	83,84,85,87
BO 157246	Escutcheon Plate-Radio-Grained	89
C 157247	Spring Assy-Front-RH-LHD and LH-RHD	89,90 exc Cab-CabPu-Panel-Station
C 157248	Spring Assy-Front-LH-LHD and RH-RHD	89,90 exc Cab-CabPu-Panel-Station
BZ 157272	Bracket-Rad Core to Headlamp	90,98
BM 157273	Pulley-Generator	89 (6 volt),38 thru 1941,1946-1947 12 Volt
BT 157274	Electric Hand Small Parts Repair Kit	35 thru 39 All
157298	Steering Wheel-Painted (Use 153320)	89 Bro-Sed-3Cpe-VicCpe-CvCpe-CvBro
157310	Head Assy-Cylinder-Std (Use 165534)	80,81,82,83,88
157311	Head Assy-Cylinder-Std (Use 162776)	89,90,98 Sedan
157312	Use 159562	
C 157313	Head Assy-Cylinder-Std	84,85,87
C 157316	Head Assy-Cylinder-Std	80,81,82,83,88 Export
157324	Use 159058	
BM 157325	Bushing-Cylinder Head Temp Indicator Hole	80 thru 88,95-97 Hi Comp Head
BZ 157344	Orifice Plate-Shock Absorber Piston Valve	83,84,85,87,93,95,97
BZ 157349	Valve-Front Shock Absorber Pressure Relief	89,90,98
157363	Connecting Rod Assy-RH (Use 166241)	80 thru 88,92 thru 97, 98 exc 5Sed,41 thru 48, 11 thru 18,21 thru 28,40-10-20 With L Eng
157364	Connecting Rod Assy-LH (Use 166242)	80 thru 88,92 thru 97,98 exc 5Sed,41 thru 48, 11 thru 18,21 thru 28,40-10-20 With L Eng
157375	Connecting Rod Assy-RH (Use 166238)	89,90,98 5Sed,40-10-20 With Std-Eng
157376	Connecting Rod Assy-LH (Use 166239)	89,90,98 5Sed,40-10-20 With Std-Eng
BZ 157382	Spring Cov Assy-Rear LH-Front RH	89,90 exc Cab-CabPu-Panel-Station
BZ 157383	Spring Coy Assy-Rear RH-Front LH	89,90 exc Cab-CabPu-Panel-Station
157384	Use 158970	
157385	Use 158971	
157387	Use 158973	
157400	Shock Abs Assy-Front (Use 166477)	
157401	Shock Abs Assy-Rear (Use 162551)	
157404	Shock Abs Assy-Front-Heavy Control (Use 166478)	83,84,85,87,93,95,97

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	157405 Shock Abs Assy-Rear-Heavy Control (Use 166575)	83,84,85,87,93,95,97
BZ	157406 Metering Washer-Front Shock Absorber Piston	81,82,80-88 Sedan,90,91,92
BT	157407 Retainer Washer-Shock Absorber Seat Tube	80 thru 89,90 thru 98
BT	157409 Interlock Kit-Transmission Shift Rail	89
BT	157410 Bracket-Transmission Shift Rail Lock Rod	89
C	157411 Main Leaf-Front Spring-For Spring 157000 .	89-90-98 Cab-CabPu-Panel,90 Sta,98 Sed
BZ	157419 Center Bolt-Spring-For Spring #157000	89-90-98 Cab-CabPu-Panel,90 Sta,98 Sed
BZ	157422 Shock Abs Assy-Front-Heavy Control	80,81,82,88,91,92
	157423 Shock Absorber (Use 166575)	
	157424 Shock Absorber (Use 301170)	
C	157528 Carrier and Gear Set Assy-4-1/.9 to 1	39 All
	157529 Gear & Pinion-Rear Axle Drive-Matched-4-1/9 to 1 (Use 166188)	39 thru 1941 All
BX	157530 Gear-Rear Axle Drive-4-1/9 to 1	39 thru 1941 All,1946-1947 All
BX	157531 Pinion-Rear Axle-4-1/9 to 1	39 thru 1941 All,1946-1947 All
	157533 Gear & Pinion-Rear Axle Dr (Use 166189)	39 thru 1941 All
BX	157534 Gear-Rear Axle Drive-4-5/9 to 1	39 thru 1941 All,1946-1947 All
BX	157535 Pinion-Rear Axle Drive-4-5/9 to 1	39 thru 1941 All,1946-1947 All
BX	157540 Bolt-Rear Axle Drive	1939 thru 1947 All
	157541 Rheostat-Instrument Light (Use 160092)	93,95,97
F	157542 Hub Cap-Wheel Outer	90
F	157543 Hub Cap-Wheel Outer	92,93,95,97,98
BO	157544 Weathermaster Kit-For B&B Heater	1938-1939 All
BZ	157545 Stud-Rear Stabilizer ConnectOr	81 thru 87,92 thru 97
	157548 Case & Stud Assy-Differential (Use 166190)	1939 thru 1942 All
BX	157553 Shaft-Differential Pinion	1939 thru 1950
C	157555 Carrier & Cap Assy-Differential	1939-1940 All
	157557 Use 158940	
	157558 Use 158941	
	157559 Use 158942	
BX	157560 Retainer-Drive Pinion Rear Bearing Shim	39 All
BX	157561 Spacer-Drive Pinion Bearing	39 All
	157562 Use 157980	
	157563 Use 157981	
	157564 Use 157982	
	157565 Use 157983	
	157566 Use 157984	
	157567 Use 157985	
	157568 Use 157986	
	157569 Use 157987	
BZ	157570 Button Assy-Horn	92
BZ	157572 Escutcheon-Horn Button	92
BT	157573 Spacer-Shift. Rail Lock Ball Spring	90-91 Panel-98 With Handy Shift
	157584 Wheel-Steering-Painted-17" (Use 153320)	90 exc Comm,98 Sed
C	157584 Wheel-Steering-Painted-18"	92
	157586 Wheel-Steering-Tenite-18" (Use 159111)	39 All
BZ	157587 Button-Horn-Painted	90 exc Comm,98 Sed
	157588 Wheel Assy-16 x 4.00 (Use 166486)	90,92
	157589 Button Assy-Horn (Use 159112)	93,95,97
	157591 Escutcheon-Horn Button (Use 159112)	93,95,97
C	157593 Spring Assy-Rear-Light Scale	92 Bro-CvBro,93-95 exc Sedan
CF	157594 Spring Assy-Rear-Light Scale	92-93-95-98 Sedan
	157595 Spring Assy-Rear-Light Scale (Use 157593)	92 3Cpe-VicCpe-CvCpe
	157596 Spring Assy-Rear-Heavy Scale (Use 157597)	92-93-95 Bro
C	157597 Spring Assy-Rear-Heavy Scale	92-93-95-97-98 Sed
C	157598 Spring Assy-Rear-Heavy Scale	92 CvBro,93-95 exc Sedan
C	157599 Spring Assy-Rear-Heavy Scale	92 CvCpe-3Cpe-VicCpe
	157600 Use 151886	
	157606 Use 157989	
BM	157608 Carburetor Assy	1939-1940 X Engines
BO	157632 Horn Assy-Air Type-Front Mt-6 V	90,91,92,98
BO	157634 Horn Assy-Air Type-High Pitch-6 V	92,93,95,97
BO	157635 Horn Assy-Air Type-Low Pitch-6 V	92,93,95,97
BO	157636 Horn Assy-Air Type-High Pitch-12 V	92,93,95,97
BO	157637 Horn Assy-Air Type-Low Pitch-12 V	92,93,95,97
	157641 Shaft Assy-Propeller-Second Type (Use 157642)	90
C	157642 Shaft-Propeller-Second Type	90
	157645 Shaft 7 Rear Joint Assy-Prop-Second Type (Use 157642)	90
	157651 Wheel Assy-16 x 4.00 (Use 166486)	90 Bro-Sed-3Cpe-VicCpe-CvCpe-CvBro,40 CvCpe
BM	157652 Distributor Assy-With Low Rate Gen	90,91,98 exc Sedan
BM	157653 Distributor Assy-With Low Rate Gen	90,91,92,93,98,90P
*BM	157654 Generator Complete-Includes Pulley	39 All,40,41X,48,10 With Std Engine,18
BM	157656 Ignition Coil Comp-Includes Lock-6V	90,92,91,93,98
BM	157657 Ignition Coil Comp-Includes Lock-6V	95,97

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	157667 Screw Assy-Jack (Use 166079)	92,93,95,97,41 thru 47,11 thru 17
BZ	157668 Base-Jack	92,93,95,97,41 thru 47,11 thru 17,21 thru 27,51,52,53,54
BO	157674 Knob Assy-Radio Control	90,91,92,98
BO	157676 Knob Complete-Radio Control	93,95,97
BO	157680 Push Button-Radio Control	39 All
BO	157684 Facing-Radio Control Button Disc	39 All
BO	157685 Retaining Spring-Radio Cont Push Button	39 All
BO	157691 Knob Assy-Light,Starter & Cl Switch	90 exc Comm,91,92,98
BO	157692 Knob-Light,Starter & Cl Switch	90 exc Comm,91,92,98
	157693 Use 155678	
	157700 Drag Link Assy-LHD-Second Prod (Use 157701)	90,98
C	157701 Drag Link Assy-LHD	90,98
	157703 Drag Link Assy-RHD-Second Prod (Use 157704)	90,98
C	157704 Drag Link Assy-RHD	90,98
BO	157709 Extra Horn Kit-Front Mount Air Type	90,91,92,98
C	157710 Steering Wheel Kit-Plastic	90,91,92,98
BO	157716 Weather Master Kit-Eaton Heater	39 All
BO	157717 Adapter-Weather Master	39 All
BO	157718 Hose-Weather Master	39 All
BZ	157723 Rebound Clip-Spring-#3-2 Piece	89-90 exc Comm
C	157726 Service Kit-Extra Spring	89-90 exc Cab-CabPu-Panel-Station
BO	157728 Companion Horn Assy	90,91,92,98
	157734 Universal Joint Repair Kit (Use 164369)	36 thru 1942 All
	157737 Use 155527	
BO	157747 Generator Complete-Low Rate	91
	157751 Use 162337	
	157752 Use 162338	
EX	157753 Companion Flange-Rear Axle	1939-1940 All
BT	157754 Companion Flange-Transmission	39 All,1940 Without OD
BZ	157756 Push Rod-Brake Pedal to Brake Control Lever	39 All Models
BZ	157757 Adj End and Yoke Assy-Brake Pedal Push Rod	1939 thru 1947 All
BZ	157758 Adj End-Brake Pedal Push Rod	1939 thru 1947 All
CF	157768 Tail Pipe	90 exc Cab-CabPu-Panel
CF	157769 Tail Pipe	92,93
CF	157770 Tail Pipe	98 exc Cab-CabPu-Panel
CF	157771 Tail Pipe	95
CF	157772 Tail Pipe	97
BZ	157773 Support Assy-Tail Pipe Clamp-Front	39 All,43,47,48
BZ	157776 Fabric-Tail Pipe Bracket-Rear	1939 thru 1942 exc Cab-CabPu-Panel,51 thru 54, 171 thru 174
	157777 Use 147297	
BZ	157778 Reinforcement-Gas Tank Neck to Body Cushion	1939-1940 Sed-2Sed-UCo,10T,10P,11 thru 17,18P,10 UCo-UCpe
	157786 Tank Assy-Gasoline-12-1/2 Gal (Use 157789)	90 Bro-Sed-UCo,98 Sed,40 Sed-2Sed-UCo
*C	157787 Tank Assy-Gasoline-12-1/2 Gal	90-40P-3Cpe-VicCpe-CvCpe-CvSed,40T VicCpe
*C	157788 Tank Assy-Gasoline-12-1/2 Gal	90-98 Cab-CabPu-Panel,90 UCpe-Station,40T 3Cpe,40UCpe
*C	157789 Tank Assy-Gasoline-16-1/2 Gal	92-93-95-97 Bro-Sed,41 thru 48 Sed-2Sed
C	157790 Tank Assy-Gasoline-16-1/2 Gal	92-93-95-41-44-45 VicCpe-3Cpe-Cv
BZ	157794 Neck Assy-Gasoline Tank Filler	1939-1940 Bro-Sed-UCo
BZ	157796 Neck Assy-Gasoline Tank Filler	1939-1940 Cpe-CvSed
BZ	157798 Neck-Gasoline Tank Filler	90-98 Cab-CabPu-Panel,90-91-92-93-95 UCpe-Sta
BZ	157799 Cushion-Gas Tank Filler Neck to Body	1939-1940 Bro-Sed-UCo,10T,10P,11 thru 17,18P,10 UCo-UCpe
	157800 Shock Absorber (Use 166573)	
	157801 Shock Absorber (Use 166573)	
BZ	157804 Strap-Gasoline Tank-Plain	92,93,95,97,90-98 Pass,40T-40P-41-44-45-47-48
	157807 Rebound Clip-Spring-#1 #4 Bolted (Use 161193)	89-90 exc Cab-CabPu-Panel Station'
BO	157818 Shut Off Valve-Hot Water Heater	39 All,1941-1942 Recirculating Heater
BX	157819 Washer-Brake Anchor Link-Brass	90 exc Comm,40T,40P
	157821 Use 160220	
	157822 Use 160221	
	157823 Use 160222	
EM	157830 Driving Pin-Flywheel	1939 thru 1941 All,1942-1946-1947-500 With 9" Clutch
	157833 Cover Assy-Timing Gear (Use 166309)	1939 thru 1942 6 Cyl
	157835 Core Assy-Radiator (Use 165530)	92
	157836 Core Assy-Radiator (Use 165530)	93
	157837 Core Assy-Radiator (Use 165533)	95,97
BZ	157842 Fabric and Plate Assy-Tail Pipe Brkt-Rear	1939 thru 1942 exc Cab-CabPu-Panel,51 thru 54,171 thru 174
	157843 Use 157842	
	157844 Propeller Shaft Assy (Use 157845)	90,92,93,95
C	157845 Propeller Shaft	90,92,93,95
	157848 Propeller Shaft & Rear Joint Assy (Use 157845)	90,92,93,95

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
157851	Carburetor Assy (Use 159654)	93,95,97,92
BZ 157854	Bracket-Autopoise Bar-RH	90 exc Cab-CabPu-Pan-Sta,98 Sedan
BZ 157855	Bracket-A utopoise Bar-LH	90 exc Cab-CabPu-Pan-Sta,98 Sedan
157862	Use 161965	
157863	Gasket-Water Jacket Cover (Use 161750)	1939 thru 1947 6 Cyl
157864	Gasket-Water Jacket Cover (Use 161751)	1939 thru 1950 8 Cyl
157865	Use 159564	
157866	Cylinder Head Assy (Use 159565)	92,93,Export,98 exc 5Sed Export
157867	Use 159566	
BM 157871	Pipe Assy-Oil Pump to Check Valve	1939 thru 1947 6 Cyl
BM 157873	Pipe Assy-Oil Pump to Cylinder	1939 thru 1947 6 Cyl
157875	Gasket-Oil Pan (Use 165484)	1939 thru 1947 6 Cyl
BM 157876	Seal-Oil Pan Suction Pipe	1939 thru 1947 All,1948 thru 1950 8 Cyl
*C 157877	Tray Assy-Oil Pan	90,98 Sed exc X Engine,40-10-20 With Std Eng
C 157881	Tray Assy-Oil Pan	92,93,90-98 X,98 exc Sed,41,43,48,11,12,18, 40-10-20 With L Eng,1946-1947 6 Cyl
157884	Use 1 each 157885-157980	
BM 157885	Cap-Crankshaft Bearing #1	90,92,93,98, X Engines,40,41,43,48
157886	Housing Assy-Clutch (Use 155499)	90,91 Panel,98
F 157895	Retainer-Water Pump Shaft Seal	1939 thru 1947 All
BZ 157923	Bracket-Frame Radiator Lower Tank Shield	92,93,95,97
C 157929	Torsion Bar Assy-Autopoise	92,93,95,97,90 Pass,98 Sed
157931	Bushing-Autopoise Bar (Use 165488)	92,93,95,97,90 Pass,98 Sed,1940 Pass
BZ 157932	Bracket-Autopoise Bar Bushing	92,93,95,97,90 Pass,98 Sed,1940 Pass
BZ 157933	Bracket-Autopoise Bar Mtg-RH	92,93,95,97
BZ 157934	Bracket-Autopoise Bar Mtg-LH	92,93,95,97
BZ 157935	Connector Autopoise	92,93,95,97,90 Pass,98 Sed
BZ 157936	Bracket-Autopoise-RH	92,93,95,97,90 Pass,98 Sed
BZ 157937	Bracket-Autopoise-LH	92,93,95,97,90 Pass,98 Sed
F 157938	Cushion-Autopoise Connector & Shock Abs	92,93,95,97,90 Pass,98 Sed,1940 thru 1950
157939	Use 157929	
157947	Use 166257	
157948	Use 166257	
BX 157949	Spring-Brake Shoe to Anchor Pin Secondary	90 Pass,40T,40P,48 5Sed
BZ 157953	Shield-Radiator Core Side	92
BZ 157954	Shield-Radiator Core Side	93
157956	Use 1 each 157885-157980	
157957.	Use 1 each 35077-157981	
157958	Use 1 each 37016-157982	
157960	Use 1 each 33109-157984	
157961	Use 1 each 33114-157985	
157962	Use 1 each 33119-157986	
157963	Use 1 each 37352-157987	
BM 157964	Bearing-Crankshaft-Upper #1	1939 thru 1941 6 Cyl
BM 157965	Bearing-Crankshaft-Lower #1	1939-1940 6 Cyl
BM 157966	Bearing-Crankshaft-Upper #2	1939 thru 1941 6 Cyl
157967	Use 162535	
BM 157968	Bearing-Crankshaft-Upper #3	1939 thru 1941 6 Cyl
BM 157969	Bearing-Crankshaft-Lower #3	1939-1940 6 Cyl
BM 157970	Bearing-Crankshaft-Upper #1	1939 thru 1950 8 Cyl
BM 157971	Bearing-Crankshaft-Lower #1	1939 thru 1950 8 Cyl
BM 157972	Bearing-Crankshaft-Upper #2	1939 thru 1950 8 Cyl
BM 157973	Bearing-Crankshaft-Lower #2	1939 thru 1950 8 Cyl
BM 157974	Bearing-Crankshaft-Upper #3	1939 thru 1950 8 Cyl
BM 157975	Bearing-Crankshaft-Lower #3	1939 thru 1950 8 Cyl
BM 157976	Bearing-Crankshaft-Upper #4	1939 thru 1950 8 Cyl
BM 157977	Bearing-Crankshaft-Lower #4	1939 thru 1950 8 Cyl
BM 157978	Bearing-Crankshaft-Upper #5	1939 thru 1950 8 Cyl
BM 157979	Bearing-Crankshaft-Lower #5	1939-1940 8 Cyl
MF 157980	Bearing Assy-Crankshaft-Reamed #1	1939-1940 6 Cyl
MF 157981	Bearing Assy-Crankshaft-Reamed #2	1939-1940 6 Cyl
MF 157982	Bearing Assy-Crankshaft-Reamed #3	1939-1940 6 Cyl
MF 157983	Bearing Assy-Crankshaft-Reamed #1	1939 thru 1950 8 Cyl
MF 157984	Bearing Assy-Crankshaft-Reamed #2	1939 thru 1950 8 Cyl
MF 157985	Bearing Assy-Crankshaft-Reamed #3	1939 thru 1950 8 Cyl
MF 157986	Bearing Assy-Crankshaft-Reamed #4	1939 thru 1950 8 Cyl
MF 157987	Bearing Assy-Crankshaft-Reamed #5	1939-1940 8 Cyl
BM 157989	Carburetor Assy	90-92-98 Without VD
BO 157997	Dial Scale-Radio-Brown	92
BO 157998	Dial Scale-Radio-Tan	93,95,97
158006	Use 159704	
C 158007	Tube & Rod Assy-Handy Shift Lever-RHD	1939 All
BT 158008	Lever-Trans Handy Shift	39 All
158009	Fulcrum-Handy Shift Lever (Use 165537)	1939-1940 All,10,11,18,20,21,28

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 158010	Washer-Handy Shift Lever Anti Rattle	1949 thru 1950 All
158011	Lever Tube & Fulcrum Bracket Assy-Handy Shift-LHD (Use 164435)	39 All
158012	Use 158369	
BT 158017	Grommet-Handy Shift Lever Tube Lever-Lower	39 All,1941-1942-1946-1947 RHD
158018	Bracket-Handy Lever Fulcrum (Use 300986 & 300988)	1939-1940 All,10,11,18,20,21,28,51,53,58,171,173,178
BT 158019	Ring-Handy Shift Lever Fulcrum Bracket	1939-1940 All,10,11,18,20,21,28,51,53,58,171,173,178
BT 158020	Bracket-Handy Shift Lever Tube-Upper	90,98
158021	Bracket-Handy Shift Lever Tube-Upper (Use 165663)	91,92,93,95,97,40 thru 48-10-11-18-20-21-28 Without DI
BT 158022	Bracket-Handy Shift Lever Tube-Lower	90,98
BT 158023	Bracket-Handy Shift Lever Tube-Lower	90,98
BT 158024	Wire,Casing & Bracket Assy-Handy Shift Lever-LHD	1939-1940 All
BT 158025	Wire,Casing & Bracket Assy-Handy Shift Lever-RHD	1939-1940 All
158026	Wire & Casing Assy-Handy Shift Lever-LHD (Use 158024)	1939-1940 All
BT 158027	Wire & Casing Assy-Handy Shift Lever-RHD	1939-1940 All
BT 158028	End-Handy Shift Lever Push Rod-Upper	1939 thru 1950 All
BT 158029	Spring-Handy Shift Lever Push Rod-Upper	1939 thru 1947 All LHD,1948 thru 1950 With HDM & All RHD
BT 158030	Anchor-Handy Shift Lever-Wire	1939 thru 1950 All
BT 158031	End-Handy Shift Push Rod-Lower	1939 thru 1950 All
BT 158032	Push Rod-Handy Shift Lever	1939 thru 1947 All LHD,1948-1949-1950 All
BT 158033	Anchor Brkt-Handy Shift Lever Wire Casing Lower	1939-1940 All
158035	Cover Assy-Handy Shift Trans-RHD (Use 160873)	39 All
TF 158039	Gasket-Handy Shift Transmission Cover	1939-1940 All
158040	Use 158806	
158041	Use 158045	
BT 158044	Pivot Bolt-Handy Shift Trans Cover Shift Finger	39 All
BT 158045	Shift Shaft Assy-Handy Shift Trans Cover-LHD	1939-1940 All
BT 158048	Lever-Handy Shift Trans Cover Shift Shaft	1939-1940 All
BT 158056	Selector Plate-Handy Shift Trans Cover Shift	1939-1940 All
BT 158057	Bolt-Handy Shift Trans Cover Selector Plate	39 All
BT 158058	Push Rod-Handy Shift Trans Cover Selector Plate	1939-1940 All
BT 158059	Seal-Handy Shift Trans Cover Selector Plate Push Rod	1939-1940 All
BT 158060	Rod Assy-Trans Handy Shift Lever Tube to Trans Cover-LHD	90,98
158061	Use 161250	
BT 158062	Rod Assy-Handy Shift Lever Tube to Trans Cover-RHD	90,98
BT 158063	Rod Assy-Handy Shift Lever Tube to Trans Cover-RED	91,92,93,95,97
158068	Anchor Bracket-Handy Shift Lever Wire Casing- Upper (Use 165032)	1939 thru 1942 All
BT 158071	Insulator Plug-Handy Shift Lever Tube to Trans Cover Rod	1939-1940 All
BT 158072	Tube-Handy Shift Lever Tube to Trans Cover Rod Insulator	1939-1940 All
BT 158073	Insulator Sleeve-Handy Shift Lever Tube to Trans Cover Rod	1939-1940 All
BT 158074	Comp Spring-Trans Handy Shift Lever Tube	1939 thru 1947 All
BT 158075	Grommet-Trans Control Lever Tube to Steering Column Bracket	90,98
BT 158076	Grommet-Trans Control Lever Tube to Steering Column Bracket	91,92,93,95,97
BT 158077	Dust Shield-Trans Handy Shift Lever Wire Selector Push Rod	1939-1940 All
ET 158080	Cover & Pin Assy-Handy Shift Transmission	39 All
BT 158082	Push Rod-Handy Shift Lever Tube-RHD	1931 thru 1947 All
BT 158083	Spring-Handy Shift Lever Push Rod-Upper-RHD	1939 thru 1947 All
BO 158084	Washer-Socket Terminal	1939 thru 1949 All
158085	Use 109807	
BM 158093	Metering Rod-First Leaner	93,95,97,92M
BM 158094	Metering Rod-Second Leaner	93,95,97,92M
C 158098	Heat Deflector & Strap Assy-Gas Tank	91,92,93,95,97,41 thru 47,48P
BO 158121	Clip-Wire	1939-1940 All
BO 158122	Junction Block & Tail & Stop Lamp Wires	39 Bro-Sed-UCo
BO 158130	Wires Assy-Instrument Panel	90,98
158131	Use 158150	
BO 158132	Wires Assy-Instrument Panel	93,95,97
BO 158139	Wires Assy-Horn Relay to Horn	90,92,98
BO 158143	Harness-Headlamp Wires-LHD	91,92
BO 158145	Harness-Headlamp Wires-RHD	91,92
BO 158147	Spacer-Junction Block	91,92,93,95,97
BO 158148	Jewel-Beam Indicator	1939 All,1948 All
BO 158148	Jewel-Direction Indicator	1942 thru 1948 All
BO 158149	Retainer-Beam Indicator & DI Jewel	39 All,1942 thru 1947 All,480 Series
BO 158150	Harness-Instrument Wires	91,92

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	158169 Harness-Headlamp Wires-LHD (Use 158143)	90,98
BO	158176 Socket Assy-License Lamp	1939-1940 Sed-2Sed-UCo
	158178 Use 158179	
BO	158179 Wire & Socket Assy-License Lamp-6 Volt	39 Bro-Sed-UCo
BO	158185 Loom-License Plate Lamp Wire	39 Bro-Sed-UCo,1940 thru 1942 Sed-2Sed,UCo,CA, 1946-1947 Bro-Sed
BO	158193 Wires & Sockets Assy-Frt DomeLamp & Service Lamp-LHD	92-93-95 Bro-Sed,97 Sed
	158202 Use 158203	
BO	158203 Wire & Socket Assy-Hood Lamp-6 Volt	93,95,97
	158204 Wires & Loom Assy-Generator (Use 158205)	90-91-92X-98 exc High Rate Gen
BO	158205 Wires & Loom Assy-Generator	90-91-92-93-98 With High Rate Gen
BO	158206 Wires & Loom Assy-Generator	95,97
BO	158237 Insulating Paper-Dial Scale Button	39 Radio
BZ	158273 Grommet-Gas Tank Filler Neck to Body	1939-1940 Sed-2Sed-UCo
BZ	158274 Rod-Pedal Lever Shaft End Lever to Hill Hold	39 All
BZ	158282 Tube Assy-Hill Hold to Frame Tee-LHD	90,98
BZ	158288 Pipe Assy-Gas Tank to Fuel Pump-RHD	91,92,93,95
BM	158306 Carburetor Assy	90-92-98 With VD
	158317 Lever Assy-Trans Control-Upper (Use 155622)	91,92,93,95,98,With Electric Hand
	158323 Use 166286	
	158324 Use 159153	
	158335 Shock Abs Assy-Front (Use 159206)	
	158336 Shock Abs Assy-Rear (Use 166167)	
	158337 Shock Abs Assy-Front-Heavy Scale (Use 166477)	93,95,97
BZ	158338 Shock Abs Assy-Rear-Heavy Scale	93,95,97
BT	158339 Lock Screw-Trans Second & High Shift Fork	1939-1940 All
BX	158341 Grease Fitting-Straight Drive Type	39 All
F	158344 Gasket Kit-Transmission	1934 thru 1940 All
BT	158345 Grease Fitting-Clutch Housing	1939 thru 1950 All
*HA	158347 Spare Tire Valve Extension	1939 thru 1950 All
BZ	158348 Mtg Assy-Frame Front Spring Front-RH	90,98
BZ	158349 Mtg Assy-Frame Front Spring Front-LH	90,98
BT	158367 Lever-Handy Shift	39 All
	158368 Tube & Fulcrum Brkt Assy-Handy Shift-LHD (Use 166435)	39 All
C	158369 Tube & Fulcrum Brkt Assy-Handy Shift-RHD	39 All,10,11,18,20,21,28,51,53,58,171,173,178
	158373 Use 159111	
	158374 Horn Button Assy (Use 159112)	
	158379 Gear-Camshaft (Use 165907)	
	158421 Piston Assy (Use 166243)	1939 thru 1942 All
F	158423 Ring-Piston-Lower Oil-Std Size	1939 thru 1947 All,1948 thru 1950 8 Cyl
F	158424 Ring-Piston-Lower Oil-.010 o/s	1939 thru 1947 All,1948 thru 1950 8 Cyl
	158432 Hose-W/Shield Defroster (Use 301187)	38-39 With Eaton Heater
F	158433 Kit-Master Cylinder Repair Parts	36 thru 1941 All
F	158434 Kit-Wheel Cylinder Repair Parts	36 thru 39 exc 89-90,40C,48C,48 7Sed, 41 thru 47,1941-1942-1946-1947 All
F	158435 Kit-Wheel Cylinder Repair Parts	89,90 Pass,40T,40P,48 5Sed
EM	158438 Speed Governor-Carburetor	93,95,97
EM	158439 Bearing Cap Assy-Crankshaft #1	90,92,93,98,40,41,43,48
	158463 Condenser-Oil Filled-.01 Mfd-2000 Volts (Use 200227)	Model DB39 - SA39 Radio,1940 Radio
BO	158497 Tube-Fuse Insulator	1939 thru 1941 Radio
BO	158498 Socket-Tube	Model DB39 - SA39 Radio
BO	158505 Vibrator	Model DB39 - SA39 Radio
BO	158511 Coil-Oscillator	Model DB39 - SA39 Radio
BO	158512 Coil-Antenna	Model DB39 - SA39 Radio
BO	158513 Coil-RF	Model DB39 - SA39 Radio
BO	158514 Transformer-First IF	Model DB39 - SA39 Radio
BO	158521 Cord-Dial Drive-4 Ft Length	Model DB39-SA39 Radio,1940 Radio,1941 Custom-DeLuxe
BO	158525 Shaft-Push Button Tuning-Threaded End	Model SA39 - DB39 Radio
BO	158528 Diffusion Plate-Dial Scale-Celluloid	Model SA39 - DB39 Radio
BO	158530 Volume Cont-Includes Switch & Flex Shaft	Model SA39 Radio
BO	158531 Volume Cont-Includes Switch & Flex Shaft	Model SA39 Radio
	158537 Dial Lamp-6 Volts (Use 171113)	Model SA39-DB39 Radio
BO	158570 Wing Nuts-Receiver to Bracket Mounting	Model SA39-DB39 Radio
BO	158572 Snap On Button-Dial Scale	Model DB39-SA39 Radio
	158573 Front End Assy-Propeller Shaft-Without OD (Use 165790)	90,40-10-20 With Std Engine
F	158574 Yoke Assy-Propeller Shaft Sleeve-Without OD	90,40-10-20 With Std Engine,51,52,53,54,171 thru 174, 58-178 With OD
F	158576 Dust Cap-Propeller Shaft Sleeve Yoke-Without OD	90,40-10-20 With Std Engine,51,52,53,54,171 thru 174, 58-178 With 00,1948-1949-1950 All
F	158579 Bearing Assy-Propeller Shaft Journal	1939 thru 1942 All
BT	158586 Shifter Assy-Trans Low and Reverse-RHD	1939-1940 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 158588	Support Assy-Front Shock Absorber-RH	90,98
BZ 158589	Support Assy-Front Shock Absorber-LH	92,93,95,97
BZ 158592	Ball Seat-Drag Link-Rear	90,98
C 158601	Autopoise Kit-Front	89
C 158602	Autopoise Kit-Front	70 thru 78,80 thru 88
158622	Engine Assy (Use 164815)	90,98 5Sed
158624	Engine Assy (Use 164815)	92
158626	Engine Assy (Use 164815)	93
158627	Engine Assy (Use 164820)	95,97
158632	Use 157081	
158633	Use 157082	
158634	Use 157083	
EM 158635	Tubing-Windshield Cleaner.-Rubber	1939 thru 1950 With Comb Pump
EM 158636	Connection-Windshield Cleaner Tubing-Copper	1939 thru 1950 With Comb Pump
C 158637	Autopoise Kit	36 All
C 158638	Bracket-Autopoise Bar Mounting-RH	36 All
C 158639	Bracket-Autopoise Bar Mounting-LH	36 All
C 158640	Steering Gear Assy	90,98
BZ 158641	Housing-Steering Gear	90,98
BZ 158649	Shock Absorber Assy-Rear-Heavy Control	91,92
158655	Brake Shoe Assy (Use 163504)	90 Pass
158664	Pump Assy-Comb Fuel & Vacuum (Use 166218)	39 thru 1942 6 Cyl
158665	Pump Assy-Comb Fuel & Vacuum (Use 166219)	39 thru 1942 8 Cyl
EM 158666	Spacer-Combination Pump to Cyl-Asbestos	1939 thru 1947 All
EM 158667	Plate-Combination Pump to Cyl Spacer	1939 thru 1947 All
EM 158668	Flexible Connection-Fuel Pump	1939 thru 1947 All
158671	Use 160181	
EM 158677	Pipe Assy-Combination Pump to Manifold	90,92,92X,98,40,48,41X,10-20 With Std Eng,18,28
EM 158679	Pipe Assy-Combination Pump to Manifold	92,93,41,43,10-20 With L Eng,11,12,21,22,1946-1947 6 Cyl
EM 158681	Pipe Assy-Combination Pump to Manifold	39 thru 1942 All,1946-1947 8 Cyl
BZ 158690	Grip & Ratchet Rod Assy-Hand Brake-RHD	90,91,98,40,41,44,45,48,10,11,18,20,21,28,51,53,58, 171,173,178
BZ 158691	Grip & Ratchet Rod Assy-Hand Brake-RHD	92,93,95,97,43,45,47,12,14,15,17,22,24,25,27,52,54, 172,174
BZ 158692	Stabilizer-Hand Brake Ratchet Rod Outer-RIID	1939 thru 1947 All
BZ 158693	Spring-Ratchet Rod-Outer-Stabilizer-RHD	1939 thru 1949 All
BZ 158733	Piston-Shock Absorber	93,95,97,43,44,45,47,14-22-24 exc Cpe,17,21 Station,27,1946-1947 All
BZ 158734	Nut-Shock Absorber Piston	93,95,97
BZ 158737	Washer-Shock Absorber Piston Valve	93,95,97,43,44,45,47,14 exc Cpe,17,22-24 exc Cpe, 27,21 Station,1946-1947 All
BZ 158738	Washer-Shock Abs Piston Valve Plate Spring-Frt	93,95,97,43,44,45,47,14 exc Cpe,17,22-24 exc Cpe, 27,21 Station,1946-1947 All
BZ 158739	Washer-Shock Abs Piston Orifice Plate	93,95,97,43,44,45,47,14 exc Cpe,17,22-24 exc Cpe, 27,21 Station,1946-1947 All
158742	Disc-Rear Shock Abs Piston Valve-Heavy Control (Use 160903)	93,95,97
BZ 158743	Relief Valve & Cyl End Assy-Frt Shock Abs	93,95,97
BZ 158748	Spring-Shock Absorber Intake Valve	93,95,97,14-22-24 exc Cpe,17,27,21 Station, 1946- 1947 All
BZ 158754	Screw-Shock Absorber Base Oil Filler	90,92,98
C 158770	Leaf-Spring Main-For Springs 157001-2	90 Cab-CabPu-Panel-Station
158801	Trans Cover Assy-Handy Shift-RHD (Use 160873)	39 All,1940 Without OD
158802	Trans Cover & Pin Assy-Handy Shift-LHD (Use 1-160874 & 2-158811)	39 All,1940 Without OD
158803	Trans Cover Assy (Use 160873)	
BT 158806	Shift Finger & Shaft Assy-Handy Shift Trans Cover-LHD	1939-1940 All
BT 158807	Shift Finger & Shaft Assy-Handy Shift Trans Cover-RHD	1939-1940 All
BT 158808	Shift Finger Assy-Handy Shift Trans Cover	39 All
BT 158810	Pivot Pin-Handy Shift Trans Cvr Shift Finger	1939-1940 All
BT 158811	Pin-Handy Shift Trans Cvr Shift Selector Plate	1939-1940 All
BZ 158813	Pipe-Assy-VD-Vacuum	1939-1942-1946-1947 8 Cyl
158815	Brake Shoes Assy-RH (Use 163506)	92,93,96,90 Cab-CabPu-Panel-Station
158816	Brake Shoes Assy-LH (Use 163506)	92,93,98,90 Cab-CabPu-Panel-Station
158819	Use 2-163507	
158820	Use 163504	
158823	Use 2-163505	
158824	Use 163508	
158827	Use 2-163509	
C 158844	Leaf-Spring-#3	90 exc Cab-CabPu-Panel
C 158846	Leaf-Spring-Rebound	90 exc Cab-CabPu-Panel
CF 158847	Leaf-Spring-Main	92,93,95,98 Sed
C 158848	Leaf-Spring-Main	92,93,95,97,98 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	158850 Leaf-Spring-Main (Use 157160)	90 exc Cab-CabPu-Panel
C	158851 Leaf-Spring #2	90 exc Cab-CabPu-Panel
C	158858 Leaf-Spring #2	90 exc Cab-CabPuzPanel
BZ	158859 Rebound Clip-Spring	90 Pass,1940 thru 1942 All
BZ	158860 Rebound Clip-Spring	90 Pass
BZ	158861 Rebound Clip-Spring #2	90 Pass
BZ	158862 Rebound Clip-Spring #3	90 Pass
BZ	158863 Bracket-Rear Spring Brake Cable Clip	1939-1940 All,10-17-18 Sed,10 Cv,11-12-Cpe,11 Sta, 1942-1946-1947 All,1949-1950 exc CvBro
BO	158864 Filter-Weather Control	39 All
BO	158865 Elbow-Weather Control	39 All
C	158868 Main & Wrapper Leaf Assy-Front Spring	90 Pass
BO	158870 Switch-Automatic Temp Control Heater	39 All
BZ	158874 Rebound Clip & Rivet Assy-Rear Spring #1	89-90 Pass
BZ	158875 Rebound Clip & Rivet Assy-Rear Spring #4	89-90 Pass
BZ	158878 Cover & Grease Retainer Tube Assy-Steering Gear Worm Housing	39 All,40,41,44,45,48,10,11,12,18,20,21,22,28,1946- 1947 6 Cyl,500
BZ	158881 Rebound Clip-Spring-#3-Service	92,1940 Springs No 161165-6-7-8
	158883 Shaft Assy-Propeller (Use 157845)	91,92,93,95
	158884 Shaft & Rear Joint Assy-Propeller (Use 157845)	91,92,93,95
	158885 Shaft Assy-Propeller (Use 152750)	97-98
C	158886 Shaft & Rear Joint Assy-Propeller	97-98
BZ	158887 Rebound Clip Kit-Rear Spring	89-90 exc Cab-CabPu-Panel-Station
	158888 Guide & Seal Assy-Shock Absorber Piston Rod	93,95,97
BZ	158908 Pedal Lever-Clutch	90-98
BZ	158912 Pin-Clutch Pedal Lever-LHD	95,97,1940 thru 1950 All
BZ	158913 Spring-Clutch Pedal Lever Assisting-LHD	95,97,44,45,47,41 Without OD
BZ	158914 Bracket-Frame-For Clutch Spring	95,97,1940 thru 1942 All,1946-1947 exc VD-HDM
BO	158916 Spacer-Horn Mtg Bolt-Short	90-98
F	158917 Ring-Piston-Compression-Std Size	1939 thru 1947 All,1948 thru 1950 8 Cyl
F	158918 Ring-Piston-Compression-.010 o/s	1939 thru 1947 All,1948 thru 1950 8 Cyl
	158920 Front End Assy-Prop Shaft (Use 165790)	91 thru 95,40-10-20 Std Eng With OD,40-10-20 With L Eng,17-18-27-28 With OD,41,44,45,11,12,14,15,21, 22,24,25
	158922 Shock Abs (Use 159206)	
	158923 Shock Abs Assy-Rear (Use 166167)	93,95,97
BZ	158926 Orifice Plate-Shock Abs Piston Valve-4 Notch	93,95,97,40 thru 48,10-11-12-20T-20P-21 exc Cpe, 10 UCo-UCpc,18P,51,171
BX	158927 Link-Brake Cyl to Shoe	90 Comm,91 thru 97,40C,41 thru 48,1941-1942-1946- 1947 All
BZ	158928 Bushing Assy-Rear Spring Front Brkt-ofs	1934-1935-1936 All
BT	158929 Interlocking Kit-Low & Reverse Gear	90,98
BT	158930 Shaft & Lock Lever Assy-Clutch Shifter Yoke	90,98
	158931 Water Pump Assy (Use 166284)	44,45,14,24,53,173,1939 thru 1947 6 Cyl exc 43
	158932 Water Pump Assy (Use 166285)	95,97,43,47,15,17,25,27,54,174
	158933 Water Pump Assy (Use 158936)	93
	158934 Body,Shaft & Imp Assy-Water Pump (Use 166284)	90,92,98,1940 thru 1942 6 Cyl exc 43
	158935 Body,Shaft & Imp Assy-Water Pump (Use 166285)	1939 thru 1942 8 Cyl exc 44-14-24
F	158936 Body,Shaft & Imp Assy-Water Pump	93
F	158938 Impeller-Water Pump	1939 thru 1947 All
F	158939 Washer-Water Pump Seal Compression Spring	1939 thru 1947 All
BX	158940 Shim-Rear Axle Drive Pinion Bearing-Thin	1939-1940 All
BX	158941 Shim-Rear Axle Drive Pinion Bearing-Med	1939-1940 All
BX	158942 Shim-Rear Axle Drive Pinion Bearing-Thick	1939-1940 All
BX	158943 Retainer-Rear Axle Drive Pinion Bearing Shim	1939-1940 All
EM	158968 Pulley-Generator-Small Dia-Export	1939-1946-1947 All
EM	158969 Nut-Generator Pulley	1939 thru 1947 All
BZ	158970 Cover Assy-Rear Spring-RH-Front	89-90 exc Cab-CabPu-Panel-Station
BZ	158971 Cover Assy-Rear Spring-LH-Front	89-90 exc Cab-CabPu-Panel-Station
BZ	158973 Cover Assy-Rear Spring-LH-Rear	89,90 exc Cab-CabPu-Panel-Station
BZ	159049 Rebound Clip-Spring-#4	1941 All
	159051 Button-Horn-Painted (Use 155606)	97 7 Sed
F	159058 Element-Temperature Indicator	1939 thru 1950 All
BT	159059 Boot-Handy Shift Lever Wire	1939 thru 1950 All
BO	159060 Core Assy-Heater	1939 Heater,1940-1941 Custom Heater
BO	159064 Bumper-Heater Door-Rubber	1939 thru 1942 Heaters
BO	159066 Motor Assy-Heater	1939 thru 1941 DeLuxe Heaters
BO	159067 Motor Assy-Heater	1939 thru 1941 Custom Heaters
BO	159070 Grommet-Heater Motor Mounting	1939 thru 1950 Heaters
BO	159077 Bolt-Heater Mounting	1939 thru 1941 Custom & DeLuxe
BO	159078 Washer-Heater Mounting Bolt	1939 thru 1941 DeLuxe,1941-1942 Recir Heater
	159079 Hose-Heater	1939 thru 1949
BO	159080 Clamp-Heater Hose	1939 thru 1942 Custom-DeLuxe,1940 thru 1950 Weather Control

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
		39 thru 1947 Heater-Weather-Control
BO 159081	Nipple-Heater Pipe	
159082	Use 161451	
159086	Use 2-163504	
159087	Use 2-163506	
159088	Use 163508	
159097	Engine Assy (Use 164815)	92
159100	Shock Abs Assy-Front (Use 166478)	
159101	Shock Abs Assy-Rear (Use 166573)	
159102	Shock Abs Assy-Front (Use 166477)	
BO 159104	Relay Assy-Generator-6 Volt	90,91,98 exc Sod
159105	Relay Assy-Generator-12 Volt	90-92P-98 Without Radio exc Sed
159106	Use 301484	
BO 159107	Charge Regulator-Generator-12 Volt	90 thru 98
BZ 159108	Shock Absorber Assy-Front-Heavy Control	91,92
159109	Shock Absorber Assy-Rear-Heavy (Use 166575)	91 exc Panel,92
F 159110	Gauge Assy-Gas Tank	1939 thru 1947 All L-
C 159111	Wheel-Steering-18" Plastic	90,91,92,98
BO 159112	Button Assy-Horn-For 18" Wheel	90,91,92,98
BZ 159113	Escutcheon-Horn Button-For 18" Wheel	90,91,92,98
BO 159115	Power Unit-Companion Horn	90,91,92,98
BO 159116	Trumpet-Companion Horn	90,91,92,98
BZ 159130	Relief Valve Assy-Rear Shock Absorber	90 Pass-UCo-UCpe,98 Sed
BZ 159131	Relief Valve Assy-Front Shock Absorber	90,98
BO 159132	Rod-Starting Switch Extension-LHD	91 Panel
BZ 159133	Guide & Seal Assy-Shock Abs Piston Rod	90,91,92,98
BZ 159140	Cyl EA.& Valve Assy-F Shock Absorber	90,98
BZ 159141	Cyl End & Valve Assy-F Shock Absorber	91,92
BZ 159145	Washer-Shock Absorber Support	90,91,92,98,40,41,48,10,11,12,14,18,20,21, 22,24,25,28,51,171
BZ 159146	Gasket-Shock Absorber Reserve Chamber	90,91,92,98,40,41,48,10,11,12,14,18,20,21, 22,24,25,28,51,171
BZ 159147	Piston-Shock Absorber	90,91,92,98,40,41,48
BZ 159150	Tube-Shock Abs Pressure Chamber-Rear	90 Pass-UCo-ITCpe,91,92,98 Sed,40,41,48
159152	Repair Kit-Water Pump (Use 166286)	1939 thru 1942 exc 93
F 159153	Repair Kit-Water Pump	93
BO 159157	Spring Assy-Horn Mounting	90,91,92,98
BO 159158	Spring Assy-Horn Mounting	92,93,95,97
BZ 159159	Bushing-Rear Spring Front Pivot Bolt	1937-1938-1939 All
BO 159161	Horn Assy-Vibrator-6 Volt	90-91-98 Cab-CabPu-Panel-Sta,90 UCo-UCpe-TrCpe
C 159167	Steering Gear Assy	91 Panel
C 159171	Frame Assy	91 Panel
159178	Use 162776	
F 159180	Threaded Bushing Assy-Shackle-RH Thread (Pkg 10)	36 thru 1950 All
F 159181	Threaded Bushing Assy-Shackle-LH Thread (Pkg 10)	36 thru 1950 All
BO 159184	Snitch-Radio	1936 Model CB6 Radio
159202	Shock Abs Assy-Front-Monroe (Use 166133)	1934 Terr
*F 159203	Shock Absorber Assy-Rear-Monroe	1934 Terr
*F 159204	Shock Absorber Assy-Rear-Monroe	1935-1936 Terr
CF 159205	Shock Absorber Assy-Front-Monroe	1936-1936 Terr
CF 159206	Shock Absorber Assy-Front-Monroe	71,72,81,82,91-92 First Type
159207	Shock Abs Assy-Front-Monroe (Use 166478)	89,90-98 First Type
159208	Shock Abs Assy-Rear-Monroe (Use 166573)	71,72
159209	Shock Abs Assy (Use 166573)	
BM 159210	Resistor-Distributor	90,91,92X,98 exc Sed,40,41,48
BZ 159211	Ferrule End-Shock Absorber Shield	1934 All,40,41,48
*BZ 159214	Shock Absorber Assy-Rear-Heavy Control	1935-1936 All
*BZ 159215	Shock Absorber Assy-Front-Heavy Control	1935-1936 All
159216	Shock Abs Assy-Front-Heavy Control (Use 166477)	37 All,38-39 Hud
159217	Shock Abs Assy-Rear-Heavy Control (Use 166575)	37 Passenger,38-39 Hud
*F 159218	Shock Absorber Assy-Rear-Heavy Control	37 Cab-CabPu-Panel-Station
159219	Shock Abs Assy-Roar-Heavy Control (Use 301770)	38 thru 1947 Cab-CabPu-Panel,38-39 Sta
159502	Support Plate Assy-Cylinder-Front (Use 1-165905 & 2-170899)	1940 thru 1946 6 Cyl
BM 159503	Support Plate Assy-Cylinder-Front	1940 thru 1946 8 Cyl
BZ 159504	Rod Assy-Manifold Bell Crank to Carburetor	40,48,40-41 X Eng,10-20 With Std Eng,18,28
159505	Camshaft (Use 1 each 162999 & 166195)	40,41,43,48,11,12,17,10-20 With L Eng,21,22,28
159506	Use 160329	
159507	Shaft Assy-Prop-Without OD (Use 159508)	43,47,48,17,18,27,28
C 159508	Shaft-Propeller-Without OD	43,47,48,17,18,27,28,58,178
159509	Shaft & Rear JOint Assy-Prop-Without OD(Use 159508)	43,47,48,17,18,27,28
159510	Shaft Assy-Propeller (Use 159511)	40
C 159511	Shaft-Propeller	40
159512	Shaft & Rear Joint Assy-Propeller (Use 159511)	40

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	159513 Oil Pan Assy (Use 166196)	1940 thru 1942 8 Cyl
F	159519 Rebushing Kit-Steering Spindle Support	1940 thru 1950 All
C	159522 Housing-Clutch Assy-Use Without Overdrive	1940 All
C	159528 Manifold Assy-Exhaust	44,45,47
*F	159533 Gear Assy-Main Drive	40,41X
F	159536 Gear Assy-Mainshaft Intermediate	40,41X
F	159538 Gear-Countershaft Drive	40,41X
F	159539 Gear-Countershaft Intermediate	40,41X
BT	159540 Shifter Fork Assy-Low and Reverse	1940 All
	159543 Cylinder & Pistons Assy (Use 166263)	40,41,43,48
C	159544 Cylinder & Pistons Assy	1940 X Engine
EM	159551 Plate-Cylinder Support-Rear	40,41,43,48,1941-1942-1946-1947 All
F	159552 Gasket-Cylinder Support Plate-Rear	1940 thru 1947 6 Cyl
EM	159553 Shaft & Support Complete-Distributor Drive	1940 thru 1947 6 Cyl
EM	159554 Shaft Assy-Distributor Drive	1940 thru 1947 6 Cyl
EM	159555 Drive Shaft-Distributor	1940 thru 1947 6 Cyl
EM	159556 Sleeve-Distributor Drive Shaft	1940 thru 1947 6 Cyl
EM	159557 Washer-Distributor Drive Shaft	1940 thru 1947 6 Cyl
EM	159558 Support Assy-Distributor Drive Shaft	1940 thru 1947 6 Cyl
EM	159560 Bushing-Distributor Drive Shaft Support	1940 thru 1947 6 Cyl
EM	159561 Bolt-Distributor Drive Shaft Support Anchor	1940 thru 1947 6 Cyl
C	159562 Head Assy-Cylinder	1940-1941 X Engine
	159563 Use 162776	
	159564 Head Assy-Cylinder (Use 166268)	41,43,48,40-10-20 With L Eng,11,12,18,21,22,28
C	159565 Head Assy-Cylinder-Export	41,43,48,40-10-20 With L Eng,11,12,18,21,22,28
	159566 Head Assy-Cylinder (Use 166269)	1940 thru 1942 8 Cyl
	159607 Use 162339	
	159608 Drive Gear & Pinion-Matched Set 4-7/8 to 1 (Use 163924)	40,10,18C
BX	159609 Drive Gear-Rear Axle-4-7/8 to 1	40,10,18C
	159615 Core Assy-Radiator (Use 1 each 164098-166027)	40
	159616 Core Assy-Radiator (Use 1 each 164099-166027)	41,43,48
	159617 Core Assy-Radiator (Use 1 each 166235-166028)	44,45,47
C	159618 Housing Complete-Rear Axle-Less Brake Shoes	40T,40P
C	159619 Housing Complete-Rear Axle-Less Brake Shoes	40 With L Engine
C	159620 Housing Complete-Rear Axle-Less Brake Shoes	40C,41,48
C	159621 Housing Complete-Rear Axle-Less Brake Shoes	43,44,45,47
F	159631 Support Assy-Steering Spindle-RH	1940 thru 1942 All
F	159632 Support Assy-Steering Spindle-LH	1940 thru 1942 All
BZ	159635 Bracket-F Stabilizer Steering Spindle-RH	1940 thru 1947 exc Cab-CabPu-Panel
BZ	159636 Bracket-F Stabilizer Steering Spindle-LH	1940 thru 1947 exc Cab-CabPu7Panel
BX	159637 Spacer-Drive Pinion Bearing-With 4-7/8 Ratio	40
C	159640 Carrier & Cap Assy-Differential-4-7/8 Ratio	40
	159641 Spindle-Steering-RH (Use 166106)	1940 thru 1942 All
	159642 Spindle-Steering-LH (Use 166187)	1940 thru 1942 All
	159643 Arm-Steering-RH (Use 166260)	1940 thru 1942 All
	159644 Arm-Steering-LH (Use 166261)	1940 thru 1942 All
	159647 Pivot Pin-Steering Spindle (Use 164744)	1940 thru 1942 All
BT	159649 Coupling Lever-Clutch Shifter Yoke Shaft	1940 All
*EM	159653 Carburetor Assy-Single	40-10-20 With Std Eng,48,18,28
EM	159654 Carburetor Assy-Duplex-Second Type	41,43
EM	159655 Carburetor Assy-Duplex	44,45,47
F	159657 Gasket-Carburetor to Manifold	1940 thru 1947 8 Cyl,1948-1949 All,501 thru 504
F	159659 Hub Cap-Wheel-Outer	1940 All
	159661 Air Cleaner-Carburetor-Oil Bath (Use 161220)	1940 X Engine,40T,40P,48P,40 tko-UCpe
EM	159662 Air Cleaner-Carburetor-Oil Bath	41,43,44,45,47,14,15,17,24-25-27-53-54-173-174 Without HDM
EM	159663 Braces-Air Cleaner	1940 X Engine,40T,40P,48P,40 UCo-UCpe
	159664 Use 161049	
	159667 Arm-Steering-Center-LHD (Use 1-165601,2-170646, 1-164734,2-164735,2-155260)	1940 thru 1942 All
	159668 Arm-Steering-Center-RHD (Use 1-165679,1-164734, 2-170646,2-164735,2-155260)	1940 thru 1942 All
	159675 Torsion Bar Assy-F Stabilizer (Use 166222)	1940 thru 1942 exc Cab-CabPu-Panel
BZ	159679 Connector-Front Stabilizer	1940 thru 1947 exc Cab-CabPu-Panel
BZ	159680 Lever Assy-Clutch Pedal-LHD	1940
BZ	159682 Assisting Spring-Clutch Pedal-LHD	40-10 With Std Engine,43,48,41-10-11-12-18 With OD
C	159683 Spring Assy-Rear-Light Scale	40 3Cpc-VicCpe-CvCpe
	159684 Spring Assy-Rear-Light Scale (Use 166742)	40 2Sed-CvSed,40 UCpe
	159685 Use 166144	
	159686 Spring Assy-Rear-Light Scale (Use 163663)	43-45-47-48 Sed
	159687 Spring Assy-Rear-Light Scale (Use 163663)	41-44 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 159688	Spring Assy-Rear-Heavy Scale	40 Sed-UCo,41-44-45 2Sed
C 159689	Spring Assy-Rear-Heavy Scale	40-41 CvCpe-3Cpe-VicCpe
C 159690	Spring Assy-Rear-Heavy Scale	40 2Sed-UCpe,44 VicCpe-3Cpe-CvCpe 1940 CvSed
C 159691	Spring Assy-Rear-Heavy Scale	43-47-48 Sed
C 159692	Spring Assy-Rear-Heavy Scale	40-41-18 CabPu-Station,28 CabPu
C 159693	Spring Assy-Rear-Heavy Scale	40-41-48 Cab-Panel,18-28 Cab,58-178 Cab-CabPu
	159694	Use 161250
BT 159695	Rod Assy-Handy Shift Lever Tube to Trans Cover-RHD	1940 All
BM 159696	Bracket-Generator Support	41,43,45,47,11 thru 18 with L Engine 10 CvSed,1942 Gener #164248,1946-1947 All,483,484,493,494,503,504
	159698	Hose-Radiator Inlet (Use 166229)
	159699	Hose-Radiator Outlet (Use 166231)
C 159704	Lever, Tube & Rod Assy-Handy Shift-LHD	1940 All
	159706	Lever-Handy Shift (Use 166287)
	159707	Tube & Fulcrum Brkt Assy-Handy Shift Lever-LHD (Use 164435)
C 159708	Tube & Fulcrum Brkt Assy-Handy Shift Lever-RHD	1940 All
C 159711	Arm Assy-Steering Spindle Support-RH	1940 thru 1947 All
C 159712	Arm Assy-Steering Spindle Support-LH	1940 thru 1947 All
F 159716	Bumper-Steering Spindle Support Arm Brace-Lower	1940 thru 1950 All
F 159718	Pivot-Spindle Support and Arm-Lower	1940 thru 1947 All
	159719	Seal-Lower Supp Arm Pivot (Use 164726)
F 159720	Bushing Assy-Spindle Support Arm Pivot-Lower	1940 thru 1950 All
	159724	Bolt-Spindle Support Arm (Use 166480)
F 159725	Bushing-Spindle Support Arm to Support Belt-Lower	1940 thru 1950 All
	159726	Nut-Spindle Support Arm to Support Bolt-Lower (Use 166481)
F 159727	Seal-Spindle Support Arm to Support Bolt-Lower	1940 thru 1950 All
BX 159728	Arm & Pivot Assy-Steering Spindle Support-Upper RH	1940 thru 1942 All
BX 159729	Arm & Pivot Assy-Steering Spindle Support-Upper LH	1940 thru 1942 All
F 159738	Bushing Assy-Support Arm Pivot-Upper Front	1940 thru 1942 All
F 159739	Bushing Assy-Support Arm Pivot-Upper	1940 thru 1950 All
F 159740	Eccentric Bushing Assy-Spindle Supp Arm-Upper	1940 thru 1942 All
	159743	Seal-Spindle Supp Arm Ecc Bush (Use 165972)
BM 159748	Retainer-Exhaust Damper	40-10-20 Std Eng,48-18-28
	159757	Front Suspension Complete-RH (Use 164708)
	159758	Front Suspension Complete-LH (Use 164709)
BZ 159763	Bracket-Frame Running Board-Front	1940-1941 All,20C,28C,58,178
BZ 159764	Bracket-Frame Running Board-Rear & Center	1940-1941 All,20C,28C,21 Station,58,178
C 159765	Wheel-Steering-17 "	40,41,44,48,43-47 7Sed,10 Del
C 159766	Button Assy-Horn	40,41,44,48,43-47 7Sed,10 Del
BZ 159769	Plate-Radiator Mounting Bolt	41,43,48,11,12,18,21,22,28,51,52,58,171,172,178
C 159770	Wheel-Steering- 18"	43 5Sed,45,47 5Sed
BZ 159771	Button Assy-Horn	43 5Sed,45,47 5Sed
	159773	Escutcheon-Horn Button (Use 159771)
BZ 159774	Anchor Plate Assy-F Shock Absorber	1940 thru 1950 All
BZ 159776	Screw-Horn Button Attaching	43 5Sed,45,47 5Sed
BZ 159777	Spring-Horn Button Attaching Screw	43 5Sed,45,47 5Sed
BZ 159778	Retainer-Horn Button Contact Cup	43 5Sed,45,47 5Sed
	159779	Knob-Handy Shift & Hood Lock (Use 203990)
C 159780	Tie Rod Assy	40 thru 48,10C,10T,18,20C,28C 1940 thru 1942 All,1947 All
C 159781	Tie Rod	1940 thru 1947 All
F 159782	Ends Complete-Tie Rod	1940 thru 1947 All
F 159783	End Assy-Tie Rod-RH	1940 thru 1947 All
F 159784	End Assy-Tie Rod-LB	1940 thru 1947 All
BX 159788	Dust Seal-Tie Rod End-Rubber	1940 thru 1947 All
BX 159789	Dust Cover-Tie Rod End-Steel	1940 thru 1947 All
BX 159790	Seat-Tie Rod End Dust Cover	1940 thru 1946 All
	159791	Lever Assy-Brake Pedal-LHD (Use 1 each 162294- 162385)
BZ 159792	Lever Assy-Brake Pedal-RHD	1940 All
C 159798	Manifold Assy-Intake-For Single Carb	40,48,10,18
C 159799	Manifold Assy-Intake-For Duplex Carb	41,43,11,12
C 159800	Frame Assy	40T-40P exc Cv,40 UCo-UCpe
C 159801	Frame Assy	40 CvCpe-CvSed
C 159803	Frame Assy	41 exc Cv
C 159804	Frame Assy	41 CvCpe-CvSed
C 159805	Frame Assy	44-45 exc Cv
C 159806	Frame Assy	44 CvCpe-CvSed
C 159808	Frame Assy	43,48P
C 159809	Frame Assy	47
C 159810	Frame Assy	48C
C 159845	Crossmember Assy-Frame Front	1940 thru 1947 All
BZ 159846	Bracket-F Crossmember Steering Arm	1940 thru 1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 159847	Bumper-Frame	1940 thru 1947
BZ 159848	Bumper Bracket-Frame	All 1940 thru 1942 All
C 159850	Reinforcement Assy-Frame Side Member-Front-LH	40 exc Cv
BZ 159869	Bracket Base-Autopose Bar Bushing	1940 thru 1942 exc Cab-CabPu-Panel-Station,1946-1947 exc Cab-CabPu
BZ 159870	Reinforcement-Frame Steering Gear-Front	40,10,20
BZ 159871	Reinforcement-Frame Steering Gear-Rear	40,10,20
BZ 159872	Reinforcement-Frame Steering Gear-Front	1940 thru 1947 exc 40-10-20
BZ 159873	Reinforcement-Frame Steering Gear-LH-Rear	1940 thru 1947 exc 40-10-20
BM 159874	Bolt-Battery Hold Down	1940 thru 1947 All
159875	Crossmember Assy-Frame Eng Support-Rear (Use 162248)	1940 All
BZ 159877	Plate-Frame Brace	1940 exc Cv
BZ 159878	Plate-Frame Brace	1940 CvCpe-CvSed
BZ 159906	Bracket-Frartie Brake Tube	1940 thru 1947 All
159907	Bracket-Frame Rear Spring Front-RH (Use 162273)	1940 All
BZ 159909	Bracket-Frame Body Bolt-#1	1940 thru 1947 All
BZ 159910	Radiator Support-F Crossmember	40,44,45,47,10,14,15,17,20,24,25,27,53,54,173,174
C 159919	Support Member-Frame Front Fender	1940 thru 1942 exc Del,1946-1947 All
BM 159920	Heat Deflector-Carburetor	41,43,44,45,47,40-10-20 With L Eng,11 thru 17,21 thru 27,1946-1947-1948 All
BM 159921	Heat Deflector-Carburetor	40-10-20 Std Eng,48,18,28
BM 159922	Stud-Carburetor to Manifold-Plain	41,43,44,45,47
BM 159923	Stud-Carburetor to Manifold-Drilled	40-10-20 L Eng,41 thru 47,11 thru 17,21 thru 27,1946-1947-1948 All
BM 159924	Stud-Carburetor to Manifold-Drilled	40-10-20 Std Eng,48,18,28
*BM 159927	Generator Complete	41,43,44,45,47,10 With L Engine,11 thru 17,10 CvSed
159928	Charge Regulator-Generator-(VRR-4001-A) (Use 301484)	1940 thru 1947 All
BM 159929	Charge Regulator-Generator-12 Volt	1940-1941-1946-1947-1948 All
*BM 159930	Coil Assy-Ignition-6 Volt-LHD	40,41,43,48,10 Del
*BM 159931	Coil Assy-Ignition-6 Volt-LHD	44,45,47
*BM 159933	Starting Motor Assy-Without Solenoid	40,41,43,48
*BM 159934	Starting Motor Assy-Without Solenoid	44,45,47
EM 159935	Solenoid Assy-Starting Motor-6 Volt	1940 All
CF 159937 Pr	Wheel Assy-16 x 3.50	40T,40 UCo-UCpe,10T,10 UCo-UCpe,20T exc UCo-UCpe
159938	Use 162831	
159939	Wheel Assy-16 x 4.50 (Use 166488)	40C,41,44,45,48,10C,18,20C,28,20 UCo-UCpe,58
159940	Wheel Assy-16 x 4.50 (Use 162831)	43
159941	Wheel Assy-16 x 5.00 (Use 162833)	45,47,15,17
159942	Wheel Assy-15 x 5.00 (Use 302427)	41 thru 48,11 thru 18,21 thru 27
159943	Pin-Rear Spring Front Mounting (Use 166319)	1940 thru 1942 All
F 159944	Rubber Bushing-Rear Spring Front Mounting	1940 thru 1950 All
BZ 159945	Plate-Rear Spring Clip-RH	1940-1941 All
BZ 159946	Plate-Rear Spring Clip-LH	1940-1941 All
C 159948	Stay Rod-Radiator	40,41,43,48
C 159949	Stay Rod-Radiator	44,45,47
BZ 159952	Push Rod-Brake Pedal	1940 All
BZ 159953	Adj End & Yoke Assy-Brake Pedal Push Rod	1940 All
BZ 159954	Adjustable End-Brake Pedal Push Rod	1940 All
BZ 159955	Pivot Pin & Brkt Assy-Brake Control Lever-LHD	1940 thru 1947 All
BZ 159956	Pivot Pin & Brkt Assy-Brake Control Lever-RHD	1940 thru 1947 All
BZ 159957	Lever Assy-Brake Control-LHD	1940 thru 1947 All
BZ 159958	Lever Assy-Brake Control-RHD	1940 thru 1947 All
BZ 159961	Bracket-Brake Control Lever Pivot Pin	1940 thru 1947 All
BZ 159962	Pivot Pin-Brake Control Lever	1940 thru 1950 All
BZ 159963	Play Link Assy-Brake Control	1940 thru 1947 All
BZ 159965	Lever-Hand Brake Cable	1940 thru 1947 All
BZ 159966	Toggle Assy-Hand Brake Cable Lever	1940 thru 1950 All
BZ 159968	Support Assy-Hand Brake Cable Lever	1940 thru 1942 All exc CvCpe-CvSed-Station,1946-1947 exc CvBro
BZ 159971	Guide Plate-Hand Brake Cable Lever	1940 thru 1942 All exc CvCpe-CvSed-Station,1946-1947 exc CvBro
BZ 159973	Engine Supp Assy-Frame S/M Reinf-Front	40,10
BZ 159974	Engine Supp Assy-Frame S/M Reinf-Front	41,43,48,11,12,18,21,22,28,51,52,58,171,172,178
159975	Hold Down Assy-Battery (Use 300469)	1940 thru 1947 6 Cyl
BZ 159977	Hold Down Assy-Battery	1940 thru 1947 8 Cyl
159980	Drag Link Assy-LHD (Use 159981)	40,10 exc Del,20
C 159981	Drag Link and Plugs Assy-LHD	40,10,20
159983	Drag Link Assy-LHD (Use 159984)	1940 thru 1947 exc 40-10-20
C 159984	Drag Link and Plugs Assy-LHD	1940 thru 1947 exc 40-10-20
159986	Drag Link Assy-RHD (Use 159987)	40,10,20
C 159987	Drag Link and Plugs Assy-RHD	40,10,20
159989	Drag Link Assy-RHD (Use 159990)	1940 thru 1947 exc 40-10-20
C 159990	Drag Link and Plugs Assy-RHD	1940 thru 1947 exc 40-10-20

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 159992	Cover Assy-Rear Spring-RH-Front	40 thru 48 exc Cab-CabPu-Panel-Station,11-14 Station,21 thru 27,1946-1947 exc Cab-CabPu
BZ 159993	Cover Assy-Rear Spring-LH-Front	40 thru 48 exc Cab-CabPu-Panel-Station,11-14 Station,21 thru 27,1946-1947 exc Cab-CabPu
BZ 159994	Cover Assy-Rear Spring-RH-Rear	40 thru 48 exc Cab-CabPu-Panel-Station,11-14 Station,21 thru 27,1946-1947 exc Cab-CabPu
BZ 159995	Cover Assy-Rear Spring-LH-Rear	40 thru 48 exc Cab-CabPu-Panel-Station,11-14 Station,21 thru 27,1946-1947 exc Cab-CabPu
160003	Use 166204	
160004	Muffler Assy (Use 166289)	1940 thru 1942 8 Cyl
BZ 160005	Clamp-Muffler Front and Exhaust Pipe	1940 thru 1947 All
BZ 160007	Bracket Assy-Muffler Clamp Support-Front	40,41,43,48,10 Cab-CabPu-Del,18,20C,28,58,178
160008	Use 160007	
160011	Pipe Assy-Exhaust (Use 161590)	40
CF 160013	Pipe Assy-Exhaust	41,43,48
CF 160015	Pipe Assy-Exhaust	44,45,47
CF 160021	Tail Pipe	40T,40P,41,40 UCo-L/Cpe
CF 160022	Tail Pipe	43,48P,18P
CF 160023	Tail Pik	44,45
CF 160024	Tail Pipe	47
BZ 160025	Clamp-Tail Pipe Front	40,41,10 Cab-CabPu-Del,20C
BZ 160026	Clamp-Tail Pipe Front	44,45
BZ 160027	Support Assy-Tail Pipe Clamp-Front	40,41,43,48,10 Cab-CabPu-Del
BZ 160029	Fabric-Tail Pipe Clamp Support-Front	40,41,44,45,10 Cab-CabPu-Del
C 160031	Heat Deflector Assy-Muffler	44,45,47
BZ 160034	Dust Cover-Drag Link-Inner	1940 thru 1950 All
BZ 160035	Dust Cover-Drag Link-Outer	1940 thru 1950 All
C 160036	Jacket Tube & Bushing Assy-Steering Gear-Pr	40,41,44,45,48
BZ 160040	Clip-Rear Spring	1940 All,11-12-14 exc Sed,10T,10P,15, 1942-1946 exc Comm,1948-1949-1950
BZ 160041	Clip-Rear Spring	40-48-10-18 Cab-CabPu-Panel-Sta,20 Cab, 28C,51,58,171,178 Cab-CabPu
BZ 160042	Silencer-Front Spring	1940 thru 1950 All
BZ 160043	Shim-Front Spring	1940 thru 1946 All
BO 160044	Knob Assy-Starter,Lighting and VD Switch	1940 All
BZ 160046	Bracket-Autopoise Bar Bushing	1940 thru 1947 exc Cab-CabPu-Panel
160055	Steering Gear Assy-LHD (Use 164550)	40,41,44,45,48,11,12,18,10 exc Del
160056	Steering Gear Assy-RHD (Use 164551)	40,41,44,45,48,11,12,18
160057	Use 162751	
C 160058	Steering Gear Assy-RHD	43,45,47,14,15,17,24,25,27
160059	Ball Arm-Steering Gear-LHD (Use 166318)	40,41,44,45,48,11,12,18,10 exc Del,20,21,22,28
BZ 160060	Ball Arm-Steering Gear-RHD	40,41,44,45,48,11,12,18,20,21,22,28,1946-1947 6 Cyl
BZ 160061	Ball Arm-Steering Gear-LHD	43,45,47,14,15,17,24,25,27,1946-1947 8 Cyl
BZ 160062	Ball Arm-Steering Gear-RHD	43,45,47,14,15,17,24,25,27,1946-1947 8 Cyl
BZ 160063	Bolt-Steering Gear to Frame	1940 thru 1946 All.
BM 160064	Cover-Exhaust Pipe-Front	40
BM 160065	Cover-Exhaust Pipe-Rear	40
BM 160066	Cover-Exhaust Pipe-Front	41,43,48
BM 160067	Cover-Exhaust Pipe-Rear	41,43,48
BM 160068	Cover-Exhaust Pipe-Front	44,45,47
BM 160069	Cover-Exhaust Pipe-Rear	44,45,47
A 160070	Guard-Engine-RH	40
A 160072	Guard Assy-Engine-LH-RHD	40,10,20
A 160073	Guard-Engine-LH	40,10,20
A 160074	Guard-Engine-RH	41 thru 48
A 160076	Guard Assy-Engine-LH-RHD	41 thru 48,11 thru 18,21 thru 28,1946-1947 All
A 160077	Guard-Engine-LH	41 thru 48,11 thru 18,21 thru 28,1946-1947 All
BZ 160078	Cover-Engine Guard Opening-LH-RHD	1940 thru 1947 All exc 20
160079	Shaft Assy-Propeller (Use 160080)	41,44,45
C 160080	Shaft-Propeller	41,44,45
C 160081	Shaft and Rear Joints Assy-Propeller	41,44,45
C 160082	Manifold Assy-Intake	44,45,47,14,15,17
BZ 160084	Lock Spring-Hand Brake Ratchet Rod	1940 thru 1947 All
BO 160086	Switch Assy-Starter	1940 All
F 160087	Switch Assy-Lighting	1940 All,10 Del
BO 160088	Fuse Block Assy	1940 All
BO 160089	Switch-Dimmer	1940 All
F 160090	Switch Assy-Stop Lamp	1940 thru 1947 All
BO 160091	Switch Assy-Dome Lamp	1940-1941 exc Cab-CabPu-Del,20,1946-1947 exc Cab-CabPu,482-484-492-494-502-504 Sed,ClubCpe
BO 160092	Rheostat-Instrument Light	43,45,47,12 thru 17,22 thru 27,52,54,172,174,482, 484,492,494,502,504
CF 160095	Tail Pipe	40 Cab-CabPu-Panel-Station
CF 160096	Tail Pipe	48 C

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*BM 160097	Coil Assy-Ignition-Includes Brkts-6 Volt-RHD	40,41,43,48
*BM 160098	Coil Assy-Ignition-Includes Brkts-6 Volt-RHD	44,45,47
160101	Shock Absorber (Use 166574)	
160102	Shock Absorber Assy-Front-Heavy Control (Use 166574)	40,41,48
160105	Shock Absorber Assy-Front-Light Control (Use 165873)	43,44,45,47,12 exc Cpe,22,24-25 Cpe
160106	Shock Abs Assy-Front-Heavy (Use 165874)	43,44,45,47,1941-1942 All
160107	Shock Abs Assy-Rear-Light (Use 166575)	40T,40P,41,48P,40-10 UCo-UCpe,10T-10P-11-12 exc Cpe,18P
160108	Shock Abs Assy-Rear-Heavy (Use 166575)	40T,40P,41,48P,40 UCo-UCpe
160109	Shock Abs Assy-Rear-Light Control (Use 165870)	43,44,45,47,12-24-25 exc 3Cpe-ClubCpe,22
160110	Shock Abs Assy-Rear-Heavy (Use 165871)	43,44,45,47,1941-1942
BZ 160113	Stud-Rear Shock Absorber-Lower	1940 thru 1950 All
BM 160115	Holder Assy-Ignition Cable-Rear	44,45,47
BM 160117	Cable Holder Assy-Ignition	1940 thru 1947 All
160119	Cover-Pedal Pad-Taupe (Use 165819)	1940 All
160121	Pedal Complete-Accel-LHD (Use 165816 & 166623)	1940 All
BZ 160122	Pedal Complete-Accel-RHD	1940 All
160124	Bushing-Autopoise Bar (Use 165486)	1940 thru 1947 exc Cab-CabPu-Del
160125	Tube Assy-Brake Master,Cyl to Frame Tee-LHD (Use 165014)	40,10
160126	Tube Assy-Brake Master Cyl to Frame Tee-LHD (Use 165014)	41 thru 48,11 thru 18,21 thru 28
BZ 160127	Tube Assy-Brake Tee to R Front Hose	40,10,20
BZ 160128	Tube Assy-Brake Tee to R Front Hose	1940 thru 1947 exc 40-10-20
BZ 160129	Tube Assy-Brake Tee to L Front Hose	40,10,20
BZ 160130	Tube Assy-Brake Tee to L Front Hose	1940 thru 1947 exc 40-10-20
BZ 160131	Tube Assy-Frame Tee to Rear Axle Hose	40
BZ 160132	Tube Assy-Frame Tee to Rear Axle Hose	41,44,45
BZ 160133	Tube Assy-Frame Tee to Rear Axle Hose	43,47,48
BM 160135	Connector-Starter Solenoid-6 Volt	1940 All
CF 160138	Cable & Conduit Assy-Hand Brake	1940 All
BZ 160146	Clip-Brake Tube	1940 thru 1947 All
CF 160147	Cable Assy-Rear Brake-RH	40T,40P
CF 160148	Cable Assy-Rear Brake-LH	40T,40P
CF 160151	Cable Assy-Rear Brake	40C,41,44,45,10C
CF 160152	Cable Assy-Rear Brake	43,47,48
160153	Hose Assy-Brake-Front (Use 166740)	1940 thru 1947 All
BT 160159	Gear-Trans Speedometer-4-7/8 to 1	40 thru 48 with VD,without OD
BT 160160	Pinion-Trans Speedometer-4-7/8 to 1	40 thru 48 with VD,without OD
160161	Spring Assy-Rear-Light (Use 164026)	41-44 2Sed-CvSed,44 CvCpe-VicCpe-3Cpe,40 Sed
160162	Spring Assy-Rear-Heavy (Use 163663)	41-44-45 Sed
BZ 160163	Rod-Ace Cross Shaft to Pull Lever-LHD	1940 All
BZ 160164	Pull Lever-Throttle Control-LHD	1940 All
BZ 160165	Clip-Throttle Control Return Spring	41 thru 47,10 thru 18
C 160166	Bar Assy-Rear Stabilizer	40P,41 thru 47,48P,10P,11 thru 17,18P,20P,21 thru 27
BZ 160169	Cushion-Rear Stabilizer Bar-Rubber	40P,41 thru 47,48P,10P,11 thru 17,18P,20P,21 thru 27, 946-1947 All exc Cab-CabPu
BZ 160170	Washer-Rear Stabilizer Bar Cushion	40P,41 thru 47,48P,10P,11 thru 17,18P,20P,21 thru 27, 1946-1947 All exc Cab-CabPu
BZ 160171	Spacer-Rear Stabilizer Bar Cushion	40P,41 thru 47,48P,10P,11 thru 17,18P,20P,21 thru 27, 1946-1947 All exc Cab-CabPu
BX 160172	Thrust Washer-Differential Pinion	32-33 Terr,34 thru 1950 All
BM 160173	Pipe Assy-Fuel Pump to Carburetor-Std Pump	40-41 X Engine
BM 160177	Pipe Assy-Fuel Pump to Carburetor-Std Pump	40,48 Sed,10-20 With Std Engine,18P
BM 160179	Pipe Assy-Fuel Pump to Carburetor-Std Pump	41,43,48C,10-20 With L Eng,11,12,18C,21,22,28C, 1946-1947 6 Cyl
BM 160181	Pipe Assy-Fuel Pump to Carburetor-Comb Pump	40-41 X Engine,41,48,10-20 With Std Engine,18,28
BM 160183	Pipe Assy-Fuel Pump to Carburetor-Comb Pump.	41,43,10-20 With L Engine,11,12,21,22,23,1946-1947 6 Cyl
160185	Pump Assy-Oil (Use 301941)	1940 thru 1942 8 Cyl
160186	Pipe Assy-Oil Pump to Check Valve (Use 166045)	1940 thru 1942 8 Cyl
BO 160188	Connector-Fuse-Horn	1940 All
BO 160190	Terminal-Fuse Connector-Horn or Heater	1940 All
BO 160191	Insulator-Fuse Connector-Terminal-Horn or Heater	1940-1941 All
BO 160192	Spring-Fuse Connector Terminal-Horn or Heater	1940-1941 All
BZ 160194	Bracket-Frame Rear Stabilizer	1940 thru 1942 exc Cab-CabPu-Panel-Station
BZ 160195	Reinforcement-Frame Rear Stabilizer Bracket	1940 thru 1942 exc Cab-CabPu-Panel-Station
BZ 160196	Dirt Seal-Rear Spring Shackle	1940 thru 1950 All
BM 160197	Metering Rod-Carburetor-Pkg	40,48,10-20 With Std Eng,18,10 Del,28
BM 160198	Metering Rod-Carburetor-Pkg	41,43
BM 160199	Metering Rod-Carburetor-Pkg	44,45,47
BM 160202	Metering Rod-Carburetor-Std	40,48,10-20 With Std Engine,18,10 Del,28
BM 160203	Metering Rod-Carburetor-1st Leaner	40,48,10-20 With Std Engine,18,10 Del,28
BM 160204	Metering Rod-Carburetor-2nd Leaner	40,48,10-20 With Std Engine,18,10 Del,28

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
EM 160205	Metering Rod-Carburetor-3rd Leaner	40,48,10-20 With Std Engine,18,10 Del,28
EM 160206	Metering Rod-Carburetor-Std	41,43
EM 160207	Metering Rod-Carburetor-1st Leaner	41,43
EM 160208	Metering Rod-Carburetor-2nd Leaner	41,43
EM 160209	Metering Rod-Carburetor-3rd Leaner	41,43
EM 160210	Metering Rod-Carburetor-Std	44,45,47
EM 160211	Metering Rod-Carburetor-1st Leaner	44,45,47
EM 160212	Metering Rod-Carburetor-2nd Leaner	44,45,47
EM 160213	Metering Rod-Carburetor-3rd Leaner	44,45,47
BZ 160214	Pipe Assy-Gas Tank to Fuel Pump	40,41
BZ 160215	Pipe Assy-Gas Tank to Fuel Pump-RHD	44,45
BZ 160216	Pipe Assy-Gas Tank to Fuel Pump-LHD	44,45
BZ 160217	Pipe Assy-Gas Tank to Fuel Pump-RHD	47
BZ 160218	Pipe Assy-Gas Tank to Fuel Pump-LHD	47
160220	Flywheel Complete-Without OD (Use 166198)	40,41,10-11,20-21 Without VD or HDM
C 160221	Flywheel Complete-Used With Overdrive	40,41,10,11
C 160221	Flywheel Complete	43,48
C 160222	Flywheel Complete	44,45,47,14,15,17
160229	Gear-Flywheel (Use 166277)	1940 thru 1942 All
160230	Use 162548	
F 160234	Filler Cap Assy-Hyd Brake Master Cyl	1940 thru 1947 All
F 160237	Gasket-Master Cyl Filler Cap	1940 thru 1947 All
BO 160239	Seat-Brake Master Cyl Check Valve	1940-1941
BZ 160245	Rod-Hill Hold (Spring End)	1940 thru 1947 All
BZ 160246	Spring-Hill Hold Rod	1940 thru 1947 All
BZ 160247	Guide-& Pin Assy-Hill Hold Rod	1940 All
BZ 160250	Spring-Hill Hold Rod Guide Pin to Clutch Lever	1940 All
BZ 160251	Washer-Hill Hold Rod Guide Pin	1940 All
BZ 160252	Connector-Hill Hold Rod	1940 thru 1947 All
BZ 160253	Rod-Hill Hold-Valve End	1940 All
BZ 160254	Lever-Hill Hold Valve	1940 thru 1947 All
BZ 160255	Fitting-Hill Hold to Master Cyl	1940 thru 1947 All
BO 160256	Switch-Direction Indicator	1940-1941 All
BO 160258	Case-Direction Indicator Switch-Pr	1940-1941 All
BO 160259	Cover Assy-Direction Ind Switch Case	40 thru 48,10,11,18
BO 160261	Jewel-Direction Indicator Switch Case Cover	1940-1941 All
BO 160262	Button-Direction Indicator Control-RH	1940 All
BO 160263	Button-Direction Indicator Control-LB	1940 All
BO 160264	Button-Direction Indicator Release	1940 All
BO 160265	Conduit-Direction Indicator Wire	40 thru 48,10,11,18,20,21,28,51,53,171,173,481, 483,491,493,500,501,503
BO 160266	Flasher Switch-Direction Indicator	1940-1941 All
BZ 160267	Baffle and Bracket Assy-Radiator Core	40,10,1942-1946-1947 All
BZ 160268	Baffle and Bracket Assy-Radiator Core	41,43,48,11,12,18
BZ 160269	Baffle and Bracket Assy-Radiator Core	44,45,47,14,15,17
BZ 160275	Wire Harness-Vacumotive Drive	1940 All
BO 160276	Bracket Assy-Horn	40T,40C,48,10T,10C,18,20T,20C,28,58,178 exc Station
BO 160278	Horn Assy-Short-High Pitch-6 Volt	40P,41,43,44,45,47,48P
BO 160279	Horn Assy-Long-Low Pitch-6 Volt	40P,41,43,44,45,47,48P
BO 160280	Horn Assy-Short-High Pitch-12 Volt	40P,41,43,44,45,47,48P
BO 160281	Horn Assy-Long-High Pitch-12 Volt	40P,41,43,44,45,47,48P
BO 160282	Bracket and Brace Assy-Twin Air Horn	40P,41,43,44,45,47,48P
BZ 160285	Wrench-Wheel Hub Bolt	1940 thru 1950 All
BZ 160286	Drain Tube-Battery Drip Pan-Rubber	1940 thru 1947 All
BO 160287	Clamp-Horn Mtg	40P,41,43,44,45,47,48P
BO 160288	Bushing-Horn Mtg Clamp	40P,41,43,44,45,47,48P
BO 160290	Bushing-Horn Trumper Spacer	1940-1941 All
160291	Use 161112	
BZ 160292	Washer-Brake Anchor Link Nut-Felt	40T,40P,48 5Sed
160298	Use 161005	
160299	Use 161006	
160302	Use 1 each 160690-160653	
160303	Use 1 each 160691-160653	
BO 160304	Insulator-Electric Clock Fuse	1940 All
BZ 160305	Gusset-Rear Spring Front Bracket	1940 thru 1942 CvCpe-CvSed,11-14-21 Sta, 1946-1947 CvBro
BZ 160306	Gusset-Rear Spring Front Bracket	1940 thru 1942 CvCpe-CvSed,11-14-21 Sta, 1946-1947 CvBro
BO 160308	Cover-Horn Motor	1940 thru 1950
BO 160309	Cover-Horn Motor-Lower-High Pitch	1940-1941 Air Type Horns
F 160313	Ignition Wires Kit-Boxed	1940 thru 1947 6 Cyl
160314	Ignition Wires Kit-Boxed,(Use 43538)	1940 thru 1942 8 Cyl
BO 160318	Projector-Horn-Short	1940-1942 Air Type Horn
160319	Thrust Washer-Camshaft (Use 162180)	1940 thru 1947 All,1948 thru 1950 8 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

221

Part No.	Name	Models
MF 160326	Projector-Horn-Long	1940-1941 Air Type Horn
MF 160327	Bearing-Camshaft-#1-.004 O/S I.D	34 thru 1940 6 Cyl
MF 160328	Bearing-Camshaft-#2-.004 O/S I.D	34 thru 1940 6 Cyl
MF 160329	Bearing-Camshaft-#3-.004 O/S I.D	1940 6 Cyl
MF 160330	Bearing-Camshaft-#3- .004 O/S I.D	34 thru 39 6 Cyl
MF 160331	Bearing-Camshaft-#1- .004 O/S I.D	34 thru 1940 8 Cyl
MF 160332	Bearing-Camshaft-#2-.004 O/S I.D	34 thru 1940 8 Cyl
MF 160333	Bearing-Camshaft-#3-.004 O/S I.D	34 thru 1940 8 Cyl
MF 160334	Bearing-Camshaft-#4-.004 O/S I.D	34 thru 1940 8 Cyl
MF 160335	Bearing-Camshaft-#5-.004 O/S I.D	34 thru 1940 8 Cyl
F 160338	Cable Assy-Battery to Starter	40,10,20
160339	Cable Assy-Battery to Starter (Use 166237)	41 thru 48,11 thru 18,10 Del,21 thru 28
BO 160340	Junction Block-Headlamp Wires	1940 thru 1950 All
160341	Junction Block-Tail Lamp Wires (Use 166483)	1940 thru 1942 All,51 thru 54,171 thru 174
BO 160342	Clip-Inst Harness to Clutch Housing	1940 thru 1947 All,1948-1949-501 thru 504 With HDM
BO 160343	Relay-Horn-6V-Used with Air Type Horns	1940 All
BO 160344	Relay-Horn-12V-Used with Air Type Horns	1940 All
BO 160345	Retaining Spring-Direction Indicator Button	1940-1941 All
BT 160347	Extension-Gov Sw Adapter Grease Fitting	1940 All
BZ 160349	Bolt and Vent Assy-Brake Control Tube Tee	1940 thru 1947 All
EM 160352	Wire Assy-#1 Spark Plug	1940 thru 1947 6 Cyl
EM 160354	Wire Assy-#2 Spark Plug	1940 thru 1947 6 Cyl
EM 160356	Wire Assy-#3 Spark Plug	1940 thru 1947 6 Cyl
EM 160358	Wire Assy-#4 Spark Plug	1940 thru 1947 6 Cyl
EM 160360	Wire Assy-#5 Spark Plug	1940 thru 1947 6 Cyl
EM 160362	Wire Assy-#6 Spark Plug	1940 thru 1947 6 Cyl
EM 160364	Wire Assy-Coil to Dist-High Tension	1940 thru 1947 6 Cyl
EM 160367	Wire Assy-Coil to Dist-High Tension	44,45,47
BZ 160373	Spring Clip-Rebound #1	For Springs 159686-8-9-90-91-160162-164031
BZ 160373	Spring Clip-Rebound #1 & #4	For Springs 162030-1-162442-3-4-103554-163660
BO 160378	Wire Assy-Charge Regulator to Fused Conn	1940 All
BO 160380	Wire Assy-Fused Conn to Horn Relay	1940 All
BZ 160383	Support-Assy-Hand Brake Cable Lever	1940 thru 1942 CvCpe-CvSed-Station,1946-1947 CvBro
BO 160386	Wire Assy-Inst Harness to Rear Junction-Tail & Stop	48 Cab-CabPu-Station
BO 160390	Wire Assy-Indicator Harness to Bonnet Lamp Conn	1940 All
BO 160392	Wire & Socket Assy-Hood Lamp-RH-With Ind	1940 All
BO 160394	Wire & Socket Assy-Hood Lamp-LH With Ind	1940 All
EM 160400	Wire Assy-Coil to Distributor-Braid Covered	40,41,43,48
EM 160402	Wire Assy-Coil to Distributor-Braid Covered	44,45,47
BO 160405	Wire Assy-Steering Conn to Horn Relay	1940 All
BT 160413	Valve Stop Rod-VD Piston	1940-1941 All,1942 thru 1949 With VD or HDM
EX 160414	Thrust Washer-Differential Gear-.036	1940 thru 1950 All
BX 160415	Thrust Washer-Differential Gear-.041	1940 thru 1950 All
EX 160416	Thrust Washer-Differential Gear-.046	1940 thru 1950 All
BX 160417	Thrust Washer-Differential Gear-.051	1940 thru 1950 All
EX 160418	Thrust Washer-Differential Gear-.056	1940 thru 1950 All
BO 160435	Wire and Socket Assy-License Lamp	1940 3Cpe-VicCpe
BO 160438	Wire & Socket Assy-Hood Lamp-RH-Without DI	40,41,44,45,48
BO 160439	Wire & Socket Assy-Hood Lamp-LH-Without DI	40,41,44,45,48
BO 160472	Socket & Wires Assy-Service Lamp-LHD	1940 CvCpe-CvSed
BO 160475	Wire & Socket Assy-Mechanical Clock Lamp-LHD	40,41,44,45,48
BO 160480	Instrument Wire Harness-LHD	1940 All
BO 160482	Socket Assy-Hood, Lamp Wire-Less DI	40,41,44,45,48
BO 160483	Socket Assy-Hood, Lamp Wire-With DI	1940 All
BO 160484	Socket Assy-License Lamp Wire	1940 CvCpe-CvSed-3Cpe-VicCpe-UCpe
BO 160486	Wire Harness-Clock-LHD-6 Volt	1940 All
BO 160487	Wire Harness-Clock-RHD-6 Volt	1940 All
BO 160490	Washer-Hood Lamp Socket Term	1940-1942-1946-1947 All
160491	Use 109807	
BO 160492	Insulating Washer-Hood Lamp Socket	1940-1942-1946-1947 All
C 160493	Shaft Assy-Propeller-Use with Overdrive	43,47,48
C 160494	Shaft-Propeller-Use with Overdrive	43,47,48
160495	Shaft Assy-Prop (Use 160496)	40,41,44,45
C 160496	Shaft-Propeller-Use with Overdrive	40,41,44,45
160497	Shaft & Rear Joint Assy-Propeller-Use with OD- (Use 160494)	43,47,48
160498	Shaft & Rear Joint Assy-Propeller-Used with OD (Use 160496)	40,41,44,45
A 160499	Guard-Engine (Right) Front	44,45,47,14,15,17,24,25,27,53,54,173,174
EM 160507	Piston Ring-Oil	40-41-10-11-12 X Engine
EM 160508	Piston Ring-Oil- .010 Oversize	40-41-10-11-12 X Engine
EM 160509	Expander-Piston Oil Ring	40-41-10-11-12 X Engine
C 160510	Spring-Front	40,41
C 160511	Spring-Front	43,48

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 160512	Spring-Front-Heavy Scale	44,45,RH for 47,1941 Cab-CabPu-Del,20,21,22,28,51,52,58,171,172,178 Cab-CabPu
C 160513	Spring-Front-LH	47
BM 160515	Combination Fuel & Vacuum Pump Kit	40-10-20 With Std Engine,48,18,28
EM 160516	Combination Fuel & Vacuum Pump Kit	40-10-20 With L Engine,41,43,11,12 21,22
BM 160517	Combination Fuel & Vacuum Pump Kit-LHD	1940 thru 1942 8 Cyl
EM 160513	Combination Fuel & Vacuum Pump Kit-RHD	1940 thru 1942 8 Cyl
BZ 160520	Housing Assy-Steering Gear-LHD	1940 thru 1947 6 Cyl
BZ 160521	Housing Assy-Steering Gear-RHD	1940 thru 1947 6 Cyl
BZ 160522	Housing Assy-Steering Gear-LHD	43,47,14,15,17
BZ 160523	Housing Assy-Steering Gear-RHD	1940 thru 1942 8 Cyl
BZ 160528	Shaft & Roller Tooth Assy-Steering Gear-LHD	1940 thru 1947 6 Cyl,44,45
BZ 160529	Shaft & Roller Tooth Assy-Steering Gear-RHD	1940 thru 1947 6 Cyl,44,45
160530	Shaft & Roller Tooth Assy-Steering Gear-LHD (Use 162918)	43,47,14,15,17
BZ 160531	Shaft & Roller Tooth Assy-Steering Gear-RHD	1941-1942 8 Cyl,43,47
BZ 160539	Oil Seal-Steering Gear Shaft	40,41,44,45,48,1941-1942-1946-1947 6 Cyl
BZ 160540	Oil Seal-Steering Gear Shaft	43,47,1941-1942-1946-1947 8 Cyl
BZ 160542	Cover-Steering Gear Housing	43,47,1941-1942-1946-1947 8 Cyl
160543	Gasket-Steering Gear Housing Cover (Use 166431)	43,47,1941-1942-1946-1947 8 Cyl
C 160546	Main Column & Worm Assy-Steering Gear-LHD	43,47,1941-1942-1946-1947 8 Cyl
C 160547	Main Column & Worm Assy-Steering Gear-RHD	43,47,1941-1942-1946-1947 8 Cyl
C 160548	Tube-Steering Gear Main Column	43,47,1941-1942-1946-1947 8 Cyl
BZ 160551	Bearing Assy-Steering Gear Worm	43,47,1941-1942-1946-1947 8 Cyl.1948-1949 All,501 thru 504
BZ 160552	Ring-Steering Gear Worm Bearing Adjusting	43,47,1941-1942-1946-1947 8 Cyl.1948-1949 All,501 thru 504
BZ 160553	Ring-Steering Gear Worm Bearing	43,47,1941-1942-1946-1947 8 Cyl,1948-1949 All,501 thru 504
BZ 160555	Shim-Steering Gear Worm Housing Cover-Thin	43,47,1941-1942-1946-1947 8 Cyl,1948-1949 All,501 thru 504
BZ 160556	Shim-Steering Gear Worm Housing Cover-Thick	43,47,1941-1942-1946-1947 8 Cyl,1948-1949 All,501 thru 504
BZ 160557	Cvr & Grease Ret Tube Assy-Strg Gear Worm Hsg	43,47,1941-1942-1946-1947 8 Cyl
BT 160561	Brkt-Handy Shift Lever Tube-Use with DI	1940 All,10,11,18,20,21,28
160566	Use 162950	
BZ 160570	Tube Assy-Master Cyl to Frame Tee-RHD	1940 thru 1947 All
BT 160571	Wire Casing & Brkt Assy-Handy Shift Lever-LHD	1940 All
*BM 160574	Starting Motor Complete-Includes Solenoid	40,41,43,48
*EM 160575	Starting Motor Complete-Includes Solenoid	44,45,47
BT 160578	Adapter-VD Gov Switch-Use with Overdrive	1940 All
160579	Switch-Vacumotive Drive (Use 153259)	1940 All
C 160580	Case Assy-Trans-For Overdrive	1940 All
*F 160582	Mainshaft Assy-For Overdrive	1940 All
*F 160584	Shift Sleeve-Mainshaft Sec & High	1940 All
F 160586	Gear-Mainshaft Low & Reverse-For Overdrive	1940 All
BT 160587	Ret Lock-Mainshaft Low & Reverse Gear-OD	1940 All
F 160588	Bearing-Trans Mainshaft-For Overdrive	1940 All
BT 160589	Cap Assy-Countershaft-For Overdrive	1940 All
BT 160591	Shim-Countershaft Cap-Thin-For Overdrive	1940 All
BT 160592	Shim-Countershaft Cap-Thick-For Overdrive	1940 All
BT 160594	Cap-Reverse Gear Shaft-For Overdrive	1940 All
BT 160595	Shift Rail-Low & Reverse-For Overdrive	1940 All
BT 160598	Pinion Sleeve-Speedometer	1940 All
BT 160599	Companion Flange-Transmission-Use with OD	1940 thru 1950 All
BT 160604	Bolt-Trans Bumper-RH-Use with Overdrive	1940 All
BT 160605	Bolt-Trans Bumper-LH-Use with Overdrive	1940 All
BT 160606	Gear-Speedometer-For OD exc 4-7/8 With 16-5.50 Tires	1940 All
BT 160607	Pinion-Speedometer-For OD-4-5/9 or 4-7/8 Axle	1940 All
BZ 160610	Rod Assy-Pedal Link B/C to Cross Shaft	1941 with OD
BT 160611	Rod-Assy-Pedal Link B/C to Cross Shaft-LHD	1940 with OD
BT 160612	Washer-Ace Pedal Link B/C to Cross Shaft Rod	1940 thru 1947 with OD
BT 160613	Swivel-Ace Pedal Link B/C to Cross Shaft Rod	1940 thru 1947 with OD
BT 160614	Sleeve-Acc Pedal Link B/C to Cross Shaft Rod Swivel	1940 thru 1947 with OD
EM 160615	Tube Assy-Distributor Vac Control	40-10-20 With Std Engine,48,18,28
EM 160617	Tube Assy-Distributor Vac Control	40-10-20 With L Engine,41,43,11,12,21,22,1946-1947 6 Cyl
BO 160620	Horn Assy-Single Unit Vibrator-6 Volt	40T,40C,48,10T,10C,18,20T,20C,28,58,178 exc Station
BO 160621	Horn Assy-Single Unit Vibrator-12 Volt	40T,40C,48,10T,10C,18,20T,20C,28,58,178 exc Station
C 160627	Side Member Assy-Frame-RH	41-44 CvCpe-CvSed
EM 160630	Stud-Starting Motor Mounting	1940 thru 1950 All
160631	Use 161145	
160632	Use 160968	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 160633	Reinforcement-Frame Steering Gear	41 thru 48,11 thru 18,21 thru 28,51 thru 54 RHD,171 thru 174 RHD
BT 160635	Gasket-Overdrive to Trans Case	1940 All
C 160636	Wire & Casing Assy-Overdrive Control-LHD	1940 All
BT 160637	Anchor Brkt-Overdrive Cont Wire Casing	1940 All
BT 160638	Lever-Overdrive Control	1940 All
BT 160639	Bolt-Overdrive Control Lever	1940 thru 1950 All
BT 160640	Swivel-Overdrive Control Lever Bolt	1940 thru 1950 All
BT 160641	Switch-Overdrive Throttle	1940 All
BT 160642	Bracket-Overdrive Throttle Switch-LHD	1940 All
C 160643	Support Member Assy-Overdrive	40-41-43-48 exc Cv
C 160644	Support Member Assy-Overdrive	40-41 CvCpe-CvSed
C 160645	Support Member Assy-Overdrive	44-45-47 exc Cv
160652	Use 1-160787,4-70863.4-170481	
BT 160653	Boot-Overdrive Solenoid	1940 All
160656	Housing Assy-Clutch-For Overdrive (Use 159522)	1940 All
C 160658	Trim Ring-Wheel Rim-For 16" Wheels	45,47,15,17
BZ 160659	Clip-Rear Spring-Heavy Scale	1940 thru 1942 All,178 Station
160661	Plate-Clutch Driving (Use 301246)	
160669	Use 45153	
*SP 160671	Hudsonite Clutch Compound-1/3 Pint	All Models
160677	Use 159654	
BZ 160678	Air Cleaner-Oil Bath-8"	41,43,40- 10-20 With L Engine,11,12,21,22 Without HDM,1946-1947 6 Cyl Without HDM
BZ 160679	Brace-8" Oil Bath Air Cleaner	41,43,40-10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
BZ 160683	Spring-Brake and Clutch Lever Return	1940 with 1947 All
BO 160684	Wire Harness-Direction Indicator-LHD	1940 All
BT 160690	Wire Harness-Overdrive-LHD	1940 All
BT 160691	Wire Harness-Overdrive-RHD	1940 All
BT 160693	Pinion-Spdmtr-for OD (4-5/9 with 6.25-6.50 or (7.00 tires (4-1/9 with 5.50 tires	1940 All
BT 160694	Pinion-Spdmtr-for OD (4-1/9 with 6.00-6.25 or (7.00 tires (4-7/8 with 5.50 tires	1940 All
BT 160695	Pinion-Spdmtr-for OD-4-7/8 with 6.00 tires	1940 All
BT 160696	Clutch Assy-Used with OD	40,41,43,48,12,10-11-18 Taxi Cab
160697	Use 160696	
C 160698	Wire and Loom Assy-Generator	40,41,43,48
C 160699	Wire and Loom Assy-Generator	44,45,47
160719	Engine Assy-With Overdrive (Use 164815)	40
160720	Engine Assy-Without Overdrive (Use 164815)	40
160722	Engine Assy (Use 164815)	48
160723	Engine Assy-Without Overdrive (Use 164815)	41
160724	Engine Assy-With Overdrive (Use 164815)	41
160725	Engine Assy-With or Without Overdrive (Use 164815)	43
160727	Engine Assy-With or Without Overdrive (Use 164820)	44,45
160728	Engine Assy-With or Without Overdrive (Use 164820)	47
160749	Use 163600	
BZ 160751	Bell Crank-Accelerator Pedal Link-RHD	44,45,47
BT 160752	Housing & Rotor Assy-VD Governor Switch	1940 All
BT 160753	Housing Assy-VD Governor Switch	1940 All
BT 160755	Rotor Assy-VD Governor Switch	1940 All
BT 160757	Nut-Governor Switch Rotor Shaft	1940-1941 All
BT 160787	Relay-Overdrive	1940 All
BO 160788	Bracket & Brace Assy-Horn	1940-1941 All
BO 160790	Horn Assy-Short-6V	1940 All
BO 160791	Horn Assy-Long-6V	1940 All
BO 160792	Horn Assy-Short-12V	1990 All
BO 160793	Horn Assy-Long-12V	1940 All
BO 160794	Wire Assy-Horn-Short-To Relay	1940 All
BO 160795	Wire Assy-Horn-Long-To Relay	1940 All
BO 160798	Spring Plate-Horn Trumpet Support	1940-1941 All
BO 160799	Relay-Horn-6V	1940 All
160800	Use 162950	
BO 160802	Horns & Bracket Complete-Includes Relay-12V	1940 All
BO 160804	Relay-Horn-12V	1940 All
BT 160806	Loom-Overdrive Control Wire-1/4"	40T,40C,48C
BZ 160807	Spacer-Horn Button	1940 All
BZ 160809	Cup-Horn Button Contact	40,48,10,11,18,17 7Sed,20,28,51,53,58,171,173,178, 481,483,491,493,500,501,503
160818	Use 163449	
BZ 160819	Insulating Washer-Horn Wire Terminal	1940 All,10 Del

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
160826	Gear-Camshaft-Std (Pkg 1-2) (Use 165907)	1936 thru 1940
160827	Gear-Camshaft-.008 O/S (Pkg 1-2) (Use 165907)	1936 thru 1940
F 160828	Connection-Battery (Pos) to Ground	1940-1941-1946-1947 All
BT 160829	Fuse Holder-Overdrive Relay	1940 All
BT 160832	Gear-Speedometer-Without Overdrive	1940 With 4-7/8 Axle and 5.50 tires
BT 160833	Gear-Speedometer-Without Overdrive	1940 exc 4-7/8 Axle and 5.50 tires
BT 160834	Pinion-Speedometer-Without Overdrive	1940 with 4-1/9 Axle and 6.00-6.25-6.50 or 7.00 tires
BT 160834	Pinion-Speedometer-Without Overdrive	1940 with 4-7/8 Axle and 5.50 tires
BT 160835	Pinion-Speedometer-Without Overdrive	1940 with 4-1/9 Axle and 5.50 tires
BT 160835	Pinion-Speedometer-Without Overdrive	1940 with 4-5/9 Axle and 6.25-6.50 or 7.00 tires
BT 160836	Pinion-Speedometer-Without Overdrive	1940 with 4-7/8 Axle and 6.25-6.50 or 7.00 tires
BT 160836	Pinion-Speedometer-Without Overdrive	1940 with 4-5/9 Axle and 5.50 or 6.00 tires
BT 160837	Pinion-Speedometer-Without Overdrive	1940 with 4-7/8 Axle and 6.00 tires
160857	Brake Shoes (Use 163504)	
160858	Use 163508	
160859	Use 163506	
160860	Use 163506	
BZ 160870	Tube Assy-Hill Hold to Frame Tee	1940 thru 1947 All
160871	Link-Acc Pedal to Bellcrank (Use 40439)	1940 All
BT 160873	Cover Assy-Trans-RHD	1940 All
BT 160874	Trans Cover & Pin Assy-LHD	1940 with OD
BT 160875	Trans Cover & Pin Assy-RHD	1940 with OD
BT 160878	Vent-Trans Cover-Use with Overdrive	1940 All
EM 160879	Pipe Assy-Fuel Pump to Carburetor-LHD	1940 thru 1947 8 Cyl
EM 160881	Pipe Assy-Fuel Pump to Carburetor-RHD	1940 thru 1947 8 Cyl
EM 160883	Pipe Assy-Comb Pump to Carburetor	1940 thru 1947 8 Cyl
BT 160885	Oil Seal-Speedometer Pinion Sleeve-Use with Overdrive	1940 All
160895	Rod Guide and Seal Assy-Sh Absorber Piston(Use 163536)	40,41,48 ,10T,10P,11,12,10 UCo-UCpe,18
BZ 160898	Pressure Tube-Front Shock Absorber	1940 thru 1947 6 Cyl exc 43-22,22-24-25 Cpe
BZ 160899	Piston-Shock Absorber	40,41,48,10,11,12,18
BZ 160900	Metering Washer-Front Shock Absorber Piston	1940 All,1941-1942 Club Cpe-3Cpe,27,1946-1947 All
BZ 160901	Metering Washer-Rear Shock Absorber Piston	1940 All,1941-1942 ClubCpe-3Cpe,27
160902	Relief Valve Disc-Front Shock Absorber Piston-.006	1940 All,10-11-20-21-22 exc Cpe,18,28,1946-1947 All
BZ 160903	Relief Valve Disc-Shock Absorber Piston-.008	1940 thru 1947 All
BZ 160904	Relief Valve Disc-Shock Absorber Piston-.010	1940 thru 1947 All
BZ 160905	Relief Valve Disc-Shock Absorber Piston-.004	1940 thru 1947 All
BZ 160906	Nut-Shock Absorber Piston Rod	1940 thru 1947 All
BZ 160907	End and Valve Assy-Front Shock Absorber	40,41,48,10-11 exc Cpe,18
BZ 160908	End and Valve Assy-Rear Shock Absorber	40,41,48,10-11-12 exc Cpe,10 UCo-UCpe,18
BO 160915	Wire Assy-Horn to Relay Short	1940 with Air Type Horns
BO 160916	Wire Assy-Horn to Relay Short	1940 with Air Type Horns
BO 160917	Ground Strap-Horn to Bracket	1940 with Air Type Horns
EM 160919	Pipe Assy-Oil Pump Suction	1940 thru 1947 6 Cyl
160924	Tool Kit (Use 164636)	43,44,45,47,48 Panel
BZ 160925	Tool Kit	40-10-20 Cab-CabPu
160929	Tool Kit-Export (Use 165159)	40T,40P,48P,40 UCo-UCpe-Panel,10T exc 3Cpe,10P, 10 UCo-Del
160930	Tool Kit-Export (Use 165161)	41,43,48,11,12,18P
160931	Tool Kit-Export (Use 164636)	44,45,47,14,15,17
160936	Gasket-Carburetor to Speed Governor (Use 159657)	1940 thru 1947 8 Cyl
BZ 160937	Pipe Assy-Gas Tank to Fuel Pump	43-48
BO 160938	Elbow-W/Shield Defroster Outlet	1940 thru 1947 All
*SP 160939	Fuse Kit-5 Silvered Fuses-Boxed	1940 thru 1947 All
F 160940	Threaded Bshg Assy-Rear Spring-Rear-RH-Lower	1940 All
F 160941	Threaded Bshg Assy-Rear Spring-Rear-LH-Lower	1940 All
160950	Cover Assy-Rear Spring-RH-Front (Use 159992)	1940 exc Cab-CabPu-Panel,11 thru 17 exc Del,18P, 21 thru 27,1946 exc Cab-CabPu
BZ 160951	Cover Assy-Rear Spring-LH-Front	1940 exc Cab-CabPu-Panel,11 thru 17 exc Del,18P, 21 thru 27,1946 exc Cab-CabPu
160952	Cover Assy-Rear Spring-RH-Rear (Use 159994)	1940 exc Cab-CabPu-Panel,11 thru 17 exc Del,18P, 21 thru 27,1946 exc Cab-CabPu
BZ 160953	Cover Assy-Rear Spring-LH-Rear	1940 exc Cab-CabPu-Panel,11 thru 17 exc Del,18P, 21 thru 27,1946 exc Cab-CabPu
BT 160963	Housing-Trans Speedometer Gear-Without OD	1940 All
160964	Bracket-Rear Spring-Front-LH (Use 162274)	1940 All
C 160968	OD Assy-Less Speed Pinion-4-1/9 to 1 and 4-5/9 to 1	40P,40C exc UCo-UCpe,41,43,44,45,47,48
160969	Grease Fitting-Water Pump Body (Use 166335)	1940 thru 1946 All
BZ 160970	Silencer-Horn Button Attaching Screw	1940 All
160995	Clutch Assy-Use with OD (Use 160996)	40,41,43,48,10,11,12,18
BT 160996	Clutch Assy	44,45,47,14,15,17
160997	Plate-Clutch Driving (Use 301246)	
EM 161002	Side Bracket Assy-Ignition Cable	44,45,47
F 161005	Shackle-Rear Spring-Rear Right-Second type	1940 thru 1950 All
F 161006	Shackle-Rear Spring-Rear Left-Second type	1940 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

225

Part No.	Name	Models
*SP 161007	Replacement Cartridge-Oil Filter	1940 thru 1947 All,481,482,491,492
F 161010	Oil Seal-Drive Pinion	1940 thru 1947 All
EX 161011	Oil Washer-Drive Pinion	1940 thru 1947 All
EX 161012	Dirt Shield-Drive Pinion Oil Seal	1940 thru 1948 All
EX 161014	Companion Flange-Rear Axle	1940 thru 1947 All
BM 161015	Stud-Carburetor to Manifold-Plain	41,43,44,45,47,10-20 With L Engine,11 thru 17,21 thru 27,1946 thru 1949 All,501 thru 504
BZ 161020	Nut-Shock Absorber Piston Rod-All Delco	43,44,45,47,12,14,17,22-24 exc Cpe,21 Sta,27,1946-1947 All
BZ 161021	Guide-Shock Absorber Piston Rod-All Delco	43,44,45,47,14-22-24 exc Cpe,17,27,1946-1947 All
BZ 161022	Oil Seal Assy-Shock Absorber Piston Rod-Delco	43,44,45,47,14-22-24 exc Cpe,17,22 Sta,27,1946-1947 All
161023	Use 160901	
161024	Use 160904	
161025	Use 160905	
BZ 161028	Dust Shield Tube-Shock Abs-Front-For 160105-6	43,44,45,47,12-22-24 exc Cpe,21 Sta,27,1947 All
BZ 161030	Pressure Tube-Shock Absorber-Front-For 160105-6	43,44,45,47,12-22-24 exc Cpe,21 Sta,27,1947 All
BZ 161031	Relief Valve & End Assy-Sh Abs-Front-For 160105-6-162032	43,44,45,47,12-14-22-24 exc Cpe,17,21,Sta,27,1946 All
BZ 161032	Relief Valve & End Assy-Sh Abs-Rear-For 160109-10.	43,44,45,47,12-14-22-24 exc Cpe,17,21,Sta,27,1946 All
BZ 161037	Metering Washer-Shock Absorber Piston	40 thru 48,14-20-21-24 exc Cpe,17,27,28,52-53-54-172-173-174 exc Cpes
*HA 161040		1940 thru 1947 All
161041	Oil Filter Kit	
BM 161045	Use 161040	1940 thru 1947 All,481,482,491,492
BM 161046	Hose-Oil Filter Inlet & Outlet	1940 thru 1947 All
BM 161048	Hose-Oil Filter Outlet	1940 thru 1947 All
BM 161049	Extension-Oil Check Valve-Body-For Filter	1940 thru 1947 8 Cyl
BO 161055	Brace-Oil Bath Air Cleaner	1940-1941 All
BO 161056	Defroster-Y-Windshield	1940-1941 All
161057	Stud-Defroster Y to Dash-5/16" 18 x 1-7/8"	1940 All
BO 161058	Hose-Defroster-21" Long (Use 301187)	1940 All
161059	Hose-Defroster-25" Long	
BZ 161061	Use 164235	40-41-48 exc Cab-CabPu-Panel-Sta
*C 161068	Pressure Relief Valve Disc-Shock Abs Piston	40-48 CabPu
BZ 161071	Tank Assy-Gasoline	40-48 CabPu
161075	Filler Neck Assy-Gasoline Tank	For Springs No 159683-4-5-7-160161
CF 161076	Leaf-Spring-Rebound (Use 163882)	For Springs No 159683-4-5-7-8-9-90-91,160161-2-5-6-7-8,161115-6-7-8-9,161937-8-9,162445-6-7-8,163661-2-3-164030-1-2
C 161077	Leaf-Spring-Main	For Springs #159683-4-5-7-8-9-90-91,160161-2,161115-6-7-8-9,161165-6-7-8,161937-8-9,163661-2-3,163049,164030-1-2
C 161078	Leaf-Spring-#2	For Springs No 159683-4-5-7-160161
C 161079	Leaf-Spring-#3	For Springs No 159683-4-5-7-160161
C 161084	Leaf-Spring-#4	For Springs No 159686-162448-163663
C 161084	Leaf-Spring-Rebound	For Springs No 159686-162448-163663
C 161091	Leaf-Spring-#4	For Springs No 159688-89-90-91-160162,161115-6-7-8-9
C 161092	Leaf-Spring-Rebound	For Springs No 159688-89-90-91-160162.161115-6-7-8-9
CF 161100	Leaf-Spring-#3	For Springs No 159692-3
C 161101	Leaf-Spring-Main	For Springs No 159692-3
C 161102	Leaf-Spring-#2	For Springs No 159692-3
C 161103	Leaf-Spring-#3	For Springs No 159692-3,159692-3
F 161112	Leaf-Spring-#4	40T,40P
161113	Nut-Brake Anchor Link	For Springs No 159680-89-90-91-160162
C 161116	Center Bolt-Spring (Use 161748)	40 UCpe-2Sed,40-41-44 CvSed,44 Cpe
C 161117	Spring Assy-Rear-Heavy Scale	40 Sed-UCo-UCpe,41-44-45 2Sed
161118	Spring Assy-Rear-Heavy Scale	41-44-45 Sed
161121	Spring Assy-Rear-Heavy Scale (Use 163663)	All Models
BZ 161122	Pump-Tire D.N.S.	
	Rod Assy-Throttle Control Pull Lever to Manifold	40,48
BT 161124	Bellcrank	1940 All
EX 161125	Rod Assy-Vacumotive Drive Threaded SleeveBell-crank	40,41,10,11,12,18
EX 161126		40,41,10,11,12,18
BZ 161135	Steering Arm-RH-Export With 18 x 3.62 Wheel	1940 thru 1947 All
BZ 161136	Steering Arm-LH-Export With 18 x 3.62 Wheel	1940 thru 1947 All
BM 161137	Spacer-Spring Rebound Clip-Rear	1940-1941 All,1942-1946-1947 with VD or HDM
BM 161138	Spacer-Spring Rebound Clip-Front	40,41,43,48
C 161145	Clip-Wiring	40T,40 UCo-UCpe
BM 161146	Stud-Cylinder Head-Long-For Heater Hose Brkt	1934 exc KU,1935 exc GH
BM 161147	OD Assy-Iess Speedo Pinion-4-7/8 to 1 16 x 5.50 tires	1934 KU,1935 GH
C 161152	Water Pump Repair Parts Kit-For 151932 Pump	40 Cab-CabPu-Panel-Station,48C,18C,10C exc UCo-UCpe,28C,58,178
	Water Pump Repair Parts Kit	
161154	Crossmember Assy-Frame Rear	
	Use 161371	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
161158	Use 161374	
161159	Use 161375	
161165	Spring Assy-Rear (Use 164025)	40 VicCpe-CvCpe-3Cpe
161166	Spring Assy-Rear (Use 166743)	40 CvSed-2Sed-UCpe,41 3Cpe-VicCpe-CvCpe
161167	Spring Assy-Rear (Use 163663)	40 UCo,41-44-45 Sed
161168	Spring Assy-Rear (Use 166745)	41-44 CvSed2Sed,44 VicCpe-3Cpe-CvCpe,45 2Sed,40 Sed
BZ 161169	Spring Clip-Rebound #3-2 Piece	1940 Springs 161115-6-7-8-9
BZ 161170	Spring Clip-Rebound #2-2 Piece	1940 Springs 159686
161171	Rebound Clip-Spring #3 (Use 46213)	For Springs 161933-4-5
161172	Rebound Clip-Spring-#2 (Use 43639)	For Springs 162445-6-7-163661-2-162448-163663
161173	Rebound Clip-Spring-#3 (Use 161195)	For Springs 163735
BX 161174	Rebound Clip-Spring-#2	For Springs 161936-161940-163027
C 161175	Leaf-Spring-Rebound	For Springs 161165-6-7-8-162446-7-162445,163661-163049
C 161176	Leaf-Spring-#3	For Springs 161165-6-7-8-161937-8-9,162445-6-7,163661-2-63049
C 161177	Leaf-Spring-#4	For Springs 161165-6-7-8-161937-8-9,162445-6-7,163661-2,63049
BZ 161181	Bolt-Spring Center	For Springs 161165-6-7-8-162445-163662,1948-1949-1950 exc for Spring 302440
BX 161182	Rebound Clip-Spring-Ng	For Spring 165075
BX 161183	Rebound Clip-Spring-#3	For Springs 161936-161940-163027-162448-163663
BZ 161184	Spring Clip-Rebound-#2-2 Piece	1940 Spring 159686
BZ 161185	Spring Clip-Rebound-#3-2 Piece	1940 Spring 159686
BZ 161186	Spring Clip-Rebound-#2-2 Piece	1940 Springs 161115-6-7-8-9
161187	Use 163723	
C 161188	Extra Spring Leaf Kit	1940 Springs 159683-4-5-7-160161
C 161189	Extra Spring Leaf Kit	1940 Spring 159686
C 161190	Extra Spring Leaf Kit	1940 Springs 161165-6-7-8-1941 Springs 162445-6-7
BZ 161191	Spring Clip-Rebound #1	1940 SpringsNo161165-6-7-8,1941-1942-1946-1947All
BZ 161191	Spring Clip-Rebound #4	1940 All
BZ 161192	Spring Clip-Rebound #1-Bolted	1940 Spring 159686 With Extra Leaf
BZ 161193	Spring Clip-Rebound #1 & 4-Bolted	1940 Extra Leaf Kit,1941 Spring 161935
BZ 161194	Spring Clip-Rebound #2-Bolted	1940 Extra Leaf Kit
BZ 161195	Spring Clip-Rebound #2-Bolted	1940 Extra Leaf Kit,1942-1946-1947 Springs 164030-1-2
BZ 161196	Center Bolt-Rear Spring	1940 Cab-CabPu-Panel,18C,1941-1942-1946-1947 Springs 159692-3
BZ 161203	Guide & Oil Seal Assy-Shock Absorber Piston Rod-Delco	93,95,97,43,44,45,47,1941 All,22-24 exc Cpe,21 Station,27,1946-1947 All
BM 161220	Air Cleaner-Oil Bath	40T,40P,48P,10T,10P,40-10 UCo-UCpe,20 Std Eng,28
A 161221	Guard-Engine-RH	40 with L Engine
BT 161222	Kit-Vacumotive Drive-6 Volt-LHD	40,41,43,48
BT 161223	Kit-Vacumotive Drive-6 Volt-LHD	44,45,47
BO 161228	Antenna & Mounting Assy-Radio	1940 thru 1942 All
BO 161230	Ball-Manual Antenna Tip	1940 thru 1942 All
BO 161242	Grounding Plate-Radio Antenna Mounting	1940 thru 1942 All
BO 161243	Pad-Radio Antenna Mounting	1940 thru 1947 All
BO 161244	Eye Bolt-Radio Antenna	1940 thru 1942 All
BO 161245	Bushing-Radio Antenna Eye Bolt	1940 thru 1942 All
BO 161246	Bushing-Radio Antenna Eye Bolt	1940 thru 1942 All
BO 161249	Cover-Radio Antenna Lead in Shield Cup	1940 thru 1942 All
BT 161250	Rod Assy-Handy Shift Tube to Trans Cover-LHD	1940 All
C 161260	Housing Assy-Overdrive	1940 All
BT 161262	Gasket-Overdrive Housing	1940 All
BT 161265	Adapter-Overdrive Housing	1940 All
BT 161266	Solenoid Assy-Overdrive	1940 All
BT 161267	Gasket-Overdrive Solenoid	1940 thru 1947 All
161268	Base-Overdrive Solenoid (Use 161349)	1940 All
BT 161269	Gasket-Overdrive Solenoid Base	1940 All
BT 161270	Stop Washer Overdrive Solenoid Core	1940 thru 1947 All
BT 161271	Lock Washer-OD Solenoid Base to Adapter	1940 thru 1950 All
BT 161273	Stationary Gear-Overdrive	1940 All
BT 161274	Plate-Overdrive Stationary Gear	1940 All
BT 161275	Snap Ring-Overdrive Stationary Gear	1940 thru 1947 All
BT 161276	Pawl-Overdrive Stationary Gear	1940 All
BT 161277	Operating Rod-OD Stationary Gear Pawl	1940 All
BT 161278	Oil Seal-OD Stationary Gear Pawl Rod	1940 thru 1950 All
BT 161279	Spring-OD Stationary Gear Pawl Rod	1940 All
BT 161280	Balk Ring-OD Stationary Gear	1940 thru 1950 All
BT 161281	Snap Ring-OD Pinion Cage Oil Collector Ring Cover	1940 thru 1947 All
BT 161282	Ring Cage-OD Pinion Cage Oil Collector	1940 thru 1947 All
BT 161283	Cage Assy-Overdrive Pinion	1940 thru 1947 All
BT 161292	Snap Ring-Overdrive Pinion Cage Retaining	1940 thru 1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

227

Part No.	Name	Models
	161294 Use 161298	
BT 161296	Thrust Washer-Overdrive Clutch Core	1940 thru 1947 All
BT 161298	Pawl and Core Complete-Overdrive	1940 All
BT 161302	Spring-OD Pawl Adjusting	1940 All
BT 161303	Screw-OD Clutch Pawl Adjusting Spring	1940 All
BT 161304	Screw-OD Clutch Pawl Adjusting Spring-Slotted	1940 All
BT 161305	Washer-OD Clutch Pawl Adjusting Spring	1940 All
	161306 Use 161302	
BT 161307	Sleeve-OD Clutch	1940 All
BT 161308	Main Shaft Assy-Overdrive	1940 thru 1947 All
BT 161310	Nut-OD or Prop Shaft Companion Flange	1940 thru 1950 All
BZ 161311	Rebound Clip #3-Rear Spring	1940-1941 Cab-CabPu
	161313 Bushing-OD Main Shaft Pilot (Use 163317)	1940 All
BT 161314	Snap Ring-OD Main Shaft-.087	1940 All
BT 161315	Snap Ring-OD Main Shaft-.090	1940 All
BT 161316	Snap Ring-OD Main Shaft-.093	1940 All
ST 161317	Snap Ring-OD Main Shaft-.096	1940 All
BT 161318	Snap Ring-OD Main Shaft Bearing-.087	1940 All
BT 161319	Snap Ring-OD Main Shaft-Bearing-.090	1940 All
BT 161320	Snap Ring-OD Main Shaft-Bearing-.093	1940 All
BT 161321	Snap Ring-OD Main Shaft Bearing-.096	1940 All
BT 161322	Oil Baffle-OD Main Shaft	1940 thru 1946 All
BT 161323	Oil Seal Assy-OD Main Shaft	1940 thru 1950 All
BT 161326	Ring Gear-Overdrive	1940 thru 1947 All
BT 161327	Snap Ring-Overdrive Ring Gear-.055	1940 thru 1947 All
BT 161328	Snap Ring-Overdrive Ring Gear-.057	1940 thru 1947 All
BT 161329	Snap Ring-Overdrive Ring Gear-.059	1940 thru 1947 All
BT 161330	Shaft-Overdrive Control	1940 All
BT 161331	Washer-Overdrive Control Shaft	1940 thru 1947 All
BT 161332	Screw-Overdrive Control Shaft	1940 All
BT 161333	Snap Ring-Overdrive Shifter Rail	1940 All
BT 161334	Oil Seal-Overdrive Control Shaft	1940 thru 1947 All
BT 161335	Shifter Head-Overdrive	1940 All
BT 161336	Screw-Overdrive Shifter Rail	1940 thru 1947 All
BT 161337	Poppet Spring-Overdrive Shifter Head	1940 All
BT 161338	Seat-Overdrive Shifter Head Poppet Spring	1940 All
BT 161339	Ball-Overdrive Shifter Head Poppet Spring	1940 All
BT 161340	Shifter Rail-Overdrive	1940 All
BT 161341	Fork-Overdrive Shifter Rail	1940 All
BT 161342	Retractor Spring-OD Shifter Rail .	1940 All
BT 161343	Expansion Ring-OD Shifter Rail	1940 thru 1947 All
BT 161344	Hole Plug-OD Lubricant Inspection	1940 thru 1947 All
BT 161345	Lock Up Plunger-OD Shifter Rail Reverse	1940 All
	161346 Cam Assy-OD Free Wheel (Use 161347-161348-163317)	1940 All
BT 161347	Cam-OD Free Wheeling	1940 thru 1947 All
BT 161348	Retaining Washer-OD Free Wheel Cam	1940 thru 1947 All
BT 161349	Base Assy-OD Solenoid	1940 All
BT 161350	Cam Roller-OD Free Wheel	1940 thru 1949 All
BT 161351	Retainer-OD Free Wheel Cam Roller	1940 thru 1947 All
BT 161352	Spring-OD Free Wheel Cam Roller Retainer	1940 thru 1950 All
BT 161353	Snap Ring-OD Free Wheel Cam Roller Retainer	1940 thru 1947 All
BT 161354	Plain Washer-OD or Prop Shaft Companion Flange	1940 thru 1950 All
	161355 Spring-OD Clutch Pawl Adjusting (Use 161302)	1940 All
BZ 161363	Rebound Clip #3-Rear Spring-Two Piece	40-48 Cab-CabPu-Panel,1941-1942 Springs
C 161371	Trans Assy-2.42 to 1,4-1/9 axle-Without OD	1940 with 5.50 or 6.00 tires
C 161374	Trans Assy-2.94 to 1,4-5/9 axle-with OD	1940 with 5.50 or 6.00 tires
C 161374	Trans Assy-2.94 to 1,4-7/8 axle-with OD	1940 with 6.25-6.50 or 7.00 tires
	161377 Driving Plate Kit-Clutch (Use 166320)	34 thru 37 6 Cyl,81,89,80 UCo-UCpe-Sed,90,91, 92,40-41-10-11 Without OD,1942,Without OD-VDor HDM
BO 161378	Service Lamp Kit-LHD	1940 exc Cv,10 thru 18
BO 161384	Bracket-Thermostatic Control Switch-Weather-Control	1940 All
	161388 Use 161750	
	161389 Gasket-Cyl Water Jacket Cover (Use 161751)	1940 thru 1946 8 Cyl
BZ 161394	Rebound Clip #2-Rear Spring-2 Piece	1940-1941 Cab-CabPu-Del
BZ 161395	Rebound Clip #2-Rear Spring-2 Piece	1940 Cab-CabPu-Panel,1941-1942-1946-1947 Springs 159692-3
	161396 Tool Kit-Domestic (Use 164636)	40T-10T 3Cpe,40-10 UCpe
BO 161401	Radio Lower Unit-For SA40,6 tube,6 Volt	1940 All
BO 161404	Radio Tuning Unit-For SA40,6 tube,6 Volt	1940 All
BO 161405	Radio Tuning Unit-For DB40,7 Tube,6 Volt	1940 All
BO 161410	Extension Assy-Radio "A" Lead	1940-1941 All
BO 161415	Bolt-Radio Tuning Unit Mounting	1940 All
BO 161417	Ground Strap-Radio-Bonnet to Cowl	1940-1941 All
BO 161418	Capacitor-Ignition Coil	1940 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 161421	Motor Assy-Weathermaster	1940 All
BO 161422	Fan & Blower Assy-Weather-Control	1940 All
BO 161423	Switch Assy-Weather-Control	1940 All
BO 161435	Clamp-Weather-Control Bowden Wire	1940 thru 1950 All
BO 161436	Jumper Wire-Heater & Weather-Control	1940-1941 All
161439	Tube-Weather-Control Core-Short (Use 301771)	1940 thru 1949 All
BO 161440	Tube-Weather-Control Core-Long	1940 All
161441	Hose-Weather-Control (Use 165535)	1940 All
BO 161442	Valve Assy-Weather-Control Shut OFF	1940 thru 1948 All
BO 161443	Bowden Wire-Weather-Control	1940 All
BO 161444	Hook Rod-Weather-Control	1940 All
BO 161445	Staplc-Weather-Control Air Filter	1940 thru 1948 All
BO 161446	Drain Hose-Weather-Control	1940 All
BO 161447	Rubber Washer-Wcather-Control Mounting	1940 thru 1950 All
BO 161448	Core Assy-DeLuxe & Recirculating Heater	1940 thru 1942 All
BO 161451	Reversing Switch-Custom & DeLuxe Heater	1940-1941 All
BO 161453	Outlet-Custom & DeLuxe Heater	1940-1941 All
BO 161455	Rod-Cowl Ventilator Operating-Use With Weather-Control	1940 All
BO 161456	Connector-Heater Fuse	1940-1941 All
BO 161457	Gasket-Weather-Control Shut Off Valve	1940 All
161458	Knob-Heater Reversing Switch (Use 161451)	1940-1941 All
BO 161468	Condenser-Multiple Electrolytic	1940 Radio
BO 161473	Condenser-.5 Mfd-150 V	1940-1941 Radio
BO 161493	Vibrator-6 Volt	1940 Radio
BO 161494	Socket-Small Octal Base	1940-1941 Radio
BO 161495	Choke Coil-A Line	1940 Radio,1941 Custom-DeLuxe
BO 161496	Transformer-2nd IF	1940 7 Tube Radio
BO 151499	Transformer-Power-6 Volt	1940 Radio
BO 161505	Transformer-First IF-In Lower Unit	1940 Radio
BO 161509	Transformer-1st IF-In Control Unit	1940 Radio
BO 161510	Transformer-2nd IF	1940 6 Tube Radio
BO 161513	Volume Control-Includes Off-On Switch	1940 Radio
BO 161516	Escutcheon-Control Head	1940 Radio
BO 161517	Solenoid Assy-Complete	1940 Radio
BO 161535	Clutch Assy	1940 Radio
BO 161540	Wheel & Pinion Assy-Tuning Control	1940 Radio
BO 161541	Disc & Drive Gear-Clutch Engaging	1940 Radio
BO 161557	Screw-Speaker to Mtg Plate	1940 Radio
BO 161558	Speaker-6"	1940 6 Tube Radio
BO 161559	Speaker-8"	1940 7 Tube Radio
BO 161560	Mounting Plate-Speaker	1940 7 Tube Radio
BO 161561	Mounting Plate-Speaker	1940 6 Tube Radio
BO 161563	Cone & Voice Coil Assy	1940 6 Tube Radio
BO 161579	"C" Washer	1940 Radio
BO 161580	Choke-Radio Antenna	40 thru 48,1941 Custom-DeLuxe
C 161581	Hub Complete-Rear	40 with L Engine
BX 161585	Backing Plate Assy-Brake-Rear-RH	40 with L Engine
BX 161586	Backing Plate Assy-Brake-Rear-LH	40 with L Engine
C 161590	Pipe Assy-Exhaust	40 with L Engine
161592	Cover-Exhaust Pipe-Front (Use 160066)	40 with L Engine
BM 161593	Cover-Exhaust Pipe-Rear	40 with L Engine
BZ 161633	Rebound Clip-Rear Spring-#2-2 Piece	1940 Springs 159688-9-90-91,160162
BO 161634	Rebound Clip-Rear Spring-#3-2 Piece	1940 Springs 159688-9-90-91,160162
BO 161635	Rebound Clip-Rear Spring-#2-2 Piece	1940 Springs 161115-6-7-8
161636	Shock Absorber Assy-Front (Use 166574)	1940 All
161657	Shock Absorber-Front (Use 166572)	1940-1941 3Cpe-VicCpe
161658	Shock Absorber-Rear (Use 166573)	1940-1941 3Cpe-VicCpe
*SP 161664	Thermostat-Cyl Head Water Outlet	15,17,25,27,54,174,1948 thru 1950 All
BZ 161665	Cyl End & Valve Assy-Shock Absorber	1940-1941 3Cpe-VicCpe
BZ 161666	Cyl End & Valve Assy-Shock Absorber	1940-1941 3Cpe-VicCpe
BZ 161667	Metering Washer-Shock Absorber	1940 thru 1942 3Cpe-VicCpe
161668	Pedal Complete-Accelerator-Black-LHD (Use 165816 & 166623)	43-47 5Sed
BZ 161669	Pedal Complete-Accelerator-Black-RHD	43-47 5Sed
161671	Cover-Pedal Pad-Black (Use 165819)	43-47 5Sed
C 161672	Steering Wheel-Black	43-47 5Sed
BZ 161673	Button Assy-Horn-Black	43-47 5Sed
C 161676	Jacket Tube Assy-Steering Gear-Plated	43-47 5Sed
BO 161680	Knob-Light Sw Starter-Vac Clutch-Black	43-47 5Sed,12 thru 17
BO 161690	Case & Cover Assy-Direction Ind-Plated	43-47 5Sed,12 thru 17
BO 161692	Button-Direction Indicator-R-Black	43-47 5Sed
BO 161693	Button-Direction Indicator-L-Black	43-47 5Sed
BO 161694	Button-Direction Indicator-Release-Black	43-47 5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

229

Part No.	Name	Models
C 161695	Lever,Tube & Rod Assy-Handy Shift-LHD-Plated	43-47 5Sed
161697	Fulcrum-Handy Shift Lever-Plate (Use 1-165661 & 1-170890)	43-47 5Sed 12,14,15,17,22,24,25,27
C 161698	Tube & Fulcrum Brkt Assy-Handy Shift-LIID-Plated. .	43-47 5Sed 12,14,15,17
161702	Knob-Handy Shift-Black (Use 203990)	43-47 5Sed
161703	Fulcrum Brkt-Handy Shift Lever-Platcd (Use 300987 & 300989)	43-47 5Sed,12,14,15,17,22,24,25,27,52,54,172,174
BT 161704	Ring-Handy Shift Fulcrum Brkt-Plated	43-47 5Sed,12,14,15,17,22,24,25,27,52,54,172,174
BT 161705	Brkt-Handy Shift Lever-Upper-Plated	43-47 5Sed,12-14-22-24 with 01,15,17,25,27
BO 161706	Conduit-Direction Indicator Wire-Plated	43-47 5Sed,12 thru 17,22 thru 27,52,54,172,174,482, 484,492,494,1950
161711	Knob-Heater Switch-Black (Use 161724)	43-47 5Sed
BO 161712	Knob-Thermo Control-Black	43-47 5Sed
161713	Hose W/Shield Defroster-Black (Use 301187)	43-47 5Sed
161714	Hose W/Shield Defroster-Black (Use 164235)	43-47 5Sed
BO 161724	Knob- W/ Master Switch	40 thru 48
BX 161728	Bumper-Spindle Support Lower Brace-4"	1940 thru 1950 All
F 161739	Gasket Kit-Valve Cover	1937 thru 1947 6 Cyl
BZ 161748	Center Bolt-Spring	For 1940 Springs #161115-6-7-8-9
F 161750	Gasket-Water Jacket Cover-Vellumoid	1932 thru 1947 6 Cyl
F 161751	Gasket-Water Jacket Cover-Vellumoid	1930 thru 1950 8 Cyl
161752	Use 163449	
BM 161753	Grease Cup Assy-Distributor	1940 thru 1947 6 Cyl
EM 161759	Shim-Crankshaft Bearing-Thin-#1	40,41,43,48
EM 161760	Shim-Crankshaft Bearing-Thick-#1	40,41,43,48
EM 161761	Shim-Crankshaft Bearing-Thin-#2	40,41,43,48
EM 161762	Shim-Crankshaft Bearing-Thick-#2	40,41,43,48
EM 161763	Shim-Crankshaft Bearing-Thin-#3	40,41,43,48
EM 161764	Shim-Crankshaft Bearing-Thick-#3	40,41,43,48
EM 161765	Shim-Crankshaft Bearing-Thin-#1	44,45,47
EM 161766	Shim-Crankshaft Bearing- Thick-#1	44,45,47
EM 161767	Shim-Crankshaft Bearing-Thin-#2-4	44,45,47
EM 161768	Shim-Crankshaft Bearing-Thick-#2-4	44,45,47
EM 161769	Shim-Crankshaft Bearing-Thin-#3	44,45,47
EM 161770	Shim-Crankshaft Bearing-Thick-#3	44,45,47
EM 161771	Shim-Crankshaft Bearing-Thin-#4	44,45,47
EM 161772	Shim-Crankshaft Bearing-Thick-#4	44,45,47
EM 161773	Gasket-Oil Filter Cover	1940 thru 1947 All,481,482,491,492
161775	Shock Absorber-Rear-Variable Control (Use 301921)	1940 All
161780	Ring Kit-Piston-With Expanders (Use 166328)	1935 thru 1938,1939 1st type
161781	Ring-Kit-Piston-With Expander (Use 166329)	1939 2nd Type,1940 thru 1946 All
F 161782	Ring-Upper Compression-Piston(Part of Kit 161780-1)	1935 thru 1946
F 161783	Ring-Lower Compression-Piston(Part of Kit 161780-1)	1935 thru 1946
F 161784	Expander-Lower Compression Ring (Part of Kit 161780-1)	1935 thru 1946
F 161785	Ring-Oil Wiper-Piston (Part of Kit 161780-1)	1935 thru 1947
F 161786	Ring-Oil-Upper-Piston (Part of Kit 161780-1)	1935 thru 1947
F 161787	Expander-Oil Ring (Part of Kit 161780-1)	1935 thru 1947
F 161788	Ring-Piston Oil-Lower	1939 Second Type,1940-1941-1942-1946 All
F 161789	Oil Ring-Lower-Piston (Part of Kit 161780)	1935 thru 1938,1939 First Type
F 161790	Expander-Lower Oil Ring (Part of Kit 161781)	1939 Second Type,1940 thru 1946
F 161791	Seat-Expander (Part of Kit 161781)	1939 Second Type,1940 thru 1946
F 161792	Seat-Expander (Part of Kit 161780)	1935 thru 1938,1939 1st Type
BO 161909	Defroster Kit-Custom & DeLuxe Heaters	1941 All
BO 161925	Fuse Connector Block to Clock Wire	1941-1942-1946-1947 All
BO 161926	Terminal-Block to Clock Wire Fuse Connector	1941-1942-1946-1947 All
BO 161927	Spring-Block to Clock Wire Fuse Connector Terminal.	1941-1942-1946-1947 All
BO 161928	Spring Washer-Block to Clock Wire Fuse Connector Terminal	1941-1942-1946-1947 All
BO 161931	Casc & Brkt Assy-Ignition Coil-RHD	1941-1942 All
C 161933	Spring Assy-Rear-Heavy Scale	10 3Cpe-ClubCpe-CvCpe
161934	Spring Assy-Rear-Heavy Scale (Use 163554)	10 2Sed-CvSed
161935	Spring Assy-Rear-Heavy Scale (Use 164028)	10 UCo-UCpe-Sed
C 161936	Spring Assy-Rear-Heavy Scale	11-12 ClubCpe-3Cpe
C 161937	Spring Assy-Rear-Heavy Scale	14-15 3Cpe-ClubCpe,11 thru 14 CvSed
C 161939	Spring Assy-Rear-Heavy Scale	11-12-14 Sedan
C 161940	Spring Assy-Rear-Heavy Scale	17,18P
BO 161950	Harness-Instrument-LHD	1941 All Exc Del
BT 161952	Harness-Overdrive-LHD	1941 All
BO 161955	Case & Cover Assy-Direction Indicator Switch	10,11,18
BO 161959	Button-Direction Indicator-R	10,11,18
BO 161960	Button-Direction Indicator-L	10,11,18
BO 161962	Button-Direction Indicator-R	12 thru 17
BO 161963	Button-Direction Indicator-L	12 thru 17

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 161964	Button-Direction Indicator-Release	12 thru 17
F 161965	Spring-Valve	1942-1946-1947 All,1948 thru 1950 8 Cyl
BO 161966	Socket Assy-Clock Lamp	1941-1942-1946-1947 All
BO 161967	Socket Assy-Tell Tale Lamp	1941 thru 1949 All
BO 161968	Socket Assy-Speedometer Lamp	1941 thru 1949 All
BO 161969	Socket Assy-License Lamp	1941 thru 1949 All,500
BT 161970	Lever Assy-Clutch Pedal-LHD	1941-1942-1946-1947 All
BZ 161972	Rod Assy-Acc Cross Shaft to Carburetor-LHD-With Overdrive	10,11,12,18
BZ 161974	Rod Assy-Acc Cross Shaft to Carburetor-LHD-With Overdrive	14,15,17
161984	Use 162635	
BO 161989	Clip-Heater Hose-Custom & DeLuxe Heaters	10,11,12,18,24,25,27
BO 161991	Seal-Water Tube to Air Duct-Weather-Control	1941 thru 1949 All
BO 161991	Spacer-F Door Wing Reg Handle Escutcheon	482,484,492,494,502,504
161995	Use 163358	
C 161997	Wire & Casing Assy-Overdrive Control-LHD	1941-1942-1946-1947 All
C 161998	Wire & Casing Assy-Overdrive Control-RHD	1941-1942-1946-1947 All
BO 162001	Cover-Lower Horn Motor	1941,1946 thru 1950
BZ 162002	Cable Assy-Speedometer-LHD-Use Without OD	1941-1942 exc Del-1946-1947 All
BZ 162003	Core-Speedometer Cable-LHD-Use Without OD	1941-1942 exc Del-1946-1947 All
BZ 162004	Cable Assy-Speedometer-LHD-Use With OD	1941-1942-1946-1947 All,1948 All RHD without OD
BZ 162005	Core Assy-Speedometer Cable-LHD-Use With OD	1941-1942-1946-1947 All
162006	Cable Assy-Speedometer-RHD (Use 302291)	1941 thru 1947 All,1948 with OD
BZ 162007	Core-Speedometer Cable-RHD	1941 thru 1947 All
BZ 162008	Cable Assy-Speedometer-LHD	10 Del
BZ 162011	Spring-Throttle Control Tension-LED	10 thru 18,1942-1946-1947 6 Cyl Without OD-VD or HDM
162012	Bezel-Ignition Lock Case-Lucite (Use 164297)	1941-1942 All
162014	Transmission Assy-For Overdrive (Use 164064)	10 with Std Engine
162016	Top Power Unit Fluid-Pint Can (Use 151105)	1941-1942 CvSed,1946-1947
BT 162018	Gasket-Speedometer Cable to Transmission	1941 thru 1950 All
162029	Clip-Wiring (Use 163410)	10 thru 18
162032	Shock Absorber-Front (Use 165875)	14-22-24 exc 3Cpe-ClubCpc,17,27
162033	Use 158185	
BO 162034	Loom-License Lamp Wire-1/4"	1941-1942 UCpe-3Cpe-ClubCpe-CvSed,1946,1947 Cpes-CvBro
162035	Use 164409	
F 162047	Gear-Transmission Main Drive (Use 163906)	10 With L Engine,11 thru 18
162049	Gear-Transmission Main Drive (Use 163907)	10 With Std Engine
F 162053	Mainshaft-Transmission-Use Without Overdrive	1941 thru 1950 All
162054	Gcar Cluster Assy-Trans Countershaft (Use 163904)	10-20 With L Engine,11 thru 18,21 thru 28
162056	Use 163905	
162058	Bushing-C/S Gear Cluster-Front (Use 165854)	1941-1942 All
162059	Low and Reverse Gear-Trans Mainshaft(Use 163909)	1941-1942 All
162060	Gear Assy-Trans Reverse Idler (Use 166197)	1941-1942 All
162062	Gear-Trans Mainshaft Intermed (Use 163908)	1941 All
BT 162066	Bushing-Trans Reverse Idler Gear	1941 thru 1950 All
BZ 162068	Push Rod-Brake Pedal	1941 thru 1947 All
162069	Switch-VD Governor (Use 164409)	
162071	Bushing-Countershaft Gear Cluster-Rear (Use 165855)	1941 thru 1950 All
C 162072	Case Assembly-Transmission	1941 All
TF 162073	Gasket-Trans Case-Front	1941 thru 1950 All
162074	Bearing-Main Drive Gear (Use 164466)	1941 All
BT 162075	Oil Seal-Main Drive Gear	1941 thru 1950 All
BT 162076	Lock Ring-Main Drive Gear-.090	1941 All
BT 162077	Lock Ring-Main Drive Gear-.093	1941 thru 1950 All
BT 162078	Lock Ring-Main Drive Gear-.096	1941 All
162079	Retainer Assy-Main Drive Gear Bearing (Use 166182).	1941-1942 All
BT 162082	Gasket-Main Drive Gear Bearing Retainer	1941 thru 1950 All
BT 162083	Needle Roller-Mainshaft	1941 thru 1950 All
BT 162084	Retainer-Mainshaft Needle Roller	1941 All
F 162088	Bearing-Mainshaft Rear-Use Without OD	1941 thru 1950 All
162089	Use 162583	
162090	Sleeve-Synchronizer Shift (Use 162583)	1941 All
162091	Hub-Synchronizer Shift Sleeve (Use 162583)	1941 All
BT 162092	Lock Ring-Synchronizer Shift Sleeve Hub-.087	1941 thru 1950 All
162093	Use 162092	
162094	Use 162092	
162095	Use 162092	
BT 162096	Ring-Synchronizer	1941 All
BT 162097	Shift Plate-Synchronizer	1941-1942 All
BT 162098	Spring-Synchronizer	1941 All
EM 162099	Rubber Mounting Block-Engine Rear	14,15,17,24,25,27,53,54,173,174

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

231

Part No.	Name	Models
162102	Countershaft (Use 166203)	1941-1942 All
162103	Thrust Washer-C/Shaft Gear Cluster-Bronze (Use 166183)	1941-1942 All
BT 162105	Thrust Washer-C/Shaft Gear Cluster-Rear-Steel	1941 thru 1950 All
C 162106	Bar Assy-Rear Stabilizer	10P,11 thru 17,18P
BT 162108	Lock Plate-Countershaft & Reverse Shaft-Without OD	1941 thru 1950 All
162109	Shaft-Reverse Idler Gear (Use 164739)	1941-1942 All
BT 162110	Shifter-Low & Reverse	1941 thru 1950 All
BT 162111	Lock Screw-Low & Reverse Shifter & Shifter Fork	1941 thru 1950 All
BT 162112	Shift Fork-Low & Reverse	1941 thru 1950 All
BT 162113	Shift Fork-Second & High	1941 All
BT 162114	Shift Rail-Low & Reverse-Without OD	1941 thru 1950 All
BT 162115	Shift Rail-Second & High	1941-1942 All
BT 162116	Housing-Speedometer Gear-Without OD-VD or HDM	1941 thru 1950 All
BT 162117	Gasket-Speedometer Gear Housing-Without OD	1941 thru 1950 All
F 162118	Oil Seal-Speedometer Gear Housing-Without OD	1941 thru 1950 All
BT 162119	Companion Flange-Transmission-Use Without OD	1941 thru 1950 All
BT 162120	Housing-Speedometer Gear-Without Overdrive- With VD or HDM	1941 thru 1947 All
162121	Shift Shaft-Transmission (Use 166184)	1941 All,1942 without HDM
BT 162122	Clip-Handy Shift Wire Casing-af Clutch Housing-LHD	1941 thru 1947 All
162123	Lever-Shift Shaft-Inner (Use 164477)	1941 All
162124	Lever-Transmission Shift Shaft-Outer-LHD (Use 162778)	1941 All,1942 Without HDM
162126	Use 163251	
BT 162128	Selector Lever & Shaft Assy-Transmission	1941 thru 1950 All
BT 162130	Bushing-Transmission Shift Selector Shaft	1941 thru 1950 All
162131	Use 163231	
BT 162133	Lever-Trans Shift Selector-Outer	1941 thru 1947 All
BT 162134	Shaft-Trans Lock	1941 thru 1947 All
BT 162135	Lever-Trans Lock Shaft	1941 thru 1946 All
BT 162138	Rod-Trans Lock Shaft Lever	1941 All
162140	Cover & Cross Lever Assy-Transmission-RHD (Use 164475)	1941 All
162142	Use 163813	
TF 162144	Gasket-Transmission Cover	1941-1942 All
BT 162146	Cross Lever-Trans Cover-RHD	1941 thru 1947 All
BT 162148	Pivot-Trans Cross Lever-RHD	1941 thru 1947 All
BT 162149	Vent-Transmission Case	1941 thru 1950 All
C 162152	Manifold Assy-Exhaust	1941 thru 1947 8 Cyl
EM 162154	Tube-Exhaust Manifold Choke Heater	1941 thru 1947 8 Cyl
162163	Gear-Camshaft-Std (Use 165907)	1941-1942-1946 All
162164	Gear-Camshaft-.004 O/S (Use 165907)	1941-1942-1946 All
162165	Gear-Crankshaft (Use 166310)	1941-1942 All
F 162166	Lever Assy-Master Cylinder Operating	1941 thru 1947 All
CF 162169	Cable Assy-Hand Brake	1941-1942 exc Del,1946-1947 All
C 162172	Wire, Casing & Bracket Assy-Handy Shift-LHD (Use 164512)	1941 All
BT 162174	Anchor Brkt-Handy Shift Wire Casing-At Transmission-RHD	1941 thru 1947 All
BT 162175	Rod Assy-Handy Shift Tube to Transmission-LHD	1941-1942 exc Del,1946-1947 All
162177	Crankshaft Assy (Use 166205)	10P,11,12,18,10-20 With L Engine,21,28
EM 162180	Thrust Washer-Camshaft	30 thru 1947 All,1948 thru 1950 8 Cyl
EM 162181	Bearing-Cam shaft-# 1	1941 thru 1947 6 Cyl
EM 162182	Bearing-Camshaft-k2	1941 thru 1947 6 Cyl
EM 162183	Bearing-Camshaft-k3	1941 thru 1947 6 Cyl
EM 162184	Bearing-Camshaft-#1	1941 thru 1950 8 Cyl
EM 162185	Bearing-Camshaft-#2	1941 thru 1950 8 Cyl
EM 162186	Bearing-Camshaft-#3	1941 thru 1950 8 Cyl
EM 162187	Bearing-Camshaft-#4	1941 thru 1950 8 Cyl
EM 162188	Bearing-Camshaft-115	1941 thru 1950 8 Cyl
162191	Housing Assy-Clutch-LHD (Use 165153)	1941-1942 All
162192	Housing Assy-Clutch-RHD (Use 165154)	1941-1942 All
BT 162195	Shaft-Clutch Shifter Yoke	1941 thru 1947 LHD,1948 thru 1950 All
BT 162196	Shaft-Clutch Shifter Yoke-RHD	1941 thru 1947 All
162197	Use 163235	
162199	Boot-Handy Shift Wire-Trans End (Use 300829)	1941 thru 1947 All
C 162200	Frame Assy-LHD	10T,10P exc Cv.10C UCo-UCpe
C 162204	Frame Assembly-LHD	11-12 exc CvSed-Station
C 162206	Frame Assembly-LHD	14-15 exc Cv-Station
C 162208	Frame Assembly-LHD	18P
C 162209	Frame Assembly-LHD	17
162211	Spring-Clutch Pedal Assisting-LHD-Without VD-OD-HDM (Use 166317)	10-20 With L Engine,11,14,15,17,21 thru 28
C 162213	Side Member Assy-Frame-RH	10T,10P exc Cv,10C UCo-UCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 166214	Side Member Assy-Frame-LH	10T,10P exc Cv,10C UCo-UCpe
C 162223	Side Member Assy-Frame-LH	18C,28C,58,178
C 162237	Reinf Assy-Frame Side Member-LH-Front	11-12-14-15 exc Cv-Station,17,18,51 thru 54-171 thru 174 exc CvBro
C 162238	Reinf Assy-Frame Side Member-RH-Front	11-12-14-21-22-24 CvSed,11-14-21 Station,1946-1947 CvBro
C 162239	Reinf Assy-Frame Side Member-LH-Front	11-12-14-21-22-24 CvSed,11-14-21 Station,1946-1947 CvBro
C 162248	Engine Support Cross Member Assy-Rear-Frame	1941-1942-1946-1947 All
C 162250	Rear Cross Member-Frame	1941-1942 exc Cab-CabPu-Station,1946-1947 exc Cab-CabPu
C 162251	Brace Front Member-Frame-RH	1941-1942 exc CvSed-Station,1946-1947 exc CvBro
C 162252	Brace Front Member-Frame-RH	1941-1942 CvSed-Station,1946-1947 CvBro
C 162253	Brace Front Member-Frame-LH	1941-1942 exc CvSed-Station,1946-1947 exc CvBro
C 162254	Brace Front Member-Frame-LH	1941-1942 CvSed-Station,1946-1947 CvBro
BZ 162256	Plate-Frame Brace	1941-1942 CvSed-Station,1946-1947 CvBro
C 162257	Brace Rear Member-Frame-RH	10 thru 15-20 thru 25 exc CvSed-Station,1946-1947 exc CvBro
C 162258	Brace Rear Member-Frame-LH	10 thru 15-20 thru 25 exc CvSed-Station,1946-1947 exc CvBro
C 162259	Brace Rear Member-Frame-RH	1941-1942 CvSed-Station,1946-1947 CvBro
C 162260	Brace Rear Member-Frame-LH	1941-1942 CvSed-Station,1946-1947 CvBro
C 162261	Brace Rear Member-Frame-RH	17,18,27,28,58,178
C 162262	Brace Rear Member-Frame-LH	17,18,27,28,58,178
C 162263	Reinf-Frame Brace to Side Member-RH-Front	1941-1942 CvSed-Station,1946-1947 CvBro
C 162264	Reinf-Frame Brace to Side Member-LH-Front	1941-1942 CvSed-Station,1946-1947 CvBro
C 162265	Reinf-Frame Brace to Side Member-RH-Rear	1941-1942 CvSed-Station,1946-1947 CvBro
C 162266	Reinf-Frame Brace to Side Member-LH-Rear	1941-1942 CvSed-Station,1946-1947 CvBro
BZ 162267	Reinf-Frame Brace to Side Member-RH-Rear-Short	1941-1942 CvSed-Station,1946-1947 CvBro
BZ 162268	Reinf-Frame Brace to Side Member-LH-Rear-Short	1941-1942 CvSed-Station,1946-1947 CvBro
C 162271	Cross Member Assy-Frame Rear Axle	10 thru 18,1942-1946-1947 Cab-CabPu
BZ 162273	Bracket-Frame Rear Spring Front-RH	1941-1946-1947 All
BZ 162274	Bracket-Frame Rear Spring Front-LH	1941-1942-1946-1947 All
BZ 162275	Gusset-Frame Rear Spring Front Bracket-RH	18C,10C exc UCo-UCpe,20C,28C,58,178
BZ 162276	Gusset-Frame Rear Spring Front Bracket-LH	18C,10C exc UCo-UCpe,20C,28C,58,178
C 162281	Reinf Assy-Frame Brace	1941-1942 CvSed-Station,1946-1947 CvBro
BZ 162294	Link Assembly-Pedal to Master Cylinder	1941-1942 exc Del,1946-1947 All
BZ 162299	Link-Pedal to Master Cylinder	1941-1942-1946 All
BZ 162299	Link-Clutch Control	10 Del 1946-1947 All
162337	Carrier & Gear Set Assy-Differential-4 1/9 to 1 (Use 166333)	10 thru 17,18P
162338	Carrier & Gear Set Assy-Differential-4 5/9 to 1 (Use 166226)	1941 All
C 162339	Carrier & Gear Set Assy-Differential-4 7/8 to 1	10,18C
162344	Housing Complete-Rear Axle (Use 164505)	10T-10P with Std Engine
C 162345	Housing Complete-Rear Axle-Less Brake Shoes	10C
162346	Housing Complete-Rear Axle-Less Brake Shoes (Use 164506)	10C,11,12,18,10 with L Engine
162347	Housing Complete-Rear Axle-Less Brake Shoes (Use 164507)	14,15,17
162353	Hub Cap-Wheel-Outer (Use 164537)	12,14,15,17,11 Station
*C 162356	Carrier & Cap Assy-Differential 4 1/9 to 1 and 45/9 to 1	1941 thru 1947 All
C 162357	Carrier & Cap Assy-Differential-4 7/8 to 1	10,18C,20,28C
BT 162360	Shift Shaft Lever Assy-Outer-Trans-RHD	1941-1942-1946-1947 All
BX 162362	Shim-Rear Axle Drive Pinion Rear Bearing-.002	1941 thru 1947 All
BX 162363	Shim-Rear Axle Drive Pinion Rear Bearing-.003	1941 thru 1947 All
BX 162364	Spacer-Drive Pinion Bearing-for 4 1/9 or 4 5/9 Axle	1941 thru 1947 All
BX 162365	Spacer-Rear Axle Drive Pinion Bearing-for 4 7/8 Axle	10,18C,20,28C
A 162366	Guard-Engine-RH-Std Engine	10,20 With OD exc Cv,20 Cv
A 162367	Guard-Engine-RH-L Engine	10,20 With OD exc Cv,20 Cv
A 162368	Guard-Engine-RH	11,12,18,21-22-28 With OD exc Cv-Station,21-22 Cv-Station,1946-1947 CvBro,51-52-58-171-172-178 With OD
A 162369	Guard-Engine-RH	14,15,17,24-25-27 With OD exc Cv,24 Cv,53,54,173,174
BT 162378	Rod Assy-Handy Shift Tube to Transmission-RHD	1941-1942-1946-1947 All
BZ 162385	Lever Assy-Brake Pedal-LHD	1941-1942-1946-1947 All
BZ 162386	Lever Assy-Brake Pedal-RHD	1941-1942-1946-1947 All
*BZ 162389	Shaft Assy-Pedal Lever-LHD	1941 All
BZ 162391	Bracket Assy-Pedal-LHD	1941-1942-1946-1947 All
BZ 162393	Bracket-Pedal-RHD	1941-1942-1946 All
C 162394	Case Assy-Transmission-Use with OD	1941 All
BT 162396	Oil Tube-Transmission Case-Use with OD	1941 thru 1950 All
F 162397	Mainshaft-Transmission-Use With OD	1941-1946-1947 All
BT 162398	Shift Rail-Trans Low & Reverse-Use With OD	1941-1942-1946-1947 All
F 162399	Hub Cap-Wheel-Outer-For 15" Wheel	11 thru 18

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

233

Part No.	Name	Models
*C 162405	Tank Assy-12 1/2 Gal	10-20 3Cpe-ClubCpe-CvSed
162408	Tank Assy-12 1/2 Gal (Use 162405)	10 UCo,10T,10P Sed-2Sed,20 Sed-2Sed-UCo
162411	Tank Assy-16 1/2 Gal (Use 166254)	1941-1942 3Cpe-ClubCpe-CvSed
162414	Tank Assy-16 1/2 Gal (Use 166254)	11-12-14 Sed-2Sed,17,18,1942 All
162417	Use 162419	
BZ 162419	Filler Neck Assy-Gasoline Tank	1941-1942 exc Cab-CabPu-Del,1946-1947 Bro-Sed
BZ 162421	Grommet-Gas Tank Filler Neck to Body	1941-1942 exc Cab-CabPu,51,52,53,54,171 thru 174
BZ 162423	Strap-Gasoline Tank-Enamel	1941-1942 exc Cab-CabPu,58,178
C 162424	Heat Deflector and Strap Assy-Gas Tank	1941-1942 With 16 1/2 Gal Tank,51,52,53,54,171 thru 174
162431	Use 162518	
162432	Use 162519	
EM 162433	Tube-Carb Choke Heat Conductor	1941 thru 1947 8 Cyl
162434	Shaft Assy-Propeller-Without Overdrive (Use 162435)	10-20 with Std Engine
C 162435	Shaft-Propeller-Without Overdrive	10-20 with Std Engine,51,52,53,54,171 thru 174
C 162437	Shaft-Propeller-With Overdrive	10,11,12,14,15,20 thru 25,51,52,53,54,171 thru 174
162438	Shaft Assy-Propeller-Without OD (Use 162435)	10-20 With L Engine,11,12,14,15,21 thru 25
162439	Shaft-Propeller-Without Overdrive (Use 162435)	10-20 With L Engine,11,12,14,15,21 thru 25
C 162440	Shaft Assy-Propeller-With OD	17,18,27,28
C 162441	Shaft-Propeller-With Overdrive	17,18,27,28,58,178
C 162442	Spring Assembly-Rear	10 3Cpe-ClubCpe 10 2Sed
C 162443	Spring Assembly-Rear	10 Sed-ClubCpe
162444	Spring Assembly-Rear (Use 164021)	11-12 3Cpe-ClubCpe
162445	Spring Assembly-Rear (Use 162446)	11-12-14 2Sed-CvSed,14-15 3Cpe-ClubCpe
C 162446	Spring Assembly-Rear	11-12-14 Sed,11-12-14-15 ClubCpe
162447	Spring Assembly-Rear (Use 165946)	17,18 Sed-CA
162448	Spring Assembly-Rear (Use 163663)	10,11,18,20,21,28
F 162449	Hub Cap-Wheel-Outer-Small	
BT 162452	Speedometer Gear-Transmission-Use Without Overdrive	1941 thru 1947 All,1948-1949-1950,With 7.10 x 15 tires
BT 162453	Speedometer Gear-Transmission-Use With OD	1941-1946-1947 All
BT 162454	Speedometer Pinion-Transmission-15 Teeth	1941 thru 1950
BT 162455	Speedometer Pinion-Transmission-16 Teeth	1941 thru 1947
BT 162456	Speedometer Pinion-Transmission-17 Teeth	1941 thru 1947
BT 162457	Speedometer Pinion-Transmission-18 Teeth	1941-1942
BT 162458	Pinion-Trans Governor-4 5/9-With VD-OD or HDM	1941-1942-1946 All,1947 All With 6.50 or 7.00 tires
BT 162459	Lock Ring-Trans Governor Pinion-With VD-OD or HDM (Pkg 10)	1941 thru 1950 All
BT 162465	Housing Assy-Speedometer Gear-Without OD-VD or HDM	1941-1942-1946-1947 All
BT 162466	Housing Assy-Speedometer Gear-With VD or HDM and Without OD	1941 thru 1950 All
BT 162467	Bushing-Trans Speedometer Gear Housing-With VD or HDM and Without OD	1941 thru 1950 All
162468	Cylinder & Pistons Assy (Use 166263)	1941-1942 6 Cyl
BT 162472	Lever and Link Assy-Trans Shift Shaft-Outer-RHD	1941-1942-1946-1947 All
BX 162478	Dust Shield-Brake Drum	1941-1942 6 Cyl,51,52,171,172
BX 162479	Dust Shield-Brake Drum	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950
BZ 162480	Rivet-Brake Drum Wheel Pilot	1941 thru 1950 All
BZ 162481	Cover-Brake Drum Inspection Hole	1941 thru 1950 All
162484	Use 164098	
162485	Use 164099	
162486	Use 166235	
C 162487	Stay Rod-Radiator	10 exc Del,11,12,18,20,21,22,28,1946-1947 6 Cyl
C 162488	Stay Rod-Radiator	1941-1942-1946-1947 8 Cyl
BZ 162497	Terminal-Horn Button to Connector Wire-Upper	1941 All
BZ 162498	Insulator-Horn Button to Connector Wire Terminal Upper	1941 All
162499	Use 163391	
BZ 162517	Contact Spring-Horn Button-For 17" Wheel	10,11,18,17 7Sed,20,28,51,53,58,171,173,178,481,483,491,493,500,501,503
EM 162518	Carburetor Assy-Without Dash Pot	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
EM 162519	Carburetor Assy-Without Dash Pot	1941-1942-1946-1947 8 Cyl
EM 162520	Gauge Assy-Oil Level	1941-1942-1946-1947 6 Cyl
EM 162521	Gauge Assy-Oil Level	1941-1942-1946-1947 8 Cyl
BZ 162522	Tube Assy-Rear Axle Tee to RH Wheel	1941 All
BZ 162523	Tube Assy-Rear Axle Tee to LH Wheel	1941 All
162524	Cover-Pedal Pad-Gray (Use 165819)	1941-1942 with Gray Trim
162525	Cover-Pedal Pad-Brown (Use 165819)	1941-1942 With Tan Trim
162526	Cover-Pedal Pad-Green (Use 165819)	10 thru 17 with Green Trim
C 162529	Cable Assy-Hand Brake	10 Del
C 162530	Coil Spring-Front-Light Scale	10T,10P,10 UCo-UCpe,11,12,20T,20P,21,22,51,52,171,172,178 Station
C 162531	Coil Spring-Front-Light Scale	18
C 162532	Coil Spring-Front	14,15,RH for 17-27,24,25,53,54,173,174

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 162533	Coil Spring-Front-LH	17,27
BM 162534	Bearing-Crankshaft-Lower #1	1941 6 Cyl
BM 162535	Bearing-Crankshaft-Lower #2	1941 6 Cyl
BM 162536	Bearing-Crankshaft-Lower #3	1941 6 Cyl
BM 162537	Bearing-Crankshaft-Lower #5	1941-1946-1947 All,1948 thru 1950 8 Cyl
MF 162538	Bearing Assy-Crankshaft #1-Reamed	1941-1942-1946-1947 6 Cyl
MF 162539	Bearing Assy-Crankshaft #2-Reamed	1941-1942-1946-1947 6 Cyl
MF 162540	Bearing Assy-Crankshaft #3-Reamed	1941-1942-1946-1947 6 Cyl
MF 162541	Bearing Assy-Crankshaft #5-Reamed	1941 thru 1950 8 Cyl
C 162543	Tank Assy-Gasoline-16 1/2 Gal	1941-1942 Cab-CabPu,10 Del,11-14-21 Sta,58,178
BZ 162544	Neck Assy-Gasoline Tank Filler	1941-1942 Cab-CabPu,10 Del,11-14-21 Sta,58,178
BZ 162546	Strap-Gasoline Tank-Enamel	1941-1942 Cab-CabPu,10 Del,58,178
162548	Master Cylinder Assy-Brake (Use 166276)	1941-1942 All
F 162551	Shock Absorber-Rear	80,81,82,88,1939 All
BX 162552	Backing Plate Assy-Front Brake-RH	1941-1942 6 Cyl,51,52,171,172
BX 162553	Backing Plate Assy-Front Brake-LH	1941-1942 6 Cyl,51,52,171,172
BZ 162554	Backing Plate Assy-Rear Brake-RH	1941-1942 6 Cyl,51,52,171,172
BX 162555	Backing Plate Assy-Rear Brake-LH	1941-1942 6 Cyl,51,52,171,178
BX 162560	Backing Plate Assy-Front Brake	1941-1942 8 Cyl,53,54,58,173,174,178,500
BX 162561	Backing Plate Assy-Rear Brake-RH	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
BX 162562	Backing Plate Assy-Rear Brake-LH	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
F 162568	Pivot Nut-Brake Adjusting Screw	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
F 162569	Socket-Brake Adjusting Screw	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
162572	Pin-Brake Shoe Cable Lever to Shoe (Use 163839)	10,11,12,18
BX 162573	Lever-Brake Shoe Cable-RH	1941-1942 8 Cyl,53,54,58,171,174,178,1948 thru 1950 All
BX 162574	Lever-Brake Shoe Cable-LH	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
BX 162575	Pin-Brake Shoe Cable Lever to Shoe	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
BX 162576	Strut-Brake Shoe Cable Lever	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
F 162577	Spring-Cable Lever Strut to Shoe	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
BX 162578	Lever & Pin Assy-Brake Shoe Cable-RH	1941-1942 6 Cyl,51,52,171,172
BX 162579	Lever & Pin Assy-Brake Shoe Cable-LH	1941-1942 6 Cyl,51,52,171,172
BX 162582	Retainer-Brake Shoe Cable Lever to Shoe Pin	1941-1942 6 Cyl,51,52,171,172
BT 162583	Shift Sleeve Assy-Trans Synchronizer-Second Design	1941 All
162584	Shift Sleeve-Trans Synchronizer-Second Design (Use 162583)	1941 All
BT 162585	Ring-Trans Synchronizer-Second Design	1941 All
BO 162588	Knob Assy-Starter and Lighting Switch	10 Del
BO 162588	Knob Assy-Inst Panel VD Switch	1941 All
BO 162588	Knob Assy-Inst Panel Dome Light Switch	10 Del
BO 162588	Knob Assy-Hyd Top Lift Switch	1941 CvSed
162590	Switch-VD Shift Rail (Use 164408)	1941 All
162591	Anchor Pin-Brake (Use 302630)	1941 thru 1948 All
BT 162592	Bracket-Overdrive Throttle Switch-LHD	1941 All
BT 162593	Relay-Overdrive-Dash-With VD	1941 All
162594	Switch-Overdrive Throttle (Use 164438)	1941 All,1942-1946 RHD
162595	Relay-Overdrive-Dash Brace (Use 164184)	1941 All
BT 162596	Switch-Overdrive Control	1941 thru 1947 All
BT 162597	Anchor Bracket-Overdrive Control Wire Casing	1941-1942-1946-1947 All
BT 162598	Lever-Overdrive Control	1941-1942-1946-1947 All
F 162599	Plate-Brake Anchor Pin Shoe Guide	1941 thru 1948 All
162613	Engine Assy-Std-9" Clutch (Use 164815)	10 Without OD
162614	Engine Assy-Std-For 10" Clutch (Use 164815)	10 With or Without OD
162615	Engine Assy-L-For 9" Clutch (Use 164815)	10-11 Without OD
162616	Engine Assy-L-For 10" Clutch (Use 164815)	10-11 With OD,12
162618	Engine Assy-(Use 164815)	18
162619	Engine Assy (Use 164820)	14
162620	Engine Assy (Use 164820)	15,17
162622	Engine Assy (Use 164815)	10 Del
162625	Tube Assy-Brake Master Cyl to Frame Tee (Use 165014)	10,20
F 162626	Bushing-Spindle Supp Arm-Lower-.010 0/S	1941 thru 1950 All
MF 162627	Bearing-Camshaft-#1-.004 0/S	10,11,12,18,20,21,22,28,1946-1947 6 Cyl
MF 162628	Bearing-Camshaft-#2-.004 0/S	10,11,12,18,20,21,22,28,1946-1947 6 Cyl
MF 162629	Bearing-Camshaft-#3-.004 0/S	10,11,12,18,20,21,22,28,1946-1947 6 Cyl
MF 162630	Bearing-Camshaft-#1-.004 0/S	1941 thru 1950 8 Cyl
MF 162631	Bearing-Camshaft-#2-.004 0/S	1941 thru 1950 8 Cyl
MF 162632	Bearing-Camshaft-#3-.004 0/S	1941 thru 1950 8 Cyl
MF 162633	Bearing-Camshaft-#4-.004 0/S	1941 thru 1950 8 Cyl
MF 162634	Bearing-Camshaft-#5-.004 0/S	1941 thru 1950 8 Cyl
162635	Muffler Assy (Use 166204)	38 thru 1941-1942 6 Cyl exc 90
162636	Cap-Horn Button-Upper-18" Wheel (Use 165678)	1941 All
BO 162638	Clip-Wiring	1941-1942-1946-1947 All,1950 CvBro
C 162639	Spring Assy-Rear	10 Cab. Pu-Del
BZ 162641	Strap-Gasoline Tank	11-14 Station,15C Station
BT 162651	Gasket-Overdrive to Transmission Case	1941-1942-1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 162652	Support Member Assy-Overdrive	10-11-12-20-21-22 exc Cv-Sta,18,28,51-171 exc CvBro,52,58,172,178
C 162654	Support Member Assy-Overdrive	10-11-12-20-21-22 Station-CvSed,51-171 CvBro
C 162656	Support Member Assy-Overdrive	14-15-17-24-25-27 exc CvSed,53,173,54-174 exc CvBro
C 162657	Support Member Assy-Overdrive	14-24 CvSed,54-174 CvBro
162660	Overdrive Assy-(Use 164411)	1941 All
EM 162670	Cap-Crankshaft Bearing-#1	1941-1942-1946-1947 6 Cyl
EM 162671	Cap-Crankshaft Bearing-#2	1941-1942-1946-1947 6 Cyl
EM 162672	Cap-Crankshaft Bearing-#3	1941-1942-1946-1947 6 Cyl
EM 162673	Cap-Crankshaft Bearing-#1	1941 thru 1950 8 Cyl
EM 162674	Cap-Crankshaft Bearing-#2	1941 thru 1950 8 Cyl
EM 162675	Cap-Crankshaft Bearing-#3	1941 thru 1950 8 Cyl
EM 162676	Cap-Crankshaft Bearing-#4	1941 thru 1950 8 Cyl
EM 162677	Cap-Crankshaft Bearing-#5	1941 thru 1950 8 Cyl
EM 162679	Cable Holder Assy-Ignition-Rear	1941-1942-1946-1947 8 Cyl
162682	Hub Complete-Front (Use 166295)	1941-1942 6 Cyl
162683	Hub Complete-Front (Use 166296)	1941-1942 8 Cyl
C 162684	Hub Complete-Rear	10T-10P-20P With Std Engine,20T With Std Eng exc UCo-UCpe
162685	Hub Complete-Rear (Use 166297)	10C,11,12,18,10-20 With L Engine,20 UCo-UCpe,21,22
C 162686	Hub Complete-Rear	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950
CF 162698	Cable Assy-Rear Brake	1941-1942 exc 17-27,51 thru 54,171 thru 174
CF 162699	Cable Assy-Rear Brake	17,18,27,28,58,178
BZ 162708	Clamp-Muffler-Rear (Tail Pipe for 18P)	10T,10P,11,12,10 UCo-UCpe,18P,20T,20P,21,22,51,52,171,172
BZ 162709	Clamp-Muffler-Rear	1941-1942-1946-1947 8 Cyl
BZ 162710	Support Brkt-Assy-Muffler Clamp-Front	10T,10P,11,12,18P,10 UCo-UCpe,20T,20P,21,22,51,52,171,172
BZ 162710	Support Brkt Assy-Exhaust Pipe	1941-1942-1946-1947 8 Cyl
BZ 162712	Support Assy-Muffler Clamp-Rear	10T,10P,11,12,10 UCo-UCpe,18P,20T,20P,21,22,51,52,171,172
BZ 162714	Support Assy-Muffler Clamp-Rear	1941-1942-1946-1947 8 Cyl
BZ 162715	Support-Tail Pipe Clamp	14,15,17,24,25,27
162720	Pipe Assembly-Exhaust (Use 166292)	10T,10P,11,12,10 UCo-UCpe,20T,20P,21,22
CF 162724	Pipe Assembly-Exhaust	18C,10 Cab-CabPu-Del,20C,28,58,178
CF 162726	Pipe Assembly-Exhaust	14,15,24,25,53,54,173,174
CF 162728	Pipe Assembly-Exhaust	17,27
EM 162732	Cover-Exhaust Pipe	1941-1942-1946-1947 6 Cyl
EM 162733	Cover-Exhaust Pipe-Front	1941-1942-1946-1947 8 Cyl
EM 162734	Cover-Exhaust Pipe-Rear	1941-1942-1946-1947 8 Cyl
CF 162741	Pipe-Tail	10T,10P,11,12,10 UCo-UCpe
CF 162743	Pipe-Tail	14,15,17 ---.
CF 162745	Pipe-Tail	IQ Cab-CabPu-Del,20C
CF 162746	Pipe-Tail	18C,28C,58,178 exc Station
BZ 162747	Support Assy-Tail Pipe Clamp-Front	18,28,58,178
BZ 162748	Clamp-Tail Pipe-Front	18,28,58,178
BZ 162749	Bushing-Steering Gear Jacket Tube	1941-1942 All
C 162751	Steering Gear Assy-LHD	1941-1942-1946-1947 8 Cyl
C 162752	Steering Gear Assy-RHD	1941-1942-1946-1947 8 Cyl
162753	Jacket Tube Assy-Steering Gear (Use 165626)	10 exc Del,11,18,20-21-28 Without DI
C 162755	Jacket Tube Assy-Steering Gear	12,22 Without DI
162757	Jacket Tube Assy-Steering Gear (Use 165634)	14,15,17,24 Without DI
BZ 162759	Button Assy-Horn-Walnut Brown	10,11,18,17 7 Sed
162760	Wheel Assy-Steering-17" (Use 162934)	10,11,18,17 7 Sed
C 162761	Wheel Assy-Steering-18" Black Plastic	11,12,14,15,17
C 162762	Wheel Assy-Steering-18" Gray Plastic	10,11,18
BZ 162763	Escutcheon-Horn Button-Walnut Brown	10,11,18,17 7 Sed
BZ 162764	Button Assy-Horn	1941 All
BZ 162765	Button Assy-Horn	10,11,18
BZ 162766	Button-Horn-For 18" Black Wheel	12,14,15,17
162767	Button-Horn-Tan 18" Gray Wheel (Use 165677)	10,11,18
BZ 162768	Ring-Horn Button-For 18" Wheel	1941-1946-1947 All
BZ 162769	Silencer-Horn Button Ring	1941-1946-1947 All
BZ 162770	Contact Cup-Horn Button-For 18" Wheel	1941-1946-1947 All
BZ 162771	Contact Spring-Horn Button-For 18" Wheel	1941-1946-1947 All
162772	Use 163754	
162773	Use 163757	
C 162776	Head Assy-Cylinder	10-20 With Std Engine
BT 162778	Lever and Pin Assy-Trans Shift Shaft-LHD	1941 thru 1947 Without HDM
BT 162779	Pin-Trans Shift Shaft Lever-LHD	1941 thru 1947 Without HDM
BZ 162781	Fabric-Muffler Clamp Rear Support	1941-1942-1946-1947 8 Cyl
BZ 162801	Cross Shaft & Brkt Assy-Clutch Control-LHD	1941-1942 exc Del,1946-1947 All
BZ 162802	Bracket-Clutch Control Cross Shaft-LHD	1941-1942-1946-1947 All
BZ 162806	Pad-Clutch Cross Shaft Coupling Lever-LHD	1941 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
162807	Link Assy-Clutch Control-LHD (Use 45235)	10 exc Del,11,12,18
162808	Use 45236	
BT 162809	Lock Plate-Countershaft and Reverse Shaft-With OD	1941-1942-1946-1947 All
BZ 162811	Pedal Assy-Clutch-LHD	1941-1942-1946-1947 All
BZ 162813	Cross Shaft & Brkt Assy-Clutch Control-RED	1941-1942-1946-1947 6 Cyl
BZ 162814	Cross Shaft & Brkt Assy-Clutch Control-RHD	1941-1942-1946-1947 8 Cyl
BZ 162817	Brkt-Clutch Cross Shaft-RHD	1941-1946-1947 All
BT 162818	Shaft & Lever Assy-Shifter Yoke Shaft-RHD	1941-1942-1946-1947 All
BT 162819	Lever-Clutch Shifter Yoke Shaft Vac Control Lever-RHD	1941-1942-1946-1947 All
162820	Tube & Fulcrum Brkt Assy-Handy Shift-LED- Painted (Use 164435-70581)	10,11,113,20,21,28
162821	Tube & Fulcrum Brkt Assy-Handy Shift-LHD- Plated (Use 164436 & 70581)	12,14,15,17,22 thru 27
C 162822	Tube & Fulcrum Brkt Assy-Handy Shift-RED-Plated	12,14,15,17,22 thru 27,52,54,172,174
162824	Brkt-Handy Shift-Upper-Plated (Use 165664)	12-14-22-24 Without DI
BT 162826	Grommet-Handy Shift to Trans Rod End	1941 thru 1947 All LHD,1948-1949-1950 All exc With HDM
BT 162827	Pin-Handy Shift to Trans Rod End-LHD	1941-1942 All
BT 162828	Spacer Handy Shift to Trans Rod-LHD	1941-1942-1946-1947 Without HDM
CF 162831 Pr	Wheel Assy-16 x 4.50	10,11,12,14,10 Sp,20,21,22,24,51,53,171,173
162832	Wheel Assy-16 x 4.50 (Use 166488)	10C,18
CF 162833 Pr	Wheel Assy-16 x 5.00	15,17
BZ 162834	Pipe Assy-Gas Tank to Fuel Pump	10,11,12,20C,21 Station
BZ 162835	Pipe Assy-Gas Tank to Fuel Pump	18,28C,58,178
BZ 162836	Pipe Assy-Gas Tank to Fuel Pump-LHD	14,15
BZ 162837	Pipe Assy-Gas Tank to Fuel Pump-RED	14,15
BZ 162838	Pipe Assy-Gas Tank to Fuel Pump-LHD	17
BZ 162839	Pipe Assy-Gas Tank to Fuel Pump-RED	17
BZ 162842	Tube Assy-Frame Tee to Rear Axle Hose	10,20
BZ 162843	Tube Assy-Frame Tee to Rear Axle Hose	11,12,14,15,21 thru 25,51 thru 54,171 thru 174
BZ 162844	Tube Assy-Frame Tee to Rear Axle Hose.	17,18,27,28,58,178
BZ 162847	Cross Shaft & Pedal Lever Assy-Clutch-LHD	1941-1942 exc Del,1946-1947 All
BZ 162848	Cross Shaft & Pedal Lever Assy-Clutch-RHD	1941-1942-1946 All
162849	Case & Brkt Assy-Ignition Lock-LHD (Use 164295)	1941-1942 All
BZ 162851	Fabric-Muffler Clamp Support-Front	10T,10P,11,12,18P,10 UCo-UCpe,20T,20P,21.22,51, 52,171,172
BZ 162851	Fabric-Exhaust Pipe Clamp Support	1941-1942-1946-1947 8 Cyl
*BM 162852	Distributor Assembly	1941-1942-1946-1947 8 Cyl
*BM 162853	Coil Assembly-Ignition-6 Volt	1941-1942 6 Cyl exc Del,1946-1947 All
*BM 162854	Coil Assembly-Ignition-6 Volt	1941 thru 1947 8 Cyl
BM 162855	Coil Assembly-Ignition-12 Volt	10,11,12,18,1946-1947 6 Cyl
BM 162856	Coil Assembly-Ignition-12 Volt	14,15,17,53,54,173,174
*BM 162857	Starting Motor & Solenoid-6 Volt	1941-1942-1946-1947 6 Cyl
BM 162859	Starting Motor & Solenoid-12 Volt	1941-1946-1947 All
162862	Pedal Complete-Accelerator-LHD-Gray (Use 165816)	1941-1942 with Gray Trim
162863	Pedal Complete-Accelerator-LHD-Brown (Use 165816)	1941-1942 with Tan Trim
162864	Pedal Complete-Accelerator-LHD-Green (Use 165816)	10 thru 17 with Green Trim
162866	Switch-VD Governor (Use 164409)	1941 All
162867	Switch-Overdrive Governor (Use 164409)	1941 All
BZ 162868	Washer-VD Trip Lever	1941 thru 1950 All
BZ 162871	Anchor Brkt Assy-Accelerator Pedal-LHD	1941 thru 1947 All
BZ 162874	Rod-Acc Pedal to Bellcrank-LHD-Without OD	10,11,12,18,22-28 Without VD or HDM,1946-1947 6 Cyl Without VD-OD-HDM
BZ 162876	Rod-Acc Pedal to Bellcrank-LHD	14,15,17
BZ 162877	Bellcrank-Acc Pedal Link Bellcrank-LHD	10 thru 18,20-21-22-28-51-52-58-171-172-178 Without OD-VD-HDM
BZ 162878	Support -Acc Pedal Link Bellcrank-LHD	10 thru 18,20-21-22-28-51-52-58-171-172-177 Without OD-VD-HDM
BZ 162879	Rod-Acc Cross Shaft Operating-LHD-Without VD	10,11,12,18,1942-1946-1947 6 Cyl Without OD-HDM
BZ 162880	Rod-Acc Cross Shaft Operating-LHD-Without VD	14,15,17
*BZ 162881	Cross Shaft & Support Assy-Accelerator-LHD	10-20 With Std Engine,18,28 Without OD-HDM
BZ 162882	Cross Shaft & Support Assy	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl Without OD-VD-HDM
BZ 162883	Cross Shaft & Support Assy-Accelerator-LHD	14-15-17
BZ 162891	Spring-Ace Cross Shaft Anti-Rattle-LHD	1941-1942-1946-1947 All
BZ 162892	Rod-Acc Cross Shaft to Carburetor-LHD	10,11,12,18,20,21-28-51-52-58-171-172-178 Without OD-VD-HDM
BZ 162893	Rod-Acc Cross Shaft to Carburetor-LHD	14,15,17
BZ 162894	Bellcrank-Throttle Control Manifold	10 with Std Eng-18 Without VD
162897	Use 164597	
162898	End-Acc Pedal to Bellcrank Rod-LED-Without OD or VD (Use 163446)	1941 All
BO 162899	Fuse Block Assy	1941 thru 1947 Without HDM

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	162911 Clip-Hub Cap (Use 153173)	1941 All
BZ	162914 Housing Assy-Steering Gear-LHD	14,15,17,1946-1947 8 Cyl
BZ	162915 Housing Assy-Steering Gear-RHD	14,15,17,1946-1947 8 Cyl
BZ	162918 Shaft & Roller Tooth Assy-Steering Gear-LHD	1941-1942-1946-1947 8 Cyl
BZ	162919 Shaft & Roller Tooth Assy-Steering Gear-RHD	14,15,17,1946-1947 8 Cyl
BZ	162922 Roller Bearing-Steering Gear Shaft	1941-1942-1946-1947 8 Cyl
BZ	162923 Spacer-Steering Gear Shaft Bearing	1941-1942-1946-1947 8 Cyl
	162924 Lever, Tube & Rod Assy-Handy Shift (Use 164418 & 70581)	10 thru 18,20,21,28
BT	162928 Clip-Handy Shift Casing-on Starter Stud-RHD	1941-1942-1946-1947 All
BT	162929 Clip-Handy Shift Casing-On Speedo Housing-RHD	1941 thru 1947 All
BT	162930 Wire,Casing & Brkt Assy-Handy Shift-RHD	1941-1942-1946-1947 All
C	162943 Wheel-Steering-17"-Gray	10,11,18,17 7Sed
C	162944 Wheel-Steering-17"-Green	10,11,18,17 7Sed
	162945 Button Assy-Horn-Gray-17" Wheel (Use 162759)	10,11,18,17 7Sed
	162946 Button Assy-Horn-Green-17" Wheel (Use 162759)	10,11,18,17 7Sed
BZ	162947 Escutcheon-Horn Button-Gray-For 17" Wheel	10,11,18,17 7Sed
BZ	162948 Escutcheon-Horn Button-Green-For 17" Wheel	10,11,18,17 7Sed
BO	162950 Horns & Brkt Assy-Electric Air Type	1941 All
BO	162952 Horn Assy-Short-6 Volt	1941 All
BO	162953 Horn Assy-Long-6 Volt	1941 All
BO	162954 Horn Assy-Short-12 Volt	1941 All
BO	162955 Horn Assy-Long-12 Volt	1941 All
BO	162957 Relay-Horn-6 Volt	1941-1942 All
BO	162958 Relay-Horn-12 Volt	1941 All
	162962 Camshaft (Use 166195)	10-20 With Std Engine
BO	162964 Switch-Headlamp Dimmer	1941 All
	162965 Use 162011	
F	162967 Spring Assy-Brake Master Cyl Piston	1941 thru 1950 All
F	162969 Check Valve Assy-Brake Master Cylinder	1941 thru 1950 All
	162980 Shaft & Rear Joints Assy-Propeller-With OD (Use 162435)	10-20 With Std Engine
	162981 Shaft & Rear Joints Assy-Propeller-With OD (Use 162437)	10,11,12,14,15,20 thru 25
	162982 Shaft & Rear Joints Assy-Propeller-Without OD (Use 162435)	10-20 With L Engine,11,12,14,15,21,22,24,25
	162983 Shaft & Rear Joints Assy-Propeller-With OD (Use 162441)	13,17,18,27,28
EM	162984 Metering Rod-Carburetor-Pkg	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
EM	162985 Metering Rod-Carburetor-Std	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
EM	162986 Metering Rod-Carburetor-1st Leaner	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
EM	162987 Metering Rod-Carburetor-2nd Leaner	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
EM	162988 Metering Rod-Carburetor-3rd Leaner	10-20 With L Engine,11,12,21,22,1946-1947 6 Cyl
EM	162989 Metering Rod-Carburetor-Pkg	14,15,17
EM	162990 Metering Rod-Carburetor-Std	14,15,17
EM	162991 Metering Rod-Carburetor-1st Leaner	14,15,17
EM	162992 Metering Rod-Carburetor-2nd Leaner	14,15,17
EM	162993 Metering Rod-Carburetor-3rd Leaner	14,15,17,24-25-27-53-54-173-174 1st Leaner
BT	162997 Bracket-OD Throttle Switch-RHD	1941-1942-1946 All
	162998 Use 156678	
EM	162999 Decalcomania-Valve Cover	10-20 With Std Engine,1946-1947 6 Cyl,481,482
BO	163004 Wire Assy-Dimmer Relay to Jet Block-6 1/2"	10 Del
	163013 Tension Spring-Throttle Control Cross Shaft Lever-RHD (Use 164597)	1941 All
BO	163017 Wire Assy-Rear Junction to Junction Block	1941-1942 CvSed,1946-1947 CvBro With DI
BO	163019 Wire Assy-Inst Harness to Rear Jet	1941-1942 CvSed,1946-1947 CvBro
BO	163021 Wire Assy-Rear Jet to Stop Lamp Connector	1941-1942 CvSed,1946 CvBro
	163027 Spring Assy-Rear (Use 161939)	11-12-14 Sed
BZ	163028 Anchor Bracket Assy-Accelerator-Pedal	10 Delivery
BZ	163033 Wire Assy-VD Ace Switch to Relay	1941 with OD
BZ	163035 Wire Assy-OD Throttle Sw to Relay	1941 With VD and OD
BZ	163036 Wire Assy-Charge Regulator to Dash Relay	1941 With VD and OD
BZ	163038 Wire Assy-OD Throttle Sw to Connector	1941 with VD and OD
BO	163045 Wire Assy-Panel Sw to VD Harness	1941 All
BO	163045 Wire Assy-Connector to Ft Door Switch	52-54-172-174 Sed
BO	163047 Wire Assy-Fuse Block to Front Dome Light	12-14-17 Sed
C	163049 Spring Assy-Rear-Heavy Scale	11-12 3Cpe-ClubCpe
BO	163050 Wires & Loom Assy-Generator	10,11,12,18
BO	163051 Wires & Loom Assy-Generator	14,15,17
BO	163056 Wire-Regulator to Horn Relay	1941 All
BO	163058 Wire Assy-Horn Relay to Horn	1941 All
BO	163060 Wire Assy-Relay to Horn	1941 All
BO	163072 Wire Assy-Coil to Distributor-Braid Covered	10-11-12-18 Without OD,20,21,22,28,1946-1947 6 Cyl
	163074 Wire Assy-Coil to Distributor-(Use 164166)	14-15-17 Without OD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
EM 163092	Wire Assy-Coil to Distributor-High Tension	1941-1942-1946-1947 8 Cyl
BO 163098	Wire Assy-Regulator (B) to Vibrator Horn	10T,10C,18
BO 163118	Wire Assy-Top Left Switch to Solenoid	1941 CvSed
BO 163125	Wire Assy-Coil to Distributor-With OD	10 exc Del,11,12,18
BO 163126	Wire Assy-Coil to Distributor-With OD	1941-1942 8 Cyl
BO 163130	Wire Assy-Dome Lamp Sw to F Dome Lamp	10-11 Sed
BO 163155	Wire Assy-License Lamp	1941-1942 Sed-2Sed-UCo,1946-1947 Bro-Sed
BO 163157	Wire Assy-License Lamp	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 3Cpe-ClubCpe
BO 163161	Wire Assy-Inst Harness to Rear Jct-With DI	1941-1942 CvSed,1946-1947 CvBro
BO 163167	Wire Assy-Inst Harness to Rear Junction	1941 All
BZ 163169	Wire Assy-Coil Lock to VD Panel Switch	1941-1942-1946-1947 All
BO 163171	Wire Assy-Coil Lock to Starter-Use Without VD	10 thru 18,1942-1946-1947 Without HDM
BO 163175	Harness-Direction Indicator-LHD	1941 All
BO 163176	Harness-Direction Indicator-RHD	1941 All
BO 163181	Wire Assy-Bonnet Lamp Conn to Lamp-LH	1941 All
BO 163183	Wire Assy-Bonnet Lamp Conn to Lamp-RH	1941-1946 All
BO 163185	Wire Assy-Fuse Block to Clock	1941-1942-1946-1947 All
BO 163197	Wire Assy-Jot Block to Fender Lamp Connector	1941 All
BO 163199	Wire Assy-License Lamp	1941-1942 CvSed,1946-1947 CvBro
BO 163202	Harness-Instrument-RHD	1941 All
BO 163203	Insulator-Electric Clock Fuse	1941 thru 1949 All
	163204 Use 163613	
BZ 163205	Rod-VD Valve Cam Threaded Sleeve-LHD	1941 All
BZ 163207	Rod-VD Bellcrank to Coupling Lever-LHD	1941-1942-1946-1947 All
BZ 163208	Bracket-VD Accelerator Switch-LHD	1941 All
BZ 163209	Stud-VD Accel Switch Brkt-LHD	1941,1942 RHD,1946-1947 All
BZ 163209	Stud-HDM Mtg Brkt & Carb Oil Bath Air Cleaner	483,484,493,494,503,504
BZ 163211	Rod Assy-VD Acc Sw to Bellcrank-Without OD	10,11,12,18
BZ 163213	Rod-Vac Cl Acc Switch to Bellcrank-LHD	1941 All
BZ 163214	Rod Assy-VD Acc Sw to Bellcrank	14,15,17
	163216 Harness-Vacumotive Drive (Use 163291 & 163045)	1941 All
BO 163217	Switch-Hydraulic Top Lift	1941-1942 CvSed,1946-1947 CvBro
BZ 163219	Rod Assy-VD Valve Lever Cam Threaded Sleeve	10,11,12,18
BZ 163220	Cylinder Assy-VD-LHD	1941-1942-1947 All
BT 163231	Set Screw-Shift Shaft Bushing	1941 thru 1950 All
BO 163232	Harness-Instrument	10 Del
	163234 Shaft & Lever Assy-Clutch Shifter Yoke- With VD (Use 165397)	1941 thru 1947 All
BT 163235	Coupling Lever-Clutch Shifter Yoke-With VD-LHD	1941 thru 1947 All
BZ 163236	Harness-Overdrive-RHD	1941 All
BO 163237	Defroster Kit-Recirculating Heater	1941-1942 All
BO 163238	Coupling Defroster Hose-Recirculating Heater	1941 All
	163240 Hose -Defroster-22-1/2" Taupe-Custom & DeLuxe (Use 301187)	1941 All
	163241 Hose-Defroster-21" Brown (Use 164237)	1941 All
	163242 Hose-Defroster-21" Gray (Use 164236)	1941 All
	163243 Hose-Defroster-21" Green (Use 164236)	1941 All
	163245 Hose-W/Shield Defroster-34" (Use 164235)	1941-1942 Recirculating Heater
	163246 Hose-W/Shield Defroster-22-1/2"-Walnut Brown (Use 301187)	1941-1942 Recirculating Heater
BT 163251	Seal-Transmission Shift Shaft	1941 thru 1948 All
BZ 163252	Pedal Complete-Accelerator-Gray-RHD	1941-1942 With Gray Trim
BZ 163253	Pedal Complete-Accelerator-Brown-RHD	1941-1942 With Tan Trim
	163254 Pedal Complete-Accelerator-Green-RHD(Use 163252).	1941 All
	163260 Seal-Water Pump Shaft (Use 155290)	1941-1942-1946 All
BZ 163262	Clip-Acc Pedal Return Spring-RHD	1941 thru 1949 All,501 thru 504
BZ 163263	Link-Acc Pedal to Bellcrank-RHD	1941 thru 1947 All
BZ 163264	Bellcrank-Acc Pedal Link-RHD	1941 thru 1947 All
BZ 163265	Rod-Acc Cross Shaft Operating-RHD-Without OD	1941 thru 1947 All
BZ 163267	Rod-Acc Cross Shaft Operating-RHD	1941 All,1942-1946-1947 With OD
BZ 163269	Cross Shaft Assy-Accelerator-RHD	10-20 With L Engine,11,12,21,22,51,52,58,171,172,178
BZ 163270	Cross Shaft Assy-Accelerator-RHD	1941-1942 8 Cyl,53,54,173,174
BZ 163273	Rod-Acc Cross Shaft to Carburetor-RHD	1941-1942-1946-1947 6 Cyl
BZ 163275	Rod-Ace Cross Shaft to Carburetor-RHD	1941-1942-1946-1947 8 Cyl
BZ 163278	Cover Assy-Rear Spring-RH Rear	10T,10P,20T exc UCo-UCpe,20P
BZ 163279	Cover Assy-Rear Spring-LH Rear	10T,10P,20T exc UCo-UCpe,20P
BZ 163286	Rod-Acc Pedal to Bellcrank-LHD With OD	10,11,12,18
BZ 163288	Rod-Ace Pedal to Bellcrank-LHD With OD	14,15,17
BT 163290	Vacumotive Drive Kit-Use Without OD	10,11,12,18
BZ 163291	Harness-Vacumotive Drive	1941 All
F 163292	Vacumotive Drive Kit-Use Without OD	14,15,17
F 163923	Gasket Kit-Transmission	1941-1942 All
C 163300	Housing Assy-Overdrive	1941-1942-1946-1947 All
BT 163302	Gasket-Overdrive Housing	1941-1942-1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 163304	Adapter-Overdrive Housing	1941-1942-1946-1947 All
BT 163305	Solenoid Assembly-Overdrive	1941-1942-1946-1947 All
BT 163307	Gasket-Overdrive Solenoid Base	1941-1942-1946-1947 All
BT 163308	Base Assy-Overdrive Solenoid	1941-1942-1946-1947 All
BT 163310	Stationary Gear-Overdrive	1941-1942-1946-1947 All
BT 163311	Plate-Overdrive Stationary Gear	1941-1942-1946-1947 All
BT 163312	Sleeve-Overdrive Governor Pinion	1941-1942-1946-1947 All
163313	Use 163349	
163314	Sleeve-Overdrive Clutch (Use 301939)	1941-1942-1946-1947 All
BT 163316	Thrust Washer-Overdrive Clutch Hub-Rear	1941-1942-1947 All
BT 163317	Pilot Bushing-OD Main Drive	1941-1942-1946-1947 All
BT 163318	Snap Ring-OD Main Shaft-.087	1941 thru 1950 All
BT 163319	Snap Ring-OD Main Shaft-.090	1941 thru 1950 All
BT 163320	Snap Ring-OD Main Shaft-.093	1941 thru 1950 All
BT 163321	Snap Ring-OD Main Shaft-.096	1941 thru 1950 All
BT 163322	Snap Ring-OD Main Shaft Bearing-.087	1941 thru 1950 All
BT 163323	Snap Ring-OD Main Shaft Bearing-.090	1941 thru 1950 All
BT 163324	Snap Ring-OD Main Shaft Bearing-.093	1941 thru 1950 All
BT 163325	Snap Ring-OD Main Shaft Bearing-.096	1941 thru 1950 All
BT 163326	Lever-Overdrive Interlock	1941-1942-1946-1947 All
BT 163328	Plunger-Overdrive Interlock Lever	1941-1942-1946-1947 All
BT 163329	Plunger-Overdrive Interlock Lever-Long	1941-1942-1946-1947 All
BT 163330	Plunger-Overdrive Interlock Lever-Long	1941-1942-1946-1947 All
BT 163331	Plunger-Overdrive Interlock Lever-Long	1941-1942-1946-1947 All
BT 163332	Plunger-Overdrive Interlock Lever-Long	1941-1942-1946-1947 All
BT 163333	Plunger-Overdrive Interlock Lever-Long	1941-1942-1946-1947 All
BT 163334	Shaft Assy-Overdrive Control	1941-1942-1946-1947 All
BT 163337	Shifter Rail-Overdrive	1941 All
BT 163338	Fork-Overdrive Shifter Rail	1941-1942-1946-1947 All
BT 163339	Spring-Overdrive Shifter Rail Retractor	1941-1942-1946-1947 All
BT 163340	Screw-Overdrive Shifter Rail Stop	1941-1942-1946-1947 All
BT 163341	Guide Pin-OD Shifter Rail Fork	1941-1942-1946-1947 All
BT 163348	Pawl-Overdrive Stationary Gear	1941-1942-1946-1947 All
BT 163349	Hub Assy-Overdrive Clutch	1941-1942-1946-1947 All
BT 163352	Plug-OD Housing Adapter	1941 thru 1950 All
163355	Core Assy-Radiator (Use 164098)	10,20
163356	Core Assy-Radiator (Use 166235)	14,15,17,24,25,27
163357	Core Assy-Radiator (Use 164099)	11,12,18,21,22,28
BO 163358	Knob-Heater Reversing Switch	1941-1942 Recirculating-Heater
BZ 163362	Rad Assy-Brake Pedal	10 Del
BZ 163366	Clutch Pedal Lever	10 Del
BZ 163369	Shaft Assy-Pedal Lever	10 Del
BZ 163370	Cross Shaft & Brkt Assy-Clutch Control-LHD	10 Del
BZ 163372	Cross Shaft & Pedal Lever Assy-Clutch Control LHD	10 Del
163373	Link Assy-Brake Pedal to Master Cylinder-LHD (Use 164427)	10 Del
163374	Link Assy-Clutch Control-LHD (Use 164427)	10 Del
BZ 163376	Cushion-Gas Tank Filler Neck to Body	1941-1942 exc Cab-CabPu-Del,51,52,53,54,171 thru 174
BZ 163376	Sleeve-Ace Pedal to Bellcrank Rod	1941 thru 1949 All
BT 163379	Rod Assy-Handy Shift Tube to Trans-LHD	10 Del
BO 163381	Brkt-Automatic Battery Filler to Dash-Upper	1941-1942-1946-1947 All
BO 163382	Brkt-Automatic Battery Filler to Dash-Lower	1941-1942-1946-1947 All
C 163383	Drag Link Assy-LHD	10 Del
BZ 163389	Reinf-Gas Tank Filler Neck Cushion	1941 exc Cab-CabPu-Del-Station,51,52,53,54,171 thru 174
C 163390	Steering Gear Assy-LHD	10 Del
BZ 163391	Sleeve-Horn Button Wire Terminal-Upper	1941 thru 1950 All
BZ 163392	Ball Arm-Steering Gear-LHD	10 Del
BZ 163393	Bolt-Battery Hold Down	10 Del
C 163394	Jacket Tube & Bushing Assy-Steering Gear	10 Del
C 163396	Main Column & Worm Assy-Steering Gear-LHD	10 Del
BZ 163397	Stay-Rod-Radiator	10 Del
C 163398	Main Column Tube-Steering Gear	10 Del
BO 163410	Clip-Wire to Roof Panel	1941-1942-1946-1947 All
F 163411	Shoes & Lining Assy Package-For 2 Wheels	1941-1942 6 Cyl,51,52,171,172
F 163412	Shoes & Lining Assy Package-For 2 Wheels	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
F 163413	Lining & Rivets Package-Brake-For 2 Wheels	1941-1942 6 Cyl,51,52,171,172
F 163414	Lining & Rivets Package-Brake-For 2 Wheels	1941-1942 8 Cyl,53,54,58,173,174,178,1948 thru 1950 All
BZ 163415	Cover Assy-Rear Spring-RH-Front-HS Spring	10T,10P,10 UCo-UCPe,20T,20P
BZ 163416	Cover Assy-Rear Spring-LH-Front-HS Spring	10T,10P,10 UCo-UCPe,20T,20P
BZ 163417	Cover Assy-Rear Spring-RH-Rear-HS Spring	10T,10P,10 UCo-UCPe,20T,20P
BZ 163418	Cover Assy-Rear Spring-LH-Rear-HS Spring	10T,10P,10 UCo-UCPe,20T,20P
BZ 163434	Brkt & Levers Assy-Acc Pedal to Relay Bracket-LHD.	10 Del

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 163439	Link-Ace Pedal to Bellcrank Relay-LHD	10 Del
BZ 163441	Rod-Ace Pedal to Bellcrank	10 Del
BT 163442	Spring-Trans Low & Reverse Lock Ball & Camshaft	1941 thru 1949 All,503,504,1950 All with OD HDM or SMD
BZ 163443	Rod-Ace Cross Shaft Operating-LHD	10,11,12,18
BZ 163444	Rod-Ace Cross Shaft Operating-LHD-With VD	14,15,17
163445	Use 162883	
BZ 163446	End-Acc Pedal to Bellcrank Rod-LHD	10 thru 18,20-21-22-28-51-52-58-171-172-178 Without VD-OD-HDM
*BZ 163447	Bellcrank Assy-Acc Pedal Link-LHD-With VD	10 thru 18
BZ 163449	Wire Kit-Horn	1938 thru 1940 All
BO 163454	Oil Reservoir Assy-Hyd Top Lift	1941 CvSed
BO 163458	Tube Assy-Top Lift Oil Reservoir	1941 CvSed
BO 163459	Brkt Assy-Hyd Top Motor Mounting-Front	1941 CvSed
BO 163461	Bracket-Hyd Top Motor Mounting-Rear	1941 CvSed
C 163462	Frame Tube Assy-Hyd Top Lift	1941 CvSed
BO 163464	Tee-Hyd Top Lift Tube-Rear	1941 CvSed
BO 163466	Tube Assy-Hud Top Lift-Rear-Short	1941 CvSed
BO 163468	Hose-Hyd Tube to Cylinder-15-1/2"	1941 CvSed
BO 163469	Flexible Hose-Hyd Top Power Unit-17"	1941 CvSed,1946-1947 Sed
BO 163470	Hose-Hyd Top Tube to Cylinder-20-1/2"	1941 CvSed
C 163471	Tube Assy-Hyd Top-Rear-Long-Upper	1941 CvSed
C 163473	Tube Assy-Hyd Top-Rear-Long-Lower	1941 CvSed
BM 163481	Bracket-Generator Support-For 163841	1941-1946-1947 AU
BM 163482	Bracket-Generator Adjusting-For 163841	1941-1946-1947 All
C 163500	Transmission and Overdrive Assy-LHD	10 With L Engine,11 thru 18
163503	Transmission Assy-Less OD-LHD (Use 164062)	10 With Std Engine
F 163504	Shoes and Lining Kit-Brake-Two Wheels	1938 thru 1940 with 9-1/16" Brakes
F 163505	Lining and Rivets Kit-Brake Shoes-Two Wheels	1938 thru 1940 With 9-1/16" Brakes
F 163506	Shoes and Lining Kit-Brake-Two Wheels	1938 thru 1940 With 10-1/16" Brakes
F 163507	Lining and Rivets Kit-Brake Shoes-Two Wheels	1938 thru 1940 With 10-1/16" Brakes
F 163508	Shoes and Lining Kit-Brake-Two Wheels	1938 thru 1940 With 11-1/16" Brakes
F 163509	Lining and Rivets Kit-Brake-Shoes-Two Wheels	1938 thru 1940 With 11-1/16" Brakes
F 163526	Gasket Kit-Valve Chamber Cover	1934 thru 1947 8 Cyl
BO 163532	Bushing-Horn Trumpet Support	1941 Electric Air Horns
BZ 163539	Piston-Shock Absorber	10,11,12,20,21,22,24,25,51,171
BZ 163541	Washer-Shock Absorber Piston Support	10,11,12,20,21,22,24,25,51,171
BZ 163542	Spacer-Shock Absorber Piston Support Washer	10,11,12,20,21,22,24,25,51,171
BZ 163543	Cyl End and Valve Assy-Shock Absorber-Front	1941-1942 3Cpe-ClubCpe
BZ 163544	Cyl End and Valve Assy-Shock Absorber-Rear	1941-1942 3Cpe-ClubCpe
BZ 163545	Cyl End and Valve Assy-Shock Absorber	10-11-20-21 exc Cpe,28
163546	Cyl End and Valve Assy-Shk Abs (Use 161032)	10-11-20-21 exc Cpe,10-20 UCc-UcCpe,18P
163550	Use 163754	
BZ 163553	Bracket-Radiator Stay Rod	1941 All
C 163554	Spring Assy-Rear	10 Sed-CvSed
BO 163555	Motor Assy-Hudson Weather-Control	1941 thru 1949 All
BO 163556	Fan and Blower Assy-Hudson Weather-Control	1941 thru 1950 All
163557	Switch Assy-HWC (Use 164241)	1941 All
BO 163558	Jumper Wire Assy-Hudson Weather-Control-LHD	1941 thru 1947 All
BO 163559	Door Assy-Hudson Weather-Control	1941 thru 1950 All
BO 163560	Gasket-Hudson Weather-Control Motor	1941 thru 1948 All
BO 163561	Spring-Hudson Weather-Control Door	1941 thru 1950 All
BO 163562	Elbow-HWC Defroster Outlet	1941 thru 1950 All
163563	Knob-Hudson Weather-Control Door (Use 140278)	1941-1942 All
BO 163564	Set Screw-HWC Heater Fan	1941 thru 1950 All
BO 163565	Bowden Wire-Hudson Weather-Control	1941 thru 1947 All
BO 163566	Hose-Hudson Weather-Control-51" Long	1941-1942-1946 All
BO 163567	Drain Hose-Hudson Weather-Control	1941 thru 1950 All
BO 163568	Filter-Hudson Weather-Control Fresh Air	1941 thru 1947 All
163569	Core Assy-Hudson Weather-Control (Use 166736)	1941 thru 1950 All
BZ 163570	Kit-Rear Shock Absorber	1940 thru 1947 Cab-CabPu
C 163571	Stay Rod Kit-Radiator	40,41,43,48
C 163572	Stay Rod Kit-Radiator	44,45,47
BO 163573	Elbow Assy- Top Lift Power Unit	1941 CvSed
BT 163580	Oil Seal-OD Governor Switch	1941 All
BT 163590	Vacumotive Drive Kit-Use With OD	1941 All
BT 163591	Vacumotive Drive Kit-Use With OD	1941 All
BO 163600	Horn Kit-Twin Air Type	10T,10C,18
BO 163609	Control Arm Kit-Hudson Weather-Control	1941 thru 1949 All
F 163610	Repair Kit-Brake Master Cylinder	1941-1942-1946-1947 All
BT 163611	Cover Assy-OD Governor Switch	1941 All
BZ 163613	Rod Assy-VD Threaded Sleeve	1941 All
BO 163650	Sleeve-Hudson-Weather-Control Bowden Wire	1941 thru 1948 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 163651	Wire & Knob Assy-OD Control	1941-1942-1946-1947 All
BZ 163658	Center Bolt-Spring	For Springs 161936-40,166370-71-75-76-77-78
163659	Use 161135	
C 163660	Spring Assy-Rear	10 2Sed
163661	Spring Assy-Rear (Use 165946)	11-12-14-15 2Sed-ClubCpe
163662	Spring Assy-Rear (Use 166747)	11-12-14-15 Sed-CvSed
C 163663	Spring Assy-Rear	17,18P
C 163664	Leaf-Spring-Rebound	For Springs 161933-4-5,164026-7-8
CF 163665	Leaf-Spring-Rebound	For Springs 161936-40
C 163666	Leaf-Spring-Rebound	For Springs 161937-8-9
C 163667	Leaf-Spring-Rebound	For Springs 162442-3-4-163554-163660
CF 163668	Leaf-Spring-Main	For Springs 161936-40-163735,164022-3-4-5-9, 164033,165933,165935,166370-71-75-76-77-78
163669	Leaf-Spring-Main (Use 158848)	For Springs 162030-1
CF 163670	Leaf-Spring-Main	For Springs 161933-4-5-162442-3-4-163554-163660, 164018-19-20-21-26-27-28
C 163671	Leaf-Spring-#2	For Springs 161933-4-5-162442-3-4-163554-163660, 164018-19-20-21-26-27-28
C 163672	Leaf-Spring-#2	For Springs 161936-40,164022-3-4-5,164029,164033
C 163673	Leaf-Spring-#2	For Springs 162030-1
C 163674	Leaf-Spring-#3	For Springs 161936-40
C 163676	Leaf-Spring-#3	For Springs 161933-4-5,164026-7-8
C 163676	Leaf-Spring-#4	For Springs 161936-40,164026-7-8
C 163677	Leaf-Spring-#3	For Springs 162442-3-4-163554-163600
C 163678	Leaf-Spring-#4	For Springs 161933-4-5,164026-7-8
C 163679	Leaf-Spring-#4	For Springs 162442-3-4-163554-163660
BZ 163720	Clip-Spring Rebound-#2	For Spring 162639
BZ 163722	Center Bolt-Spring	For Spring 162639
BZ 163723	Center Bolt-Spring	For Spring 163735
BO 163725	Bottle-Battery Filler	1941-1942-1946-1947 All
BT 163727	Taximeter Kit-4-1/9 Axle	1941-1942-1946-1947 With 6.00-6.25-6.50 or 7.00 tires
BT 163728	Taximeter Kit-4-5/9 Axle	1941-1942-1946-1947 With 5.50 or 6.00 tires
C 163729	Kit-Extra Spring Leaf	For Springs 162442-3-4,163554,163560,164018-19-20- 21,165078
BZ 163731	Clip-Spring Rebound-#1-#4	For Springs 161937-8-9-162446-7-163735-163661, 164049,30-32,165075
BO 163733	Wire Assy-Top Lift Motor	1941 CvSed
C 163735	Spring Assy-Rear	11-14 Station
BZ 163739	Gasket-VD Shift Rail Switch	1941 thru 1950 All
C 163750	Frame Assy-RHD	10CUCo-UCpe,10T-10P exc CvSed
BO 163752	Hose-Top Lift Power Unit	1941 CvSed
BO 163753	Tee-Top Lift Tube	1941 CvSed
BZ 163754	Wire Assy-Horn Button to Connector	10 thru 18
BZ 163755	Terminal-Horn Button Wire-Upper	1941 thru 1950 All
BZ 163756	Insulator-Horn Button Wire Terminal-Upper	1941 thru 1950 All
BZ 163757	Spring-Horn Button Wire-For 18" Wheel	1941 thru 1950 All
C 163758	Tube Assy-Top Lift-Frame	1941 CvSed
BO 163760	Elbow and Screen Assy-Top Power Unit	1941 CvSed
BT 163763	Gear-Speedometer-5 Teeth	1941-1942-1946-1947 With Taxi Speedometer
BT 163764	Pinion-Speedometer-15 Teeth	1941-1942-1946-1947 With Taxi Speedometer
BT 163765	Pinion-Speedometer-17 Teeth	1941-1942-1946-1947 With Taxi Speedometer
BT 163766	Sleeve-Speedometer Pinion	1941-1942-1946-1947 With Taxi Speedometer
BT 163767	Cable Assy-Speedometer	1941-1942-1946-1947 With Taxi Speedometer
BT 163768	Core-Speedometer Cable	1941-1942-1946-1947 With Taxi Speedometer
BT 163769	Clip-Speedometer Cable to Transmission	1941-1942-1946-1947 With Taxi Speedometer
BO 163770	Pump Assy-Top Lift	1941 CvSed
BO 163772	Oil Seal-Pump Houseing	1941 CvSed
BO 163774	Gasket-Pump-Inner	1941 CvSed
BO 163775	Plate-Pump-Rear	1941 CvSed
BO 163776	Gear-Pump Drive	1941 CvSed
BO 163778	Gear-Pump Drive	1941 CvSed
BO 163779	Plate-Pump Inner	1941 CvSed
BO 163780	Washer-Pump	1941 CvSed
BO 163781	Valve Assy-Pump	1941 CvSed
BO 163783	Gasket-Pump Valve Housing	1941 CvSed
BO 163786	Gasket-Valve Outlet Fitting	1941 CvSed
BO 163787	Check Valve Assy-Pump Valve	1941 CvSed
163792	Nut-Rear Brkt to Pump Bolt (Use 12481)	1941 CvSed
F 163793	Gasket-Exhaust Manifold	1937 thru 1947 6 Cyl
BO 163794	Switch Assy-Heater Reversing	1941-1942 Recirculating Heater
BO 163796	Motor Assy-Heater	1941-1942 Recirculating Heater
BO 163797	Fan & Blower Assy-Heater	1941-1942 Recirculating Heater
BO 163799	Jumper Wire Assy-Heater-Fused	1941-1942 Recirculating Heater
BT 163811	Lock Kit-Transmission Shift	1941 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 163812	Battery Filler-Automatic	1941-1946-1947 All
BT 163813	Cover-Assy-Trans-Includes Baffle	1941,1942 Without OD
C 163817	Pipe-Tail	11 Station
C 163818	Pipe-Tail	14 Station
EM 163841	Generator Complete-32 Amp-Special	1941-1946-1947 All
EM 163843	Charge Regulator-For 163841 Generator	1941-1946-1947 All
BO 163847	Filler Cap-Top Oil Reservoir	1941 CvSed
*HA 163851	Kit-Hill Hold	1941-1942-1946-1947 All
BZ 163853	Valve Lever & Rod Guide Assy-Hill Hold	1941-1942-1946-1947 All
BZ 163854	Bracket-Hill Hold Clutch Pedal	1941-1942-1946-1947 All
BZ 163855	U Bolt-Hill Hold Pedal Bracket	1941-1942-1946-1947 All
BZ 163856	Rod-Hill Hold	1941-1942-1946-1947 All
BZ 163857	Camshaft-Hill Hold	1941-1942-1946-1947 All
	163858 Use 163670	
	163859 Leaf-Spring-#3 (Use 163676)	10 UCo-UCpe-Sed
C 163860	Leaf-Spring-#4	10 UCo-UCpe-Sed
C 163872	Leaf-Spring-Main	For Springs #162639-165076
C 163873	Leaf-Spring-#2	For Springs #162639-165076-7
C 163875	Leaf-Spring-#4	For Springs #162639-165076-7
C 163882	Leaf-Spring-Rebound	For Spring #163735
CF 163883	Leaf-Spring-Main	For Springs #163735-163049-165075
C 163885	Leaf-Spring-#3	For Springs #163735
C 163886	Leaf-Spring-#4	For Spring #163735
EM 163891	Generator Complete-35 Amp-#GEA 4803 B	1941-1946-1947 All
BO 163892	Charge Regulator-Generator (Use with 163891)	1941-1946-1947 All
F 163904	Gear Cluster Assy-Trans Countershaft	10 With L Engine,11 thru 18,1948-1949 exc with HDM
F 163905	Gear Cluster Assy-Trans Countershaft	10 With Std Engine,1942-1946-1947 All,1948 With HDM,1949-1950 All
5F 163906	Gear-Trans Main Drive	10 With L Engine,11 thru 18
*F 163907	Gear-Trans Main Drive	10 With Std Engine
*F 163908	Gear-Trans Intermediate	1941 All
	163909 Gear-Trans M/S Low & Reverse (Use 166332)	1941-1942 All
	163920 Main Shaft-Trans (Use 1 each 162053 & 170705)	1941-1942 All
	163921 Main Shaft-Trans With OD (Use 162397)	1941-1942 All
	163922 Gear & Pinion-Rear Axle-4-1/9 to 1 (Use 166188)	1941-1942 All
	163923 Gear & Pinion-Rear Axle-4-5/9 to 1 (Use 166189)	1941-1942 All
F 163924	Gear & Pinion-Rear Axle-4-7/8 to 1	1941-1942 All
BX 163925	Gear-Rear Axle Drive 4-1/9 to 1	1941-1942 All
	163926 Pinion-Rear Axle Drive-4-1/9 to 1 (Use 157531)	1941-1942 All
BX 163927	Gear-Rear Axle Drive-4-5/9 to 1	1941-1942 All
BX 163928	Pinion-Rear Axle Drive-4-5/9 to 1	1941-1942 All
BZ 163929	Gear-Rear Axle Drive-4-7/8 to 1	1941-1942 All
	163931 Shift Rail-Trans Low & Rev With OD (Use 162398)	1941-1942 All
	163932 Shift Rail-Trans Low & Rev-Less OD (Use 162114)	1941-1942 All
	163933 Shift Rail-Trans 2nd & High (Use 162115)	1941-1942 All
	163934 Gear-Differential (Use 166227)	1942 All
	163938 Brg-Crankshaft-Upper-#1 (Use 157964)	1941-1942 6 Cyl
	163939 Brg-Crankshaft-Lower-#1 (Use 162534)	1941-1942 6 Cyl
	163940 Brg-Crankshaft-Upper-#2 (Use 157966)	1941-1942 6 Cyl
	163941 Brg-Crankshaft-Lower-#2 (Use 162535)	1941-1942 6 Cyl.
	163942 Brg-Crankshaft-Upper-#3 (Use 157968)	1941-1942 6 Cyl
	163943 Brg-Crankshaft-Lower-#3 (Use 162536)	1941-1942 6 Cyl
BO 164001	Harness-Instrument-LHD	20,21,28,51,53,58,171,173,178
BO 164002	Harness-Instrument-LHD	22 thru 27,52,54,172,174
BZ 164003	Harness-Chassis	20
BZ 164004	Harness-Chassis	21 thru 28,1946-1947 All
BZ 164005	Tube Assy-HDM Power Unit-Manifold End	20,21,22,28,1946-1947 6 Cyl
BZ 164006	Tube Assy-HDM Power Unit-Manifold End	24,25,27,1946-1947 8 Cyl
BT 164007	Locking Washer-OD, Governor Switch	1942 thru 1950 All
BZ 164008	Tube-HDM Power Unit-Air Cleaner End	20,21,22,28 1946-1947 6 Cyl
BZ 164009	Tube-HDM Power Unit-Air Cleaner End	24,25,27,1946-1947 8 Cyl
BZ 164010	Hose-HDM Intake Tube to Air Cleaner	1942-1946-1947 All
BZ 164011	Clip-HDM Intake Tube-At Manifold Stud	1942-1946-1947 All
BZ 164012	Tube-HDM Power Unit Vacuum-On Frame	1942 All
BZ 164013	Tube-HDM Power Unit Intake-On Frame	1942 All
BZ 164014	Hose-HDM Power Unit Tube Coupling	1942 thru 1950 All
BZ 164015	Clip-HDM Power Unit Tube-at Frame C/M	1942-1946-1947 All
BZ 164016	Clip-HDM Power Unit Tube-at Frame S/M	1942-1946-1947 All
BZ 164017	Tube-HDM Power Unit-At Power Unit	1942-1946-1947 All
C 164018	Spring Assy-Rear-Light Scale	20 3Cpe
	164019 Spring Assy-Rear-Light Scale (Use 163544)	20 ClubCpe
C 164020	Spring Assy-Rear-Light Scale	20 3Sed-ClubCpe
C 164021	Spring Assy-Rear-Light Scale	20 Sed-CvSed
	164022 Spring Assy-Rear-Light Scale (Use 165932)	21-22-24 3Cpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

243

Part No.	Name	Models
164023	Spring Assy-Rear-Light Scale (Use 165932)	21-22-24-25 ClubCpe-2Sed-3Cpe,1946-1947 Bro-3Cpe
164024	Spring Assy-Rear-Light Scale (Use 165934)	21-22-24 Sed-CvSed-ClubCpe,1946-1947 Sed ClubCpe-CvBro
C 164025	Spring Assy-Rear-Light Scale	27 Sed
C 164026	Spring Assy-Rear-Heavy Scale	20 3Cpe-ClubCpe
164027	Spring Assy-Rear-Heavy Scale (Use 163554)	20CvSed-2Sed
C 164028	Spring Assy-Rear-Heavy Scale	20 Sed-UCo-UCpe
164029	Spring Assy-Rear-Heavy Scale (Use 165942)	21-22-3Cpe-ClubCpe,51-52 -171-172 3Cpe-ClubCpe
164030	Spring Assy-Rear-Heavy Scale (Use 165944)	24-25 3Cpe-ClubCpe,21 thru 24 CvSed,53-54-173-174 Cpes,1946-1947 CvBro
164031	Spring Assy-Rear-Heavy Scale (Use 165946)	21-22-24 2Sed,1946-1947 Bro
164032	Spring Assy-Rear-Heavy Scale (Use 165948)	21-22-24 Sed,1946 Sed
C 164033	Spring Assy-Rear-Heavy Scale	27 Sed
BO 164034	Socket Assy-Courtesy Lamp	21 thru 27 Sed-3Cpe-ClubCpe-CvSed,2Sed,52,54,172,174
164035	Loom-1/4"-Hood Lamp Wire (Use 158185)	1942 All
BZ 164036	Loom-3/8"-Generator Wires	1942-1946-1947 All
BT 164040	Cover,Baffle and Clip Assy-Trans-Use With VD,HDM	1942 Without OD
BO 164049	Spacer-Fuse Block-RHD	1942-1946-1947 All
BT 164059	Spacer-Transmission Governor Pinion	1942 thru 1947 All,With OD,VD or HDM,1948-1949- 1950 with VD or HDM But Without OD
C 164062	Transmission Assy-Without OD-HDM	1942-1946-1947 All
C 164063	Transmission Assy-Without OD,with HDM	1942-1946-1947 All
C 164064	Transmission Assy-With OD-Without HDM	1942-1946-1947 All
C 164065	Transmission Assy-With OD-HDM	1942-1946-1947 All
C 164066	Transmission & OD Assy-Without HDM	1942-1946- 1947 All
C 164067	Transmission & OD Assy-With HDM	1942-1946-1947 All
BO 164071	Clip-Coil Distributor Wire Dash	24,25,27,53,54,173,174
BO 164072	Harness-Instrument-RHD	1942-1946 All
BT 164073	Harness-Overdrive-LHD-Body Half	1942 All
BT 164074	Harness-Overdrive-RHD-Body Half	1942 All
BT 164075	Harness-Overdrive-Chassis Half	1942 All
BT 164076	Harness-Vacumotive Drive	1942 All
BZ 164077	Harness-HDM-Body Half	1942-1946-1947 All
BZ 164078	Harness-HDM-Chassis Half	1942 All
BZ 164079	Boot-HDM Harness Trans Sw Plug	1942 thru 1949 All
BZ 164080	Plug-Harness Six Prong	1942-1946-1947 All
BZ 164081	Cap-Harness Plug	1942-1946-1947 All
BZ 164082	Socket-Harness Plug	1942 thru 1949 All
BZ 164083	Cap-Harness Plug Socket	1942-1946-1947 All
164084	Pedal-Complete-Accelerator-LHD (Use 165816)	20P,21 thru 27
BZ 164085	Pedal Complete-Accelerator-RHD	20P,21 thru 27
164087	Cover-Pedal Pad-Dar Green (Use 165819)	20P,21 thru 27
A 164088	Guard-Engine-RH-LHD-Without OD	20 with Std Engine exc CvSed
A 164089	Guard-Engine-RH-LHD-Without OD	20 with L Engine,50
A 164090	Guard-Engine-RH-LHD-Without OD	21 thru 28 exc Cv-Station,1946-1947 exc Cv-Bro-Station
BO 164095	Clip-Wiring	1942-1946-1947 All
BZ 164096	Clip-Wiring-With HDM	1942-1946-1947 All
BZ 164097	Clip-Wiring	1942-1946-1947 All 1948-1949-501 thru 504 with HDM
C 164098	Core Assy-Radiator	20
C 164099	Core Assy-Radiator	21,22,28,51,52,58,171,172,178 -.r
BO 164102	Power Unit Assy-Hydraulic Top	1942 CvSed exc 20T,1946 CvBro
BO 164103	Hose-Hyd Top Power Unit	1942 CvSed exc 20T,1946 CvBro
BO 164104	Tee-Hyd Top Tube	1942 CvSed exc 20T,1946-1947 CvBro
BO 164105	Tube Assy-Hyd Top-Short	1942 CvSed exc 20T,1946-1947 CvBro
C 164106	Tube Assy-Hyd Top-Long	1942 CvSed exc 20T,1946-1947 CvBro
C 164107	Tube Assy-Hyd Top-Long	1942 CvSed exc 20T,1946 CvBro
164108	Use 1 each 163217-164751	
BO 164109	Collar-Hyd Top Operating Switch	1942 CvSed exc 20T
BO 164110	Hose-Top Lift Tube to Cylinder	1942 CvSed exc 20T,1946-1947 CvBro
BO 164127	Terminal-Battery Cable	1936 All
BZ 164129	Bracket-Rear Spring Front (Service for 156839)	89,90
BO 164138	Wires Assy-DI Harness Plug to Fender Lamp Cover	20 thru 28,51 thru 54,171 thru 174
BO 164142	Wires Assy-Connector to Courtesy Lamp	21 thru 27,54-174 CvBro
BO 164144	Wire Assy-Connector to Courtesy Lamp-LH	21-22-24 CvSed
BO 164146	Wires Assy-Regulator (B) to Horn-LHD	20T,20C,28,58,178
164152	Wire Assy-Horn Button to Relay or Conn (Use 301039)	1942-1946-1947 All
BO 164157	Wire Assy-Charge Regulator (B) to Horn	20T,20C
BO 164166	Wire Assy-Coil to Distributor	24,25,27,53,54,173,174
EM 164169	Screw-Vibration Dampener Cap	1946 thru 1950 All
BO 164172	Case & Cover Assy-DI-Painted-LHD	20,21,51,53,171,173
BO 164174	Case & Cover Assy-Direction Indicator-LHD	22 thru 27,52,54,172,174
BO 164176	Switch-Direction Indicator	1942 All,1946-1947 exc 58,178
BO 164177	Case-Direction Indicator-Prime	20,21,51,53,171,173,481,483,491,493

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 164178	Case-Direction Indicator-Plated	22,24,52,54,172,174,482,484,492,494,1950
BO 164179	Cover-Direction Indicator Switch Case	1942 All,1946-1947 exc 58-178,1950
164180	Lever-Direction Indicator Control (Use 301851)	1942 All,1946-1947 exc 58-178
BO 164181	Knob-Direction Indicator Control Lever	1942 All,1946-1947 exc 58-178,1948 thru 1950
BO 164182	Knob Assy-Hyd Top Switch	1942 CvSed exc 20T,1946-1947 CvBro
BO 164183	Knob-Hyd Top Switch	1942 CvSed exc 20T,1946-1947 CvBro
BT 164184	Relay-Overdrive	1942 All
BZ 164185	Rod Assy-VD Threaded Sleeve	20,21,22,28,1946-1947 6 Cyl
BZ 164187	Rod Assy-VD Threaded Sleeve	24,25,27,1946-1947 8 Cyl
BZ 164189	Swivel-VD Throttle Lock Diaphragm Rod-Use with HDM or SMD	1942 thru 1950 All
BZ 164192	Dirt Shield-Drive Master	1942-1946-1947 All
BT 164196	Shifter Rail-Overdrive	1942-1946-1947 All
BT 164197	Sleeve-OD Shifter Rail	1942-1946-1947 All
BT 164198	Spring-OD Shifter Rail Sleeve	1942-1946-1947 All
BT 164199	Pin-OD Shifter Rail Sleeve	1942-1946-1947 All
BT 164201	Cover & Clip Assy-Trans-LHD-With OD	1942-1946-1947 All
BT 164202	Rubber Spacer-Power Unit Mtg Stud-Use With HDM	1942-1946-1947 All
BT 164203	Rubber Washer-Power Unit Mtg Stud-Use With HDM	1942-1946-1947 All
BT 164205	Bracket-Power Unit Mounting-Use With HDM	1942-1946-1947 All
BT 164207	Rod Assy-Shift-Used With HDM	1942-1946-1947 All
BT 164208	Bushing-Shift Rod-Used With HDM	1942 thru 1950 All
BT 164210	Rod-HDM Transfer Diaphragm	1942-1946-1947 All
BT 164211	End-HDM Transfer Diaphragm Rod	1942-1946-1947 All
BT 164212	Sleeve-HDM Transfer Diaphragm Rod	1942-1946-1947 All
BT 164213	Rod-HDM Clutch Switch Operating	1942-1946-1947 All
BT 164214	Rod-HDM Transfer Switch	1942-1946-1947 All
BT 164215	Rod-HDM Selector Switch Operating	1942-1946-1947 All
BT 164217	Rod-HDM Neutral & Limit Switch	1942-1946-1947 All
BT 164218	Swivel-HDM Neutral & Limit Switch Rod	1942 thru 1949 All
BT 164219	Spring-HDM Tension-at Lock Lever	1942-1946-1947 All
BT 164220	Clip-HDM Lock Lever Tension Spring	1942-1946-1947 All
BT 164221	Clip-Accel VD & HDM Rod Retaining	1942 thru 1950 All
BT 164222	Clip-Rod Retaining	1942 thru 1950 All
BZ 164226	Plate-Rear Spring Clip-RH	1942 thru 1950 All exc 178
BZ 164227	Plate-Rear Spring Clip-LH	1942 thru 1950 All exc 178
BZ 164228	Tube Assy-Rear Axle Tee to Right Rear Wheel	1942-1946-1947 All
BZ 164229	Tube Assy-Rear Axle Tee to Left Rear Wheel	1942-1946-1947 All
164234	Defroster Kit-W/ Shield-For Recir.Heater(Use 163237)	1942 All
BO 164235	Hose-W/Shield Defroster-34" Dark Gray	1942 All
164236	Hose-W/Shield Defroster-22-1/2" Dark Gray (Use 301187)	1942 All
BO 164237	Hose-W/Shield Defroster-21"-Dark Gray	1942 thru 1950 All
164238	Switch Assy-Heater Defroster (Use 163794)	1942 All
164239	Knob-Heater Reversing Switch (Use 163358)	1942 All
BO 164241	Switch Assy-Hudson Weather-Control & Underseat Heater	1942 thru 1949 All,1950 with underseat heater
*BM 164247	Generator Complete-Used Without HDM	20 With Std Engine exc 20P CvSed,28,58,178
*BM 164248	Generator Complete-Used Without HDM	20 with L Engine,20P CVsed,21 thru 27, 1946 thru 1949 All exc 178
*BM 164248	Generator Complete-Used With HDM	1942 thru 1949 All
BO 164249	Flasher Switch-Direction Indicator	20 thru 28,51 thru 54,171 thru 174
BT 164252	Shift Shaft-Trans-Used with HDM Thrust	1942-1946-1947 All
BT 164253	Split Thrust Washer-Shift Shaft-Use With HDM	1942-1946-1947 All
BT 164254	Lever Complete-Shift Shaft-Use With HDM	1942-1946-1947 All
BT 164258	Bushing-Shift Shaft Lever Hub-Use with HDM	1942 thru 1950
BT 164260	Shift Shaft Lever-HDM Hand Shift	1942-1946-1947 All
BT 164264	Bushing-Shift Shaft Lever Hub-HDM Hand Shift	1942 thru 1950 All
BT 164265	Pin-HDM Hand Shift Lever Stop	1942-1946-1947 All
BT 164266	Pin-HDM Hand Shift Shaft Lever	1942-1946-1947 All
BT 164268	Hub-Trans Shift Shaft Transfer Key-Used with HDM	1942-1946-1947 All
BT 164269	Key Trans Shift Shaft Transfer-Used with HDM	1942-1946-1947 All
BT 164270	Pin-Trans Shift Shaft Transfer Key to Hub-Used with HDM	1942 thru 1950 All
BT 164271	Lock Lever Assy-Trans Shift-Used with HDM	1942-1946-1947 All
BZ 164273	Spacer-OD Control Wire Anchor Brkt Stud Without HDM	1942-1946-1947 All
C 164275	Wheel Steering-18" Blue Plastic	1942 All
164276	Escutcheon Assy-Strg Wheel-18" Blue (Use 165375)	1942 All
164277	Escutcheon-Strg Wheel-18" Blue (Use 165292)	1942 All
BZ 164280	Ring Assy-Horn-18" Wheel	1942 All
BZ 164281	Ornament-Horn Ring-18" Blue Wheel	1942 All
BZ 164283	Tapped Spacer-Horn Ring-18" Wheel	1942 All
BZ 164284	Silencer-Horn Ring-18" Wheel	1942 All
BZ 164285	Contact Plate-Horn Ring-18" Wheel	1942 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

245

Part No.	Name	Models
BZ 164286	Spacer-Horn Ring Contact Clip-18" Wheel	1942 All
BZ 164287	Spring-Horn Ring-18" Wheel	1942 All
BZ 164288	Retainer-Horn Ring Spring-Lower-18" Wheel	1942 All
BZ 164289	Retainer-Horn Ring Spring-Upper-18" Wheel	1942 All
BZ 164290	Screw-Horn Ring Spring Retainer Upper Spacer to Wheel-18" Wheel	1942 All
BZ 164291	Strip-Wheel to Horn Wire Contact-18" Wheel	1942 All
BZ 164292	Strip-Wheel to Horn Contact	1942 All
BZ 164293	Spring-Horn Ring Spring Retainer Spacer Screw	1942 All
BT 164294	Pinion-Trans Governor-With OD-VD or HDM	1942 thru 1950
BO 164295	Lock Case & Brkt Assy-Ignition-LHD	20 thru 27,1946-1947 All
BO 164296	Lock Case & Brkt Assy-Ignition-RHD	20 thru 27,1946-1947 All
BO 164297	Bezel-Ignition Lock Case	20 thru 27,1946-1947 All
	164300 Frame Assy-LHD (Use 164650)	20T-20P exc Cv
	164301 Frame Assy-RHD (Use 164651)	20T-20P exc Cv
	164303 Frame Assy-LHD (Use 164655)	21-22 exc Cv-Station
	164306 Frame Assy-LHD (Use 164659)	24-25 exc Cv
C 164315	Side Member Assy-Frame-LH	20 CvSed
C 164316	Side Member Assy-Frame-RH	21-22-24-25 exc Cv-Station,51 thru 54-171 thru 174 exc CvBro
C 164317	Side Member Assy-Frame-LH	21-22-24-25 exc Cv-Station,51 thru 54-171 thru 174 exc CvBro
C 164318	Side Member Assy-Frame-RH	21-22-24-CvSed Station,1946-1947 CvBro
C 164319	Side Member Assy-Frame-LH	21-22-24 CvSed-Station,1946-1947 CvBro
C 164336	Cross Member-Frame Rear Axle	1942-1946-1947 exc Cab-CabPu
	164338 Bracket-Frame Rear Stabilizer (Use 165749)	20T,20P,21 thru 28
BZ 164339	Bracket-Frame Running Board	20T,20P,20 thru 27 exc Station,51,52,53,54,171 thru 174
BZ 164340	Manifold Assy-Intake	20 With Std Engine,28
	164341 Manifold Assy-Intake (Use 165911 & 8-771)	20 With L Engine,21,22,1946-1947 6 Cyl
	164343 Manifold Assy-Intake-Cast Iron (Use 166131)	24,25,27,53,54,173,174
BZ 164345	Stud-Intake Manifold	20 With Std Engine,28
BZ 164346	Shaft Assy-Pedal Lever	1942-1946-1947 All
BZ 164348	Bumper-Frame Rear Axle	1942-1946-1947 All
C 164351	Wheel Assy-Steering-17"-Gray	20,28
BZ 164355	Button Assy-Horn-Without Horn Ring-Gray	20,28
	164356 Button Assy-Horn-Without Horn Ring-Russet (Use 164355)	20,28
BZ 164357	Button Assy-Horn-Without Horn Ring-Green	20,28
BZ 164358	Button Assy-Horn-With Horn Ring-17"'-Gray	20,28
BZ 164359	Button Assy-Horn-With Horn Ring-17"-Russet	20,28
BZ 164360	Button Assy-Horn-With Horn Ring-17"-Green	20,28
BZ 164361	Escutcheon Horn Button-17" Wheel-Gray	20,28
BZ 164362	Escutcheon Horn Button-17" Wheel-Russet	20,28
BZ 164363	Escutcheon Horn Button-17" Wheel-Green	20,28
BZ 164364	Trim Ring-Steering Wheel Hub-17" Wheel-Gray	20P
F 164369	Repair Kit-Universal Joint	1936 thru 1950 All
BZ 164370	Contact Plate Assy-Horn Ring-17" Wheel	20,28,51,53,58,171,173,178
BZ 164372	Spacer-Horn Ring Contact Plate-17" Wheel	20,28,51,53,58,171,173,178
BZ 164373	Spring-Horn Ring Contact Plate-17" Wheel	20,28,51,53,58,171,173,178
BZ 164374	Retainer-Horn Ring Contact Plate Spring-17" Wheel	20,28,51,53,58,171,173,178
BZ 164375	Contact Cup-Horn Button-17" Wheel	20,28,51,53,58,171,173,178
BZ 164376	Spring-Horn Button Contact Cup-17" Wheel	20,28,51,53,58,171,173,178
BZ 164377	Retainer-Horn Button Contact Cup Spring-17" Wheel	20,28,51,53,58,171,173,178
BZ 164378	Spring-Horn Button	20,28,51,53,58,171,173,178
BZ 164379	Screw-Horn Button-17" Wheel	20,28,51,53,58,171,173,178
BZ 164380	Ornament-Horn Ring-Gray 17" Wheel	20,28
BZ 164381	Ornament-Horn Ring-Russet-17" Wheel	20,28
BZ 164383	Ring-Horn 17" Wheel	20,28,51,53,58,171,173,178
BO 164385	Block Assy-Fuse-Use With HDM	1942-1946-1947 All
	164387 Use 165028	
BO 164388	Switch-F Domelight Inst Panel & Pillar	20T,20P,21 thru 27,51 thru 54,171 thru 174
BO 164389	Switch-Vacumotive Drive Accelerator	1942 All
	164390 Flywheel Complete (Use 166302)	22,28,20-21 with OD-VD or HDM
	164391 Flywheel Complete (Use 166303)	24,25,27
BZ 164398	Brkt-VD Acc Sw and OD Throttle Sw	1942-1946-1947 All
BZ 164399	Rod-VD Acc Sw and OD Throttle Sw Bellcrank	1942-1946-1947 All
BO 164401	Relay-Air Type Horn-6V	1942 thru 1950
C 164402	Wheel-Steering-18"-Russet	1942 All
C 164403	Wheel-Steering-18"-Green	1942 All
BZ 164404	Tension Spring-VD or HDM Cylinder	1942 thru 1950
BZ 164405	Cyl & Throttle Lock Diaphragm Assy-HDM Clutch Control	1942 All
BZ 164407	Switch-Inst Panel VD	1942-1946-1947 All
BZ 164408	Switch-VD and HDM Shift Rail	1942 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 164409	Switch-VD and OD Governor	1942 All
*C 164411	Overdrive Assembly	1942-1946-1947 All
BT 164412	Power Unit Assy-HDM	1942-1946 All
BZ 164413	Switch Assy-HDM-on Transmission	1942-1946-1947 All
BO 164414	Switch-HDM-on Inst Panel	1942-1946-1947 All
*BO 164415	Switch-HDM Governor	1942 All,500 with SMD
BZ 164417	Hose-VD Connector	1942 thru 1950
C 164418	Lever,Tube & Rod Assy-Handy Shift-LHD	1942 All
C 164419	Lever,Tube & Rod Assy-Handy Shift-RHD	1942 All
164420	Case Assy-Trans Without OD or HDM (Use 165035-165047-165045 LHD,or 165043 RHD)	
164421	Case Assy-Trans-Without HDM-With OD (Use 165039-165047-164201 LHD,or 165048 RHD)	
C 164422	Case Assy-Trans-With HDM-Without OD	1942 All
C 164423	Case Assy-Trans-With HDM and OD	1942 All
BZ 164427	Link Assy-Clutch Control	20,21,22,28,1946-1947 6 Cyl
BT 164428	Pin-Trans Case Shift Lock-With HDM	1942-1946-1947 All
BT 164429	Pin-Trans Case Shift Detent-With HDM	11142-1946-1947 All
BZ 164434	Outlet Unit-Gasoline Tank	20T,20P,21 thru 27 exc Station,51,52,53,54,171 thru 174
C 164435	Tube & Fulcrum Brkt Assy-Handy Shift-Lever-LHD-Painted	20,21,28,51,53,58,171,173,178
C 164436	Tube & Fulcrum Brkt Assy-Handy Shift-LHD-Plated	22,24,25,27,52,54,172,174
BT 164437	Pin-Handy Shift Tube to Trans Rod End-LHD	1942 thru 1947 with HDM,1948-1949-1950 All exc with HDM
BT 164438	Switch-OD Throttle	1942 thru 1949 All
BO 164439	Switch & Wires Assy-Headlamp Dimmer	1942-1946-1947 All
C 164442	Bar Assy-Rear Stabilizer	20P,21 thru 27,1946-1947 All exc Cab-CabPu
164455	Tail Pipe (Use 166294)	20T,20P,20Sp,21 exc Station,22
CF 164457	Tail Pipe	24,25,27,53,54,173,174
BZ 164458	Ornament-Horn Ring-Russet-18" Wheel	1942 All
BZ 164459	Ornament-Horn Ring-Green-18" Wheel	1942 All
164465	Gear-Trans Main Drive (Use 302472)	1942 All
F 164466	Bearing-Trans Main Drive Gear	1942 thru 1950 All
BT 164467	Snap Ring-Trans Main Drive Gear Bearing'	1942 thru 1950 All
F 164468	Intermediate Gear-Trans Mainshaft	1942 thru 1950 All
BT 164469	Shift Sleeve Assy-Trans Synchronizer	1942 thru 1950 All
164470	Shift Sleeve-Trans Synchronizer (Use 164469)	1942-1946-1947 All
164471	Hub-Trans Synch Shift Sleeve (Use 164469)	1942-1946-1947 All
BT 164472	Ring-Trans Synchronizer	1942 thru 1950 All
BT 164473	Spring-Trans Synchronizer	1942 thru 1950 All
164474	Shift Fork-Trans Second & High (Use 303887)	1942 thru 1950 All
BT 164475	Cover & Cross Lever Assy-Trans-RHD-Without OD	1942 All
BT 164477	Lever-Trans Shift Shaft-Inner	1942 thru 1950 All
BT 164478	Shift Plate-Trans Synchronizer	1942 thru 1950 All
164479	Shift Rail-Trans 2nd & high (Use 301356 & 163442)	1942 thru 1949 All
BT 164480	Stop Screw-Trans 2nd & High Shift Rail	1942 thru 1950 All
BT 164481	Lever Assy-Trans Shift Selector-Outer-With HDM	1942-1946-1947 All
BT 164483	Lock Kit-Trans Shift-Without HDM	1942-1946-1947 All
BT 164484	Lock Kit-Trans Shift-With HDM	1942-1946-1947 All
BT 164485	Spacer-Trans Shift Lock Lever-With HDM-LHD	1942-1946-1947 All
BT 164486	Rod-Trans Shift Lock Lever-Without HDM	1942-1946-1947 All
BT 164487	Rod-Trans Shift Lock Lever-With HDM-LHD	1942-1946-1947 All
BZ 164488	Spring-Clutch Shifter Yoke Shaft Coupling Lever	1942-1946-1947 All with HDM
BO 164489	Horns & Brkt Assy-Twin Air Type	20
BO 164490	Horns & Brkt Assy-Twin Air Type	21 thru 28,1946-1947 All
BO 164491	Horn Assy-High Pitch-6 Volt Air Type	1942 thru 1948
BO 164492	Horn Assy-Low Pitch-6 Volt Air Type	1942 thru 1948
BO 164493	Bracket & Brace Assy-Horn-Air Type Horns	20
BO 164494	Bracket & Brace Assy-Horn-Air Type Horns	21 thru 28,1946-1947 All
BO 164498	Spring Plate-Air Type Horn Trumpet Support	1942-1946-1947 All
164499	Wire,Casing & Brkt Assy-Handy Shift-LHD-With HDM (Use 166288)	1942 All
C 164505	Housing Complete-Rear Axle	20T,20P With Std Engine exc UCo-UCpe
C 164506	Housing Complete-Rear Axle	20T UCo-UCpe-20C-21-22-28 With Std,Brakes, 20T-20P with L Engine
C 164507	Housing Complete-Rear Axle	24,25,27,20-21-22-28 with 11" Brakes,53,54,58,173, 174,178,51-52-171-172 with 11" Brakes
C 164512	Wire,Casing & Brkt Assy-Handy Shift-LHD-Without HDM	20,21,28,1946-1947 All
164514	Use 165034	
EM 164515	Air Cleaner-Carburetor-Dry Type-With HDM	20 With Std Engine,28
EM 164516	Air Cleaner-Carburetor-Dry Type-With HDM	20 With L Engine,21 thru 27,1946-1947 All
EM 164517	Air Cleaner-Carburetor-Oil Bath-With HDM	20 With Std Engine,28
EM 164518	Air Cleaner-Carburetor-Oil Bath-With HDM	20 With L Engine,21,22,28,1946-1947 6 Cyl
EM 164519	Air Cleaner-Carburetor-Oil Bath-With HDM	24,25,27,53,54,173,174

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

247

Part No.	Name	Models
164520	Clutch Assembly (Use 301251)	22,28,20-21 With OD-VD or HDM
164521	Clutch Assembly (Use 301251)	24,25,27
164526	Pressure Plate-Clutch (Use 166336)-	22 thru 28,20-21 with OD-VD or HDM
164527	Finger-Clutch Throwout (Use 166339)	22 thru 28,20-21 With OD-VD or HDM
164528	Cover Assy-Clutch (Use 166338)	22 thru 28,20-21 With OD-VD or HDM
BT 164530	Driving Lug-Clutch Cover	22 thru 28,20-21 With OD-VD or HDM,53,54,58,173, 174,178,51-52-171-172 With VD-OD or HDM,1948-
		1949 All,501 thru 504,500 with HDM,SMD or OD
BT 164531	Nut-Clutch Throwout Finger Ret-Driving Lug	22 thru 28,20-21 with OD-VD or HDM,53,54,58,173,174, 178,51-52-171-172 with VD-OD or HDM,1948 thru 1950
		1942 All
164533	Guide-Exhaust Valve (Use 166200)	1942-1946-1947 All
BO 164534	Cap Kit-Automatic Battery Filler-1-1/4"x13"	20,21,22,24,28,51,53,171,173
CF 164537	Hub Cap-Wheel-Outer-Large-16" Wheel	21 thru 28
164538	Hub Cap-Wheel-Outer-Large-15" Wheel (Use 165801)	20,21,28,51,53,58
*HA 164539	Hub Cap-Kit-Set of Four 164537	20,21,28
164545	Shock Absorber-Front-Monroe (Use 166574)	20,21
164546	Shock Absorber-Rear-Monroe (Use 166575)	20-21-22-24-25 3Cpe-ClubCpe
164547	Shock Absorber-Front-Monroe (Use.166572)	20-21-22-24-25 3Cpe-ClubCpe
164548	Shock Absorber-Rear-Monroe (Use 166573)	20,21,22,1946-1947 6 Cyl
C 164550	Gear Assy-Steering-LHD	20,21,22,1946-1947 6 Cyl
C 164551	Gear Assy-Steering-RHD	20,21,22,1946-1947 6 Cyl
C 164552	Jacket Tube & Bushing Assy-Steering Gear	20-21-28 Without DI
C 164554	Jacket Tube & Bushing Assy-Steering Gear	22 With DI
C 164556	Jacket Tube & Bushing Assy-Steering Gear	24 With 01,25,27
C 164558	Main Column Tube & Worm Assy-Strg Gear-LHD.	20,21,22,24,1946-1947 All 6 Cyl
C 164559	Main Column Tube & Worm Assy-Strg Gear-RHD	20,21,22,24,1946-1947 All 6 Cyl
C 164560	Main Column Tube-Steering Gear	20,21,22,24,1946-1947 All
BZ 164562	Rod-Acc Pedal to Bellcrank-LHD	1942-1946-1947 6 Cyl With VD-OD or HDM
BZ 164564	Rod-Acc Pedal to Bellcrank-LHD	1942-1946-1947 8 Cyl
BZ 164565	End Assy-Acc Pedal to Bellcrank Rod-LHD	1942 with VD-OD or HDM,24-25-27 Without VD-OD-HDM, 1946-1947 with VD-OD or HDM,53,54,173,174
BZ 164568	Bellcrank-Acc Pedal Link-LHD	1942-1946-1947 With VD or HDM
BZ 164569	Support-Acc Pedal Link Bellcrank-LHD	1942-1946-1947 All With VD-OD or HDM,24-25-27 Without OD-VD-HDM
BZ 164570	Bushing-Acc Pedal Link Bellcrank Support-LHD	1942-1946-1947 All With VD-OD or HDM 24-25-27- 53-54-173-174 Without OD-VD-HDM
BZ 164571	Torsion Spring-Acc Pedal Link Bellcrank-LHD	1942-1946-1947 With. VD-OD or HDM,24-25-27-53-54- 173-174 Without OD-VD-HDM
BZ 164572	Lever Assy-Acc Pedal Link Bellcrank-LHD	1942-1946-1947 All With VD-OD or HDM,24-25-27-53- 54-173-174 Without OD-VD-HDM
BZ 164575	Rod-Ace Cross Shaft Operating-LHD	1942-1946-1947 6 Cyl With VD-OD or HDM
BZ 164576	Rod-Ace Cross Shaft Operating-LHD	1942-1946-1947 8 Cyl
BZ 164577	Cross Shaft & Supp Assy-Accelerator-LHD	20 with Std Engine,28
BZ 164578	Cross Shaft & Supp Assy-Accelerator-LHD	20 with L Engine,21,22,1946-1947 6 Cyl with VD-OD- HDM
*BZ 164579	Cross Shaft & Supp Assy-Accelerator-LHD	24,25,27,53,54,173,174
BZ 164586	Rod-Acc Cross Shaft to Carburetor-LHD	1942-1946-1947 6 Cyl with VD-OD or HDM
BZ 164587	Rod-Acc Cross Shaft to Carburetor-LHD	1942-1946-1947 8 Cyl
BZ 164588	Bellcrank-Throttle Control Manifold-LHD	20 with Std Engine,28
BZ 164589	Brkt-Throttle Control Tension-LHD	20 with Std Engine,28
164591	Screw Assy-Jack (Use 1 each 166079 & 166080)	89,90,98,40T,10T,10P,18P,20T,20P
164593	Screw Assy-Jack (Use 1 each 166079 & 166080)	21 thru 27,51,52,53,54
EM 164594	Tube-Breather	1942-1946-1947 All
EM 164595	Gasket-Breather Tube	1942-1946-1947 All
BZ 164596	Spring-Throttle Control-At Manifold	1942 thru 1947 with VD or HDM
BZ 164597	Spring-Throttle Control-At Cross Shaft	1942-1946-1947 All
164598	Escutcheon-Strg Wheel-18"-Russet (Use 165292)	1942 All
164599	Escutcheon-Strg Wheel-18"-Green (Use 165292)	1942 All
164601	Knob-Weather-Control Arm & Door-Ivory (Use 140278)	1942 thru 1949 All,501 thru 504
164602	Pipe Assy-Exh-LHD-Use Without OD (Use 166290)	20SP,20T-21-22 exc Station-Cv
CF 164604	Pipe Assy-Exhaust-LHD-Use Without OD	24-25 exc Cv,53,173,54-174 exc CvBro
CF 164606	Pipe Assy-Exhaust-LHD-Use Without OD	27
EM 164608	Cover-Exhaust Pipe-Front-LHD-Use Without OD	20T,20Sp,20P-21-22 exc,Station-Cv,51-171 exc CvBro,52,172
EM 164609	Cover-Exhaust Pipe-Rear-LHD-Use Without OD	20T,20Sp,20P-21-22 exc Station-Cv,51-171 exc CvBro,52,172
EM 164610	Cover-Exhaust Pipe-Front-LHD-Use Without OD	24-25-27 exc CvSed,53,173,54-174 exc CvBro
EM 164611	Cover-Exhaust Pipe-Rear-LHD-Use Without OD	24-25-27 exc CvSed,53,173,54-174 exc CvBro
164612	Pipe Assy-Gas Tank to Fuel Pump (Use 166054)	20P,20T,20Sp,21 exc Station,22,51,52
BZ 164614	Pipe Assy-Gas Tank to Fuel Pump-LHD	24,25,53,54,173,174
BZ 164615	Pipe Assy-Gas Tank to Fuel Pump-RHD	24,25,53,54,173,179
BZ 164616	Pipe Assy-Gas Tank to Fuel Pump-LHD	27
BZ 164617	Pipe Assy-Gas Tank to Fuel Pump-RHD	27
BZ 164636	Tool Kit-Domestic	21 thru 27,1946-1947 exc CabCabPu

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 164642	Roller Assy-Trans Shift Lock Lever-With HDM	1942 All
BT 164645	Stud-Trans Shift Lock Lever-With HDM	1942-1946-1947 All
164646	Trim Ring-Steering Wheel Hub-Russet (Use 165862)	20,28
BZ 164647	Trim-Ring-Steering Wheel Hub-Green	20P
BO 164648	Wire Assy-Hyd Top Lift Motor	1942 CvSed,1946-1947 CvBro
*C 164650	Frame Assy-LHD	20T-20P exc CvSed
*C 164651	Frame Assy-RHD	20T-20P exc CvSed
*C 164652	Frame Assembly	20 CvSed
*C 164653	Frame Assembly	20 Cab-CabPu
*C 164655	Frame Assembly-LHD	21-22 exc Cv & Station,51-171 exc CvBro,52,172
*C 164656	Frame Assembly-RHD	21-22 exc Cv & Station,51-171 exc CvBro,52,172
*C 164657	Frame Assembly	21-22 CvSed,Station,51-171 CvBro
*C 164659	Frame Assembly-LHD	24-25 exc CvSed,53,173,54-174 exc CvBro
*C 164660	Frame Assembly-RHO	24-25 exc CvSed,53,173,54-174 exc CvBro
*C 164661	Frame Assembly	24 CvSed,54-174 CvBro
C 164664	Frame Assembly-LHD	27
C 164665	Frame Assembly-RHD	27
*C 164666	Frame Assembly	28C,58,178
BZ 164667	Bracket-Frame Bumper	1942-1946-1947 All
BO 164670	Wire Assy-Charge Reg (B) to Horn Relay (B)	1942-1946-1947 All
BO 164672	Wire Assy-Horn Relay (H) to Horn	21 thru 28,1946-1947 All
BO 164674	Wire Assy-Horn Relay (H) to Horn	20
BO 164679	Relay & Wires Assy-Direction Indicator-LHD	1942 All
C 164692	Wheel Assy-Steering-17"-Russet	20,28
164693	Wheel Assy-Steering-17"-Green (Use 165193)	20,28
*BM 164695	Carburetor Assy-Single-Automatic Choke	20 with Std Engine,28
BZ 164696	Ring Kit-Horn-Gray	20,28
BZ 164697	Ring Kit-Horn-Russet	20,28
BZ 164698	Ring Kit-Horn-Green	20,28
C 164708	Front Suspension Complete-RH	1942-1946-1947 All
C 164709	Front Suspension Complete-LH	1942-1946-1947 All
164710	Support Assy-Strg Spindle-RH (Use 166274)	1942 All
164711	Support Assy-Strg Spindle-LH (Use 166275)	1942 All
EX 164716	Supp Arm & Pivot Assy-Steering Spindle-RH	1942-1946-1947 All
EX 164717	Supp Arm & Pivot Assy-Steering Spindle-LH	1942-1946-1947 All
164726	Seal-Spindle Supp Arm Pivot (Use 165972)	1942 All
164728	Eccentric Bushing Assy-Spindle Supp Arm Upper to Bolt (Use 166015)	1942 All
164729	Nut-Spdl Upper Supp Arm to Supp Bolt (Use 166482)	1942-1946 All
164732	Arm-Center Steering-LHD (Use 165601)	1942 All
164733	Arm-Center Steering-RHD (Use 165679)	1942 All
EX 164734	Race-Steering Arm Needle Bearing	1942-1946-1947 All
EX 164735	Spacer-Steering Arm Needle Bearing	1942-1946-1947 All
EM 164736	Suction Pipe-Oil Pan	20,21,22,28,1946-1947 All
164737	Use 164736	
164738	Countershaft-Transmission (Use 166203)	1942 All
BT 164739	Shaft-Trans Reverse Idler Gear	1942 thru 1950 All
164742	Pin-Piston (Use 37029)	1942 All
F 164744	Pivot Pin-Steering Spindle	1942 thru 1950 All
164746	Seal-Upper Supp Arm to Supp Bolt (Use 165972)	1942-1946 All
BZ 164747	Escutcheon Assy-Steering Wheel-18"-Russet	1942 All
BZ 164748	Escutcheon Assy-Steering Wheel-18"-Green	1942 All
164749	Timing Gear Set-Matched (Use 165907)	1936 thru 1942 All
BO 164751	Collar-Top Switch Mounting	1942 CvSed,1946-1947 CvBro
BO 164758	Wires Assy-Jct Block T to Bonnet Lamps	22 thru 28
BZ 164762	Wire Assy-VD Switch to Harness Plug	1942 All
BO 164763	Wire Assy-Temp Gauge to Top Lift Switch	20P-21-22-24 CvSed,1946-1947 CvBro
BO 164774	Wire Assy-Courtesy Lamp Conn to Front Door Switch.	21 thru 25 2Sed-3Cpe-ClubCpe,27Sed,52-54-172-174 ClubCpe
BO 164778	Wires Assy-Connector to Courtesy Lamp	21 thru 25 2Sed-Cpe,52-54-172-174 ClubCpe
BO 164781	Wire Assy-Connector to Courtesy Lamp	21 thru 27 Sed,52-54-172-174 Sed
164786	Shock Absorber Assy-Front (Use 166574)	20-21 exc 3Cpe-ClubCpe,28
164787	Shock Absorber-Rear (Use 166575)	20T-20P-21 exc 3Cpe-ClubCpe
C 164813	Engine Assy-Without VD-3" x 4-1/8"	20
164814	Engine Assy-With VD-OD or HDM-3" x 4-1/8" (Use 164815)	20 with 10" Clutch
*C 164815	Engine Assy-Without VD-OD or HDM-3"x 5"	20-21 with Std 9" Clutch,1946-1947 6 Cyl
164816	Engine Assy-3" x 5" (Use 164815)	20-21 with 10" Clutch-VD-OD or HDM,22,1946-1947 6 Cyl with VD-OD or HDM,58,178
164818	Engine Assy-With VD-OD or HDM-3" x 5" (Use 164815)	28
*C 164820	Engine Assy	24,53,173
164821	Engine Assy (Use 164820)	25,27,54,174
BO 164826	Valve Stem & Disc Assy-Weather-Control Shut Off	1940 thru 1948 All
BO 164827	Crank & Swivel Assy-Weather-Control Shut Off Valve	1940 thru 1948 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 164832	Wire Harness-Complete-DI-Body Half	1942 Without OD or VD
BO 164833	Wire Harness-Complete-DI-Body Half	1942 Without OD
BO 164834	Wire Harness-Complete-DI-Chassis Half	1942 All
EM 164838	Metering Rod Package-Carburetor-Export	24,25,27,53,54,173,174
EM 164839	Metering Rod-Carburetor-Standard	24,25,27,53,54,173,174
EM 164840	Metering Rod-Carburetor-2nd Leaner	24,25,27,53,54,173,174
EM 164841	Metering Rod-Carburetor-3rd Leaner	24,25,27,53,54,173,174
BO 164842	Relay & Wires Assy-Direction Indicator-RHD	1942 All
164843	Drive Plate Assy-Clutch (Use 301246)	22 thru 28,20-21 with VD-OD or HDM
BO 164846	Mounting Bar-Direction Indicator Relay	1942 thru 1947 exc 58,178
*HS 164848	Gasket-Paste-1 lb Can	All Models
*BO 164849	Horn Kit-Twin Air Type	20T,20C,58
BZ 164882	Solenoid Coil & Hsg Assy-VD	1942-1946-1947 With VD or HDM
BZ 164884	Disc-VD Solenoid Plunger	1942 thru 1950 with VD-HDM or SMD
BZ 164885	Valve Assy-VD Throttle Lock Solenoid	1942-1946 with HDM,1950 with HDM or SMD
BZ 164886	Ground Wire Assy-VD Throttle Lock Solenoid	1942 thru 1948 with HDM
BZ 164887	Plate Assy-VD Throttle Lock Solenoid Valve to Cylinder	1942 thru 1950 with HDM or SMD
BZ 164890	Body-Throttle Lock Solenoid Valve-With HDM or SMD.	1942 thru 1950 All
BZ 164891	Coil & Hsg Assy-VD Throttle Lock Solenoid-With HDM	1942,1950 All with HDM or SMD
BZ 164893	Hsg & Terminals Assy-VD Throttle Lock Sol	1942-1946-1947 with HDM
BZ 164894	Tube Assy-Upper-Sol Valve to Diaphragm-With HDM	1942-1946-1947 All
BZ 164896	Sleeve-Throttle Lock Solenoid to Diaphragm Tube	1942 thru 1950 All with HDM or SMD
BZ 164897	Tube & Nut Assy-VD Sol Diaph to Solenoid	1942-1946-1947 with HDM
BZ 164899	Elbow-VD Throttle Lock Diaphragm Tube	1942 thru 1949 with HDM
BZ 164900	Cyl Assy-VD Throttle Lock Diaphragm	1942-1946-1947 with HDM
BZ 164901	Spring-Throttle Lock Diaphragm Return-With HDM	1942 thru 1949 All
BZ 164904	Felt-Throttle Lock Diaphragm-With HDM or SMD	1942 thru 1950
BZ 164905	Retainer-Throttle Lock Diaphragm Felt-Outer	1942 thru 1950 with SMD All
BZ 164906	Retainer-Throttle Lock Diaphragm Felt-Inner	1942 thru 1950 with SMD All
BZ 164907	Cable Assy-Throttle Lock Diaphragm-With HDM	1942-1946-1947 All
BZ 164908	Mounting Bracket-VD Throttle Lock Solenoid Diaphragm	1942-1946-1947 With HDM
BZ 164909	Mounting Nut-VD Throttle Lock Solenoid Diaphragm	1942 thru 1950 With HDM or SMD
BO 164910	Spring-Bonnet Lamp Socket Terminal Washer	1942 thru 1950 All
BO 164911	Sleeve-Instrument Harness Wire	1948 thru 1950
BO 164913	Harness-Instrument-LHD	20,28
164914	Harness-Instrument-LED (Use 164002 & 6-164912)	21 thru 27
BZ 164916	Harness-Chassis	20
BZ 164918	Bellcrank-Acc Pedal Link-LHD	20-21-22-28-51-52-58-171-172-178 With OD and Without VD or HDM,24-25-27-53-54-173-174 Without VD or HDM
164921	Bushing-Trans Counter Shaft Gear Cluster-Front (Use 165854)	1942 thru 1950 All
EM 164922	Pipe Assy-Fuel Pump to Carburetor	20 with Std Engine & Fuel Pump
EM 164924	Pipe Assy-Combination Pump to Carburetor	20 with Std Engine,28
*HA 164926	Vacumotive Drive Kit-6 Cyl-Without OD	20,21,22,28
BZ 164940	Tube-Shock Absorber Pressure Chamber	20-21-22 exc 3Cpe-ClubCpe
BO 164941	Plug-Harness-With VD-OD or DI	1942 All
BO 164942	Socket-Harness Plug-With VD-OD or DI	1942 All
BO 164943	Boot-Harness Plug-With VD-OD or DI	1942 All
EM 164953	Pin-Piston Ring-Lower-Steel Pistons	1942 All
BT 164955	Cylinder Assy-HDM Power	1942-1946-1947 All
BT 164956	Shell Assy-HDM Power Cylinder	1942-1946-1947 All
BT 164958	Bracket Assy-HDM Power Cylinder	1942-1946-1947 All
BT 164960	End Plate and Seal Assy-HDM Cylinder	1942 thru 1950 All
BT 164964	Piston Assy-HDM Cylinder	1942 thru 1950 All
BT 164966	Cylinder Assy-HDM Diaphragm	1942-1946-1947 All
BT 164968	Diaphragm-HDM	1942-1946-1947 All
BT 164969	Plate-HDM Diaphragm	1942-1946-1947 All
BT 164970	Rod-HDM Diaphragm	1942-1946-1947 All
BT 164971	Spring-HDM Diaphragm	1942-1946-1947 All
BT 164972	Spacer-Diaphragm	1942-1946-1947 All
BT 164973	Gasket-Diaphragm	1942-1946-1947 All,1950 with HDM or SMD
BT 164977	Tube Complete-HDM Valve to Cylinder-Short	1942-1946-1947 All
BT 164980	Tube Complete-HDM Valve to Cylinder-Long	1942-1946-1947 All
BT 164983	Bolt-HDM Power Cyl Plate	1942-1946-1947 All
BO 164985	Harness -HDM -Body Half	1942 All
BO 164986	Harness-HDM-Chassis Half	1942 All
BO 165002	Wires and Loom Assy-Generator	1942-1946-1947 All
BO 165013	Loom-HYD Top Lift Wire	20P-21-22-24 CvSed,1946-1947 CvBro
BZ 165014	Tube Assy-Brake Master Cyl to Frame Tee-LHD	1942-1946-1947 All
F 165015	Pin-Piston-Steel Pistons	1942 All
EM 165022	Pin-Piston Ring-Upper-Steel Pistons	1942 All
165025	Universal Joint Repair Kit (Use 164369)	1936 thru 1942 All
BO 165027	Clip-Wiring	1942-1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 165028	Switch-Door Hinge Plunger	21 thru 27 exc Station,52,54,172,174
BO 165029	Washer-Domelamp Wire Socket Terminal	1942 thru 1949 exc 28
BO 165030	Washer-Domelamp Wire Socket Insulating	20 thru 27,1946-1947 All
BT 165032	Anchor Brkt-Handy Shift-LHD-Steering Gear End	1942 thru 1950 All
BT 165034	Anchor Brkt-Handy Shift-LHD-Trans End	1942-1946-1947 All
C 165035	Case Assy-Trans-Use Without OD or HDM	1942-1946-1947 All
C 165037	Case Assy-Trans-Use With HDM, Without OD	1942-1946-1947 All
C 165039	Case Assy-Trans-Use With OD, Without HDM	1942-1946-1947 All
C 165040	Case Assy-Trans-Use With OD, and HDM	1942-1946-1947 All
BT 165042	Cover, Baffle & Clip Assy-Trans-LHD-Use with VD-HDM without OD	1942-1946-1947 All
BT 165043	Cover & Cross Lever Assy-Trans-RHD-without OD	1942 thru 1947 All
BT 165045	Cover & Baffle Assy-Trans-Use without OD-VD-HDM	1942 thru 1949 All,1950 less OD
TF 165047	Gasket-Trans Cover	1942 thru 1950 All
BT 165048	Cover & Cross Lever Assy-Trans-RHD-with OD	1942-1946-1947 All
BO 165052	Motor Assy-Top Control	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165053	Gasket-Top Control Motor	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165054	Pump Assy-Top Control	20P-21-22-24 CvSed,1946 CvBro
BO 165055	Housing-Top Control Pump	20P-21-22-24 CvSed,1946 CvBro
BO 165056	Rotor Assy-Top Control Pump-Inner	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165057	Rotor Assy-Top Control Pump-Outer	20P-21-22-24 CvSed,1946 CvBro
BO 165058	Gasket-Top Control Pump-Inner	20P-21-22-24 CvSed,1946 CvBro
BO 165059	Adapter-Top Control Pump Plate	20P-21-22-24 CvSed,1946 CvBro
BO 165060	Thrust Washer-Top Control Pump	20P-21-22-24 CvSed,1946-1947 CvBro
165061	Valve Assy-Top Control Pump Pressure Balance (Use 166468)	20P-21-22-24 CvSed,1946 CvBro
BO 165062	Gasket-Top Cont Pump Pressure Balance Valve	20P-21-22-24 CvSed,1946 CvBro
BO 165063	Solenoid-Top Control Power Unit	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165064	Solenoid-& Strap Assy-Top Control Power Unit	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165065	Insulator-Top Cont Power Unit Solenoid-Loom	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165066	Connector-Top Cont Power Unit Solenoid-Battery	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165067	Connector-Top Cont Power Unit Solenoid-Field	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165068	Reservoir & Bracket Assy-Top Control Power Unit	20P-21-22-24 CvSed,1946 CvBro
BO 165069	Cap-Top Control Power Unit Reservoir	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165070	Gasket-Top Control Unit Reservoir	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165071	Tube Assy-Top Control Power Unit Reservoir	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165072	Elbow-Top Control Power Unit Reservoir	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165073	Bracket Assy-Top Control Power Unit-Front	20P-21-22-24 CvSed,1946-1947 CvBro
BO 165074	Bracket-Top Control Power Unit-Rear	20P-21-22-24 CvSed,1946-1947 CvBro
C 165075	Spring Assy-Rear	21 Station,178 Station
165076	Spring Assy-Rear (Use 162639)	20 CabPu
165078	Spring Assy-Rear (Use 164018)	20 3Cpe
C 165079	Spring Leaf-Rebound	1942 Springs 164018-19-20-21
C 165080	Spring Leaf-Rebound	For Springs 164022-3-4-5
C 165081	Spring Leaf-Rebound	For Springs 164029-33
C 165082	Spring Leaf-Rebound	For Springs 164030-32
C 165083	Spring Leaf-Rebound	For Springs 164031
C 165084	Spring Leaf-Rebound	For Springs 165075
C 165087	Spring Leaf-#3	For Springs 164018-19-20-21
C 165088	Spring-Leaf-#3	For Springs 164022-3-4-5
C 165089	Spring Leaf-#4	For Springs 164022-3-4-5
C 165090	Spring Leaf-#4	For Springs 164019-20-21
C 165093	Spring Leaf-#4	For Springs 164018
C 165094	Spring Leaf-#3	For Springs 164029-33
C 165095	Spring Leaf-#4	For Springs 164029-33
C 165100	Spring Leaf-#3	For Springs 164030-1-2
C 165101	Spring Leaf-#4	For Springs 164030-32
C 165106	Spring Leaf-#4	For Spring 164031
C 165108	Spring Leaf-#3	For Spring 165075
BZ 165114	Center Bolt-Spring	For Springs 165076-7
BZ 165115	Clip-#2-Spring Rebound	For Springs 165076-7
BZ 165116	Clip-#3-Spring Rebound	For Springs 165076-7
BZ 165117	Clip-#1 & 4 Spring Rebound	For Springs 165076-7
C 165118	Head Assy-Cylinder-7.25 to 1	20 with Std Engine
C 165119	Head Assy-Cylinder-6.46 to 1	20 with L Engine,21,22,28
C 165121	Head Assy-Cylinder	24,25,27
165126	Cylinder & Pistons Assy (Use 166263)	20 with Std Engine
C 165127	Cylinder & Pistons Assy	20 with L Engine,21,22,28
F 165134	Piston Ring-Upper Compression	1942 All
F 165135	Piston Ring-Upper Compression-.010 0/S	1942 All
F 165136	Piston Ring-Lower Compression	1942 All
BM 165137	Piston Ring-Lower Compression-.010 0/S	1942 All
F 165138	Piston Ring-Oil Ends Complete-Tie Rod (Use 159782)	1942 All 1942-1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	165144 Ends Complete-Tie Rod-LH Rod (Use 159782)	1942-1946 All
C	165145 Tie Rod Assy-RH	1942-1946-1947 All
	165146 Tie Rod Assy-LH (Use 159780)	1942-1946-1947 All
	165147 End Assy-Right Tie Rod-LH (Use 159784)	1942-1946-1947 All
	165148 End Assy-Left Tie Rod-RH (Use 159783)	1942-1946-1947 All
BO	165149 Kit-Battery Filler Cap-1" x 13	1942-1946-1947 All
F	165150 Piston Assy	1942 All
*C	165151 Clutch Housing Complete- LHD-Incl Yoke-Shaft & Lever	1942-1946-1947 All
C	165152 Clutch Housing Complete-RHD	1942-1946-1947 All
*C	165153 Housing Assembly-Clutch-LHD	1942-1946-1947 All
*C	165154 Housing Assembly-Clutch-RHD	1942-1946-1947 All
	165156 Thrust Washer-OD Clutch Hub-Rear (Use 163316)	1942-1946 All
BT	165157 Plunger-OD Interlock Lever-Long	1942-1946-1947 All
BZ	165158 Tool Kit-Domestic	20C ,28C,58,178 Cab-CabPu
C	165163 Kit-Extra Spring Leaf	For Springs #164022-3-4-5
	165182 Cap-Gasoline Tank-Painted (Use 155298)	1942 All
	165184 Hub Cap-Wheel Outer-Large-16" Wheel-Pntd (Use 164537)	20,21,22,24,28
C	165191 Wheel Assy-Steering-17" Gray	20P
	165192 Wheel Assy-Steering-17" Russet (Use 164692)	20,28
C	165193 Wheel Assy-Steering-17" Green.	20P
	165195 Wire & Casing Assy-OD-LHD-Lac (Use 161997)	1942 All
	165196 Wire & Casing Assy-OD-RHD-Lac (Use 161998)	1942 All
C	165197 Wire & Knob Assy-OD-Lac	1942 All
	165200 Grip & Ratchet Rod Assy-Hand Brake-LHD-Lac (Use 150651)	22 thru 27
	165201 Grip & Ratchet Rod Assy-Hand Brake-RHD-Lac (Use 158691)	22 thru 27
BZ	165205 Trim Ring-Steering Wheel Hub-Gray	20P
	165206 Trim Ring-Steering Wheel Hub-Russet (Use 164646)	20,28
	165207 Trim Ring-Steering Wheel Hub-Green (Use 164647)	20P
BZ	165209 Ring-Horn-17" Wheel	20,28
	165210 Grip-Hand Brake (Use 150652)	22 thru 27
	165211 Button Assy-Horn-17" Wheel without Ring (Use 165864)	20P
	165212 Button Assy-Horn-17" Wheel without Ring (Use 164355)	20,28
BZ	165213 Button Assy-Horn-17" Wheel without Ring	20P
	165214 Button Assy-Horn-17" Wheel with Ring (Use 164358)	20P
BZ	165215 Button Assy-Horn-17" Wheel with Ring	20,28
BZ	165216 Button Assy-Horn-17" Wheel with Ring	20P
BZ	165217 Escutcheon-Horn Button-17" Wheel-Gray	20P
BZ	165218 Escutcheon-Horn Button-17" Wheel-Russet	20,28
BZ	165219 Escutcheon-Horn Button-17" Wheel-Green	20P
	165220 Connecting Rod Assy-RH (Use 166238)	20 with Std Engine
	165221 Connecting Rod Assy-LH (Use 166239)	20 with Std Engine
	165222 Connecting Rod Assy-RH (Use 166241)	20 with L Engine,21 thru 28
	165223 Connecting Rod Assy-LH (Use 166242)	20 with L Engine,21 thru 28
F	165234 Bushing-Connecting Rod	20 thru 28
	165235 Switch Assy-Top-Lac (Use 163217)	1942 CvSed
	165236 Collar-Top Switch-Lac (Use 164751)	1942 CvSed
BO	165237 Lever-Direction Indicator Switch-Lac	20 thru 27
	165238 Case-Direction Indicator Switch-Lac (Use 164178)	20 thru 27
	165239 Cover-Direction Indicator Switch (Use 164179)	20 thru 27
	165242 Case & Cover Assy-DI Switch (Use 164172)	20-21 exc Sta,28 Opt
	165244 Case & Cover Assy-DI Switch (Use 164174)	22-24 Opt,25-27 Std
BO	165246 Conduit-Direction Indicator Wire	22 thru 27
	165248 Wheel-Steering-18" Russet (Use 164275)	20 thru 27
	165249 Wheel-Steering-18" Green (Use 164403)	20P,21 thru 27
	165264 Lever, Tube & Rod Assy-Handy Shift-LHD (Use 164418)	20,21,22
	165268 Lever-Handy Shift (Use 166287)	1942 All
	165269 Lever-Tube and Fulcrum Brkt Assy-Handy Shift- LHD (Use 164436)	22 thru 27
	165270 Lever, Tube & Fulcrum Brkt Assy-Handy Shift- RHD (Use 162822)	22 thru 27
	165273 Fulcrum Brkt -Handy Shift Lever (Use 300987 & 800989)	22 thru 27
	165274 Ring-Handy Shift Fulcrum Brkt (Use 161704)	22 thru 27
BT	165275 Brkt-Handy Shift Tube-Upper-Without DI	22,24
BT	165276 Brkt-Handy Shift Tube-Upper-With DI	22,24,25,27
	165277 Escutcheon Assy-Steering Wheel-Blue (Use 165375)	1942 18" Wheel
	165278 Escutcheon Assy-Steering Wheel-Russet (Use 165375).	1942 18" Wheel
BZ	165280 Bezel-Escutcheon-18" Wheel	21 thru 27
	165282 Ring Assy-Horn-18" Wheel (Use 164280)	21 thru 27
	165284 Jacket Tube & Bushing Assy-Strg Gear-Less Indicator (Use 162755)	22
C	165286 Jacket Tube & Bushing Assy-Strg Gear-Less Indicator	24

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
165288	Jacket Tube & Bushing Assy-Strg Gear-With Indicator (Use 164554)	22
165290	Jacket Tube & Bushing Assy-Strg Gear-With Indicator (Use 164556)	24,25,27
BZ 165292	Escutcheon-18" Steering Wheel	21 thru 27
165347	Gasket-Cylinder Head (Use 166201)	37 thru 42 6 Cyl
165348	Gasket-Cylinder Head (Use 166240)	37 thru 42 8 Cyl
BT 165365	Kit-Speedometer-Used with 4 1/9 Gear Ratio	1942-1946-1947 Police Cars
BT 165366	Kit-Speedometer-Used with 4 5/9 Gear Ratio	1942-1946-1947 Police Cars
BO 165367	Speedometer Assembly	1942-1946-1947 Police Cars
BT 165368	Cable Assy-Speedometer	1942-1946-1947 Police Cars
BT 165369	Adapter Assy-Speedometer Cable	1942-1946-1947 Police Cars
BT 165371	Wire Assy-Speedometer Lamp	1942-1946-1947 Police Cars
BZ 165375	Escutcheon Assy-Steering Wheel-18" Wheel	1942 All
165377	Shaft & Rear Joint Assy-Propeller-Without OD (Use 159508)	27,28
C 165378	Shaft & Rear Joint Assy-Propeller-With OD	20 thru 25
C 165380	Shaft & Rear Joint Assy-Propeller-Without OD	20 with L Eng,21 thru 25
C 165384	Shaft Assy-Propeller-Without OD	20 with Std Eng
165385	Shaft Assy-Propeller-Without OD (Use 162435)	20 with L Eng,21 thru 25
C 165386	Shaft Assy-Propeller-Without OD	27,28
C 165387	Shaft Assy-Propeller-With OD	20 thru 25
165390	Universal Joint Assy-Front (Use 165790)	20 L Eng,21,22,24,25
BZ 165393	Tee-Hydraulic Tube-Steel	36 thru 42 All
BZ 165394	Fitting-Master Cylinder Head Outlet-Steel	38 exc 89,39 thru 42 All
BZ 165395	Fitting-Wheel Cylinder Tube Rear-Steel	36 thru 42 All
BT 165397	Clutch Shifter Shaft,Yoke and Coupling Lever Assy	1941 thru 1947 All LHD
F 165398	Gasket-Oil Pan-Korkoid	1934 thru 1947 8 Cyl
BT 165402	Gasket-IIDM trans Switch Cover	1942 thru 1947
F 165484	Gasket-Oil Pan-Korkoid (Service for 157875).	1939 thru 1947 6 Cyl
BZ 165486	Bushing-Auto Poise Bar-Synthetic (Service for 157931-160124)	1939 thru 1947
165498	Clamp and Bracket Assy-Exhaust Pipe	1937 thru 1939
165499	Sealed Beam Assy-1942 Fog Lamp (Mazda 4015) (Use 209887)	1942 All
165507	Engine Assy-Steel Pistons (Use 164820)	24
165508	Engine Assy-Steel Pistons (Use 164820)	25-27
F 165524	Piston Ring Kit 6 Cyl	1936 thru 1938,1939 1st Type
F 165525	Piston Ring Kit 6 Cyl	1939 2nd Type,1940 thru 1946
165528	Timing Gear Kit-14° (Use 165907)	1937 thru 1940 All
165529	Timing Gear Kit-20° (Use 165907)	1941-1942 All
C 165530	Radiator Core-Less Upper and Lower Tank (Part of 152551)	70,71,72
C 165531	Radiator Core-Less Upper and Lower Tank (Part of 152553)	1937 8 Cyl
165532	Radiator Core (Use 165530)	92,93
C 165533	Radiator Core-Less Upper & Lower Tank (Part of 157837)	1939 8 Cyl
C 165534	Cylinder Head Assy-Service Replacement	1936 thru 1939 6 Cyl exc 89-90
165535	Hose-Heater-6" Synthetic Rubber-Service (Use 159079)	1939 thru 1946
*SP 165536	Spark Plug-Complete-J8-Service	All
BT 165537	Fulcrum-Control Lever-Service for 158009-161697	51,53,58,171,173,178,481,483,491,493,500,501,503
F 165538	Piston Ring-Oil-.030 O/S	1939 thru 1947 All,1948 thru 1950 8 Cyl
F 165539	Piston Ring-Oil-.030 O/S	1939 thru 1947 All,1948 thru 1950 8 Cyl
F 165542	Piston Ring-Compression-.030 O/S	1932 thru 1947 All,1948 thru 1950 8 Cyl
F 165546	Timing Gear-Camshaft-Emergency for 162163	1941-1942
165548	Piston Assy-.030 O/S (Use 166345)	1939 thru 1942
MF 165550	Bearing Assy-Crankshaft #1-Reamed-.010 U/S	1939-1940 6 Cyl
MF 165551	Bearing Assy-Crankshaft #2-Reamed-.010 U/S	1939-1940 6 Cyl
MF 165552	Bearing Assy-Crankshaft #3-Reamed-.010 U/S	1939-1940 6 Cyl
MF 165553	Bearing Assy-Crankshaft #1-Reamed-.010 U/S	1939 thru 1950 8 Cyl
MF 165554	Bearing Assy-Crankshaft #2-Reamed-.010 U/S	1939 thru 1950 8 Cyl
MF 165555	Bearing Assy-Crankshaft #3-Reamed-.010 U/S	1939 thru 1950 8 Cyl
MF 165556	Bearing Assy-Crankshaft-#4-Reamed-.010 U/S	1939 thru 1950 8 Cyl
MF 165557	Bearing Assy-Crankshaft-#5-Reamed-.010 U/S	1939-1940 8 Cyl
MF 165558	Bearing Assy-Crankshaft-#1-Reamed-.010 U/S	1941 thru 1947 6 Cyl
MF 165559	Bearing Assy-Crankshaft-#2-Reamed-.010 U/S	1941 thru 1947 6 Cyl
MF 165560	Bearing Assy-Crankshaft-#3-Reamed-.010 U/S	1941 thru 1947 6 Cyl
MF 165561	Bearing Assy-Crankshaft-#5-Reamed-.010 U/S	1941 thru 1950 8 Cyl
F 165562	Connecting Rod-RH-Assy-.010 U/S	1930 thru 1937
F 165563	Connecting Rod-LH-Assy-.010 U/S	1930 thru 1937
F 165564	Connecting Rod-RH-Assy-.010 U/S	1938 thru 1942 L Engine-8 Cyl,1946-1947 All,1948 thru 1950 8 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
F 165565	Connecting Rod-LH-Assy- .010 U/S	1938 thru 1942 L Engine-8 Cyl,1946-1947 All,1948 thru 1950 8 Cyl
F 165566	Connecting Rod-RH-Assy- .010 U/S	1938 thru 1942 Std 6 Cyl Engine
F 165567	Connecting Rod-LH-Assy-.010 U/S	1938 thru 1942 Std 6 Cyl Engine
C 165568	Crankshaft Assy-.010 U/S Rod & Bearing Pins Service	1936 thru 1947 8 Cyl
C 165569	Crankshaft Assy-.010 U/S Rod & Bearing Pins Service	1938 thru 1942 Std 6 Cyl Engine
C 165570	Crankshaft Assy- .010 U/S Rod & Bearing Pins Service	1936-19376 Cyl,1938 thru 1942 L Engine,1946-1947 6 Cyl
165571	Piston Pin-.001 0/S Service	1932 thru 1947 All
F 165572	Piston Pin-.002 0/S Service	1932 thru 1947 All,1948 thru 1950 8 Cyl
F 165573	Piston Pin-.005 0/S Service	1932 thru 1947 All,1948 thru 1950 8 Cyl
F 165574	Piston Pin-.010 0/S Service	1932 thru,1947 All,1948 thru 1950 8 Cyl
165575	Piston Pin-.015 0/S Service	1932 thru 1947 All
165576	Piston Pin-.020 0/S Service	1932 thru 1947 All
C 165591	Crankshaft Assy-3 x 4 1/8 Engine .010 U/S Crank Pins	89,90,98,40,10,20
C 165592	Crankshaft Assy-L 3x 5 Engine .010 U/S Crank Pins	1940 thru 1947 6 Cyl
C 165593	Crankshaft Assy-.010 U/S Crank Pins	1936 thru 1947 8 Cyl
C 165594	Crankshaft Assy-3x 4 1/8 Engine .010 U/S Brg Journals	89,90,98,40,10,20
C 165595	Crankshaft Assy-L 3x5 Engine-.010U/SBrgJournals	1940 thru 1947 6 Cyl
C 165596	Crankshaft Assy-.010 U/S Brg Journals	1936 thru 1947 8 Cyl
BX 165601	Arm-Center Steering-LHD	1942-1946-1947 All
C 165603	Head Assy-Cylinder-Aluminum	1946 thru 1950 8 Cyl
165606	Cylinder & Piston Assy-6 Cyl (Use 166263)	1941 thru 1942
F 165612	Hub Cap-Wheel Outer-Small-16" Wheel	51,53,58,171,173,178,481,483,491,493
F 165613	Gasket Kit-Transmission-Service	1942 Second Type,1946 thru 1950
C 165626	Jacket Tube & Bearing Assy-Steering Gear-Without DI	51,58,171,178
C 165628	Jacket Tube & Bearing Assy-Steering Gear-Without DI	52,172
C 165630	Jacket Tube & Bearing Assy-Steering Gear-Without DI	51,171
C 165632	Jacket Tube & Bearing Assy-Steering Gear-Without DI	52,172
C 165634	Jacket Tube & Bearing Assy-Steering Gear-Without DI	53,173
C 165636	Jacket Tube & Bearing Assy-Steering Gear-Without DI	54,174
C 165638	Jacket Tube & Bearing Assy-Steering Gear-With DI	53,173
C 165640	Jacket Tube & Bearing Assy-Steering Gear-With DI	54,174
BZ 165642	Bearing Assy-Steering Gear Jacket Tube	1946 thru 1950 All
BZ 165646	Spring-Jacket Tube Bearing	1946 thru 1950 All
BZ 165647	Spacer-Jacket Tube Bearing	1946 thru 1950 All
BZ 165648	Spacer-Jacket Tube Bearing Spring-With DI	1946 thru 1950 All
C 165659	Lever,Tube & Rod Assy-Handy Shift-LHD-Painted	51,53,58,171,173,178
165660	Lever,Tube & Rod Assy-Handy Shift-LHD-Plated (Use 165659)	52,54,172,174
BT 165661	Fulcrum-Handy Shift	52,54,172,174,482,484,492,494,502,504
BT 165663	Bracket-Handy Shift Tube-Upper-Painted-Without DI	51,53,58,171,173,178,481,483,491,493,500,501,503
BT 165664	Bracket-Handy Shift Tube-Upper-Plated-Without DI	52,54,172,174,482,484,492,494,502,504
BT 165665	Brkt-Handy Shift Tube-Upper-Painted-With DI	51,53,171,173,481,483,491,493,500,501,503
BT 165666	Bracket-Handy Shift Tube-Upper-Plated-With DI	52,54,172,174,482,484,492,494,502,504
C 165667	Propeller Shaft Assy-Without OD	51,52,53,54,171 thru 174
165671	Power Unit-Vacumotive Drive	1946 All
165672	Valve Assy-6V-V/D Throttle Lock Solenoid	1942-1946 All
C 165675	Steering Wheel-18" Blue Plastic	52,54,172,174 Opt 51-53-58-171-173-178
BZ 165676	Horn Button Assy	52,54,172,174
BZ 165677	Horn Button-18" Wheel	1946-1947 All
BZ 165678	Cap-Horn Button Transparent-Upper-18" wheel	1946-1947 All
BX 165679	Steering Arm-Center-RHD	1942-1946-1947 All
165687	Engine Assy-Eight Cylinder-Alum Cyl Head (Use 164820)	53,173
165688	Engine Assy-Eight Cylinder-Alum Cyl Head (Use 164820)	54,174
EX 165708	Bolt & Lockwasher Assy-Wheel Cyl to Backing Plate	1946 thru 1950 All
C 165721	Lever, Tube & Rod Assy-Handy Shift-RHD-Pntd	51,53,171,173,178
C 165722	Lever,Tube & Rod. Assy-Handy Shift-RHD-Pltd	52,54,172,174
BM 165726	Shim-#1 Bearing-.031-Steel	1940 thru 1942
EM 165727	Shim-#3 Bearing-.031-Alum	1940 thru 1942
C 165733	Steering Wheel Kit-18" Blue Plastic-Service	51,53,171,173,178
165734	Journal Assy-Propeller Shaft	51,52,53,54.171 thru 174
C 165740	Radiator Core-Replacement For 150543	64 thru 67
EM 165747	Generator Complete-12 Volt	1946-1947 All
BO 165748	Relay-Twin Electric Air Horn-12 Volt	1946-1947 All
BZ 165749	Bracket-Rear Stabilizer Frame	1946-1947 exc Cab-CabPu
165750	Shock Absorber Assy-Front-Light (Use 166572)	51-171 3Cpe-ClubCpe
165751	Shock Absorber Assy-Rear-Light Control (Use 166573)	51-171 3Cpe-ClubCpe
165752	Shock Absorber Assy-Front-Monroe (Use 166572)	1942 3Cpe-ClubCpe
165753	Shock Absorber Assy-Rear-Monroe (Use 166573)	1942 3Cpe-ClubCpe
165754	Shock Absorber Assy-Front-Light (Use 166574)	51-171 exc 3Cpe-ClubCpe
165755	Shock Absorber Assy-Rear-Light Control (Use 166575)	51-171 exc 3Cpe-ClubCpe
BO 165758	Horn Assy-Twin Electric High Pitch-12 Volt	1946-1947 All
BO 165759	Horn Assy-Twin Electric Low Pitch-12 Volt	1946-1947 All
BO 165761	Power Unit Assy-Hydraulic Top Lift-12 Volt	1946-1947 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
F 165762	Shackle & Bushing Kit-RH-Rear Spring	1939 thru 1950 All
F 165763	Shackle & Bushing Kit-LH-Rear Spring	1939 thru 1950 All
BZ 165768	Valve & End Assy-Shock Absorber	51,171
BZ 165790	Universal Joint Assy-Front	1946 with OD
165792	Piston Assy-For 165751 Shock Absorber	1942-1946
F 165798	Gasket Kit-Complete Engine Overhaul	1937 thru 1947 6 Cyl
165799	Wheel Assy-15x 5.00 (Use 302427)	51 thru 54,171 thru 174,1948 All
*CF 165801	Hub Cap-Outer-Large-15" Wheel	51 thru 54,171 thru 174,1948-1949
*C 165802	Trim Ring-Wheel Rim-15" Wheel	51 thru 54,171 thru 174,1948-1949-1950 All
165803	Prop-Shaft Assy (Use 162437)	51 thru 54
BO 165811	Loom-1/4" Front Hood Ornament Wire	1946-1947 All
BO 165812	Wire Assy-Junction Block to Hood Fn Ornament	1946-1947 All
BO 165814	Wire Assy-Hood Front Ornament to Connector	1946-1947 All
BZ 165816	Pedal Complete-Accelerator-Black-LHD	1946-1947 All
BZ 165817	Pedal Complete-Accelerator -Black-RHD	1946-1947 All
BZ 165819	Cover-Pedal Pad-Black	1946-1947 All
BT 165826	Relay-Overdrive	1946 thru 1949 All
BT 165827	Power Unit Assy-HDM	1946-1947 All
BZ 165828	Switch-VD Accelerator	1946 thru 1949
BZ 165829	Switch-VD & OD Governor	1946 thru 1950 All
BZ 165830	Solenoid Valve-VD Throttle Lock-6 Volt	1946 thru 1949 All with HDM
BT 165831	Switch-HDM Governor	1946 thru 1949 An
BZ 165832	Cap-Wiring Harness Plug and Socket	1946 thru 1949 All
BT 165833	Plug-HDM Wiring Harness-4 Prong	1946-1947 All
BT 165834	Socket-HDM Wiring Harness-4 Prong	1946 thru 1949 All
BT 165835	Socket-HDM-VD Wiring Harness-2 Prong	1946 thru 1949 All
BZ 165836	Socket-HDM-VD & OD Wiring Harness-3 Prong	1946 thru 1949 All
BZ 165844	Wiring Harness-Vacumotive Drive	1946-1947 All
165845	Wiring Harness-HDM-Chassis Half	1946-1947 All
*HA 165852	Hudson Weather Control Heater Comp-Vict.Gray	1946-1947 All
165853	Gear Cluster Assy-Trans Countershaft (Use 163905)	1946-1947 All
BT 165854	Bushing-Countershaft Gear Cluster-Front	1946-1947 All
BT 165855	Bushing-Countershaft Gear Cluster-Rear	1941 thru 1948 All
C 165859	Wheel Assy-Steering-17"-Gray	58,178
BZ 165861	Steering Wheel Assy-Victory Gray Grained-17"	51,53,171,173
BZ 165862	Trim Ring-17" Steering Wheel Hub	51,53,58,171,173,178
BZ 165864	Button Assy-Horn-Without Ring-17" Wheel-Gray	51,53,58,171,173,178
BZ 165865	Button Assy-Horn-With Ring-17" Wheel-Gray	51,53,58,171,173,178
BZ 165866	Escutcheon-Horn Button-17" Wheel	51,53,58,171,173,178
BZ 165867	Ornament-Horn Ring-Ivory-17" Wheel	51,53,58,171,173,178
*HA 165868	Horn Ring Kit-17" Wheel	51,53,58,171,173,178
*F 165870	Shock Absorber Assy-Rear-Light Control.	52-53-54-172-173-174 3Cpe-ClubCpe
*F 165871	Shock Absorber Assy-Rear-Heavy Control	1946-1947 All
*F 165873	Shock Absorber Assy-Front-Heavy Control	1946-1947 All
*F 165874	Shock Absorber Assy-Front-Heavy Control	1946-1947 All
*F 165875	Shock Absorber Assy-Front-Light Control	52-53-54-172-173-174 Bro-Sed
BZ 165884	Relief Valve & End Assy-Shock Absorbers- For 165873-4-5	1946-1947 All
BZ 165885	Relief Valve & End Assy-Shock Absorbers- For 165870-1	1946-1947 All
BZ 165894	Vacumotive Drive Power Unit Assy with HDM	1946-1947 All
*HS 165896	Radiator Stop Leak-10 oz	
*HS 165897	Gasket Cement-2 oz	
*HS 165898	Penetrating Oil-4 oz	
*HS 165899	General Use Oil-4 oz	
EM 165903	Plate-Camshaft Gear Reinforcement	1946-1947 All,1948 thru 1950 8 Cyl
EM 165905	Support Plate Assy-Cylinder Front	1946 6 Cyl 2nd type,1947 6 Cyl
F 165907	Timing Gear Replacement Kit-Alum Cam Gear	1936 thru 1947
F 165908	Timing Gear Set-Matched	1946-1947 All,1948 thru 1950 8 Cyl
C 165911	Intake Manifold Assy-Alum Interchange with 164341	1946-1947 6 Cyl
BO 165916	Bracket Assy-OD Solenoid Conn Plug	1946 thru 1949 All
BO 165920	Washer-OD Solenoid Conn Plug Brkt-Insulating	1946 thru 1949 All
*HS 165922	Radiator Cleaner Kit	
*HS 165923	Radiator Rust Preventive	
C 165932	Spring & Cover Assy-Rear-Light Scale	1946-1947 Bro-3Cpe
C 165934	Spring & Cover Assy-Rear-Light Scale	1946-1947 Sed-ClubCpe-CvBro
C 165940	Spring & Cover Assy-Rear-Heavy Scale	20 Sed-UCo-UCpe
C 165942	Spring & Cover Assy-Rear-Heavy Scale	51-52-171-172 3Cpe-ClubCpe
C 165944	Spring & Cover Assy-Rear-Heavy Scale	53-54-173-174 3Cpe-ClubCpes,51-54-171-174 CvBro
C 165946	Spring & Cover Assy-Rear-Heavy Scale	1946-1947 Bro
C 165948	Spring & Cover Assy-Rear-Heavy Scale	1946-1947 Sedan
C 165950	Spring & Cover Assy-Rear	178 Station
*HA 165952	Trim Ring Kit-15" Wheel	1946-1947 All,1948 thru 1950
165953	Hub Cap Kit-15" Wheel (Use 303085)	1946 thru 1949 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*HS 165955	Pib-1 Ounce	All
*HS 165956	Pib-4 Ounce	All
F 165958	Gear-Camshaft	1946-1947 All,483,484
BO 165963	Power Unit Assy-6V-Hyd Top Lift	1946-1947 CvBro
BO 165964	Hose-Short-Power Unit	1946-1947 CvBro
BO 165965	Hose-Long-Power Unit	1946-1947 CvBro
BO 165966	Tube Assy-Upper-Short	1946-1947 CvBro
F 165972	Seal-Spindle Support Arm Pivot	1946 thru 1950 All
C 165973	Tube Assy-Long	946-1947 CvBro
EM 165974	Mounting Plate-Electrical Fuel Pump	1946 6 Cyl
BM 165975	Mounting Bracket-Electric Fuel Pump	1946 6 Cyl
EM 165976	Gasket-Mounting Plate to Cyl-Elec Fuel Pump	1946 6 Cyl
BM 165977	Pipe Assy-Elec Fuel Pump to Carb	1946 6 Cyl
EM 165980	Electric Fuel Pump Assy	1946 6 Cyl
BO 165981	Wire Harness-Body Half-LHD-Overdrive	1946-1947 All
BO 165982	Wire Harness-Body Half-RHD-Overdrive	1946-1947 All
BT 165983	Wire Harness-Chassis Half-Overdrive	1946-1947 All
BO 165984	Wire Harness-Vacumotive Drive	1946-1947 All
BO 165985	Wire Harness-Direction Indicator	1946-1947 All
BT 165986	Wire Harness-Chassis Half-HDM	1946-1947 All
BO 165987	D.N.S.	
EM 165988	Wire Assy-Electric Fuel Pump to Coil	1946-1947 6 Cyl
BZ 165990	Cylinder Assy-VD	1946-1947 All
165993	Solenoid Valve Assy-VD (Use 302752)	1946-1947-1948 All
BT 165994	Relay & Wires Assy-LHD-Direction Indicator	1946-1947 All
BT 165995	Relay & Wires Assy-RHD-Direction Indicator	1946-1947 All
BZ 165998	Tube-HDM Power Unit Vacuum-on frame	1946-1947 All
BZ 165999	Tube-HDM Power Unit Intake-on frame	1946-1947 All
BZ 166001	Spring-HDM Tube Coupling	1946 thru 1950 All
EX 166015	Eccentric Bushing Assy-Spdl Supp Arm Upper	1946 thru 1950 All
BO 166017	Resistor Assy-Headlamp Dimming	1946-1947 All
BO 166018	Guard-Headlamp Dimming Resistor	1946-1947 All
BO 166019	Resistor Kit-Headlamp Dimming	1946-1947 All
BO 166020	Connector-Double-H/ Lamp Dimming	1946-1947 All,1948 thru 1950 with Back-up Lamp
BO 166021	Plate Assy-Front-Cylinder Support	1946-1947 8 Cyl
C 166027	Stay Rod Kit-Radiator	1940 6 Cyl
C 166028	Stay Rod Kit-Radiator	1940 8 Cyl
BZ 166029	Washer-V/D Valve Lever Cam Screw	1946 thru 1950 All
BZ 166031	Cover Set-Rear Half-Rear Spring	51,52,53,54
BZ 166032	Cover Set-Rear Half-Rear Spring	51,52,53,54
BZ 166033	Cover Set-Front Half-Rear Spring	51,52,53,54
BZ 166034	Cover Set-Front Half-Rear Spring	51,52,53,54
BM 166045	Pipe Assy-Oil Pump to Check Valve	53,54,173,174
*SP 166047	Pipe Plug-3/4"-Magnetic Type	All
*SP 166048	Pipe Plug-1/2"-Magnetic Type	All
*SP 166049	Pipe Plug-3/8"-Magnetic Type	All
*SP 166051	Drain Plug Kit-Magnetic	All
BZ 166054	Pipe Assy-Gas Tank to Fuel Pump	51,52,171,172
BT 166063	Valve Assy-HDM	1946 thru 1949 All,501 thru 504
BT 166064	Plate Assy-HDM Valve Contact	1946 thru 1949 All,501 thru 504
C 166066	Side Member Assy-Frame-RH	58,178
BZ 166079	Ratchet Assy-Jack	1946-1947 exc Cab-CabPu
BZ 166080	Base-Jack	1946-1947 exc Cab-CabPu
EX 166081	Bracket-Rear Axle Housing Stabilizer	1946-1947 All
*HA 166082	Direction Indicator Kit-LHD-Painted	51,53,171,173
*HA 166083	Direction Indicator Kit-LHD-Plated	52,54,172,174
C 166097	Spring Leaf-No 4-Rear	51 thru 54,171 thru 174
BZ 166101	Coil & Housing Assy-VD Throttle Lock Solenoid	1946 All
BO 166105	Wire Assy-Fuse Block to Clock-RHD	1946-1947 All
C 166131	Manifold Assy-Intake-Aluminum	53,54,173,174
*BZ 166133	Shock Absorber Assy-Front-Service	1934 Hudson
*BZ 166134	Shock Absorber Assy-Rear-Service	1934 Hudson
*BZ 166135	Shock Absorber Assy-Rear-Service	1935 Hudson
BZ 166136	Shock Absorber Assy-Rear-Service	1935 Hudson
*BZ 166137	Shock Absorber Assy-Rear-Service	1936 Hudson
BZ 166138	Shock Absorber Assy-Rear-Service	1936 Hudson
*BZ 166139	Shock Absorber Assy-Rear-Service	1937 Hudson
*BZ 166140	Shock Absorber Assy-Rear-Service	1937 Hudson
BZ 166141	Coil & Housing Assy-6V-V/D Solenoid	1946 thru 1949 All
BZ 166142	Coil & Hsg Assy-6V-V/D Throttle Lock Solenoid	1946 thru 1949 All
*BZ 166167	Shock Absorber-Rear-Service	1939 Hudson
BT 166172	Bracket-Overdrive Throttle Switch-RHD	1946-1947 All
EM 166174	Stud-Aluminum Intake Manifold	1946-1947 All,483,484
*SP 166177	Hydraulic Brake Fluid #21-12 oz	1946 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 166178	Ground Strap-Auto Sel Power Unit	1946-1947 All
BT 166182	Retainer Assy-Main Drive Gear Brg	1946 thru 1950 All
BT 166183	Thrust Washer-C/Shaft Gear Cluster-Bronze	1946 thru 1950 All
BT 166184	Shift Shaft-Transmission	1946-1947 Without HDM,1948 thru 1950 All
EX 166186	Spindle-Steering-RH	1946-1947-1948 All
BX 166187	Spindle-Steering-LH	1946-1947-1948 All
F 166188	Gear & Pinion-Rear Axle Drive-Matched 4 1/9 to 1	1946-1947 All
F 16189	Gear & Pinion-Rear Axle Drive-Matched 4 5/9 to 1	1946-1947 All
*F 166190	Case & Stud Assy-Differential	1946-1947 All
F 166191	Shaft Assembly-Rear Axle Drive	1946-1947 All
166192	Drive Plate Assy-Clutch (Use 301246)	53,54,58,173,174,178,51-52-171-172 With VD-OD or HDM
166194	Tank Assy-Gasoline-16 1/2 Gal (Use 16629	1946-1947 Bro-Sed
C 166195	Camshaft	1946-1947 6 Cyl
*C 166196	Oil Pan Assembly	53,54,173,174
F 166197	Gear Assy-Trans Reverse Idler	1946 thru 1950
C 166198	Flywheel Complete-With 9" Clutch	40,41,10,11,20-21,51-52-171-172-500 Without VD or HDM
F 166199	Guide-Inlet Valve	1946-1947 All,1948 thru 1950 8 Cyl
F 166200	Guide-Exhaust Valve	1946-1947 All,1948 thru 1950 8 Cyl
F 166201	Gasket-Cyl Head (For Cast Iron Head)	1946-1947 6 Cyl
166202	Gear-Trans Maindrive (Use 302472)	1946-1947 All,1948-1949 with HDM
F 166203	Countershaft-Transmission	1946 thru 1950
C 166204	Muffler Assembly	51,52,58,171,172,178
C 166205	Crankshaft Assembly	1946-1947 6 Cyl
BZ 166215	Washer-Strg Column to Housing	51,52,58,171,172,178
EM 166216	Fuel Pump Assy	1946-1947 All exc 8 Cyl RHD
EM 166217	Fuel Pump Assy-RHD	1946-1947 8 Cyl
*SP 166218	Pump Assy-Combination Fuel & Vacuum	1946-1947 6 Cyl
*SP 166219	Pump Assy-Combination Fuel & Vacuum	1946-1947 8 Cyl
F 166220	Hose-Radiator Outlet	1946-1947 6 Cyl
C 166221	Camshaft	1946 thru 1950 8 Cyl
C 166222	Torsion Bar Assy-F Stabilizer	1946-1947 exc Cab-CabPu
F 166224	Oil Seal Assembly-Drive Shaft	1946 thru 1950 All
F 166225	Pinion Assembly-Differential	1946 thru 1950 All
*C 166226	Carrier & Gear Set Assy-Diff-4 5/9 to 1	1946-1947 All
F 166227	Differential Gear-Rear Axle	1946 thru 1950 All
F 166228	Hose-Radiator Inlet	1946-1947 6 Cyl
F 166229	Hose-Radiator Inlet	1946-1947 8 Cyl
F 166231	Hose-Radiator Outlet	1946-1947 8 Cyl
MF 166232	Guide-Valve Tappet	1946-1947 All,1948 thru 1950 8 Cyl
F 166233	Valve Tappet	1946-1947 All,1948 thru 1950 8 Cyl
BZ 166234	Washer-Steering Column to Housing	53,54,173,174,1948-1949 All,501 thru 504
C 166235	Core Assy-Radiator	53,54,173,174
F 166237	Cable Assy-Battery to Starter Solenoid	1946-1947 All
F 166238	Connecting Rod Assy-RH	89,90,98 5Sed,40-10-20 With Std Eng
F 166239	Connecting Rod Assy-LH	89,90,98 5Sed,40-10-20 With Std Eng
F 166240	Gasket-Cylinder Head-CI	1946 thru 1950 8 Cyl .
F 166241	Connecting Rod Assy-RH	1946-1947 All,1948 thru 1950 8 Cyl
F 166242	Connecting Rod Assy-LH	1946-1947 All,1948 thru 1950 8 Cyl
166243	Piston Semi-finished	1946-1947 All
F 166244	Bushing-Piston Pin	1946-1947 All,1948 thru 1950 8 Cyl
BT 166245	Clutch Assy	51-52-171-172 Without VD-OD or HDM
F 166246	Drive Plate-Complete-tClutch	51-52-171-172 Without VD-OD or HDM
F 166247	Pressure Plate-Clutch	51-52-171-172 Without VD-OD or HDM,500 Without HDM or SMD
TF 166248	Throwout Finger-Clutch	51-52-171-172 Without VD-OD or HDM,500 Without HDM or SMD
TF 166249	Retainer-Clutch Finger	1946 thru 1950 All
TF 166250	Spring-Clutch	51-52-171-172 Without VD-OD or HDM,500 Without HDM or SMD
TF 166251	Spring-Clutch	53,54,58,173,174,178,51-52-171-172 with VD-OD or HDM,1948-1949 All,501 thru 504,500 with HDM,SMD or OD
BT 166252	Cover-Clutch	51-52-171-172 Without VD-OD or HDM
F 166253	Hearing Assy-Clutch Throwout	1946 thru 1950
*C 166254	Tank Assy-Gasoline-16 1/2 Gal	1946-1947 CvBro-3Cpe-ClubCpe
166255	Collar Assy-Clutch (Use 303855)	1946 thru 1950
BT 166256	Collar-Clutch	1946 thru 1950
EM 166257	Mounting-Engine Rear	1946-1947 6 Cyl
EM 166258	Insulator-Generator Charge Reg Term	1946 thru 1950
BO 166259	Jumper Wire Assy-Heater-RHD	1946-1947 All
BX 166260	Arm-Steering-RH	1946-1947 All
BX 166261	Arm-Steering-LH	1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

257

Part No.	Name	Models
F 166262	Thrust Washer & Ball Cup Assy	1946 thru 1950 All
*C 166263	Cylinder & Piston Assy	1940 thru 1947 6 Cyl
MF 166265	Cover Assy-Cylinder Water Jacket (Pkg 10)	51,52,58,171,172,178
MF 166266	Cover Assy-Cylinder Water Jacket	1946 thru 1950 8 Cyl
C 166268	Head Assy-Cylinder	51,52,58,171,172,178
C 166269	Head Assy-Cylinder	1946 thru 1950 8 Cyl
BM 166271	Water Outlet-Cylinder Head	1946-1947 All exc 54-174
F 166272	Thermostat-Cyl Head Water Outlet	54,174,1948 thru 1950 All
MF 166273	Gasket-Cylinder Head Water Outlet	1946-1947 All,1948 thru 1950 8 Cyl
F 166274	Support Assy-Steering Spindle-RH	1946 thru 1950 All
F 166275	Support Assy-Steering Spindle-LH	1946 thru 1950 All
F 166276	Master Cylinder Assy-Brake Control	1946-1947 All
F 166277	Gear-Flywheel	1946 thru 1950 All
F 166279	Hose Assy-Wheel Cylinder to Frame	1946-1947 All
MF 166280	Fan Blade-Water Pump	1946-1947 All
F 166281	Hub Assy-Water Pump Shaft & Pulley	1946-1947 All
F 166283	Hose-Rad Inlet & Water Pump Outlet	1946-1947 All
F 166284	Body,Shaft & Impeller Assy-Water Pump	1946-1947 exc 54,174
BM 166285	Body,Shaft & Impeller Assy-Water Pump	54,174
F 166286	Repair Kit-Water Pump	1946-1947 All
BT 166287	Lever-Handy Shift	1946-1947 All,1948-1949-1950 All LHD
C 166288	Wire,Casing & Brkt Assy-Handy Shift-With HDM	1946-1947 All LHD
C 166289	Muffler Assembly	1946-1947 8 Cyl
CF 166290	Pipe Assembly-Exhaust-LHD-Without OD	51-171 exc CvBro,52,172
CF 166292	Pipe Assembly-Exhaust-RHD & OD	51,52,171,172
CF 166294	Tail Pipe	51,52,171,172
C 166295	Hub Complete-Front	51,52,171,172
C 166296	Hub Complete-Front	53,54,58,173,174,178
C 166297	Hub Complete-Rear	51,52,171,172
F 166298	Thrust Washer-W/P Shaft Seal	1946-1947 All
166299	Fan Pulley-Vibration Dampener (Use 301935)	1946-1947-1948 All
BM 166300	Hub-Vibration Dampener	1946-1947 All
BM 166301	Vibration Dampener Assembly	1946-1947 All
C 166302	Flywheel Complete	51-52-171-172 With VD-OD or HDIVI,58,178,481,482, 1949-1950 All
C 166303	Flywheel Complete	1946-1947 8 Cyl,483,484,493,494
BZ 166304	Filler Neck Assy-Gas Tank	1946-1947 3Cpe-ClubCpe-CvBro
C 166306	Oil Pan Assembly	1946-1947 6 Cyl
BM 166307	Cover Assembly-Timing Gear	1946-1947 8 Cyl
F 166308	Valve-Inlet	1946 thru 1950 8 Cyl
BM 166309	Cover Assembly-Timing Gear	1946-1947 6 Cyl
F 166310	Gear-Crankshaft	1946-1947 All,1948 thru 1950 8 Cyl
F 166311	Valve-Exhaust	1946 thru 1950 8 Cyl
MF 166312	Pump Assembly-Oil	1946-1947 6 Cyl
166313	Pump Assembly-Oil (Use 301941)	1946-1947 8 Cyl
BM 166314	Shaft Assy-Oil Pump	1946-1947 All,1948 thru 1950 8 Cyl
MF 166315	Gear-Oil Pump	1946-1947 All,1948 thru 1950 8 Cyl
166316	Valve Assy-Oil Check (Use 301547)	1946-1947 All
BZ 166317	Spring-Clutch Pedal Assisting-LHD-Without VD-OD-HDM-SMD	1946 thru 1949,501 thru 504
BZ 166318	Ball Arm-Steering Gear-LHD	1946-1947 6 Cyl
F 166319	Pin-Rear Spring Front Mounting	1946-1947 All
F 166320	Driving Plate.Kit-Clutch	51-52-171-172 without VD-OD or HDM,500 without HDM
*SP 166324	Piston Ring Set-Cast Iron Oil Rings-Std	1936 thru 1939 6 Cyl
*SP 166325	Piston Ring Set-Cast. Iron Oil Rings-Std	1939 thru 1947 6 Cyl
*SP 166326	Piston Ring Set-Cast Iron Oil Rings-Std	1936 thru 1939 8 Cyl
*SP 166327	Piston Ring Set-Cast Iron Oil Rings-Std	1939 thru 1950 8 Cyl
*SP 166328	Piston Ring Set-With Steel Segments-Std	1936 thru 1939 6 Cyl
*SP 166329	Piston Ring Set-With Steel Segments-Std	1939 thru 1947 6 Cyl
F 166330	Valve-Inlet	1946-1947 6 Cyl
F 166331	Valve-Exhaust	1946-1947 6 Cyl
F 166332	Gear-Trans M/S Low & Reverse	1946 thru 1950 All
*C 166333	Carrier & Gear Set Assy-Diff-4 1/9 to 1	1946-1947 All
BM 166335	Grease Fitting-Water Pump Body	1946-1947 All
F 166336	Pressure Plate-Clutch	53,54,58,173,174,178,51-52-171-172 With VD-OD or HDM.1948,1949,501 thru 504,500 with HDM or SMD
C 166337	Crankshaft Assembly	1946-1947 8 Cyl
BT 166338	Cover Assy-Clutch	53,54,58,173,174,178,51-52-171-172 With VD-OD or HDM,1948,1949,501 thru 504,500 with OD,HDM or SMD
BT 166339	Throwout Finger-Clutch	53,54,58,173,175,178,51-52-171-172 With VD-OD or HDM.1948,1949,501thru 504,500 with OD,HDM or SMD
166340	Clutch Assy (Use 301251)	58,178,51-52-171-172 with VD-OD or HDM
166341	Clutch Assy (Use 301251)	53,54,173,174

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
166342	Harness-Instrument	51,53,58,171,173,178
166343	Harness-Instrument	52,54,172,174
166344	Harness-Chassis	1946-1947 All
166345	Piston Assy-.030 0/S (Use 166597 or 166598)	1946-1947 All
C 166371	Rear Spring Assy-Light Scale-With Paper Liners	1947 Sed-ClubCpe-CvBro
BM 166385	Conversion Kit-Electric Fuel Pump	1946-1947 All
BM 166387	Guard-Electric Fuel Pump	1946-1947 All
BM 166388	Pipe Assy-Electric Fuel Pump to Carb	1946-1947 All
BZ 166395	Clip-Rear Spring	51 thru 54,171 thru 174,178 Station
BZ 166397	Jack Ratchet Assembly	1946-1947 exc Cab-CabPu
BZ 166398	Jack Base	1946-1947 exc Cab-CabPu
BO 166421	Switch-Door Hinge-Plunger Type-For Courtesy Lights	52-54-172-174
BZ 166429	Bolt-Strg Gear Shaft Housing Cover	1946 thru 1950 All
BZ 166430	Gasket-Strg Gear Shaft Housing Cover	51,52,58,171,172,178,500
BZ 166431	Gasket-Strg Gear Shaft Housing Cover	53,54,173,174
*SP 166442	Piston Ring Set-CI Oil Rings-.010 0/S	36 thru 39 6 Cyl
*SP 166443	Piston Ring Set-CI Oil Rings-.020 0/S	36 thru 39 6 Cyl
*SP 166444	Piston Ring Set-CI Oil Rings-.010 0/S	39 thru 1947 6 Cyl
*SP 166445	Piston Ring Set-CI Oil Rings-.020 0/S	1939 thru 1947 6 Cyl
*SP 166446	Piston Ring Set-CI Oil Rings-.010 0/S	1936 thru 1939 8 Cyl
*SP 166447	Piston Ring Set-CI Oil Rings-.020 0/S	1936 thru 1939 8 Cyl
166448	Piston Ring Set-CI Oil Rings-.010 0/S (Use 166449)	1939 thru 1950 8 Cyl
*SP 166449	Piston Ring Set-CI Oil Rings-.020 0/S	1939 thru 1950 8 Cyl
*SP 166450	Piston Ring Set-Steel Segments-.010 0/S	1936 thru 1939 6 Cyl
*SP 166451	Piston Ring Set-Steel Segments-.020 0/S	1936 thru 1939 6 Cyl
166452	Piston Ring Set-Steel Segments-.010 0/S (Use 166453)	1939 thru 1947 6 Cyl
*SP 166453	Piston Ring Set-Steel Segments-.020 0/S	1939 thru 1947 6 Cyl
166454	Piston Ring-Upper Compression-.020 0/S	1936 thru 1947 All
166457	Piston Ring-Lower Oil-.010 0/S	1936 thru 1939 All
166458	Piston Ring-Lower Oil-.020 0/S	1936 thru 1939 All
166459	Piston Ring-Upper Oil-Cast Iron-.010 0/S	1936 thru 1947 All
166460	Piston Ring-Upper Oil-Cast Iron-.020 0/S	1936 thru 1947 All
166461	Piston Ring-Lower Oil-.010 0/S	1939 thru 1947 All
166462	Piston Ring-Lower Oil-.020 0/S	1939 thru 1947 All
166463	Piston Ring-Lower Compression-.010 0/S	1936 thru 1947 All
166464	Piston Ring-Lower Compression-.020 0/S	1936 thru 1947 All
166465	Piston Ring Segments-Upper Oil-Steel-.010 0/S	1936 thru 1947 6 Cyl
166466	Piston Ring Segments-Upper Oil-Steel-.020 0/S	1936 thru 1947 6 Cyl
BO 166468	Valve Assy-Top Control Pump Pressure Balance	1946-1947 CvBro
BO 166469	Pump Assy-Top Control	1946-1947 CvBro
BO 166470	Housing-Top Control Pump	1946-1947 CvBro
BO 166471	Rotor-Top Control Pump-Outer	1946-1947 CvBro
BO 166472	Gasket-Top Control Pump-Inner	1946-1947 CvBro
BO 166473	Reservoir & Brkt Assy-Top Control Power Unit	1946-1947 CvBro
CF 166477	Shock Absorber Assy-Front-Service	1937-1938-1939
CF 166478	Shock Absorber Assy-Front-Service	1938-1939
166479	Shock Absorber Assy-Rear-Service (Use 301770)	1937-1938-1939
F 166480	Bolt-Spindle Support Arm to Support-Lower	1946-1947 All
F 166481	Nut-Spindle Support Arm to Support Bolt-Lower	1946-1947 All
EX 166482	Nut-Spindle Support Arm to Support Bolt-Upper	1946-1947 All
BO 166483	Junction Block-Tail & Stop Lamp Wires	171 thru 174
166484	Wheel Assy-16 x 4.00-Service (Use 166486)	61 thru 67
BZ 166485	Spring Clip-Wheel Disc-For Wheel Assy 166488	58,178
C 166486 Pr	Wheel Assy-16 x 4.00-Service	1937 All,83,90,92,93,40 CvCpe
C 166486 La	Wheel Assy-16 x 4.00-Service	1937 All,83,90,92,93,40 CvCpe
C 166488 Pr	Wheel Assy-16 x 4.50	58,178
166489	Bumper Jack-Hydraulic-Complete (Use 301674)	All
*SP 166490	Piston Ring Set-Steel Segment-Standard	1936 thru 1939 8 Cyl
*SP 166491	Piston Ring Set-Steel Segment-.010 0/S	1936 thru 1939 8 Cyl
*SP 166492	Piston Ring Set-Steel Segment-.020 0/S	1936 thru 1939 8 Cyl
*SP 166493	Piston Ring Set-Steel Segment-Standard	1939 thru 1950 8 Cyl
*SP 166494	Piston Ring Set-Steel Segment-.010 0/S	1939 thru 1950 8 Cyl
*SP 166495	Piston Ring Set-Steel Segment-.020 0/S	1939 thru 1950 8 Cyl
*HA 166496	Deflector Assy-Tail Pipe Exhaust	1935 thru 1947 6 Cyl
166497	Deflector Assy-Tail Pipe Exhaust (Use 301619)	1935 thru 1947 8 Cyl
BZ 166499	Jack Handle-For Bumper Type	All
CF 166500	Conn Rod Assy-RH-Rebabbitted-Exchange-Std	1930 thru 1937 All
CF 166501	Conn Rod Assy-LH-Rebabbitted-Exchange-Std	1930 thru 1937 All
CF 166502	Conn Rod Assy-RH-Rebabbitted-Exchange-Std	89,90,40,10,20
CF 166503	Conn Rod Assy-LH-Rebabbitted-Exchange-Std	89,90,40,10,20
CF 166504	Conn Rod Assy-RH-Rebabbitted-Exchange-Std	1938 thru 1947 exc 89-90-40-10-20,1948-1949
CF 166505	Conn Rod Assy-LH-Rebabbitted-Exchange-Std	1938 thru 1947 exc 89-90-40-10-20,1948-1949
C 166507	Leaf-Spring-Rebound	For Springs 166370-71
C 166508	Leaf-Spring-#2	For Springs 166370-71-75-76-77-78

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 166510	Leaf-Spring-#3	For Springs 166370-71
C 166512	Leaf-Spring-#4	For Springs 166370-71
C 166518	Liner-Spring Leaf-Fabric Tip	For Springs 166370-71-75-76-77-78
C 166519	Liner-Spring Leaf-Fabric Tip	For Springs 166370-71
C 166522	Liner-Spring Leaf-Plain	For Springs 166370-71
C 166524	Liner-Spring Leaf-Plain	For Springs 166370-71
BZ 166526	Rebound Clip #1	For Springs 166370-71-75-76-77-78
BZ 166527	Rebound Clip #2	For Springs 166370-71
BZ 166529	Rebound Clip #3	For Springs 166370-71
BZ 166531	Rebound Clip #3	For Springs 166370-71-75-76-77-78
BZ 166532	Rebound Clip-Inner	For Spriggs 166370-71-75-76-77-78
BZ 166533	Bracket-R Spring Brake Cable Clip	For Springs 166370-71-75-76-77-78
*SP 166534	Filter-Gasoline-Carburetor	1934 thru 1950 exc 500
*HS 166548	Radiator Flush	
*C 166549	Corrosion Resistant Oil	All with Alum Cyl Hd
BO 166560	Wire Assy-Tail Lamp	1947 Cpe-CvBro
BZ 166563	Lock-Acc Pedal Link Bellcrank Support-LHD	1947 All
*F 166572	Shock Absorber Assy-Front	171 3Cpe-ClubCpe
*F 166573	Shock Absorber Assy-Rear	171 3Cpe-ClubCpe
CF 166574	Shock Absorber Assy-Front	171 Bro-Sed-CvBro
CF 166575	Shock Absorber Assy-Rear	171 Bro-Sed-CvBro
166576	Shock Absorber Assy-Rear (Use 301770)	1937 thru 1946 Commercial
*HS 166578	Tire Static Eliminator Injector	
*HS 166579	Tire Static Eliminator Powder Pkg	
C 166581	Tail Pipe	1947 Station
F 166584	Piston B	1946-1947 All,1948 thru 1950 8 Cyl
F 166585	Piston D	1946-1947 All,1948 thru 1950 8Cyl
F 166586	Piston F	1946-1947 All,1948 thru 1950 8 Cyl
F 166587	Piston J	1946-1947 All,1948 thru 1950 8 Cyl
F 166588	Piston L	1946-1947 All,1948 thru 1950 8 Cyl
F 166589	Piston P	1946-1947 All,1948 thru 1950 8 Cyl
F 166590	Piston BO	1946-1947 All,1948 thru 1950 8 Cyl
F 166591	Piston DO	1946-1947 All,1948 thru 1950 8 Cyl
F 166592	Piston FO	1946-1947 All,1948 thru 1950 8 Cyl
F 166593	Piston LO	1946-1947 All,1948 thru 1950 8 Cyl
F 166594	Piston BB	1946-1947 All,1948 thru 1950 8 Cyl
F 166595	Piston DD	1946-1947 AH,1948 thru 1950 8 Cyl
F 166596	Piston FF	1946-1947 All,1948 thru 1950 8 Cyl
F 166597	Piston B000	1946-1947 All,1948 thru 1950 8 Cyl
F 166598	Piston E000	1946-1947 All,1948 thru 1950 8 Cyl
EM 166599	Gasket-Oil Check Valve Pressure Ind Contact Pin Inner	1947 All,1948 thru 1950 8 Cyl
*C 166600	Parts Kit-Skeleton Engine Installation	1940 thru 1947 6 Cyl
*HS 166605	Rubber Lubricant-8 oz	
*HS 166606	Rubber Lubricant-1 gal	
BO 166607	Reservoir & Brkt Assy-Hyd Top Lift	1947 CvBro
BO 166610	Reservoir Cap-Hyd Top Lift	1947 CvBro
BO 166611	Gasket-Reservoir Cap-Hyd Top Lift	1947 CvBro
BZ 166623	Link-Accelerator Pedal to Bellcrank-LHD	1940-1941-1942
F 166625	Gasket-Cylinder Head (For Alum Head)	1947 thru 1950 8 Cyl
EM 166626	Tube-Exhaust Manifold Auto Choke Heater	1948 thru 1950 8 Cyl
*SP 166627	Piston Ring Set-Steel Segment-Standard	1935 thru 1939 6 Cyl
*SP 166628	Piston Ring Set-CI Oil Rings-Standard	1935 thru 1939 6 Cyl
*SP 166629	Piston Ring Set-CI Oil Rings-Standard	1939 thru 1947 6 Cyl
*SP 166630	Piston Ring Set-Steel Segment-Standard	1939 thru 1947 6 Cyl
*SP 166631	Piston Ring Set-Steel Segment-Standard	1935 thru 1939 8 Cyl
*SP 166632	Piston Ring Set-CI Oil Rings-Standard	1935 thru 1939 8 Cyl
*SP 166633	Piston Ring Set-Steel Segment-Standard	1939 thru 1950 8 Cyl
*SP 166634	Piston Ring Set-CI Oil Rings-Standard	1939 thru 1950 8 Cyl
*SP 166647	Piston Ring Set-Steel Segment-.010 0/S	1935 thru 1939 6 Cyl
*SP 166648	Piston Ring Set-Steel Segment-.020 0/S	1935 thru 1939 6 Cyl
*SP 166649	Piston Ring Set-CI Oil Rings-.010 0/S	1935 thru 1939 6 Cyl
*SP 166650	Piston Ring Set-CI Oil Rings-.020 0/S	1935 thru 1939 6 Cyl
*SP 166651	Piston Ring Set-CI Oil Rings-.010 0/S	1939 thru 1947 6 Cyl
*SP 166652	Piston Ring Set-CI Oil Rings-.020 0/S	1939 thru 1947 6 Cyl
*SP 166653	Piston Ring Set-Steel Segment-.010 0/S	1939 thru 1947 6 Cyl
*SP 166654	Piston Ring Set-Steel Segment-.020 0/S	1939 thru 1947 6 Cyl
*SP 166655	Piston Ring Set-Steel Segment-.010 0/S	1935 thru 1939 8 Cyl
*SP 166656	Piston Ring Set-Steel Segment-.020 0/S	1935 thru 1939 8 Cyl
*SP 166657	Piston Ring Set-CI Oil Rings-.010 0/S	1935 thru 1939 8 Cyl
*SP 166658	Piston Ring Set-CI Oil Rings-.020 0/S	1935 thru 1939 8 Cyl
*SP 166659	Piston Ring Set-Steel Segment-.010 0/S	1939 thru 1950 8 Cyl
*SP 166660	Piston Ring Set-Steel Segment-.020 0/S	1939 thru 1950 8 Cyl
*SP 166661	Piston Ring Set-CI Oil Rings-.010 0/S	1939 thru 1950 8 Cyl
*SP 166662	Piston Ring Set-CI Oil Rings-.020 0/S	1939 thru 1950 8 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 170000	Union-Tube-1/4"	BM 170095	Bolt-Hex Head-3/8"-16 x 1/2"
BO 170002	Lock Washer-Internal Tooth-1/2"	BO 170099	Screw-Binding Head Sheet Metal-#6x7/16"
BO 170003	Rivet-Tubular-3/16" x 5/16"	BO 170100	Mach Screw-Oval Head-#8-32 x 7/16"
BO 170004	Fuse-2 Ampere	BO 170101	Washer-Ctsk Finish #8 x 1/2"
BO 170005	Cap Screw-Self Tapping-3/8" x 7/8"	BO 170102	Nut-Hex 3/4"-28 x 7/8"
EX 170006	Lock Washer-Positive Type-5/8"	BM 170104	Grommet-1-1/16" ID-1-1/2" OD
BO 170008	Screw-Oval Head-#4 x 1"	MF 170105	Nut-Companion3/8''-24
BO 170009	Rivet-Truss Head-1/4" x 5/16"	BO 170106	Screw-Spec Head Sh Metal-#8 x 3/4"
BO 170011	Bulb-Double Cont,12-16 V,21-6CP	BO 170107	Screw-Spec Head Sh Metal-#8 x 1-1/8"
BO 170012	Bulb-Double Cont,12-16 V,50-50 CP	BO 170110	Rivet-Flat Head Sh Metal-#14x1"
BO 170013	Bulb-Single Cont,12-16 V,1.5 CP	BM 170112	Stud-5/16"-18 Stud and Nut End x 1-1/2"
BO 170014	Bulb-Single Cont,12-16 V,3 CP	BM 170113	Stud-3/8-16 Stud End 3/8-16 Nut End x 4-9/32"
BO 170015	Bulb-Single, Cont,12-16 V,15 CP	BO 170115	Wood Screw-Spec Oval Head-#10 x 1-1/4"
BO 170018	Bulb-Single Contact 12-16 V,3 CP	BO 170117	Screw-Special Oval Head Sheet Metal #10 x 5/8"
BO 170019	Bolt-Step-5/16"-18 x 2-1/4"	BO 170118	Spade Terminal-3/16"
BO 170020	Nut-Acorn-#6-32	BO 170119	Eye Terminal 3/16"
BO 170021	Bolt-Wing-1/4"-20 x 2"	BO 170120	Eye Terminal-3/8"
BO 170023	Bolt-Flat Head-1/4"-28 x 1/2" (Use 170376)	170121	Screw-Spec Oval Head Machine-#8-32 x 9/16"
BO 170024	Cap Screw-Self Tapping-7/16"x7/8"	BO 170122	Washer-1/16 x 1-3/4" x 3/32
BO 170025	Cinch Fastener-Wood Screw Type	BT 170124	Elbow-45°-1/2" Inv Flared Type
BO 170026	Wing Bolt-1/4"-20 x 11/16"	BM 170125	Elbow-5/16"-Inverted Flared Type
BO 170027	Screw-Sheet Metal-#14 x 7/8"	BM 170126	Elbow-45°-5/16"-Inv Flared Type
BO 170028	Lock Washer-Heavy Type-5/16"	BM 170127	Union-1/ 4"-Inv Flared Tube
BO 170030	Bolt-Hex Head-5/16"-24 x 1-1/4"	BM 170128	Union-5/16"-Inv Flared Tube
BO 170031	Screw-Hex Head-5/16"-18 x 1-1/4"	BM 170129	Tube Nut-5/16"-Inv Flared Tube
BO 170032	Use 70733	BM 170130	Connection-1-13/16" x 3/8" Pipe Thread x 3/4" 18 Int Thread
BO 170036	Mach Screw-Round Head #8-32 x 3/8"	BM 170131	Elbow-1/2" Inverted Flared Tube
BO 170039	Screw-SP lid SM #8 x 1-1/8" (Use 170107)	BM 170132	Connection-3 Way 2-15/32" x 3/8" Pipe x 3/4"-18
BO 170040	Screw-Spec Head Sh Metal-#8 x 7/8"	BO 170135	Screw-Binding Head-#10 x 3/4"
BO 170041	Screw-Self Tapping-#14 x 1/2"	170136	Mach Screw-Oval Head-1/4"-28 x 7/16" (Use 170254)
BO 170042	Rivet-Oval Head Tubular-1/4"x9/16"	170141	Screw-Oval Hd Mach #8-32 x 1-3/8 (Use 170417)
BT 170044	Washer-Plain-13/ 32"x3/ 4"x1/16"	BO 170142	Mach Screw-Spec Oval Head-#10-32 x 1-1/4"
BO 170045	Bolt-Hex Head-5/16"-24 x 3/4" (Use 170961)	BO 170144	Lock Washer-Int and Ext Tooth-1/4"
BO 170046	Cap-Glove Fastener Socket	BO 170145	Nut-Hex-3/8"-24 x 1/8"
BO 170047	Bolt-Flat Head-5/16"-18 x 1-1/2"	BO 170146	Lock Washer-Internal Tooth-3/8"
BO 170048	Screw-Binding Head Sheet Metal-#8 x 3/8"	BO 170147	Button-Glove Fastener-Mach Screw Type
EX 170050	Nut-Hex Slotted-9/16"-18x39/64"	BO 170148	Screw-Oval Head-#8 x 7/8"
BO 170051	Washer-Pl-19/32"xl-1/16" x 1/8"	BO 170149	Bolt-Carriage-3/8"-16 x 5"
BM 170054	Elbow-1/8" x 45 - For 1/4" Tube	BO 170153	Lock Washer-Medium #6
BO 170055	Bolt-Carriage-1/4"-20 x 1-1/4"	BZ 170155	Washer-Plain-11/ 32"xl 1/ 16"x1/ 16"
BO 170056	Nut-Spring-#8-15	BZ 170157	Mach Screw-Round Head-#10-24 x 1"
BZ 170057	Bolt-Hex Head-5/8"-18 x 3-1/4"	170159	Plain Washer-#10
EX 170058	Stud-3/8"-24 Nut End, 3/8"-16 Stud End, x 2-7/32"	BO 170160	Screw-Hex Head Sh Metal-#10x11/16"
BO 170059	Drive Screw-Spec Head #4 x 1/2"	BO 170161	Screw-Flat Head Machine-#6-32 x 5/16"
BO 170060	Screw-Binding Head Sh Metal-#10 x 3/8"	BT 170162	Screw-R/Head-4-40 x 7/16"
EX 170061	Bolt-Hex Head-3/8"-24 x 7/8	BT 170164	Lockwasher-#10 Medium
BZ 170064	Clip-1/4" Tube-for 17/64" or 9/32" Hole-Snap Type	BZ 170165	Rivet-Flat Head-3/8" x 1"
BO 170065	Clip-5/16" Tube-For 17/64" Hole-Snap Type	BZ 170166	Rivet-Flat Head-3/8" x 1-1/8"
BO 170066	Screw-Special Fillister Head-5/16"-24 x 3/4"	BO 170167	Lock Washer-Light #8
BO 170067	Set-Screw-Cup Point Headless-#10-32 x 5/8"	170169	Bolt-Hex Head 1/4"-20x5/8" (Use 9159)
BT 170069	Bolt-Hex Head Spec-3/8"-24 x 1-13/32"	170170	Washer-17/64" x 3/4" x 1-16 (Use 12857)
BT 170070	Bolt-Hex Head-3/8"-24 x 1-1/4"	BZ 170171	Washer-Pl-29/64" x 1-3/16" x 1/4"
BO 170071	Bolt-Hex Head-1/4"-20 x 1"	BO 170172	Pipe Plug-Bendix #BK-12887
BO 170072	Screw-Oval Hd Machine-#8-32 x 3/8"	BO 170173	Mach Screw-Spec Oval Head-#8-32
BO 170073	Screw-Spec Head Sh Metal-#8x7/8"	BO 170178	Washer-Plain-9/32 x 3/32 x 1/8
BZ 170076	Bearing-Roller-#15118-#15250	170179	Screw-SM-#10 x 1 (Use 170617)
F 170077	Cone-Roller Bearing-Front Wheel	BO 170182	Hex Nut-Special-#8-32 x 5/16"
BO 170078	Mach Screw-Oval Head #10-32x3/4"	170184	Bolt-Slotted Hex Head-1/4"-20x3/4" (Use 9159)
BO 170079	Wood Screw-Spec Head #8 x 7/8"	BO 170185	Washer-21/64" x 3/4" x 1/16"
BO 170080	Wood Screw-Spec Head Sheet Metal-#8x1"	BO 170186	Screw-Binding Head Sh Metal-#6x1/2"
BO 170081	Screw-Spec Head Sh Metal-#8 x 1-1/4" (Use 170242)	BZ 170187	Cable Terminal-No 2
170082	Clamp-Hose-1-7/8" (Use 70327)	BO 170188	Lock Washer-1/4" Int x 31/32" Ext
BO 170083	Mach Screw-Flat Head-#8-32xl1/2"	BO 170189	Ferrule-Rubber-1"
BO 170084	Mach Screw-Spec Fill Head #8-32x3/8"	BO 170190	Bolt-Hex Head-5/16"-24 x 2-1/2"
BZ 170085	Bolt-Carriage-3/8"-16 x 1-3/16"	BZ 170191	Washer-Plain-3/ 16"x3/ 8 "xl/ 32"
BZ 70087	Nut-Companion-3/8"-16	170192	Washer-Plain-33/64x13/16x1/8 (Use 157178)
170088	Terminal-Wire-15 Amp (Use 170406)	BZ 170194	Washer Plain-3/16"x3/8"xl/64"
BO 170089	Terminal-Wire-15 Amp	BO 170195	Bolt-Hex Head-1/4"-20x1-1/2"
170090	Terminal-Wire-15 Amp (Use 170562)	BO 170196	Washer-Finish-#6
BO 170091	Terminal-Wire-15 Amp	BO 170197	Rivet-Oval Head Tubular-1/8"x7/32"
BT 170094	Steel Ball-7/ 16"		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 170198	Bolt-Hex Head-7/16"-14 x 2"	BO 170288	Screw-Fillister Head Sheet Metal-#12
BO 170200	Screw-Oval Head Sh Metal-#6 x 3/4"	BZ 170289	Nut-Hex-5/16"-24 x 3/8"
BO 170201	Rivet-Oval Head Tubular-1/8"x3/16"	170290	Ferrule-Rubber-1/2" (Use 170303)
BO 170202	Nut-Hex-5/16"-24 x 7/32"	170291	Use 71554
BO 170204	Fuse-3 Ampere	BO 170292	Screw-Flat Head Mach-1/4"-20 x 1-7/8"
BZ 170205	Yoke-Adjustable-3/ 4"-24	BO 170293	Screw-Flat Head Mach-#10 x 1"
BO 170206	Screw-RH Mach-#12-28 x 1/2"	BZ 170294	Bolt-Hex Head-5/16"-18 x 2-7/16"
BO 170207	Bulb-Headlamp	BO 170295	Fastener-Cinch-Double
BZ 170210	Bolt-Hex Head-5/16"-24 x 1-1/8"	BO 170298	Bolt-Hex Head-1/4-20 x 1-3/4
BO 170211	Screw-Fill Head Sh Metal #12	BO 170300	Washer-Spring Type-3/8"
BO 170214	Spring Nut-#12	BO 170301	Screw-Rd lid Mach-#12-28 x 9/16"
EX 170215	Bearing Assy-170216 Cone-170217 Cup	BO 170303	Grommet-Rubber
F 170216	Cone-For 170215 Assembly	BO 170304	Screw-Sheet Metal-#8 x 1/2"
F 170217	Cup-For 170215 Assembly	BO 170306	Bolt-Hex Head-5/16"-24 x 3-3/4"
BX 170218	Bearing Assy-170219 Cone-170220 Cup	BO 170307	Screw-Fl Hd Mach-5/16"-24 x 1-1/8"
F 170219	Cone-For 170218 Assembly	BO 170309	Bolt-Hex Head-9/16"-18 x 1-3/4"
F 170220	Cup-For 170218 & 170515 Assembly	BM 170310	Terminal-High Tension
EX 170221	Bolt-Hex Head-3/8-24 x 1-15/16"	BO 170311	Tee Nut-5/16"-24
BO 170222	Screw-LH Machine #8-32	BO 170312	Bolt-Flat Head-5/16" x 1-3/4"
BT 170224	Set Screw-Allen Head-1/4"-20x1/4"	BO 170313	Bolt-Flat Head-5/16"-24 x 1-7/8"
BT 170225	Screw-Fill Head Machine-5/16"-18x15/ 10"	BO 170315	Tip-Binding-Nickel Plated
BT 170226	Key-Woodruff-.196 x .0938	BO 170316	Screw-Spec Head-#6-32 x 9/16"
BT 170227	Washer -Plain-1/ 4"x7/ 16"x3/ 64"	BO 170317	Bolt-Hex Head-1/4"-20 x 4-1/2"
BT 170228	Companion Nut-5/16"-18 x .140	BO 170320	Wood Screw-Phillips Head-#4 x 5/8"
BT 170229	Ball Joint -3/8"-24	BO 170321	Wood Screw-Flat Head-#14 x 3"
BT 170230	Nut-Hex Head-3/8"-24 x 7/32"	BT 170322	Washer-Plain-25/64" x 3/4" x 1/64"
170231	Bolt-Hex Head-1/4"-20 x 5/8"	BO 170326	Screw-#4 x 11/32" Binding Head
BO 170232	Bolt-Hex Head-3/8"-16 x 3/4"	BO 170327	Screw-Fillister Head-1/4"-28 x 5/8"
BX 170233	Bearing Assy-170234 Cone-170235 Cup	BM 170328	Pin-Straight-1/8" x 13/16"
F 170234	Cone-For 170233 Assy	BO 170329	Washer-Plain-33/64" x 1" x 1-1/16"
F 170235	Cup-For 170233 Assy	BO 170330	Lockwasher-Int & Ext Tooth-1/4"
BO 170236	Eyelet-Cinch Fastener	BO 170331	Nut-Spring-1/8"
BO 170237	Screw-Oval Head Sheet Metal-#10 x 3/4"	BO 170332	Screw-Fillister Head Sheet Metal-#12
BO 170238	Screw-Spec Head Sheet Metal-#8 x 3/4"	EX 170333	Bolt-Hex Head-1/2"-20 x 3-7/16"
C 170239	Screw-Spec Head Sheet Metal-#8 x 3/8"	170334	Use 170352
BO 170240	Screw-Spec Head Sheet Metal-#8 x 1"	BX 170335	Bearing Assy-#916 Wide Double Row
BO 170242	Screw-Spec Head Sheet Metal-#8 x 1-1/4"	EX 170336	Bolt-Hex Head-3/8"-24 x 1-3/4"
BO 170243	Washer-Plain-11/ 32"x3/ 4"x3/ 32"	EX 170337	Bolt-Hex Head-7/16"-20 x 1-5/16"
BO 170245	Screw-Oval Head-#10 x 1-1/4"	EX 170338	Bolt-Hex Head-I/2"-20 x 1-5/16"
BO 170246	Screw-Oval Head-#8 x 1-1/4"	EX 170339	Rivet-5/8" x 2-3/8"
170247	Screw-Oval Head-#10 x 1-1/2" (Use 170245)	BT 170340	Ball joint-3/8-24
F 170248	Nut-Drive Pinion-3/4"-16 x 9/16"	BM 170341	Bolt-Hex Head-7/16"-20 x 2-3/4"
BO 170250	Screw-Oval Head-#8 x 1-1/4"	BM 170342	Bolt-Hex Head-7/16"-20 x 3
170251	Screw-Flat Head-#10 x 3/4" (Use 170293)	BM 170343	Nut-Hex Self Locking-7/16"-20
BT 170252	Pin-Straight-.187 x 9/16"	BO 170344	Nut-Clinch-1/4"-28
BO 170253	Screw-Flat Head Mach-1/4"-20 x 5/8"	170345	Wood Screw-Cross Recess Head-#8 x 7/8"
BO 170254	Screw-Oval Head Mach-1/4"-20 x 7/8"	(Use 170255)	
BO 170255	Screw-Oval Head Wood-#8 x 7/8"	170346	Bolt-Carriage (Use 70715)
170256	Screw-Oval Head Mach-#8-32 x 1-3/8"	BZ 170347	Screw-Sheet Metal-#10 x 1/2"
(Use 170417)		BZ 170348	Washer-Plain-1-1/32" x 1-5/8" x 1/ 16" '
BO 170257	Screw-Oval Head Mach-#10 x 32 x 1-1/4"	BZ 170349	Washer-Plain-1-1/32" x 1-5/8" x 1/8"
BO 170258	Screw-Button Head Wood-#8 x 1-1/2"	BZ 170351	Screw-Cross Rec Sht Metal-#8 x 1-1/2"
170259	Bolt-Hex Head-#10-32 x 3/8"	BZ 170352	Nut-Self Locking-1/2"-20
(Use 70112 & 71518)		BO 170354	Nut-Clip Type-#10
170263	Nut-Spring Type-5/32" Stud (Use 170941)	BO 170355	Screw-Oval Cr-Recess Hd Machine-#10-32 x 1"
BO 170264	Set Screw-Cup Point-Fillister Head-#10-32 x 11/16"	BO 170356	Bolt-Hex Head-#8-32 x 3/8"
BO 170265	Bolt-Hex Head-5/16"-18 x 1-1/4"	BO 170357	Screw-Oval Cross Recess Head Machine-#10-32 x 2"
BO 170267	Screw-Fillister Head Mach-#10-32	BO 170358	Nut-Spring Type-1/4"
BO 170269	Hole Plug-17/64"-Steel	BO 170359	Screw-Spec Head Machine-#10732 x 1/2"
170271	Fastener-Cinch-Long Single (Use 170295)	BO 170360	Bolt-Carriage-1/4"-20 x 1/2"
BO 170272	Spring Nut-#12	170361	Use 17421
BO 170273	Screw-Round Head Mach-#6-32 x 3/16"	BZ 170362	Nut-Weld Anchor-3/8"-24 x 11/32"
BO 170274	Washer-Plain-13/64" x 1-1/4" x 1/16"	*SP 170363	Bulb-Mazda #1154,6-8 Volt,21-3 CP
BO 170275	Cap Screw-Hex Socket Fillister Head-5/16"-18 x 1"	BO 170364	Bulb-Mazda #1016,12-16 Volt,21-6 CP
BO 170276	Lock Washer-Ext Tooth-#12	BO 170365	Rivet-Oval Head Tubular-1/4" x 3/8"
BO 170277	Bolt-Hex Head-5/16"-24 x 1"	BZ 170366	Nut-Companion-1/2"-20
BM 170278	Elbow-90-1/8 Int x 1/8" Ext Pipe Thread	BO 170367	Screw-RH-Machine-#10-32 x 1/2"
BO 170279	Pipe Plug-Slotted Headless-3/4"-20	BO 170368	Washer-Plain 13/64" x 7/8" x 1/16"
BM 170282	Elbow-1/8" Pipe Thread x 90-For 1/4" Tubing	BO 170369	Screw-RH Machine #4-40 x 1/4"
BT 170283	Washer-Plain-41/64" x 1 x 1/32"	BO 170370	Bolt-Hex Head-5/16"-24 x 1-1/2"
BO 170284	Washer-Plain-25/64" x 1-1/8" x 1/8"	BO 170371	Bolt-Hex Head-5/16"-24 x 1-3/4"
BO 170287	Screw-Round Head-1/4"-20 x 3/4"	BZ 170372	Bolt-Hex Head-7/16"-20 x 1"

Part No.	Name	Part No.	Name
BX 170373	Nut-Hex Slotted-3/4"-16 x 13/16"	BO 170454	Nut-Wing-1/4"-20
BX 170374	Washer-Plain-49/64" x 1-3/4" x 1/8"	BO 170455	Lock Washer-Int Tooth-1/4"
BO 170375	Screw-Oval Cross Recess Head Machine-1/4"-20 x 9/16"	BO 170456	Grommet-Rubber-3/16"
BZ 170376	Screw-Oval Cross Recess Head Machine-1/4"-28 x 1/2"	BO 170457	Screw-Round Head Mach-#10-32x1/2"
170377	Use 170441	BO 170459	Washer-Plain-7/32 x 1/2" x .032
BZ 170378	Grommet-Rubber-#6	BO 170460	Bulb-50 Amp-2 C.P.
EM 170379	Tube Nut-Inverted Flared Type-3/16"	BO 170462	Screw-Binding Head Drive- #4-11/ 32"
EM 170380	Elbow-3/16"-45°	170463	Bolt-Spec Hex Head-5/16"-18x19/32" (Use 395 & 71638)
EM 170381	Connector-Inverted Flared Tube-3/16"	BO 170464	Pal Nut-#10
BT 170382	Bolt-Hex Head-3/8"-16 x 1-15/16"	BO 170466	Hole Plug-7/8"
BT 170383	Bolt-Hex Head-3/8"-16 x 2-5/8"	BO 170468	Rivet-Truss Head-3/8" x .182
BO 170384	Lock Washer-#10 Int Ext Tooth	BZ 170469	Bolt-Hex Head-7/16"-20 x 1-3/8"
BO 170385	Screw-Hex Head Combination-3/8"-16 x 7/8"	BO 170470	Screw-Flat Head Mach-5/16"-24 x 1"
EM 170386	Fitting-Pipe-5/16" x 1/8" x 45°	BO 170471	Screw-Cross Recess Sheet Metal-#8 x 1/2"- Chrome
EM 170387	Fitting-Pipe-5/16" x 1/8" x 900	BO 170472	Screw-Cross Recess Sheet Metal-#8 x 1/2"- Parkerized
BO 170389	Screw-Cross Recess Oval Head #10-32 x 1/2"	BZ 170473	Bolt-Hex Head-1/2"-20 x 1-1/2"
BO 170390	Screw-Cross Recess Oval Head-#6-32 x 1/2"	BO 170474	Staple-Wire-3/64" x 3/8" x 13/32"
BT 170391	Lock Washer-Internal Tooth-7/16"	BO 170477	Lock Washer-External Tooth-7/16"
BO 170392	Bolt-Hex Head-5/16"-18 x 1/2" '	BZ 170478	Rivet-Flat Head-5/16" x 1-1/8"
BO 170393	Screw-Oval Head-#6-32 x 5/16"	BZ 170479	Lock Washer-7/16"-Cadmium
BO 170395	Lock Washer-Ext Tooth-3/16"	BO 170480	Fuse-14 Ampere-Nickle Plated
BT 170396	Washer Plain-25/64" x 3/4" x 1/16"	BT 170481	Lock Washer-#6-Cadmium
BO 170397	Screw-Round Head Machine-#8-32 x 3/16"	BO 170482	Staple-1/ 4"-Chisel Point
F 170398	Nut-Self Lock-3/4"-16 x 9/16"	170484	Bolt-Hex Head-5/16"-10 x 7/8"- Parkerized (Use 170993)
BO 170399	Bolt-Hex Head-#10-32 x 4-1/2"	BZ 170485	Clip Nut-5/16"-10-Black
BO 170400	Pin-Straight-1-7/16" x 1/8 Dia	BO 170486	Screw-Filister Head-5/16"-24 x 3/4"-Nickle
BO 170401	Screw-Spec Head Mach-#6-32 x 5/16"	BT 170487	Set Screw-Allen Head-1/4"-20 x 1/4"-Nickle
BO 170402	Lock Washer-Ext Tooth-#6	BZ 170488	Washer-Plain-11/ 32"x 1-1/4"x 1/ 8"-Parkerized
BO 170403	Nut-Self Locking-5/16"-24	BT 170492	Washer-Plain-25/64" x 1-1/4" x 3/32"
170404	Screw-Spec Fil Hd Mach-#10-32 x 3/8" (Use 171032)	BT 170493	Pin-Straight-5/32" x 9/16"
BO 170405	Nut-Self Locking-3/8"-16	BT 170494	Pin-Straight-5/32" x 45/64"
BO 170406	Terminal-Wire-Bullet Type	170495	Nut-Hex Slotted (Use 170705)
BO 170407	Screw-Cross Recess Sheet-Metal-#10 x 7/8"	BT 170496	Pin-Groove-1/8" x 1"
170408	Screw-#6-32 x 1/2" (Use 170393)	BT 170497	Pin-Straight-5/32" x 15/32"
F 170409	Bearing-ND #3206	BO 170498	Drive Screw-Round Head-#6 x 3/8"
EM 170410	Elbow-1/8"-7/16"-20 x 90°	BO 170499	Bolt-Hex Head-5/16"-18 x 23/32"
EM 170411	Union-1/8"-7/16"-20 x 1/2"-20 x 90°	BO 170500	Combination Screw-Oval Hd-5/16"-24 x 3/4"
BO 170412	Screw-Spec Head Machine-1/4"-28 x 1/2"	BO 170501	Combination Screw-Hex Hd-5/16"-24 x 7/8"
170413	Use 170359	BO 170502	Washer-Plain-29/64" x 1" x 3/32"
BO 170415	Screw-Flat Head Mach-#10-32 x 5/8"	BZ 170504	Screw-5/16 x 5/8
BO 170416	Screw-Flat Head Mach-#10-32 x 2-3/8"	BO 170505	Bolt-Self Tapping-3/8" x 16 x 1-1/4"
BO 170417	Screw-Flat Head Mach-#8-32 x 1-5/16"	BT 170506	Pin-Taper-#00 x 1-1/2"
BZ 170418	Bolt-Hex Head-1/2"-13 x 5"	BT 170507	Spring Washer-3/8"
BZ 170419	Bolt-Carriage-5/16"-18 x 3"	BT 170509	Rivet-Oval Head Tubular-3/16" x 3/4"
170420	Fuse-20 Ampere (Use 160938)	BZ 170510	Spring Nut-5/16"-18
BO 170421	Nut-Spring Type-#2-56	BO 170511	Combination Screw-5/16"-24 x 3/4"
BO 170422	Nut-Spring-1/8"	BO 170512	Screw-Oval Head Machine #8-32 x 1/2"
BO 170424	Bolt-Spec Hex Head-1/4"-28 x 3/4"	BO 170513	Spring Nut-#8-32
BO 170425	Fuse-10 Ampere	BO 170514	Screw-Sheet Metal-#10 x 5/8"
BO 170427	Spring Nut-3/16"	BX 170515	Bearing Assy-170516 Cone-170220 Cup
170428	Screw-Sheet Metal-#10 x 1-1/2" (Use 170618)	F 170516	Cone-For Assembly 170515
BO 170429	Nut-Clip Tube-#12	BX 170517	Nut-Hex-7/16"-20 x 3/8"
BO 170430	Screw-Cross Recess Sheet Metal-#12 x 3/4"	BO 170518	Bulb-Mazda 1209 S
BO 170431	Screw-Cross Recess Comb-1/4"-28 x 1/2"	BO 170519	Screw-10 x 1/2" Sheet Metal
BO 170433	Washer-Plain-3/ 16"x9/ 16"x1/ 32"	BO 170520	Nut-Hex-7/16"-20 x 3/8"
BO 170434	Lock Washer-13/64x13/32x1/64"	BO 170521	Pin-Straight-1-11/16"
BO 170435	Hex Nut-Brass-#10-32 x 3/8"	BO 170522	Screw-Round Head-#10-32 x 7/16"
BO 170437	Screw-Special Head Machine-#10-32 x 1/4"	BO 170523	Spring Clip-Stud-3/16"
BO 170438	Screw-Cross Recess Machine-1/4-28 x 9/16"	BO 170524	Nut-Hex-1/2"-24 Special
BO 170439	Rivet-FH Tubular-1/4" x 7/16"	BZ 170525	Nut-Square-3/8"-16 x 5/16";
170440	Use 170462	BZ 170526	Bolt-Hex Head-3/8"-16 x 1-1/4"
BO 170441	Screw-Cross Recess Combination-1/4"-28x11/16"	170527	Bolt-Carriage-7/16"-14 x 1-7/8"
BO 170442	Screw-Cross Recess Oval Head Sheet Metal-#10 x 3/4"	BO 170528	Bulb-Fog Lamp-Mazda #1211-S
BO 170443	Spring Washer-3/8"	BO 170529	Clip Nut-#10
BO 170446	Washer-Special-.225 x 3/4" x 3/64"	BO 170530	Tee Nut-#12-28
BO 170447	Bolt-Hex Head-5/16"-24 x 5/8"	*SP 170531	Bulb-Mazda #1129-3 Amp/21 C.P.
BO 170448	Screw-Binding Head Sheet Metal #10 x 5/8"	BZ 170533	Yoke End-Adjustable-5/16"
170449	Use 170147	BT 170534	Bolt-Hex Head-7/16"-14 x 1-1/8"
BO 170450	Screw-Oval Head Machine-#6-32 x 7/16"	BT 170535	Bolt-Hex Head-5/16"-18 x 5/8"
BO 170451	Nut-Hex-Nickel-3/8"-16	BT 170536	Screw-Hex Head Sheet Metal-#14 x 5/8"
BO 170453	Washer-Plain-3/8 x 1-17/32 x .065		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BO 170537	Nut-Speed-#14	BO 170633	Screw-Sheet Metal-#10 x 7/16"
BO 170538	Screw-Sheet Metal-#10 x 3/8"	BO 170634	Screw-Sheet Metal-#6-22 x 1/4"
BM 170539	Washer-17/32" x 13/16" x 1/16"	BO 170640	Bolt-Step-1/4"-20 x 1-1/4"
170540	Use 12371	BO 170641	Bolt-Step-1/4"-20 x 1-1/2"
BO 170541	Screw-Fillister Head Machine #10-32 x 1/2"	BO 170642	Bolt-Step-1/4"-20 x 2-1/4"
BZ 170542	Pin-Clevis-1/4" x 17/32"	BO 170643	Screw-5/16"-24 x 3/4"-Comb
BO 170544	Screw-Oval Head Sht Metal-#8 x 1/2"	170644	Screw-5/16"-24 x 3/4"-Comb (Use 171419)
BZ 170545	Pin-Clevis-1/4" x 11/16"	BO 170645	Rivet-9/64" x 1/4" Tubular-Oval Head
BO 170546	Screw-Rd Head Machine-10-32 x 3/4"	BX 170646	Needle Bearing Assembly
BO 170548	Screw-Hex Hd Sht Metal-#14 x 1-1/2"	BT 170647	Stud-5/16"-18 x 1-11/16"
BO 170551	Screw-Oval Hd Sheet Metal-#8 x 3/4"	BZ 170648	Screw-Self Tapping-3/8" x 7/8"
170552	Use 170471	BZ 170649	Bolt-Hex Hd-7/16"-20 x 1-1/2"
BT 170553	Nut-Hex-7/16"-20 x 1/8"	BT 170650	Screw-Headless Set-5/16"-24 x 15/16"
BT 170554	Stud-5/16"-18 x 2-11/16"	BT 170651	Nut-Hex-5/8"-18 x 3/16"
BT 170555	Bolt-Hex Head-3/8"-16 x 2-1/8"	BT 170652	Washer-Plain-21/32" x 7/8" x 3/32"
BO 170556	Screw-Fillister Hd Machinc-#12-24 x 5/8"	BZ 170653	Screw-Machine-Round Hd-6/32 x 5/8"
BO 170557	Screw-Flat-Hd Machine-#10-32 x 1/2"	BM 170654	Stud-3/8"-16 x 1-3/8"
BO 170558	Screw-Oval Head-#8-32 x 1"	BO 170656	Screw-Binding Head-6-32 x 3/8"
BZ 170559	Nut-Square-5/16"-24	BO 170657	Pin-Taper-00 x 1-1/4"
F 170560	Spring Washer-3/8" x 25/32"	BO 170658	Lockwasher-Medium #6
BO 170561	Rivet-Oval Split-9/64" x 7/8"	*SP 170659	Bulb-15 CP-DC-#88
BO 170562	Terminal-Wire-15 Amp Douglas	BO 170661	Rivet-Tubular-Oval Head-3/8" x 9/16"
BO 170563	Screw-Combination-1/4"-28 x 3/8"	BZ 170662	Screw-Sheet Metal-Oval HD-6-3/8"
BT 170564	Plug-1/2"-14 Extension Head	BT 170663	Washer-Plain-29/64" x 13/16" x .042
BO 170566	Bolt-Square Head-1/4"-20 x 1-1/4"	BZ 170664	Elbow-45°-1/2" Tube
BO 170567	Nut-Hex-8-32 x 3/32"	BZ 170665	Connection-Taper Pipe-3/8"-18
BZ 170571	Nut-7/16"-14 Self Locking	BZ 170666	Connection-Two Way-3/8"-18
BO 170572	Screw-#8 x 3/4" Sheet Metal	BZ 170667	Connection-Tee-Two Way-3/8"-18
BO 170573	Tee Nut-#10-32	BO 170668	Nut-Hex-5/16"-18 x 17/64"
BO 170574	Bolt-8-32 x 1/4"	BO 170669	Button-Clinch-1"
BO 170575	Speed Nut-3/16"	BO 170670	Nut-Acorn-1/4"-20
170576	Lockwasher-3/8" Ctsk Ext Tooth(Use 70177)	BO 170671	Screw-Machine-Oval Head-1/4"-28 x 1-1/2"
BT 170577	Screw-Fillister Hd Mach-5/16"-18 x 15/16"	BO 170672	Screw-Machine-Oval Head-1/4"-28 x 1/2"
BO 170578	Bolt-Hex Head-5/8"-18 x 4-1/2"	BO 170673	Nut-Spring Type-5/32"
BO 170579	Screw-Flat Hd Machine-12-24x5/16"	BO 170674	Nut-Spring Type-3/16"
BO 170580	Rivet-Ctsk Head 3/16" x 1/2"	BO 170675	Elbow-1/4" Pipe x 1/2" x 90°
BO 170581	Screw-Sheet Metal-#10 x 3/8"	F 170676	Clamp-Hose-1-7/8"
BZ 170582	Screw-Rd Hd Machine-10-32 x 1"	BZ 170678	Nut-3/8" Tube
BZ 170583	Screw-Rd Hd Machine-10-32 x 1"	BO 170679	Screw-10-32 x 1-1/2" Oval HD
BO 170584	Screw-Flat Hd Machine-1/4"-20x1/2"	BT 170680	Bolt-1/4"-20 x 7/8 Fillister Hd
BO 170585	Bolt-Fillister Head-5/16"-24 x 2"	BO 170681	Terminal-Ware
BO 170587	Wood Screw-Oval Head-#12 x 1"	BO 170685	Screw-Binding Head Sheet Metal-#6 x 3/8"
BO 170593	Screw-Truss Head-1/4"-20 x 1/2"	BO 170686	Connector-6 Wire Line
BO 170594	Screw-Oval Hd Machine-#8-32 x 3/4"	BO 170687	Screw-#10 x 1/2" Rd Hd Sheet Metal
170595	Use 163760	BT 170688	Elbow-3/8" Inverted Flared Tube
BO 170596	Washer-Plain-7/16" x 2-1/2" x 1/16"	BO 170689	Bulb-6V-32 CP-Mazda 1323
BO 170600	Screw-Oval Head-1/4"-20 x 1-3/8"	BO 170690	Bulb-6V-50 CP-Mazda 1503
BO 170601	Wood Screw-Oval Head-#14 x 1-1/2"	BO 170691	Fuse-3 Amp
BO 170602	Screw-Combination-1/4"-28 x 1/2"	BO 170692	Clip-Spring Type-3/16" Stud
BO 170603	Tee Nut-#10-32	BO 170693	Screw-Rd Head Machine-#8-32 x 1/2"
BO 170604	Bolt-Hex Head-5/16"-10 x 5/8"	BO 170694	Screw-#6 x 1/4" Binding Head
BO 170606	Screw-Binding Head Mach-10-32 x 3/4"	170695	Washer-29/64" x 12/16" x .042 (Use 170663)
BO 170607	Rivet-Tubular-9/64" x 1/2"	BO 170696	Bolt-Carriage-1/4"-20 x 1/2"
170608	Rivet-Tubular-9/64" x 3/4" (Use 170561)	BO 170698	Bolt-Square Head-1/4"-20 x 2"
BO 170609	Screw-#8 x 1" Round Head Sheet Metal	BO 170700	Screw-Sheet Metal-#8 x 1-5/16"
170610	Screw-Sheet Metal-1/2"-12 (Use 170707)	BZ 170701	Nut-#6-32 x 3/32" Hex
BO 170611	Lock Washer-#10 Light	BO 170702	Clip-For 3/16" Stud
BO 170612	Bolt-Hex Head-5/16"-24 x 1-3/4"	BO 170703	Screw-Sheet Metal-#8 x 5/8"
170613	Fuse-30 Ampere (Use 160939)	BT 170704	Plain Washer-25/64" x 27/32" x 1/16"
BZ 170614	Washer-Plain-11/32" x 1-1/2" x 1/8"	BT 170705	Nut-3/4"-16 x 21/32"
BO 170615	Socket-Fastener	BO 170707	Screw-#10 x 1/2"-12 Binding Head
BO 170616	Screw-Flat Head Mach-6-32 x 3/4"	BO 170708	Screw-#8 x 1-5/16" Sheet Metal
BO 170617	Screw-Sheet Metal-#10 x 1"	BZ 170709	Washer-.317 x 5/8 x 1/32
BO 170618	Screw-Sheet Metal-#10 x 1-1/2"	BO 170710	Lockwasher-9/32 x 15/32 x 3/64
BZ 170619	Pin-Escutcheon-3/8"	BM 170742	Washer-Plain
BO 170620	Bolt-Carriage-5/16"-24 x 3/4"	BZ 170767	Bolt-Hex Head-3/8-24 x 1
BO 170623	Screw-Sheet Metal-#12	BT 170770	Bolt-Hex Head-3/8-24 x 1-3/4
BO 170624	Bolt-Carriage-5/16"-18 x 1-3/4"	BZ 170772	Bolt-Hex Head-3/8-24 x 3
BT 170625	Washer-Plain-29/64 x 5/8"	BM 170789	Bolt-Hex Head-3/8-16 x 2-1/4
BO 170627	Bolt-Hex Head-3/8"-24 x 3-1/2"	BO 170794	Bolt-Hex Head-1/4-28 x 1
BO 170628	Bolt-Hex Head-3/8"-24 x 4-1/2"	BO 170806	Nut-Hex-#6-32 x 7/64
BO 170629	Nut-3/16" Spring Type	BO 170852	Lock Washer-1/4-Int Tooth
BO 170630	Washer-Plain-21/32"	BZ 170857	Rivet-Round Head-3/8 x 1-1/8
BZ 170631	Rivet-Round Head-5/16" x 11/16"	BZ 170858	Rivet-Round Head-3/8 x 1

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BZ 170859	Nut-Hexagon-3/8-16 x 21/64	BM 170983	Bolt-Hex Head-5/16-24 x 2
BO 170864	Lock Washer-Heavy-1/2"	BX 170985	Lockwasher-3/8
BO 170869	Screw-Round Head-#10-32 x 1-3/4	BO 170986	Nut-Clinch-1/4-28
170872	Lock Washer-Special-5/16	BO 170987	Screw-Metal-Flat Hd-#8 x 1/2
BO 170873	Nut-Spring-3/16 x 5/16	BM 170990	Stud-3/8-16 x 1-5/8
BO 170874	Screw-Round Head Combination-#6-32 x 1/4	BM 170991	Stud-3/8-16 x 1-15/16
BO 170875	Screw-Round Head Machine-#10-24 x 13/16	BM 170992	Stud-3/8-16 x 3-1/2
BO 170876	Screw-Round Head Machine-#10-24 x 5/8	BZ 170993	Bolt-Hex Head-5/16-10 x 1
BM 170877	Pipe Plug-Square Head-Aluminum-3/8"	BO 170994	Screw-Sheet Metal-Binding-Head-#10 x 3/4
BT 170879	Lock Washer-Special-5/16	BX 170996	Needle Bearing-Center Steering Arm
BT 170880	Screw-Self Locking Set-1/4-28x 7/16-Cadmium	BX 170997	Locknut-5/8-18
BT 170881	Screw-Self Locking Set-1/4-28x 7/16-Nickel	BX 170998	Taper Pin-Center Steering Arm
170882	Spring Nut-For 1/8 x 5/8 Stud	BT 170999	Lock Washer-3/32
BO 170885	Screw-Cross Recess Machine-10-32 x 7/8	BM 171000	Bolt-Hex Head-3/8-16 x 1-1/4
BO 170886	Washer-Finish-#10 Countersink	BO 171001	Screw-#6-32 x 3/8
BO 170887	Screw-Cross Recess Machine-10-32 x 1-1/4	BO 171002	Screw-Comb Oval Head-1/4-28 X 1/2
BO 170888	Speed Nut-Tinnerman Flat Type-4 z	BO 171003	Washer-Flat-15/32 x 15/16 x 1/16
BO 170889	Screw-Phillips Head #4 Pk Type z	BO 171004	Nut-Clinch-5/16-24
BO 170890	Lock Washer-Internal Tooth-Special-5/16	BZ 171005	Nut-Clinch-3/ 8-24
BO 170891	Screw & Washer Assy-#6-32 x 3/8	BO 171006	Nut-Clinch-1/4-28
BM 170894	Stud-Cylinder Head	BO 171007	Nut-Spring-1/12A
BM 170897	Plug-Intake Manifold Expansion 3/4"-(Alum)	BZ 171008	Screw-Comb Machine-1/4-28 x 7/16
BM 170898	Bolt-Hex Head-3/8-16 x 7/8	BO 171011	Clevis Pin-1/4 x 2-1/8
BM 170899	Screw-Phillips Countersink Head-3/16-16 x 3/4	BO 171012	Screw-Machine-#8-32 x 7/8
BO 170900	Clevis Pin-3/8 x 1-21/32	BZ 171013	Screw-Self Tapping-#14 x 5/8
170903	Bolt-Square Head-1/4-20 x 1-1/2"	BO 171014	Rivet-Oval Head-3/8 x 1/2
BO 170905	Nut-1/2-27 x 3/16	BO 171015	Clevis Pin-3/8 x 9/16
BO 170926	Washer-Grip-1/2 x 3/4	171016	Nut-Self Locking-7/8-14 x 49/64 (Use 171325)
BO 170927	Bolt-Spec Head-1/4-20 x 1/2"	BO 171017	Screw-Sheet Metal-#10 x 7/8
BM 170928	Bolt-Hex Head-1/4-20 x 3/8	BZ 171018	Nut-Anchor-7/16-20 x 13/32
BM 170929	Clamp-Hose-5/8"	BZ 171019	Screw-Cross Recess-#8-32 x 3/8
170931	Screw-Hex Head-7/16-14 x 1"	BO 171020	Nut-Clinch-#8-32
BO 170932	Bolt-Flat Head-1/4-20 x 1-1/4"	BO 171023	Screw-Cross Recess-#10-32 x 5/8
130 170933	Bolt-Flat Head-1/4-20 x 2-1/4"	BO 171024	Bolt-Hex Head-5/16-24 x 1/2
BO 170934	Bolt-Flat Head-5/16-18 x 1-1/2"	BZ 171025	Washer Plain-3/8 x 7/8 x 1/16
BO 170935	Bolt-Flat Head-5/16-18 x 2-1/4"	BO 171027	Trim Clip-Double Loop
BM 170938	Plug-3/8" Expansion-Cast Iron	BM 171028	Pin-Straight-5/32 x 7/8
170939	Bolt-Hex Head-5/8-18 x 4-1/2	BM 171029	Bolt-Hex Head-3/8-16 x 2-1/2
F 170940	Clamp-Hose-1-3/16	BO 171030	Trim Clip-Special
BO 170941	Nut-Spring Type-5/32	BO 171031	Lockwasher-1/4 x 9/16
BZ 170942	Washer-Plain-11/32 x 1 x 1/16	BO 171032	Screw-Cross Recess-#10-32 x 7/16
BO 170944	Washer-Plain-13/32 x 13/16 x 1/16	171033	Bolt-Hex Head-#10-32 x 3/8 (Use 171263)
BZ 170945	Bolt-Hex Head-5/16 x 7/8	BZ 171034	Bolt-Hex Head-1/2-20 x 2-1/2 (Use 171287)
170946	Bolt-Special Tee-#10-32 x 1/2 (Use 210998)	171035	Bolt-Hex Head-7/16-14 x 2-7/8 (Use 171249)
170947	Nut-Clip-5/16-12 (Use 171332)	171036	Washer-Plain-15/32 x 7/8 x 3/32 (Use 171096)
*SP 170948	Spark Plug Complete-J6	F 171037	Bearing-Prop Shaft-Type 88000
*SP 170949	Spark Plug Complete-H9-Com	BO 171038	Trim Clip-Double Loop-1-7/64 Long
*SP 170950	Spark Plug Complete-J12	BO 171040	Bolt-Hex Head-7/16-14 x 1
*SP 170951	Spark Plug Complete-Y-4-A	BO 171042	Trim Clip-Double Loop-1-1/16 Long
*SP 170952	Spark Plug Complete Y-6	BO 171043	Washer-1/4 x 9/16 x 3/64
*SP 170953	Spark Plug Complete-Y-8	BM 171044	Expansion Plug-Cylinder-.687
BM 170955	Nut-Flared Tube-5/16	BM 171045	Plug-Cylinder Water Jacket-2"
*SP 170956	Spark Plug Complete-C-4	BO 171047	Screw-Cross Recess-#8 x 1-1/4
*SP 170957	Spark Plug Complete-15-A	BZ 171048	Bolt-Square Head-5/16-18 x 5/8
BO 170958	Screw-Sheet Metal-Binding Head-#8 x 7/16	BZ 171050	Washer-Plain-41/64 x 1-7/8 x 1/8
BO 170959	Screw-Sheet Metal-Binding Head-#8 x 1/2	BZ 171051	Bolt-Hex Head-5/8-18 x 3-1/8
F 170960	Clamp-Hose- 2"	BZ 171052	Bolt-Hex Head-5/8-18 x 3-5/8
F 170961	Bolt-Hex Head-5/16-24 x 3/4"	BO 171053	Screw-Cross Recess-#10-32 x 5/16
BO 170963	Screw-Fill Head-1/4-28 x 3/8"	BO 171054	Washer-Plain-27/64 x 3/4 x 3/64
170964	Bolt-Comb Hex Head-5/16-24 x 3/4 (Use 171213)	171055	Screw-Cross Recess-1/4-28 x 1/2 (Use 171292)
BO 170965	Washer-Plain-9/32 x 5/8 x 1/16	BZ 171056	Bolt-Hex Head-7/16-20 x 1-3/8
BO 170967	Bolt-Hex Head-1/4-28 x 3/8	BZ 171057	Key-Woodruff-3/16 x 3/4
BO 170968	Bolt-Hex Head-1/4-28 x 5/8	BZ 171058	Ferrule-5/16
170969	Screw-Comb-1/4-28 x 3/4 (Use 170441)	BZ 171059	Screw-Cross Recess-#10-32 x 1-1/4
BO 170970	Screw-Comb-1/4-28 x 1-1/4	BO 171060	Screw-Cross Recess-#6-32 x 5/16
BX 170971	Bolt-Hex Head-7/16-14 x 2-1/8	BO 171061	Screw-CrossRecess-#10-32 x 5/8
F 170973	Cone-Diff Bearing-#25580	171062	Screw-Cross Recess-#8-32 x 7/8 (Use 171354)
F 170974	Cup-Diff Bearing-#25520	BO 171063	Screw-Cross Recess-1/4-28 x 1/2
BX 170975	Screw-	SP 171066	Bulb-6-8V-6CP-Mazda #81
BX 170976	Lockwasher-Int tooth-1/2"	BO 171067	Screw-Sheet Metal-#8 x 1/2
F 170979	Cone-Drive Pinion Bearing-#3877	BO 171068	Screw-Cross Recess-#10-32 x 1/2
F 170980	Cup-Drive Pinion Bearing-#3820	BZ 171071	Clamp-Hose-5/8
BM 170981	Lockwasher-1/2"	BZ 171072	Rivet-5/16 dia x 5/8
BO 170982	Washer-Plain-5/16 x 3/4 x 1/16	F 171073	Clamp-Hose-1-7/16

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Part No.	Name
BO 171074	Screw-Cross Recess-1/4-28 x 5/8	BO 171168	Screw-Combination-#8-32 x 5/16
BO 171076	Screw-Cross Recess-1/4-28 x 3/4	BO 171169	Screw-Combination-#6-32 x 1/4
BO 171077	Screw-Cross Recess-#10-32 x 3	F 171171	Cone-F Wheel-Inner Brg-#15124
BZ 171079	Bolt-Carriage-5/16-18 x 5/8	F 171172	Cup-F Wheel-Inner Brg-#15125
BZ 171080	Nut-Hex Head-5/16-18	F 171174	Cone-F Wheel-Outer Brg-#09067
BO 171082	Lockwasher-1/4 x 7/8	BO 171176	Lockwasher-#10 Special
BZ 171083	Bolt-7/16-20 x 7/8	171178	Nut-Spring Type-#8 (Use 213564)
BO 171084	Screw-Cross Recess-#8 x 3/4	BM 171179	Extension-1/4" Pipe
BZ 171085	Bolt-Hex Head-1/2-20 x 3-5/8	BM 171180	Elbow-1/4-60 degrees
BZ 171086	Bolt-Hex Head-7/16-14 x 7/8	BZ 171181	Washer-Plain-29/64 x 1-1/8 x 1/8
BO 171089	Washer-Plain-5/16 x 3/4 x 1/16	BZ 171183	Bolt-Hex Head-5/16-24 x 1-1/2
BO 171090	Screw-Cross Recess-1/4-28 x 1/2	BZ 171184	Nut-Companion-5/16-24 x .119
BM 171091	Plug-9/16-Cup Type	BO 171186	Screw-Cross Recess-#8 x 3/8
BZ 171092	Screw-Fill Head-#8-32 x 1-1/2	F 171187	Clamp-Hose-2-1/16
BZ 171093	Bolt-5/16-18 x 1-5/8	BX 171188	Washer-Cone-3/ 8
BO 171094	Nut-Spring-Type 8j	BX 171189	Seal-Rubber-5/8 x 13/32 x 7/64
BM 171096	Washer-15/32 x 15/16 x 3/32	BZ 171190	Tee-VD Pipe Valve
BO 171097	Screw-Cross Recess-#12-24 x 1/2	BZ 171191	Stud-5/16-18 x 1-1/2
BO 171098	Screw-Cross Recess-1/4-28 x 5/8	BO 171193	Screw-Set-#6-32 x 3/16
BT 171099	Clevis-3/8-24	BO 171194	Screw-Set-#10-24 x 7/16
BT 171100	Clevis Pin-3/8 x 15/16	BO 171195	Screw-Cross Recess-#8 x 3/4
BO 171101	Screw-Cross Recess-#6-32 x 3/8	BO 171197	Washer-Plain-21/64 x 7/8 x 3/64
BO 171104	Nut-Weld-1/2-20	BO 171198	Nut-3/8-32 x 3/32
171105	Set Screw-#6-32 x 1/4 (Use 171436)	BO 171199	Nut-9/16-24
BO 171106	Screw-Cross Recess-#10-32 x 7/8	BO 171200	Lockwasher-Int Tooth-9/16
BZ 171107	Union-Gasoline Pipe-5/16	BO 171201	Washer-Plain-37/64 x 1 x 1/32
BZ 171108	Clip-Single-5/16	BO 171202	Screw-Combination-#10-32 x 1/2
BO 171110	Lockwasher-#12 x 19/32	BO 171203	Screw-Cross Recess-#10 x 1-1/2
BZ 171111	Nut-Flared Tube-3/16	BO 171206	Bolt-Hex Head-1/4-28 x 1-1/2
BO 171112	Screw-Cross Recess-#12 x 1/2	BO 171207	Rivet-3/16 x 1-1/2
BO 171113	Bulb-.75 CP-6V-#44	BO 171208	Nut-Spring-3/16
BZ 171114	Clip-3/16	BO 171209	Washer-Plain-5/32 x 1/2 x 1/32
BZ 171115	Union-3/16 Flared Tube	BZ 171210	Clevis-Clutch Control Link
BO 171116	Screw-Cross Recess-#8 x 2"	BZ 171211	Nut-1/4-28 x 5/32
BO 171117	Washer-Plain-3/16 x 7/16 x 3/64	BO 171212	Lockwasher-Int Tooth-#10 x 19/32
BO 171118	Screw-Cross Recess-#8-32 x 5/8	BO 171213	Bolt-Combination-5/16-24 x 3/4
BO 171119	Nut-Clinch Type-for #10 Screw	BZ 171214	Washer-Plain-11/32 x 1 x 3/32
BZ 171120	Bolt-Hex Head-1/2-20 x 1-1/4	BO 171215	Screw-Combination-#10-32 x 3/8
BO 171122	Bolt-Hex Head-1/2-20 x 1-5/8	BO 171216	Screw-Combination-5/16-24 x 1
BO 171123	Bolt-Hex Head-1/2-20 x 1-3/4	BO 171217	Bolt-Hex Head-#10-32 x 1/2
BO 171124	Lockwasher-1/2" Domed Type	BO 171218	Screw-Cross Recess-1/4-20 x 7/16
BO 171125	Screw-Cross Recess-#10 x 1/2	BO 171219	Washer-1/4 Countersunk
BM 171126	Terminal-Brass	BO 171220	Screw-Cross Recess-#8-32 x 1/4
BO 171129	Screw-Cross Recess-#8-32 x 5/16	BO 171221	Screw-#6 x 1/4
BO 171131	Screw-Cross Recess-#8-32 x 3/8	BO 171222	Screw-#6 x 5/16
BO 171132	Screw-Round Head-#6-32 x 3/16	BO 171223	Lockwasher-Ext Tooth-3/8 x 57/64
BZ 171133	Washer-Plain-21/64 x 5/8 x 1/32	BM 171225	Bolt & Lockwasher-Oil Pump Cover
BO 171134	Screw-#8-32 x 7/16	BZ 171226	Screw-Special-#10-24 x 7/8
BO 171135	Screw-Binding Head-#8 x 3/8	BZ 171227	Nut-#10-24 x 1/8
BO 171136	Screw-Combination-#10-32 x 13/32	BO 171228	Screw-Cross Recess-#10 x 1-1/8
BZ 171137	Bolt-Hex Head-7/16-20 x 1-1/2	BO 171229	Washer-Finish-#8
BO 171138	Terminal-for #14 or #16 Wire	BO 171231	Nut-Clip Type #14-J
BO 171139	Screw-Fillister Head-#8-32 x 5/16	BO 171232	Rivet-Tubular-1/8 x 3/16-Ctsk Hd
BO 171140	Clip-Triple-for Wiring	BO 171233	Clip-1/8 Dia Tubular Stud
BO 171141	Trim Clip-Staple Type	171234	Screw-Cross Recess-#8-32 x 1-1/2 (Use 171286)
BM 171144	Elbow-3/16 Inverted Flared Tube	BO 171235	Rivet-Tubular-1/8 x 3/16-Oval Head
BM 171146	Bolt-Hex Head-5/16-18 x 1-3/8	BO 171236	Screw-Cross Recess-#8-32 x 1/2
BX 171147	Lockwasher-3/8 Special	BM 171237	Cork Plug-Oil Bath Air Cleaner
BZ 171151	Nut-5/16-24 x 21/64	BT 171238	Washer-Plain-21/64 x 1 x 1/16
BZ 171153	Clevis Pin-1/4 x 2-3/32	BO 171240	Screw-#8-18 x 1-1/2
BO 171154	Lockwasher-#10 Special	BO 171241	Screw-#8-18 x 7/8
BZ 171155	Lockwasher-7/16 Int Tooth	BO 171242	Rivet-Tubular-1/4 x 1-17/32
BO 171156	Washer-Plain-21/64 x 7/8 x 1/16	BO 171243	Bolt-Hex Head-1/4-20 x 5/8
BO 171157	Bolt-Special Hex Head-5/16-24 x 1-7/8	BO 171244	Plug-1-1/8
BO 171158	Bolt-Special Hex Head-5/16-24 x 2-1/4	BT 171245	Bolt-Hex Hd-3/8-16 x 2-3/8
BO 171159	Screw-Cross Recess-#6-32 x 1/2	BM 171246	Bolt-Hex Hd-7/16-14 x 1-3/8
BO 171160	Screw-Cross Recess-#8 x 7/8	BO 171247	Rivet-Tubular-1/4 x 5/16
BO 171161	Screw-Cross Recess-1/4-20 x 3/8	BO 171248	Rivet-Split-3/16 x 1/2
171162	Screw-Cross Recess-1/ 4-28 x 3/ 8(Use 170441)	BM 171249	Bolt-Hex 11d-7/16-14 x 2
BO 171163	Screw-Cross Recess-1/4-28 x 1-1/16	BO 171250	Screw-Cross Recess-#8 x 1
BZ 171164	Woodruff Key-1/4 x 1	BO 171251	Screw-#4-40 x 3/16
BO 171165	Washer-#8	BO 171252	Screw-Hex Hd Slotted-#6-32 x 3/16
171166	Screw-Hex Head-#10 x 1/2 (Use 170519)	BO 171253	Pin-Grooved-1/8 x 3/4
BO 171167	Bolt-#10-24 x 3/4		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name
BO 171254	Screw-Cross Recess-#8 x 1/2
BO 171255	Grommet-Rubber-3/8 x 11/16
BO 171258	Screw-Pan Head-#8-32 x 3/8
BM 171261	Plug-2-1/8"
BX 171262	Nut-Special self-locking-5/8-18
BO 171263	Bolt-Combination-#10-32 x 3/8
BO 171264	Bolt-Combination-#10-32 x 1/2
BO 171265	Screw-Comb-#10-32 x 7/16
BO 171266	Screw-Comb-#10-32 x 7/16
171267	Screw-Comb-#10-32 x 5/8
BO 171268	Screw-Comb-#10-32 x 3/4
171269	Screw-Comb-#8-32 x 7/16 (Use 171400)
BO 171270	Screw-Cross Recess-#8-32 x 5/8
BO 171271	Tee Nut-#8-32
BO 171272	Grommet-Rubber-9/32 x 9/16
BO 171273	Grommet-Rubber-7/32 x 17/32
BO 171274	Bolt-#12-24 x 1/2
BO 171275	Tee-Top Control Hyd Tube
BO 171276	Elbow-Top Control Hyd Tube
BO 171277	Union-Top Control Hyd Tube
BO 171278	Screw-Self Tapping-#10 x 3/8
BO 171279	Screw-Cross Recess-#8-32 x 5/16
BZ 171280	Bolt-Hex Hd-5/16-12 x 1
BO 171281	Screw-Flat Head Wood-#8 x 1-1/4
BZ 171283	Clevis Pin-3/8 x 17/32
BO 171284	Bolt-Hex Hd-1/4-28 x 5/8
BO 171285	Screw-Cross Recess-1/4-28 x 1
BZ 171286	Screw & L/Washer Assy-#8-32 x 1-1/2
BZ 171287	Bolt-Hex Head-1/2-20 x 2-3/4
BO 171289	Bolt-Hex Head-1/4-28 x 1
BO 171291	Screw-Cross Recess-#8-32 x 3/16
171292	Screw-Cross Recess-1/4-28 x 5/8
BO 171293	Stud-Folding Top Dust Boot
BO 171294	Nut-Self Locking-5/16-24
BO 171295	Nut-Self Locking-1/4-28
BO 171296	Nut-Self Locking #10-32
171297	Screw-Cross Recess-1/4-28 x 1" (Use 171392)
BO 171298	Clevis Pin-3/8 x 1-1/2
BO 171299	Nut-Hex Slotted-5/16-24
BO 171300	Screw-Comb-Pan Hd-#8-32 x 5/8
BO 171302	Clip-Single-For 7/16 Pipe
BO 171303	Clip-Double-For 7/16 Pipe
BO 171304	Clip-Single-For 5/16 Pipe
BO 171305	Clip-Special-For 5/16 Pipe
BO 171306	Clip-Double-For 5/16 Pipe
BO 171307	Grommet-Rubber-1/2 x 27/32
BO 171308	Screw-Cross Recess-#9 x 1
BO 171309	Nut-Acorn-1/4-20
BO 171313	Elbow-90 degree-1/8 Pipe
BO 171315	Terminal-Eyelet
BO 171316	Screw-Cross Recess-5/8-24 x 7/8
BO 171317	Nut-3/8-16 x 7/32
F 171319	Clamp-Hose-1-15/16
BO 171320	Screw-Cross Recess-5/16-24 x 5/8
BZ 171321	Bolt-Hex Hd-5/16-18 x 2-5/8
BO 171322	Washer-Plain-17/32 x 1-1/16 x 3/32
BO 171323	Screw-Cross Recess-1/4-20 x 3/4
BO 171324	Elbow-Folding Top Hyd Power Tube
F 171325	Nut-Self Locking-7/8-14 x 49/64
BO 171326	Clinch Nut-#10-32
BZ 171327	Plug-Steel-9/16"
BO 171328	Washer-Plain-13/32 x 13/16 x 1/16
BO 171329	Screw-Hex Hd-1/4-14 x 1
BO 171330	Clip Nut-1/4-14 "U" Type
BO 171331	Clip Nut-1/4-14 "J" Type
BZ 171332	Clip Nut-Type J 5/16-12
BO 171333	Screw-Cross Recess-#8-32 x 1/2
BO 171335	Spring Nut-#10-Twin Type
BO 171337	Screw-Comb Lockwasher-1/4-20 x 5/8
BO 171340	Clip Nut-#6-32 "U" Type
BO 171341	Screw-Cross Recess-#8-32 x1
BO 171343	Rivet-Oval Hd Tubular-9/64 x 3/16
BO 171344	Screw-Slotted-#8-32 x 3/8

Part No.	Name
BO 171345	Screw-Slotted-#8-32 x 15/16
BO 171346	Nut-Square-#8-32 x 1/8
BO 171347	Rivet-Tubular-.144 x 1/4
BO 171348	Rivet-Flat Hd-1/8 x 11/16
BO 171350	Screw-Cross Recess-#8-3/4
BO 171351	Screw-Flat Hd-#6-32 x 5/16
BO 171352	Screw-Tapping-#6 x 3/8
BO 171354	Screw-Bronze Finish-#8-32 x 7/8
BO 171356	Bolt-Hex Hd-1/4-28 x 1-1/4
BO 171357	Screw-Cross Recess-#8-32 x 1/2
BO 171358	Rivet-Flat Hd-9/64 x 9/16
BO 171359	Spring Washer-11/32 x 9/16 x 1/16
BO 171360	Washer-Plain-33/64 x 3/4 x 1/16
BO 171361	Set Screw-Headless-1/4-20 x 1-1/2
BO 171362	Nut-Hex-1/4-20
BO 171363	Screw-Cross Recess-410-24 x 3/8
BO 171364	Screw-Tapping-#10-24 x 1/2
BO 171365	Screw-Cross Recess-#8 x 3/4
BO 171366	Screw-Machine-#10-24 x 1/2
BO 171367	Screw-Pan Head-#10-24 x 1/2
BO 171368	Screw-Comb Lockwasher-1/4-20 x 3/8
BO 171369	Bolt-Comb-1/4-20 x 3/4
BO 171370	Screw-Comb Lockwasher-1/4-20 x 1
BO 171371	Spring Nut-9/64 Stud
BO 171373	Screw-Cross Recess-#8-32 x 1/2
BO 171374	Screw-Flat Head-#6 x 3/8
BO 171375	Rivet-C'sunk Head-3/16 x 1/2
BO 171376	Staple-1/4"
BO 171377	Screw-Pan Head-#6 x 3/8
BO 171378	Washer-Plain-1/4 x 9/16 x 3/64
BO 171379	Screw-Cross Recess-#10-24 x 3/8
BO 171380	Plug-1/8" Slotted Headless Pipe
BO 171381	Screw-Pan Head-#6-18 x 1/4
BO 171383	Nut-Stamped-3/8-16
BT 171384	Clip-Wire Harness
BZ 171385	Bolt & Lockwasher Assy-#10-32 x 5/8
BO 171386	Finish Washer-#8
BO 171387	Screw-Oval Hd-#8 x 1
BO 171388	Screw-Cross Recess-#12 x 5/8
BO 171389	Lockwasher-5/16" Int Tooth
BZ 171391	Screw-Hex Hd-#14 x 3/4 St
BZ 171392	Screw-Cross Recess-#12-24 x 1"
BO 171393	Spring Nut-Type J-#10
171394	Screw-Truss Hd-#8 x 3/4
BO 171395	Screw-Hex Hd-#12-24 x 3/8
BO 171396	Screw-Round Hd-#8-32 x 3/8
BO 171399	Screw-Fillister Hd-#12-24 x 5/8
BO 171400	Screw-Comb Lockwasher-#8-32 x 3/4
171401	Fastener Button-Screw Type-#8-32 x 7/8
BO 171402	ScrewV-Tapping-#6 x 1/2
BZ 171403	Nut-Hex-5/16-18 x 3/8
BM 171404	Bolt-Hex Head-3/8-16 x 1-1/2
BM 171405	Elbow-3 Way-1/8-27 x 1/2-20 x 1/2-20
BM 171406	Street Ell-1/8"-90°
BO 171409	Spring Nut-#14-10 Type J
171410	Clamp-Hose-2 " dia (Use 171319)
BZ 171414	Bolt-Hex Hd-1/2-13 x 2-3/4
BZ 171415	Union-3/8 Std Inverted Flared Tube
BO 171417	Screw-Tapping-#12 x 1/2
BO 171418	Bolt & L/Washer Assy-5/16-24 x 3/4
BO 171419	Screw & L/Washer Assy-5/16-24 x 1"
BO 171420	Rivet-Oval Hd Tubular-3/16 x 11/32
BO 171421	Spring Nut-#10-12-Latching Type
BO 171422	Spring Nut-#10-12 Type "J"
BO 171424	Screw-Cross Recess-#8-32 x 3/4
BZ 171425	Screw-Hex Hd-1/4-14 x 1/2
BO 171426	Rivet-Tubular-.141 to .144 dia x 9/32
BX 171427	Nut-Hex Special-5/8-18 x 35/64
BM 171428	Bolt & Lockwasher Assy-5/16-18 x 5/8
BZ 171429	Clevis-Clutch Control Link
BZ 171430	Washer-Plain-9/32 x 1-1/4 x 1/16
BO 171431	Spring Nut-3/16 Stud
BZ 171432	Spring Nut-#10-12 Type "J"
BO 171433	Grommet-Rubber-1-1/2 x 2-1/8

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
175128	Body Lacquer-Majestic Maroon	1941-1942 All,1946-1947 exc Cab-CabPu
*C 175277	Body Lacquer-Nepal Ivory	1946-1947 exc Cab-CabPu
*C 175278	Body Lacquer-Gunmetal	1946-1947 Cab-CabPu
*C 175279	Lacquer-Bar Harbor Blue-For pickup box	1946-1947 CabPu
*C 175280	Lacquer-Victory Gray	1946 Cab-CabPu
*C 175283	Enamel-Black-Wheel Striping	51,53
C 175286	Rubber Lacquer-Blue Gray	1946 All
*C 175288	Enamel-Royal Red	1946-1947
175289	Enamel-Cream	1946-1947
*C 175293	Lacquer Thinner	
*C 175294	Body Lacquer-Jamestown Blue	1946-1947 All exc Cab-CabPu
*C 175295	Body Lacquer-Saxon Green	1946
*C 175296	Body Lacquer-Peasant Green	1946
*C 175315	Body Lacquer-Sherwood Green	1947
*C 175316	Body Lacquer-Palace Green	1947
175319	Body Lacquer-Savoy Green	1948 exc CvBro
*C 175320	Body Lacquer-Piedmont Green	1948 exc CvBro
175321	Body Lacquer-Quartermaster Gray	1948
*C 175322	Body Lacquer-Gallant Gray	1948
*C 175323	Body Lacquer-Harness Tan	1948
175324	Body Lacquer-Navahoe Bronze	1948
175325	Body Lacquer-Jockey Blue	1948
175326	Body Lacquer-Banner Blue	1948
*C 175327	Body Lacquer-Deep Maroon	1948 exc CvBro
*C 175328	Body Lacquer-Ruby Red	1948
*C 175339	Body Lacquer-Royal Red	1947
SC 175342	Body Lacquer-Belvidere Blue	1947
175343	Body Lacquer-Jefferson Blue	1947
175351	Lacquer-Velchrome	1948
SC 175353	Primer Enamel-Navahoe Bronze	1948,1949
*C 175354	Body Lacquer-Platinum	1948
C 175355	Rubber Lacquer-French Gray	1948
C 175356	Permagum	1948,1949,1950
*C 175363	Body Lacquer-Holster Tan	1948 exc CvBro
SC 175364	Body Lacquer-Nomad Bronze	1948 exc CvBro
*C 175368	Body Lacquer-Jersey Blue	1948
175369	Body Lacquer-Brigantine Blue	1948 exc CvBro
*C 175370	Body Lacquer-Queenstown Gray	1948
175371	Body Lacquer-Glowing Gray	1948
*HS 175379	Ebony Black Touch-Up Lacquer-3 oz can	All
*HS 175380	Majestic Maroon Touch-Up Lacquer-3 oz Can	1946,1947
*HS 175381	Belvidere Blue Touch-Up Lacquer-3 oz can	1947
*HS 175382	Jamestown Blue Touch-Up Lacquer-3 oz can	1947
*HS 175383	Jefferson Blue Touch-Up Lacquer-3 oz can	1947
*HS 175384	Brigantine Blue Touch-Up Lacquer-3 oz can	1948,1949
*HS 175385	Sherwood Green Touch-Up Lacquer-3 oz can	1947
*HS 175386	Palace Green Touch-Up Lacquer-3 oz can	1947
*HS 175387	Savoy Green Touch-Up Lacquer-3 oz can	1948,1949
*HS 175388	Piedmont Green Touch-Up Lacquer-3 oz can	1948,1949
*HS 175389	Quartermaster Gray Touch-Up Lacquer-3 oz can	1948
*HS 175390	Gallant Gray Touch-Up Lacquer-3 oz can	1948
*HS 175391	Harness Tan Touch-Up Lacquer-3 oz can	1948
*HS 175392	Navahoe Bronze Touch-Up Lacquer-3 oz can	1948
*HS 175393	Jockey Blue Touch-Up Lacquer-3 oz can	1948
*HS 175394	Banner Blue Touch-Up Lacquer-3 oz can	1948
*HS 175395	Deep Maroon Touch-Up Lacquer-3 oz can	1948,1949
*HS 175396	Ruby Red Touch-Up Lacquer-3 oz can	1948,1949
*HS 175397	Royal Red Touch-Up Lacquer-3 oz can	1947
*HS 175398	Platinum Touch-Up Lacquer-3 oz can	1948,1949
*HS 175399	Jersey Blue Touch-Up Lacquer-3 oz can	1948,1949
*HS 175400	Glowing Gray Touch-Up Lacquer-3 oz can	1948,1949
*HS 175401	Quaker Gray Touch-Up Lacquer-3 oz can	1946,1947
*HS 175402	Queenstown Gray Touch-Up Lacquer-3 oz can	1948,1949
*HS 175403	Bar Harbor Blue Touch-Up Lacquer-3 oz can	1946,1947
*HS 175404	Gunmetal Touch-Up Lacquer-3 oz can	1946,1947
*HS 175405	Holster Tan Touch-Up Lacquer-3 oz can	1948,1949
*HS 175406	Harvest Tan Touch-Up Lacquer-3 oz can	1946,1947
*HS 175407	Nomad Bronze Touch-Up Lacquer-3 oz can	1948,1949
*HS 175408	Kit-Touch-Up Lacquers	
C 175421	Satin Finish Clear Lacquer-1 pt	1948 thru 1950
C 175422	Satin Finish Clear Lacquer-1 qt	1948 thru 1950
*HS 175423	Nepal Ivory Touch-Up Lacquer-3 oz can	1946,1947
*HS 175424	Copper Red Touch-Up Lacquer-3 oz can	1946
*HS 175425	Paragon Green Touch-Up Lacquer-3 oz can	1946

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*HS 175426	Spring Green Touch-Up Lacquer-3 oz can	1946
*HS 175427	Saxon Green Touch-Up Lacquer-3 oz can	1946
*HS 175428	Peasant Green Touch-Up Lacquer-3 oz can	1946
*HS 175429	Jewel Blue Touch-Up Lacquer-3 oz can	1946
*HS 175431	Undercoating-55 gal drums	
175433	Semi-Gloss Clear Lacquer.	1948
C 175442	Lacquer-Velvet Sheen	1948,1949
C 175462	Primer Enamel-Blue Spruce	1950
C 175463	Wheel Enamel-Coronation Red	1950
C 175489	Rubber Lacquer-Brown-For Rear Window WI strip	502-504
*C 175500	Body Lacquer-Ebony Black-pint	1948,1949,1950
*C 175501	'Body Lacquer-Ebony Black-quart	1948,1949,1950
*C 175502	Body Lacquer-Ebony Black-Gallon	1948,1949,1950
*C 175503	Body Lacquer-Quartermaster Gray-pint	1948,1949
*C 175504	Body Lacquer-Quartermaster Gray-quart	1948,1949
*C 175505	Body Lacquer-Quartermaster Gray-gallon	1948,1949
*C 175506	Body Lacquer-Gallant Gray-pint	1948,1949
*C 175507	Body Lacquer-Gallant Gray-quart	1948,1949
*C 175508	Body Lacquer-Gallant Gray-gallon	1948,1949
*C 175509	Body Lacquer-Harness Tan-pint	1948,1949
*C 175510	Body Lacquer-Harness Tan-quart	1948,1949
*C 175511	Body Lacquer-Harness Tan-gallon	1948,1949
*C 175512	Body Lacquer-Banner Blue-pint	1948,1949
*C 175513	Body Lacquer-Banner Blue-quart	1948,1949
*C 175514	Body Lacquer-Banner Blue-gallon	1948,1949
*C 175515	Body Lacquer-Platinum-pint	1948,1949
*C 175516	Body Lacquer-Platinum-quart	1948,1949
*C 175517	Body Lacquer-Platinum-gallon	1948,1949
*C 175518	Body Lacquer-Savoy Green-pint	1948,1949
*C 175519	Body Lacquer-Savoy Green-quart	1948,1949
*C 175520	Body Lacquer-Savoy Green-gallon	1948,1949
*C 175521	Body Lacquer-Piedmont Green-pint	1948,1949
*C 175522	Body Lacquer-Piedmont Green-quart	1948,1949
*C 175523	Body Lacquer-Piedmont Green-gallon	1948,1949
*C 175524	Body Lacquer-Navahoe Bronze-pint	1948,1949
*C 175525	Body Lacquer-Navahoe Bronze-quart	1948,1949
*C 175526	Body Lacquer-Navahoe Bronze-gallon	1948,1949
*C 175527	Body Lacquer-Jockey Blue-pint	1948,1949
*C 175528	Body Lacquer-Jockey Blue-quart	1948,1949
*C 175529	Body Lacquer-Jockey Blue-gallon	1948,1949
*C 175530	Body Lacquer-Deep Maroon-pint	1948,1949
*C 175531	Body Lacquer-Deep Maroon-quart	1948,1949
*C 175532	Body Lacquer-Deep Maroon-gallon	1948,1949
*C 175533	Body Lacquer-Ruby Red-pint	1948,1949
*C 175534	Body Lacquer-Ruby Red-quart	1948,1949
*C 175535	Body Lacquer-Ruby Red-gallon	1948,1949
*C 175536	Body Lacquer-Queenstown Gray-pint	1948,1949
*C 175537	Body Lacquer-Queenstown Gray-quart	1948,1949
*C 175538	Body Lacquer-Queenstown Gray-gallon	1948,1949
*C 175539	Body Lacquer-Glowing Gray-pint	1948,1949
*C 175540	Body Lacquer-Glowing Gray-quart	1948,1949
*C 175541	Body Lacquer-Glowing Gray-gallon	1948,1949
*C 175542	Body Lacquer-Brigantine Blue-pint	1948,1949
*C 175543	Body Lacquer-Brigantine Blue-quart	1948,1949
*C 175544	Body Lacquer-Brigantine Blue-gallon	1948,1949
*C 175545	Body Lacquer-Jersey Blue-pint	1948,1949
*C 175546	Body Lacquer-Jersey Blue-quart	1948,1949
*C 175547	Body Lacquer-Jersey Blue-gallon	1948,1949
*C 175548	Body Lacquer-Holster Tan-pint	1948,1949
5C 175549	Body Lacquer-Holster Tan-quart	1948,1949
*C 175550	Body Lacquer-Holster Tan-gallon	1948,1949
*C 175551	Body Lacquer-Nomad Bronze-pint	1948,1949
*C 175552	Body Lacquer-Nomad Bronze-quart	1948,1949
*C 175553	Body Lacquer-Nomad Bronze-gallon	1948,1949
*C 175554	Chassis Enamel-Black-pint	1948,1949,1950
*C 175555	Chassis Enamel-Black-quart	1948,1949,1950
*C 175556	Chassis Enamel-Black-gallon	1948,1949,1950
*C 175557	Primer & Surfacer-Red-quart	1948,1949,1950
*C 175558	Primer & Surfacer-Red-gallon	1948,1949,1950
*C 175559	Lacquer Thinner-one gallon	1948,1949,1950
*C 175560	Lacquer Thinner-five gallons	1948,1949,1950
*C 175561	Lacquer Thinner-Fifty-five gallons	1948,1949,1950
*C 175562	Body Lacquer-Pacemaker Green-Code 8-Pint	1949
*C 175563	Body Lacquer-Pacemaker Green-Code 8-quart	1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*C 175564	Body Lacquer-Pacemaker Green-Code 8-gal	1949
*C 175565	Body Lacquer-Sierra Green-Code 10-pint	1949
*C 175566	Body Lacquer-Sierra Green-Code 10-quart	1949
*C 175567	Body Lacquer-Sierra Green-Code 10-gal	1949
*C 175568	Body Lacquer-Hardwood Tan-Code 3-pint	1949
*C 175569	Body Lacquer-Hardwood Tan-Code 3-quart	1949
*C 175570	Body Lacquer-Hardwood Tan-Code 3-Gal	1949
*C 175574	Body Lacquer-Jet Blue-Code 4-pint	1949
*C 175575	Body Lacquer-Jet Blue-Code 4-quart	1949
*C 175576	Body Lacquer-Jet Blue-Code 4-gal	1949
*C 175577	Body Lacquer-Brazilian Blue-Code 1-pint	1949
*C 175578	Body Lacquer-Brazilian Blue-Code 1-quart	1949
*C 175579	Body Lacquer-Brazilian Blue-Code 1-gal	1949
*C 175580	Body Lacquer-Burgundy Maroon-Code 6-pint	1949
*C 175581	Body Lacquer-Burgundy Maroon-Code 6-quart	1949
*C 175582	Body Lacquer-Burgundy Maroon-Code 6-gal	1949
*C 175583	Body Lacquer-Quebec Gray-Code 9-pint	1949
*C 175584	Body Lacquer-Quebec Gray-Code 9-quart	1949
*C 175585	Body Lacquer-Quebec Gray-Code 9-gal	1949
*C 175586	Body Lacquer-Gull Gray-Code 2-pint	1949
*C 175587	Body Lacquer-Gull Gray-Code 2-quart	1949
*C 175588	Body Lacquer-Gull Gray-Code 2-gal	1949
*C 175589	Body Lacquer-Radiant Red-Code 16-Pint	1949
*C 175590	Body Lacquer-Radiant Red-Code 16-Quart	1949
*C 175591	Body Lacquer-Radiant Red-Code 16-Gal	1949
*C 175592	Body Lacquer-Gray Gold-Code 17-pint	1949
*C 175593	Body Lacquer-Gray Gold-Code 17-quart	1949
*C 175594	Body Lacquer-Gray Gold-Code 17-gal	1949
*HS 175595	Touch-up Lacquer-Pacemaker Green-Code 8-3 oz	1949
*HS 175596	Touch-up Lacquer-Sierra Green-Code 10-3 oz	1949
*HS 175597	Touch-up Lacquer-Hardwood Tan-Code 3-3 oz	1949
*HS 175599	Touch-up Lacquer-Jet Blue-Code 4-3 oz	1949
*HS 175600	Touch-up Lacquer-Brazilian Blue-Code 1-3 oz	1949
*HS 175601	Touch-up Lacquer-Burgundy Maroon-Code 6-3 oz	1949
*HS 175602	Touch-up Lacquer-Quebec Gray-Code 9-3 oz	1949
*HS 175603	Touch-up Lacquer-Gull Gray-Code 2-3 oz	1949
*HS 175604	Touch-up Lacquer-Radiant Red-Code 16-3 oz	1949
*HS 175605	Touch-up Lacquer-Gray Gold-Code 17-3 oz	1949
*C 175606	Body Lacquer-Brigade Blue-Code 18-pint	1949
*C 175607	Body Lacquer-Brigade Blue-Code 18-quart	1949
*C 175608	Body Lacquer-Brigade Blue-Code 18-gal	1949
*C 175609	Body Lacquer-Roman Red-Code 19-Pint	1949
*C 175610	Body Lacquer-Roman Red-Code 19-quart	1949
*C 175611	Body Lacquer-Roman Red-Code 19-gal	1949
*HS 175612	Touch-up Lacquer-Brigade Blue-Code 18-3 oz	1949
*HS 175613	Touch-up Lacquer-Roman Red-Code 19-3 oz	1949
*C 175614	Wheel Enamel-Royal Red-1 pint	1946 thru 1949 All
*C 175615	Wheel Enamel-Cream-1 pint	1946 thru 1950 All
*C 175616	Body Lacquer-Rivard Blue-Code 38-pint	1950
*C 175617	Body Lacquer-Rivard Blue-Code 38-quart	1950
*C 175618	Body Lacquer-Rivard Blue-Code 38-gallon	1950
*C 175619	Body Lacquer-Lagoon Blue-Code 35-pint	1950
*C 175620	Body Lacquer-Lagoon Blue-Code 35-quart	1950
*C 175621	Body Lacquer-Lagoon Blue-Code 35-gallon	1950
*C 175622	Body Lacquer-Legion Blue-Code 36-pint	1950
*C 175623	Body Lacquer-Legion Blue-Code 36-quart	1950
*C 175624	Body Lacquer-Legion Blue-Code 36-gallon	1950
*C 175625	Body Lacquer-Twilight Gray-Code 23-pint	1950
*C 175626	Body Lacquer-Twilight Gray-Code 23-quart	1950
*C 175627	Body Lacquer-Twilight Gray-Code 23-gallon	1950
*C 175628	Body Lacquer-Gray Mist-Code 24-pint	1950
*C 175629	Body Lacquer-Gray Mist-Code 24-quart	1950
*C 175630	Body Lacquer-Gray Mist-Code 24-gallon	1950
*C 175631	Body Lacquer-Oriental Green-Code 25-pint	1950
*C 175632	Body Lacquer-Oriental Green-Code 25-quart	1950
*C 175633	Body Lacquer-Oriental Green-Code 25-gallon	1950
*C 175634	Body Lacquer-Peacock Green-Code 26-pint	1950
*C 175635	Body Lacquer-Peacock Green-Code 26-quart	1950
*C 175636	Body Lacquer-Peacock Green-Code 26-gallon	1950
*C 175637	Body Lacquer-Texas Tan-Code 27-pint	1950
*C 175638	Body Lacquer-Texas Tan-Code 27-quart	1950
*C 175639	Body Lacquer-Texas Tan-Code 27-gallon	1950
*C 175640	Body Lacquer-Revue Red-Code 28-pint	1950
*C 175641	Body Lacquer-Revue Red-Code 28-quart	1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

273

Part No.	Name	Models
C 200003	Spring-Front Seat Back Panel	1941 ClubCpe-CvSed,15 3Cpe
C 200005	Spring-Front Seat Back-LH	1941 ClubCpe-CvSed,15 3Cpe
BO 200010	Support-Inst Panel Switch Bracket	1941 thru 1947 All
BO 200019	Clip-Cowl Vent Tube & Dash Wire	1941 thru 1950
BO 200020	Brkt-Inst Panel Cigar Lighter Switch-Prime	1941 thru 1947 All
	200021 Use 200020	
BO 200024	Brkt-Inst Panel Fog Lamp & Heater Switch-Painted	1941 thru 1947 All
BO 200025	Use 200024	
BO 200028	Brkt-Inst Panel Top Switch-Painted	1941 CvSed,1946-1947 CvBro
C 200034	Spring-Rear Seat Cushion	1941 CvSed
C 200035	Spring-Rear Seat Back	1941-1942-CvSed,1946-1947 CvBro
C 200036	Spring-Rear Seat Cushion	12-14 Sed-2Sed,17 5Sed
C 200037	Spring-Rear Seat Back	17 5Sed
C 200039	Spring-Front Seat Back-LH	17 5Sed
C 200040	Spring-Rear Seat Back	10T-10P-11 Sed-2Sed,IOUCo
C 200043	Spring-Front Seat Cushion	10 thru 18 5Sed,10 thru 14 3Cpe-Lea
C 200046	Spring-F Seat Outer Arm Rest	17
C 200048	Spring-Front Seat Cushion	12 thru 17 5Sed,12-14 3Cpe
BO 200050	Ash Tray Assy-Rear Quarter-Grained	12 thru 17 Sed-ClubCpe,10-11 ClubCpe
	200051 Ash Tray Assy-Rear Quarter-Gray (Use 200050)	12 thru 17 Sed-ClubCpe,10-11 ClubCpe
	200052 Ash Tray Assy-Rear Quarter-Green (Use 200050)	12 thru 17 Sed-ClubCpe,10-11 ClubCpe
BO 200054	Cover-Quarter Ash Tray-Gray	12 thru 17 Sed-ClubCpe,10-11 ClubCpe
BO 200057	Retainer-Rear Quarter Ash Receiver	12 thru 17 Sed-ClubCpe,10-11 ClubCpe,1946-1947 Bro-Sed-ClubCpe
BO 200058	Knob-Rear Quarter Ash Receiver	12 thru 17 Sed-ClubCpe,10-11 ClubCpe
C 200060	Frame Assy-Front Assy	17-18 7Sedan
BO 200061	Insi,lator-Dome Lamp Switch	1941-1942 ClubCpe-UCpe-UCo-3Cpe-2Sed
	200062 Filler-U/Body Panel-RH	178 Station
	200063 Filler-U/Body Panel-LH	178 Station
BO 200067	Clip-Radio Dial Hole Cover Retaining	1941 All
BO 200068	Ornament-Door Trim Panel	10P Sed-2Sed-3Cpe-ClubCpe
BO 200068	Ornament-Quarter Trim Panel	10P 2Sed
C 200070	Track Assy-Drivers Seat-LHD	1941 2Sed-5Sed-UCo-UCpe,20 UCo
C 200071	Track Assy-Drivers Seat-RHD	1941 2Sed-5Sed-UCo-UCpe,20 UCo
C 200073	Frame Assy-Driver & Pass Seat Cushion-LH-LHD	1941 2Sed-5Sed-UCo-UCpe,20 UCo
C 200079	Spring-Rear Seat Cushion	10-20 UCo
BO 200101	Bumper-Locker Box Door Hinge	1941 thru 1947 All
	200129 Use 170523	
	200141 Clip-F Seat Back Panel Spring Ret	1946-1947 ClubCpe-CvBro
*HA 200156	Seat Cover-Front	10-11-12-14 ClubCpe-2Sed,15Cpe
C 200170	Frame Assy-Front Seat Cushion-LHD	10-11-12-14 3Cpe-UCpe,20 UCpe
BO 200176	Bolt-Qtr & Bonnet Belt Moulding	10 exc Del,20,51,53,171,173
BO 200177	Bolt-Qtr & Bonnet Belt Moulding	11 thru 17,18P,21 thru 28,52,54,172,174
BO 200181	Spacer-Plate-Door Lock Striker-1/8"	1941-1942-1946-1947 All
C 200192	Retainer Assy-Rear Seat Cushion	10-11 ClubCpe
C 200193	Retainer Assy-Rear Seat Cushion	12-14-15 ClubCpe,10-11 Lea Trim ClubCpe,1942 ClubCpe,1946-1947 ClubCpe
BO 200210	Condenser-Ignition Coil-.5 mfg-150 volt	1941 Radio
BO 200220	Condenser-Temperature Compensator	1941 Custom Radio
BO 200224	Condenser-Elect-10 Mfd-450 volt	1941 Radio
BO 200225	Condenser-Temperature Compensator	1941 DeLuxe Radio
BO 200227	Condenser-Buffer-.01 mmfd-2000 volt	1941 Radio
	200250 Headlamp Complete-RH (Use 206250)	1942 exc Del
	200251 Headlamp Complete-LH (Use 206251)	1942 exc Del
BO 200252	Connector & Wires Assy-Headlamp-RH	1942 exc Del,1946-1947 All
BO 200253	Connector & Wires Assy-Headlamp-LH	1942 exc Del,1946-1947 All
	200254 Headlamp Complete-RH-Export 6 Volt (Use 209894)	1942 exc Del,1946 All
	200255 Headlamp Complete-LH-Export 6 Volt (Use 209895)	1942 exc Del,1946 All
BO 200262	Ground Cable Assy-Headlamp-LHD	1941 thru 1947 All exc 1942 Del
BO 200263	Connector Terminale Assy Headlamp-LHD	1941 thru 1950 All exc 1942 Del
C 200269	Spring-Rear Seat Cushion	10-11-12-14 CvSed
C 200272	Spring-Rear Seat Cushion	10-11-12-14-15 ClubCpe
C 200273	Spring-Rear Seat Back	10-11-12-14 ClubCpe
C 200279	Rubber Pad-Rear Seat Back Center Arm Rest	15 ClubCpe
C 200280	Tie Arm-Pillar to Rear Seat Back-RH	1941-1942 CvSed,1946-1947 CvBro
C 200281	Tie Arm-Pillar to Rear Seat Back-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200295	Catch-Locker Box Door Lock	1941 thru 1947 All
BO 200296	Pusher-Locker Box Door Lock Bolt	1941 thru 1947 All
BO 200297	Spring-Locker Box Door Lock Bolt	1941-1946-1947 All
BO 200298	Spacer-Plate-Door Lock Striker-1/16"	1941 thru 1947 All
C 200302	Bar-Rear Bumper Impact-RH	11-14-21 Station
C 200303	Bar-Rear Bumper Impact-LH	11-14-21 Station
C 200304	Bar-Rear Bumper Frame-RH	11-14-21 Station
C 200305	Bar-Rear Bumper Frame-LH	11-14-21 Station

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 200310	Trim Moulding-Front Fender	10 thru 18,1942 Station
BO 200311	Trim Moulding-Rear Fender	10 thru 18,1942 Station
BO 200319	Ball-Vacuum Antenna Tip	1941 All
C 200320	Spring-Front Seat Back	10-11-12-14 3Cpe-Sed,18 5Sed
C 200321	Spring-Rear Seat Back	10-11-12-14 Sed-2Sed,10 UCo-18 5Sed
BZ 200322	Clip Assy-Jack	1941-1942 All,51 thru 54,171 thru 174
BO 200324	Weatherstrip-Deck Door	1941 Cpe-CvSed
BO 200325	Weatherstrip-Rear Comp Door	1941 Sed-2Sed-UCo-Ca
BO 200326	Clip-Quarter Trim Moulding	12-14 ClubCpe-2Sed
BO 200338	Speedometer Assy-Miles	1941-1942-1946-1947 Taxicab
BO 200340	Track Assy-Front Seat-RH-RHD	1941 thru 1947 Station-5Sed-3Cpe
BO 200341	Track Assy-Front Seat-LH-LHD	1941 thru 1947 Station-5Sed-3Cpe
C 200342	Tie Bar Assy-Front Seat Track	1941 thru 1947 Station-5Sed-3Cpe
BO 200344	Door,Lens & Bezel Assy-Locker Box-RH-LHD-Grained	10 exc Del,11,18
BO 200345	Door,Lens & Bezel Assy-Locker Box-LH-LHD-Grained	10 exc Del,11,18
BO 200346	Door,Lens & Bezel Assy-Locker Box-RH-LHD-Green	10 exc Del,11,18
BO 200347	Door,Lens & Bezel Assy-Locker Box-LH-LHD-Green	10 exc Del,11,18
BO 200348	Door,Lens & Bezel Assy-Locker Box-RH-RHD-Gray	10 exc Del,11,18
BO 200349	Door,Lens & Bezel Assy-Locker Box-LH-LHD-Gray	10 exc Del,11,18
BO 200350	Door,Lens & Bezel Assy-Locker Box-RH-LHD-Grained	12,14,15,17
BO 200351	Door,Lens & Bezel Assy-Locker Box-LH-LHD-Grained	12,14,15,17
BO 200352	Door,Lens & Bezel Assy-Locker Box-RH-LHD-Green	12,14,15,17
BO 200353	Door,Lens & Bezel Assy-Locker Box-LH-LHD-Green	12,14,15,17
BO 200354	Door,Lens & Bezel Assy-Locker Box-RH-LHD-Gray	12,14,15,17
BO 200355	Door,Lens & Bezel Assy-Locker Box-LH-LHD-Gray	12,14,15,17
BO 200360	Housing Assy-Headlamp	1941-1942-1946-1947 All
BO 200361	Nut-Headlamp Adjusting	1941-1942 exc Del,1946 thru 1950 All
BO 200362	Retainer-Headlamp Adjusting Nut	1941-1942 exc Del,1946 thru 1949 All
BO 200412	Knob-Locker Box Door Clock	1941 All
BO 200416	Switch-Starter	1941 thru 1947 All
F 200417	Switch-Lighting	1941-1942 exc Del,1946-1947 All
BO 200418	Spring-Starter & Lighting Switch Push Button	1941-1942 exc Del,1946-1947 All
BO 200421	Mldg-Inst Panel-LH-Inner	12 thru 17
BO 200422	Mldg-Inst Panel-LH-Outer	12 thru 17
BO 200423	Clip-Inst Panel Mldg	12 thru 17
C 200432	Frame & Tee Nut Assy-Aux Seat Cushion-RH	1941 7Sed-CA
C 200433	Frame & Tee Nut Assy-Aux Seat Cushion-LH	1941 7Sed-CA
BO 200434	Support-Auxiliary Seat Hinge Bracket	1941 7Sed-CA
BO 200435	Pin-Rear Door Hinge-Upper	1941 Sed-CA,1946-1947 Sed
BO 200436	Pin-Front Hinge Upper-Rear Lower	1941-1942-1946-1947 All
BO 200437	Bushing-Door Hinge	1941-1942-1946-1947 All
C 200441	Roof Bow #3	17P,18P,27
C 200443	Roof Bow #4	17,18P,27
C 200444	Bow-Roof #1	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 ClubCpe-3Cpe
C 200445	Bow-Roof-#2	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 ClubCpe-3Cpe
200450	Use 1 each 207043 & 200735	
200451	Use 1 each 207043 & 200735	
200452	Use 1 each 200731 & 200735	
200453	Use 1 each 200731 & 200735	
200454	Use 1 each 200732 & 200735	
200455	Use 1 each 200732 & 200735	
200456	Use 1 each 200733 & 200735	
200457	Use 1 each 200733 & 200735	
200458	Use 200735	
200459	Use 200735	
C 200462	Trim Retainer Assy-Rear Pillar-RH	1941 ClubCpe-3Cpe-UCpe,1946-1947 Cab-CabPu
C 200463	Trim Retainer Assy-Rear Pillar-LH	1941-1942 ClubCpe-3Cpe-UCpe,1946-1947 ClubCpe-3Cpe
C 200464	Spring-Front Seat Back-RH	1941 ClubCpe-CvSed,15 3Cpe
C 200466	Spring-Front Seat Back Panel	1941-1942 ClubCpe-CvSed,15-25 3Cpe,1946-1947 ClubCpe-CvBro
200468	Name Plate-Heed Side-RH-Cadmium (Use 200469)	10 exc Del
BO 200469	Name Plate-Hood Side-LH-Cadmium	10 exc Del
C 200486	Silencer-Underbody Panel	12-14-15 Sed-2Sed-3Cpe-ClubCpe,17-18 5Sed,22 thru 27,51 thru 54
C 200491	Panel Assy-F Seat Back-LH-LHD	15 3Cpe
BZ 200497	Brkt & Arm Assy-F License Plate	10,11,18
BZ 200498	Support-F License Plate Clamp	10P,11,10 Del
BZ 200499	Support & Clamp Assy-F License Plate Brkt	10P,11,10 Del
C 200512	Side Board-Pickup Box-RH	1941 3Cpe-UCpe,1942 UCpe
BO 200520	Regulator Assy-Front Door Window-RH	10T,10C exc Del,18
BO 200521	Regulator Assy-Front Door Window-LH	10T,10C exc Del,18

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
200544	Use 148414	
200571	Dial Light-6 Volt (Use 171113)	1941 Radio
BO 200577	Vibrator	1941 Radio
BO 200583	Choke Coil	1941 Radio
BO 200584	Switch-Radio-On-Off	1941 Custom-DeLuxe Radio
BO 200586	Output-Transformer.	1941 DeLuxe-Junior Radio
BO 200588	Volume Control-1 meg	1941 DeLuxe-Custom Radio
BO 200599	Power Transformer-6 Volt Primary	1941 Custom Radio
BO 200610	Push Button-HI"	1941 Custom-DeLuxe Radio
BO 200611	Push Button-"On-Off"	1941 Custom-DeLuxe Radio
BO 200612	Push Button-"2"	1941 Custom-DeLuxe Radio
BO 200613	Push Button-"3"	1941 Custom-DeLuxe Radio
BO 200614	Push Button-"4"	1941 Custom-DeLuxe Radio
BO 200615	Push Button-"5"	1941 Custom-DeLuxe Radio
BO 200624	Spring-for Push Button	1941 Custom-DeLuxe Radio
BO 200645	Clutch Case & Coil Assembly	1941 Custom-DeLuxe Radio
BO 200660	"Lock-Unlock" Mechanism-Includes Driver Bit	1941 Custom-DeLuxe Radio
BO 200664	Spring-On-Push Button Shaft	1941 Custom-DeLuxe Radio
BO 200669	Knob-Push On	1941 Junior Radio
BO 200685	Cone & Voice Coil Assembly	1941 DeLuxe Radio
BO 200686	Cone & Voice Coil Assembly	1941 Custom Radio
BO 200687	"J" Bolt-For Receiver Mounting	1941 Radio
BO 200688	Wing Nut-For Receiver Mounting	1941 Radio
BO 200699	Receiver Case-Wrap Around Section-Brown	1941 DeLuxe Radio
BO 200704	Set Screw-8 x 32-Slotted Head	1941 Custom-DeLuxe Radio
BO 200705	Screw-Self Tapping 8 x 1/4 for Case	1941 Junior Radio
BO 200706	Screw-for Mtg Escutcheon to Case Nose	1941 Radio
200730	Weatherstrip-Door Opening-Upper (Use 207043)	1941-1942 ClubCpe-3Cpe-2Sed-UCo-UCpe, 1946 Bro-3Cpe-ClubCpe
200731	Weatherstrip-Door Opening-Upper (Use 207044)	1941-1942-1946 Sedan exc 17-18P-27
BO 200732	Weatherstrip-Door Opening-Upper	17,18P,27
200733	Weatherstrip-Door Opening-Upper (Use 207045)	1941-1942-1946 Cab-CabPu
BO 200734	Weatherstrip-Door Opening-Upper	1941-1942 CvSed,1946-1947 CvBro
BO 200735	Weatherstrip-Door Opening-Lower	1941-1942 exc Del-Cv,1946-1947 exc CvBro
BO 200736	Weatherstrip-Door Opening-Lower	1941-1942 CvSed,1946-1947 CvBro
BO 200774	Gusset-Compt Panel-RH	1941 CA
BO 200775	Gusset-Compt Panel-LH	1941 CA
BO 200776	Brkt-Compt Panel Qtr Panel	1941 CA
C 200789	Floor Board-Rear Compt-Center	18CA
C 200791	Floor Board-Rear Compt-LH	18CA
C 200796	Spring-Front Seat Back-RH	1941 ClubCpe-CvSed,15 3Cpe
BO 200801	Bracket-Folding Top Front Center	1941-1942 CvSed,1946-1947 CvBro
C 200802	Header Rail Assy-Top Side-RH	1941-1942 CvSed,1946-1947 CvBro
C 200803	Header Rail Assy-Top Side-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200804	Bracket-Top Side Header Rail-RH	1941-1942 CvSed,1946-1947 CvBro
BO 200805	Bracket-Top Side Header Rail-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200806	Bumper-Top Side Header Rail Bracket	1941-1942 CvSed,1946-1947 CvBro
BO 200807	Link-Top Pillar to Side Header	1941-1942 CvSed,1946-1947 CvBro
200808	Use 200938	
200809	Use 200939	
200810	Use 200938	
200811	Use 200939	
BO 200812	Hinge-Folding Pillar Front-RH	1941-1942 CvSed,1946-1947 CvBro
BO 200813	Hinge-Folding Pillar Front-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200814	Hinge-Folding Pillar Rear-RH	1941-1942 CvSed,1946-1947 CvBro
BO 200815	Hinge-Folding Pillar Rear-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200816	Brace-Folding Pillar Hinge-RH	1941-1942 CvSed,1946-1947 CvBro
BO 200817	Brace-Folding Pillar Hinge-LH	1941-1942 CvSed,1946-1947 CvBro
C 200818	Main Bow-Top	1941-1942 CvSed,1946-1947 CvBro
C 200820	Link-Side Header to Pillar Hinge-RH	1941-1942 CvSed,1946-1947 CvBro
C 200821	Link-Side Header to Pillar Hinge-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200822	Reinforcement-Side Header to Pillar Hinge Link	1941-1942 CvSed,1946-1947 CvBro
BO 200823	Sleeve-Side Header to Pillar Hinge Link	1941-1942 CvSed
BO 200824	Bracket-Side Header to Pillar Hinge Link Guide	1941-1942 CvSed,1946-1947 CvBro
BO 200825	Link-Pivot Bracket-Lower	1941-1942 CvSed,1946-1947 CvBro
C 200826	Extension-Rear Bow-RH	1941-1942 CvSed,1946-1947 CvBro
C 200827	Extension-Rear Bow-LH	1941-1942 CvSed,1946-1947 CvBro
C 200828	Auxiliary Bow-Top	1941-1942 CvSed,1946-1947 CvBro
BO 200830	Bracket-Folding Pillar Upper-RH	1941-1942 CvSed,1946-1947 CvBro
BO 200831	Bracket-Folding Pillar Upper-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200832	Slat-Folding Top Pillar-RH	1941-1942 CvSed,1946-1947 CvBro
BO 200833	Slat-Folding Top Pillar-LH	1941-1942 CvSed,1946-1947 CvBro
BO 200834	Pivot Bolt-Top Rear Bow Extension	1941-1942 CvSed,1946-1947 CvBro
BO 200835	Pivot Bolt-Top Pivot Brkt Lower Link	1941-1942 CvSed,1946-1947 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 200836	Pivot Bolt-Pillar to Side Header Link-Front	1941-1942 CvSed,1946-1947 CvBro
BO 200837	Pivot Bolt-Pillar to Side Header Link-Rear	1941-1942 CvSed,1946-1947 CvBro
BO 200838	Bolt-Side Header to Pillar Hinge Link-Front	1941-1942 CvSed,1946-1947 CvBro
BO 200839	Bolt-Side Header to Pillar Hinge Link-Rear	1941-1942 CvSed,1946-1947 CvBro
BO 200840	Spacer-Pillar to Side. Header Link-Front & Rear	1941-1942 CvSed
BO 200841	Rivet-Top Auxiliary Bow	1941
BO 200842	Bolt-Top Side Header to Pillar Hinge Link	1941-1942 CvSed,1946-1947 CvBro
BO 200846	Tension Washer-Pillar to Side Header Link	1941-1942 CvSed,1946 thru 1950 CvBro
BO 200848	Screw-Top Auxiliary Bow Pivot	1941-1942 CvSed,1946-1947 CvBro
BO 200850	Hydraulic Cylinder Assy-Folding Top-Use 1-209722, 1-209721, 1-70125 & 1-170900	1941-1942 CvSed,exc 20T,1946 CvBro
BO 200851	Yoke-Top Hydraulic Cyl Connecting Rod	1941-1942 CvSed exc 20T,1946-1947 CvBro
C 200872	Bar-Rear Bumper Frame-RH	10 Del
C 200873	Bar-Rear Bumper Frame-LH	10 Del
C 200878	Installation Kit-R/Board-Without Moldings	17,18
C 200879	Installation Kit-R/Board-With Moldings	17,18
C 200880	Removal Kit-Running Board	10
C 200885	Spring-Rear Seat Back	17 7Sed
C 200887	Spring-Rear Seat Cushion	17,18P
BZ 200905	Fender Guard-Rear Bumper	10 Del
C 200909	Spring-Rear Seat Cushion	1941 Taxi Cab-Police Car-5Sed
C 200914	Spring-Rear Seat Cushion-RH	1941 5Sed-2Sed-UCo
C 200915	Spring-Rear Seat Cushion-LH	1941 5Sed-2Sed-UCo
BO 200917	Brkt-Partition Board Right to Seat Tray Support	1941 5Sed-2Sed-UCo
BO 200925	Lamp Complete-Tail-6 Volt	11r21 Station,178 Station
BO 200927	Wires Assy-Tail Lamp	1441-1942 Station,178 Station
BO 200929	Body Assy-Tail Lamp	1941-1942 Station,178 Station
C 200931	Running Board & Moldings Complete-LH	1s0 exc Del
C 200934	Running Board & Moldings Complete-RH	17,18
C 200935	Running Board & Moldings Complete-LH	17,18
BO 200938	Pillar Assy-Folding Top-RH	1941 CvSed,1946-1947 CvBro
BO 200939	Pillar Assy-Folding Top-LH	1941 CvSed,1946-1947 CvBro
BO 200950	Panel Assy-Quarter-RH-Without Mldg Holes- (Use 148888-146376)	10-11 ClubCpe
BO 200951	Panel Assy-Quarter-LH-Without Mldg Holes- (Use 148889-146376)	10-11 ClubCpe
BO 200952	Panel Assy-Quarter-RH-With Mldg Holes- (Use 148902-146376)	10 thru 15 ClubCpe
BO 200953	Panel Assy-Quarter-LH-With Mldg Holes- (Use 148903-146376)	10 thru 15 ClubCpe
BZ 200959	Cage Assy-Spare Tire Lock	1941-1942-1947 Station
C 200981	Ring-Spare Tire Cover-Prime	14 Sta,11-21-178 Sta with 6.50 tires
C 200982	Side Plate-Spare Tire Cover-Prime	14 Sta 11-21-178 Sta with 6.50 tires
BO 201048	Lamp Assy-Front Fender-RH-6 Volt	10 thru 18 with DI
BO 201049	Lamp Assy-Front Fender-LH-6 Volt	10 thru 18 with DI
BO 201050	Lamp Assy-Front Fender-RH-12 Volt	10 thru 18 with DI
BO 201051	Lamp Assy-Front Fender-LH-12 Volt	10 thru 18 with DI
BO 201052	Use 204510	
BO 201053	Lamp Assy-Front Fender-LH-6 Volt (Use 204511)	10 thru 18 without DI
BO 201054	Lamp Assy-Front Fender-RH-12 Volt	10 thru 18 without DI
BO 201055	Lamp Assy-Front Fender-RH-12 Volt	10 thru 18 without DI
BO 201056	Base, Socket & Wire Assy-F Fender Lamp-RH	1941-1942 All
BO 201057	Base,Socket & Wire Assy-F Fender Lamp-LH	1941-1942 All
BO 201060	Housing-Front Fender Lamp-RH (Use 206520)	1941-1942 All
BO 201061	Housing-Front Fender Lamp-LH (Use 206521)	1941-1942 All
BO 201062	Screw-Front Fender Lamp Housing	1941 thru 1947 All
BO 201064	Base & Socket Assy-F Fender Lamp Base-RH	10 thru 18
BO 201065	Base & Socket Assy-F Fender Lamp Base-LH	10 thru 18
BO 201085	Reinf Plate-F Seat Riser Panel	1941 Sed-3Cpe
BO 201088	Mat-Cowl Rubber	1941 Vac Antenna
BO 201089	Insulator-Bakelite	1941 Vac Antenna
BO 201090	Washer-Upper	1941 Vac Antenna
BO 201091	Nut-Hex Dome	1941 Vac Antenna
BO 201092	Seal-Leather	1941 Vac Antenna
BO 201093	Spring-Leather Seal	1941 Vac Antenna
BO 201094	Seat-Leather Seal Spring	1941 Vac Antenna
BO 201100	Belt Mldg-F End Panel-RH-Chrome (Use 148200)	10T,10P,10C exc Del
BO 201101	Belt Mldg-F End Panel-LH-Chrome (Use 148201)	10T,10P,10C exc Del
BO 201102	Belt Mldg-Qtr Panel-RH-Chrome (Use 148204)	10T-10P-10 Sp 2Sed,10 UCo
BO 201103	Belt Mldg-Qtr Panel-LH-Chrome (Use 148205)	10T-10P-10 Sp 2Sed,10 UCo
BO 201105	Belt Mldg-Qtr Panel-LH-Chrome (Use 148207)	10 Sed
BO 201106	Belt Mldg-Qtr Panel-RH-Chrome (Use 148204)	10 3Cpe-ClubCpe-UCpe
BO 201107	Belt Mldg-Qtr Panel-LH-Chrome (Use 148209)	10 3Cpe-ClubCpe-UCpe
BO 201108	Belt Mldg-Qtr Panel-RH-Chrome (Use 148248)	10 CvSed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
201109	Belt Mldg-Qtr Panel-LH-Chrome (Use 148249)	10 CvSed
201110	Belt Mldg-F Door Panel-RH (Use 148224)	10T-10P exc Sed,10UCo-UCpe
201111	Belt Mldg-F Door Panel-LH (Use 148225)	10T-10P exc Sed,10UCo-UCpe
C 201112	Belt Mldg-F Door Panel-RH-Chrome	10 Sed-Cab-CabPu
C 201113	Belt Mldg-F Door Panel-LH-Chrome	10 Sed-Cab-CabPu
201114	Belt Mldg-Rear Door Panel-RH-Chrome (Use 148232)	10 Sed
C 201115	Belt Mldg-Rear Door Panel-LH-Chrome	10 Sed
C 201116	Belt Mldg-Hood-RH-Chrome	10 exc Del
201117	Belt Mldg-Hood-LH-Chrome (Use 148311)	10 exc Del
C 201118	Belt Mldg-Hood-RH-Chrome	10 exc Del
C 201119	Belt Mldg-Hood-LH-Chrome	10 exc Del
BO 201125	Clip-Headlamp Rim Retaining	1939 All
BO 201126	Screw-Headlamp Rim Retaining	1939 All
BO 201127	Shield-Spot Light Bulb	1941-1942-1946-1947 All
BO 201128	Lens-Spot Light	1941-1942-1946-1947 All
BO 201130	Lens-Fog Lamp	1941-1942 All
BO 201131	Gasket-Spot & Fog Lamp Lens	1941-1942-1946 All
BO 201132	Rim & Screws-Spot & Fog Lamp Lens	1941-1942-1946-1947 All
BO 201133	Screw & Nut-Spot Fog & Backup Lamp Rim	1941-1942-1946-1947 All
SP 201134	Universal Floor Mat	1940 thru 1947 All
BO 201150	Headlamp Assy-RH	1941 Del
201151	Headlamp Assy-LH (Use 201150)	1941 Del
BO 201152	Rim-Headlamp	1941 Del
BO 201153	Lens-Headlamp	1941 Del
BO 201155	Lamp Assy-Tail	1941 Del
A 201157	Louver-Panel Assy	1941 Del
A 201158	Fender-Front-RH	1941 Del
BO 201168	Handle-Rear Door Outside-RH	1941 Del
C 202050	Trim Assy-Qtr Arm Rest-RH	11 2Sed
C 202051	Trim Assy-Qtr Arm Rest-LH	11 2Sed
C 202054	Trim Assy-Qtr Arm Rest-RH	11 5Sed
C 202055	Trim Assy-Qtr Arm Rest-LH	11 5Sed
C 202060	Arm Rest Assy-Qtr-RH	12-14 Sed
C 202061	Arm Rest Assy-Qtr-LH	12-14 Sed
C 202062	Trim Assy-Qtr Arm Rest-RH	12-14 Sed
C 202063	Trim Assy-Qtr Arm Rest-LH	12-14 Sed
C 202086	Trimboard-Rear Seat Back Spring	18 7Sed
C 202089	Cushion Frame & Back Complete-F Seat-LHD	10T 3Cpe
C 202090	Cushion Frame & Back Complete-F Seat-RHD	10T 3Cpe
BO 202097	Protector-Air Foam Pad	1941-1942-1946-1947 All,1948 thru 1950 CvBro
BO 202098	Arm Rest Kit-F Door-Cloth	10 thru 18
BO 202099	Arm Rest Kit-F Door-Leather	10 thru 18
202100	Floor Mat-Rear Compartment (Use 202102)	12-14-15 Sed-2Sed 13-17 5Sed
C 202102	Covering Assy-Rear Compt Floor	10-11 Sed-2Sed,18 5Sed
C 202103	Covering Assy-Rear Compt Floor	10-11-20-51,53,171,173 ClubCpe-3Cpe
202104	Arm Rest Assy-Quarter-Cloth Trim	1941-1942 ClubCpe exc 10T-15-20T-25,1946-1947 ClubCpe Comb Trim
202108	Arm Rest Assy-Quarter-Cloth Trim	10T-15-20T-25 ClubCpe
C 202116	Center Arm Rest Complete-Rear Seat Back-Cloth	17 5Sed
C 202117	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	17 5Sed
C 202118	Center Arm Rest Complete-Rear Seat Back-Cloth	15 ClubCpe
C 202119	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	15 ClubCpe
C 202120	Valance Assy-Rear Seat Back Center Arm Rest	15 ClubCpe
C 202125	Carpet Assy-Rear Floor-LHD	10-11 2Sed
C 202126	Carpet Assy-Rear Floor-AHD	10-11 2Sed
C 202127	Carpet Assy-Rear Floor-LHD	10-11 ClubCpe
C 202128	Carpet Assy-Rear Floor-RHD	10-11 ClubCpe
C 202129	Carpet Assy-Rear Floor	10-11 3Cpe-UCpe
C 202130	Carpet Assy-Rear Floor	10-11 Sedan
C 202131	Carpet Assy-Rear Floor	17-27 5Sed
C 202134	Silencer-Rear Compt Door Panel	1941-1942 Sed-2Sed-UCo-CA,1946-1947 Sed-Bro
C 202135	Silencer-Rear Compt Door Panel	1941-1942 Cpe-CvSed,1946-1947 3Cpe-ClubCpe-CvBro
C 202140	Silencer-Roof	1941-1942 3Cpe-ClubCpe-IJCpe,1946-1947 3Cpe-ClubCpe
202141	Silencer-Roof (Use 210748)	1941-1942 Sed-2Sed-UCo exc 17-27,1946-1947 Bro-Sed
C 202159	Trimboard-Rear Seat Back Spring	10-11-12-14-20-21 ClubCpe-1946-1947 ClubCpe
C 202167	Carpet Assy-Front Floor-LHD	15,17,25,27
C 202168	Carpet Assy-Front Floor-RHD	15,17,25,27
C 202169	Carpet Assy-Transmission Opening-LHD	15,17,25,27
C 202170	Carpet Assy-Transmission Opening-RHD	15,17,25,27
C 202198	Silencer-R Compt Door Panel-Small	1941-1942 Sed-2Sed-UCo-CA,1946-1947 Bro-Sed
C 202199	Silencer-R Compt Door Panel-Small	1941-1942 Cpe-CvSed,1946-1947 3Cpe-ClubCpe-CvBro
C 202206	Trimboard Assy-Rear Seat Back Spring	15-22-24-25 ClubCpe
C 202221	Boot Assy-Rear Seat Back Bottom	1941 2Sed-5Sed-UCo

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 202224	Trim Assy-Rear Seat Back Compt Panel-RH	1941 2Sed-5Sed-UCo
202246	Arm Rest Assy-Quarter-Leather Trim	1941-1942-1946-1947 ClubCpe
C 202247	Trim Assy-Quarter Arm Rest-Leather Trim	1941-1942-1946-1947 ClubCpe
BO 202252	Clip-Door Trimboard Retaining	11-12-14 Sed-2Sed-3Cpe-ClubCpe
C 202287	Cushion Frame & Back Complete-F Seat-LHD-Lea	10T 5Sed
C 202288	Cushion Frame & Back Complete-F Seat-RHD-Lea	10T 5Sed
C 202289	Cushion Frame & Back Complete-F Seat-LHD-Lea	10P 5Sed
C 202290	Cushion Frame & Back Complete-F Seat-RHD-Lea	10P 5Sed
C 202291	Cushion Frame & Back Complete-F Seat-LHD-Lea	10T-10P 3Cpe
C 202292	Cushion Frame & Back Complete-F Seat-RHD-Lea	10T-10P 3Cpe
C 202293	Trim Assy-F Seat Bak-Leather	10T-10P-11-12-14 5Sed-3Cpe
C 202294	Cushion Complete-F/Seat Leather-Std	10T-10P-11 5Sed-3Cpe
C 202295	Cushion Complete-F Seat-Leather	12-14 5Sed-3Cpe,17 5Sed
C 202295	Cushion Complete-F Seat-Leather-Airfoam	10T-10P-11 5Sed-3Cpe
C 202296	Trim Assy-F Seat Cushion-Leather	10T-10P-11-12-14 5Sed-3Cpe,17 5Sed
C 202301	Cushion Frame & Back Complete-LHD-Leather	11-12-14 5Sed
C 202302	Cushion Frame & Back Complete-RHD-Leather	11-12-14 5Sed
C 202303	Trimboard & Pocket Assy-F Seat Back-Leather	11-12-14 5Sed
C 202305	Cushion Frame & Back Complete-F Seat-LHD-Lea	11-12-14 3Cpe
C 202306	Cushion Frame & Back Complete-F Seat-RHD-Lea	11-12-14 3Cpe
C 202307	Cushion Frame & Back Complete-F Seat-LIID	17 5Sed
C 202308	Cushion Frame & Back Complete-F Seat-RHD	17 5Sed
C 202310	Trim Assy-F Seat Back-RH-Lea	17 5Sed
C 202311	Trim Assy-F Seat Back-LH-Lea	17 5Sed
C 202314	Center Arm Rest Complete-F Seat-Lea	17 5Sed
C 202320	Trim Assy-F Seat Cushion-Lea	10T-10P-11-12-14 2Sed,10 UCpe
C 202321	Back Complete-F Seat-LHD-Drivers-Lea	10T-10P-11 2Sed
C 202322	Back Complete-F Seat-RHD-Drivers-Lea	10T-10P-11 2Sed
C 202323	Back Complete-F Seat-LHD-Passenger-Lea	10T-10P-11 2Sed
C 202324	Back Complete-F Seat-RHD-Passenger-Lea	10T-10P-11 2Sed
C 202325	Cushion Complete-F Seat-Lea-Std	10T-10P-11 2Sed,10 UCpe
C 202326	Trim Assy-F Seat Back-RH-Lea	10T-10P-11-12-14 2Sed,10 UCpe
C 202327	Trim Assy-F Seat Back-LH-Lea	10T-10P-11-12-14 2Sed,10 UCpe
C 202328	Cushion Complete-F Seat-Lea-Airfoam	10T-10P-11-12-14 2Sed,10 UCpe
C 202333	Back Complete-F Seat-LHD-Drivers-Lea	12-14 2Sed
C 202334	Back Complete-F Seat-RHD-Drivers-Lea	12-14 2Sed
C 202335	Back Complete-F Seat-LHD-Passengers-Lea	12-14 2Sed
C 202336	Back Complete-F Seat-RHD-Passengers-Lea	12-14 2Sed
C 202342	Back Complete-F Seat-RH-Lea	10 UCpe
C 202343	Back Complete-F Seat-LH-Lea	10 UCpe
C 202351	Back Complete-F Seat-LHD-Drivers-Lea	10T-10P-11 ClubCpe
C 202352	Back Complete-F Seat-RHD-Drivers-Lea	10T-10P-11 ClubCpe
C 202353	Back Complete-F Seat-LHD-Passengers-Lea	10T-10P-11 ClubCpe
C 202354	Back Complete-F Seat-RHD-Passengers-Lea	10T-10P-11 ClubCpe
C 202355	Back Complete-F Seat-LHD-Drivers-Lea	12-14 ClubCpe,15 3Cpe-ClubCpe
C 202356	Back Complete-F Seat-RHD-Drivers-Lea	12-14 ClubCpe,15 3Cpe-ClubCpe
C 202357	Back Complete-F Seat-LHD-Passengers-Lea	12-14 ClubCpe,15 3Cpe-ClubCpe
C 202359	Trim Assy-F Seat Cushion-Leather	10 thru 15 ClubCpe-2Sed,15 3Cpe,10 UCpe
C 202360	Trim Assy-F Seat Back-RH-Leather	1941 ClubCpe,15 3Cpe
C 202361	Trim Assy-F Seat Back-LH-Leather	1941 ClubCpe,15 3Cpe
C 202364	Cushion Complete-F Seat-Leather-Std	10T-10P-11 ClubCpe-2Sed,10 UCpe
C 202365	Cushion Complete-F Seat-Leather-Airfoam	1941 ClubCpe-2Sed,15 3Cpe,10 UCpe
C 202367	Cushion Frame & Back Complete-Front Seat-LHD-Mohair	10T 5Sed
C 202368	Cushion Frame & Back Complete-Front Seat-RHD-Mohair	10T 5Sed
C 202369	Cushion Frame & Back Complete-Front Seat-LHD-Mohair	11 5Sed
C 202370	Cushion Frame & Back Complete-Front Seat-RHD-Mohair	11 5Sed
C 202371	Back Complete-Rear Seat-Leather	10T-10P-11-12-14-18 5Sed
C 202372	Back Complete-Rear Seat-Leather	10T-10P-11-12-14-18 5Sed
C 202373	Trim Assy-Rear Seat Back-Leather	10 UCo
C 202374	Cushion Complete-Rear Seat-Leather-Std	10T-10P-11 5Sed-2Sed,18 5Sed
C 202375	Cushion Complete-Rear Seat-Leather-Airfoam	10T-10P-11-12-14 5Sed,2Sed,17 5Sed
C 202376	Trim Assy-Rear Seat Cushion	10T-10P-11-12-14 5Sed,2Sed,17 5Sed
C 202377	Back Complete-Rear Seat Lea	17 5Sed
C 202378	Back Complete-Rear Seat Lea	17 5Sed
C 202379	Floor Covering Assy-Rear Compartment	10-11-20-21 CvSed,51,171 CvBro
C 202380	Trim Assy-Rear Seat Back-RH-Lea	17 5Sed
C 202381	Trim Assy-Rear Seat Back-LH-Lea	17 5Sed
C 202382	Center Arm Rest Complete-Rear Seat Back-Lea	17 5Sed
C 202391	Back Complete-Rear Seat-Leather	10T-10P-11-12-14 ClubCpe
C 202392	Trim Assy-Rear Seat Back-Lea	10T-10P-11-12-14 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

279

Part No.	Name	Models
C 202393	Cushion Complete-Rear Seat-Leather-Std	10T-10P-11 ClubCpe
C 202394	Cushion Complete-Rear Seat-Leather-Airfoam	10T-10P-11-12-14-15 ClubCpe,15 3Cpe
C 202395	Trim Assy-Rear Seat Cushion-Leather	10T-10P-11-12-14-15 ClubCpe
C 202396	Trim Assy-Rear Seat Back-RH-Leather	15 ClubCpe
C 202397	Trim Assy-Rear Seat Back-LH-Leather	15 ClubCpe
C 202398	Back Complete-Rear Seat-Leather	15 ClubCpe
C 202402	Center Trimboard Assy-F Seat Back	17 5Sed
C 202409	Center Arm Rest Complete-Rear Seat Back-Lea	15 ClubCpe
C 202414	Seat Complete-Auxiliary-RH	18 Carryall
C 202415	Seat Complete-Auxiliary-LH	18 Carryall
C 202416	Trim Assy-Auxiliary Seat Cushion-RH	18 Carryall
C 202417	Trim Assy-Auxiliary Seat Cushion-LH	18 Carryall
C 202418	Seat Complete-Auxiliary-RH-Cloth	17-18 7Sed
C 202419	Seat Complete-Auxiliary-LH-Cloth	17-18 7Sed
C 202420	Trim Assy-Auxiliary Seat-RH-Lea	17-18 7Sed
C 202421	Trim Assy-Auxiliary Seat-LH-Lea	17-18 7Sed
C 202422	Trim Assy-Auxiliary Seat Back-Cloth	17-18 7Sed
C 202462	Carpet Assy-Rear Pillar Floor	1941-1942 CvSed,1946-1947 CvBro
C 202463	Carpet Assy-Rear Floor-LHD	10-11 CvSed
C 202464	Carpet Assy-Rear Floor-RHD	10-11 CvSed
C 202465	Floor Covering Assy-Rear Seat Tray Floor	1941-1942 CvSed,1946-1947 CvBro
C 202466	Carpet-Wheelhouse-RH	1941-1942 CvSed,1946-1947 CvBro
C 202467	Carpet-Wheelhouse-LH	1941-1942 CvSed,1946-1947 CvBro
C 202471	Trimboard-Rear Compartment	1941-1942 CvSed,1946-1947 CvBro
C 202476	Trimboard & Trim Assy-Rear Compartment	1941-1942 CvSed,1946-1947 CvBro
C 202480	Trimboard-Rear Seat Back Spring	1941 CvSed,1946-1947 CvBro
C 202485	Back Complete-F. Seat-Drivers-LHD	10-11 CvSed
C 202486	Back Complete-F Seat-Drivers-RHD	10-11 CvSed
C 202487	Back Complete-F Seat-Passenger-LHD	10-11 CvSed
C 202488	Back Complete-F Seat-Passenger-RHD	10-11 CvSed
C 202490	Trim Assy-Front Seat Back-RH	10-11 CvSed
C 202491	Trim Assy-Front Seat Back-LH	10-11 CvSed
C 202492	Cushion Complete-Front Seat	10-11 CvSed
C 202493	Trim Assy-Front Seat Cushion	10-11 CvSed
C 202494	Back Complete-Rear Seat	10-11 CvSed,51-171 CvBro
C 202495	Trim Assy-Rear Seat Back	10-11-20P-21 CvSed,51 CvBro
C 202496	Cushion Complete-Rear Scat	10-11 CvSed
C 202497	Trim Assy-Rear Seat Cushion	10-11 CvSed
C 202503	Back Complete-F Seat-Driver-LHD	12-14 CvSed
C 202504	Back Complete-F Seat-Driver-RHD	12-14 CvSed
C 202505	Back Complete-F Seat-Passenger-LHD	12-14 CvSed
C 202506	Back Complete-F Seat-Passenger-RHD	12-14 CvSed
C 202508	Trim Assy-Front Seat Back-RH	12-14 CvSed
C 202509	Trim Assy-Front Seat Back-LH	12-14 CvSed
C 202510	Cushion Complete-F Seat	12-14 CvSed
C 202511	Trim Assy-F Seat Cushion	12-14 CvSed
C 202512	Back Complete-Rear Seat	12-14-22-24 CvSed
C 202513	Trim Assy-Rear Seat Back	12-14-22-24 CvSed
C 202514	Cushion Complete-Rear Seat	12-14 CvSed
C 202515	Trim Assy-Rear Seat Cushion	12-14 CvSed
BO 202526	Slide Fastener Assy-Top Rear Curtain-RH	1941-1942 CvSed
BO 202527	Slide Fastener Assy-Top Rear Curtain-LH	1941-1942 CvSed
C 202530	Top Complete-Less Qtr Window	1941-1942 CvSed
C 202531	Top Deck & Side Quarter Assy-Less Qtr Wdo	1941-1942 CvSed
C 202532	Top Complete	1941-1942 CvSed,1946-1947 CvBro
C 202533	Top Deck & Side Quarter Assy-With Qtr Wdo	1941-1942 CvSed,1946-1947 CvBro
C 202534	Reinforcement Assy-Top-RH	1941-1942 CvSed,1946-1947 CvBro
C 202535	Reinforcement Assy-Top-LH	1941-1942 CvSed,1946-1947 CvBro
C 202536	Curtain and Window Assy-Top Rear	1941-1942 CvSed
BO 202538	Dust Boot Assy-Top	1941-1942 CvSed,1946-1947 CvBro
BO 202539	Bag Assy-Top Dust Boot Use 207766	1941-1942 CvSed,1946-1947 CvBro
C 202561	Back Complete-Rear Seat-Cloth exc Mohair	10 UCo
C 202562	Cushion Complete-Rear Seat-Cloth exc Mohair	10 UCo
C 202563	Trim Assy-Rear Scat Cushion-Cloth exc Mohair	10 UCo
C 202564	Back Complete-Rear Seat-Mohair	10 UCo
C 202565	Cushion Complete-Rear Scat-Mohair	10 UCo
C 202566	Trim Assy-Rear Seat Cushion-Mohair	10 UCo
C 202567	Back Complete-Rear Seat-Leather	10 UCo
C 202568	Cushion Complete-Rear Seat-Leather	10 UCo
C 202569	Trim Assy-Rear Seat Cushion-Leather	10 11Co
C 202570	Trim Panel-Rear Seat Back-Tan Cloth	10-11-12-14 Sed-2Sed,17 5Sed
C 202598	Arm Rest Assy-Qtr-RH	10T Sed
C 202599	Arm Rest Assy-Qtr-LH	10T Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 202608	Arm Rest Assy-Qtr-RH	10P Sed
C 202609	Arm Rest Assy-Qtr-LH	10P Sed
C 202610	Trim Assy-Qtr Arm Rest-RH	10 Sed
C 202611	Trim Assy-Qtr Arm Rest-LH	10 Sed
C 202641	Trim Assy-Front Seat Cushion Retainer-Cloth	10T ClubCpe
C 202643	Cushion Frame & Back Complete-F Scat-LHD-Cloth	10T Sed
C 202644	Cushion Frame & Back Complete-F Seat-RHD-Cloth	10T Sed
C 202651	Cushion Frame & Back Complete-F Seat-LHD-Cloth	10T 3Cpe
C 202652	Cushion Frame & Back Complete-F Seat-RHD-Cloth	10T 3Cpe
C 202653	Trim Assy-F Seat Riser Panel-Cloth	10T-20T 2Sed,10-20 UCo,UCpe
C 202654	Trim Assy-F Seat Riser Panel-Cloth	10T 2Sed,10 UCo,20T ClubCpe
C 202656	Trim Assy-Rear Seat Cushion	10T Sed-2Sed,10 UCo
BO 202658	Weatherstrip Assy-Folding Pillar-RH	1941-1942 CvSed,1946-1947 CvBro
BO 202659	Weatherstrip Assy-Folding Pillar-LH	1941-1942 CvSed,1946-1947 CvBro
C 202660	Weatherstrip Assy-Side Header Rail-RH	1941-1942 CvSed,1946-1947 CvBro
C 202661	Weatherstrip Assy-Side Header Rail-LH	1941-1942 CvSed,1946-1947 CvBro
C 202663	Rubber Pad Assy-Rear Seat Cushion	17 7Sed
C 202664	Weatherstrip Assy-Front Door Bottom-RH	1941-1942-1946-1947 Sed exc 17-27,1941-1947 Cab-CabPu
C 202665	Weatherstrip Assy-Front Door Bottom-LH	1941-1942-1946-1947 Sed exc 17-27,1941-1947 Cab-CabPu
C 202666	Weatherstrip Assy-Front Door Bottom-RH	1941-1942-1946-1947 exc Sed-Cab-CabPu
C 202667	Weatherstrip Assy-Front Door Bottom-LH	1941-1942-1946-1947 exc Sed-Cab-CabPu
C 202668	Weatherstrip Assy-Rear Door Bottom	1941-1942-1946-1947 Sed
C 202669	Back Complete-Rear Seat-Cloth	17 7Sed
C 202670	Trim Assy-Rear Seat Back-RH-Cloth	17 7Sed
C 202671	Trim Assy-Rear Seat Back-LH-Cloth	17 7Sed
C 202672	Cushion Complete-Rear Seat Cloth	17 7Sed
C 202673	Trim Assy-Rear Seat Cushion-Cloth	17 7Sed
C 202674	Back Complete-Rear Seat-Leather-RH	17 7Sed
C 202675	Back Complete-Rear Seat-Leather-LH	17 7Sed
C 202676	Trim Assy-Rear Seat Back-RH-Leather	17 7Sed
C 202677	Trim Assy-Rear Seat Back-LH-Leather	17 7Sed
C 202678	Cushion Complete-Rear Seat-Leather	17 7Sed
C 202679	Trim Assy-Rear Seat Cushion-Leather	17 7Sed
C 202680	Arm Rest Complete-Rear Seat Center-Cloth	17 7Sed
C 202681	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	17 7Sed
C 202682	Arm Rest Complete-Rear Seat Back Center-Lea	17 7Sed
C 202683	Trim Assy-Rear Seat Back Center Arm Rest-Lea	17 7Sed
C 202685	Back Complete-Rear Seat-Cloth	18 7Sed
C 202686	Trim Assy-Rear Seat Back-Cloth	18 7Sed
C 202687	Cushion Complete-Rear Seat-Cloth-Std	18 7Sed
C 202688	Cushion Complete-Rear Seat-Cloth-Airfoam	18 7Sed
C 202689	Trim Assy-Rear Seat Cushion-Cloth-Std	18 7Sed
C 202690	Trim Assy-Rear Seat Cushion-Cloth-Airfoam	18 7Sed
C 202691	Back Complete-Rear Seat-Leather	18 7Sed
C 202692	Trim Assy-Rear Seat Back-Leather	18 7Sed
C 202693	Cushion Complete-Rear Seat-Leather-Std	18 7Sed
C 202694	Cushion Complete-Rear Seat-Leather-Airfoam	18 7Sed
C 202695	Trim Assy-Rear Seat Cushion-Leather	18 7Sed
C 202698	Back Complete-Rear Seat	18 Carryall
C 202699	Trim Assy-Rear Seat Back	18 Carryall
C 202700	Cushion Complete-Rear Seat	18 Carryall
C 202701	Trim Assy-Rear Seat Cushion	18 Carryall
C 202702	Seat Complete-Aux-RH-Leather	17-18 7Sed
C 202703	Seat Complete-Aux-LH-Leather	17-18 7Sed
C 202704	Trim Assy-Aux Seat Cushion-RH-Leather	17-18 7Sed
C 202705	Trim Assy-Aux Seat Cushion-LIT-Leather	17-18 7Sed
C 202706	Trim Assy-Aux Seat Cushion Back-Leather	17-18 7Sed
C 202707	Back Complete-Front Seat-Cloth	17-18 7Sed
C 202708	Back Complete-Front Seat-Leather	17-18 7Sed
C 202718	Filler Block & Trim Assy-Top to Qtr Panel-RH	1941-1942 CvSed
C 202719	Filler Block & Trim Assy-Top to Qtr Panel-LH	1941-1942 CvSed
C 202720	Trim Panel-Shelf-Bottom-Newport Tan	1941 3Cpe-UCpe
C 202722	Trim Panel-Shelf-Bottom-Green	10P-11-12-14-15 3Cpe
C 202731	Trim Panel-Shelf-Bottom-Quaker Gray	1941 ClubCpe
C 202734	Trim Panel-Shelf-Bottom-Light Tan	10T ClubCpe
BO 202741	Carpet Assy-Rear Floor-LHD	10-20 UCo
BO 202742	Carpet Assy-Rear Floor-RHD	10-20 UCo
C 202746	Back Complete-Rear Seat-RH-Cloth	1941 2Sed-5Sed-UCo
C 202747	Back Complete-Rear Seat-LH-Cloth	1941 2Sed-5Sed-UCo
C 202748	Trim Assy-Rear Seat Back-RH-Cloth	1941 2Sed-5Sed-UCo
C 202749	Trim Assy-Rear Seat Back-LH-Cloth	1941 2Sed-5Sed-UCo
C	Cushion Complete-Rear Seat-RH-Cloth	1941 2Sed-5Sed-UCo

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 202751	Cushion Complete-Rear Seat-LH-Cloth	1941 2Sed-5Sed-UCo
C 202752	Trim Assy-Rear Seat Cushion-RH-Cloth	1941 2Sed-5Sed-UCo
C 202753	Trim Assy-Rear Seat Cushion-LH-Cloth	1941 2Sed-5Sed-UCo
C 202754	Back Complete-Rear Seat-RH-Leather	1941 2Sed-5Sed-UCo
C 202755	Back Complete-Rear Seat-LH-Leather	1941 2Sed-5Sed-UCo
C 202758	Cushion Complete-Rear Seat-RH-Leather	1941 2Sed-5Sed-UCo
C 202759	Cushion Complete-Rear Seat-LH-Leather	1941 2Sed-5Sed-UCo
C 202764	Trimboard Complete-Qtr-RH-Cloth	13-17 7Sed
C 202765	Trimboard Complete-Qtr-LH-Cloth	13-17 7Sed
C 202766	Trimboard Complete-Qtr-RH-Leather	13-17 7Sed
C 202767	Trimboard Complete-Qtr-LH-Leather	13-17 7Sed
C 202771	Trimboard-Lower Quarter	18 7Sed
C 202785	Carpet Assy-Rear Floor	18 Carryall
C 202786	Trimboard Complete-Qtr-RH-Cloth	18 7Sed
C 202787	Trimboard Complete-Qtr-LH-Cloth	18 7Sed
C 202788	Trimboard Complete-Quarter-RH-Leather	18 7Sed
C 202789	Trimboard Complete-Quarter-LH-Leather	18 7Sed
C 202794	Trimboard Complete-Quarter	18 Carryall
C 202795	Trimboard Complete-Quarter	18 Carryall
C 202803	Trim Assy-Rear Seat Cushion	1941 2Sed-5Sed-Uco
BO 202804	Carpet Assy-Rear Floor	18 7Sed
BO 202805	Carpet Assy-Rear Floor	17 7Sed
	202806 Carpet Assy-Rear Floor (Use 202130)	12-14 Sedan,1942 Sed exc 27,1946-1947 Sed
	202807 Carpet Assy-Rear Floor-LHD (Use 202125)	12-14 2Sed,1942 Sed,1946-1947 Bro
C 202808	Carpet Assy-Rear Floor-RHD	12-14 2Sed,1942 Sed,1946-1947 Bro
C 202809	Carpet Assy-Rear Floor-LHD	12-14-15 ClubCpe,1942-1946-1947 ClubCpe
C 202810	Carpet Assy-Rear Floor-RHD	12-14-15 ClubCpe,1942-1946-1947 ClubCpe
C 202811	Carpet Assy-Rear Floor-LHD	15 3Cpe
C 202812	Carpet Assy-Rear Floor-RHD	15 3Cpe
C 202813	Carpet Assy-Rear Floor	12-14 3Cpe,1942 3Cpe-UCpe,1946-1947 3Cpe
C 202814	Trimboard Assy-Front Seat Back-Cloth	10-11-12-14 3Cpe
BO 202815	Carpet Assy-Rear Floor-LHD	12-14 CvSed,1942 CvSed,1946-1947 CvBro
BO 202816	Carpet Assy-Rear Floor-RHD	12-14 CvSed,1942 CvSed 1946-1947 CvBro
C 202817	Trimboard Assy-Front Seat Back-Leather	10-11-12-14 3Cpe
C 202830	Trimboard-Lower Quarter	11-12-14 VicCpe
C 202831	Trimboard-Lower Quarter	11-12-14 VicCpe
BO 202832	Dust Boot Assy-Top	1941-1942 CvSed
C 202834	Trimboard & Trim Assy-Folding Pillar-RH	1941-1942 CvSed
C 202835	Trimboard & Trim Assy-Folding Pillar-LH	1941-1942 CvSed
C 202836	Headlining Assy	10C-18C Cab-CabPu
C 202837	Cushion Frame & Back Complete-Front Seat-LHD	10 UCpe
C 202838	Cushion Frame & Back Complete-Front Seat-RHD	10 UCpe
C 202844	Carpet Assy-Rear Floor-LHD	10-11 2Sed
C 202845	Carpet Assy-Rear Floor-RHD	10-11 2Sed
C 202845	Carpet Assy-Rear Floor-LHD	12-14 2Sed
C 202847	Carpet Assy-Rear Floor-RHD	12-14 2Sed
C 202848	Carpet Assy-Rear Floor-LHD	10-11 Sed
C 202849	Carpet Assy-Rear Floor-RHD	10-11 Sed
C 202850	Carpet Assy-Rear Floor-LHD	12-14 Sed
C 202851	Carpet Assy-Rear Floor-RHD	12-14 Sed
C 202852	Carpet Assy-Rear Floor-LHD	17 5Sed
C 202853	Carpet Assy-Rear Floor-RHD	17 5Sed
C 202855	Panel-Rear Compt Side Trim	1941-1942 CvSed,1946-1947 CvBro
C 202857	Trim Panel & Trim Assy-Rear Compt Side	1941-1942 CvSed,1946-1947 CvBro
C 202866	Trimboard Complete-Quarter-RH-Cloth	12-14 2Sed
C 202867	Trimboard Complete-Quarter-LH-Cloth	12-14 2Sed
C 202868	Trimboard Complete-Quarter-RH-Leather	12-14 2Sed
C 202869	Trimboard Complete-Quarter-LH-Leather	12-14 2Sed
C 202876	Trimboard Complete-Quarter-RH-Cloth	11-12-14 ClubCpe
C 202877	Trimboard Complete-Quarter-LH-Cloth	11-12-14 ClubCpe
C 202878	Trimboard Complete-Quarter-RH-Leather	11-12-14 ClubCpe
C 202879	Trimboard Complete-Quarter-LH-Leather	11-12-14 ClubCpe
C 202880	Trim Assy-Front Seat Back-Cloth	10T Sed-3Cpe
C 202881	Trim Assy-Front Seat Back-Cloth	10P-11 Sed-3Cpe
C 202882	Trim Assy-Front Seat Back-Cloth	12-14 Sed-3Cpe
C 202883	Trim Assy-Front Seat Back-Leather	10-11-12-14 Sed-3Cpe
C 202884	Trim Assy-Rear Seat Back-Cloth exc Mohair	10T Sed-2Sed,10UCo
C 202885	Trim Assy-Rear Seat Back-Cloth	10P-11 Sed-2Sed
C 202886	Trim Assy-Rear Seat Back-Cloth	12-14 Sed-2Sed
C 202887	Trim Assy-Rear Seat Back-Mohair	10T Sed-2Sed
C 202888	Trim Assy-Rear Seat Back-Leather	10-11-12-14 Sed-2Sed,10 UCo
C 202890	Trimboard Complete-Qtr-RH-Cloth Exc Mohair	11 2Sed
C 202891	Trimboard Complete-Qtr-LH-Cloth Exc Mohair	11 2Sed
C 202892	Trimboard Complete-Qtr -RH-Mohair	11 2Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 202893	Trimboard Complete-Qtr-LH-Mohair	11 2Sed
C 202894	Trimboard Complete-Qtr-RH-Leather	11 2Sed
C 202895	Trimboard Complete-Qtr-LH-Leather	11 2Sed
C 203002 Pr	Panel-Cowl-RH	21 thru 27 exc Station,51 thru 54,171 thru 174
C 203003 Pr	Panel-Cowl-LII	21 thru 27 exc Station,51 thru 54,171 thru 174
C 203004 Pr	Panel-Cowl-RH	20C
C 203005 Pr	Panel-Cowl-LH	20C
C 203006 Pr	Panel-Front End	22 thru 27,52,172,54-174 exc CvBro
C 203007	Panel Assy-Front End	20 Cab-CabPu
C 203008	Panel Assy-Front End	20 exc Cab-CabPu
C 203009	Panel Assy-Front End	28 Cab-CabPu,21 Station,58-178 Cab-CabPu
C 203020 Pr	Panel-Cowl-RH	28 Cab-CabPu,21 Station,58-178
C 203021 Pr	Panel-Cowl-LH	28 Cab-CabPu,21 Station,58-178
C 203028	Panel Assy-Dash-LHD	1942-1946-1947 All
C 203029 Pr	Panel Assy-Dash-RHD	1942-1946-1947 All
*A 203030 Pr	Fender-Rear-RH	20T,20P,21 thru 27 exc Station
*A 203031 Pr	Fender-Rear-LH	20T,20P,21 thru 27 exc Station
C 203034	Panel-Cowl-RH	20T,20P,20Sp
C 203035	Panel-Cowl-LH	20T,20P,20Sp
*C 203040	Extension Assy-F Door Outside Panel-RH	20-21-22-24 Sed,1946-1947 Sed
*C 203041	Extension Assy-F Door Outside Panel-LH	20-21-22-24 Sed,1946-1947 Sed
*C 203046	Extension Assy-F Door Outside Panel-RH	1942 ClubCpe-3Cpe-2Sed-UCo-UCpe-CvSed,27 Sed. 1946-1947 exc Sed-Cab-CabPu
*C 203047	Extension Assy-F Door Outside Panel-LH	1942 ClubCpe-3Cpe-2Sed-UCo-UCpe-CvSed,27 Sed, 1946-1947 exc Sed-Cab-CabPu
BO 203059	Bracket-Roof Panel Bow	1942 Sed-2Sed-UCo-Cpe,1946-1947 Bro-Sed-3Cpe-ClubCpe
203061	Panel-Roof (Use 146061)	22-24 Sed-2Sed,52-54 Bro-Sed
C 203070	Trim Retainer Assy-F Door Bottom-RH	1942 2Sed-3Cpe-ClubCpe-UCo-UCpe,27 Sed,1946-1947 Bro-3Cpe-ClubCpe
C 203071	Trim Retainer Assy-F Door Bottom-LH	1942 2Sed-3Cpe-ClubCpe-UCo-UCpe,27 Sed,1946-1947 Bro-3Cpe-ClubCpe
BO 203072	Weatherstrip-Deck Door	1942 UCo-Sed-2Sed;1946-1947 Bro-Sed
BO 203073	Weatherstrip-Rear Compt Door	1942 ClubCpe-3Cpe-UCpe-CvSed,1946-1947 CvBro-3Cpe-ClubCpe
C 203098 Pr	Extension-Center Pillar	20 Sed,51-53 Sed,171-173 Sed
C 203099 Pr	Extension-Center Pillar	21 thru 27 Sed,52-54 Sed,172-174 Sed
C 203102	Trim Retainer Assy-F Door Bottom-RH	20-21-22-24 Sed,20-28 Cab-CabPu,1946-1947 Sed-Cab-CabPu
C 203103	Trim Retainer Assy-F Door Bottom-LH	20-21-22-24 Sed,20-28 Cab-CabPu,1946-1947 Sed-Cab-CabPu
BO 203105	Trim Retainer Assy-Rear Door Bottom	1942-1946-1947 Sed
C 203114	Panel Assy-Quarter Trim Protector-RH	20 UCo
C 203120 Pr	Header Assy-Body-RH	20 thru 24 Sed
C 203121 Pr	Header Assy-Body-LH	20 thru 24 Sed
C 203123 Pr	Header Assy-Body-LH	27 Sed
C 203129	Panel-Roof	20-21 Sed-2Sed-UCo
C 203130	Panel Assy-Roof	27,28P
C 203132	Panel Assy-Roof	22-24 Sed-2Sed
C 203134	Extension Assy-Quarter Panel-RH	20Cpe-UCo-.2Sed-CvSed,51-53-171-173 exc Sed
C 203135	Extension Assy-Quarter Panel-LH	20Cpe-UCo-2Sed-CvSed,51-53-171-173 exc Sed
C 203136 Pr	Extension Assy-Quarter Panel-RH	21-22-24-25 Cpe-2Sed-CvSed,51-53-171-173 exc Sed
C 203137 Pr	Extension Assy-Quarter Panel-LH	21-22-24-25 Cpe-2Sed-CvSed,51-53-171-173 exc Sed
*BO 203138	Extension Assy-Quarter Panel-RH	1942-1946-1947 Sed
*BO 203139	Extension Assy-Quarter Panel-LH	1942-1946-1947 Sed
C 203151	Tray and Reinf Assy-Rear Seat	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
C 203157	Brkt & Toe Board Riser Assy-F Pillar to Dash-LH	20
C 203161	Brkt & Toe Board Riser Assy-F Pillar to Dash-LH	21 thru 28,1946-1947 All
BO 203166	Support-Courtesy Lamp Socket	1942-52-54-172-174 Sed
BO 203167	Brkt-Cowl Panel Hinge Reirif Switch	21 thru 27 exc Station,52,54,172,174
BO 203169	Support-Courtesy Lamp Socket	1942 2Sed-Cpe,52-54-172-174-482-484-492-494-502-504 exc Sed
*C 203176	Extension Assy-Rear Door Outside Panel-RH	1942-1946-1947 Sed
*C 203177	Extension Assy-Rear Door Outside Panel-LH	1942-1946-1947 Sed
C 203180	Panel-Roof	1942 UCo-Cpe-3Cpe-ClubCpe
BZ 203190	Stone Deflector Kit-F Fender	1942-1946-1947 All
BZ 203191	Deflector-F Fender Stone	1942-1946-1947 All
BZ 203194	Stone Deflector Assy-F Fender-RH	1942-1946-1947 All
BZ 203195	Stone Deflector Assy-F Fender-LH	1942-1946-1947 All
BZ 203196	Channel & Supp Assy-F Fender Stone Deflector-RH	1942-1946-1947 All
C 203200	Panel-Rear Compt Door-Outside	20-21 Bro-Sed
C 203204	Panel-Rear Deck Door	1942 3Cpe-ClubCpe
203211	Door Assy-Rear Compartment (Use 206761)	20-21 Sed-2Sed,20T UCo
203213	Door Assy-Rear Compartment (Use 206761)	22-24-Sed-2Sed,27 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

283

Part No.	Name	Models
C 203215	Door Assy-De Ck (Use 206763)	20-21 3Cpe-ClubCpe-CvSed-UCpe
*A 203217	Door Assy-De Ck (Use 206763)	22-24-27 3Cpe-ClubCpe-CvSed
C 203219 Pr	Hood Assy	20
C 203225	Wire Well-Rear Seat Tray-Prime	20T,20P,21 thru 27 exc Station,51thru54,171 thru 174
C 203238	Cross Shaft Assy-Hood Lo Ck-LHD	1942-1946-1947 All
C 203239	Cross Shaft Assy-Hood Lo Ck-RHD	1942-1946-1947 All
C 203270	Tread-Safety Step-Front-RH	1942 ClubCpe-3Cpe-2Sed-CvSed-UCo-UCpe,27
203272	Tread-Safety Step-Front-RH (Use 203584)	20-21-22-24 Sed
203273	Use 203585	
C 203274	Tread-Safety Step-Rear-RH	1942 Sed
C 203275	Tread-Safety Step-Rear-LH	1942 Sed
*A 203289 Pr	Hood Assembly	21,28
*A 203299 Pr	Hood Assembly	22 thru 27
BZ 203309	Spa Cer-Bumper Fender Guard	21 thru 27,51,52,53,54
BZ 203311 Pr	Center Panel Assy-Rad Louver-Upper-Prime	1942 All
BO 203314	Bolt-F Fender Molding	20 thru 28,51 thru 54,171 thru 174
BO 203364	Bolt-Molding	22 thru 27 Bro-Sed-3Cpe-ClubCpe,52,54,172,174
BZ 203366	Brkt-Hood Hinge to Hood Panel-RH	1942-1946-1947 All
BZ 203367	Brkt-Hood Hinge to Hood Panel-LH	1942-1946-1947 All
BO 203368	Brkt-Hood Hinge Support	1942-1946-1947 All
203372	Arm & Cross Shaft Assy-Hood Hinge (Use 206372)	1942 All
BZ 203373	Spring-Hood Hinge Bolt	1942-1946-1947 All
BO 203376	Silencer-Hood Hinge to Hood Panel Brkt	1942 All
BO 203377	Bushing-Hood Hinge	1942-1946-1947 All
BO 203378	Liner-Hood Hinge Bushing	1942-1946-1947 All
BO 203379	Retainer-Hood Hinge Bushing	1942-1946-1947 All
*C 203470	Under BODy Panel Extension-RH	20 exc Cab-CabPu
*C 203471	Extension Assy-Under BODy Panel-LH	20T,20P
*C 203472	Extension Assy-Under BODy Panel-RH	21 exc Station,22,24,25,51 thru 54,171 thru 174
*C 203473	Extension Assy-Under BODy Panel-LH	21 exc Station,22,24,25,51 thru 54,171 thru 174
*C 203474	Extension Assy-Under BODy Panel-RH	27
*C 203475	Extension Assy-Under BODy Panel-LH	27
203499	Rim-Headlamp Lens (Use 212880)	1942 All
BO 203500	Ash Receiver Assy-Instrument Panel-Grained	22,28,21 Station
BO 203501	Ash Receiver Assy-Instrument Panel-Painted	20 thru 28 exc Station
C 203520	Extension Assy- Cowl Panel-RH	20 liCo-UCpe
C 203521	Extension Assy- Cowl Panel-LH	20 UCo-UCpe
*C 203530	Extension Assy- Cowl Panel-RH	21 thru 28,51 thru 54,171 thru 174
*C 203531	Extension Assy- Cowl Panel-LH	21 thru 28,51 thru 54,171 thru 174
C 203537 Pr	Side Panel & Extension Assy- Cowl-LH	20T,20P
C 203538 Pr	Side Panel & Extension Assy- Cowl-RH	21 exc Station,22 thru 27,51 thru 54,171 thru 174
C 203539 Pr	Side Panel & Extension Assy- Cowl-LH	21 exc Station,22 thru 27,51 thru 54,171 thru 174
C 203542	Panel-Front End	1942 CvSed,51-171 CvBro
BO 203554	Hinge & Cover Plate Assy-F Door-Upper BODy Half-RH	1942-1946-1947 exc Cab-CabPu
BO 203555	Hinge & Cover Plate Assy-F Door-Upper BODy Half-LH	1942-1946-1947 exc Cab-CabPu
BO 203556	Spring-Front Door Hinge-Upper RH-Lower LH	20 thru 28 exc Station,1946-1947 All
BO 203557	Spring-Front Door Hinge-Upper LH-Lower RH	20 thru 28 exc Station,1946-1947 All
BO 203558	Hinge-F Door-Upper Door Half-RH	1942-1946-1947 exc Cab-CabPu
BO 203559	Hinge-F Door-Upper Door Half-LH	1942-1946-1947 exc Cab-CabPu
BO 203562	Hinge-F Door-Lower BODy Half-RH	1942-1946-1947 exc Cab-CabPu
BO 203563	Hinge-F Door-Lower BODy Half-LH	1942-1946-1947 exc Cab-CabPu
BO 203564	Hinge-F Door-Lower Door Half-RH	1942-1946-1947 exc Cab-CabPu
BO 203565	Hinge-F Door-Lower Door Half-LH	1942-1946-1947 exc Cab-CabPu
BO 203566	Pin-F Door Hinge-Lower	1942-1946-1947 exc Cab-CabPu
BO 203576	Hinge & Cover Plate Assy-Rear Door-Lower Body Half-RH	1942-1946-1947 Sedan
BO 203577	Hinge & Cover Plate Assy-Rear Door-Lower Body Half-LH	1942-1946-1947 Sedan
BO 203578	Spring-Rear Door Hinge-Upper RH-Lower-LH	1942-1946-1947 Sedan
BO 203579	Spring-Rear Door Hinge-Upper LH-Lower-RH	1942-1946-1947 Sedan
BO 203582	Tread-Safety Step-Front-RH	1942 2Sed-UCo-UCpe-3Cpe-ClubCpe-CvSed,27 Sed,51 thru 54,171 thru 174 exc Sed
C 203583	Tread-Safety Step-Front-LH	1942 2Sed-UCo-UCpe-3Cpe-ClubCpe-CvSed,27 Sed,51 thru 54,171 thru 174 exc Sed
C 203584	Tread-Safety Step-Front-RH	20-21-22-24 Sed,1946-1947 Sed
C 203585	Tread-Safety Step-Front-LH	20-21-22-24 Sed,1946-1947 Sed
C 203586	Tread-Safety Step-Rear-RH	1942-1946-1947 Sed
C 203587	Tread-Safety Step-Rear-LH	1942-1946-1947 Sed
C 203662 Pr	Panel-F Door Outside-RH-Without Mldg Holes	20-21-51-53-171-173 3Cpe-ClubCpe,20 UCpe
C 203664	Panel-F Door Outside-RH-Without Mldg Holes-Prime.	20-21-51-53-171-173 Sed
C 203668	Panel-F Door Outside-RH-With Mldg Holes-Prime	20-21-51-53-171-173 3Cpe-ClubCpe,20 UCpe
203669	Panel-F Door Outside-LH-With Mldg Holes-Prime (Use 206629)	20-21 3Cpe-ClubCpe,20 UCpe,51-53 3Cpe-ClubCpe
C 203670	Panel-F Door Outside-RH-With Mldg Holes-Prime	20-21-51-53-171-173 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 203671	Panel-F Door Outside-LH-With Mldg Holes-Prime	20-21 Sed,51-53 Sed
C 203672	Panel-F Door Outside-RH-Prime	20-21 CvSed,51-171 CvBro
C 203678	Panel-F Door Outside-RH-Prime	22-24-25-52-54-172-174 3Cpe-ClubCpe
C 203679	Panel -F Door Outside-LH-Prime	22-24-25 3Cpe-ClubCpe,52-54 3Cpe-ClubCpe
C 203680	Panel-F Door Outside-RH-Prime	22-24-52-54-172-174 Sed
C 203681	Panel-F Door Outside.-LH-Prime (Use 206641)	22-24 Sed,52-54 Sed
C 203682	Panel-F Door Outside-RH-Prime	1942-1946-1947 Cab-CabPu
C 203683	Panel-F Door Outside-LH-Prime	1942-1946-1947 Cab-CabPu
C 203692	Panel-Rear Door Outside-RH-With Mldg-Prime	20-21-51-53-171-173 Sed
C 203697	Panel-Rear Door Outside-LH-Prime	22-24-52-54-172-174 Sed
C 203698	Panel-Rear Door Outside-Rll-Prime	27
C 203699	Panel-Rear Door Outside-LH-Prime	27
BO 203762	Spring-Rear Compt Door Clamping Lever-RH	20 thru 28,51,52,53,54,171 thru 174
BO 203763	Spring-Rear Compt Door Clamping Lever-LH	20 thru 28,51,52,53,54,171 thru 174
BO 203766	Clamping Lever & Brkt Assy-Rear Compt Door-RH	20 thru 28,51,52,53,54,171 thru 174
BO 203767	Clamping Lever & Brkt Assy-Rear Compt Door-LH	20 thru 28,51,52,53,54,171 thru 174
BZ 203769	Shim-Rear Bumper Stone Guard to Frame Bar	20 thru 28,51 thru 54,171 thru 174
C 203772	Frame Assy-F Seat Cushion	20-21-22-24 5Sed,1946-1947 Sed
C 203773	Frame & T Nut Assy-F Seat Cushion	20-21-22-24 5Sed,1946-1947 Sed
C 203774	Frame Assy-F Seat Cushion	20-21-22-24 5Sed,1946-1947 3Cpe
BO 203787	Clamp-Cigar Lighter Base	27 Sed
C 203792	Riser Panel & Brkts Assy-F Seat	1942 5Sed,20-21-22-24 3Cpe,1946-1947 3Cpe-Sed
BO 203800	Screen-Inst Panel Grille	1942 All
BO 203801	Screen-Inst Panel Grille	1942 All
BO 203806	Brkt-F Seat Side Panel to Back Frame	27 5Sed
C 203811	Panel Assy-LH-F Seat Back-LHD	1942 2Sed,1946-1947 Bro
C 203812	Panel Assy-RH-F Seat Back-RHD	1942 2Sed,1946-1947 Bro
C 203813	Panel Assy-LH-F Seat Back-RHD	1942 2Sed,1946-1947 Bro
C 203814	Panel Assy-F Seat Back-RH-LHD	1942 CvSed-ClubCpe,1946-1947 CvBro-ClubCpe
C 203815	Panel Assy-F Seat Back-LH-LHD	1942 CvSed-ClubCpe,1946-1947 CvBro-ClubCpe
C 203818	Frame Assy-F Seat Back	27 5Sed
C 203821	Panel & Riser Assy-F Seat Back	20-21-22-24 Sed-3Cpe,1946-1947 Sed-3Cpe
C 203822	Panel Assy-F Seat Back	20-21-22-24-1946-1947 Sed-3Cpe
C 203826	Lacquer-Glidden	All
C 203828	Frame Assy-F Seat Cushion	27 5Sed
BO 203836	Weatherstrip-Door Lock Pillar	1942-1946-1947 All
*C 203838	Pillar Assy-Center-RH	20T Sed,51-53 Sed,171-173 Sed
*C 203839	Pillar Assy-Center-LH	20T Sed,51-53 Sed,171-173 Sed
*C 203840	Pillar Assy-Center-RH	21 thru 27 Sed,52-54 Sed,172-174 Sed
*C 203841	Pillar Assy-Center-LH	21 thru 27 Sed,52-54 Sed,172-174 Sed
*A 203880 Pr	Fender Assy-Front-RH-Without Lamp Holes	20T,20P,20Sp,21 exc Station
*A 203881 Pr	Fender Assy-Front-LH-Without Lamp Holes	20T,20P,20S11,21 exc Station
203882	Fender Assy-Front-RH-With Lamp Holes (Use 203880).	20T,20P,20Sp,21 exc Station
203882	Fender Assy-Front-LH-With Lamp Holes (Use 203881).	20T,20P,20Sp,21 exc Station,22 thru 27
A 203890 Pr	Fender Assy-Front-RH	1942 Cab-CabPu
A 203891 Pr	Fender Assy-Front-LH	1942 Cab-CabPu
A 203894 Pr	Fender Assy-Front-RH-Without Lamp Holes	21 Station
A 203895 Pr	Fender Assy-Front-LH-Without Lamp Holes	21 Station
A 203896 Pr	Fender Assy-Front-RH-With Lamp Holes	21 Station
A 203897 Pr	Fender Assy-Front-LH-With Lamp Holes	21 Station
*C 203902 Pr	Door Assy-Front-RH-Without Mldg Holes	20-21 2Sed-UCo,51-53-171-173 Bro
203903	Door Assy-Front-LH-Without Mldg Holes (Use 206403).	20-21 2Sed-UCo,51-53 Bro
203906	Door Assy-Front-RH-With Mldg Holes (Use 203902)	20-21 2Sed-UCo,51-53-171-173 Bro
203907	Door Assy-Front-LH-With Mldg Holes (Use 206407)	20-21 2Sed-UCo,51-53 Bro
*C 203910 Pr	Door Assy-Front-RH-Without Mldg Holes	20-21 Sed,51-53-171-173 Sed
203911	Door Assy-Front-LH-Without Mldg Holes (Use 206411).	20-21 Sed,51-53 Sed
203914	Door Assy-Front-RH-With Mldg Holes (Use 203910)	20-21 Sed,51-53-171-173 Sed
203915	Door Assy-Front-LH-With Mldg Holes (Use 206411)	20-21 Sed,51-53 Sed
*C 203918 Pr	Door Assy-Front-RH	1942-1946-1947 Cab-CabPu
*C 203919 Pr	Door Assy-Front-LH	1942-1946-1947 Cab-CabPu
*C 203922 Pr	Door Assy-Front-RH-Without Mldg Holes	20-21 ClubCpe-3Cpe-IJCpe,51-53-171-173 3Cpe-ClubCpe
203923	Door Assy-Front-LH-Without Mldg Holes (Use 206423).	20-21 ClubCpe-3Cpe-UCpe,51-53 3Cpe-ClubCpe
203926	Door Assy-Front-RH-With Mldg Holes (Use 203922)	20-21 3Cpe-ClubCpe-UCpe,51-53-171-173 3Cpe-ClubCpe
203927	Door Assy-Front-LH-With Mldg Holes (Use 206423)	20-21 3Cpe-ClubCpc-UCpe,51-53 3Cpe-ClubCpe
*C 203930 Pr	Door Assy-Front-RH	22-24 2Sed,27,52-54-172-174 Bro
203931	Door Assy-Front-LH (Use 206431)	22-24 2Sed,27,52-54 Bro
*C 203934 Pr	Door Assy-Front-RH	22-24 Sed,52-54-172-174 Sed
203935	Door Assy-Front-LH (Use 206435)	22-24 Sed,52-54 Sed
203938	Door Assy-Front-RH (Use 203922)	22-24-25 3Cpe-ClubCpe,52-54-172-174 3Cpe-ClubCpe
203939	Door Assy-Front-LH (Use 206439)	22-24-25 3Cpe-ClubCpe,52-54 3Cpe-ClubCpe
*C 203942 Pr	Door Assy-RH	20-21 CvSed,51-171 CvBro
203943	Door Assy-LH (Use 206443)	20-21 CvSed,51 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
203946	Door Assy-RH (Use 203942)	22-24 CvSed,54-174 CvBro
203947	Door Assy-LH (Use 206443)	22-24 CvSed,54 CvBro
*C 203962 Pr	Door Assy-Rear-RH-Without Mldg Holes	20-21 Sed,51-53-171-173 Sed
*C 203963	Door Assy-Rear-LH-Without Mldg Holes	20-21 Sed,51-53-171-173 Sed
203966	Door Assy-Rear-RH-With Mldg Holes (Use 203978)	20-21 Sed,51-53-171-173 Sed
C 203967 Pr	Door Assy-Rear-LH-With Mldg Holes	20-21 Sed,51-53-171-173 Sed
*C 203978 Pr	Door Assy-Rear-RH	22-24 Sed,52-54-172-174 Sed
*C 203979 Pr	Door Assy-Rear-LH	22-24 Sed,52-54-172-174 Sed
203982	Use 203978	
203983	Door Assy-Rear-LH (Use 203979)	27
203985	Washer-Cowl Vent Operating Handle-Lea(Use 120347)	1942-1946 All
BO 203986	Washer-Cowl Vent Hinge Brkt to Link Rivet-Leather	1942-1946-1947 All
BO 203990	Knob-Bonnet Lock & Handy Shift Handle	20T,20P,21 thru 27,1946-1947 All
BO 203991	Knob-Inst Panel Ash Receiver	20 thru 27,1946-1947 All
*HA 203992	Lighter Assy-Cigar-6 Volt	20 thru 27
203994	Knob-Cigar Lighter (Use 203995)	20 thru 27,1946-1947 All
BO 203995	Heating Element & Knob Assy-Cigar Lighter-6 Volt	20 thru 27,1946-1947 AU
203998	Shim-Front Splash Apron to Frame Bar-Rubber (Use 207046)	1942-1946 All exc Station-Del
BO 204012	Safety Lock Assy-Door-Less Cylinder	1942-1946-1947 All
BO 204014	Safety Lock Complete-Door	1942 exc Station-Del,1946-1947 All
BO 204020	Support-Radio Speaker	1942-1946-1947 All
BO 204021	Bracket-Radio Support	1942-1946-1947 All
BO 204022	Cover Plate-Radio Speaker	1942-1946-1947 All
BO 204023	Speaker Assy-Radio	1942 All
BO 204024	Gasket-Radio Speaker	1942-1946-1947 All
BO 204025	Tubing Shaft & Gear Assy-Radio	1942-1946-1947 All
BO 204026	Collar-Radio Manual Automatic Breaker	1942 All
BO 204027	Blade Assy-Radio Manual Automatic Selector Switch	1942 All
BO 204028	Brkt & Index Spring-Radio Tuning Shaft Rear	1942 All
BO 204030	Automatic Shaft, Gear, Screw & Top Assy-Radio	1942 All
BO 204031	Drum-Radio Indicator Dial	1942 All
BO 204032	Gear-Radio Dial Ratchet	1942 All
BO 204033	Drive Lever & Spring Assy-Radio Dial Ratchet Gear	1942 All
BO 204034	Spring-Radio Dial Ratchet Gear Drive Return	1942 All
BO 204035	Spring Assy Front Magnet Brkt & Detent Lever	1942 All
BO 204036	Brkt-Rear Magnet Mounting	1942 All
BO 204037	Coil and Terminal Assy-Magnet	1942 All
BO 204039	Spring-Magnet Coil Plunger Return	1942 All
BO 204040	Pointer-Radio Dial	1942-1946-1947 All
BO 204043	Scale-Radio Manual Tuning	1942 All
BO 204044	Scale-Radio Automatic Tuning	1942 All
BO 204045	Shield & Background Plate-Radio Dial Light	1942 All
BO 204052	Brkt-Qtr Wdo Frame to Rear Seat Back Panel-Lower	1942-1946-1947 Sed
BO 204053	Brkt-Qtr Wdo Frame to Rear Seat Back Panel Brace	1942 2Sed-UCo,1946-1947 Bro
BZ 204056	Brkt & Clamp Assy-F License Plate	20T,20C,28
BO 204062	Brkt-F Back Extension to Cushion Frame-RH	20 thru 24 5Sed-3Cpe,1946-1947 Sed-3Cpe
BO 204063	Brkt-F Seat Back Extension to Cushion Frame-LH	20 thru 24 5Sed-3Cpe,1946-1947 Sed-3Cpe
204066	Shim-F Seat Back Panel to Cushion FrameBrkt Rear	1946-1947 Sed-3Cpe
BO 204071	Anchor Brkt Assy-F Seat Back Spring	20T,20P,21 thru 27,51,52,53,54,171 thru 174
BO 204072	Hanger Brkt-F Seat Back Spring	20T,20P,21 thru 27
A 204080 Pr	Fender Assy-Rear-RH-Prime	1942 Station
BO 204089	Grounding Strip-Domelamp Switch	1942-1946-1947 Sed
C 204090	Pillar Assy-Center	20 Sed
204092	Use 203840 for RH, 203841 for LH	
C 204094	Pillar Assy-Front-RH	1942 exc CvSed-Cab-CabPu,1946-1947 exc CvBro-Cab-CabPu
C 204095	Pillar Assy-Front-LH	1942 exc CvSed-Cab-CabPu,1946-1947 exc CvBro-Cab-CabPu
C 204096	Reinf Assy-Center Pillar Upper	21 thru 27 Sed
C 204097	Reinf Assy-Center Pillar Lower	21 thru 27 Sed
BO 204100	Dial-Inst and Speedometer-LHD-Miles	20,21,22,24,28
BO 204101	Dial-Inst and Speedometer-LHD-Metric	20,21,22,24,28
BO 204102	Dial-Inst and Speedometer-RHD-Miles	20,21,22,24,28
BO 204103	Dial-Inst and Speedometer-RHD-Metric	20,21,22,24,28
BO 204104	Dial-Inst and Clock-LHD	20,21,22,24,28
BO 204105	Dial-hist and Clock-RHD	20,21,22,24,28
BO 204110	Dial-Inst and Speedometer-LHD-Miles	22 thru 27
BO 204111	Dial-Inst and Speedometer-LHD-Metric	22 thru 27
BO 204112	Dial-Inst and Speedometer-RHD-Miles	22 thru 27
BO 204113	Dial-Inst and Speedometer-RHD-Metric	22 thru 27
BO 204114	Dial-Inst and Clock-LHD	22 thru 27
BO 204115	Dial-Inst and Clock-LHD	22 thru 27
BO 204120	Backing Plate-Inst and Speedometer Dial-LHD	1942 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 204121	Backing Plate-Inst and Speedometer Dial-RHD	1942 All
BO 204122	Backing Plate-Inst and Clock Dial-LHD	1942 All
BO 204124	Finish Plate-Inst and Clock Dial-LHD	22 thru 27
BO 204125	Finish Plate-Inst and Clock Dial-RHD	22 thru 27
BO 204126	Finish Plate-Inst and Speedometer-LED	22 thru 27
BO 204127	Finish Plate-Inst and Speedometer-RHD	22 thru 27
BO 204131	Dial & Bezel Assy-Inst and Speedometer-Miles-LHD	22 thru 27
BO 204132	Dial & Bezel Assy-Inst and Speedometer-Miles-RHD	22 thru 27
BO 204133	Dial & Bezel Assy-Inst and Speedometer-Metric-LHD	22 thru 27
BO 204134	Dial & Bezel Assy-Inst and Speedometer-Metric-RHD	22 thru 27
BO 204135	Dial & Bezel Assy-Inst & Clock-LHD	22 thru 27
BO 204136	Dial & Bezel Assy-Inst and Clock-RHD	22 thru 27
BO 204138	Spring-Door Handle Return-RH	10,11,18,20,21,28,51,53,58,171,173,178
BO 204139	Spring-Door Handle Return-LH	10,11,18,20,21,28,51,53,58,171,173,178
F 204140	Handle Assy-RH Front-LH Rear	20,51,53,58,171,173,178
F 204141	Handle Assy-LH Front-RH Rear	20,51,53,58,171,173,178
F 204142	Handle Assy-RH Front-LH Rear	21 exc Station28,52,54,172,174
F 204143	Handle Assy-LH Front-RH Rear	21 exc Station,28,52,54,172,174
F 204144	Handle Assy-RH Front-LH Rear	22,24,25,27,52,54,172,174
F 204145	Handle Assy-LH Front-RH Rear	22,24,25,27,52,54,172,174
BO 204146	Spring-Door Handle Return-RH	12,14,15,17,22,24,25,27,52,54,172,174
BO 204147	Spring-Door Handle Return-LH	12,14,15,17,22,24,25,27,52,54,172,174
C 204152	Tray Assy-Rear Seat	20 UCpe-3Cpe
C 204153	Tray Assy-Rear Seat	21-22-24 3Cpe,1946-1947 3Cpe
C 204154	Tray Assy-Rear Seat	20 ClubCpe
C 204155	Tray Assy-Rear Seat	21-22-24-25 ClubCpe,1946-1947 ClubCpe
C 204156	Tray Assy-Rear Seat	20 CvSed
C 204157	Tray Assy-Rear Seat-Prime	21-22-24 CvSed,1946-1947 CvBro
BO 204161	Dial & Bezel Assy-Inst & Speedometer-Miles-LHD	20,21,22,24,28
BO 204162	Dial & Bezel Assy-Inst & Speedometer-Miles-RHD	20,21,22,24,28
BO 204163	Dial & Bezel Assy-Inst & Speedometer-Metric-LHD	20,21,22,24,28
BO 204164	Dial & Bezel Assy-Inst & Speedometer-Metric-RHD	20,21,22,24,28
BO 204165	Dial & Bezel Assy-Inst & Clock-LHD	20,21,22,24,28
BO 204166	Dial & Bezel Assy-Inst & Clock-RHD (Use 205949)	20,21,22,24,28
C 204168	Link Assy-Folding Top Side Header to Hinge-RH	1942 CvSed,1946-1947 CvBro
C 204169	Link Assy-Folding Top Side Header to Hinge-LB	1942 CvSed,1946-1947 CvBro
BZ 204170	Support-Radiator Louver-Outer-RH	1942 All
BZ 204171	Support-Radiator Louver-Outer-LH	1942 All
BZ 204172	Support-Radiator Louver-Inner	1942 All
BO 204173	Spacer-Side Header to Pillar Hinge Link-Front	1942 CvSed,1946-1947 CvBro
BO 204175	Control Assembly-W/Shield Cleaner	1942 All
BO 204177	Brkt-Rear View Mirror	20 thru 28,51 thru 54 exc CvBro,171 thru 174 exc CvBro
BO 204178	Leather Washer-Folding Top	1942 CvSed,1946-1947 CvBro
BO 204179	Pad-Side Header to Pillar Hinge Link	1942 CvSed,1946-1947 CvBro
BO 204180	Spring-Bonnet Support Arm	21 thru 28,1946-1947 All
BO 204181	Spacer-Folding Top	1942 CvSed,1946-1947 CvBro
BO 204182	Bezel Assy-Speedometer,Clock & Instrument	1942-1946-1947 All
BO 204184	Molding-Locker Box Door	22 thru 27,52,54,172,174
BO 204186	Retainer-Locker Box Door Molding	20 thru 27,52,54,172,174
BO 204188	Spacer-Rear Comp Trimboard-Side	1942 CvSed,1946-1947 CvBro
BO 204189	Spacer-Rear Comp Trimboard-Side	1942 CvSed,1946-1947 CvBro
BO 204191	Brkt-F Seat Back Panel Spring Hanger	1942 2Sed-ClubCpe-UCpe-CvSed-Sed,51,52,53,54
C 204196	Pillar Assy-Front-RH	1942 CvSed,1946-1947 CvBro
C 204197	Pillar Assy-Front-LH	1942 CvSed,1946-1947 CvBro
C 204202	Frame Assy-Quarter Window-RH	20P-21 thru 27 5Sed,1946-1947 Sed
C 204203	Frame Assy-Quarter Window-LH	20P-21 thru 27 5Sed,1946-1947 Sed
C 204206	Frame Assy-Quarter Window-RH	21-22-24-25 ClubCpe
C 204207	Frame Assy-Quarter Window-LH	21-22-24-25 ClubCpe
C 204208	Retainer Assy-Quarter Wdo Weatherstrip-RH	20P-21 thru 27 5Sed
C 204209	Retainer Assy-Quarter Wdo Weatherstrip-LH	20P-21 thru 27 5Sed
C 204210	Retainer Assy-Quarter Wdo Weatherstrip-RH	21-22-24-25 ClubCpe
C 204211	Retainer Assy-Quarter Wdo Weatherstrip-LH	21-22-24-25 ClubCpe
BO 204213	Brkt-Quarter Wdo Frame to Fastening Plate	20P-21 thru 27 Sed,21-22-24-25 ClubCpe, 1946-1947 Sed,52-54-172-174 ClubCpe
BO 204215	Brkt-Qtr Wdo to Rear Seat Back Panel-Upper	20P-21 thru 27 Sed,21-22-24-25 ClubCpe, 1946-1947 Sed,52-54-172-174 ClubCpe
BO 204216	Brkt-Qtr Wdo Frame to Rear Seat Back Panel-Lower	20P-21 thru 27 5Sed
BO 204219	Felt-Qtr Wdo Glass Stop	20 thru 27 Sed-ClubCpe,1946-1947 Sed, 52-54-172-174 ClubCpe
BO 204226	Regulator & Glass Rest Channel Assy-Qtr Wdo-RH	20P-21 thru 27 Sed,21 thru 25 ClubCpe
BO 204227	Regulator & Glass Rest Channel Assy-Qtr Wdo-LH	20P-21 thru 27 Sed,21 thru 25 ClubCpe
BO 204228	Panel Assy-Qtr Wdo Regulator-RH	20P-21 thru 27 Sed,21 thru 25 ClubCpe, 1946-1947 Sed,52-54-172-174 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 204229	Panel Assy-Qtr Wdo Regulator-LH	20P-21 thru 27 Sed,21 thru 25 ClubCpe, 1946-1947 Sed,52-54-172-174 ClubCpe
BO 204230	Weatherstrip-Quarter Wdo-Inner-RH	20P-21 thru 27-1946-1947 Sed
BO 204231	Weatherstrip-Quarter Wdo-Inner-LH	20P-21 thru 27-1946-1947 Sed
BO 204232	Weatherstrip-Quarter Wdo-Inner-RH	21 thru 25-52-54-172-174 ClubCpe
BO 204233	Weatherstrip-Quarter Wdo-Inner-LH	21 thru 25-52-54-172-174 ClubCpe
BO 204237	Knob-Quarter Window Regulator	1942 Sed-ClubCpe
BO 204238	Knob-Quarter Window Regulator-Blue	1942-1946-1947 Sed-ClubCpe
BO 204239	Knob-Quarter Window Regulator-Green	1942 Sed-ClubCpe
C 204244	Weatherstrip-F Door Panel Extension	20-21-22-24 Sed,1946-1947 Sed
C 204245	Weatherstrip-F Door Panel Extension	1942 UCo-2Sed-3Cpe-CvSed-UCpe-ClubCpe 27, 51 thru 54 exc Sed,171 thru 174 exc Sed
C 204246	Weatherstrip-Rear Door Panel Extension	1942-1946-1947 Sed
BO 204250	Handle-Door Inside	21 thru 27 exc Station,52,54,172,174
BO 204251	Handle Assy-Regulator-Russet Knob	20,21,28
BO 204252	Handle Assy-Door Window-Regulator-Green Knob	20P,21
BO 204253	Handle Assy-Door Window-Regulator-Blue Knob	20P,21,51,53,58,171,173,178
BO 204254	Handle Assy-Door Window Regulator-Russet Knob	21 thru 27 exc Station
BO 204255	Handle Assy-Door Window Regulator-Green Knob	21 thru 27 exc Station
BO 204256	Handle Assy-Door Window Regulator-Blue Knob	21 thru 27 exc Station,52,54,172,174
BO 204257	Handle Assy-Door Window Regulator-Russet Knob	20-21 CvSed
BO 204258	Handle Assy-Door Wing Regulator-Green Knob	20P-21 CvSed
BO 204259	Handle Assy-Door Wing Regulator-Blue Knob	20P-21 CvSed,51-171 CvBro
BO 204260	Handle Assy-Door Wing Regulator-Russet Knob	22 thru 27,21 CvSed
BO 204261	Handle Assy-Door Wing Regulator-Green Knob	22 thru 27,21 CvSed
BO 204262	Handle Assy-Door Wing Regulator-Blue Knob	22 thru 27,21 CvSed,52,54,172,174
BO 204263	Escutcheon-Inside Handle-Russet	20,21
BO 204264	Escutcheon-Inside Handle-Green	20,21
BO 204265	Escutchen-Inside Handle-Blue	20,21,51,53,58,171,173,178
BO 204266	Escutcheon-Inside Handle-Russet	22 thru 27
BO 204267	Escutcheon-Inside Handle-Green	22 thru 27
BO 204268	Escutcheon-Inside Handle-Blue	22 thru 27,52,54,172,174
BO 204269	Use 209661	
BO 204275	Block Assy-F Door Arm Rest	25,27
BO 204276	Bracket-Door Arm Rest Block to Crossmember	25,27,20-21-22-24 CvSed,1946-1947 CvBro
BO 204277	Block-F Door Arm Rest	20,21,22,24,28,1946-1947 All
BO 204278	Brkt-F Door Arm Rest Block	20,21,22,24,28,1946-1947 All
BO 204281	Pillar Assy-Center (Use 203840 for RH,203841 for LH)	21 thru 27 Sedan
C 204290	Panel & Clip Assy-Rear Seat Back Compt-RH	1942 CvSed,1946 CvBro
C 204291	Panel & Clip Assy-Rear Seat Back Compt-LH	1942 CvSed,1946 CvBro
C 204300	Trim Molding-Front Fender-RH-Upper	22 thru 27,51 thru 54,171 thru 174
C 204301	Trim Molding-Front Fender-LH	20T,20P,21 exc Station
C 204301	Trim Molding-Front Fender-LH-Upper	22 thru 27,51 thru 54,171 thru 174
BO 204302	Trim Molding-Front Fender-RH-Center	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
BO 204303	Trim Molding-Front Fender-LH-Center	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
BO 204304	Trim Molding-Front Fender-RH-Lower	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
BO 204305	Trim Molding-Front Fender-LH-Lower	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
C 204306	Trim Molding-Rear Fender-RH	20T,20P,21 exc Station
C 204306	Trim Molding-Rear Fender-RH-Upper	22 thru 27,51 thru 54,171 thru 174
C 204307	Trim Molding-Rear Fender-LH	20T,21 exc Station20P
C 204307	Trim Molding-Rear Fender-LH-Upper	22 thru 27,51 thru 54,171 thru 174
BO 204308	Trim Molding-Rear Fender-RH-Center	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
BO 204309	Trim Molding-Rear Fender-LB-Center	20T,20P,21 thru 27 exc Station,51 thru 54,171 thru 174
BO 204310	Trim Molding-Rear Fender-RH-Lower	20T,20P,21 thru 27 exc Station
BO 204311	Trim Molding-Rear Fender-I,H-Lower	20T,20P,21 thru 27 exc Station
BO 204312	Ornament-Front Fender-RH	22 thru 27
BO 204313	Ornament-Front Fender-LH	22 thru 27
C 204320	Panel Assy-Underbody	20 2Sed
C 204321	Panel Assy-Underbody	20 UCo
C 204324	Panel Assy-Underbody	1942 7Sed
C 204329	Panel Assy-Underbody	20P CvSed
C 204330	Panel Assy-Underbody	20 ClubCpe
C 204334	Panel Assy-Underbody	21-22-24 2Sed,1946-1947 Bro
C 204335	Panel Assy-Underbody	21-22-24 Sed,1946-1947 Sed
C 204337	Panel Assy-Underbody	21-22-24 3Cpe,1946-1947 3Cpe
C 204339	Panel Assy-Underbody (Use 209723)	21-22-24 CvSed,1946 CvBro
C 204349	Panel Assy-Underbody	20T CvSed
C 204372	Belt Mldg-Rear Door Panel-RH	20,51-53-171-173 Sed
C 204373	Belt Mldg-Rear Door Panel-LH	20,51-53-171-173 Sed
C 204374	Belt Mldg-Rear Door Panel-RH	21 thru 27 Sed,52-54-172-174 Sed
C 204375	Belt Mldg-Rear Door Panel-LH	21 thru 27 Sed,52-54-172-174 Sed
*A 204380 Pr	Splash Apron-Front•Bumper-RH-Prime	1942 All
*A 204381 Pr	Splash Apron-Front Bumper-LH-Prime	1942 All
BZ 204382	Center Plate-F Bumper Splash Apron Molding	1942 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 204383	Bolt-F Bumper Splash Apron	1942 All
C 204384	Mldg-F Bumper Splash Apron-Lower-RH	1942 All
C 204385	Mldg-F Bumper Splash Apron-Lower-LH	1942 All
C 204386	Mldg-F Bumper Splash Apron-Center-RH	1942 All
C 204387	Mldg-F Bumper Splash Apron-Center-LH	1942 All
C 204388	Mldg-F Bumper Splash Apron-Upper-RH	1942 All
C 204389	Mldg-F Bumper Splash Apron-Upper-LH	1942 All
BZ 204393	Bracket & Clamp Assy-F License Plate	20T,20C,28,1946-1947 Cab-CabPu
204396	Center Bar-Windshield-Outer (Use 140969)	1942 CvSed
204397	Center Bar-Windshield-Outer (Use1-140964 & 3-170417)	1942 Exc CvSed,1946 exc CvBro
204398	Knob-Door Lock Release Rod-Second Type (Use 209661)	1942 All
C 204401	Trim Molding-F Door	25 ClubCpe,27
C 204403	Trim Molding-Rear Door-LH	27
BO 204404	Trim Molding-Qtr-Trim Panel-Bottom	25 ClubCpe
BO 204411	Handle Assy-Cowl Vent Operating	1942-1946-1947 All
C 204416	Bow-Roof-#4 & 5	1942 3Cpe-UCpe,20 ClubCpe,1946-1947 3Cpe-51-53-171-173 ClubCpe
C 204420	Louver-Radiator-RH-#5	1942 All
C 204420	Louver-Radiator-RH-#4	22 thru 27
C 204421	Louver-Radiator-LH-#5	1942 All
C 204421	Louver-Radiator-LH-#4	22 thru 27
C 204422	Louver-Radiator-RH-#4	20,21,28
C 204423	Louver-Radiator-LH-#4	20,21,28
C 204424	Louver-Radiator-RH-#3	1942 All
C 204425	Louver-Radiator-LH-#3	1942 All
C 204426	Louver-Radiator-RH-#2	1942 All
C 204427	Louver-Radiator-LH-#2	1942 All
C 204428	Louver-Radiator-RH-#1	1942 All
C 204429	Louver-Radiator-LH-#1	1942 All
BZ 204430	Spacer-Radiator Louver-Rubber	1942 All
BZ 204432	Support-Louver Center Panel-Lower	1942 All
BZ 204433	Support-Louver Center Panel-Upper.	1942 All
BO 204434	Grille-Inst Panel	1942 All
A 204439	Shield & Extension Assy-Rad Lower Tank	20
*A 204440	Shield & Extension Assy-Rad Lower Tank	21,22,28
A 204441	Shield & Extension Assy-Rad Lower Tank	24,25,27
BZ 204445	Brace Assy-Louver Center Panel to Tank Shield, Extension	1942 All
*BZ 204446	Center Panel Lower & Extension Brace Assy-Louver-Prime	1942 All
BO 204450	Ash Receiver Assy-Quarter-Grained	25 ClubCpe,27
BO 204451	Ash Receiver Assy-Quarter-Gray	25 ClubCpe,27
BO 204452	Ash Receiver Assy-Quarter-Green	25 ClubCpe,27
BO 204453	Cover-Qtr Ash Receiver-Grained	25 ClubCpe,27
BO 204454	Cover-Qtr Ash Receiver-Gray	25 ClubCpe,27
BO 204455	Cover-Qtr Ash Receiver-Green	25 ClubCpe,27
BO 204471	Knob-Qtr Ash Receiver-Blue	25 ClubCpe,27
BO 204472	Knob-Qtr Ash Receiver-Green	24 Sed-2Sed-ClubCpe,27
BO 204481	Ground Strap Assy-Radio or Hyd Power Unit	1942-1946-1947 All,1948 thru 1950 CvBro
BO 204485	Foot Switch & Cable Assy-Radio	1942 All
C 204495	Door Assy-Rear Compartment	20-21 Sed-UCo,28P
C 204497	Door Assy-Rear Compartment	22-24-25-27 Sed-2Sed
204500	Ash Receiver Assy-Inst Panel-Grained (Use 208646).	1942 All
204501	Ash Receiver Assy-Inst Panel (Use 208646)	1942 All,58,178
BO 204506	Brkt,Clamp and Bolt Assy-Fog Lamp	1942-1946-1947 All
204510	Lamp Assy-F Fender-6 Volt-RH-Without Indicator (Use 206510)	1942 All
204511	Lamp Assy-F Fender-6 Volt-LH-Without Indicator (Use 206511)	1942 All
204514	Lamp Assy-F Fender-6 Volt-RH-With Indicator (Use 206514)	20 thru 28
204515	Lamp Assy-F Fender-6 Volt-LH-With Indicator (Use 206515)	20 thru 28
BO 204518	Base,Socket & Wires Assy-Fender Lamp-RH	1942-1946-1947 All
BO 204519	Base,Socket & Wires Assy-Fender Lamp-LH	1942-1946-1947 All
204520	Fender Lamp Kit (Use 206530)	20,21,28
BO 204534	Base & Socket Assy-Fender Lamp-RH	1942,-1946-1947 All
BO 204535	Base & Socket Assy-Fender Lamp-LH.	1942-1946-1947 All
BO 204536	Wires Assy-Fender Lamp-RH	1942-1946-1947 All
BO 204537	Wires Assy-Fender Lamp-LH	1942-1946-1947 All
BO 204540	Hinge Assy-Rear Compt Door-RH	1942 Sed-2Sed-UCo-UCpe-CvSed-3Cpe-ClubCpe,51,52,53,54,171 thru 174
BO 204541	Hinge Assy-Rear Compt Door-LH	1942-1946-1947 exc Cab-CabPu,Station

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 204542	Gasket-Rear Compt Door Hinge-Body Half	1942-1946-1947 exc Cab-CabPu,Station
BO 204543	Name Plate-Rear Compt Door	20,21,28
BO 204545	Brkt & Arm Assy-Rear License Plate	20,21,28
BO 204546	Name Plate-Rear Compartment Door-Used With HDM	1942 All
BZ 204550	Stone Protector-Rear Fender-RH	20T,20P,21-24 exc Station,22,25,27,51 thru 54,171 thru 174
BZ 204551	Stone Protector-Rear Fender-LH	20T,20P,21-24 exc Station,22,25,27,51 thru 54,171 thru 174
C 204554	Finish Molding & W/Strip Assy-F Door-RH-Grained	20-21 2Sed,20 UCo-UCpe
C 204555	Finish Mldg & W/Strip Assy-F Door-LH-Grained	20-21 2Sed,20 UCo-UCpe
C 204556	Finish Molding & W/Strip Assy-F Door-RH-Grained	20-21 5Sed
C 204557	Finish Molding & W/Strip Assy-F Door-LH-Grained	20-21 5Sed
C 204558	Finish Molding & W/Strip Assy-Door-RH-Grained	20-21 3Cpe-ClubCpe-UCpe
C 204559	Finish Molding & W/Strip Assy-Door-LH-Grained	20-21 3Cpe-ClubCpe-UCpe
C 204560	Finish Mldg & W/Strip Assy-F Door-RH-Grained	20-21 Sed
C 204561	Finish Molding & W/Strip Assy-F Door-LB-Grained	20-21 Sed
C 204562	Finish Molding & W/ Strip Assy-Qtr Window-RH-Grained	20-21 UCo-2Sed
C 204563	Finish Molding & W/Strip Assy-Qtr Window-LH-Grained	20-21 1UCo-2Sed
BO 204568	Hinge-Rear Door-Body Half-Upper-RH	1942-1946-1947 Sed
BO 204569	Hinge-Rear Door-Body Half-Upper-LH	1942-1946-1947 Sed
BO 204575	Board Assy-F Seat Back Center Arm Rest	27 5Sed
C 204580	Spring-F Seat Cushion	20-21-22-24 Sed-2Sed,27 5Sed Leather Trim, 1946-1947 Sed-3Cpe
C 204581	Spring-Rear Seat Cushion	20-22-24 Sed-2Sed,21-27 5Sed Leather Trim, 1946-1947 Bro-Sed
C 204582	Spring-Rear Seat Back	20 Sed-2Sed-UCo,51-53-171-173 Sed-51-171 Bro
C 204587	Spring-Front Seat Back-LH	27 5Sed
C 204590	Spring-F Seat Back	20-21-22-24-25 5Sed-3Cpe,1946-1947 Sed-3Cpe
C 204592	Spring-F Seat Cushion	20 thru 25 ClubCpe-2Sed-CvSed-UCpe,1946 Bro-ClubCpe,51-171 CvBro
C 204593	Spring-Rear Seat Back	20-21 ClubCpe,1946-1947 ClubCpe
C 204594	Spring-Rear Seat Cushion	1942-1946-1947 ClubCpe
C 204595	Spring-Rear Seat Cushion	1942,51-54-171-174 CvBro
C 204596	Spring-F Seat Back-RH	1942 2Sed-UCpe,1946-1947 Bro
C 204597	Spring-F Seat Back-LH	1942 2Sed-UCpe,1946-1947 Bro
C 204598	Spring-F Seat Back-RH	1942 ClubCpe-CvSed-1946-1947 ClubCpe-CvBro
C 204599	Spring-F Seat Back-LH	1942 ClubCpe-CvSed-1946-1947 ClubCpe-CvBro
C 204601	Spring-Rear Seat Cushion-Special	1942-1946-1947 Taxi & Police Cars
C 204604	Spring-F Seat Cushion-for 2Sed Seat	1942-1946-1947 Taxi & Police Cars
C 204605	Spring-R Seat Cushion-For 2Sed Seat	1942 Taxi and Police Cars
C 204610	Finish Molding & W/Strip Assy-Qtr Window-RH-Grained	20P-21 5Sed
C 204611	Finish Molding & W/Strip Assy-Qtr Window-LH-Grained	20P-21 5Sed
C 204614	Finish Molding & W/Strip Assy-Qtr Window-RH-Chrome	22 thru 27 Sed,52-54-172-174 Sed
C 204615	Finish Molding & W/Strip Assy-Qtr Window-LH-Chrome	22 thru 27 Sed,52-54-172-174 Sed
BO 204618	Lens-Underbody Panel Extension Lamp	21 thru 27,52,54,172,174
C 204690	Finish Mldg-Windshield-Upper-RH	21 thru 27 exc CvSed
C 204691	Finish Mldg-Windshield-Upper-LH	21 thru 27 exc CvSed
C 204697	Finish Mldg-Windshield-Upper-LH	1942 CvSed
C 204700	Finish Mldg-Windshield-Lower	1942 All
BO 204704	Regulator & Rest Channel Assy-Qtr Wdo-RH	20P-21 thru 27 Sed,21 thru 25 ClubCpe, 1946-1947 Sed,52-54-172-174 ClubCpe
BO 204705	Regulator & Rest Channel Assy-Qtr Wdo-LH	20P-21 thru 27 Sed,21 thru 25 ClubCpe, 1946-1947 Sed,52-54-172-174 ClubCpe
C 204706	Retainer Assy-Qtr Wdo Weatherstrip-RH	20P-21 thru 27 Sed,1946-1947 Sed
C 204707	Retainer Assy-Qtr Wdo Weatherstrip-LH	20P-21 thru 27 Sed,1946-1947 Sod
204710	Molding-Safety Step-RH (Use 205342)	20T,20P,20Sp
204711	Molding-Safety Step-LH (Use 204720)	20T,20P,20Sp
204713	Molding-Safety Step-LB (Use 205345)	21 exc Station22,24,25
C 204714	Molding-Safety Step-Painted	27
204715	Molding-Safety Step-Painted (Use 205347)	27
C 204718	Molding-Safety Step-RH-Stainless Steel	27
204719	Molding-Safety Step-LH-Stainless Steel(Use 205347)	27
204720	Molding-Safety Step-RH-Stainless Steel(Use 205342)	20T,20P,20Sp
C 204721	Molding-Safety Step-LH-Stainless Steel	20T,20P,20Sp
BO 204722	Spacer-Qtr Wdo Regulator Panel	20P-21 thru 27 Sed,21 thru 25 ClubCpe, 1946-1947 Sed,54-54-172-174 ClubCpe
C 204723	Trim Molding-F Seat Back Frame-Lower	27 5Sed
C 204724	Trim Molding,-F Seat Riser Panel-RH	27 5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 204725	Trim Molding-F Seat Riser Panel-LH	27 5Sed
C 204726	Trim Molding-F Seat Riser Panel-RH	22-24 5Sed72Sed-3Cpe
BO 204730	Lock Assy-Front Door-RH	1942-1946-1947 All
BO 204731	Lock Assy-Rear Door-LH	1942-1946-1947 All
BO 204733	Lock Assy-Door-Front-LH-Rear-RH	1942-1946 All, 1947 Sed-Cab-CabPu
BO 204735	Lock Assy-Door-Front-LH	171 thru 174
BO 204736	Finish Molding-Rear Window-Inner	22 thru 27,52-54-172-174 exc CvBro
BO 204737	Finish Molding-Rear Window-Outer	22 thru 27,52-54-172-174 exc CvBro
BO 204738	Shim-Rear Wdo Finish Molding	22 thru 27,52-54-172-174 exc CvBro
C 204740	Finish Molding & W/Strip Assy-Qtr Window-RH-Grained	21 ClubCpe
C 204741	Finish Molding & W/Strip Assy-Qtr Window-LH-Grained	21 ClubCpe
C 204744	Finish Molding & W/Strip Assy-Qtr Window-RH-Chrome	22-24-25 ClubCpe,52-54-172-174 ClubCpe
C 204745	Finish Molding & W/Strip Assy-Qtr Window-LH-Chrome	22-24-25 ClubCpe,52-54-172-174 ClubCpe
BO 204756	Bracket Assy-Rear Compt Panel Reinf Hinge-RH	1942 Sed-2Sed-UCpe
BO 204757	Bracket Assy-Rear Compt Panel Reinf Hinge-LH	1942 Sed-2Sed-UCo
BO 204759	Bracket-Rear Compt Door Hinge	1942 Sed-2Sed-UC0
BO 204764	Door Assy-Locker Box-RH-LHD-Gray	20P,21 exc Station
BO 204765	Door Assy-Locker Box-LH-LHD-Gray	20P,21 exc Station
BO 204766	Door Assy-Locker Box-RH-RHD-Gray	20P,21 exc Station
BO 204768	Door Assy-Locker Box-RH-LHD-Green	20P,21 exc Station
BO 204769	Door Assy-Locker Box-LH-LHD-Green	20P,21 exc Station
BO 204770	Door Assy-Locker Box-RH-RHD-Green	20P,21 exc Station
BO 204772	Door Assy-Locker Box-RH-LHD-Grained	20,21
BO 204773	Door Assy-Locker Box-LH-LHD-Grained	20,21
BO 204774	Door Assy-Locker Box-RH-RHD-Grained	20,21
BO 204780	Door Assy-Locker Box-RH-LHD Gray	22,24,25,27
BO 204781	Door Assy-Locker Box-LH-LHD Gray	22,24,25,27
BO 204782	Door Assy-Locker Box-RH-RHD-Gray	22,24,25,27
BO 204784	Door Assy-Locker Box-RH-LHD-Green	22,24,25,27
BO 204785	Door Assy-Locker Box-LH-LHD-Green	22,24,25,27
BO 204786	Door Assy-Locker Box-RH-RHD-Green	22,24,25,27
BO 204788	Door Assy-Locker Box-RH-LHD-Grained	22,24,25,27
BO 204789	Door Assy-Locker Box-LH-LHD-Grained	22,24,25,27
BO 204790	Door Assy-Locker Box-RH-RHD-Grained	22,24,25,27
C 204793	Retainer Assy-Qtr Wdo Weatherstrip-LB	21 thru 25-52-54-172-174 ClubCpe
C 204794	Frame Assy-Qtr Window-RH	21 thru 25-52-54-172-174 ClubCpe
C 204795	Frame Assy-Qtr Window-LH	21 thru 25-52-54-172-174 ClubCpe
F 204811	Indicator Assy-Oil & Generator	1942 All
BO 204812	Clock Assy-Mechanical	20,21,28
BO 204813	Clock Assy-Electric	22 thru 27
BO 204815	Knob-Locker Box Door Clock	20 thru 28,51,53,58,171,173,178,481,483, 491,493
204820	Ash Receiver Assy-Quarter-Grained (Use 209556)	20P-20Sp-21-22-24-25 Sed-2Sed-ClubCpe,27
204821	Ash Receiver Assy-Quarter-Gray (Use 209556)	20P-21-22-24 Sed-2Sed-ClubCpe,25,27
204822	Ash Receiver Assy-Quarter-Green (Use 209556)	20P-21-22-24 Sed-2Sed-ClubCpe,25,27
204823	Cover-Qtr Ash Receiver-Grained (Use 209557)	20P-21-22-24 Sed-2Sed-ClubCpe,25,27
BO 204824	Cover-Qtr Ash Receiver-Gray	20P-21-22-24 Sed-2Sed-ClubCpe,25,27
BO 204825	Cover-Qtr Ash Receiver-Green	20P-21-22-24 Sed-2Sed-ClubCpe,25,27
BO 204831	Knob-Qtr Ash Receiver-Blue	20P-21-22-24 Sed-2Sed-ClubCpe,25,27,1946-1947 Sedan-ClubCpe
204832	Knob-Qtr Ash Receiver-Green (Use 204831)	20P-21-22-24 Sed-2Sed-ClubCpe,25,27
204837	Spring-Rear Seat Cushion-Cloth (Use 204601)	21 2Sed-5Sed
C 204838	Spring-Rear Seat Cushion-Cloth	21 ClubCpe
BO 204846	Push Button-Starter Switch	1942-1946-1947 All
BO 204847	Push Button-Lighting Switch	1942-1946-1947 All
BZ 204855	Welt-Front Fender-Lower	1942 exc 20C-28C Station,5I thru 54,171 thru 174
C 204857	Welt-Rear Fender-Upper	20T,20P,21 exc Station,22,24,25,27,51,53,171,173
C 204858	Welt-Rear Fender-Upper	22,24,25,27,21 Station,52,54,172,174
C 204863	Trim Molding-F Seat Riser Panel-LH	22-24-25 ClubCpe-CvSed
204866	Packing-Hyd Top Cylinder Piston (Use 206544)	1941-1942 CvSed,1946-1947 CvBro
BO 204867	Support-Hyd Top Cylinder Piston Packing	1942-1942 CvSed,1946-1947 CvBro
BO 204868	Spacer-Hyd Top Cylinder Piston Packing Support	1941-1942 CvSed,1946-1947 CvBro
204869	Use 170230	
BO 204870	Ornament-Hood Top-Lower	20,21,28
BO 204871	Ornament-Hood Top-Lower-Export	20,21,28
BO 204872	Ornament-Hood Top-Upper	20,21,28
BO 204873	Molding-Rad Louver Center Panel-Upper	20,21,28
BO 204874	Ornament-Rad Louver Center Panel-Upper	22 thru 27
BO 204875	Ornament-Rad Louver Center Panel-Upper-Export	22 thru 27
BO 204876	Ornament-Hood Top Lower	22 thru 27
BO 204877	Ornament-Hood Top-Upper	20,21,28

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

291

Part No.	Name	Models
BO 204880	Name Plate-Instrument Panel	20,28
BO 204881	Name Plate-Instrument Panel	21
BO 204882	Name Plate-Instrument Panel	22
BO 204883	Name Plate-Instrument Panel	24,25,27
BO 204884	Lens-Inst Panel Name Plate	1942 All
BO 204885	Molding Assy-Inst Panel Center-Without VD or HDM	1942-1946-1947 All
BO 204886	Molding Assy-Inst Panel Center-With VD	1942-1946-1947 All
BO 204887	Molding Assy-Inst Panel Center-With HDM	1942-1946-1947 All
BO 204888	Cover Assy-Inst Panel Radio Dial Hole	1942 All
BO 204889	Cover Assy-Inst Panel Radio Dial Hole	1942 All
BO 204890	Choke Coil-Radio Main Hash	1942 All,1948 thru 1950
BO 204891	Coil-Radio Oscillator Series	1942 All
BO 204892	Transformer-Radio 1st IF	1942 All
BO 204893	Transformer-Radio 2nd IF	1942 All
BO 204894	Choke Coil Assy-Radio Motor Noise	1942 All
BO 204895	Coil & Core Assy-Radio Untuned-RF	1942 All
BO 204897	Coil & Shield Assy-Radio Oscillator	1942 All
BO 204898	Coil & Shield Assy-Radio Frequency	1942 All
BO 204899	Coil Assy-Oscillator Shunt	1942 All
BO 204900	Condenser-600 V-0001 Mfd	1942 thru 1947 All,1950
BO 204901	Condenser-400 V-1 Mfd	1942 thru 1950 All
BO 204902	Condenser-600 V-00025 Mfd	1942 thru 1950 All
BO 204903	Condenser-200 V-1 Mfd	1942 All
BO 204904	Condenser-200 V-05 Mfd	1942 thru 1950 All
BO 204905	Condenser-600 V-005 Mfd	1942 thru 1949 All
BO 204906	Condenser-200 V-005 Mfd	1942 thru 1949 All
BO 204907	Condenser-120 V-5 Mfd	1942 thru 1947 All
BO 204908	Condenser-200 V-007 Mfd	1942 All
BO 204909	Condenser-Radio Dual Spark Plate	1942 thru 1947 All
BO 204910	Condenser-600 V-01 Mfd	1942 thru 1949 All
BO 204911	Condenser-Radio Dry Electrolytic	1942 All
BO 204912	Ceramic Trimmer-Radio Single Section	1942 All
BO 204913	Ceramic Trimmer-Radio Single Section	1942 All
BO 204914	Condenser-120 V-5 Mfd	1942 All
BO 204915	Condenser-600 V-004 Mfd	1942 thru 1949 All
BO 204916	Condenser-1600 V-008 Mfd	1942 All
BO 204917	Compensator-350 MMfd	1942 All
BO 204918	Condenser-Antenna Trimmer	1942 All
BO 204919	Resistor-1/4 Watt-220 Ohm	1942 All
BO 204920	Resistor-1/4 Watt-1 Megohm	1942 All
BO 204921	Resistor-1/4 Watt-100 Ohm	1942 All
BO 204922	Resistor-1/4 Watt 68000 Ohm	1942 All
BO 204923	Resistor-1/4 Watt-330000 Ohm	1942 All
BO 204924	Resistor-1/2 Watt-15000 Ohm	1942 All
BO 204925	Resistor-1/4 Watt-27000 Ohm	1942 All
BO 204926	Resistor-1/4 Watt-33000 Ohm	1942 All
BO 204927	Resistor-1/4 Watt-22000 Ohm-Insulated	1942 All
BO 204928	Resistor-1 Watt-390 Ohm-Wire Wound	1942 All
BO 204929	Resistor-1 Watt-33000 Ohm-Insulated	1942 All
BO 204930	Resistor-2 Watt-1800 Ohm-Wire Wound	1942 All
BO 204931	Resistor-1/4 Watt-15 Megohm	1942 All
BO 204932	Resistor-1/2 Watt-82 Megohm	1942 All
BO 204933	Tone Control, Vol Control & Switch-Radio	1942 All
BO 204934	Housing-Antenna Connector	1942 All
BO 204935	"A" Lead-Radio to Fuse Holder	1942 thru 1947 All
BO 204937	Cable & Plug-Radio Speaker	1942 All
BO 204938	Socket-Radio Vibrator	1942 All
BO 204939	Socket-Radio Foot Control Switch	1942 All
BO 204940	Socket-Radio Tube-8 Contact	1942 All
BO 204941	Socket-Radio Tube-6 Contact	1942 All
BO 204942	Socket-Radio Tube-5 Contact	1942 All
BO 204943	Socket-Antenna Connector	1942 All
BO 204944	Transformer-Radio Power	1942 All
BO 204945	Transformer-Radio Output	1942 All
BO 204946	Shield-Radio Tube	1942 All
BO 204947	Vibrator Assy-Radio	1942 All
BO 204949	Cone & Voice Coil Assy-Radio Speaker	1942 All
204951	Bar-Front Bumper (Use 206704)	21 thru 27
204952	Frame Bar Assy-Front Bumper-RH (Use 206952)	21 thru 27
204953	Frame Bar Assy-Front Bumper-LH (Use 206953)	21 thru 27
C 204956	Frame Bar Assy-Front Bumper-RH	20,28,1946-1947 Cab-CabPu
C 204957	Frame Bar Assy-Front Bumper-LH	20,28,1946-1947 Cab-CabPu
C 204958	Bar-Front Bumper	20P
C 204959	Bar-Front Bumper	20T,28,20C,1946-1947 Cab-CabPu

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*HA 204960	Fender Guard Kit-Front Bumper	20C,20T,20Sp,28,1946-1947 Cab-CabPu
BZ 204963	Spacer-Bumper Guard	20P
BZ 204964	Bolt-Bumper Guard	20P
BZ 204966	Bracket & Clamp Assy-F License Plate	21 thru 27,1946 thru 1950
BZ 204968	Bracket & Clamp Assy-F License Plate	20P
BZ 204969	Bolt-F License Plate Clamp Bracket	20P,21 thru 27,1946-1947 All
BZ 204972	Guard Assy-F License Plate-Upright-RH	20P
BZ 204973	Guard Assy-F License Plate-Upright-LH	20P
BZ 204974	Guard-Rear Bumper-RH-Without Cross Bar	20P,21 exc Station
204975	Guard-Rear Bumper-LH-Without Cross Bar(Use 204977)	20P,21 exc Station
BZ 204976	Guard Assy Rear Bumper-RH	20P
BZ 204977	Guard Assy-Rear Bumper-LH	20P
BZ 204978	Cross Bar-F License Plate Guard-Upper	20P
C 204979	Cross Bar-F License Plate Guard-Lower	20P
204980	Cross Bar-F License Plate Guard-Lower (Use 206980)	21,22,24
C 204981	Cross Bar-F License Plate Guard-Lower	25,27
C 204986	Cross Bar-Rear Bumper Fender Guard	21 thru 27 exc Station
204992	Guard-Front License Plate-Upright-RH (Use 208817)	21 thru 27
204993	Guard-Front License Plate-Upright-LH (Use 208818)	21 thru 27
204994	Guard Assy-Rear Bumper-RH (Use 208819)	21 exc Station,22,24
204995	Guard Assy-Rear Bumper-LH (Use 208820)	21 exc Station,22,24
BZ 204996	Guard Assy-Rear Bumper-RH-Optional	21 exc Station,22,24
BZ 204997	Guard Assy-Rear Bumper-LH-Optional	21 exc Station,22,24
C 205063	Side Board-Pickup Box-LH	20 UCpe
C 205070	Floor Board-Pickup Box	20 UCpe
C 205072	Angle Assy-Floor Board to Side Board-RH	20 UCpe
BO 205098	Spring-Rear Compt Door Handle	1942-1942 All,51,52,53,54,171 thru 174,481,483, 491,493,500,501,503
C 205100	Panel Assy-Quarter-RH-Without Molding Holes	20 UCo-2Sed
C 205101	Panel Assy-Quarter-LH-Without Molding Holes	20 UCo-2Sed
205112	Panel Assy-Quarter-RH-Without Molding Holes (Use 208883)	21 2Sed
C 205113	Panel Assy-Quarter-LH-Without Molding Holes	21 2Sed
C 205122	Panel Assy-Quarter-RH	22-24 2Sed
C 205123	Panel Assy-Quarter-LH	22-24 2Sed
C 205130	Panel Assy-Quarter-RLI-Without Molding Holes	20-21 5Sed
C 205131	Panel Assy-Quarter-LH-Without Molding Holes	20-21 5Sed
C 205132	Panel Assy-Quarter-RH-With Molding Holes	20-21 5Sed
C 205133	Panel Assy-Quarter-LH-With Molding Holes	20-21 5Sed
C 205151	Panel Assy-Quarter-LH	22 thru 27 5Sed
C 205160	Panel Assy-Quarter-RH-Without Molding Holes	20 3Cpe-UCpe,51-53-171-173 3Cpe
C 205161	Panel Assy-Quarter-LH-Without Molding Holes	20 3Cpe-UCpe,51-53-171-173 3Cpe
C 205162	Panel Assy-Quarter-RH-With Molding Holes	20 3Cpe-IJCpe,51-53-171-173 3Cpe
C 205163	Panel Assy-Quarter-LH-With Molding Holes	20 3Cpe-IJCpe,51-53-171-173 3Cpe
C 205168	Panel Assy-Quarter-RH-Without Molding Holes	20 ClubCpe,51-53-171-173 ClubCpe
C 205169	Panel Assy-Quarter-LH-Without Molding Holes	20 ClubCpe,51-53-171-173 ClubCpe
C 205170	Panel Assy-Quarter-RH-With Molding Holes	20 ClubCpe,51-53-171-173 ClubCpe
C 205171	Panel Assy-Quarter-LH-With Molding Holes	20 ClubCpe,51-53-171-173 ClubCpe
C 205180	Panel Assy-Quarter-RH-Without Molding Holes	21 3Cpe
C 205183	Panel Assy-Quarter-LH-With Molding Holes	21 3Cpe
C 205188	Panel Assy-Quarter-RH-Without Molding Holes	21 ClubCpe
C 205189	Panel Assy-Quarter-LH-Without Molding Holes	21 ClubCpe
C 205190	Panel Assy-Quarter-RH-With Molding Holes	21 ClubCpe
C 205191	Panel Assy-Quarter-LH-With Molding Holes	21 ClubCpe
C 205200	Panel Assy-Quarter-RH	22-24-52-54-172-174 3Cpe
C 205201	Panel Assy-Quarter-LH	22-24-52-54-172-174 3Cpe
C 205204	Panel Assy-Quarter-RH	22-24-25-62-54-172-174 ClubCpe
C 205205	Panel Assy-Quarter-LH	22-24-25-52-54-172-174 ClubCpe
*C 205210	Panel Assy-Quarter-RH	20 CvSed,51-171 CvBro
*C 205211	Panel Assy-Quarter-LH	20 CvSed,51-171 CvBro
C 205214	Panel Assy-Quarter-RH	21 CvSed,54-174 CvBro
C 205215	Panel Assy-Quarter-LH	21-22-24 CvSed,54-174' CvBro
BO 205230	Belt Molding-F End Panel Auxiliary-RH	22 thru 27,52,54,172,174
BO 205231	Belt Molding-F End Panel Auxiliary-LH	22 thru 27,52,54,172,174
C 205232	Molding-F Door Panel Auxiliary Belt-RH	22-24-25 ClubCpe-3Cpe-2Sed,52-54-172-174 exc Sed
C 205233	Molding-F Door Panel Auxiliary Belt-LH	22-24-25 ClubCpe-3Cpe-2Sed,52-54-172-174 exc Sed
C 205234	Molding-F Door Panel Auxiliary Belt-RH	22-24 Sed,52-54-172-174 Sed
C 205235	Molding-F Door Panel Auxiliary Belt-LH	22-24 Sed,52-54-172-174 Sed
C 205236	Molding-Rear Door Auxiliary Belt	22 thru 27 Sed,52-54-172-174 Sed
C 205238	Belt Mldg-Qtr Panel Auxiliary-RH	22-24 2Sed,52-54-172-174 Bro
C 205239	Belt Mldg-Qtr Panel Auxiliary-LH	22-24 2Sed,52-54-172-174 Bro
C 205240	Belt Mldg-Qtr Panel Auxiliary-RH	22 thru 27-52-54-172-174 Sed
C 205241	Belt Mldg-Qtr Panel Auxiliary-LH	22 thru 27-52-54-172-174 Sed
C 205242	Belt Mldg-Qtr Panel Auxiliary-RH	22-24-25-52-54-172-174 3Cpe-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

293

Part No.	Name	Models
C 205243	Belt Mldg-Qtr Panel Auxiliary-LH	22-24-25-52-54-172-174 ClubCpe
BO 205244	Molding-Qtr Panel Auxiliary Belt-RH	22-24 CvSed,54-174 CvBro
BO 205245	Molding-Qtr Panel Auxiliary Belt-LH	22-24 CvSed,54-174 CvBro
BO 205247	Joint Cover-Qtr Panel Auxiliary Belt Molding	22 thru 27,52,54,172,174
BO 205248	Retainer-Molding	1942-1946-1947 Bro,3Cpe,ClubCpe,CvBro
BO 205249	Retainer-Molding	21 thru 27 exc Station,51 thra 54,171 thru 174
C 205250	Molding-F Door Panel Extension Joint	1942 2Sed-3Cpe-ClubCpe-CvSed-UCo-UCpe, 1946-1947 exc Sed-Cab-CabPu
C 205251	Molding-F Door Panel Extension Joint	20-21-22-24 5Sed,1946-1947 Sed
C 205252	Molding-Rear Door Panel Extension Joint	1942-1946-1947 Sect
BO 205253	Molding-Qtr Panel Extension Joint	1942 2Sed-3Cpe-ClubCpe-CvSed-UCo-UCpe,1946-1947 Bro-3Cpe-ClubCpe-CvBro
BO 205254	Molding-Cowl Panel Extension Joint-RH	21 thru 27 exc Station,51 thru 54,171 thru 174
BO 205255	Molding-Cowl Panel Extension Joint-LH	21 thru 27 exc Station,51 thru 54,171 thru 174
BO 205256	Filler-Cowl Panel Extension Molding-RH	20T,20P,20Sp
BO 205256	Filler-Quarter Panel Extension Molding-RH	20 time 27
BO 205257	Filler-Cowl Panel Extension Molding-LH	20T,20P,20Sp
BO 205257	Filler-Quarter Panel Extension Molding-LH	20 thru 27 Sedan
*HS 205259	Cloth-Cleaning & Polishing	
205260	Trim Retainer Assy-Rear Pillar-RH (Use 205262)	1942 2Sed-UCo,1946 Bro
C 205262	Trim Retainer Assy-Rear Pillar-RH	1942 ClubCpe-3Cpe-UCpe,1946-1947 3Cpe-ClubCpe- Bro
*HS 205264	Cleaner-Liquid Glaze-Pint	
*HS 205265	Cleaner-Liquid Glaze-Gal	
*HS 205266	Sealer-Liquid Glaze-Pint	
*HS 205267	Sealer-Liquid Glaze-Gal	
*HS 205268	Sealer-Liquid Glaze-8 oz	
*HS 205269	Cleaner-Liquid Glaze-8 oz	
BO 205270	Remote Control Assy-F Door Lock-RH	1942 2Sed-3Cpe-ClubCpe-UCo-UCpe,27,1946-1947 Bro-3Cpe-ClubCpe
BO 205271	Remote Control Assy-F Door Lock-LH	1942 2Sed-3Cpe-ClubCpe-UCo-UCpe,27,1946-1947 Bro-3Cpe-ClubCpe
BO 205272	Remote Control Assy-F Door Lock-RH	20 thru 24 Sed-Cab-CabPu,28C,1946-1947 Sed
BO 205273	Remote Control Assy-F Door Lock-LH	20 thru 24 Sed-Cab-CabPu,28C,1946-1947 Sed
BO 205274	Remote Control Assy-Door Lock-RH	1942 CvSed,1946-1947 CvBro
BO 205275	Remote Control Assy-Door Lock-LH	1942 CvSed,1946-1947 CvBro
BO 205276	Remote Control Assy-Rear Door Lock-RH	1942 CvSed,1946-1947 CvBro
BO 205277	Remote Control Assy-Rear Door Lock-LH	1942-1946-1947 Sed
BO 205280	Condenser-Radio Ignition	1942 All
BO 205281	Suppressor-Radio Distributor	1942 thru 1949 All
BO 205282	Spring-Radio Bonnet Bonding	1942-1946 All
BO 205283	Nut-Radio Mounting	1942-1946-1947 All
BO 205286	Screw-Radio Case-6 x 3/16" Hex Hd	1942 All
BO 205287	Screw-Radio-8-32 x 1/2" Hex Rd	1942-1946 All
BO 205288	Screw-Radio-10-32 x 5/16" Hex Rd	1942-1946-1947 All
BO 205289	Wing Nut-Radio	1942-1946-1947 All
BO 205290	Knob Kit-Radio Tuning	1942 All
BO 205291	Trim & Switch Knob Assy-Radio	1942 All
BO 205292	Knob-Volume Control	1942 All
BO 205293	Knob-Tone Control	1942 All
BO 205294	Dummy Knob-Radio	1942 All
BO 205296	Installation Kit-Radio	1942 All
BO 205297	Set Screw-Radio Control Tuning Knob	1942 All
BO 205300	Retainer-Outside Molding	22 thru 27,52,54,172,174
BO 205301	Retainer-Qtr Panel Molding	22 thru 27,52,54,172,174
BO 205306	Housing-Hood Side Lamp	20
BO 205308	Lens-Hood Side Lamp-RH	20
BO 205309	Lens-Hood Side Lamp-LH	20
C 205310	Molding-Hood Belt-RH	20
C 205311	Molding-Hood Belt-LH	20
BO 205314	Ornament-Hood Side-RH	20,21,28
BO 205315	Ornament-Hood Side-LH	20,21,28
BO 205316	Ornament-Hood Side-Lamp-RH	21 thru 28,52,54,172,174
BO 205317	Ornament-Hood Side Lamp-LH	21 thru 28,52,54,172,174
BO 205318	Housing-Hood Side Lamp	21 thru 28
BO 205320	Lens-Hood Side Lamp	21 thru 28,52,54,172,174
C 205322	Molding-Hood Belt-RH	21 thru 28,52,54,172,174
C 205323	Molding-Hood Belt-LH	21 thru 28,52,54,172,174
C 205324	Molding-Hood Auxiliary Belt-RH	22 thru 27
C 205325	Molding-Hood Auxiliary Belt-LH	22 thru 27
BO 205326	Molding-Hood Side-RH	21 thru 28
BO 205327	Molding-Hood Side-LIT	21 thru 28
BO 205328	Name Plate-Hood Side Hudson	21 thru 28
BO 205331	Gasket-Hood Side Lamp Lens	20

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 205332	Gasket-Hood Side Lamp Lens	21 thru 28,52,54,172,174
BO 205334	Handle Assy-Door and Qtr Wdo Regulator-Russet	20,21,28
BO 205335	Handle Assy-Door and Qtr Wdo Regulator-Green	20P,21
BO 205336	Handle Assy-Door and Qtr Wdo Regulator-Blue	20P,21
C 205342	Molding-Safety Step-RH-Stainless Steel	20T,20P,20Sp
C 205343	Molding-Safety Step-LH-Stainless Steel	20T,20P,20Sp
C 205344	Molding-Safety Step-RH-Stainless Steel	21,22,24,25,51 thru 54,171 thru 174
C 205345	Molding-Safety Step-LH-Stainless Steel	21,22,24,25,51 thru 54,171 thru 174
C 205346	Molding-Safety Step-RH-Stainless Steel	27
C 205347	Molding-Safety Step-LH-Stainless Steel	27
C 205348 Pr	Molding-Safety Step-RH-Prime	28P
C 205349 Pr	Molding-Safety Step-LH-Prime	28P
A 205402	Panel Assy-Instrument-LHD-Painted	21 thru 27 exc Station
A 205403	Panel Assy-Instrument-RHD-Painted	21 thru 27 exc Station
A 205404	Panel Assy-Instrument-LHD-Grained	20T,20P,28,20C,21 Station
A 205405	Panel Assy-Instrument-RHD-Grained	20T,20P,28,20C,21 Station
BO 205426	Rim and Glass Assy-Domelamp	20T,20P-21 thru 27 exc Cv,51 thru 54 exc CvBro, 171 thru 174 exc CvBro
BO 205427	Reflector Assy-Domelamp	20T-20P-21 thru 27 exc Cv,51 thru 54 exc CvBro, 171 thru 174 exc CvBro
BO 205453	Lead In and Loom Assy-Radio Antenna	1942 All
C 205477	Front End Assy-RHD-Painted Panel	22-24-25 Sed-2Sed-3Cpe-ClubCpe,27
C 205492	Front End Assy-LHD-Painted Panel	21 CvSed
C 205493	Front End Assy-RHD-Painted Panel	21 CvSed
C 205512	Front End Assy-LHD-Grained Panel	20 Cab-CabPu
C 205513	Front End Assy-RHD-Grained Panel	20 Cab-CabPu
C 205521	Front End Assy-RHD-Grained Panel	20P Sed-2Sed-3Cpe-ClubCpe
C 205524	Front End Assy-LHD-Grained Panel	21 Sed-2Sed-3Cpe-ClubCpe
C 205530	Front End Assy-LHD-Grained Panel	22 thru 27 exc CvSed
C 205534	Front End Assy-LHD-Grained Panel	28C
C 205546	Front End Assy-LHD-Grained Panel	21 CvSed
C 205548	Front End Assy-LHD-Grained Panel	22-24 CvSed
C 205549	Front End Assy-RHD-Grained Panel	22-24 CvSed
BO 205600	Lamp Assy-Tail-RH-6 Volt	20 Sed-2Sed-UCo,51-53-171-173 Bro-Sed
BO 205601	Lamp Assy- Tail-LH-6 Volt	20 Sed-2Sed-UCo,51-53-171-173 Bro-Sed
BO 205604	Lamp Assy-Tail-RH-6 Volt	20 CvSed-3Cpe-ClubCpe-UCpe,21 ClubCpe-3Cpe, 51-53-171-173 3Cpe-ClubCpe-CvBro
BO 205605	Lamp Assy-Tail-LH-6 Volt	20 CvSed-3Cpe-ClubCpe-UCpe,21 ClubCpe-3Cpe, 51-53-171-173 3Cpe-ClubCpe-CvBro
BO 205610	Lamp Assy-Tail-RH-6 Volt	22 thru 27 Sed-2Sed-52-54-172-174 Bro-Sed
BO 205611	Lamp Assy-Tail-LH-6 Volt	22 thru 27 Sed-2Sed-52-54-172-174 Bro-Sed
BO 205614	Lamp Assy-Tail-RH-6 Volt	22-24-25 ClubCpe-3Cpe-CvSed,52-54-172-174 ClubCpe-3Cpe-CvBro
BO 205615	Lamp Assy-Tail-LH-6 Volt	22-24-25 ClubCpe-3Cpe-CvSed,52-54-172-174 ClubCpe-3Cpe-CvBro
BO 205620	Lens-Tail Lamp-RH	20-21 Sed-2Sed,51,53,171,173
BO 205621	Lens-Tail Lamp-LH	20-21 Sed-2Sed,51,53,171,173
BO 205622	Housing-Tail Lamp Lens-RH	20-21 Sed-2Sed,51,53,171,173
BO 205623	Housing-Tail Lamp Lens-LH	20-21 Sed-2Sed,51,53,171,173
BO 205624	Base Assy-Tail Lamp-Outer-RH	20-21 Sed-2Sed,51,53,171,173
BO 205625	Base Assy-Tail Lamp-Outer-LH	20-21 Sed-2Sed,51,53,171,173
BO 205626	Base Assy-Tail Lamp-Inner-RH	20-21 Sed-2Sed,51,53,171,173
BO 205627	Base Assy-Tail Lamp-Inner-LH	20-21 Sed-2Sed,51,53,171,173
205628	Gasket-Tail Lamp Lens-RH (Use 205629)	20-21 Sed-2Sed,51,53,171,173
BO 205629	Gasket-Tail Lamp Lens	20-21 Sed-2Sed,51,53,171,173
205630	Pad-Tail Lamp Housing (Use 205642)	20-21 Sed-2Sed,51-53-171-173 CvBro-BroSed
205631	Pad-Tail Lamp Housing (Use 205643)	22-24-27 Sed-2Sed,52-54-172-174 Bro-Sed
BO 205632	Lens-Tail Lamp-RH	22-24-27 Sed-2Sed,52,54,172,174
BO 205633	Lens-Tail Lamp-LH	22-24-27 Sed-2Sed,52,54,172,174
BO 205634	Housing-Tail Lamp Lens-RH'	22-24-27 Sed-2Sed,52,54,172,174
BO 205635	Housing-Tail Lamp Lens-LH	22-24-27 Sed-2Sed,52,54,172,174
BO 205636	Base Assy-Tail Lamp-Upper-RH	22-24-27 Sed-2Sed,52,54,172,174
BO 205637	Base Assy- Tail Lamp-Upper-LH	22-24-27 Sed-2Sed,52,54,172,174
BO 205638	Base Assy-Tail Lamp-Lower-RH	22-24-27 Sed-2Sed,52,54,172,174
BO 205639	Base Assy-Tail Lamp-Lower-LH	22-24-27 Sed-2Sed,52,54,172,174
BO 205640	Gasket-Tail Lamp Lens-RH	22-24-27 Sed-2Sed,52,54,172,174
BO 205641	Gasket-Tail Lamp Lens-LH	22-24-27 Sed-2Sed,52,54,172,174
BO 205642	Pad-Tail Lamp Housing	20T-20P-21 3Cpe-ClubCpe-UCpe-CvSed,51-53- 171-173-3Cpe-ClubCpe-CvBro
BO 205643	Pad-Tail Lamp Housing	22-24 3Cpe-ClubCpe-CvSed,25,52-54-172-174 3Cpe-ClubCpe-CvBro
C 205670	W/Strip Retainer & Glass Assy-RH-F Door Wing	20-21 exc CvSed,28
205671	W/Strip Retainer & Glass Assy-LH-F Door Wing (Use 141903)	20-21 exc CvSed,28

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

295

Part No.	Name	Models
C 205674	W/Strip Retainer & Glass Assy-RH-F Door Wing	22-24 exc CvSed,25,27
C 205675	W/Strip Retainer & Glass Assy-LH-F Door Wing	22-24 exc CvSed,25,27
BO 205684 Pr	Molding-Cowl Panel Ext Joint-RH	21 thru 27
BO 205685 Pr	Molding-Cowl Panel Ext Joint-LH	21 thru 27
BO 205686 Pr	Molding-Cowl Panel Ext Joint-RH	20
BO 205687 Pr	Molding-Cowl Panel Ext Joint-LH	20
BO 205688 Pr	Molding-F End Panel Belt-RH	20
BO 205689 Pr	Molding-F End Panel Belt-LH	20
205690	Molding-F End Panel Belt-RH-(Use 148202)	21 thru 28
205691	Molding-F End Panel Belt-LH-(Use 148203)	21 thru 28
BO 205692 Pr	Ornament-Cowl Vent Cover	1942 All
BO 205693 Pr	Center Bar-W/Shield Outer	1942 All
C 205694 Pr	Belt Molding-Qtr Panel-RH	20 UCo-2Sed
C 205695 Pr	Belt Molding-Qtr Panel-LH	20 UCo-2Sed
205696	Belt Molding-Qtr Panel-RH-(Use 148206)	20 5Sed
C 205697 Pr	Belt Molding-Qtr Panel-LH	20 5Sed
C 205698 Pr	Belt Molding-Qtr Panel-RH	21-22-24 2Sed
C 205699 Pr	Belt Molding-Qtr Panel-LH	21-22-24 2Sed
205700	Belt Molding-Qtr Panel-RH-(Use 148212)	21 thru 27 Sed
C 205701 Pr	Belt Molding-Qtr Panel-LH	21 thru 27 Sed
C 205702 Pr	Belt Molding-Qtr Panel-RH	20 ClubCpe-3Cpe-1JCpe
205703	Belt Molding-Qtr Panel-LH-(Use 148209)	20 ClubCpe-3Cpe-UCpe
205704	Belt Molding-Qtr Panel-RH-(Use 148214)	21 thru 25 ClubCpe-UCpe
205705	Belt Molding-Qtr Panel-LH-(Use 148215)	21 thru 25 ClubCpe-UCpe
BO 205710 Pr	Molding-Qtr Panel Extension Joint	1942 ClubCpe-2Sed-CvSed
205711	Housing-License Lamp (Use 205813)	1942 All
205712	Name Plate-Rear Compartment Door (Use 204543)	20,21,28
BO 205713	Name Plate-Rear Compartment Door	22
205714	Name Plate-Rear Compartment Door (Use 147542)	24,25,27
205715	Name Plate-Rear Compartment Door Drive Indicator (Use 204546)	1942 With HDM
C 205716 Pr	Finish Mldg-W/Shield Reveal-RH	20P-21 thru 27 exc Cv
C 205717 Pr	Finish Mldg-W/Shield Reveal-LH	20P-21 thru 27 exc Cv
C 205718 Pr	Finish Mldg-Rear Window Reveal-RH	20P-21 thru 27 exc Cv
205719	Finish Mldg-Rear Window Reveal-LH (Use 148621)	20P-21 thru 27 exc Cv
205720	Finish Mldg-Rear Window-Outer-(Use 204737)	22 thru 27
BO 205721 Lac	Finish Mldg-Rear Window-Inner	22 thru 27
BO 205721 Pr	Finish Mldg-Rear Window-Inner	22 thru 27
BO 205722 Pr	Cover-Rear Wdo Reveal Mldg Joint	22 thru 27
205723	Lamp Assy-License (Use 211087)	1942 All
205724	Belt Mldg-F Door Panel-RH-(Use 148224)	20T-20P exc Sed
C 205725 Pr	Belt Mldg-F Door Panel-LH	20T-20P exc Sed
C 205726 Pr	Belt Mldg-F Door Panel-RH	20T-20P Sed 20Cab-CabPu
C 205727 Pr	Belt Mldg-F Door Panel-LH	20T-20P Sed 20Cab-CabPu
205728	Belt Mldg-F Door Panel-RH (Use 204372)	20 5Sed
205729	Belt Mldg-Rr Door Panel-LH (Use 204373)	20 5Sed
C 205730 Pr	Belt Mldg-F Door Panel-RH	21-22-24 exc Sed,25,27
C 205731 Pr	Belt Mldg-F Door Panel-LH	21-22-24 exc Sed,25,27
C 205732 Pr	Belt Mldg-F Door Panel-RH	21-22-24 Sed 28C
C 205733 Pr	Belt Mldg-F Door Panel-LH	21-22-24 Sed 28C
205734	Belt Mldg-Rr Door Panel-RH (Use 204374)	21 thru 27 Sed
205735	Belt Mldg-Rr Door Panel-LH (Use 204375)	21 thru 27 Sed
C 205736 Pr	Mldg-F Door Panel Extension Joint	27 5Sed,1942 Cpe-2Sed-UCo-CvSed
205737	Mldg-F Door Panel Extension Joint (Use 205251)	20 thru 24 Sed
C 205738 Pr	Mldg-Rr Door Ext Joint	1942 5Sed
C 205739 Pr	Cover-Ctr Panel Aux Belt Mldg	22 thru 27
205742	Center Bar & W/Strip-F Door Wdo-RH (Use 134230)	1942 All
BO 205743 Pr	Center Bar & W/Strip-F Door Wdo-LH	1942 All
BO 205744 Pr	Frame Assy-F Door Wing-RH	20,21,28
BO 205745 Pr	Frame Assy-F Door Wing-LH	20,21,28
BO 205746 Pr	Frame-F Door Wing-RH	22,24,25,27
BO 205747 Pr	Frame-F Door Wing-LH	22,24,25,27
BO 205748 Pr	Glass & Frame Assy-F Door Wing-RH	22,24,25,27
BO 205749 Pr	Glass & Frame Assy-F Door Wing-LH	22,24,25,27
BO 205750 Pr	Belt Mldg-F End Panel Axu-RH	22,24,25,27
BO 205751 Pnt	Belt Mldg-F End Panel Aux-LH-Painted	22,24,25,27
205752	Chain Housing & Arm-W/S Cleaner-RH (Use 148152)	1942 All
205753	Chain Housing & Arm-W/S Cleaner-LH (Use 148153)	1942 All
BO 205754 Pr	Belt Mldg-Qtr Panel Aux-RH	22-24 2Sed
BO 205755 Pr	Belt Mldg-Qtr Panel Aux-LH	22-24 2Sed
205756	Belt Mldg-Qtr Panel Aux-RH (Use 205240)	22-24-27 Sed
BO 205757 Pr	Belt Mldg-Qtr Panel Aux-LH	22-24-27 Sed
205758	Belt Mldg-Qtr Panel Aux-RH (Use 205242)	22-24-25 ClubCpe-3Cpe
205759	Belt Mldg-Qtr Panel Aux-LH (Use 204243)	22-24-25 ClubCpe-3Cpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
205760	Belt Mldg-Qtr Panel Aux-RH (Use 205244)	22-24 CvSed
205761	Belt Mldg-Qtr Panel Aux-LH (Use 205245)	22-24 CvSed
205762	Handle Assy-Door Outside-RH-Front-LH-Rear- (Use 204140)	20
205763	Handle Assy-Door Outside-LH-Front-RH-Rear- (Use 204141)	20
205764	Handle Assy-Door Outside-RH-Front-LH-Rear- (Use 204142)	21 exc Station 28
205765	Handle Assy-Door Outside-LH-Front-RH-Rear- (Use 204143)	21 exc Station,28
205766	Handle Assy-Door Outside-RH-Front-LH-Rear- (Use 204144)	22,24,25,27
205767	Handle Assy-Door Outside-LH-Front-RH-Rear- (Use 204145)	22,24,25,27
C 205768 Pr	Molding-F Door Panel Aux Belt-RH	22-24 ClubCpe-3Cpe-2Sed-CvSed,25,27
C 205769 Pr	Molding-F Door Panel Aux Belt-LH,	22-24 ClubCpe-3Cpe-2Sed-CvSed,25,27
C 205770 Pr	Molding-F Door Panel Aux Belt-RH	22-24 Sed
C 205771 Pr	Molding-F Door Panel Aux Belt-LH	22-24 Sed
C 205772 Pr	Molding-Rr Door Panel Aux Belt	22-24-27 5Sed
BO 205773	Escutcheon Plate-Domelamp Switch	1942 All
C 205774 Pr	Reveal Mldg-F Door Wdo-RH	20-21-23-24 UCo-2Sed 27
C 205777 Pr	Reveal Mldg-F Door Wdo-LH	20-21-22-24 Sed
205778	Reveal Mldg-F Door Wdo-RH (Use 147720)	20 thru 25 ClubCpe-3Cpe-UCpe
205779	Reveal Mldg-F Door Wdo-LH (Use 147721)	20 thru 25 ClubCpe-3Cpe-UCpe
205780	Reveal Mldg-Rr Door Wdo-RH (Use 147714)	20-21-22-24-27 Sed
C 205781 Pr	Reveal Mldg-Rr Door Wdo-LH-Prime	20-21-22-24-27 Sed
C 205782 Pr	Reveal Mldg-Qtr Wdo-RH-Prime	1942 UCo-2Sed
205783	Reveal Mldg-Qtr Wdo-LH (Use 147719)	1942 UCo-2Sed
205784	Reveal Mldg-Qtr Wdo-RH (Use 147716)	1942 Sed
C 205785 Pr	Reveal Mldg-Qtr Wdo-LH	1942 Sed
C 205786 Pr	Reveal Mldg-Qtr Wdo-RH	1942 ClubCpe-UCpe-3Cpe
205787	Reveal Mldg-Qtr Wdo-LH (Use 147723)	1942 ClubCpe-UCpe-3Cpe
C 205790	Mldg-F Seat Riser Panel-RH	22-24 Sed-2Sed-3Cpe
C 205791	Mldg-F Seat Riser Panel-LH	22-24 Sed-2Sed-3Cpe
C 205792	Mldg-F Seat Riser Panel-RH	22-24-25 ClubCpe-CvSed
C 205793	Mldg-F Seat Riser Panel-LH	22-24-25 ClubCpe-CvSed
BO 205794	Escutcheon-F Seat Track Handle	1942 All
205795	Handle-Door Inside-Lac (Use 142009)	20,21,28
205796	Handle-Window Regulator-Russet Knob (Use 204251)	20,21,28
205797	Handle Assy-Door Wdo Regulator-Green Knob (Use 204252)	20P,21
205798	Handle Assy-Door Wdo Regulator-Blue Knob (Use 204253)	20P,21
205799	Handle Assy-Door Wing Regulator-Russet Knob (Use 204257)	20-21 CvSed
205800	Handle Assy-Door Wing Regulator-Green Knob (Use 204258)	20P-21 CvSed
205801	Handle Assy-Door Wing Regulator-Blue Knob (Use 204259)	20P-21 CvSed
C 205804	Trim Mldg-F Seat Back Frame-Lower	27
205805	Handle-Door Inside (Use 121840)	20-21 exc Cv
205806	Handle Assy-Door & Qtr Wdo Regulator-Russet (Use 205334)	20,21,28
205807	Handle Assy-Door & Qtr Wdo Regulator-Green (Use 205335)	20,21,28
BO 205808	Handle Assy-Door & Qtr Wdo Regulator-Blue	20,21,28
BO 205809	Escutcheon-Inside Handle	20,21,28
BO 205813 Pr	Housing & Gasket Assy-License Lamp	1942 Pass Cars
205814	Retainer & Gasket Assy-License Lamp Lens (Use 148354)	1942 Pass Cars
205815	Handle-Door Inside (Use 204250)	21 thru 27
205816	Handle Assy-Door & Qtr Wdo Regulator-Russet Knob (Use 204254)	21 thru 27
BO 205817	Handle Assy-Door & Qtr Wdo Regulator-Green Knob	21 thru 27
205818	Handle Assy-Door & Qtr Wdo Regulator-Blue Knob (Use 204256)	21 thru 27
205819	Handle Assy-Door Wing Regulator-Russet Knob (Use 204260)	21 thru 27,21 CvSed
205820	Handle Assy-Door Wing Regulator-Green Knob (Use 204261)	21 thru 27,21 CvSed
205821	Door Wing Regulator-Blue Knob (Use 204262)	22 thru 27,21 CvSed
205822	Escutcheon-Inside Handle-Russet Knob (Use 204266)	22 thru 27
205823	Escutcheon-Inside Handle-Green Knob (Use 204267)	22 thru 27
205824	Escutcheon-Inside Handle-Blue Knob (Use 204268)	22 thru 27

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 205826 Pr	Belt Molding-Hood-RH	20
C 205827 Pr	Belt Molding-Hood-LH	20
C 205828 Pr	Belt Molding-Hood-RH	21 thru 28
C 205829 Pr	Belt Molding-Hood-LH	21 thru 28
BO 205830 Pr	Molding-Hood Side-RH	21 thru 28
BO 205831 Pr	Molding-Hood Side-LH	21 thru 28
C 205832 Pr	Belt Mldg-Hood Aux-RH	22 thru 27
C 205833 Pr	Belt Mldg-Hood Aux-LH	22 thru 27
205834	Louver-Radiator #1-RH-(Use 204428)	1942 All
205835	Louver-Radiator #1-LH-(Use 204429)	1942 All
205836	Louver-Radiator #2-RH-(Use 204426)	1942 All
C 205837 Pr	Louver-Radiator #2-LH	1942 All
C 205838 Pr	Louver-Radiator #3-RH	1942 All
C 205839 Pr	Louver-Radiator #3-LB	1942 All
C 205840 Pr	Louver-Radiator #4-RH	22,24,25,27
C 205840 Pr	Louver-Radiator #5-RH	1942 All
C 205841 Pr	Louver-Radiator # 4-LH	22,24,25,27
C 205841 Pr	Louver-Radiator #5-RH	1942 All
C 205842 Pr	Louver-Radiator #4-RH	20,28
C 205843 Pr	Louver-Radiator #4-LB	20,28
C 205844 Pnt	Extension-Hood Top Ornament-Rear	20,28
205846	Ornament-Hood Top-Upper (Use 204872)	20,21,28
BO 205847	Ornament-Hood Top-Louver	22,24,25,27
BO 205848	Base-Hood Top Ornament	22,24,25,27
BO 205849 Pr	Molding-Lower Center Panel	20,21,28
205850	Ornament-Hood Top-Lower-Domestic (Use 204870)	20,21,28
BO 205851 Pr	Ornament-Hood Top-Lower-Export	20,21,28
BO 205852 Pr	Ornament Assy-Hood Side-RH	20
BO 205853 Pr	Ornament Assy-Hood Side-LH	20
BO 205854 Pr	Ornament Assy-Hood Lamp-RH	21 thru 28
BO 205855 Pr	Ornament Assy-Hood Lamp-LH	21 thru 28
205856	Ornament-Lower Center Panel-Upper-Domestic (Use 204874)	22 thru 27
BO 205857	Ornament-Lower Center Panel-Upper-Export	22 thru 27
BO 205858 Pr	Extension-Hood Top Ornament-Rear-Long	21,28C
BO 205859 Pr	Extension-Hood Top Ornament-Rear	22 thru 27
205860	Mldg-F Bumper Splash Apron-Lower-RH (Use 204384)	1942 All
205861	Mldg-F Bumper Splash Apron-Lower-LH (Use 204385)	1942 All
205862	Mldg-F Bumper Splash Apron-Center-RH (Use 204386)	1942 All
205863	Mldg-F Bumper Splash Apron-Center-LH (Use 204387)	1942 All
C 205864 Pnt	Mldg-F Bumper Splash Apron-Upper-RH	1942 All
C 205864 Pr	Mldg-F Bumper Splash Apron-Upper-RH	1942 All
205865	Mldg-F Bumper Splash Apron-Upper-LH (Use 204389)	1942 All
205866	Center Plate-F Bumper Splash Apron Mldg- (Use 204382)	1942 All
205867	Bezel Assy-Speedometer,Clock & Inst (Use 204182)	1942 All
BO 205868 Pr	Ornament-F Fender-RH	22,24,25,27
BO 205869 Pr	Ornament-F Fender-LH	22,24,25,27
C 205870 Pr	Trim Mldg-F Fender-Upper-RH	20 thru 27
C 205871 Pr	Trim Mldg-F Fender-Upper-LH	20 thru 27
BO 205872 Pr	Trim Mldg-F Fender-Center-RH	20 thru 27
BO 205873 Pr	Trim Mldg-F Fender-Center-LH	20 thru 27
BO 205874	Ornament-Hood Top	22 thru 27
BO 205875	Base-Hood Top Ornament	22 thru 27
BO 205876	Clamp-Hood Top Ornament	22 thru 27
C 205877	Extension-Hood Top Ornament-Rear	22 thru 27
BO 205878 Pr	Trim Mldg-F Fender-Lower-RH	20 thru 27
BO 205879 Pr	Trim Mldg-F Fender-Lower-LH	20 thru 27
C 205880 Pr	Trim Mldg-Rr Fender-Upper-RH	20 thru 27
205881	Trim Mldg-Rr Fender-Upper-LH-(Use 204307)	20 thru 27
BO 205882 Pr	Trim Mldg-Rr Fender-Center-RH	20 thru 27
BO 205883 Pr	Trim Mldg-Rr Fender-Center-LH	20 thru 27
BO 205884 Pr	Trim Mldg-Rr Fender-Lower-RH	20 thru 27
BO 205885 Pr	Trim Mldg-Rr Fender-Lower-LH	20 thru 27
BO 205888	Clamp-Visor Support Rod	20 thru 28 exc CvSed
205889	Arm-Visor Bracket (Use 120672)	20 thru 28 exc CvSed
BO 205890	Plate-Visor Header Hinge	20 thru 28 exc CvSed
BO 205891	Clamp-Visor Header Hinge	20 thru 28 exc CvSed
BO 205894	Screw-Visor Arm to Clamp	20 thru 28 exc CvSed
BO 205895	Bolt-Visor Header Hinge Clamp	20 thru 28 exc CvSed
BO 205896 Pr	Trim Mldg-F Fender	1942 Station
BO 205897 Pr	Trim Mldg-Rr Fender	1942 Station
205898	Rim-Headlamp Lens (Use 212880)	22,24,25,27
205899	Rim-Headlamp Lens (Use 206499)	20,21,28

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
205900	Retainer-Sealed Beam Assy (Use 206263)	1942 All
205901	Ornament-F Fender Lamp (Use 1-206670 & 3-170367)	20 thru 27
BO 205902 Pr	Lamp Assy-F Fender-RH-6V-With DI	20 thru 27
BO 205903 Pr	Lamp Assy-F Fender-LH-6V-With DI	20 thru 27
BO 205906	Lamp Assy-F Fender-RH-6V-Without DI	20,21,22,24
BO 205907 Pr	Lamp Assy-F Fender-LH-6V-Without DI	20,21,22,24
BO 205910	Housing-F Fender Lamp-RH	20 thru 27
BO 205911	Housing-F Fender Lamp-LH	20 thru 27
205912	Lamp Assy-Tail-RH-6V (Use 205600)	20-21 Sed-2Sed-UCo
BO 205913	Lamp Assy-Tail-LH-6V	20-21 Sed-2Sed-UCo
205914	Lamp Assy-Tail-RH-12V (Use 205602)	20-21 Sed-2Sed-UCo
BO 205916	Lamp Assy-Tail-RH-6V	20-21 ClubCpe-3Cpe-UCpe-CvSed
BO 205917	Lamp Assy-Tail-LH-6V	20-21 ClubCpe-3Cpe-UCpe-CvSed
BO 205920	Lamp Assy-Tail-RH-6V	24-25-27 Sed-2Sed
BO 205921	Lamp Assy-Tail-LH-6V	24-25-27 Sed-2Sed
BO 205924	Lamp Assy-Tail-RH-6V	22-24-25 ClubCpe-3Cpe-CvSed
BO 205925	Lamp Assy-Tail-LH-6V	22-24-25 ClubCpe-3Cpe-CvSed
205930	Hinge Assy-Rear Compt Door-RH (Use 204540)	1942 All
205931	Hinge Assy-Rear Compt Door-LH (Use 204541)	1942 All
205932	Hinge Assy-Rear Compt Door-Less Cyl-Lac (Use 147394)	1942 All
205934	Name Plate- BOnnet Side-Rear (Use 208771)	21
205935	Name Plate- BOnnet Side-Rear (Use 147235)	22,24,25,27
205936	Number Plate- BOnnet Side-Rear (Use 142234)	24,25,27
BO 205937	Name Plate Assy- BOnnet Side	21 thru 28
BO 205938	Center Molding Assy-Inst Panel-Without VD or HDM	1942 All
BO 205939	Center Molding Assy-Inst Panel-With VD	1942 All
130 205940	Center Molding Assy-Inst Panel-With HDM	1942 All
205941	Brkt-Starting & Light Sw Button (Use 147838)	1942 All
205944	Dial and Bezel Assy-Inst & Spdo-LHD-Miles (Use 204161)	20,21,28
BO 205945	Dial and Bezel Assy-Inst & Spdo-RHD-Miles	20,21,28
205946	Dial and Bezel Assy-Inst & Spdo-LHD-Metric (Use 204163)	20,21,28
205947	Dial and Bezel Assy-Inst & Spdo-RHD-Metric (Use 204164)	20,21,28
205948	Dial and Bezel Assy-Inst & Clock-LHD (Use 204165)	20,21,28
BO 205949	Dial and Bezel Assy-Inst & Clock-RHD	20,21,28
205950	Grille-Inst Panel (Use 204434)	1942 All
205952	Dial and Bezel Assy-Inst and Spdo-LHD-Miles (Use 204131)	22,24,25,27
BO 205953	Dial and Bezel Assy-Inst and Spdo-RHD-Miles	22,24,25,27
205954	Dial and Bezel Assy-Inst and Spdo-LHD-Metric (Use 204133)	22,24,25,27
205955	Dial and Bezel Assy-Inst and Spdo-RHD-Metric (Use 204134)	22,24,25,27
205956	Dial and Bezel Assy-Inst and Clock-LHD (Use 204135)	22,24,25,27
205957	Dial and Bezel Assy-Inst and Clock-RHD (Use 204136)	22,24,25,27
BO 205958	Molding-Locker B0x Door	22,24,25,27
BO 205959	Brkt-Steering Gear Jacket Tube	22,24,25,27
BO 205960	Cap-Steering Gear Jacket Tube Brkt	22-24 with DI,25,27
205961	Cap-Steering Gear Jacket Tube Brkt (Use 147845)	22-24 Without DI
205962	Escutcheon-Inst Panel Steering Hole-Inner-LHD (Use 148782)	20 thru 27
BO 205963	Escutcheon-Inst Panel Steering Hole-Outer-LHD	20 thru 27
130 205964	Escutcheon-Inst Panel Steering Hole-Outer-RHD	20 thru 27
BO 205965	Escutcheon-Inst Panel Steering Holes-Inner-RHD	20 thru 27
BO 205967	Rim and Glass Assy-Domelamp	1942 All
205968	Control Assy-W/S Cleaner (Use 204175)	1942 All
C 205971 Pr	Scuff Plate-F Door-LH	20T-20P-21 thru 25 exc Sed,27 Sed
C 205972 Pr	Scuff Plate-F Door-RH	20-21-22-24 Sed,21 Station
C 205973 Pr	Scuff Plate-F Door-LH	20-21-22-24 Sed,21 Station
C 205974 Pr	Scuff Plate-Rr Door-RH	20-21-22-24 Sed,21 Station
205975	Scuff Plate-Rear Door-LH (Use 147747)	20-21-22-24 Sed,21 Station
BO 205976	Scuff Plate-Rear Door-RH	27 Sed
BO 205977	Scuff Plate-Rear Door-LB	27 Sed
205978	Ash Receiver Assy-Inst Panel-Grained (Use 208646)	20 thru 27
205980	Ash Receiver Assy-Inst Panel (Use 208646)	20 thru 27
205996	Finish Mldg W/Shield Reveal-RH (Use 142048)	1942 CvSed
205997	Finish Mldg-W/Shield Reveal-LH (Use 142049)	1942 CvSed
*C 205999	Cement-Black Rubber	1946-1947 All
BO 206002	Retainer-Qtr Ash Receiver	1942 Sed-2Sed-ClubCpe
206003	Ash Receiver Assy-Quarter-Grained (Use 209556)	1942 Sed-2Sed-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	206004 Ash Receiver Assy-Quarter-Gray (Use 209556)	1942 Sed-2Sed-ClubCpe
	206005 Ash Receiver Assy-Quarter-Green (Use 209556)	1942 Sed-2Sed-ClubCpe
	206006 Cover-Quarter Ash Receiver-Grained (Use 209557)	1942 Sed-2Sed-ClubCpe
	206007 Cover-Quarter Ash Receiver-Gray (Use 209557)	1942 Sed-2Sed-ClubCpe
	206008 Cover-Quarter Ash Receiver-Green (Use 209557)	1942 Sed-2Sed-ClubCpe
BO	206010 Ash Receiver Assy-Quarter-Grained	25,27
	206011 Ash Receiver Assy-Quarter-Gray (Use 204451)	25,27
BO	206012 Ash Receiver Assy-Quarter-Green	25,27
BO	206013 Cover-Qtr Ash Receiver-Grained	25,27
BO	206014 Cover-Qtr Ash Receiver-Gray	25,27
BO	206015 Cover-Qtr Ash Receiver-Green	25,27
	206016 Reg & Chan Assy-Qtr Wdo-RH (Use 204704)	20P Sed,21 thru 27 Sed-ClubCpe
	206017 Reg & Chan Assy-Qtr Wdo-LH (Use 204705)	20P Sed,21 thru 27 Sed-ClubCpe
BO	206027 Socket and Bracket Assy-Tail Lamp	1942-1946-1947 Pass Cars
	206028 Bezel-Tail Lamp-RH (Use 205622)	20T,20P,21 exc Station
	206029 Bezel-Tail Lamp-LH (Use 205623)	20T,20P,21 exc Station
BO	206033 Cigar Lighter Assy-Qtr Panel-6V	27 Sed
BO	206034 Cigar Lighter Assy-Qtr Panel-12V	27 Sed
	206036 Element-Cigar Lighter-6V (Use 142146)	1942 All
	206037 Element-Cigar Lighter-12V (Use 142147)	1942 All
	206038 Element & Knob Assy-Cigar Lighter-6V (Use 148532)	27 Sed
*HA	206042 Cigar Lighter Assy-Inst Panel-6V	1942 All
BO	206046 Escutcheon-Steering Column Hole-Inner-LHD	1942 Cab-CabPu
BO	206047 Escutcheon-Steering Column Hole-Outer-LHD	1942 Cab-CabPu
	206048 Escutcheon-Strg Col Hole-Outer-RHD (Use 148792)	1942 Cab-CabPu
	206049 Escutcheon-Steering Col Hole-Inner-RHD (Use 148793)	1942 Cab-CabPu
	206050 Glass and Frame Assy-F Door Wing-RH-Enamel Frame (Use 140874)	20,21
	206051 Glass and Frame Assy-F Door Wing-LH-Enamel Frame (Use 140875)	20,21
	206052 Handle-Front Door Pull-to (Use 142312)	25,27
	206053 Bracket-Front Door Pull-to Handle (Use 148244)	25,27
	206056 Bezel-Tail Lamp-RH-Prime (Use 205634)	22,24,25,27
BO	206057 Bezel-Tail Lamp-LH-Prime	22,24,25,27
	206059 Rim-Tail Lamp Lens (Use 144736)	1942 Cab-CabPu-Station
	206061 Knob Kit-Radio (Use 205290)	1942 All
	206062 Trim & Switch Knob Assy-Radio (Use 205291)	1942 All
	206063 Knob-Radio Tone Control (Use 205293)	1942 All
	206064 Knob-Radio Dummy (Use 205294)	1942 All
	206065 Nut-Radio Mounting (Use 205283)	1942 All
	206066 Lamp Complete-Tail-6V (Use 144730)	1942 Cab-CabPu
BO	206067 Lamp Complete-Tail-12V	1942 Cab-CabPu
BO	206068 Lamp Complete-Tail-6V	1942 Station
BO	206069 Lamp Complete-Tail-12V	1942 Station
	206070 Headlamp Complete-RH-LHD-6V (Use 206250)	1942 All
	206071 Headlamp Complete-LH-LHD-6V (Use 206251)	1942 All
BO	206072 Headlamp Complete-RH-RHD-6V	1942 All
	206073 Headlamp Complete-LH-RHD-6V (Use 209895)	1942 All
BO	206074 Headlamp Complete-RH-12V	1942 All
BO	206075 Headlamp Complete-LH-12V	1942 All
	206076 Finish Molding & W/Strip Assy-F Dr Wdo-RH (Use 148920)	22-24 2Sed,27
	206077 Finish Molding & W/Strip Assy-F Dr Wdo-LH (Use 148921)	22-24 2Sed,27
	206080 Finish Molding & W/Strip Assy-F Dr Wdo-RH (Use 148936)	22-24 3Cpe-ClubCpe,25
	206081 Finish Molding & W/Strip Assy-F Dr Wdo-LH (Use 148937)	22-24 3Cpe-ClubCpe,25
	206082 Finish Molding & W/Strip Assy-R Dr Wdo-RH (Use 148944)	22-24-27 Sed
c	206083 Finish Molding & W/Strip Assy-R Dr Wdo-LH	22-24-27 Sed
c	206084 Finish Molding & W/Strip Assy-Qtr Wdo-RH	22-24 2Sed
	206086 Finish Molding & W/Strip Assy-Qtr Wdo-RH (Use 204614)	22-24-27 Sed
	206087 Finish Molding & W/Strip Assy-Qtr Wdo-LH (Use 204615)	22-24-27 Sed
c	206091 Trim Assy-Front Seat Back	1946 3Cpe-Sed-Comb Trim
c	206092 Trim Assy-Front Seat Back-RH	1946 Bro-Comb Trim
c	206093 Trim Assy-Front Seat Back-LH	1946 Bro-Comb Trim
c	206094 Trim Assy-Front Seat Back-RH	1946 ClubCpe-Comb Trim
c	206095 Trim Assy-Front Seat Back-LH	1946 ClubCpe-Comb Trim
BO	206096 Clock Assy-Locker Box Door-Elec (New Haven)	172,174 Opt 171-173-178
	206116 Arm Rest Assy-Front Door-Cloth Trim	1946-1947 All exc CvBro
	206118 Trim Assy-F/D Arm Rest-Cloth Trim	1946-1947 All exc CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
206120	Trimboard Comp-RH-Front Door-Cloth Trim	51-53-171-173 Bro-3Cpe-ClubCpe
206121	Trimboard Comp-LH-Front Door-Cloth Trim	51-53-171-173 Bro-3Cpe-ClubCpe
206122	Trimboard Comp-RH-Front Door-Cloth Trim	51-53-171-173 Sed
206123	Trimboard Comp-LH-Front Door-Cloth Trim	51-53-171-173 Sed
206124	Trimboard Comp-RH-Rear Door-Cloth Trim	1946-1947 Sed
206125	Trimboard Comp-LH-Rear Door-Cloth Trim	1946-1947 Sed
206126	Trimboard Comp-RH-Front Door-Cloth Trim	52-54-172-174 Bro-3Cpe-ClubCpe
206127	Trimboard Comp-LH-Front Door-Cloth Trim	52-54-172-174 Bro-3Cpe-ClubCpe
206128	Trimboard Comp-RH-Front Door-Cloth Trim	52-54-172-174 Sedan
206129	Trimboard Comp-LH-Front Door-Cloth Trim	52-54-172-174 Sedan
206134	Cushion Frame & Back Comp-F Seat-LHD-Cloth Trim	51-53-171-173 Sedan
206135	Cushion Frame & Back Comp-F Seat-RHD-Cloth Trim	51-53-171-173 Sedan
206136	Cushion Frame & Back Comp-F Seat-LHD-Cloth Trim	52-54-172-174 Sedan
206137	Cushion Frame & Back Comp-F Seat-RED-Cloth Trim	52-54-172-174 Sedan
206138	Cushion Frame & Back Comp-F Seat-LED-Cloth Trim	1946-1947 3Cpe
206139	Cushion Frame & Back Comp-F Seat-RHD-Cloth Trim	1946-1947 3Cpe
206142	Back Comp-Drivers-F Seat-LED-Cloth Trim	1946-1947 Bro
206143	Back Comp-Drivers-F Seat-RHD-Cloth Trim	1946-1947 Bro
206144	Back Comp-Drivers-F Seat-LHD-Cloth Trim	1946-1947 ClubCpe
206145	Back Comp-Drivers-F Seat-RHD-Cloth Trim	1946-1947 ClubCpe
206146	Back Comp-Pass-F Seat-LHD-Cloth Trim	1946-1947 Bro
206147	Back Comp-Pass-F Seat-RHD-Cloth Trim	1946-1947 Bro
206148	Back Comp-Pass-F Seat-LHD-Cloth Trim	1946-1947 ClubCpe
206149	Back Comp-Pass-F Seat-RHD-Cloth Trim	1946-1947 ClubCpe
206150	Trim Assy-RH-F Seat Back-Cloth Trim	1946 Bro
206151	Trim Assy-LH-F Seat Back-Cloth Trim	1946 Bro
206152	Trim Assy-F Seat Back-Cloth Trim	1946 Sed-3Cpe
206154	Trim Assy-RH-F Seat Back-Cloth Trim	1946 ClubCpe
206155	Trim Assy-LH-F Seat Back-Cloth Trim	1946 ClubCpe
C 206156	Trim Assy-F Seat Back Panel & Riser Panel-Cloth Trim	51-53-171-173 Sed
206157	Trim Assy-F Seat Back Panel & Riser Panel-Cloth Trim	52-54-172-174 Sed
C 206158	Trim Assy-F Seat Back Panel & Riser Panel-Cloth Trim	1946-1947 3Cpe
206159	Trim Assy-F Seat Riser Panel-Cloth Trim	1946-1947 Bro
206160	Trim Assy-F Seat Riser Panel-Cloth Trim	1946-1947 ClubCpe
206162	Trimboard & Trim Assy-RH-F Seat Foot Rest	1946 Bro-ClubCpe
206163	Trimboard & Trim Assy-LH-F Seat Foot Rest	1946 Bro-ClubCpe
206164	Trimboard & Trim Assy-RH-F Seat Foot Rest	1946 Sedan
206165	Trimboard & Trim Assy-LH-F Seat Foot Rest	1946 Sedan
206166	Cushion Comp-F Seat-Standard-Cloth Trim	51-53-171-173 Bro-ClubCpe
206167	Cushion Comp-F Seat-Standard-Cloth Trim	52-54-172-174 Bro-ClubCpe
206168	Cushion Comp-F Seat-Standard-Cloth Trim	51-53-171-173 Sed-3Cpe
206169	Cushion Comp-F Seat-Standard-Cloth Trim	52-54-172-174 Sed-3Cpe
206170	Trim Assy-F Seat Cushion-Cloth Trim	1946-1947 Bro-ClubCpe
206171	Trim Assy-F Seat Cushion-Cloth Trim	1946-1947 Sed-3Cpe
206172	Back Comp-R Seat-Cloth Trim	51-171 Bro,51-53-171-173 Sed
206173	Back Comp-F Seat-Cloth Trim	52-54 Sedan
206174	Back Comp-R Seat-Cloth Trim	1946-1947 ClubCpe
206175	Trim Assy-R Seat Back-Cloth Trim	1946 Bro,51-53 Sed
206176	Trim Assy-RH-R Seat Back-Cloth Trim	52-54 Sedan
206177	Trim Assy-LH-R Seat Back-Cloth Trim	52-54 Sedan
206178	Trim Assy-R Seat Back-Cloth Trim	1946 ClubCpe
206179	Arm Rest Assy-F Seat Back Center-Cloth Trim	52-54 Sedan
206180	Trim Assy-R Seat Back Center Arm Rest-Cloth Trim	52-54-172-174 Sed
206181	Valance Assy-R Seat Back Center Arm Rest-Cloth Trim	52-54 Sed
206182	Cushion Comp-R Seat-Standard-Cloth Trim	51-53-171-173 Bro-Sed
206183	Cushion Comp-R Seat-Standard-Cloth Trim	51-53-171-173 ClubCpe
C 206184	Cushion Comp-R Seat-Standard-Cloth Trim	52-54-172-174 Bro-Sed
206185	Cushion Comp-R Seat-Standard-Cloth Trim	52-54-172-174 ClubCpe
206186	Trim Assy-R Seat Cushion-Cloth Trim	1946 Bro-Sed
206187	Trim Assy-F Seat Cushion-Cloth Trim	1946 ClubCpe
C 206188	Retainer & Trim Assy-R Seat Cushion-Cloth Trim	1946-1947 Bro-Sed
206189	Retainer & Trim Assy-R Seat Cushion-Cloth Trim	1946-1947 ClubCpe
C 206190	Trim Assy-R Seat Cushion Retainer-Cloth Trim	1946-1947 Bro-Sed
206191	Trim Assy-R Seat Cushion Retainer-Cloth Trim	1946-1947 ClubCpe
BO 206196	Lock Cyl Assy-Rear Compt Door Handle	1946 thru 1950 exc 58-178
BO 206197	Lock Cyl & Keys Assy-Rear Compt Door Handle	1946 thru 1950 exc 58-178
BO 206198	Seal-Frame Sidemember to Rocker Panel	1948-1949 All,1950 exc Sed
*HA 206199	License Plate Frame Kit-Service	1946-1947-1948 All
C 206201	Cushion Comp-Seat-Air Foam	1946-1947 Cab-CabPu
BZ 206220	Spacer-Frt Bumper-Impact Bar	1940 All,10,11,18
BZ 206221	Spacer-Bumper Impact Bar-Tapered	1940 All,10,11,18
BZ 206222	Kit-Front Bumper Impact Bar Attaching Parts	For installing 1946-1947 bars to 1940 & Model 10, 11,18 cars

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 206223	Kit-Rear Bumper Impact Bar Attaching Parts	For installing 1946-1947 bars to 1940 & Model 10,11,18 cars
*HS 206225	Spot Remover (5 oz)	All
*HS 206226	Fabric Cleaner (gallon)	All
*HS 206227	Door Ease Stick-Shop Size #SS-6	All
*HS 206228	Door Ease Stick-Universal Size #B-12	All
*HS 206229	Tissue Dispenser Assy	All
*HA 206231	Fire Extinguisher & Tire Infl Tank Kit	All
*HS 206232	Rust Dissolver-6 oz	All
*HS 206233	Rust Dissolver-1 gal	All
*HA 206236	Lamp Kit-Extension-Magnalite	All
*HS 206240	Display Rack-Shop & Owner Supplies	All
BO 206242	Track Assy-Front Seat-RH	1947 Sed-3Cpe
BO 206243	Track Assy-Front Seat-LH	1947 Sed-3Cpe
BO 206250	Headlamp-Complete-RH-6V	1946-1947 All
BO 206251	Headlamp-Complete-LH-6V	1946-1947 All
BO 206252	Control Valve-Automatic Windshield Washer	1946-1947 All
BO 206253	Connection "Y"-Automatic W/S Washer	1946-1947 All
BO 206254	Jet Valve & Nozzle Assy-Automatic W/S Washer	1946-1947 All
BO 206255	Washer-Automatic W/S Washer Nozzle	1946-1947 All
BO 206256	Tee Connection Assy-Automatic W/S Washer	1946 thru 1950
BO 206257	W/Shield Washer & Bracket Assy-Automatic	1946-1947 All, 480 Series
BO 206258	Hose-1/8"-Automatic W/S Washer	1946-1947 All
BO 206259	Hose-3/16"-Automatic W/S Washer	1946-1947 All
BO 206260	Nut-Automatic W/S Washer Nozzle	1946-1947 All
BO 206263	Retainer-Headlamp Sealed Beam Assy	1946 thru 1950 All
*HA 206340	Seat Cover Kit-Fiber-F Seat	1946-1947 Bro-ClubCpe
*C 206372	Arm & Cross Shaft Assy- BOnnet Hinge	1946-1947 All
206374	Solvent-Automatic W/S Washer-Wtr-4 oz (Use 209976)	1946-1947-1948 All
*C 206403 Pr	Door Assy-LH-Without Mldg Holes	171 Bro
C 206407 Pr	Door Assy-LH-With Mldg Holes	171 Bro
*C 206411 Pr	Door Assy-Front-LH-Without Mldg Holes	171-173 Sed
*C 206423 Pr	Door Assy-Front-LH-Without Mldg Holes	171-173 3Cpe-ClubCpe
*C 206431 Pr	Door Assy-Front-LH	172-174 Bro
*C 206435 Pr	Door Assy-Front-LH	172-174 Sed
*C 206439 Pr	Door Assy-Front-LH	172-174 3Cpe-ClubCpe
*C 206443 Pr	Door Assy-Front-LH	171 CvBro
206447	Door Assy-Front-LH (Use 206443)	174 CvBro
C 206482	Valance Assy-R Seat Center Arm Rest-Cloth Trim	172-174 Sed
C 206483	Valance Assy-R Seat Center Arm Rest-Comb & Leather Trim	172-174 Sed
C 206484	Arm Rest Complete-Center-Rear Seat-Cloth Trim	172-174 Sed
C 206485	Arm Rest Complete-Center-Rear Seat-Comb & Leather Trim	172-174 Sed
BO 206499	Rim-Headlamp Lens	1946-1947 All
BO 206503	Bracket-Rear Seat Back Spring Hanger	172-174 Sed
BO 206504	Retainer-Rear Seat Center Arm Rest Valance	172-174 Sed
C 206506	Spring-Rear Seat Back-RH	172-174 Sed
C 206507	Spring-Rear Seat Back-LH	172-174 Sed
BO 206510	Lamp Assy-Front Fender-6V-RH-Without DI	1946-1947 All
BO 206511	Lamp Assy-Front Fender-6V-LH-Without DI	1946-1947 All
BO 206512	Lamp Assy-Front Fender-12V-RH-Without DI	1946-1947 All
BO 206513	Lamp Assy-Front Fender-12V-LH-Without DI	1946-1947 All
BO 206514	Lamp Assy-Front Fender-6V-RH-With DI	51 thru 54,171 thru 174
BO 206515	Lamp Assy-Front Fender-6V-LH-With DI	51 thru 54,171 thru 174
BO 206516	Lamp Assy-Front Fender-12V-RH-With DI	51 thru 54,171 thru 174
BO 206517	Lamp Assy-Front Fender-12V-RH-With DI	51 thru 54,171 thru 174
BO 206520	Housing-Front Fender Lamp-RH	1946-1947 All
BO 206521	Housing-Front Fender Lamp-LH	1946-1947 All
*BO 206530	Fender Lamp Kit-Front	51-53-58-171-173-178
206540	Fender Assy-RH-Front-With Fender Lamps (Use 209540)	58,178
206541	Fender Assy-LH-Front -With Fender Lamps (Use 209541)	58,178
BO 206544	Packing-Top Hydraulic Cylinder Piston	1941 thru 1947 CvBro
BZ 206580	Lock Assy-Spare Tire	178 Station
206581	Lock Cylinder Assy-Spare Tire	178 Station
206582	Key-Spare Tire Lock	178 Station
BZ 206584	Lock Cylinder & Keys-Spare Tire	178 Station
C 206590	Impact Bar to Frame Bar Assy-Rear Bumper-RH	178 Station
C 206591	Impact Bar to Frame Bar Assy-Rear Bumper-LH	178 Station
BZ 206594	Bumper Guard Assy-Rear-RH	178 Station
BZ 206595	Bumper Guard Assy-Rear-LH	178 Station
C 206598	Impact Bar-Rear Bumper-RH	178 Station
C 206599	Impact Bar-Rear Bumper-LH	178 Station
C 206629	Panel-F Door Outside-LH-With Mldg Holes-Prime	171-173 3Cpe-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 206631	Panel-F Door Outside-LH-With Mldg Holes-Prime	171-173 Sed
C 206633	Panel-F Door Outside-LH-Prime	171 CvBro
C 206637	Panel-F Door Outside-LH-Prime	172-174 Bro
C 206641	Panel-F Door Outside-LH-Prime	172-174 Sed
BO 206656	Cross Arm Assembly-Radio	1947 All
BO 206657	Oscillator Shunt Coil Assy-Radio	1947 All
BO 206658	Hand Selector & Muting Switch Assy-Radio	1947 All
BO 206660	Antenna Trimmer-Radio	1947 All
BO 206661	Resistor-15 Megohm-Radio	1947 All
BO 206662	Transformer-Power-Radio	1947 All
BO 206663	Transformer-Output-Radio	1947 All
BO 206664	Ratchet Gear-Radio	1947 All
206666	Speaker Assy-Radio (Use 208590)	1947 All
BO 206667	Cone & Voice Coil-Radio	1947 All
BO 206668	Coil & Shield Assy-LH-Radio	1947 All
BO 206669	Coil & Shield Assy-RH-Radio	1947 All
C 206670	Ornament-Front Fender Lamp	1946-1947 All
BO 206674	Connector-Electric Clock Fuse-Male Half	1947 All
*HA 206675	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206676	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206677	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206678	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206679	License Plate Frame-Rayline-Pair	1947-1948-1949
*HA 206680	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206681	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206682	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206683	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206684	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206685	License Plate Frame-Rayline-Pair	1947 thru 1950
*HA 206686	License Plate Frame-Rayline-Pair	1947,1948,1949
*HA 206687	License Plate Frame-Rayline-Pair	1947,1948,1949
BO 206700	Housing-Hood Front Ornament	1947 All
BO 206701	Ornament Assy-Bonnet Front	1947 All
C 206704	Impact Bar-Front Bumper-Service	1940,1941,1947 All
BO 206740	Name Plate-Rear Compt Door	171 thru 174
BO 206741	Condenser-100 MMFD-Radio	1947 All
BO 206742	Condenser-Two Section Electrolytic-Radio	1947 All
BO 206743	Resistor-22000 Ohm-Radio	1947 All
BO 206744	Resistor-56000-Ohm-Radio	1947 All
BO 206745	Cable-Volume Control-Radio	1947 All
206750	Panel-Rear Compt Door-Outside-Prime (Use 203200)	1947 Bro-Sed
*C 206751 Pr	Panel-Outside-R/C Deck Door	1947 3Cpe-ClubCpe-CvBro
*C 206761 Pr	Door Assy-Rear Compt	1947 Bro-Sed
*C 206763 Pr	Door Assy-Rear Deck	1947 3Cpe-ClubCpe-CvBro
C 206764	Arm Rest Assy-RH-Quarter-Comb Trim	172-174 Bro-Sed
C 206765	Arm Rest Assy-LH-Quarter-Comb Trim	172-174 Bro-Sed
C 206766	Trim Assy-RH-Qtr Arm Rest-Comb Trim	172-174 Bro-Sed
C 206767	Trim Assy-LH-Qtr Arm Rest-Comb Trim	172-174 Bro-Sed
C 206768	Trimboard Complete-Quarter-RH-Comb Trim	171-173 Bro
C 206769	Trimboard Complete-Quarter-LH-Comb Trim	171-173 Bro
C 206770	Trimboard Complete-Quarter-RH-Comb Trim	171-173 Sed
C 206771	Trimboard Complete-Quarter-LH-Comb Trim	171-173 Sed
C 206772	Trimboard Complete-Quarter-RH-Comb Trim	171-173 ClubCpe
C 206773	Trimboard Complete-Quarter-LH-Comb Trim	171-173 ClubCpe
C 206774	Trimboard Complete-Quarter-RH-Comb Trim	172-174 Bro
C 206775	Trimboard Complete-Quarter-LH-Comb Trim	172-174 Bro
C 206776	Trimboard Complete-Quarter-RH-Comb Trim	172-174 Sed
C 206777	Trimboard Complete-Quarter-LH-Comb Trim	172-174 Sed
C 206778	Trimboard Complete-Quarter-RH-Comb Trim	172-174 ClubCpe
C 206779	Trimboard Complete-Quarter-LH-Comb Trim	172-174 ClubCpe
C 206800	Trimboard Complete-RH-F Door-Comb Trim	171-173 Bro-3Cpe-ClubCpe
C 206801	Trimboard Complete-LH-F Door-Comb Trim	171-173 Bro-3Cpe-ClubCpe
C 206804	Trimboard Complete-RH-F Door-Comb Trim	171-173 Sed
C 206805	Trimboard Complete-LH-F Door-Comb Trim	171-173 Sed
C 206806	Trimboard Complete-RH-R Door-Comb Trim	171-173 Sed
C 206807	Trimboard Complete-LH-R Door-Comb Trim	171-173 Sed
C 206812	Trimboard Complete-RH-F Door-Comb Trim	172-174 Bro-3Cpe-ClubCpe
C 206813	Trimboard Complete-LH-F Door-Comb Trim	172-174 Bro-3Cpe-ClubCpe
C 206816	Trimboard Complete-RH-F Door-Comb Trim	172-174 Sed
C 206817	Trimboard Complete-LH-F Door-Comb Trim	172-174 Sed
C 206818	Trimboard Complete-RH-R Door-Comb Trim	172-174 Sed
C 206819	Trimboard Complete-LH-R Door-Comb Trim	172-174 Sed
C 206830	Frame & Back Complete-F Seat-LHD-Comb Trim	171-173 Sed
C 206831	Frame & Back Complete-F Seat-RHD-Comb Trim	171-173 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 206834	Frame & Back Complete-F Seat-LHD-Comb Trim	172-174 Sod
C 206835	Frame & Back Complete-F Seat-RHD-Comb Trim	172-174 Sed
C 206836	Frame & Back Complete-F Seat-LHD-Comb Trim	171-173 3Cpe
C 206837	Frame & Back Complete-F Seat-RHD-Comb Trim	171-173 3Cpe
C 206840	Frame & Back Complete-F Seat-LHD-Comb Trim	172-174 3Cpe
C 206841	Frame & Back Complete-F Seat-RHD-Comb Trim	172-174 3Cpe
C 206848	Back Complete-F Seat-Drivers-LHD-Comb Trim	171-173 Bro
C 206849	Back Complete-F Seat-Drivers-RHD-Comb Trim	171-173 Bro
C 206850	Back Complete-F Seat-Pass-LHD-Comb Trim	171-173 Bro
C 206851	Back Complete-F Seat-Pass-RHD-Comb Trim	171-173 Bro
C 206856	Back Complete-F Seat-Drivers-LHD-Comb Trim	172-174 Bro
C 206857	Back Complete-F Seat-Drivers-RHD-Comb Trim	172-174 Bro
C 206858	Back Complete-F Seat-Pass-LHD-Comb Trim	172-174 Bro
C 206859	Back Complete-F Seat-Pass-RHD-Comb Trim	172-174 Bro
C 206860	Back Complete-F Seat-Drivers-LHD-Comb Trim	171-173 ClubCpe
C 206861	Back Complete-F Seat-Drivers-RHD-Comb Trim	171-173 ClubCpe
C 206862	Back Complete-F Seat-Pass-LHD-Comb Trim	171-173 ClubCpe
C 206863	Back Complete-F Seat-Pass-RHD-Comb Trim	171-173 ClubCpe
C 206868	Back Complete-F Seat-Drivers-LHD-Comb Trim	172-174 ClubCpe
C 206869	Back Complete-F Seat-Drivers-RHD-Comb Trim	172-174 ClubCpe
C 206870	Back Complete-F Seat-Pass-LHD-Comb Trim	172-174 ClubCpe
C 206871	Back Complete-F Seat-Pass-RHD-Comb Trim	172-174 ClubCpe
C 206892	Cushion Complete-F Seat-Std-Comb Trim	171-173 Bro-ClubCpe
C 206893	Cushion Complete-F Seat-Airfoam-Comb Trim	171-173 Bro-ClubCpe
C 206894	Cushion Complete-F Seat-Std-Comb Trim	171-173 Sed-3Cpe
C 206895	Cushion Complete-F Seat-Airfoam-Comb Trim	171-173 Sed-3Cpe
C 206896	Cushion Complete-F Seat-Comb Trim	172-174 Bro-ClubCpe
C 206897	Cushion Complete-F Seat-Comb Trim	172-174 Sed-3Cpe
C 206902	Back Complete-R Seat-Comb Trim	171-173 Bro-Sed
C 206904	Back Complete-11 Seat-Comb Trim	171-173 ClubCpe
C 206910	Back Complete-11 Seat-Comb Trim	172-174 Bro
C 206913	Back Complete-R Seat-Comb Trim	172-174 ClubCpe
C 206917	Cushion Complete-R Seat-Std-Comb Trim	171-173 Bro-Sed
C 206918	Cushion Complete-11 Seat-Airfoam-Comb Trim	171-173 Bro-Sed
C 206920	Cushion Complete-R Seat-Std-Comb Trim	171-173 ClubCpe
C 206921	Cushion Complete-R Seat-Airfoam-Comb Trim	171-173 ClubCpe
C 206923	Cushion Complete-ft Seat-Comb Trim	172-174 Bro-Sed
C 206925	Cushion Complete-R Seat-Comb Trim	172-174 ClubCpe
C 206928	Arm Rest Assy-RH-Quarter-Comb Trim	171-173 Bro-Sed
C 206929	Arm Rest Assy-LH-Quarter-Comb Trim	171-173 Bro-Sed
C 206930	Trim Assy-Qtr Arm Rest-RH-Comb Trim	171-173 Bro-Sed
C 206931	Trim Assy-Qtr Arm Rest-LB-Comb Trim	171-173 Bro-Sed
C 206940	Panel Assy-Underbody	178 Station
206951	Bumper Impact Bar-Front (Use 1-206704 & 2 each 210669-170479-71521-71591)	1946-1947 All
C 206952	Frame Bar Assy-Front Bumper-RH	1946-1947 All exc Cab-CabPu
C 206953	Frame Bar Assy-Front Bumper-LH	1946-1947 All exc Cab-CabPu
C 206961	Bumper Impact Bar-Rear	51 thru 54,171 thru 174,178 Station,1940-1941
C 206962	Frame Bar Assy-Rear Bumper-RH	51 thru 54,171 thru 174,178 Station
C 206963	Feame Bar Assy-Rear Bumper-LH	51 thru 54,171 thru 174,178 Station
*HS 206964	Sponge-Car Washing-Medium Size	
*HS 206965	Sprong-Car Washing-Large Size	
BO 206973	Converter Assy-Short Wave-Radio	1947 All
BO 206974	Condenser-Short Wave Converter Gen-Radio	1947 All
BO 206975	Bonding Cable-Short Wave Converter-Radio	1947 All
BO 206976	Suppressor-Spark Plug-Radio Short Wave Cony	1947 thru 1950 All
BO 206977	Bolt-Short Wave Converter-Radio	1947 All
BO 206978	Washer-Short Wave Converter-Radio	1947 All
C 206980	Cross Bar-F License Plate Guard-Lower	1946-1947 All
BO 2069p6	Fusetron-Radio-10 Amp	1947 All
BO 206994	Foot Switch & Muter Assy-Radio-LHD	1946-1947 All
BO 206995	Foot Switch & Muter Assy-Radio-RHD	1947 All
BO 206996	Tone Control,Volume Control & Switch Assy	1946-1947 All
BO 206997	Socket-Radio Foot Switch Cable Plug	1946-1947 All
BO 207043	Weatherstrip-Door Opening-Upper	1946-1947 Bro-3Cpe-ClubCpe
BO 207044	Weatherstrip-Door Opening-Upper	1946-1947 Sed
BO 207045	Weatherstrip-Door Opening-Upper	1946-1947 Cab-CabPu
BZ 207046	Shim-F Splash Apron to Frame Bar	1946-1947 All
207055	Assist Strap Assy-Russet Leather-Lac Brkt (Usc 207130)	20 thru 27 Sed-2Sed-ClubCpe
BO 207056	Assist Strap Assy-Maroon Leather-Lac Brkt	20 thru 27 Sed-2Sed-ClubCpe
207059	Brkt-Robe Hanger (Use 149069)	20 thru 27 Sed
BO 207071	Bracket-Assist Strap	1942 All
BO 207075	Binding-Wire on-Maroon	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
M 207093	Imitation Leather-Sidewall-Maroon	
M 207098 Yd	Imitation Leather-Brown	
M 207100 Yd	Seat Cloth-Boucle	
M 207101 Yd	Sidewall Clock-Boucle	
M 207102 Yd	Seat Cloth-Brown Shadow Stripe	
M 207103 Yd	Sidewall Cloth-Brown Plain	
BO 207105	Robe Hanger Assy-Brown Cloth	20P 5Sed
BO 207106	Assist Strap Assy-Brown Cloth	20-21 Sed-2Sed-ClubCpe
M 207110 Yd	Seat Cloth-Brown Three Tone Cord	
M 207112 Sq ft	Seat Leather-Russet	
M 207113	Imitation L6ather-Sidewall-Russet	
M 207115 Yd	Imitation Leather-Headlining-Russet	
M 207118 Yd	Sidewall Cloth-Brown	
M 207120 Yd	Seat Cloth-Brown Bedford Cord	
M 207124 Yd	Imitation Leather-Russet	
BO 207126	Assist Strap Assy-Brown Cloth	22-24 Sed-2Sed-ClubCpe
BO 207127	Robe Hanger Assy-Brown Cloth	22-24 Sed,51-53-171-173 Sed
BO 207128	Robe Hanger Assy-Brown Cloth	22-24 2Sed
BO 207129	Robe Hanger Assy-Russet Leather	22-24 2Sed
BO 207130	Assist Strap Assy-Russet Leather	1942 Sed-2Sed-ClubCpe
BO 207134	Visor Assy-Swivel Type-Cloth Trim	51-171 exc CvBro,53-173
BO 207136	Visor Assy-Swivel Type-Cloth Trim	51-171 exc CvBro,53-173
C 207143	Trim Panel & Silencer Assy-Dash-Riisset	20P,20T,21 thru 27
C 207144	Trim Panel & Silencer Assy-Dash-Gray	20P thru 27 exc Station
C 207147	Silencer-Dash-Outer Center	1942-1946-1947 All
C 207148	Silencer-Dash-Outer Ends	1942-1946-1947 All
C 207150	Trim Panel Assy-Cowl-RH-LHD-Russet	20P,20T,21 thru 27
C 207151	Trim Panel Assy-Cowl-RH-LHD-Gray	20-28 Cab-CabPu,20P,21 thru 27 exc Station
C 207152	Trim Panel Assy-Cowl-RH-LHD-Green	20P,21 thru 27 exc Station
C 207156	Trim Panel Assy-Cowl-LH-LHD-Gray	20P,21 thru 27 exc Station,20-28 Cab-CabPu
C 207157	Trim Panel Assy-Cowl-LH-LHD-Green	20P,21 thru 27 exc Station
C 207162	Trim Panel Assy-Cowl-RH-RHD-Green	20P,21 thru 27 exc Station
C 207166	Trim Panel-Cowl-LH-RHD-Gray	20P,21 thru 27 exc Station,20-28 Cab-CabPu
C 207167	Trim Panel-Cowl-LH-RHD-Green	20P,21 thru 27 exc Station
BO 207168	Assist Strap Assy-Brown Cloth-Lac Brkt	20P-21 Sed-2Sed-ClubCpe
207169	Assist Strap Assy-Brown Cloth-Lac Brkt(Use 207126)	22-24 Sed-2Sed-ClubCpe
M 207170 Yd	Seat Cloth-Brown Broadbrook Two Tone Cord	
M 207171 Yd	Seat Cloth-Brown Broadbrook Plain Cord	
BO 207176	Assist Strap Assy-Brown Cloth	25 ClubCpe-2Sed,27 5Sed
BO 207177	Robe Hanger Assy-Brown Cloth	27 5Sed
BO 207177	Robe Hanger Assy-Russet Leather	20P-21-22-24-27 5Sed
BO 207181	Assist Strap Assy-Cloth	20T 5Sed
BO 207182	Assist Strap Assy-Leather Or Mohair Trim	20T 5Sed
BO 207186	Robe Hanger Assy-Brown-Lac Brkt	20P Sed
BO 207187	Robe Hanger Assy-Brown-Lac Brkt	21 Sed
BO 207188	Robe Hanger Assy-Brown-Lac Brkt	22-24 Sed
BO 207189	Robe Hanger Assy-Brown-Lac Brkt	22-24 2Sed
BO 207190	Assist Strap Assy-Lac Brkt	20T Sod exc Mohair
BO 207191	Assist Strap Assy-Lac Brkt	20T Sed Mohair
BO 207192	Robe Hanger Assy-Brown-Lac Brkt	20-21-22-24 Leather Sed,27
BO 207193	Robe Hanger Assy-Russet Leather-Lac Brkt	22-24 2Sed
207196	Assist Strap Assy-Brown-Lac Brkt (Use 207176)	25,27
*HS 207197 Pkg	Shampoo-Hurricane Auto	All
*HS 207198	Shampoo-Hurricane Auto-13 oz can	All
*HS 207199	Shampoo-Hurricane Auto-4 lb can	All
M 207202 Yd	Seat Cloth-Blue Gray Shadow Stripe	
M 207203 Yd	Sidewall Cloth-Blue Gray Plain	
BO 207205	Robe Hanger Assy-Blue Gray Cloth	20P 5Sed
207206	Assist Strap Assy (Use 209003)	20P-21 thru 27 Sed-2Sed-ClubCpe
M 207210 Yd	Seat Cloth-Blue Gray Three Tone Cord	
M 207212 Sq ft	Seat Leather-Blue	
M 207213	Imitation Leather-Sidewall-Blue	
M 207215 Yd	Imitation Leather-Headlining-Blue	
207217	Robe Hanger Assy-Blue Gray Cloth (Use 208602)	21 5Sed
M 207220 Yd	Seat Cloth-Blue Gray Bedford Cord	
M 207224 Yd	Imitation Leather-Blue	
BO 207226	Assist Strap Assy-Blue Gray Cloth	22-24 Sed-2Sed-ClubCpe
BO 207228	Robe Hanger Assy-Blue Gray Cloth	22-24 2Sed
BO 207229	Robe Hanger Assy-Blue Leather	22-24 2Sed
M 207233 Yd	Headlining Cloth-Blue Gray	
TC 207250 Yd	Top Material-Black	1946-1947 CvBro
BO 207268	Assist Strap Assy-Blue Gray-Lac Brkt	20 thru 27 Sed-2Sed-ClubCpe
207269	Assist Strap Assy-Blue Gray-Lac Brkt (Use 207226)	22-24 Sed-2Sed-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
M 207271	Seat Cloth-Blue Gray Plain Cord	27 5Sed
207276	Assist Strap Assy-Blue Gray Cloth Trim (Use 207296)	27 SSed
BO 207277	Robe Hanger Assy-Blue Gray Cloth Tri M	20P-21-22-24-27 5Sed
BO 207277	Robe Hanger Assy-Blue Leather Tri M	20P Sed
BO 207286	Robe Hanger Assy-Green-Lac Brkt	21 Sed
207287	Robe Hanger Assy-Blue-Lac Brkt (Use 208602)	22-24 Sed
BO 207288	Robe Hanger Assy-Blue-Lac Brkt	22-24 2Sed
BO 207289	Robe Hanger Assy-Blue-Lac Brkt	20 thru 27 Leather Sed
BO 207292	Robe Hanger Assy-Blue-Lac Brkt	22-24 2Sed
207293	Robe Hanger Assy-Blue-Lac Brkt (Use 207229)	25,27
BO 207296	Assist Strap Assy-Blue-Lac Brkt	1946 thru 1950 All
*HA 207299	Vanity Mirror Assy-Service	51 thru 54,171 thru 174
BO 207300	Pin-Rear Compt Door Hinge	1946-1947 All
BO 207301	Transformer-2nd I.F.-Radio	
M 207302	Seat Cloth-Green Shadow Stripe	
M 207303	Seat Cloth-Green Plain	20P 5Sed
BO 207305	Robe Hanger Assy-Green Cloth Trim	20P-21 Sed-2Sed-ClubCpe
BO 207306	Assist Strap Assy-Green Cloth Tri M	20P-21 thru 27 Sed-2Sed-ClubCpe
BO 207306	Assist Strap Assy-Green Leather Trim	
BO 207307	Carpet Binding	
M 207312	Seat Leather-Green	
M 207313	Imitation Leather-Green-Sidewall	
M 207314	Imitation Leather-Green Headlining	21 SSed
BO 207317	Robe Hanger Assy-Green Cloth Tri M	1942 Leather Trim
BO 207319	Yd Binding-Wire on-Green	
M 207320	Yd Seat Cloth-Bedford Cord-Green	
M 207321	Imitation Leather-Green	22-24 Sed-2Sed-ClubCpe
BO 207326	Assist Strap Assy-Green Cloth	22-24 5Sed
BO 207327	Robe Hanger Assy-Green Cloth	22-24 2Sed
BO 207328	Robe Hanger Assy-Green Cloth	22-24 2Sed
BO 207329	Robe Hanger Assy-Green Leather	
M 207333	Headlining Cloth-Green	20P-21 2Sed
C 207340	Trimboard Complete-Quarter-RH-Leather	20P-21 2Sed
C 207341	Trimboard Complete-Quarter-LH-Leather	22-24 2Sed
C 207342	Trimboard Complete-Quarter-RH-Leather	22-24 2Sed
C 207343	Trimboard Complete-Quarter-LH-Leather	20P-21 5Sed
C 207344	Trimboard Complete-Quarter-RH-Leather	20P-21 5Sed
C 207345	Trimboard Complete-Quarter-LB-Leather	22-24 5Sed
C 207346	Trimboard Complete-Quarter-RH-Leather	22-24 5Sed
C 207347	Trimboard Complete-Quarter-LH-Leather	27 5Sed
C 207348	Trimboard Complete-Quarter-RH-Leather	27 5Sed
C 207349	Trimboard Complete-Quarter-LH-Leather	1942 Sed-2Sed-UCo
C 207351	Boot Assy-Rr Seat Back Bottom	20P ClubCpe
C 207354	Trimboard Complete-Quarter-RH-Leather	20P ClubCpe
C 207355	Trimboard Complete-Quarter-LH-Leather	21 ClubCpe
C 207356	Trimboard Complete-Quarter-RH-Leather	21 ClubCpe
C 207357	Trimboard Complete-Quarter-LH-Leather	22-24-25 ClubCpe
C 207358	Trimboard Complete-Quarter-RH-Leather	22-24-25 ClubCpe
C 207359	Trimboard Complete-Quarter-LH-Leather	1942 Sed-2Sed-UCo
C 207366	Support-Sleeper Kit Mattress	1942 Sed-2Sed-UCo
BO 207367	Brkt-Rear Seat Back Support-for Sleeper Kit	20 thru 27 Sed-2Sed-ClubCpe
BO 207368	Assist Strap Assy-Green Cloth-Lac Brkt	22-24 Sed-2Sed-ClubCpe
BO 207369	Assist Strap Assy-Green Cloth-Lac Brkt	
M 207371	Seat Cloth-Green Plain Cord	25 ClubCpe,27 5Sed
BO 207376	Assist Strap Assy-Green Cloth	27 5Sed
BO 207377	Robe Hanger Assy-Green Cloth	20P-21-22-24-27 5Sed
BO 207377	Robe Hanger Assy-Green Leather	20T CvSed
C 207378	Trimboard Complete-Quarter-RH	20T CvSed
C 207379	Trimboard Complete-Quarter-LH	20P-21 CvSed
C 207380	Trimboard Complete-Quarter-RH	20P-21 CvSed
C 207381	Trimboard Complete-Quarter-LH	22-24 CvSed
C 207382	Trimboard Complete-Quarter-RH	22-24 CvSed
C 207383	Trimboard Complete-Quarter-LH	20P Sed
BO 207386	Robe Hanger Assy-Green-Lac Brkt	21 Sed
207387	Robe Hanger Assy-Green-Lac Brkt (Use 207317)	22-24 Sed
207388	Robe Hanger Assy-Green-Lac Brkt (Use 207327)	22-24 2Sed
BO 207389	Robe Hanger Assy-Green-Lac Brkt	20-21-22-24 Leather Sed,27
BO 207392	Robe Hanger Assy-Green-Lac Brkt	22-24 Leather 2Sed
207393	Robe Hanger Assy-Green-Lac Brkt (Use 207329)	20 UCpe-3Cpe,21 3Cpe Mohair
C 207394	Trimboard Complete-Quarter-RH-Leather	20 UCpe-3Cpe,21 3Cpe Mohair
C 207395	Trimboard Complete.-Quarter-LH-Leather	25,27
BO 207396	Assist Strap Assy-Green-Lac Brkt	20T,20P,21 thru 27
BO 207483	Clip-Cowl Trim Panel-Russet	20P-21 2 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 207489	Trimboard Complete-Quarter-LH-Mohair	20P-21 2Sed
BO 207490	Clip-Trimboard Retaining	1946-1947 Bro-Sed-3Cpe-ClubCpe
207491	Clip-Trimboard Retaining (Use 210829)	1942 All,51 thru 54,171 thru 174,1948
C 207492	Trimboard Complete-Quarter-RH-Mohair	20P-21 ClubCpe
C 207493	Trimboard Complete-Quarter-LH-Mohair	20P-21 ClubCpe
C 207494	Trimboard Complete-Quarter-RH-Mohair	20T UCo-2Sed
C 207495	Trimboard Complete-Quarter-LH-Mohair	20T UCo-2Sed
C 207496	Trimboard Complete-Quarter-RH-Mohair	20T 5Sed
C 207497	Trimboard Complete-Quarter-LH-Mohair	20T 5Sed
C 207498	Trimboard Complete-Quarter-RH-Mohair	20T ClubCpe
C 207499	Trimboard Complete-Quarter-LH-Mohair	20T ClubCpe
BO 207501	Robe Hanger Assy-Maroon-Lac Brkt	20P-21-22-24-27 Leather-Sed
BO 207503	Robe Hanger Assy-Maroon-Lac Brkt	22-24 Leather 2Sed
C 207504	Trimboard Complete-Quarter-RH-Cloth	20 UCpe-3Cpe,21 3Cpe,Mohair
C 207505	Trimboard Complete-Quarter-LH-Cloth	20 UCpe-3Cpe,21 3Cpe,Mohair
C 207506	Trim Assy-Rear Seat Back Compt Panel-RH	1942 Sed-2Sed-UCo
C 207512	Arm Rest Assy-RH-Quarter-Cloth exc Mohair	20T 2Sed-Sed-UCo
C 207513	Arm Rest Assy-LH-Quarter-Cloth exc Mohair	20T 2Sed-Sed-UCo
C 207521	Trimboard & Trim Assy-Compt Shelf-Rear-Leather	1942 ClubCpe-3Cpe
C 207536	Trim Assy-Qtr Arm Rest-RH-Cloth	22-24 Sed-2Sed
C 207537	Trim Assy-Qtr Arm Rest-LH-Cloth	22-24 Sed-2Sed
C 207540	Covering Assy-Rear Compt Floor	20-21 Sed-2Sed,51-53-171-173 Bro-Sed
C 207543	Molding-F Seat Back Panel-Lower	27 5Sed
BO 207546	Headlining Assy-Cloth	20-21-22-24 2Sed-UCo,1946-1947 Bro
BO 207547	Headlining Assy-Leather	20P-21-22-24 2Sed
BO 207548	Headlining Assy-Cloth	20T Sed
BO 207549	Headlining Assy-Cloth	20P-21-22-24 Sed,1946-1947 Sed
BO 207550	Headlining Assy-Leather	20P-21-22-24 Sed
BO 207551	Headlining Assy-Cloth	27
BO 207552	Headlining Assy-Leather	27
BO 207553	Headlining Assy-Cloth	20-21-22-24 3Cpe-UCpe,1946-1947 3Cpe
BO 207554	Headlining Assy-Leather	20P-21-22-24 3Cpe
BO 207555	Headlining Assy-Cloth	20 ClubCpe,51-53-171-173 ClubCpe
BO 207556	Headlining Assy-Leather	20P ClubCpe
BO 207557	Headlining Assy-Cloth	21-22-24-25 ClubCpe,52-54-172-174 ClubCpe
BO 207558	Headlining Assy-Leather	21-22-24-25 ClubCpe
C 207560	Cushion Frame & Back Complete-F Seat-RHD-Cloth-Exc Mohair	20T 5Sed
C 207561	Cushion-Frame & Back Complete-F Seat-LHD-Cloth-Exc Mohair	20T 3Cpe
C 207562	Cushion-Frame & Back Complete-F Seat-RHD-Cloth-Exc Mohair	20T 3Cpe
C 207565	Cushion Frame & Back Complete-F Seat-Cloth-Exc Mohair	20T ClubCpe
C 207569	Back Complete-Front Seat-Drivers-LHD-Cloth	20T-20P 2Sed,21 2Sed Mohair,51-53 Bro Comb Trim
C 207570	Back Complete-Front Seat-Drivers-RHD-Cloth	20T-20P 2Sed,21 2Sed Mohair,51-53 Bro Comb Trim
C 207571	Back Complete-Front Seat-Passenger-LHD-Cloth	20T-20P 2Sed,21 2Sed Mohair,51-53 Bro Comb Trim
C 207572	Back Complete-F Seat-Passenger-RHD-Cloth	20T-20P 2Sed,21 2Sed Mohair,51-53 Bro Comb Trim
C 207573	Back Complete-F Seat-Driver-LHD-Cloth	20T-20P ClubCpe,21 ClubCpe Mohair,51-53 ClubCpe Comb Trim
C 207574	Back Complete-F Seat-Driver-RHD-Cloth	20T-20P ClubCpe,21 ClubCpe Mohair,51-53 ClubCpe Comb Trim
C 207575	Back Complete-F Seat-Passenger-LHD-Cloth	20T-20P ClubCpe,21 ClubCpe Mohair,51-53 ClubCpe Comb Trim
C 207576	Back Complete-F Seat-Passenger-RHD-Cloth	20T-20P ClubCpe,21 ClubCpe Mohair,51-53 ClubCpe Comb Trim
C 207577	Trim Assy-F Seat Back-Cloth Exc Mohair	20T 5Sed-3Cpe
C 207578	Trim Assy-F Seat Back-RH-Cloth	20T 2Sed-UCpe,20P-21 2Sed
C 207579	Trim Assy-F Seat Back-LH-Cloth	20T 2Sed-UCpe,20P-21 2Sed
C 207580	Trim Assy-F Seat Back-RH-Cloth	20T-20P-21 ClubCpe
C 207581	Trim Assy-F Seat Back-LH-Cloth	20T-20P-21 ClubCpe
C 207582	Back Complete-Front Seat-RH-Cloth	20 UCpe
C 207583	Back Complete-Front Seat-LH-Cloth	20 UCpe
C 207584	Back Panel & Riser Trim Assy-F Seat-Cloth exc Mohair	20T 5Sed
C 207585	Back Panel & Riser Trim Assy-F Seat-Cloth exc Mohair	20T 3Cpe
C 207586	Back Panel Trim-F Seat-RH-Cloth	20T-20P-21, thru 25 ClubCpe-2Sed,51-53 Bro-ClubCpe
C 207587	Back Panel Trim-F Seat-LH-Cloth	20T-20P-21 thru 25 ClubCpe-2Sed,51-53 Bro-ClubCpe
C 207588	Back Panel Trim Assy-F Seat-RH-Cloth	20T UCpe
C 207589	Back Panel Trim Assy-F Seat-LH-Cloth	20T UCpe
C 207590	Cushion Complete-F Seat-Cloth-Standard	20T Sed-3Cpe
C 207591	Trim Assy-F Seat Cushion-Cloth-Standard	20T Sed-3Cpe
C 207592	Cushion Complete-F Seat-Cloth-Airfoam	20T Sed-3Cpe
C 207593	Trim Assy-F Seat Cushion-Airfoam	20T Sed-3Cpe
C 207594	Cushion Complete-F Seat-Cloth-Standard	20T UCpe-ClubCpe-2Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 207595	Trim Assy-F Seat Cushion-Cloth-Standard	20T UCpe-ClubCpe-2Sed
C 207596	Cushion Complete-F Seat-Cloth-Airfoam	20T UCpe-ClubCpe-2Sed
C 207597	Trim Assy-F Seat Cushion-Cloth-Airfoam	20T UCpe-ClubCpe-2Sed
C 207601	Back Complete-Rear Seat-Cloth	20T Sed-2Sed
C 207602	Trim Assy-Rear Seat Back-Cloth	20T Sed-2Sed-UCo
C 207603	Cushion Complete-Rear Seat-Cloth-Standard	20T Sed-2Sed
C 207604	Trim Assy-Rear Seat Cushion-Cloth-Standard	20T Sed-2Sed
C 207605	Cushion Complete-Rear Seat-Cloth-Airfoam	20T Sed-2Sed
C 207606	Trim Assy-Rear Seat Cushion-Cloth-Airfoam	20T Scd-2Sed
C 207607	Back Complete-Rear Seat-Cloth	20 UCo
C 207608	Cushion Complete-Rear Seat-Cloth	20 UCo
C 207609	Trim Assy-Rear Seat Cushion	20 UCo
C 207611	Trim Assy-Rear Seat Back-Cloth	20T ClubCpe
C 207612	Cushion Complete-Rear Seat-Cloth-Standard	20T ClubCpe
C 207613	Trim Assy-Rear Seat Cushion-Cloth-Standard	20T ClubCpe
C 207614	Cushion Complete-Rear Seat-Cloth-Airfoam	20T ClubCpe
C 207615	Trim Assy-Rear Seat Cushion-Cloth-Airfoam	20T ClubCpe
C 207618	Airfoam Pad-F Seat Cushion	21 5Sed-3Cpe-Station,1946-1947, Sed-3Cpe-Cab-CabPu-178 Station
C 207619	Airfoam Pad-F Seat Cushion	21 ClubCpe-2Sed-20-21 CvSed,1946-1947 Bro-ClubCpe,51 CvBro
C 207620	Airfoam Pad-Rear Seat Cushion	21 Sed-2Sed,1946-1947 Bro-Sed,1948 thru 1950 CvBro
C 207621	Airfoam Pad-Rear Seat Cushion	21 Sed-2Sed,20P CvSed,1946-1947 ClubCpe,51-171 CvBro
C 207623	Airfoam Pad-F Seat Cushion-Cloth Trim	20 UCpe-ClubCpe-2Sed
C 207625	Airfoam Pad-Rear Seat Cushion-Cloth Trim	20 ClubCpe
C 207632	Retainer & Trim Assy-Rear Seat Cushion-Cloth	20T Sed-2Sed
C 207633	Trim Assy-Rear Seat Cushion Retainer-Cloth	20T Sed-2Sed-UCo
C 207634	Retainer & Trim Assy-Rear Seat Cushion-Cloth	20T ClubCpe
C 207635	Trim Assy-Rear Seat Cushion Retainer-Cloth	20T ClubCpe
C 207636	Retainer and Trim Assy-Rear Seat Cushion-Cloth	20 UCp
C 207638	Frame & Back Complete-F Seat Cushion-RHD-Cloth exc Mohair	20P 5Sed
C 207640	Frame & Back Complete-F Seat Cushion-RILD-Cloth	20P 3Cpe
C 207641	Trim Assy-F Seat Back Panel & Riser-Cloth exc Mohair	20P 5Sed
C 207642	Trim Assy-F Seat Back Panel & Riser-Cloth	20P-21-51-53-171-173 3Cpe
C 207644	Cushion Frame & Back Complete-F Seat-RHD-Cloth	20P 2Sed
C 207645	Cushion Frame & Back Complete-F Seat-LHD-Cloth	20P ClubCpe
C 207646	Cushion Frame & Back Complete-F Seat-RHD-Cloth	20P ClubCpe
C 207647	Trim Assy-F Seat Back-Cloth	20-21 Sed-3Cpe
C 207648	Cushion Complete-F Seat	20 5Sed-3Cpe
C 207649	Trim Assy-F Seat Cushion-Cloth-Std	20 5Sed-3Cpe
C 207650	Cushion Complete-F Seat-Cloth-Airfoam	20-21 5Sed-3Cpe
C 207651	Trim Assy-F Seat Cushion-Cloth-Airfoam	20-21 5Sed-3Cpe
C 207652	Cushion Complete-F Seat-Cloth-Std	20 2Sed-ClubCpe
C 207653	Trim Assy-F Seat Cushion-Cloth-Std	20-2Sed-ClubCpe
C 207654	Cushion Complete-F Seat-Cloth-Airfoam	20 2Sed-ClubCpe
C 207655	Trim Assy-F Seat Cushion-Cloth-Airfoam	20 Sed-ClubCpe
C 207656	Back Complete-Rear Seat-Cloth	20P 2Sed-5Sed,20T-21 2Sed-5Sed Mohair
C 207657	Trim Assy-Rear Seat Back-Cloth	20P 2Sed-5Sed,20T-21 2Sed-5Sed Mohair
C 207658	Cushion Complete-Rear Seat-Cloth-Std	20P 2Sed-5Sed,20T-2Sed-5Sed Mohair
C 207659	Trim Assy-Rear Seat Cushion-Std	20P 2Sed-5Sed,20T-2Sed-5Sed Mohair
C 207660	Molding-Quarter Trim Panel-RH	20T-25 ClubCpe,20T CvSed
C 207660	Molding-Door Trim Panel-RH	20T,27,20-21 Leather Trim 5Sed
C 207661	Molding-Quarter Trim Panel-LH	20T-25 ClubCpe,20T CvSed
C 207661	Molding-Door Trim Panel-LB	20T,27 20-21 Leather Trim 5Sed
C 207662	Trimboard Complete-F Door-RH-Cloth	20T 5Sed
C 207663	Trimboard Complete-F Door-LH-Cloth	20T 5Sed
C 207664	Trimboard Complete-Rear Door-RH-Cloth	20T 5Sed
C 207665	Trimboard Complete-Rear Door-LH-Cloth	20T 5Sed
C 207666	Cushion Complete-Rear Seat-Cloth-Airfoam	20P Sed-2Sed,20T-21 2Sed-5Sed Mohair
C 207667	Trim Assy-Rear Cushion-Cloth-Airfoam	20P Sed-2Sed,20T-21 2Sed-5Sed Mohair
C 207668	Retainer & Trim Assy-Rear Seat Cushion-Cloth	20P Sed-2Sed 1946-1947 Bro-Sed Comb Trim
C 207669	Trim Assy-Rear Seat Cushion Retainer-Cloth	20P Sed-2Sed 1946-1947 Bro-Sed Comb Trim
C 207670	Back Complete-Rear Seat-Cloth	20P ClubCpe
C 207671	Trim Assy-Rear Seat Back-Cloth	20P ClubCpe
C 207672	Cushion Complete-Rear Seat-Cloth-Std	20P ClubCpe,20T ClubCpe Mohair
C 207673	Trim Assy-Rear Seat Cushion-Std	20P ClubCpe,20T ClubCpe Mohair
C 207674	Cushion Complete-Rear Seat-Cloth-Airfoam	20P ClubCpe,20T-21 ClubCpe Mohair
C 207675	Trim Assy-Rear Seat Cushion Cloth-Airfoam	20P ClubCpe,20T-21 ClubCpe Mohair
C 207676	Retainer & Trim Assy-Rear Seat Cushion-Cloth	20P ClubCpe,1946-1947 ClubCpe Comb Trim
C 207677	Trim Assy-Rear Seat Cushion Retainer-Cloth	20P ClubCpe,1946-1947 ClubCpe
C 207678	Molding-F Door Trim Panel-RH	20T exc Sed,25 ClubCpe,27,20-21 Cpe-2Sed Leather
C 207678	Molding-Qtr Trim Panel-RH	20T UCo-2Sed-CvSed,20P-21 2Sed
C 207679	Molding-F Door Trim Panel-LH	20T exc Sed,25 ClubCpe,27,20-21 Cpe-2Sed Leather

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 207680	Molding-Qtr Trim Panel-RH	20P ClubCpe-2Sed-3Cpe
C 207680	Molding-F Door Trim Panel-RH-Mohair	20T-21 2Sed-Cpe-UCo
C 207681	Molding-Qtr Trim Panel-LH	20P ClubCpe-2Sed-3Cpe
C 207681	Molding-F Door Trim Panel-LH-Mohair	20T-21 2Sed-Cpe-UCo
C 207684	Molding-Rear Door Trim Panel-RH	20P 5Sed,20T-21 Sed Mohair
207685	Molding-Rear Door Trim Panel-LH	20P 5Sed,20T-21 Sed Mohair
207686	Molding-Qtr Trim Panel-RH (Use 207678)	20T UCo-2Sed,20T-21 ClubCpe-Mohair
207687	Molding-Qtr Trim Panel-LH (Use 207679)	20T UCo-2Sed,20T-21 ClubCpe-Mohair
C 207689	Molding-Qtr Trim Panel-LH	20P 2Sed,20T-21 UCo-2Sed-Mohair
C 207690	Molding-Qtr Trim Panel-RH	21 2Sed,1946-1947 Bro
C 207691	Molding-Qtr Trim Panel-LH	21 2Sed,1946-1947 Bro
C 207692	Molding-F Door Trim Panel-RH	21 2Sed-3Cpe-ClubCpe,1946-1947 Bro-3Cpe-ClubCpe
C 207693	Molding-F Door Trim Panel-LH	21 2Sed-3Cpe-ClubCpe,1946-1947 Bro-3Cpe-ClubCpe
C 207694	Molding-F Door Trim Panel-RH	21 5Sed,1946-1947 Sed
C 207695	Molding-F Door Trim Panel-LH	21 5Sed,1946-1947 Sed
C 207696	Molding-Rear Door Trim Panel-RH	21 5Sed,1946-1947 Sed
C 207696	Molding-Quarter Trim Panel-RH	21 ClubCpe,1946-1947 ClubCpe
C 207697	Molding-Rear Door Trim Panel-LH	21 5Sed,1946-1947 Sed
C 207697	Molding-Quarter Trim Panel-LH	21 ClubCpe,1946 ClubCpe
C 207698	Trimboard Complete-F Door-RH-Cloth exc Mohair	20T exc Sed
C 207699	Trimboard Complete-F Door-LH-Cloth exc Mohair	20T exc Sed
C 207700	Trimboard Complete-F Door-RH-Cloth exc Mohair	20P 2Sed-3Cpe-ClubCpe
C 207701	Trimboard Complete-F Door-LH-Cloth exc Mohair	20P 2Sed-3Cpe-ClubCpe
C 207702	Trimboard Complete-F Door-RH-Cloth exc Mohair	20P 5Sed
C 207703	Trimboard Complete-F Door-LH-Cloth exc Mohair	20P 5Sed
C 207704	Trimboard Complete-Rear Door-RH-Cloth exc Mohair	20P 5Sed
C 207705	Trimboard Complete-Rear Door-LH-Cloth exc Mohair	20P 5Sed
C 207706	Trimboard Complete-F Door-RH-Cloth exc Mohair	21 2Sed-3Cpe-ClubCpe
C 207707	Trimboard Complete-F Door-LH-Cloth exc Mohair	21 2Sed-3Cpe-ClubCpe
C 207708	Trimboard Complete-F Door-RH-Cloth exc Mohair	21 5Sed
C 207709	Trimboard Complete-F Door-LH-Cloth exc Mohair	21 5Sed
C 207710	Trimboard Complete-Rear Door-RH-Cloth exc Mohair	21 5Sed
C 207711	Trimboard Complete-Rear Door-LH-Cloth exc Mohair	21 5Sed
C 207712	Trimboard Complete-F Door-RH-Cloth	22-24 2Sed-3Cpe-ClubCpe
C 207713	Trimboard Complete-F Door-LH-Cloth	22-24 2Sed-3Cpe-ClubCpe
C 207714	Trimboard Complete-F Door-RH-Cloth	22-24 5Sed
C 207715	Trimboard Complete-F Door-LH-Cloth	22-24 5Sed
C 207716	Trimboard Complete-Rear Door-RH-Cloth	22-24 5Sed
C 207717	Trimboard Complete-Rear Door-LH-Cloth	22-24 5Sed
C 207718	Trimboard Complete-F Door-RH-Cloth	25 ClubCpe,27 Sed
C 207719	Trimboard Complete-F Door-LH-Cloth	25 ClubCpe,27 Sed
C 207721	Trim Panel-Rear Compt Shelf Bottom-Blue Gray	20P-21-22-24 3Cpe
207727	Mat-Rear Compt Floor (Use 209608)	22 thru 27 5Sed-2Sed
207728	Mat-Rear Compt Floor (Use 209609)	22-24-25-52-54 3Cpe-ClubCpe
207729	Mat-Rear Compt Floor (Use 209610)	22-24-25-54 CvBro,27 7Sed
C 207731	Trim Panel-Rear Compt Shelf Bottom-Blue Gray	20P-21-22-24-25 ClubCpe
C 207736	Trimboard Complete-Rear Door-RH-Cloth	27 Sed
C 207737	Trimboard Complete-Rear Door-LH-Cloth	27 Sed
C 207738	Trimboard Complete-F Door-RH-Mohair	20T-20P-21 2Sed-3Cpe-ClubCpe
C 207739	Trimboard Complete-F Door-LH-Mohair	20T-20P-21 2Sed-3Cpe-ClubCpe
C 207740	Trimboard Complete-F Door-RH-Mohair	20T-20P-21 5Sed
C 207741	Trimboard Complete-F Door-LH-Mohair	20T-20P-21 5Sed
C 207742	Trimboard Complete-Rear Door-RH-Mohair	20T-20P-21 5Sed
C 207743	Trimboard Complete-Rear Door-LH-Mohair	20T-20P-21 5Sed
C 207750	Trimboard Complete-RH-Quarter-Cloth exc Mohair	20T 2Sed-UCo
C 207751	Trimboard Complete-LH-Quarter-Cloth exc Mohair	20T 2Sed-UCo
C 207754	Trimboard Complete-RH-Quarter-Cloth exc Mohair	20T Sed
C 207755	Trimboard Complete-LH-Quarter-Cloth exc Mohair	20T Sed
C 207764	Trim Panel Assy-Rear Compartment Side-RH	1942 5Sed-2Sed,1946-1947 Sed-Bro
C 207765	Trim Panel Assy-Rear Compartment Side-LH	1942 5Sed-2Sed,1946-1947 Sed-Bro
C 207766	Trimboard-Rear Seat Back Spring	20 UCo
C 207767	Trimboard-Rear Seat Back Spring	20-21 Sed-2Sed-1946-4947 Bro-51-53-171-173 Sed
C 207770	Trim Panel-Rear Seat Back Shelf-Russet	20P-21 thru 27 2Sed-5Sed
C 207771	Trim Panel-Rear Seat Back Shelf-Blue Gray	20P-21 thru 27 2Sed-5Sed
*HS 207774	W/S Cleaner Arms & Blade Kit	1946-1947 All
C 207778	Trimboard and Trim Assy-Front Pillar-Cloth	1942 exc CvSed-Station
C 207779	Trimboard and Trim Assy-Front Pillar-Cloth	1942 exc CvSed-Station
C 207786	Drain Trough Assy-Qtr Window-RH	20 thru 27 Sed,1946-1947 Sed
C 207787	Drain Trough Assy-Qtr Window-LH	20 thru 27 Sed,1946-1947 Sed
C 207788	Drain Trough Assy-Qtr Window-RH	20 thru 24 UCo-2Sed,1946-1947 Bro
C 207789	Drain Trough Assy-Qtr Window-LH	20 thru 24 UCo-2Sed,1946-1947 Bro
C 207794	Trimboard Complete-Quarter-RH-Cloth	20P 2Sed
C 207795	Trimboard Complete-Quarter-LH-Cloth	20P 2Sed
C 207796	Trimboard Complete-Quarter-RH-Cloth	20P 5Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	207797 Trimboard Complete-Quarter-LH-Cloth	20P 5Sed
C	207798 Trimboard Complete-Quarter-RH-Cloth	20P ClubCpe
C	207799 Trimboard Complete-Quarter-LH-Cloth	20P ClubCpe
C	207800 Trimboard Complete-Quarter-RH-Cloth	21 2Sed
C	207801 Trimboard Complete-Quarter-LH-Cloth	21 2Sed
C	207802 Trimboard Complete-Quarter-RH-Cloth	21 2Sed
C	207803 Trimboard Complete-Quarter-LH-Cloth	21 5Sed
C	207804 Trimboard Complete-Quarter-RH-Cloth	21 ClubCpe
C	207805 Trimboard Complete-Quarter-LH-Cloth	21 ClubCpe
C	207806 Trimboard Complete-Quarter-RH-Cloth	22-24 2Sed
C	207807 Trimboard Complete-Quarter-LH-Cloth	22-24 2Sed
C	207808 Trimboard Complete-Quarter-RH-Cloth	22-24 2Sed
C	207809 Trimboard Complete-Quarter-LH-Cloth	22-24 5Sed
C	207810 Trimboard Complete-Quarter-RH-Cloth	22-24 ClubCpe
C	207811 Trimboard Complete-Quarter-LH-Cloth	22-24 ClubCpe
C	207812 Trimboard Complete-Quarter-RH-Cloth	25 ClubCpe
C	207813 Trimboard Complete-Quarter-LH-Cloth	26 ClubCpe
C	207814 Trimboard Complete-Quarter-RH-Cloth	27
C	207815 Trimboard Complete-Quarter-LH-Cloth	27
C	207816 Arm Rest Assy-Quarter-RH-Cloth	20P Sed-2Sed
C	207817 Arm Rest Assy-Quarter-LH-Cloth	20P Sed-2Sed
C	207818 Trim Assy-Quarter Arm Rest-RH-Cloth	20P Sed-2Sed
C	207819 Trim Assy-Quarter Arm Rest-LH-Cloth	20P Sed-2Sed
C	207820 Arm Rest Assy-Quarter-RH-Cloth exc Mohair	21 Sed-2Sed
C	207821 Arm Rest Assy-Quarter-LH-ClothExc Mohair	21 Sed-2Sed
C	207822 Trim Assy-Quarter Arm Rest-RH	21 Sed-2Sed
C	207823 Trim Assy-Quarter Arm Rest-LH	21 Sed-2Sed
C	207824 Arm Rest Assy-Quarter-RH-Cloth	22-24 Sed-2Sed,27
C	207825 Arm Rest Assy-Quarter-LH-Cloth	22-24 Sed-2Sed,27
C	207826 Trim Assy Quarter Arm Rest-RH-Cloth	22-24 Sed-2Sed,27
C	207827 Trim Assy-Quarter Arm Rcst-LH-Cloth	22-24 Sed-2Sed,27
C	207829 Trimboard Assy-Rear Seat Back Spring	22-24 2Sed-5Sed,27
BO	207877 Sensitivity Control-Radio	1946-1947 All
BO	207879 Molding-Qtr Trim Panel	27
C	207880 Molding-F Door Trim Panel-#1-2-5	25 ClubCpe,27
BO	207881 Molding-F Door Trim Panel-#3-4 Front	25 ClubCpe,27
BO	207882 Molding-Qtr Trim Panel-#4 Center	25 ClubCpe,27
BO	207883 Molding-Rear Door Trim Panel-#3-4 Center & Rear	27
BO	207883 Molding-F Door Trim Panel-#3-4 Rear	25 ClubCpe,27
BO	207884 Molding-Rear Door Trim Panel-#1-2-5	27
BO	207884 Molding-Qtr Trim Panel-#1	25 ClubCpe
C	207887 Molding-Qtr Trim Panel-LH	20P ClubCpe
BO	207888 Molding-Qtr Trim Panel-#2-3-4-5	25 ClubCpe
	207911 Mat & Pad Assy-F Floor-LHD-Black (Use 201134)	20-28 Cab-CabPu
	207912 Mat & Pad Assy-F Floor-RHD-Black (Use 208601)	20-28 Cab-CabPu
	207913 Mat & Pad Assy-F Floor-LHD-Tan (Use 201134)	20T,20Sp,20P,21
	207914 Mat & Pad Assy-F Floor-RHD-Tan (Use 201134)	20T,20Sp,20P,21
	207915 Mat & Pad Assy-F Floor-LHD-Gray (Use 208600)	20P,21 exc Station
	207917 Mat & Pad Assy-F Floor-LHD-Green (Use 207915)	20P,21 exc Station
C	207918 Mat & Pad Assy-F Floor-RI-ID-Green	20P,21 exc Station
	207919 Mat & Pad Assy-F Floor-LHD-Tan (Use 207921)	22,24
C	207920 Mat & Pad Assy-F Floor-RHD-Tan	22,24
	207921 Mat & Pad Assy-F Floor-LHD-Gray (Use 201134)	22,24,52,54
C	207922 Mat & Pad Assy-F Floor-RHD-Gray	22,24,52,54
	207923 Mat & Pad Assy-F Floor-LHD-Green (Use 207921)	22,24
C	207924 Mat & Pad Assy-F Floor-RHD-Green	22,24
	207925 Rear View Oval Mirror Assy-Service(Use 210756)	1946 thru 1948
C	207926 Trim Assy-F Seat Back Panel-RH	22-24 ClubCpe 2Sed
C	207927 Trim Assy-F Seat Back Panel-LH	22-24 ClubCpe 2Sed
BO	207929 Hole Cover-Front Floor Mat Steering-Green	20P,21 thru 27
C	207938 Rear Curtain & Window Assy-Top	1946-1947 CvBro
BO	207939 Resistor-68 Megohms-1/4 watt-Radio	1946-1947 All
BO	207940 Resistor-47000 Ohms-1/4 Watt-Radio	1946-1947 All
C	207941 Cushion Frame & Back Complete-F Seat-LHD-Cloth-exc Mohair	21 5Sed
C	207942 Cushion Frame & Back Complete-F Seat-RHD-Cloth-exc Mohair	21 5Sed
C	207944 Cushion Frame & Back Complete-F Seat-RHD-Cloth-exc Mohair	21 3Cpe
C	207945 Trim Assy-F Scat Back Panel & Riser-Cloth	21 5Sed,51-53-171-173 Sed
C	207946 Trim Assy-F Seat Back-Cloth	21 5Sed-3Cpe
C	207947 Cushion Complete-F Seat-Cloth	21 5Sed-3Cpe
C	207948 Trim Assy-F Seat Cushion-Cloth	21 5Sed-3Cpe
C	207951 Back Complete-F Seat-Drivers-LHD-Cloth	21 2Sed
C	207952 Back Complete-F Seat-Drivers-RHD-Cloth	21 2Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 207953	Back Complete-F Seat-Pass-LHD-Cloth	21 2Sed
C 207954	Back Complete-F Seat-Pass-RHD-Cloth	21 2Sed
C 207955	Cushion Complete-F Seat-Cloth	21 2Sed-ClubCpe
C 207956	Trim Assy-F Seat Back-RH-Cloth	21 2Sed
C 207957	Trim Assy-F Seat Back-LH-Cloth	21 2Sed
C 207958	Trim Assy-F Seat Cushion-Cloth	21 2Sed-ClubCpe
C 207961	Back Complete-F Seat-Drivers-LHD-Cloth	21 ClubCpe
C 207962	Back Complete-F Seat-Drivers-RHD-Cloth	21 ClubCpe
C 207963	Back Complete-F Seat-Pass-LHD-Cloth	21 ClubCpe
C 207964	Back Complete-F Seat-Pass-RHD-Cloth	21 ClubCpe
C 207965	Trim Assy-F Seat Back Panel & Riser-Cloth	22-24 5Sed
C 207966	Trim Assy-F Seat Back-RH-Cloth	21 ClubCpe
C 207967	Trim Assy-F Seat Back-LH-Cloth	21 ClubCpe
C 207968	Trim Assy-F Seat Back Panel & Riser-Cloth	22-24 3Cpe
C 207970	Cushion Frame & Back Complete-F Seat-RHD-Cloth	22-25 5Sed
C 207971	Cushion Frame & Back Complete-F Seat-LHD-Cloth	22-24 3Cpe
C 207972	Cushion Frame & Back Complete-F Seat-RHD-Cloth	22-24 3Cpe
C 207973	Trim Assy-F Seat Back-Cloth	22-24 5Sed-3Cpe
C 207974	Cushion Complete-F Seat-Cloth	22-24 5Sed-3Cpe
C 207975	Trim Assy-F Seat Cushion-Cloth	22-24 5Sed-3Cpe
C 207976	Trim Assy-F Seat Riser Panel-Cloth	22-24 ClubCpe
C 207979	Back Complete-F Seat-Drivers-LHD-Cloth	22-24 2Sed
C 207980	Back Complete-F Seat-Drivers-RHD-Cloth	22-24 2Sed
C 207981	Back Complete-F Seat-Pass-LHD-Cloth	22-24 2Sed
C 207982	Back Complete-F Seat-Pass-RHD-Cloth	22-24 2Sed
C 207985	Back Complete-F Seat-Drivers-LHD-Cloth	22-24 ClubCpe
C 207986	Back Complete-F Seat-Drivers-RHD-Cloth	22-24 ClubCpe
C 207987	Back Complete-F Seat-Pass-LHD-Cloth	22-24 ClubCpe
C 207988	Back Complete-F Seat-Pass-RHD-Cloth	22-24 ClubCpe
C 207989	Trim Assy-F Seat Riser Panel-Cloth	22-24 2Sed
C 207990	Trim Assy-F Seat Back-RH-Cloth	22-24 2Sed
C 207991	Trim Assy-F Seat Back-LH-Cloth	22-24 2Sed
C 207992	Trim Assy-F Seat Back-RH-Cloth	22-24 ClubCpe
C 207993	Trim Assy-F Seat Back-LH-Cloth	22-24 ClubCpe
C 207994	Cushion Complete-F Seat-Cloth	22-24 ClubCpe-2Sed
C 207995	Trim Assy-F Seat Cushion-Cloth	22-24 ClubCpe-2Sed
C 207996	Rubber Pad-Front Seat Cushion	1942 2Sed-ClubCpe
C 207996	Rubber Pad-F Seat Cushion-Leather Trim	1946-1947 Bro-ClubCpe
C 207997	Rubber Pad-Front Seat Cushion	1942 5Sed-3Cpe,5
C 207997	Rubber Pad-Front Seat Cushion-Leather Trim	1946-1947 Sed-3Cpe
C 207998	Rubber Pad-Rear Seat Cushion	1942 2Sed-Sed
BO 207998	Rubber Pad-Rear Seat Cushion-Leather	1946-1947 Bro-Sed
C 207999	Rubber Pad-Rear Seat Cushion	1942 ClubCpe
C 207999	Rubber Pad-Rear Seat Cushion-Leather	1946-1947 ClubCpe
BO 208000	Resistor-18000 Ohms 1/4 Watt	1946-1947 All
C 208003	Back Complete-F Seat-Drivers-LHD-Cloth	25 ClubCpe
C 208004	Back Complete-F Seat-Drivers-RHD-Cloth	25 ClubCpe
C 208005	Back Complete-F Seat-Pass-LHD-Cloth	25 ClubCpe
C 208006	Back Complete-F Seat-Pass-RHD-Cloth	25 ClubCpe
C 208007	Trim Assy-F Scat Riser Panel-Cloth	25 ClubCpe
C 208008	Trim Assy-F Seat-Back-RH-Cloth	25 ClubCpe
C 208009	Trim Assy-F Seat Back-LH-Cloth	25 ClubCpe
C 208010	Cushion Complete-F Seat-Cloth	25 ClubCpe
C 208011	Trim Assy-F Seat Cushion-Cloth	25 ClubCpe
C 208012	Trim Assy-F Seat Side Panel & Riser-Cloth	27 5Sed
C 208014	Cushion Frame & Back Complete-F Seat-RHD-Cloth	27 5Sed
C 208015	Trim Assy-F Seat Back Panel-Cloth	27 5Sed
C 208016	Trim Assy-F Seat Back-RH-Cloth	27 5Sed
C 208017	Trim Assy-F Seat Back-LH-Cloth	27 5Sed
C 208018	Cushion Complete-F Seat-Cloth	27 5Sed
C 208019	Trim Assy-F Seat Cushion-Cloth	27 5Sed
C 208020	Center Arm Rest Complete-F Seat Back-Cloth	27 5Sed
C 208021	Trim Assy-F Seat Back Arm Rest-Cloth	27 5Sed
C 208022	Valance Assy-F Seat Back Arm Rest-Cloth	27 5Sed
C 208023	Trim Assy-F Seat Back Frame Top Center-Cloth	27 5Sed
C 208024	Back Complete-Rear Seat-Cloth	21 5Sed-2Sed,51-53 Bro-Sed Comb Trim
C 208025	Trim Assy-Rear Seat Back-Cloth	21 5Sed-2Sed,51-53 Bro-Sed Comb Trim
C 208026	Cushion Complete-Rear Seat-Cloth	21 5Sed-2Sed
C 208027	Trim Assy-Rear Seat Cushion-Cloth	21 5Sed-2Sed
C 208029	Trim Assy-Rear Seat Cushion Retainer-Cloth	21 5Sed-2Sed
C 208030	Back Complete-Rear Seat-Cloth	21 ClubCpe,51-53 ClubCpe Comb Trim
C 208031	Trim Assy-Rear Seat Back-Cloth	21 ClubCpe,51-53 ClubCpe Comb Trim
C 208032	Cushion Complete-Rear Seat Cloth	21 ClubCpe
C 208033	Trim Assy-Rear Seat Cushion-Cloth	21 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 208035	Trim Assy-Rear Seat Cushion Retainer-Cloth	21 ClubCpe
C 208037	Cushion Complete-Rear Seat-Cloth	22-24 Sed-2Sed
C 208038	Trim Assy-Rear Scat Back-RH-Cloth	22-24 Sed-2Sed
C 208039	Trim Assy-Rear Seat Back-LH-Cloth	22-24 Sed-2Sed
C 208040	Trim Assy-Rear Seat Cushion-Cloth	22-24 Sed-2Sed
C 208042	Trim Assy-Rear Seat Cushion Retainer-Cloth	22-24 Sed-2Sed
C 208043	Arm Rest Complete-Rear Seat Back Center-Cloth	22-24 Sed-2Sed
C 208044	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	22-24 Sed-2Sed
C 208045	Back Complete-Rear Seat-Cloth	22-24 ClubCpe
C 208046	Trim Assy-Rear Seat Back-RH-Cloth	22-24 ClubCpe
C 208047	Trim Assy-Rear Seat Back-LH-Cloth	22-24 ClubCpe
C 208048	Cushion Complete-Rear Seat-Cloth	22-24 ClubCpe
C 208049	Trim Assy-Rear Seat Cushion-Cloth	22-24 ClubCpe
C 208051	Trim Assy-Rear Seat Cushion Retainer-Cloth	22-24 ClubCpe
C 208052	Arm Rest Complete-Rear Seat Back Center-Cloth	22-24 ClubCpe
C 208053	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	22-24 ClubCpe
C 208054	Trim Assy-Rear Seat Back-RH-Cloth	25 ClubCpe
C 208055	Trim Assy-Rear Seat Back-LH-Cloth	25 ClubCpe
C 208056	Back Complete-Rear Seat-Cloth	25 ClubCpe
C 208057	Cushion Complete-Rear Seat-Cloth	25 ClubCpe
C 208058	Trim Assy-Rear Scat Cushion-Cloth	25 ClubCpe
C 208060	Trim Assy-Rear Seat Cushion-Cloth	25 ClubCpe
C 208061	Arm Rest Complete-Rear Seat Back Center-Cloth	25 ClubCpe
C 208062	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	25 ClubCpe
C 208063	Back Complete-Rear Seat-Cloth	27 5Sed
C 208064	Trim Assy-Rear Seat Back-RH-Cloth	27 5Sed
C 208065	Trim Assy-Rear Seat Back-LH-Cloth	27 5Sed
C 208066	Cushion Complete-Rear Seat-Cloth	27 5Sed
C 208067	Trim Assy-Rear Seat Cushion-Cloth	27 5Sed
C 208069	Trim Assy-Rear Seat Cushion Retainer-Cloth	27 5Sed
C 208070	Arm Rest-Complete-Rear Seat Back Center-Cloth	27 5Sed
C 208071	Trim Assy-Rear Seat Back Center Arm Rest-Cloth	27 5Sed
BO 208124	Arm Rest Assy-F Door-Cloth exc Mohair	20-21-22-24 Sed-2Sed-3Cpe-ClubCpe-UCo-UCpe,51 thru 54-171 thru 174 exc CvBro-Comb Trim
	208125 Trim Assy-Front Door Arm Rest-Comb Trim	51-171 exc CvBro
BO 208126	Arm Rest Assy-F Door-Mohair	20-21-22-24 Sed-2Sed-3Cpe-ClubCpe-UCo-UCpe
BO 208128	Arm Rest Assy-F Door-Leather	20-21-22-24 Sed-2Sed-3Cpe-ClubCpe-UCo-UCpe,51 thru 54,171 thru 174
	208130 Use 208128	
BO 208132	Arm Rest Assy-F Door-Cloth	25-27 Sed-ClubCpe
BO 208134	Arm Rest Assy-F Door-Leather	25-27 Sed-ClubCpe
BO 208136	Arm Rest Kit-F Door-Cloth exc Mohair	20-21-24,-24 Sed-2Sed-3Cpe-ClubCpe-UCo-UCpe,1946-1947 Sed-Bro-3Cpe-ClubCpe
BO 208137	Arm Rest Kit-F Door-Mohair	20-21 Sed-2Sed-3Cpe-ClubCpe-UCo-UCpe
BO 208138	Arm Rest Kit-F Door-Leather	20-21-22-24 Sed-2Sed-Cpe-UCo,20-28 CabPu,1946 Cab-CabPu
C 208140	Trimboard and Trim Assy-RH-F Seat Foot Rest End	20-21-22-24 Sed
C 208141	Trimboard and Trim Assy-LH-F Seat Foot Rest End	20-21-22-24 Sed
C 208142	Carpet Assy-F Seat Foot Rest	20-21-22-24 Sed
C 208184	Rubber Pad-F Seat Back Arm Rest	27 5Sed
C 208186	Rubber Pad-Rear Seat Back Arm Rest	27 5Sed
BO 208190	Air Cleaner Assy-Rear Seat Tray	1942 All,51 thru 54,171 thru 174
BO 208222	Spring-Front Seat Back Pocket	27
C 208239	Glass-Top Rear Curtain Window	1946-1947 CvBro,481-491-1950 CvBro
BO 208248	Frame-Inner Top Rear Curtain Window	1946-1947 CvBro
BO 208249	Frame-Outer-Top Rear Curtain Window	1946-1947 CvBro
BO 208272	Switch Assy-Fog Lamp-Service	1946-1947 All
C 208275	Back Complete-Drivers-LHD	20-21 CvSed,51-171 CvBro
C 208276	Back Complete-Drivers-RHD	20-21 CvSed,51-171 CvBro
C 208277	Back Complete-Passenger-LHD	20-21 CvSed,51-171 CvBro
C 208278	Back Complete-Passenger-RHD	20-21 CvSed,51-171 CvBro
C 208279	Trim Assy-F Seat Riser Panel	20T CvSed
C 208280	Trim Assy-F Seat Back-RH	20-21 CvSed,51 CvBro
C 208281	Trim Assy-F Seat Back-LH	20-21 CvSed,51 CvBro
C 208282	Cushion Complete-Front Seat	20T CvSed
C 208283	Trim Assy-F Seat Cushion	20T CvSed'
C 208284	Trim Assy-F Scat Back Panel-RH-Leather	20-21-22-24 CvSed-2Sed-2Sed-ClubCpe,25 ClubCpe,51-53 Bro-ClubCpe,51-54 CvBro
C 208285	Trim Assy-F Seat Back Panel-LH-Leather	20-21-22-24 CvSed-ClubCpe,25 ClubCpe,51-53 Bro-ClubCpe,51-54 CvBro
C 208286	Back Complete-Rear Seat	20T CvSed
C 208287	Trim Assy-Rear Seat Back	20T CvSed
C 208288	Cushion Complete-Rear Seat	20T CvSed
C 208289	Trim Assy-Rear Seat Cushion	20T CvSed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 208290	Cushion Complete-Rear Seat	22-24 CvSed
C 208291	Trim Assy-Rear Seat Cushion	22-24 CvSed
C 208295	Cushion Complete-F Seat	20P-21 CvSed
C 208296	Trim Assy-F Seat Cushion	20P-21 CvSed
C 208297	Cushion Complete-Rear Seat	20P-21 CvSed
C 208298	Trim Assy-Rear Seat Cushion	20P-21 CvSed
C 208300	Trim Assy-Rear Seat Cushion Retainer	22-24 CvSed
C 208303	Back Complete-Front Seat-Drivers-LHD	22-24 CvSed
C 208304	Back Complete-Front Seat-Drivers-RHD	22-24 CvSed
C 208305	Back Complete-Front Seat-Passenger-LHD	22-24 CvSed
C 208306	Back Complete-Front Seat-Passenger-RHD	22-24 CvSed
C 208307	Trim Assy-F Seat Riser Panel	22-24 CvSed
C 208308	Trim Assy-F Seat Back-RH	22-24 CvSed
C 208309	Trim Assy-F Seat Back-LH	22-24 CvSed
C 208310	Cushion Complete-F Seat	22-24 CvSed
C 208311	Trim Assy-F Seat Cushion	22-24 CvSed
C 208312	Trim Assy-F Seat Riser Panel-Leather	22-24 2Sed
C 208315	Back Complete-F Seat-Drivers-LHD-Leather	20-21 2Sed,1946-1947 Bro
C 208316	Back Complete-F Seat-Drivers-RHD-Leather	20-21 2Sed,1946-1947 Bro
C 208317	Back Complete-F Seat-Passenger-LHD-Leather	20-21 2Sed,1946-1947 Bro
C 208318	Back Complete-F Seat-Passenger-RHD-Leather	20-21 2Sed,1946-1947 Bro
C 208319	Cushion Complete-F Seat-Leather	20 2Sed-ClubCpe-UCpe
C 208320	Trim Assy-F Seat Cushion-Leather	20 2Sed-ClubCpe-UCpe
C 208321	Cushion Complete-F Seat-Airfoam-Leather	20 thru 25 ClubCpe-2Sed-UCpe
C 208322	Trim Assy-F Seat Cushion-Airfoam-Leather	20 thru 24 ClubCpe-2Sed-UCpe
C 208323	Trim Assy-F Seat Back Panel & Riser-Leather	20T 5Sed
C 208324	Trim Assy-F Seat Back-RH-Leather	20-21-22-24 2Sed-UCo,1946 Bro
C 208325	Trim Assy-F Seat Back-LH-Leather	20-21-22-24 2Sed-UCo,1946 Bro
C 208326	Trim Assy-F Seat Back Panel & Riser-Leather	20P-21 5Sed,51-53-171-173 Sed
C 208329	Trim Assy-F Seat Back Panel & Riser-Leather	20T-20P-21-51-53-171-173 3Cpe
C 208330	Back Complete-F Seat-RH-Leather	20 UCpe
C 208331	Back Complete-F Seat-LH-Leather	20 UCpe
C 208332	Trim Assy-F Seat Back Panel & Riser-Leather	22-24 2Sed
C 208335	Back Complete-F Seat-Drivers-LHD-Leather	22-24 2Sed
C 208336	Back Complete-F Seat-Drivers-RHD-Leather	22-24 2Sed
C 208337	Back Complete-F Seat-Passenger-LHD-Leather	22-24 2Sed
C 208338	Back Complete-F Seat-Passenger-RHD-Leather	22-24 2Sed
C 208339	Cushion Frame & Back Complete-F Seat-LHD-Leather	20T 5Sed
C 208340	Cushion Frame & Back Complete-F Seat-RHD-Leather	20T 5Sed
C 208341	Cushion Frame & Back Complete-F Seat-LHD-Leather	20P-21 5Sed
C 208342	Cushion Frame & Back Complete-F Seat-RHD-Leather	20P-21 5Sed
C 208343	Cushion Frame & Back Complete-F Seat-LHD-Leather	20T-20P-21 3Cpe
C 208344	Cushion Frame & Back Complete-F Seat-RHD-Leather	20T-20P-21 3Cpe
C 208345	Trim Assy-F Scat Back-Leather	20-21-22-24-51-52-53-54 Sed-3Cpe
C 208346	Cushion Complete-F Seat-Standard-Leather	20 5Sed-3Cpe
C 208347	Trim Assy-F Seat Cushion-Standard-Leather	20 5Sed-3Cpe
C 208348	Trim Assy-F Seat Cushion-Standard-Leather	20-22-24 5Sed-3Cpe,27
C 208349	Trim Assy-F Seat Cushion-Airfoam-Leather	20-22-24 5Sed-3Cpe,27
C 208350	Trim Assy-F Seat Back Panel & Riser-Leather	22-24 3Cpe
C 208351	Frame & Back Complete-F Seat-LHD-Leather	22-24 5Sed
C 208352	Frame & Back Complete-F Seat-RHD-Leather	22-24 5Sed
C 208353	Frame & Back Complete-F Seat-LHD-Leather	22-24 3Cpe
C 208354	Frame & Back Complete-F Seat-RHD-Leather	22-24 3Cpe
C 208355	Frame & Back Complete-F Seat-RHD-Leather	20-21 ClubCpe
C 208356	Frame & Back Complete-F Seat-RHD-Leather	20-21 ClubCpe
C 208357	Back Complete-F Seat-Drivers-LHD-Leather	20-21-22-24-25 ClubCpe,1946-1947 ClubCpe
C 208358	Back Complete-F Seat-Drivers-RHD-Leather	20-21-22-24-25 ClubCpe,1946-1947 ClubCpe
C 208359	Back Complete-F Seat-Passenger-LHD-Leather	20-21-22-24-25 ClubCpe,1946-1947 ClubCpe
C 208360	Back Complete-F Seat-Passenger-RHD-Leather	20-21-22-24-25 ClubCpe,1946-1947 ClubCpe
C 208363	Trim Assy-F Scat Riser Panel-Leather	22-24-25 ClubCpe
C 208364	Trim Assy-F Seat Back-RH-Leather	20-21-22-24-25-51-52-53-54 ClubCpe
C 208365	Trim Assy-F Seat Back-LH-Leather	20-21-22-24-25-51-52-53-54 ClubCpe
C 208366	Trim Assy-F Seat Back-RH-Leather	20 UCpe
C 208367	Trim Assy-F Seat Back Panel-LH-Leather	20 UCpe
C 208368	Trim Assy-F Seat Back Panel-Leather	27 5Sed
C 208369	Frame & Back Complete-F Seat-LHD-Leather	27 5Sed
C 208370	Frame & Back Complete-F Seat-RHD-Leather	27 5Sed
C 208371	Trim Assy-F Seat Side Panel & Riser-Leather	27 5Sed
C 208372	Trim Assy-F Seat Back-RH-Leather	27 5Sed
C 208373	Trim Assy-F Seat Back-LH-Leather	27 5Sed
C 208374	Center Arm Rest Complete-F Seat-Leather	27 5Sed
C 208375	Trim Assy-F Seat Back Center Arm Rest-Leather	27 5Sed
C 208378	Back Complete-Rear Seat-Leather	20T 2Sed-5Sed
C 208379	Back Complete-Rear Seat-Leather	20P-21 2Sed-5Sed,51-53-171-173 Bro-Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 208380	Back Complete-Rear Seat-Leather	20 UCo
C 208381	Trim Assy-Rear Seat Back-Leather	20-21 2Sed-5Sed-UCo,51-53 Bro-Sed
C 208382	Cushion Complete-Rear Seat-Leather-Standard	20 2Sed-5Sed
C 208383	Trim Assy-Rear Seat Cushion-Leather-Standard	20 2Sed-5Sed
C 208384	Cushion Complete-Rear Seat-Leather-Airfoam	20-21-22-24 2Sed-5Sed,27
C 208385	Trim Assy-Rear Seat Cushion-Leather-Airfoam	20-21-22-24 2Sed-5Sed,27
C 208386	Back Complete-Rear Seat-Leather	22-24 2Sed-5Sed,27
C 208387	Arm Rest Complete-Rear Seat Back-Leather	20-24 2Sed-5Sed,27
C 208388	Trim Assy-Rear Seat Back Center Arm Rest-Leather	22-24 2Sed-5Sed,27
C 208390	Trim Assy-Rear Seat Back-RH-Leather	22-24 2Sed-5Sed,27
C 208391	Trim Assy-Rear Seat Back-LH-Leather	22-24 2Sed-5Sed,27
C 208393	Trim Assy-Rear Seat Cushion Retainer-Leather	20-21 2Sed-5Sed-UCo,1946-1947 Bro-Sed
C 208395	Trim Assy-Rear Seat Cushion Retainer-Leather	22-24 2Sed-5Sed,27
C 208396	Cushion Complete-Rear Seat-Leather	20 UCo
C 208397	Trim Assy-Rear Seat Cushion-Leather	20 UCo
C 208399	Back Complete-Rear Seat-Leather	20-21 ClubCpe,51-53-171-173 ClubCpe
C 208400	Trim Assy-Rear Seat Back-Leather	20-21 ClubCpe,51-52-53-54 ClubCpe
C 208401	Cushion Complete-Rear Seat-Standard-Leather	20 ClubCpe
C 208402	Trim Assy-Rear Seat Cushion-Standard-Leather	20 ClubCpe
C 208403	Cushion Complete-Rear Seat-Airfoam-Leather	20 thru 25 ClubCpe
C 208404	Trim Assy-Rear Seat Cushions-Airfoam-Leather	20 thru 25 ClubCpe
C 208405	Back Complete-Rear Seat-Leather	22-24-25 ClubCpe
C 208406	Trim Assy-Rear Seat Back-RH-Leather	22-24-25 ClubCpe
C 208407	Trim Assy-Rear Seat Back-LH-Leather	22-24-25 ClubCpe
C 208408	Arm Rest Complete-Rear Seat Back-Leather	22-24-25 ClubCpe
C 208409	Trim Assy-Rear Seat Back Center Arm Rest-Leather	22-24-25 ClubCpe
C 208412	Trim Assy-Rear Seat Cushion Retainer-Leather	22-24-25 ClubCpe
C 208414	Trim Assy-Rear Seat Cushion Retainer-Leather	20-21 ClubCpe,1946-1947 ClubCpe
C 208415	Frame & Back Complete-F Seat Cushion-LHD-Mohair	20T 5Sed
C 208416	Frame & Back Complete-F Seat Cushion-RHD-Mohair	20T 5Sed
C 208417	Frame & Back Complete-F Seat Cushion-LHD-Mohair	20P-21 5Sed
C 208418	Frame & Back Complete-F Seat Cushion-RHD-Mohair	20P-21 5Sed
C 208419	Frame & Back Complete-F Seat Cushion-LHD-Mohair	20P-21 5Sed
C 208420	Frame & Back Complete-F Seat Cushion-RIM-Mohair	20P-21 5Sed
C 208427	Trim Assy-F Seat Riser Panel-Mohair	20 UCpe
C 208429	Trim Assy-F Seat Riser Panel-Mohair	20-21 ClubCpe
C 208430	Trim Assy-F Seat Riser Panel-Mohair	20-21 2Sed
C 208431	Trim Assy-F Seat Back Panel & Riser-Mohair	20T 5Sed
C 208432	Trim Assy-F Seat Back Panel & Riser-Mohair	20P-21 5Sed
C 208433	Trim Assy-F Seat Back Panel & Riser-Mohair	20-21 3Cpe
C 208435	Trim Assy-Rear Seat Cushion-Mohair	20 UCO
C 208439	Trim Assy-Rear Seat Cushion Riser-Mohair	20-21 ClubCpe
208480	Mldg-F Door Trim Panel-RH-Lac (Use 207678)	20T exc Sed,25,20-21 Cpe-2Sed Leather
208480	Mldg-Qtr Trim Panel-RH-Lac (Use 207678)	20T CvSed-2Sed-UCo,20P-21 2Sed Leather
208481	Mldg-F Door Trim Panel-LH-Lac (Use 207679)	20T exc Sed,25,20-21 Cpe-2Sed Leather
208481	Mldg-Qtr Trim Panel-LH-Lac (Use 207679)	20T CvSed-2Sed-UCo,20P-21 2Sed Leather
C 208482	Mldg-Door Trim Panel-RH-Lac	20T-27 Sed,20-21 5Sed-Leather
C 208482	Mldg-Qtr Trim Panel-RH-Lac	20T-25 ClubCpe,20P-21 ClubCpe Leather
208483	Mldg-Door Trim Panel-LH-Lac (Use 207661)	20T-27 Sed,20-21 5Sed-Leather
208483	Mldg-Qtr Trim Panel-LH-Lac (Use 207661)	20T-25 ClubCpe,20 P-21 ClubCpe Leather
208484	Mldg-F Door Trim Panel-RH-Lac (Use 207680)	20-21 2Sed-3Cpe-ClubCpe-UCo-UCpe
208485	Mldg-F Door Trim Panel-LH-Lac (Use 207681)	20-21 2Sed-3Cpe-ClubCpe-UCo-UCpe
C 208487	Mldg-F Door Trim Panel-LH-Lac	20-21 5Sed
208488	Mldg-Rear Door Trim Panel-RH-Lac (Use 207684)	20-21 5Sed
C 208489	Mldg-Rear Door Trim Panel-LH-Lac	20-21 5Sed
208491	Mldg-Qtr Trim Panel-LH-Lac (Use 207689)	20P 2Sed,20T-21 2Sed-UCo Mohair
208493	Mldg-Qtr Trim Panel-LH-Lac (Use 207887)	20-21 ClubCpe
C 208494	Mldg-F Door Trim Panel-RH-Lac	21 2Sed-3Cpe-ClubCpe
C 208495	Mldg-F Door Trim Panel-LB-Lac	21 2Sed-3Cpe-ClubCpe
208496	Mldg-F Door Trim Panel-RH-Lac (Use 207694)	21 5Sed
C 208497	Mldg-F Door Trim Panel-LH-Lac	21 5Sed
208498	Mldg-Rear Door Trim Panel-RH-Lac (Use 207696)	21 5Sed
208498	Mldg-Qtr Trim Panel-RH-Lac (Use 207696)	21 ClubCpe
C 208499	Mldg-Rear Door Trim Panel-LH-Lac	21 5Sed
C 208499	Mldg-Qtr Trim Panel-LH-Lac	21 ClubCpe
208501	Mldg-Qtr Trim Panel-LH-Lac (Use 207691)	21 2Sed
C 208502	Mldg-F Door Trim Panel-Upper-Lac	22-24-25 exc Sed,27,20P-2I CvSed
C 208503	Mldg-F Door Trim Panel-Lower-Lac	22-24-25 exc Sed,27,20P-21 CvSed
C 208503	Mldg-Qtr Trim Panel-Upper-Lac	22-24 2Sed
208504	Mldg-F Door Trim Panel-Upper-Lac (Use 148636)	22-24 5Sed
208504	Mldg-Qtr Trim Panel-Upper-Lac (Use 148636)	20-21-22-24 CvSed
208505	Mldg-F Door Trim Panel-Lower-Lac (Use 148637)	22-24 5Sed
C 208506	Mldg-Rear Door Trim Panel-Upper-Lac	22-24 Sed,27 Sed Leather
208507	Mldg-Rear Door Trim Panel-Lower-Lac (Use 148725)	22-24 Sed,27 Sed Leather

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 208508	Mldg-Qtr Trim Panel-Lac (Use 148633)	20-21-22-24 Sed, 27 Sed Leather
208509	Mldg-Qtr Trim Panel-Lower-Lac (Use 148619)	22-24 2Sed, 22-24-25 ClubCpe, 1942 CvSed
BO 208510	Mldg-F Door Trim Panel-#1-2-5 Lac	25, 27
208511	Mldg-F Door Trim Panel-#3-4 Front-Lac (Use 207881)	25, 27
208511	Mldg-Qtr Trim Panel-Short (Use 207881)	27
208512	Mldg-Qtr Trim Panel-#4 Center-Lac (Use 207882)	25, 27
208512	Mldg-Rear Door Trim Panel-#3-4 Center & Rear (Use 207882)	27
BO 208513	Mldg-F Door Trim Panel-#3-4 Rear (Use 207883)	25, 27
208514	Mldg-Rear Door Trim Panel-#1-2-5 Front (Use 207884)	27
208514	Mldg-Qtr Trim Panel-#1-Lac (Use 207884)	25
208516	Mldg-Qtr Trim Panel-#2-3-4-5 Lac (Use 207888)	25
208517	Mldg-Qtr Trim Panel-Lac (Use 207879)	25, 27
C 208519	Mldg-Rear Door Bottom-Trim-LH-Lac	27
208520	Mldg-Front Door Bottom Trim-Lac (Use 204401)	25, 27
208521	Mldg-Qtr Trim Panel Bottom-Lac (Use 204404)	25
C 208522	Mldg-F Seat Back Panel-Lac	27
208523	Mldg-F Seat Back Panel-Lac (Use 207543)	27
BO 208524	Adjusting Screw Kit-Headlamp	1940 All
*SP 208526	Sealed Beam Unit-Back & Driving Lamps	1946-1947 All
BO 208527	Ring-Inner-Sealed Beam Unit Mounting	1946-1947 All
BO 208528	Clamp & Bolt Assy-Back Up Lamp Mounting	1946-1947 All
BO 208543	Brackets-RH Pair-Spot Lamp Mounting	1946-1947 All
BO 208544	Brackets-LH Pair-Spot Lamp Mounting	1946-1947 All
BO 208545	Switch & Wire Assy-Spot Lamp	1946-1947 All
BO 208546	Reflector-For 209965 & 6 Spotlamps	1946-1947 All
208558	Arm Rest Assy-RH-Quarter-Cloth Trim	1946-1947 Bro-Sed
208559	Arm Rest Assy-LH-Quarter-Cloth Trim	1946-1947 Bro-Sed
208560	Trim Assy-RH-Quarter Arm Rest-Cloth Trim	1946-1947 Bro-Sed
208561	Trim Assy-LH-Quarter Arm Rest-Cloth Trim	1946-1947 Bro-Sed
208562	Arm Rest Assy-Quarter-Cloth Trim	1946-1947 ClubCpe
208563	Trim Assy-Quarter Arm Rest-Cloth Trim	1946-1947 ClubCpe
208564	Trimboard Comp-RH-Quarter-Cloth Trim	1946-1947 Bro-Sed
208565	Trimboard Comp-LH-Quarter-Cloth Trim	1946-1947 Bro-Sed
208566	Trimboard Comp-RH-Quarter-Cloth Trim	51-53-171-173 Sed
208567	Trimboard Comp-LH-Quarter-Cloth Trim	51-53-171-173 Sed
208568	Trimboard Comp-RH-Quarter-Cloth Trim	52-54-172-174 Sed
208569	Trimboard Comp-LH-Quarter-Cloth Trim	52-54-172-174 Sed
208570	Trimboard Comp-RH-Quarter-Cloth Trim	51-53-171-173 3Cpe
208571	Trimboard Comp-LH-Quarter-Cloth Trim	51-52-171-173 3Cpe
208582	Trimboard Comp-RH-Quarter-Cloth Trim	52-54-172-174 3Cpe
208583	Trimboard Comp-LH-Quarter-Cloth Trim	52-54-172-174 3Cpe
208584	Trimboard Comp-RH-Quarter-Cloth Trim	51-53-171-173 ClubCpe
208585	Trimboard Comp-LH-Quarter-Cloth Trim	51-53-171-173 ClubCpe
208586	Trimboard Comp-RH-Quarter-Cloth Trim	52-54-172-174 ClubCpe
208587	Trimboard Comp-LH-Quarter-Cloth Trim	52-54-172-174 ClubCpe
208588	Trim Foundation & Trimboard Assy-RH-Center Pillar-Cloth Trim	1946-1947 Sed
208589	Trim Foundation & Trimboard Assy-LH-Center Pillar-Cloth Trim	1946-1947 Sed
BO 208590	Speaker & Support Brkt Assy-Radio	1946-1947 All
BO 208591	Resistor-10 Ohms-1/2 Watt-Radio	1946 All
BO 208592	Condensor Assy-Gen & Ignition Coil-Radio	1946 thru 1950 All
BO 208599	Lock Assy-Locker Box Door-Service	All
208600	Mat & Pad Assy-F Floor-LHD-Black (Use 201134)	51, 53, 58, 171, 173, 178
C 208601	Mat and Pad Assy-F Floor-RHD-Black	51, 53, 58, 171, 173, 178
BO 208602	Robe Hanger Assy-Combination Trim	51-53-171-173 Sedan
BO 208603	Robe Hanger Assy-Blue Leather	52-54-172-174 Sed Comb Trim 1946-1947 Sed Leather Trim
C 208604	Finish Mldg-Windshield-Upper-RH-Grained	1946-1947 exc CvBro
C 208605	Finish Mldg-Windshield-Upper-LH-Grained	1946-1947 exc CvBro
C 208606	Finish Mldg-Windshield-Lower-Grained	1946-1947 All
C 208610	Finish Mldg & W/Strip Assy-F Door Wdo-RH	51-53-171-173 Bro
C 208611	Finish Mldg & W/Strip Assy-F Door Wdo-LH	51-53-171-173 Bro
C 208612	Finish Mldg & W/Strip Assy-F Door Wdo-RH	51-53-171-173 Sed, 58, 178
C 208613	Finish Mldg & W/Strip Assy-F Door Wdo-LH	51-53-171-173 Sed, 58, 178
C 208614	Finish Mldg & W/Strip Assy-F Door Wdo-RH	51-53-171-173 3Cpe-ClubCpe
C 208615	Finish Mldg & W/Strip Assy-F Door Wdo-LH	51-53-171-173 3Cpe-ClubCpe
C 208622	Finish Mldg & W/Strip Assy-R Door Wdo-RH	51-53-171-173 Sed
C 208623	Finish Mldg & W/Strip Assy-R Door Wdo-LH	91-537171-173 Sed
C 208626	Finish Mldg & W/Strip Assy-Qtr Wdo-RH	51-53-171-173 Bro
C 208627	Finish Mldg & W/Strip Assy-Qtr Wdo-LH	51-53-171-173 Bro
C 208628	Finish Mldg & W/Strip Assy-Qtr Wdo-RH	51-53-171-173 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 208629	Finish Mldg & W/Strip Assy-Qtr Wdo-LH	51-53-171-173 Sed
*A 208640	Panel Assy-Instrument-LHD-Grained	51 thru 54,171 thru 174,178 Station
*A 208641	Panel Assy-Instrument-RHD-Grained	51 thru 54,171 thru 174
BO 208642	Door Assy-RH-Lo Cker BOx-LHD-Grained	51,53,171,173,178 Station
BO 208643	Door Assy-LH-Lo Cker BOx-LHD-Grained	51,53,171,173,178 Station
BO 208644	Door Assy-RH-Lo Cker BOx-LHD-Grained	52,54,172,174
BO 208645	Door Assy-LH-Lo Cker BOx-LHD-Grained	52,54,172,174
BO 208646	Ash Reciever Assy-Inst Panel-Grained	51 thru 54,171 thru 174
BO 208649	Resistor-120 Ohms-1/2 Watt-Radio	1946-1947 All
C 208654	Molding-RH-Quarter Panel Belt	51-53-171-173 Bro
C 208655	Molding-LH-Quarter Panel Belt	51-53-171-173 Bro
C 208656	Molding-RH-Quarter Panel Belt	51-53-171-173 Sed
C 208657	Molding-LH-Quarter Panel Belt	51-53-171-173 Sed
C 208660	Molding-RH-Quarter Panel Belt-Front	52-54-172-174 Sed
C 208661	Molding-LH-Quarter Panel Belt-Front	52-54-172-174 Sed
C 208662	Molding-RH-Quarter Panel Belt-Rear	52-54-172-174 Bro-Sed
C 208663	Molding-LH-Quarter Panel Belt-Rear	52-54-172-174 Bro-Sed
BO 208664	Visor Assy-Hinge Type- Comb Trims & Leather Trim	51-171 exc CvBro,53,173
BO 208665	Visor Assy-Swivel Type-All Trims	52,172,54-174 exc CvBro
*C 208670	Body Lacquer-Spring Green Opalescent	1946 exc Cab-CabPu
*C 208671	Body Lacquer-Jewel Blue Opalescent	1946 exc Cab-CabPu
*C 208672	Body Lacquer-Quaker Gray Opalescent	1946-1947 exc Cab-CabPu-Station
*C 208673	Body Lacquer-Paragon Green Opalescent	1946 exc Cab-CabPu
*C 208674	Body Lacquer-Bar Harbor Blue Opalescent	1946-1947 All exc Station
*C 208675	Body Lacquer-Gunmetal Opalescent	1946-1947 All exc Station
*C 208678	Body Lacquer- Copper Red Opalescent	51 thru 54
*C 208679	Wheel Enamel- Cream	1946-1947 All
*C 208681	Wheel Enamel-Royal Red	1946-1947 All
M 208700 Yd	Seat Cloth-Blue Gray Bedford Cord	52,172,54-174 exc CvBro
M 208701 Yd	Seat Cloth-Blue Gray Shadow Weave	51-171 exc CvBro,53,173
M 208702Yd	Sidewall Cloth-Blue Gray	1946-1947 Bro-Sed-3Cpe-ClubCpe
BO 208709	Resistor-100 Ohms 1/4 Watt-Radio	1946-1947 All
BO 208710	Molding #4-Grille-Outer	1946-1947 All
BO 208711	Molding-#3 Grille-Outer	1946-1947 All
BO 208712	Molding-#2 Grille-Outer	1946-1947 All
BO 208713	Molding-#1 Grille-Outer	1946-1947 All
BO 208714	Molding-Grille- Center	1946-1947 All
	208715 Bolt-Grille Molding (Use 209724)	1946 All
BO 208716	Support-RH-Grille Molding Inner	1946-1947 All
BO 208717	Support-LH-Grille Molding Inner	1946-1947 All
BZ 208718	Support-F Bumper Splash Apron Grille Mldg-Outer	1946-1947 All
BO 208719	Ornament and Crest Assy-Hood Top	52,54,172,174
BO 208720	Vane-Grille Center	1946-1947 All
BO 208721	Plate-Grille Center Vane Base	1946-1947 All
C 208722	Molding-RH-Grille Splash Apron-Upper	1946-1947 All
C 208723	Molding-LH-Grille Splash Apron-Upper	1946-1947 All
C 208724	Molding-Grille Splash Apron-Lower	1946-1947 All
BZ 208726	Clip-Grille Splash Apron Mldg-Upper	1946-1947 All
BZ 208727	Clip-Grille Splash Apron Mldg-Lower	1946-1947 All
	208732 Splash Apron, Extension & Support Assy-RH-F Bumper (Use 209652 & 208718)	1946-1947 All
	208733 Splash Apron, Extension & Support Assy-LH-F Bumper (Use 209653 & 208718)	1946-1947 All
*BZ 208736 Pr	Panel Assy-RH-F Fender Molding	1946-1947 All
*BZ 208737 Pr	Panel Assy-LH-F Fender Molding	1946-1947 All
BO 208738	Stud-F Fender Mldg Panel	1946-1947 All
BO 208739	Name Plate-Hood Side- Commodore	52,54,172,174
C 208740	Louver-RH-Hood	1946-1947 All
C 208741	Louver-LH-Hood	1946-1947 All
*A 208744 Pr	Hood Assembly	51,53,58,171,173,178
BO 208745	Number Plate-Hood Side-Eight	54,174
*A 208748 Pr	Hood Assembly	52,54,172,174
BO 208749	Number Plate-Hood Side-Six	52,172
BO 208750	Ornament Assy-Hood Side-RH	51,53,58,171,173,178
BO 208751	Ornament Assy-Hood Side-LH	51,53,58,171,173,178
BO 208752	Ornament Assy-Hood Front	1946 All
	208753 Lens-Hood Front Ornament (Use 211514)	1946-1947 All
BO 208754	Housing-Hood Front Ornament	1946 All
BZ 208755	Bolt-Grille Splash Apron Mldg-Lower	1946-1947 All
	208756 Filler-Hood Panel Joint	1946 All
BZ 208757	Reflector-Hood Front Ornament Lamp	1946 thru 1949 All
A 208758	Splash Apron Assy-F Bumper-RH	1946-1947 All
A 208759	Splash Apron Assy-F Bumper-LH	1946-1947 All
BZ 208760	Cover-F Bumper Splash Apron Joint	1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 208761	Support-F Bumper Splash Apron-Side	1946-1947 All
C 208762	Molding-Hood Top	1946-1947 All
C 208764	Molding-RH-Hood Belt	51,53,58,171,173,178
C 208765	Molding-LH-Hood Belt	51,53,58,171,173,178
BO 208768	Ornament-Hood Top	51,53,58,171,173,178
BO 208770	Crest-Hood Top Ornament	52,54,172,174
BO 208771	Name Plate-Hood Side-Super Six	51,171,178 Station
BO 208784	Extension-Quarter Panel Belt Molding	51-53-171-173 Bro-Sed
BO 208785	Extension-Quarter Panel Belt Molding	52-54-172-174 Bro-Sed
208787	Panel-Rear Compartment Door-Outside (Use 203200)	1946 Bro-Sed
BO 208789	Gasket-Hood Front Ornament Lens	1946 thru 1949 All
BO 208793	Retainer-Quarter Panel Belt Molding-Rear	51-53-171-173 Sed
BO 208794	Retainer-#1-RH-Quarter Panel Front Belt Mldg	52-54-172-174 Bro-Sed
BO 208795	Retainer-#1-LH-Quarter Panel Front Belt Mldg	52-54-172-174 Bro-Sed
BO 208796	Retainer-#2-RH-Quarter Panel Front Belt Mldg	52-54-172-174 Bro-Sed
BO 208797	Retainer-#2-LH-Quarter Panel Front Belt Mldg	52-54-172-174 Bro-Sed
C 208802	Molding-Hood Belt Auxiliary	52,54,172,174
BO 208805	Grille-Instrument Panel	1946-1947 All
BO 208806	Screen-Instrument Panel Grille-Silver	51,53,58,171,173,178
208807	Screen-Instrument Panel Grille-Gold (Use 208806)	52,54,172,174
BO 208808	Cover Assy-Inst Panel Radio Dial Hole	51,53,58,171,173,178
208809	Cover Assy-Inst Panel Radio Dial Hole (Use 208808)	52,54,172,174
BO 208810	Control Assy-W/S Cleaner Operating	1946-1947 All
BO 208812	Switch and Cable Assy-Radio Foot Control-LHD	1946 All
208814	Door Assy-Rear Compartment (Use 206761)	1946 Bro-Sed
BZ 208817	Guard Assy-RH-F Bumper Fender	1946-1947 All
BZ 208818	Guard Assy-LH-F Bumper Fender	1946-1947 All
BZ 208819	Guard Assy-RH-F Bumper Fender	1946-1947 All
BZ 208820	Guard Assy-LH-R Bumper Fender	1946-1947 All
C 208821	Extension-RH-F Bumper Bar	52,54,172,174,Opt 51-53-171-173-178 Station
C 208822	Extension-LH-F Bumper Bar	52,54,172,174,Opt 51-53-171-173-178 Station
BZ 208823	Clamp-Bumper Bar Extension	52,54,172,174,Opt 51-53-171-173-178 Station
BO 208824	Spacer-Hood Front Ornament	1946-1947 All
BO 208825	Clip-Hood Lamp Lens Retainer-Side	52,54,172,174
208826	Speaker Assy-Radio (Use 208590)	1946-1947 All
208827	Bolt-Bumper Bar Ext Clamp (Use 126568)	52,54,Opt 51-53
BZ 208834	Guard Assy-RH-F Bumper Bar Extension	52,54,172,174,Opt 51-53-171-173-178 Station
BZ 208835	Guard Assy-LH-F Bumper Bar Extension	52,54,172,174,Opt 51-53-171-173-178 Station
C 208838	Extension-RH-R Bumper Bar	52,54,172,174,Opt 51-53-171-173-178 Station
C 208839	Extension-LH-R Bumper Bar	52,54,172,174,Opt 51-53-171-173-178 Station
BO 208840	Molding-RH-Rear Fender Trim-Lower	51 thru 54,171 thru 174
BO 208841	Molding-LH-Rear Fender Trim-Lower	51 thru 54,171 thru 174
C 208843	Frame & Back Complete-F Seat-LHD- Comb Trim	51-53 Sect
C 208845	Cushion Complete-F S Cat-Standard- Comb Trim	51-53 Bro-ClubCpe
C 208846	Cushion Complete-F Seat-Airfoam- Comb Trim	51-53 Bro-ClubCpe
C 208847	Cushion Complete-F Seat-Standard- Comb Trim	51-53 Sed-3Cpe
C 208848	Cushion Complete-F Seat-Airfoam- Comb Trim	51-53 Sed-3Cpe
C 208849	Trim Assy-F Seat Cushion- Comb Trim	51-53 Bro-ClubCpe
C 208850	Trim Assy-F Seat Cushion- Comb Trim	51-53 Sed-3Cpe
C 208851	Cushion Complete-R Seat-Standard- Comb Trim	51-53 Bro-Sed
C 208852	Cushion Complete-R Seat-Airfoam- Comb Trim	51-53 Bro-Sed
C 208853	Cushion Complete-R Seat-Standard- Comb Trim	51-53 ClubCpe
C 208854	Cushion Complete-R Seat-Airfoam- Comb Trim	51-53 ClubCpe
C 208855	Trim Assy-R Seat Cushion- Comb Trim	51-53 Bro-Sed
C 208856	Trim Assy-R Seat Cushion- Comb Trim	51-53 ClubCpe
*A 208858 Pr	Fender-Rear-RH	51 thru 54,171 thru 174
*A 208859 Pr	Fender-Rear-LH	51 thru 54,171 thru 174
*C 208883	Panel Assy-RH-Quarter-Without Reveal Mldg-Holes	51-53-171-173 Bro
*C 208884	Panel Assy-LH-Quarter-Without Reveal Mldg-Holes	51-53-171-173 Bro
*C 208891	Panel Assy-RH-Quarter	52-54-172-174 Bro
*C 208892	Panel Assy-LH-Quarter	52-54-172-174 Bro
C 208894	Board Assy-R Seat Back Center Arm Rest	52-54-172-174 Sed
C 208897	Spring-Rear Seat Back	52-54-172-174 Sed
C 208898	Spring-Rear Seat Back Center Arm Rest	52-54-172-174 Sed
BO 208903	Hinge Assy-R Seat Back Center Arm Rest	52-54-172-174 Sed
*C 208914	Panel Assy-RH-Quarter-Without Reveal Mldg-Holes	51-53-171-173 Sed
*C 208915	Panel Assy-LH-Quarter-Without Reveal Mldg-Holes	51-53-171-173 Sed
*C 208922	Panel Assy-RH-Quarter	52-54-172-174 Sed
*C 208923	Panel Assy-LH-Quarter	52-54-172-174 Sed
BO 208926	Name Plate-Hudson Drive Master-Rear Compt Door	51-52-53-54,171 thru 174
C 208928	Arm Rest Complete-R Seat Back Center	52-54 Scd-Comb Trim & Lea Trim
C 208929	Trim Assy-R Seat Back Center Arm Rest	52-54-172-174 Comb Trim & Lea Trim
208930	Valance-R/S Back Center Arm Rest- Comb Trim & Leather Trim	52-54 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 208931	Front End Assy-LHD-Grained Inst Panel	51-171 exc CvBro,53,173
208939	Front End Assy-LHD-Grained Inst Panel (Use 208931)	52,172,54-174 exc CvBro
*C 208941 Pr	Stone Guard & Extension Assy-Rear Bumper	52,54,172,174
*BZ 208942	Extension-RH-Rear Bumper Stone Guard	52,54,172,174
*BZ 208943	Extension-LH-Rear Bumper Stone Guard	52,54,172,174
208945	Impact Bar-Front Bumper (Use 206704)	52,54,172,174
C 208950	Trimboard Complete-RH-F Door-Comb Trim	51-53 Bro-3Cpe-ClubCpe
C 208951	Trimboard Complete-LH-F Door-Comb Trim	51-53 Bro-3Cpe-ClubCpe
C 208952	Trimboard Complete-RH-F Door-Comb Trim	51-53 Sed
C 208953	Trimboard Complete-LH-F Door-Comb Trim	51-53 Sed
C 208954	Trimboard Complete-RH-F Door-Comb Trim	51-53 Sed
C 208955	Trimboard Complete-LH-R Door-Comb Trim	51-53 Sed
C 208962	Trimboard Complete-RH-F Door-Comb Trim	52-54 Bro-3Cpe-ClubCpe
C 208963	Trimboard Complete-LH-F Door-Comb Trim	52-54 Bro-3Cpe-ClubCpe
C 208964	Trimboard Complete-RH-F Door-Comb Trim	52-54 Sed
C 208965	Trimboard Complete-LH-F Door-Comb Trim	52-54 Sed
C 208966	Trimboard Complete-RH-R Door-Comb Trim	52-54 Sed
C 208967	Trimboard Complete-LH-R Door-Comb Trim	52-54 Sed
C 208988	Scuff Plate-RH-Front Door	51-53-171-173 exc Sed,178 Station
C 208989	Scuff Plate-LH-Front Door	51-53-171-173 exc Sed,178 Station
C 208990	Scuff Plate-RH-Front Door	52-54-172-174 exc Sed
C 208991	Scuff Plate-LH-Front Door	52-54-172-174 exc Sed
C 208992	Scuff Plate-RH-Front Door	51-53-171-173 Sed,178 Station
C 208993	Scuff Plate-LH-Front Door	51-53-171-173 Sed,178 Station
C 208994	Scuff Plate-RH-Front Door	52-54-172-174 Sed
C 208995	Scuff Plate-LH-Front Door	52-54-172-174 Sed
C 208996	Scuff Plate-RH-Rear Door	51-53-171-173 Sed
C 208997	Scuff Plate-LH-Rear Door	51-53-171-173 Sed
C 208998	Scuff Plate-RH-Rear Door	52-54-172-174 Sed
C 208999	Scuff Plate-LH-Rear Door	52-54-172-174 Sed
M 209000 Sq ft	Seat Leather-Blue Hand Buffed	51 thru 54,171 thru 174
M 209001 Yd	Imitation Leather-Blue	1946-1947 All
BO 209003	Assist Strap Assy-Blue Gray Cloth	51-53-171-173 Bro-Sed-ClubCpe
BO 209004	Assist Strap Assy-Blue Gray Cloth	52-54-172-174 Bro-Sed-ClubCpe
BO 209005	Name Plate-Rear Compartment Door	51,52,53,54
M 209008 Yd	Imitation Leather-Blue	51 thru 54,171 thru 174
BO 209010	Dial-Inst and Speedometer-Miles-RHD	51,53,58,171,173,178
BO 209011	Dial-Inst and Speedometer-Miles-RED	52,54,172,174
BO 209012	Dial-Inst and Speedometer-Miles-LHD	51,53,58,171,173,178
BO 209013	Dial-Inst and Speedometer-Miles-LHD	52,54,172,174
BO 209014	Dial-Inst and Speedometer-Metric-LHD	51,53,58,171,173,178
BO 209015	Dial-Inst and Speedometer-Metric-LHD	52,54,172,174
BO 209016	Dial-Inst and Speedometer-Metric-RED	51,53,58,171,173,178
BO 209017	Dial-Inst and Speedometer-Metric-RED	52,54,172,174
BO 209020	Speedometer Assy-Miles	1946-1947 All
BO 209021	Speedometer Assy-Metric	1946-1947 All
BO 209022	Dial-Inst and Clock-LHD	51,53,58,171,173,178
BO 209023	Dial-Inst and Clock-LHD	52,54,172,174
BO 209024	Dial-Inst and Clock-RHD	51 53 58 171,173,178
BO 209025	Dial-Inst and Clock-RHD	52,54,172,174
BO 209028	Gauge Assy-Fuel	1946-1947 All
BO 209029	Gauge Assy-Water Temperature	1946-1947 All
BO 209030	Dial and Bezel Assy-Inst and Clock-LHD	51,53,58,171,173,178
BO 209031	Dial and Bezel Assy-Inst and Clock-LHD	52,54,172,174
BO 209032	Dial and Bezel Assy-Inst and Clock-RHD	51,53,58,171,173,178
BO 209033	Dial and Bezel Assy-Inst and Clock-RHD	52,54,172,174
BO 209034	Dial & Bezel Assy-Inst & Spdo-Miles-LHD	51,53,58,171,173,178
BO 209035	Dial & Bezel Assy-Inst & Spdo-Miles-LHD	52,54,172,174
BO 209036	Dial & Bezel Assy-Inst & Spdo-Metric-LHD	51,53,58
BO 209037	Dial & Bezel Assy-Inst & Spdo-Metric-LHD	52,54
BO 209038	Dial & Bezel Assy-Inst & Spdo-Miles-RHD	51,53,58,171,173,178
BO 209039	Dial & Bezel Assy-Inst & Spdo-Miles-RHD	52,54,172,174
BO 209040	Dial & Bezel Assy-Inst & Spdo-Metric-RHD	51,53,58
BO 209041	Dial & Bezel Assy-Inst & Spdo-Metric-RHD	52,54
C 209044	Trimboard Assy-Rear Seat Back Spring	52-54-172-174 Sed
C 209050	Frame and Back Complete-F Seat-LHD-Comb Trim	52-54 Sed
C 209052	Back Complete-F Seat-Drivers-LHD-Comb Trim	52-54 ClubCpe
C 209053	Back Complete-F Seat-Pass-LHD-Comb Trim	52-54 ClubCpe
C 209057	Trim Assy-F Seat Back Panel & Riser-Comb Trim	52-54-172-174 Sed
C 209058	Trim Assy-F Seat Back Panel-RH-Cloth	52-54 Bro-ClubCpe
C 209059	Trim Assy-F Seat Back Panel-LH-Cloth	52-54 Bro-ClubCpe
C 209060	Cushion Complete-F Seat-Comb Trim	52-54 Bro-ClubCpe
C 209061	Cushion Complete-F Seat-Comb Trim	52-54 Sed-3Cpe
C 209062	Trim Assy-F Seat Cushion-Comb Trim	52-54 Bro-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 209063	Trim Assy-F Seat Cushion- Comb Trim	52-54 Sed-3Cpe
C 209064	Back Complete-R Seat- Comb Trim	52-54 Sed
C 209065	Back Complete-R S Cat- Comb Trim	52-54 ClubCpe
C 209066	Trim Assy-R Seat Back-RH- Comb Trim	52-54 Sed
C 209067	Trim Assy-R Seat Back-LH- Comb Trim	52-54 Sed
C 209068	Trim Assy-R Seat Back- Comb Trim	52-54 ClubCpe
C 209070	Cushion Complete-R Seat- Comb Trim	52-54 Bro-Sed
C 209071	Cushion Complete-R Seat- Cloth Comb Trim	52-54 ClubCpe
C 209072	Trim Assy-R Seat- Cushion- Comb Trim	52-54 Bro-Sed
C 209073	Trim Assy-R Seat- Cushion- Comb Trim	52-54 ClubCpe
C 209087	Rubber Pad-Rear Seat Back Center Arm Rest	52-54-172-174 Sed
BO 209088	Name Plate-Instrument Panel-"Super Six"	51,58,171,178
BO 209089	Name Plate-Instrument Panel-"Super Eight"	53,173
BO 209090	Name Plate-Instrument Panel-" Commodore Six"	52,172
BO 209091	Name Plate-Instrument Panel-" Commodore Eight"	54,174
BO 209092	Clock Assy-Locker Box Door-Mechanical	51,53,58,171,173,178
BO 209093	Clock Assy-Locker Box Door-Electric (Borg)	
((Use 206096 & 166683)	52,54,172,174,Opt 51-53-58-171-173-178
BO 209096	Reinfor Cement-RH-Rear Compartment Opening Corner	51 thru 54,171 thru 174
BO 209097	Reinfor Cement-LH-Rear Compartment Opening Corner	51 thru 54,171 thru 174
209099	Binding-Wire Cable	1946-1947 All
C 209100	Arm Rest Assy-RH-Quarter	51 thru 54 Bro-Sed
C 209101	Arm Rest Assy-LH-Quarter	51 thru 54 Bro-Sed
C 209102	Trim Assy-Quarter Arm Rest-RH	51-53 Bro-Sed
C 209103	Trim Assy-Quarter Arm Rest-LH	51-53 Bro-Sed
C 209104	Arm Rest Assy-RH-Quarter	52-54 Bro-Sed
C 209105	Arm Rest Assy-LH-Quarter	52-54 Bro-Sed
C 209106	Trim Assy-RH-Quarter Arm Rest- Comb Trim	52-54 Bro-Sed
C 209107	Trim Assy-LH-Quarter Arm Rest- Comb Trim	52-54 Bro-Sed
C 209108	Trim BBoard Complete-Quarter-RH- Comb Trim	51-53 Bro
C 209109	Trim BBoard Complete-Quarter-LH- Comb Trim	51-53 Bro
C 209110	Trim BBoard Complete-Quarter-RH- Comb Trim	51-53 Sed
C 209111	Trim BBoard Complete-Quarter-LH- Comb Trim	51-53 Sed
C 209112	Trim BBoard Complete-Quarter-RH- Comb Trim	52-54 Sed
C 209113	Trim BBoard Complete-Quarter-LH- Comb Trim	52-54 Sed
C 209114	Trim BBoard Complete-Quarter-RH- Comb Trim	51-53 ClubCpe
C 209115	Trim BBoard Complete-Quarter-LH- Comb Trim	51-53 ClubCpe
C 209116	Trim BBoard Complete-Quarter-RH- Comb Trim	52-54 ClubCpe
C 209117	Trim BBoard Complete-Quarter-LH- Comb Trim	52-54 ClubCpe
C 209118	Trim BBoard Complete-Quarter-RH- Comb Trim	52-54 Bro
C 209119	Trim BBoard Complete-Quarter-LH- Comb Trim	52-54 Bro
209121	Door Assy-Rear De Ck (Use 206763)	1946 3Cpe-ClubCpe-CvBro
C 209123	Panel-Outside-R/ C De Ck Door	1946 3Cpe-ClubCpe-CvBro
C 209124	Trim BBoard Complete-Quarter-RH- Comb Trim	51-53-171-173 3Cpe
C 209125	Trim BBoard Complete-Quarter-LH- Comb Trim	51-53-171-173 3Cpe
C 209126	Trim BBoard Complete-Quarter-RH- Comb Trim	52-54-172-174 3Cpe
C 209127	Trim BBoard Complete-Quarter-LH- Comb Trim	52-54-172-174 3Cpe
*A 209134 Pr	Fender Assy-Front-RH-Without Lamp Holes	51,53,171,173
*A 209135 Pr	Fender Assy-Front-LH-Without Lamp Holes	51,53,171,173 ..
*A 209136 Pr	Fender Assy-Front-RH-With Lamp Holes	52,54,172,174,51-53-171-173 With DI or Fender Lamps
*A 209137 Pr	Fender Assy-Front-LH-With Lamp Holes	52-54,172,174,51-53-171-173 With DI or Fender Lamps
C 209140	Finish Molding-Windshield-Upper-RH	1946-1947 CvBro
C 209141	Finish Molding-Windshield-Upper-LH	1946-1947 CvBro
*A 209148	Splash Apron & Ext Grille Mldg Assy	1946-1947 All
M 209149 Yd	Leather Grained Material	
C 209150	Front End Assy-LHD-Grained Instrument Panel	51-171 CvBro
C 209152	Front End Assy-RHD-Grained Instrument Panel	51-171 CvBro
C 209158	Front End Assy-LHD-Grained Instrument Panel	54-174 CvBro
C 209193	Front End Assy-LHD-Grained Instrument Panel	178 Station
C 209194	Front End Assy-RHD-Grained Instrument Panel	51-171 exc CvBro,53,173
C 209200	Front End Assy-RHD-Grained Instrument Panel	52,172,54-174 exc CvBro
C 209232	Roof BOW #5	52-54-172-174 ClubCpe
C 209233	Roof BOW #4	52-54-172-174 ClubCpe
C 209241	Cement-Black Rubber	1946-1947 All
BO 209242	Door Comp-Locker Box-RH	171-172
BO 209243	Door Comp-Locker Box-LH	171-172
BO 209250	Door Assy-RH Locker Box-RHD-Grained	51,53,171,173
BO 209251	Door Assy-LH Locker Box-RHD-Grained	51,53,171,173
BO 209256	Door Assy-RH-Locker Box-RHD-Grained	52,54,172,174
BO 209257	Door Assy-LH-Locker Box-RHD-Grained	52,54,172,174
C 209294	Trim BBoard Comp-RH-Front Door-Leather Trim	51-53-171-173 Bro-3Cpe-ClubCpe
C 209295	Trim BBoard Comp-LH-Front Door-Leather Trim	51-53-171-173 Bro-3Cpe-ClubCpe
C 209296	Trim BBoard Comp-RH-Front Door-Leather Trim	51-53-171-173 Sed
C 209297	Trim BBoard Comp-LH-Front Door-Leather Trim	51-53-171-173 Sed

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 209298	Trimboard Comp-RH-Rear Door-Leather Trim	51-53-171-173 Sed
C 209299	Trimboard Comp-LH-Rear Door-Leather Trim	51-53-171-173 Sed
C 209300	Trimboard Comp-RH-Front Door-Leather Trim	52-54-172-174 Bro-3Cpe-ClubCpe
C 209301	Trimboard Comp-LH-Front Door-Leather Trim	52-54-172-174 Bro-3Cpe-ClubCpe
C 209302	Trimboard Comp-RH-Front Door-Leather Trim	52-54-172-174 Sed
C 209303	Trimboard Comp-LH-Front Door-Leather Trim	52-54-172-174 Sed
C 209304	Trimboard Comp-RH-Rear Door-Leather Trim	52-54-172-174 Sed
C 209305	Trimboard Comp-LH-Rear Door-Leather Trim	52-54-172-174 Sed
C 209306	Trimboard Comp-RH-Door-Leather Trim	1946-1947 CvBro
C 209307	Trimboard Comp-LH-Door-Leather Trim	1946-1947 CvBro
C 209310	Trimboard Comp-RH-F Door	1946-1947 Cab-CabPu
C 209311	Trimboard Complete-LH-F Door	1946-1947 Cab-CabPu
C 209315	Frame & Back Complete-F Seat-RHD-Comb Trim	51-53 Sed
C 209316	Frame & Back Complete-R Seat-LHD-Leather	1946-1947 Sed
C 209317	Frame & Back Complete-F Seat-RED-Leather	1946-1947 Sed
C 209318	Frame & Back Complete-F Seat-LHD-Comb Trim	51-53 3Cpe
C 209319	Frame & Back Complete-F Seat-RHD-Comb Trim	51-53 3Cpe
C 209320	Frame & Back Complete-F Seat-LHD-Leather	1946-1947 Sed
C 209321	Frame & Back Complete-F Seat-RHD-Leather	1946-1947 Sed
C 209331	Frame & Back Complete-F Seat-RHD-Comb Trim	52-54 Sed
C 209334	Frame & Back Complete-LHD-Comb Trim	52-54 3Cpe
C 209335	Frame & Back Complete-RHD-Comb Trim	52-54 3Cpe
209383	Headlining Cloth (Use 207233)	
209384	Top Material-Black (Use 207250)	
BO 209386 Yd	Binding-3/4," Double Fold	1946-1947 CvBro
BO 209387 Yd	Binding-Wire On	1946-1947 CvBro
M 209388	Top Bow Material-Tan	1946-1947 CvBro
C 209392	Back Complete-F Seat-Drivers-LHD-Comb Trim	52-54 Bro
C 209393	Back Complete-F Seat-Drivers-RHD-Comb Trim	52-54 Bro
C 209396	Back Complete-F Seat-Drivers-RHD-Comb Trim	52-54 ClubCpe
C 209399	Back Complete-F Seat-Pass-LHD-Comb Trim	52-54 Bro
C 209400	Back Complete-F Seat-Pass-RHD-Comb Trim	52-54 Bro
C 209403	Back Complete-F Seat-Pass-RHD-Comb Trim	52-54 ClubCpe
C 209406	Back Complete-F Seat-Driver-LHD	54-174 CvBro
C 209407	Back Complete-F Seat-Driver-RHD	54-174 CvBro
C 209408	Back Complete-F Seat-Pass-LHD	54-174 CvBro
C 209409	Back Complete-F Seat-Pass-RHD	54-174 CvBro
C 209419	Trim Assy-F Seat Back Panel-RH-Leather	52-54 Bro-ClubCpe
C 209420	Trim Assy-F Seat Back Panel-LH-Leather	52-54 Bro-ClubCpe
209421	Trim Assy-F Seat Back Panel & Riser-Leather (Use 208326)	52-54-172-174 Sed
C 209422	Trim Assy-F Seat Back Panel & Riser-Comb Trim	52-54-172-174 3Cpe
C 209423	Trim Assy-F Seat Back Panel & Riser-Leather	52-54-172-174 3Cpe
C 209424	Cushion Complete-F Seat-Standard-Leather	51-53-171-173 Bro-ClubCpe
C 209425	Cushion Complete-F Seat-Airfoam-Leather	51-53-171-173 Bro-ClubCpe
C 209426	Cushion Complete-F Seat-Standard-Leather	51-53-171-173 Sed-3Cpe
C 209427	Cushion Complete-F Seat-Airfoam-Leather	51-53-171-173 Sed-3Cpe
C 209428	Cushion Complete-F Seat	51-171 CvBro
C 209429	Cushion Complete-F Seat-Leather	52-54-172-174 Bro-ClubCpe
C 209430	Cushion Complete-F Seat-Leather	52-54-172-174 Sed-3Cpe
C 209431	Cushion Complete-F Seat	54-174 CvBro
C 209432	Trim Assy-F Seat Cushion-Leather	51-53 Bro-ClubCpe
C 209433	Trim Assy-F Seat Cushion-Leather	51-53 Sed-3Cpe
C 209434	Trim Assy-F Seat Cushion	51 CvBro
C 209435	Trim Assy-F Seat Cushion-Leather	52-54 Bro-ClubCpe
C 209436	Trim Assy-F Seat Cushion-Leather	52-54 Sed-3Cpe
C 209437	Trim Assy-F Seat Cushion	54 CvBro
C 209438	Back Complete-R Seat-Comb Trim	52-54 Bro
C 209439	Back Complete-R Seat-Leather	52-54-172-174 Bro
C 209440	Back Complete-R Seat-Leather	52-54 Sod
C 209441	Back Complete-R Seat-Leather	52-54-172-174 ClubCpe
C 209442	Back Complete-R Seat-Leather	54-174 CvBro
C 209443	Trim Assy-R Seat Back-Comb Trim	52-54 Bro
C 209445	Trim Assy-R Seat Back-RH-Leather	52-54 Sed
C 209446	Trim Assy-R Seat Back-LH-Leather	52-54 Sed
C 209452	Cushion Complete-R Seat-Standard-Leather	51-53-171-173 Bro-Sed
C 209453	Cushion Complete-R Seat-Airfoam-Leather	51-53-171-173 Bro-Sed
C 209454	Cushion Complete-R Seat-Standard-Leather	51-53-171-173 ClubCpe
C 209455	Cushion Complete-R Seat-Airfoam-Leather	51-53-171-173 ClubCpe
C 209456	Cushion Complete-R Seat-Leather	51-171 CvBro
C 209457	Cushion Complete-R Seat-Leather	52-54-172-174 Bro-Sed
C 209458	Cushion Complete-R Seat-Leather	52-54-172-174 ClubCpe
C 209459	Cushion Complete-R Seat-Leather	54-174 CvBro
C 209460	Trim Assy-R Seat Cushion-Leather	51-52-53-54 Bro-Sed

Part No.	Name	Models
C 209461	Trim Assy-R Seat Cushion-Leather	51-52-53-54 ClubCpe
C 209462	Trim Assy-R Seat Cushion-Leather	51 CvBro
C 209465	Trim Assy-R Seat Cushion-Leather	54 CvBro
C 209466	Rubber Pad-R Seat Back Center Arm Rest	52-54 Sed
BO 209489	Assist Strap Assy-Blue Leather	1946-1947 Bro-Sed-ClubCpe
209490	Imitation Leather-Blue (Use 209149)	58
BO 209491 Yd	Binding-Wire On-Blue	1946-1947 All
BO 209492	Covering-Seaming Welt-Blue	1946-1947 All
C 209493	Trimboard Complete-RH-Quarter Panel-Leather	51-53-171-173 Bro
C 209494	Trimboard Complete-LH-Quarter Panel-Leather	51-53-171-173 Bro
C 209495	Trimboard Complete-RH-Quarter Panel-Leather	51-53-171-173 Sed
C 209496	Trimboard Complete-LH-Quarter Panel-Leather	51-53-171-173 Sed
C 209497	Trimboard Complete-RH-Quarter Panel-Leather	51-53-171-173 3Cpe
C 209498	Trimboard Complete-LH-Quarter Panel-Leather	51-53-171-173 3Cpe
C 209499	Trimboard Complete-RH-Quarter Panel-Leather	51-53-171-173 ClubCpe
C 209500	Trimboard Complete-LH-Quarter Panel-Leather	51-53-171-173 ClubCpe
C 209501	Trimboard Complete-RH-Quarter Panel-Leather	1946-1947 CvBro
C 209502	Trimboard Complete-LH-Quarter Panel-Leather	1946-1947 CvBro
C 209503	Trimboard Complete-RH-Quarter Panel-Leather	52-54-172-174 Bro
C 209504	Trimboard Complete,LH-Quarter Panel-Leather	52-54-172-174 Bro
C 209505	Trimboard Complete-RH-Quarter Panel-Leather	52-54-172-174 Sed
C 209506	Trimboard Complete-LH-Quarter Panel-Leather	52-54-172-174 Sed
C 209507	Trimboard Complete-RH-Quarter Panel-Leather	52-54-172-174 3Cpe
C 209508	Trimboard Complete-LH-Quarter Panel-Leather	52-54-172-174 3Cpe
C 209509	Trimboard Complete-RH-Quarter Panel-Leather	52-54-172-174 ClubCpe
C 209510	Trimboard Complete-LH-Quarter Panel-Leather	52-54-172-174 ClubCpe
BO 209515	Gasket-Spdo & Clock Dials	1946-1947 All
BO 209516	Finish Plate-Instrument & Spdo Dial- LHD-Silver Finish	51,53,58,171,173,178
BO 209517	Finish Plate-Instrument & Spdo Dial-RHD-Silver Finish	51,53,58,171,173,178
BO 209518	Finish Plate-Instrument & Spdo Dial- LHD-Gold Finish	52,54,172,174
BO 209519	Finish Plate-Instrument & Spdo Dial-RHD-Gold Finish	52,54,172,174
BO 209520	Finish Plate-Instrument & Clock Dial-LHD-Silver Finish	51,53,58,171,173,178
BO 209521	Finish Plate-Instrument & Clock Dial -RHD-Silver Finish	51,53,58,171,173,178
BO 209522	Finish Plate-Instrument & Clock Dial- LHD-Gold Finish-LHD	52,54,172,174
BO 209523	Finish Plate-Instrument & Clock Dial-RHD-Gold Finish-RHD	52,54,172,174
BO 209531	Indicator Assy-Oil Pressure and Generator	1946-1947 All
*A 209540 Pr	Fender Assy-RH-Front-Without Fender Lamps	58,178
*A 209541 Pr	Fender Assy-LB-Front-Without Fender Lamps	58,178
BO 209549	Stud-Bonnet Front Ornament Housing	1946-1947 All
*C 209550	Body Lacquer-Harvest Tan Opalescent	1946-1947 All
BO 209551	Battery Cable-To Fuse Block-Radio	1946-1947 All
BO 209553	Knob-Radio Selector	1946-1947 All
M 209555 Sq	Seat Leather-Blue-Leather Trim	1946
ft	Ash Receiver Assy-Quarter-Blue	1946-1947 Bro-Sed-ClubCpe
BO 209556	Cover-Quarter Ash Receiver	1946-1947 Bro-Sed-ClubCpe
BO 209557	Antenna Complete-66"-Telescopic Type	1946-1947 All
*BO 209558	Escutcheon-Radio	1946-1947 All
BO 209560	Switch Assy-Automatic Selector-Radio	1946-1947 All
BO 209566	Solenoid-Part of Tuning Unit-Radio	1940-1947 All
BO 209567	Coil-Oscillator Series-Radio	1946-1947 All
BO 209568	Transformer-IST IF-Radio	1946-1947 All
BO 209569	Transformer-2nd IF-Radio	1946 All
BO 209570	Coil Assy-Motor Choke Noise-Radio	1946 thru 1949 All
BO 209571	Coil & Core Assy-Untuned-RF-Radio	1946-1947 All
BO 209572	Coil & Shield Assy-Oscillator-Radio	1946-1947 All
BO 209574	Coil & Shield Assy-RF-Radio	1946-1947 All
BO 209575	Coil Assy-Oscillator-Radio	1946-1947 All
BO 209576	Condenser-1 MFD-Radio	1946 thru 1950 All
BO 209577	Condensor -Radio	1946-1947 All
BO 209578	Condensor-008 MFD-Radio	1946 thru 1949 All
BO 209579	Condenser-Antenna Trimmer-Radio	1946-1947 All
BO 209580	Trimmer-Oscillator-Radio	1946-1947 All
BO 209581	Trimmer-Cony-Radio	1946-1947 All
BO 209582	Trimmer-Rif-Radio	1946-1947 All
BO 209583	Condensor-001 MFD-Radio	1946-1947 All
BO 209584	Condensor-250 MFD-Radio	1946 thru 1950 All
BO 209585	Condenser-003 MFD-Radio	1946 thru 1949 All
BO 209587	Chain Housing & Conn Arm Assy-RH-W/S Cleaner	1946-1947 All
BO 209590	Chain Housing & Conn Arm Assy-LH-W/S Cleaner	1946-1947 All
BO 209591	Motor Assy-W/S Cleaner	1946-1947 All
BO 209592	Spacer-Quarter Trim Board to Panel	1946-1947 Sed
BO 209593	Shim-Quarter Trimboard to Panel Spacer	1946-1947 Sod
BO 209594	Mat-Rear Compartment Floor	52-54-172-174 Bro-Sed
C 209608		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 209609	Mat-Rear Compartment Floor	52-54-172-174 3Cpe-ClubCpe
C 209610	Mat-Rear Compartment Floor	54-174 CvBro
209611	Mat and Pad Assy-Front Floor-LHD-Black (Use 201134)	52,54,172,174
C 209612	Mat and Pad Assy-Front Floor-RHD-Black	52,54,172,174
C 209621	Panel-Upper Rear	58,178
C 209622	Panel-Roof	1946-1947 Cab-CabPu
BO 209629	Clip-Cowl Trim Panel Trim	1946-1947 All
C 209634	Front End Assy-LHD-Painted Inst Panel	58,178
C 209635	Front End Assy-RHD-Painted Inst Panel	58,178
A 209642	Panel Assy-Instrument-LHD-Painted	58,178
A 209643	Panel Assy-Instrument-RHD-Painted	58,178
BO 209647	Plug-Pillar to Dash	1946-1947 All
BO 209648	Door Assy-RH-Locker Box-LHD-Painted	58,178
BO 209649	Door Assy-LH-Locker Box-LHD-Painted	58,178
BO 209650	Door Assy-RH-Locker Box-RHD-Painted	58,178
BO 209651	Door Assy-LH-Locker Box-RHD-Painted	58,178
*A 209652 Pr	Splash Apron & Extension Assy-RH-F Bumper	1946-1947 All
*A 209653 Pr	Splash Apron & Extension Assy-LH-F Bumper	1946-1947 All
C 209655	Trim Panel & Silencer Assy-Dash	1946-1947 All
C 209656	Cowl Trim Panel Assy-RH-LHD	1946-1947 All
C 209657	Cowl Trim Panel Assy-LH-LHD	1946-1947 All
C 209658	Cowl Trim Panel Assy-RH-RHD	1946-1947 All
C 209659	Cowl Trim Panel Assy-LH-RHD	1946-1947 All
209660	Knob-Door Lock Release Rod (Use 209661)	1946 All
BO 209661	Knob-Gray-Door Lock Release	1946-1947 All
BO 209662	Name Plate-Hood Side-"Super Eight"	53,173
BO 209664	Knob-Gray-Seat Track	1946-1947 Sed-3Cpe
BO 209665	Knob-Gray-Seat Track	1946-1947 Bro-ClubCpe-CvBro
209668	Baffle-Grille Center Molding (Use 209717)	1946-1947 All
BO 209672	Tone Control Volume Control & Switch-Radio	1946 All
BO 209674	Resistor-Sensitivity Control-Radio	1946 thru 1949
BO 209681	Spring-Key Return Radio	1946-1947 All
BO 209682	Scale-Radio	1946-1947 All
BO 209683	Socket-Foot Control Switch-Radio	1946 All
BO 209684	Transformer-Power-Radio	1946-1947 All
BO 209685	Transformer-Output-Radio	1946-1947 All
BO 209686	Vibrator-Radio	1946-1947 All
BO 209689	Name Plate-Radio Dial Hole Cover-Without Radio	1946-1947 All
BO 209691	Disc-Indexing-Radio	1946-1947 All
BO 209692	Gear-Ratchet-Radio	1946-1947 All
BO 209694	Name Plate-Radio	1946-1947 All
BO 209695	Spring-Gear Indexing-Radio	1946 All
BO 209696	Spring-Cam Lever-Radio	1946-1947 All
BO 209697	Spring-Ratchet Gear Return-Radio	1946-1947 All
BO 209698	Spring-Lever-Radio	1946-1947 All
BO 209699	Spring-Kick Off-Radio	1946-1947 All
BO 209700	Spring-Tuning Shaft-Radio	1946-1947 All
BO 209701	Spring-Solenoid Switch-Radio	1946-1947 All
BO 209702	Spring-Solenoid Switch Contract-Radio	1946-1947 All
BO 209703	Spring-Knob Return-Radio	1946-1947 All
BO 209705	Lock Ring-Turret Screw-Radio	1946-1947 All
BO 209706	Plug & Bracket Assy-Solenoid End-Radio	1946-1947 All
BO 209707	Ratchet & Bracket Assy-Radio	1946-1947 All
BO 209708	Cross Arm Assy-Radio	1946-1947 All
BO 209709	Turret Assy-Radio	1946-1947 All
C 209710	Glass Run-Front Door Window	1946-1947 Sed-Cab-CabPu
C 209711	Glass Run-Rear Door Window	1946-1947 Sed
209712	Glass Run-Front Door Window (Use 209714)	1946-1947 Bro
C 209713	Glass Run-Quarter Window	1946-1947 Bro
C 209714	Glass Run-Front Door Window	1946-1947 3Cpe-ClubCpe
A 209717	Baffle Assy-Radiator Grille Center Mldg	1946-1947 All
C 209718	Trim Panel-Rear Seat Back Shelf-Gray	1946-1947 Bro-Sed
C 209719	Trim Panel-Rear Compt Shelf Bottom-Gray	1946 3Cpe-1946-1947 3dpe
C 209720	Trim Panel-Rear Compt Shelf Bottom-Gray	1946-1947 ClubCpe
BO 209721	Bracket-U/B Panel to Hyd Cylinder	1946-1947 CvBro
BO 209722	Cylinder Assy-Folding Top Hyd Lift	1946-1947 CvBro
C 209723	Panel Assy-Underbody	1946-1947 CvBro
BO 209724	Bolt-Radiator Grille Mldg	1946-1947 All
*HA 209728	Lamp Kit-Rear Compt	1946-1947 All
*HA 209733	Automatic Lamp Kit-Rear Compartment, Locker Box, Under Hood	1946-1947 All
*HS 209734	Fabric Cleaner-Pint	All
*HS 209735	Glass Cleaner-12 oz	All
*HS 209736	Rubber Finish-Black-Gallon	All
*HS 209737	Chromium Polish-8 oz	All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 209738	Drum & Bracket Assy-Dial-Radio	1946 All
BO 209739	Plate & Lever Assy-Mounting-Radio	1946-1947 All
BO 209740	Dial Light & Socket Assy-Radio	1946-1947 All
BO 209741	Choke Assy-Antenna Motor Noise-Radio	1946 thru 1950 All
BO 209745	Socket-Vibrator-Radio	1946-1947 All
BO 209746	Socket-8 Contact-Tube-Radio	1946-1947 All
BO 209747	Switch-On-Off-Radio	1946-1947 All
BO 209748	Washer-Vibrator Cushion-Radio	1946-1947 All
BO 209751	Coil Assy-Speaker Cone & Voice-Radio	1946-1947 All
BO 209752	Spring-Knob Retaining-Radio	1946-1947 All
*HA 209753	Kit Complete-Radio Installation	1946-1947 All
BO 209754	Condensor-01 MFD-Radio	1946-1947 All
BO 209758	Lead in Wire & Shield Assy-Radio Antenna	1946-1947 All
BO 209759	Antenna & Mounting Assy-Radio Antenna-66"	1946-1947 All
BO 209761	Shim-Rear Seat Tray to Frame	1946-1947 All
*BO 209770	Lighter Assy-Inst Panel Cigar-6 Volt	1946-1947 All
BO 209772	Base Assy-Inst Panel Cigar Lighter	1946 thru 1948 All
BO 209773	Clamp-Inst Panel Cigar Lighter Base	1946-1947 All
BO 209774	Wire Assy-Inst Panel Cigar Lighter	1946-1947 All
BO 209789	Gear-Volume Control-Radio	1946-1947 All
BO 209799	Spring & Core-Adjusting-Radio	1946-1947 All
*HA 209805	Scat Covers-Front-Tailored	1946-1947 Bro-ClubCpe
*HA 209806	Seat Covers-Front-Tailored	1946-1947 Sed-3Cpe
*HA 209807	Seat Cover Set-Front & Rear-Tailored	1946-1947 Bro
*HA 209809	Seat Cover Set-Front & Rear-Tailored	1946-1947 ClubCpe
BO 209877	Name Plate-Rear-Hood Side	51 thru 54,171 thru 174.178 Station
*SP 209887	Sealed Beam Unit-Fog Lamp	1946 thru 1950
BO 209888	Ring Assy-Fog & Driving Lamp Sealed Beam Ret	1946-1947 All
BO 209889	Cover-Fog & Driving Lamp Sealed Beam Ret Ring	1946-1947 All
BO 209890	Washer-Fog & Driving Lamp Mounting Screw	1946-1947 All
209893	Sealed Beam Unit Assy-Headlamp-Export (Use 209989)	1946-1947 All
BO 209894	Headlamp Comp-RH-Export	1946-1947 All
BO 209895	Headlamp Comp-LH-Export	1946-1947 All
BO 209901	Covering-Seaming Welt	51-53-171-173 Bro-Sed
BO 209918	Eye Bolt-Upper-Radio Antenna	1946-1947 All
BO 209919	Compensator-350 MFD-Radio	1946-1947 All
BO 209920	Resistor-1800 Ohms-Radio	1946-1947 All
BO 209921	Resistor-270 Ohms-1 Watt-Radio	1946-1947 All
BO 209922	Resistor-1 Megohm-1/4 Watt-Radio	1946-1947 All
BO 209923	Resistor-330000 Ohms-Radio	1946-1947 All
BO 209924	Resistor-47 Ohms-Radio	1946-1947 All
BO 209925	Resistor-10 Ohms-1/4 Watt-Radio	1946-1947 All
BO 209926	Resistor-68000 Ohms-Radio	1946-1947 All
BO 209928	Resistor-33000 Ohms-Radio	1946 thru 1949 All
BO 209929	Resistor-82 Ohms-Radio	1946-1947 All
BO 209930	Resistor-15 Megohms-Radio	1946-1947 All
BO 209931	Resistor-15 Ohms-Radio	1946-1947 All
BO 209934	Antenna Socket,Bracket & Term Assy-Radio	1946-1947 All
BO 209936	Tuning Control & Trim Knob Assy-Radio	1946-1947 All
BO 209937	Volume Control Knob & Spring Assy-Radio	1946-1947 All
209939	Cover-R/S Tray Tire Well Drain Hole	1946-1947 All
BO 209960	Slide Fastener-Side-Top Rear Curtain	1946-1947 Bro
BO 209961	Slide Fastener-Top-Top Rear Curtain	1946-1947 Bro
209962	Rear Curtain Assy-Less Glass-Top	1946-1947 CvBro
209963	Rear Curtain & Window Assy-Top	1946 CvBro
BO 209964	Visor Assy-Hinge Type-Leather Trim	1946-1947 CvBro
*HA 209965	Spot Lamp Assy-LH-Reflector Type	1946-1947 All
*HA 209966	Spot Lamp Assy-RH-Reflector Type	1946-1947 All
209967	Filler-Bonnet Joint	1946 All
BO 209968	Cable & Plug Assy-Speaker-Radio	1946-1947 All
BO 209969	Spring-Door Lock Bolt	1942-1946-1947 All
209974	Washer Kit-W/S Automatic (Use 210874)	1946-1947 All
*HS 209976	Solvent-W/S Auto Washer-6 oz Bottle-Winter	1946 thru 1950
*SP 209982	Blade-9" Long-W/S Cleaner	1946-1947 All
*HA 209984	Bumper Bar Extension Kit-Front & Rear	51,53,171,173
BO 209986	Covering-Seaming Welt	1946-1947 Bro-Sed-3Cpe-ClubCpe
BO 209987	Glass Jar-Automatic Windshield Washer	1946-1947 All
*SP 209988	Clip-W/S Cleaner Blade	1946-1947 All
BO 209989	Sealed Beam Assy-Headlamp-6V-Export	1947 thru 1950
*SP 209998	Arm & Driving Burrs-Short-W/S Cleaner Adj	1946-1947 All
*SP 209999	Arm & Driving Burr-Long-W/S Cleaner Adj	1946-1947 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*C 210000	Frame & Underbody-Complete-LHD	1948-1949-501 thru 504 Sed-Bro-Cpes
*C 210002	Side Member Assy-Frame-Inner-Frt-RH	1948 thru 1950 Sed-Bro-Cpes
*C 210003	Side Member Assy-Frame-Inner-Frt-LH	1948 thru 1950 Sed-Bro-Cpes
C 210004	Frame & Underbody Assy-Front-um	1948-1949-501 thru 504 Sed-Bro-Cpes
C 210013	Crossmember Assy-#4-Frame	1948 thru 1950
*C 210019	Rear Sub Assy-Frame	1948 thru 1950
C 210023	Center Assy-Underbody Panel	1948 thru 1950
*C 210026	Sidemember-Outer Front-RH-Rear Frame	1948 thru 1950 exc 500
*C 210027	Sidemember-Outer Front-LH-Rear Frame	1948 thru 1950 exc 500
C 210028	Spacer-Frame Sidemember	1948 thru 1950
*C 210030	Cross Member Assy #6-Frame	1948 thru 1950
*C 210040	Toe Board Riser Assy-RH	1948,1949,501 thru 504
*C 210041	Toe Board Riser Assy-LH	1948,1949,501 thru 504
*C 210050	Floor Cover Assy-Trans Opening-LHD	1948,1949
C 210060	Seat Tray Assy-Front	1948 thru 1950
*C 210067	Seat Tray Assy-Rear	1948 thru 1950 Bro-Sed-Cpes
BZ 210068	Brkt-Rear Rocker Panel-RH	1948 thru 1950
BZ 210069	Brkt-Rear Rocker Panel-LH	1948 thru 1950
*C 210070	Roof Panel	1948-1949-500 Bro-Sed
C 210075	Crossmember-Frame-Rear-Outer	1948 thru 1950
C 210077	Crossmember-Frame-Rear-Inner	1948 thru 1950
C 210080	Crossmember Assy-#7-Frame	1948 thru 1950
*C 210086	Suspension Member Assy-Rear Spring-RH	1948 thru 1950
*C 210087	Suspension Member Assy-Rear Spring-LH	1948 thru 1950
*C 210101	Panel-Rear Compt Floor	1948 thru 1950
BO 210107	Seal-Gas Filler Hole	1948 thru 1950
BO 210108	Retainer-Gas Filler Hole Seal-Long	1948 thru 1950
C 210109	Panel Assy-Rear Compt Floor	1948 thru 1950
*C 210110	Wheelhouse Panel-Inner-RH	1948 thru 1950
*C 210111	Wheelhouse Panel-Inner-LH	1948 thru 1950
*C 210112	Wheelhouse Panel-Outer-RH	1948 thru 1950
*C 210113	Wheelhouse Panel-Outer-LH	1948 thru 1950
C 210114	Reinforcement-Rear Window Opening	1948-1949-500 Bro-Sed,1950 Cpes
C 210115	Glass-Rear Window	1948-1949-500 Bro-Sed-Cpes
BO 210116	Lever-Rear Compt Door Latch	482,484,492,494,502,504
BO 210118	Striker-Compt Door	1948 thru 1950
*C 210119 Pr	Door Assy-Rear Compt	482-484-492-494 Bro-Sed
BO 210128	Tapping Plate-Rear Compt Door-RH	1948 thru 1950
BO 210129	Tapping Plate-Rear Compt Door-LH	1948 thru 1950
C 210134	Reinforcement-Rear Fender to Body-RH	1948 thru 1950 Bro-Cpes-CvBro
C 210135	Reinforcement-Rear Fender to Body-LH	1948 thru 1950 Bro-Cpes-CvBro
C 210136	Reinforcement-Rear Fender to Body-RH	1948 thru 1950 Sedan
C 210137	Reinforcement-Rear Fender to Body-LH	1948 thru 1950 Sedan
BO 210160	Retainer-Gas Filler Hole Seal-Short	1948 thru 1950
A 210170 Pr	Splash Guard-Front-Upper	1948-1949
A 210186	Reinforcement-Front Fender to Side Dust Shield-RH	1948,1949,501 thru 504
A 210187	Reinforcement-Front Fender to Side Dust Shield-LH	1948,1949,501 thru 504
BO 210192	Reinforcement Assy-Rear Compt Door Lamp	481,483,491,493,500,501,503
BO 210197	Dash Brkt Assy-Dash to Frame Brace	1948,1949,501 thru 504
*C 210200 Pr	Quarter Panel-Outer-RH	1948 thru 1950 Bro
*C 210201 Pr	Quarter Panel-Outer-LH	1948 thru 1950 Bro
C 210204	Reinforcement-Quarter Panel Flange-RH	1948 thru 1950 exc Sed-Cab-CabPu
C 210205	Reinforcement-Quarter Panel Flange-LH	1948 thru 1950 exc Sed-Cab-CabPu
*C 210210 Pr	Quarter Panel-Outer-RH	1948 thru 1950 Sed
*C 210211 Pr	Quarter Panel-Outer-LH	1948 thru 1950 Sed
C 210214	Reinf-Quarter Panel Flange-RH	1948 thru 1950 Sed
C 210215	Reinf-Quarter Panel Flange-LB	1948 thru 1950 Sed
*C 210216	Quarter Panel Assy-Inner-RH	1948 thru 1950 Sed
*C 210217	Quarter Panel Assy-Inner-LH	1948 thru 1950 Sed
*C 210220 Pr	Quarter Panel-Outer-RH	1948 thru 1950 BsCpe-ClubCpe
*C 210221 Pr	Quarter Panel-Outer-LH	1948 thru 1950 BsCpe-ClubCpe
	210222 Quarter Panel-Inner-RH	1948 thru 1950 BsCpe-ClubCpe
	210223 Quarter Panel-Inner-LH	1948 thru 1950 BsCpe-ClubCpe
*C 210224 Pr	Quarter Panel-Outer-RH	1948 thru 1950 CvBro
*C 210225 Pr	Quarter Panel-Outer-LH	1948 thru 1950 CvBro
BO 210230	Hinge Assy-Lower-F Door-RH	1948 thru 1950 exc CvBro
BO 210231	Hinge Assy-Lower-F Door-LH	1948 thru 1950 exc CvBro
BO 210234	Tapping Plate-Front Pillar Hinge-Lower	1948 thru 1950
BO 210240	Tapping Plate-Front Pillar Hinge-Upper	1948 thru 1950
*C 210246	Pillar Assy-Rear-RH	1948 thru 1950 Sedan
*C 210247	Pillar Assy-Rear-LH	1948 thru 1950 Sedan
*C 210248	Pillar Assy-Rear-RH	482-484-492-494-502-504 Bro-Cpes
*C 210249	Pillar Assy-Rear-LH	482-484-492-494-502-504 Bro-Cpes
BO 210259	Pin-Door Hinge	1948 thru 1950 exc CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 210272	Retainer-Center Pillar Hinge Tapping Plate-Upper-RH	1948 thru 1950 Sedan
BO 210273	Retainer-Center Pillar Hinge Tapping Plate-Upper-LH	1948 thru 1950 Sedan
BO 210274	Tapping Plate-Center Pillar Hinge	1948 thru 1950 Sedan
C 210278	Channel-Rear Door Window Run-Upper-RH	1948 thru 1950 Sedan
C 210279	Channel-Rear Door Window Run-Upper-LH	1948 thru 1950 Sedan
C 210282	Channel-Door Window Run-Upper-RH	1948 thru 1950 Bro-BsCpes-ClubCpe
C 210283	Channel-Door Window Run-Upper-LH	1948 thru 1950 Bro-BsCpes-ClubCpe
BO 210284	Brace-Rear Compt Partition to W/House-RH	1948 thru 1950 BsCpe
BO 210285	Brace-Rear Compt Partition to W/House-LH	1948 thru 1950 BsCpe
*C 210289	Extension Assy-Rear Compt Floor Panel	1948 thru 1950 BsCpe
C 210290	Panel-Rear Compt Opening	1948 thru 1950
BO 210291	Reinforcement-Rear Compt Opening Panel-Lower	1948 thru 1950
C 210292	Channel-Front Door Wdo Run-Upper-RH	1948 thru 1950 Sed-Cab-CabPu
C 210293	Channel-Front Door Wdo Run-Upper-LH	1948 thru 1950 Sed-Cab-CabPu
*C 210298	Front Pillar Assy-RH	482-484-492-494-502-504 exc CvBro
*C 210299	Front Pillar Assy-LH	482-484-492-494-502-504 exc CvBro
BO 210312	Striker-Door Lock-RH	1948
BO 210313	Striker-Door Lock-LH	1948
BO 210324	Support-Horn Bracket-Dash to Frame Brace	1948,1949,501 thru 504
BO 210325	Cover-Pedal Opening	1948 thru 1950
C 210332	Sidemember- Frame-Outer -Rear	1948 thru 1950
C 210334	Weatherseal-Rear Compt Opening	1948 thru 1950 Bro-Sed
C 210335	Weatherseal-Rear Compt Opening	1948 thru 1950 Cpes-CvBro
BZ 210338	Brkt-Brake Hose-On Frame #7 Crossmember	1948 thru 1950
C 210340	Sidemember Assy-Frame-Inner-Rear-RII	1948 thru 1950
C 210341	Sidemember Assy-Frame-Inner-Rear-LH	1948 thru 1950
C 210342	Extension-Inner Rear-Frame Sidemember-RH	1948 thru 1950
C 210343	Extension-Inner Rear-Frame Sidemember-LH	1948 thru 1950
BZ 210346	Cover-Floor Brake Cylinder Hole	1948 thru 1950
BO 210348	Cover-Drain Hole	1948 thru 1950
BZ 210349	Hanger-Gas Tank Strap	1948 thru 1950
210352	Sealing Strip-Fr Fender Side Dust Shield-Upper (Use 216356)	1948
210353	Sealing Strip-Fr Fender Side Dust Shield-Upper (Use 216356)	1948
*HS 210356	Glass Cleaner-10 oz Self-dispensing can	
A 210362 Pr	Reinf Assy-Rear-Hood-RH	1948 thru 1950
A 210363 Pr	Reinf Assy-Rear-Hood-LH	1948 thru 1950
A 210366 Pr	Reinf -Front -Hood	1948,1949
BO 210369	Spring-Hood Lock Safety Hook	1948,1949
BO 210371	Safety Hook-Hood Lock	1948,1949
BO 210372	Lever & Aux Lever Assy-Hood Lock	1948 thru 1950
BO 210373	Rivet-Hood Lock Lever	1948 thru 1950
BO 210374	Retainer-Hood Lock Lift Spring	1948 thru 1950
BO 210376	Spring-Hood Lock Lift	1948 thru 1950
BO 210377	Plunger-Hood Lock	1948 thru 1950
BZ 210384	Reinf-Frt Fender Frt Corner-RH	1948 thru 1950
BZ 210385	Reinf-Frt Fender Frt Corner-LH	1948 thru 1950
*C 210390	Shelf Panel-Rear Seat Back	1948-1949 Bro-Sed
C 210391	Extension-Front Flange-Rear Seat Shelf Panel	1948 thru 1950 Bro-Sed
C 210392	Extension-Rear Seat Shelf Panel	1948-1949 Sed-Bro-Cpes
C 210399	Extension-Front Flange-Rear Seat Shelf Panel	1948 thru 1950 Cpes
BO 210400	Cross Shaft Assy-Cowl Vent	1948 thru 1950
BO 210404	Brkt-Cowl Vent Hinge	1948 thru 1950
BO 210408	Link-Cowl Vent	1948 thru 1950
BO 210411	Spring-Cowl Vent Cross Shaft	1948 thru 1950
210412	Retainer-Front Splash Guard Mldg (Use 213903)	1948,1949
BO 210413	Brkt-Cowl Vent Handle	1948 thru 1950
BO 210414 Pr	Screen-Cowl Vent	1948 thru 1950
C 210415	Extension-Rear Shelf Panel-Front	1948 thru 1950 BsCpe
BO 210416	Hinge-Assy-Cowl Vent-RH	1948 thru 1950
BO 210417	Hinge Assy-Cowl Vent-LH	1948 thru 1950
BO 210420 Pr	Cover Assy-Cowl Vent	1948 thru 1950
BO 210428	Weatherseal-Cowl Vent	1948 thru 1950
BO 210433	Silencer-Cowl Vent Air Duct to Dash	1948,1949,501 thru 504
*C 210436	Air Duct Assy-Cowl Vent	1948,1949,501 thru 504
BO 210440	Drain Pipe-Cowl Vent Air Duct	1948 thru 1950
BO 210441	Rod-Cowl Vent Handle	1948 thru 1950
BO 210445	Weatherseal-Cowl Vent Drain Pipe	1948 thru 1950
BO 210446	Hose-Cowl Vent Drain-LHD	1948 thru 1950
BO 210448	Handle Assy-Cowl Vent	1948,1949
C 210453	Floorboard Assy-Rear Seat Tray	1948 thru 1950 BsCpe
BO 210454	Brkt-Cowl Vent Air Duct to Radio	1948,1949
*C 210460	Cowl Side Panel-RH	1948-1949 Sed-Bro-ClubCpe-BsCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*C 210461	Cowl Side Panel-LH (Use 221527)	1948-1949 Sed-Bro-ClubCpe-BsCpe
BO 210466 Pr	Brace Assy-Cowl Side Panel to Frame-Right-LHD	1948,1949
BO 210467	Brace Assy-Cowl Side Panel to Frame-Left (Use 220135)	1948-1949 exc CvBro
C 210474	Panel Assy-Rear Compt Seat Back-RH	1948-1949 ClubCpe
C 210475	Panel Assy-Rear Compt Seat Back-LH	1948-1949 ClubCpe
*A 210481	Tie Panel & Hood Lock Supt Assy-F Fender	1948,1949
BZ 210482	Bracket-Frt Fender Tie Panel-RH	1948 thru 1950
BZ 210483	Bracket-Frt Fender Tie Panel-LH	1948 thru 1950
BO 210484	Retainer-Rear Compt Floor to Rear Seat Tray Trimboard	1948 thru 1950 BsCpe
BO 210485	Name Plate-Rear Compt Door	482,484,492,494
210488	Panel Assy-Qtr Wdo Reg-RH (Use 216608)	1948 CvBro
210489	Panel Assy-Qtr Wdo Reg-LH (Use 216609)	1948 CvBro
*A 210502	Reinf Assy-Front Fender to Side Dust Shield-RH	1948-1949,501 thru 504
*A 210503	Reinf Assy-Front Fender to Side Dust Shield-LIT	1948-1949,501 thru 504
BO 210509	Weatherstrip-Rear Window	1948-1949-500 Bro-Sed-Cpes
BO 210510	Weatherstrip-Windshield-RH	1948 thru 1950
BO 210511	Weatherstrip-Windshield-LH	1948 thru 1950
C 210512	Glass-Windshield-RH	1948 thru 1950
C 210513	Glass-Windshield-LH	1948 thru 1950
BO 210518	Brkt-Front Domelamps	1948 thru 1950 exc CvBro
BO 210519	Brkt-Rear View Mirror	1948 thru 1950
*C 210521	Header Assy-Windshield	1948 thru 1950 exc CvBro
*C 210526	Header Assy-Windshield	1948 thru 1950 CvBro
*C 210535	Mounting Channel Assy-Radiator Core	1948 thru 1950
*C 210542	Roof Front Panel	1948 thru 1950 CvBro
BZ 210548	Pad-Radiator Core Mounting Channel	1948 thru 1950
BZ 210549	Shim-Radiator Core Mounting Channel	1948,1949
C 210551	Front End Panel	1948 thru 1950
A 210564 Pr	Splash Guard-Lower Front-RH	1948,1949
A 210565 Pr	Splash Guard-Lower Front-LH	1948,1949
BO 210568	Joint Cover-Lower-Front Splash Guard	1948,1949
BO 210573	Shim-Front End Panel to Hood	1948 thru 1950
A 210576	Radiator Air Deflection-Upper	481,482,491,492,501,502
BO 210584	Retainer-Lower-Windshield Glass (Use 217109)	1948,1949
BO 210608	Screw-Assist Strap	481-483-491-493-500-501-503 Sed-Bro-ClubCpe
BZ 210619	Seal Washer-Front Fender Name Plate	1948,1949,501 thru 504
BZ 210622	Name Plate-Front Fender-RH	1948,1949
BZ 210623	Name Plate-Front Fender-LH	1948,1949
*A 210630 Pr	Hood Assy	1948,1949
C 210633	Silencer-Wheelhouse Inner Panel	1948 thru 1950 Bro-Sed
C 210634 Pr	Cowl Side Panel-RH	481 CvBro with Manual Wdo Reg
C 210635 Pr	Cowl Side Panel-LH	481 CvBro with Manual Wdo Reg
*HS 210637	Chamois-Car Washing	
*C 210638	Front End Panel Assy	1948 thru 1950 exc CvBro
*C 210639	Front End Panel Assy	1948 thru 1950 CvBro
BO 210641	Ornament-Hood Crest	482,484,492,494
BO 210642	Bumper-Hood Front	1948 thru 1950
BO 210645	Ornament-Hood Top	481,483,491,493
BO 210646	Crest-Hood	482,484,492,494
*HA 210654	Mirror Assy-Outside Rear View	1948 thru 1950
BZ 210669	Bolt-Frt & Rr Bumper Impact Bar	1948 thru 1950
C 210674	Extension Assy-Rear Compt Floor Panel	482-484-492-494-502-504 ClubCpe
C 210695	Extension Assy-Rear Compt Floor Panel	481-483-491-493-500-501-503 ClubCpe
*C 210708	Body Header & Reinforcement Assy-RH	1948 thru 1950 Sed
*C 210709	Body Header & Reinforcement Assy-LH	1948 thru 1950 Sed
*C 210714	Body Header & Reinf Assy-RH	1948 thru 1950 BsCpe-ClubCpe
*C 210715	Body Header & Reinf Assy-LH	1948 thru 1950 BsCpe-ClubCpe
*C 210726	Body Header & Reinf Assy-RH	482-484-492-494-502-504 Bro
*C 210727	Body Header & Reinf Assy-LH	482-484-492-494-502-504 Bro
*C 210728	Body Header & Reinf Assy-RH	481-483-491-493-500-501-503 Bro
*C 210729	Body Header & Reinf Assy-LH	481-483-491-493-500-501-503 Bro
C 210733	Spring-Rear Seat Center Arm Rest	482-484-492-494-502-504 Bro-Sed-ClubCpe
210734	Spring-Rear Seat Cushion (Use 214591)	1948 Sed-Bro
C 210735	Spring-Rear Seat Back	481-483-491-493-500-501-503 Bro-Sed
C 210736	Spring-Rear Seat Back-RH	482-484-492-494-502-504 Sed-Bro
C 210737	Spring-Rear Seat Back-LH	482-484-492-494-502-504 Sed-Bro
BO 210740	Grommet-Roof Bow	1948 thru 1950 Bro-Sed-Cpes
C 210741	Spring-Front Seat Back	1948 Sedan
C 210742	Pad & Protector Assy-Seat Cushion-With Rubber Pads	1948 thru 1950 exc CvBro
C 210743	Spring-Front Seat Cushion	1948-1949-501 thru 504 Sedan
C 210744	Spring-Front Seat Cushion	1948-1949-501 thru 504 Bro-Cpes
BO 210745	Bracket-Roof Bow #5	1948 thru 1950 Bro-Sed-Cpes
C 210746	Spring-Front Seat Back-RH	1948 Bro-BsCpe-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 210747	Spring-Front Seat Back-LH	1948 Bro-BsCpe-ClubCpe
C 210748	Silencer-Roof Panel	1948-1949 Sed-Bro
C 210749	Silencer-Roof Panel	1948-1949 BsCpe-ClubCpe
BO 210752	Check Arm Assy-Door	1948 thru 1950
BO 210753	Check Arm Assy-Rear Door	1948 thru 1950 Sedan
BO 210754	Guide-Door Check Arm	1948 thru 1950
BO 210755	Rivet-Door Check Arm	1948 thru 1950
*HA 210756	Mirror Assy-Rear View Oval	1948,1949
C 210761	Roof Bow #1	1948 Sed,1948-1949 Bro-Cpes
C 210762	Roof Bow #2	1948 Sed
C 210763	Roof Bow #3	1948 Sed
C 210764	Roof Bow #4	1948 Sed
C 210765	Roof Bow #5	1948 Sed
C 210766	Roof Bow #6	1948 Sed
C 210767	Roof Bow #7	1948-1949 Sed
C 210768	Roof Bow #2	1948-1949 Bro-Cpes
C 210769	Roof Bow #3	1948-1949 Bro-Cpes
*C 210770 Pr	Roof Panel	1948 thru 1950 BsCpe-ClubCpe
C 210774	Roof Bow #4	1948-1949 Bro
C 210775	Roof Bow #5	1948-1949 Bro
C 210776	Roof Bow #6	1948-1949 Bro
C 210777	Roof Bow #7	1948-1949 Bro
BO 210780	Center Bar-Outer-Windshield	1948 thru 1950
BO 210781	Finish Mldg-Windshield Center	1948 thru 1950
210789	Air Stop Block-Windshield Lower Mldg (Use 214967)	1948
C 210794	Brace Assy-Cowl Side Panel to Frame-RH	1948,1949
BO 210802	Bracket-Rear Compt Door Striker	1948 thru 1950
BO 210806	Cover-Rear Compt Door Hinge	1948,1949
BO 210808	Spring-Rear Compt Door Striker	1948 thru 1950
BO 210810	Link-Rear Compt Door Latch-RH	482,484,492,494,502,504
BO 210811	Link-Rear Compt Door Latch-LH	482,484,492,494,502,504
BO 210812	Clamp Lever & Brkt Assy-Rear Compt Floor-RH	1948 thru 1950
BO 210813	Clamp Lever & Brkt Assy-Rear Compt Floor-LH	1948 thru 1950
BO 210814	Cover Assy-Rear Compt Door Hinge	1948-1949 A11,1950 CvBro
BO 210816	Ornament-Front Fender	1948,1949
210818	Body Header & Reinf Assy-RH (Use 210708)	482-484 Sed
210819	Body Header & Reinf Assy-LH (Use 210709)	482-484 Sed
C 210820	Silencer-Rear Compt Outer Panel	1948 thru 1950 Bro-Sed
C 210821	Silencer-Toe Board Riser	1948
C 210824	Silencer-Underbody Center Panel-Rear-RH	1948
C 210825	Silencer-Underbody Center Panel-Rear-LH	1948
C 210826	Silencer-Underbody Center Panel Side	1948
*HA 210827	Rear View Mirror (Glare Proof)	1948 thru 1950
*HA 210828	Radiator Grille Guard Kit	1948,1949
BO 210829	Clip-Trimboard Retaining	1948 thru 1950
BZ 210830	Brkt-Rear Spring Front Eye-Outer	1948 thru 1950
BZ 210831	Brkt-Rear Spring Front Eye- Inner	1948 thru 1950
BZ 210840	Brkt-Rear Spring Rear Mounting-RH	1948 thru 1950
BZ 210841	Brkt-Rear Spring Rear Mounting-LH	1948 thru 1950
C 210853	Finish Panel Assy-Front-Roof	1948 thru 1950 CvBro
BO 210854	Door Safety Lock Assy-Less Cyl	1948 thru 1950
BO 210858	Door Safety Lock & Cyl-With Keys	1948 thru 1950
HZ 210866	Brkt & Arm Assy-Rear License Plate	1948,1949
C 210870	Reinforcement-Quarter Window Opening-RH	1948 thru 1950 Sed
C 210871	Reinforcement-Quarter Window Opening-LH	1948 thru 1950 Sed
C 210872	Glass-Quarter Wing	1948-1949-501 thru 504 Sedan
C 210873	Glass-F Door Wing	1948 thru 1950 exc CvBro
*HA 210874	Automatic W/Shield Washer Kit	1948,1949
C 210875	Glass-Rear Door	1948 thru 1950
C 210877	Glass-Front Door	1948 thru 1950 Sed-Cab-CabPu
C 210880	Glass-Door	1948 thru 1950 Bro-Cpes
C 210881	Glass-Rear Qtr Window	1948 thru 1950 Bro
*C 210887	Extension Assy-Rear Compt Floor Panel	1948 thru 1950
BO 210888	Bumper-Door	1948-1949 exc CvBro,1950 Sed-Cab-CabPu
BO 210889	Cylinder & Keys Assy-Door Safety Lock	1948 thru 1950
BO 210909	Joint Cover-Window Reveal Mldg	1948 thru 1950 Bro-Sed-Cpes
C 210912	Reveal Mldg-Qtr Window-RH	1948 thru 1950 Sed
C 210913	Reveal Mldg-Qtr Window-LH	1948 thru 1950 Sed
BO 210915	Brkt Assy-Front Dome Lamp	1948 thru 1950 Bro-Sed-Cpes
C 210928	Side Member Assy-Inner Front-Rear Frame-RH	1948 thru 1950 CvBro exc 500
C 210929	Side Meber Assy-Inner Front-Rear Frame-LH	1948 thru 1950 CvBro exc 500
BO 210930	Filler-Frt Door Window Finish Molding	1948 thru 1950 Sed
BO 210931	Air Stop Block-Windshield Lower Finish Mldg-Rear	1948 thru 1950
BO 210936	Seal Washer-Front Fender Ornament	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 210950	Filler-Wdo Finish Mldg	1948,1949
BO 210952	Spacer-Qtr Window Finish Mldg	1948 thru 1950 Bro
BO 210959	Cylinder-Door Safety Lock	1948 thru 1950
C 210964	Body Header-Front-RH	1948 thru 1950 CvBro
C 210965	Body Header-Front-LH	1948 thru 1950 CvBro
C 210966	Reveal Mldg-Rear Window-RH	1948-1949 Bro-Sed-Cpes,501 thru 504 Cpes, 500 exc CvBro
C 210967	Reveal Mldg-Rear Window-LH	1948-1949 Bro-Sed-Cpes,501 thru 504 Cpes, 500 exc CvBro
C 210968	Spring-Rear Seat Cushion	1948 ClubCpe
C 210969	Spring-Rear Seat Back	481-483-491-493-500-501-503 ClubCpe
C 210970	Finish Mldg-Windshield-Upper-RH	1948,1949
C 210971	Finish Mldg-Windshield-Upper-LH	1948,1949
BO 210982	Filler-Wdo Finish Mldg-Door & Qtr	1948 thru 1950 Sed-Bro-Cpes
BZ 210983	Bolt Pkg-License Plate Frame	For Assy's 206675 thru 206687
C 210984	Reveal Mldg-Windshield-RH	1948 thru 1950
C 210985	Reveal Mldg-Windshield-LH	1948 thru 1950
C 210986	Reveal Mldg-Windshield-Center-RH	1948 thru 1950
BO 210987	Reveal Mldg-Windshield-Center-LH	1948 thru 1950
C 210988	Spring-Rear Seat Back-RH	482-484-492-494-502-504 ClubCpe
C 210989	Spring-Rear Seat Back-LH	482-484-492-494-502-504 ClubCpe
C 210990	Scuff Plate-Door-RH	481-483-491-493 exc Sed
210991	Scuff Plate-Door-LH (Use 216811)	481-483-491-493 exc Sed
C 210992	Scuff Plate-Door-RH	482-484-492-494 Cpes-CvBro
C 210993	Scuff Plate-Door-LH	482-484-492-494 Cpes-CvBro
C 210994	Scuff Plate-Front Door-RH	481-483-491-493 Sed
C 210995	Scuff Plate-Front Door-LH	481-483-491-493 Sed
C 210996	Scuff Plate-Front Door-RH	482-484-492-494 Sed
C 210997	Scuff Plate-Front Door-LB	482-484-492-494 Sed
BO 210998	Clip-End-Radiator Grille Mldg	1948,1949
C 211004	Stone Guard Assy-Rear	1948,1949,501 thru 504
*HS 211005	Tar & Road Oil Remover-8 oz	All
BO 211008	Brace Assy-Dash to Frame-RH	1948
BO 211009	Brace Assy-Dash to Frame-LH	1948
C 211010	Scuff Plate-Rear Door-RH	481-483-491-493 Sedan
C 211011	Scuff Plate-Rear Door-LH	481-483-491-493 Sedan
C 211012	Scuff Plate-Rear Door-RH	482-484-492-494 Sedan
211013	Scuff Plate-Rear Door-LH	482-484-492-494 Sedan
BO 211025	Lens-Courtesy Lamp	482,484,492,494,502,504
C 211026	Rubber Pad-Front Seat Cushion Spring-Cloth Trim	481-483-491-493-500 Sed
C 211027	Rubber Pad-Rear Seat Cushion Spring-Cloth Trim	481-483-491-493-500 Bro-Sed-ClubCpe
C 211030	Channel-Quarter Window Glass Run-RH	1948-1949 Bro
C 211031	Channel-Quarter Window Glass Run-LH	1948-1949 Bro
*HS 211035	Owner Supply Kit	All
BO 211048	Spacer Assy-Visor-W/Shield Opening Reinf-RH	482-484 with Lea Trim
BO 211049	Spacer Assy-Visor-W/Shield Opening Reinf-LH	482-484 with Lea Trim
BO 211051	Spacer-Visor-Lea Trim	482-484-492-494-502-504 exc CvBro
C 211060	Filler-Qtr Window Finish Mldg-Rli	1948 thru 1950 Bro
C 211061	Filler-Qtr Window Finish Mldg-LH	1948 thru 1950 Bro
C 211062	Glass Run & Clip Assy-Fr Door Window-RH	1948 thru 1950 Sed-Cab-CabPu
C 211063	Glass Run & Clip Assy-Fr Door Window-LH	1948 thru 1950 Sed-Cab-CabPu
C 211066	Glass Run & Clip Assy-Door Window-RH	1948 thru 1950 Bro-Cpes
C 211067	Glass Run & Clip Assy-Door Window-LH	1948 thru 1950 Bro-Cpes
BO 211068	Clip-Door Window Run Retaining	1948 thru 1950 exc CvBro
BO 211069	Clip-Rear Door & Quarter Wdo Run Retaining	1948 thru 1950 Bro-Sed-Cpes
BO 211087	License Lamp Assy-Rear Compt Door	481,483,491,493,500
211090	Channel Assy-Door Window Glass Run-Lower-RH (Use 217390)	1948-1949 exc CvBro
211091	Channel Assy-Door Window Glass Run-Lower-LH (Use 217391)	1948-1949 exc CvBro
BO 211096	Brkt-Door Check Arm	1948 thru 1950
*C 211104	Stone Guard Assy-Front Fender-RH	1948,1949,501 thru 504
*C 211105	Stone Guard Assy-Front Fender-LH	1948,1949,501 thru 504'
BZ 211106	Bumper-Rear Compt	1948 thru 1950
BO 211107	Bracket-Seat Back Spring Hanger	1948 thru 1950 Bro-Sed-ClubCpe
BO 211109	Bracket-Rear Seat Cushion Spring Locating	1948 thru 1950 Bro-Sed
211110	Weatherstrip-Door Bottom-RH (Use 216166)	1948 Bro-ClubCpe-BsCpe-CvBro
211111	Weatherstrip-Door Bottom-LH (Use 216167)	1948 Bro-ClubCpe-BsCpe-CvBro
211112	Weatherstrip-Front Door Bottom-RH (Use 216168)	1948 Sed
211113	Weatherstrip-Front Door Bottom-LH (Use 216169)	1948 Sed
211114	Weatherstrip-Rear Door Bottom-RH (Use 216170)	1948 Sed
211115	Weatherstrip-Rear Door Bottom-LH (Use 216171)	1948 Sed
BO 211117	Brace Assy-Cowl Side Panel to Frame-LH	1948-1949 CvBro
211122	Filler-Door Wdo Finish Mldg-RH (Use 210950)	481 exc CvBro,483

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
211123	Filler-Door Wdo Finish Mldg-LH (Use 210950)	481 exc CvBro,483
*HA 211125	Rear Bumper Center Guard Kit	1948,1949,500
BZ 211131	Bracket Assy-Rear Stabilizer	1948 thru 1950
BZ 211138	Support Assy-Spare Wheel	1948,1949
BZ 211139	Reinforcement-Spare Wheel Support	1948 thru 1950
C 211141	Cover Assy-Rear Compt Spare Wheel	1948 thru 1950
A 211144	Extension-Rocker Panel-RH	1948 thru 1950 Bro-ClubCpe-BsCpe-CvBro
A 211145	Extension-Rocker Panel-LH	1948 thru 1950 Bro-ClubCpe-BsCpe-CvBro
A 211146	Extension-Rocker Panel-Front-RH	1948 thru 1950 Sedan
A 211147	Extension-Rocker Panel-Front-LH	1948 thru 1950 Sedan
A 211148	Extension-Rocker Panel-Rear-RH	1948 thru 1950 Sedan
A 211149	Extension-Rocker Panel-Rear-LH	1948 thru 1950 Sedan
BO 211150	Water Baffle-Quarter Window	1948-1949-501 thru 504 Sedan
BO 211151	Support-Quarter Window Water Baffle	1948-1949-501 thru 504 Sedan
A 211156 Pr	Rocker Panel Assy-Rear-RH	482,484,492,494,502,504
A 211157 Pr	Rocker Panel Assy-Rear-LH	482,484,492,494,502,504
A 211158 Pr	Rocker Panel Assy-Rear-RH	481,483,491,493,501,503
A 211159 Pr	Rocker Panel Assy-Rear-LH	481,483,491,493,501,503
BO 211162	Control Assy-Hood Lock	1948,1949
211163	Wire & Knob Assy-Hood Lock Control (Use 216770)	1948,1949
BO 211166	Hood Lock Assy-Upper Half	1938,1949
BO 211167	Hood Lock Assy-Lower Half	1948,1949
BO 211175	Spring-Hood Lock Lever	1948,1949
BO 211185	Stiffener-Hood Lock Upper Mounting Plate	1948 thru 1950
211207	Plug-Rocker Panel Extension to Center Pillar (Use 216037)	1948 Sed
BO 211212	Brace-Strg Column to Front End Panel	1948
BO 211216	Clamp-Cigar Lighter Base	1948 thru 1950
BO 211217	Element & Knob Assy-Cigar Lighter	482,484,492,494,502,504
BO 211218	Base & Wire Assy-Cigar Lighter	1948 thru 1950
BO 211219	Knob Assy-Cigar Lighter	482,484,492,494,502,504
C 211223	Support Assy-Instrument Panel-LIED	1948,1949
*HA 211233	Spot Lamp Kit-LH	1948 thru 1950
*HA 211234	Spot Lamp Kit-RH	1948 thru 1950
211237	Mldg-Top Front Header-Front Upper (Use 216867)	1948-1949 CvBro
*C 211239 Pr	Door Assy-Rear Compt	481-483-491-493 Bro-Sed
BO 211241	Escutcheon-Cigar Lighter Housing	1948 thru 1950
BO 211243	Bracket-Hood Lock Control	1948,1949,501 thru 504
BO 211244	Support-Hood Lock Control Brkt-RHD	1948,1949
*C 211245 Pr	Door Assy-Rear Compt	482-484-492-494 ClubCpe-BsCpe-CvBro
*C 211246 Pr	Door Assy-Rear Compt	481-483-491-493 ClubCpe-BsCpe-CvBro
211247	Filler-Headlining to Windshield Header	1948 thru 1950 Bro-Sed-Cpes
211248	Weatherseal-Rear Wheel Cover to Frame (Use 216658)	1948
C 211254 Pr	Cover & Rod Assy-Rear Wheel-RH	482,484,492,494,502,504
C 211255 Pr	Cover & Rod Assy-Rear Wheel-LH	482,484,492,494,502,504
C 211256 Pr	Cover & Rod Assy-Rear Wheel-RH	481,483,491,493,501,503
C 211257 Pr	Cover & Rod Assy-Rear Wheel-LH	481,483,491,493,501,503
*C 211262	Cowl Side Panel-RH	1948-1949 CvBro
*C 211263	Cowl Side Panel-LH	1948-1949 CvBro
BZ 211264	Clip-Rear Wheel Cover to Frame	1948 thru 1950
211270	Mat & Pad Assy-Front Floor-Black-LHD (Use 213642)	481,483
211272	Mat & Pad Assy-Front Floor-Taupe-LHD (Use 213643)	1948 exc 481 CvBro
C 211274	Mat & Pad Assy-Front Floor-RHD	481,483
C 211275	Mat & Pad Assy-Front Floor-RHD	1948
BO 211278	Bracket Assy-RH-Support to Pillar-RHD	1948,1949,501 thru 504
BO 211279	Bracket Assy-LH-Support to Pillar	1948,1949,501 thru 504
BO 211280	Bolt-Rocker Panel Upper & Lower Mldg	1948 thru 1950
BO 211281	Filler-Strg Column-Front Floor Mat-LIED	1948 thru 1950
BZ 211288	Seal-Frame Side Member to Rear Fender	1948 thru 1950
BO 211289	Retainer-Rear Rocker Panel Lower Mldg	1948 thru 1950
BZ 211297	Plate-Rear Fender to Qtr Panel Bolt	1948 thru 1950
BO 211298	Retainer-Rocker Panel & Rear Wheel Cover Mldg	1948 thru 1950
BO 211299	Bolt-Rocker Panel & Rear Wheel Cover Mldg	482,484,492,494,502,504
BZ 211300	Filler-Rocker Panel to Frame-Rear-RH	1948 thru 1950
BZ 211301	Filler-Rocker Panel to Frame-Rear-LH	1948 thru 1950
BZ 211302	Bracket-Rocker Panel-Rear-RH	1948 thru 1950
BZ 211303	Bracket-Rocker Panel-Rear-LH	1948 thru 1950
BZ 211304	Filler-Rear Rocker Panel to Frame-RH	1948 thru 1950
BZ 211305	Filler-Rear Rocker Panel to Frame-LH	1948 thru 1950
BO 211307	Retainer-Rocker Panel Upper Mldg	482,484,492,494,502,504
BO 211311	Lens & Rim Assy-Front Dome Lamp	1948 thru 1950 exc 500
BO 211312	Reflector & Switch Assy-Front Dome Lamp	1948 thru 1950 exc 500
211315	Extension Assy-Outer-Rear Curtain	1948 thru 1950 CvBro with Plastic Wdo
C 211316	Pad Assy-Top Deck	1948-1949 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 211317	Pad Assy-Top Deck	1948-1949 CvBro
BO 211321	Filler Block-Fr Fender to Pillar Brkt	1948 thru 1950
BO 211321	Filler Block-Sidemember to Rear Fender Hole	1948-1949 Sed
C 211323	Support Assy-Instrument Panel-RHD	1948-1949 Sed-Bro-Cpes
C 211324	Retainer-Headlining-RH-Rear	1948 thru 1950 Sedan
C 211325	Retainer-Headlining-LH-Rear	1948 thru 1950 Sedan
BO 211326	Retainer-Windlace-RH-Front	1948 thru 1950 exc CvBro
BO 211327	Retainer-Windlace-LH-Front	1948 thru 1950 exc CvBro
C 211328	Retainer-Headlining-RH-Rear	1948 thru 1950 Bro-Cpes
C 211329	Retainer-Headlining-LH-Rear	1948 thru 1950 Bro-Cpes
BO 211331	Lever-Rear Compt Door Latch Operating	481,483,491,493,500,501,503
BO 211332	Link-Rear Compt Door Latch	481,483,491,493,500,500,501,503
BO 211343	Clamp-Hood Lock Control Cable	1948
*A 211344 Pr	Rocker Panel Assy-RH	481-483-491-493-501-503 Sedan
*A 211345 Pr	Rocker Panel Assy-LH	481-483-491-493-501-503 Sedan
*A 211346 Pr	Rocker Panel Assy-RH	482-484-492-494-502-504 Sedan
*A 211347 Pr	Rocker Panel Assy-LH	482-484-492-494-502-504 Sedan
211348	Carpet Assy-Front Seat Side Panel Ext-RH	1948 ClubCpe-CvBro
211349	Carpet Assy-Front Seat Side Panel Ext-LH	1948 ClubCpe-CvBro
*A 211354 Pr	Rocker Panel Assy-RH	481-483-491-493-501-503 exc Sedan
*A 211355 Pr	Rocker Panel Assy-LH	481-483-491-493-501-503 exc Sedan
*A 211356 Pr	Rocker Panel Assy-RH	482-484-492-494-502-504 exc Sedan
*A 211357 Pr	Rocker Panel Assy-LH	482-484-492-494-502-504 exc Sedan
BO 211371	Arm Rest Assy-Door-Cloth Trim	481-491 BsCpe
BZ 211373	Weatherseal-Rear Wheel Cover-Upper	1948 thru 1950
BZ 211374	Weatherseal-Rear Wheel Cover-End	1948 thru 1950
BO 211378	Molding-Lower-Front Fender	1948,1949
C 211380	Molding-Lower-Rear Fender	1948-1949-500 Sedan
C 211381	Molding-Lower-Rear Fender	1948-1949-500 Bro-Cpes-CvBro
211389	Retainer-R Fender Panel Lower Mldg-Short (Use 212288)	1948 Sed
BO 211396	Reinforcement-Side Assy-Rear Compt Opening-RH	1948 thru 1950
BO 211397	Reinforcement-Side Assy-Rear Compt Opening-LH	1948 thru 1950
*C 211398	Rear Compt Opening Panel Assy-RH Side	1948 thru 1950 BsCpe-ClubCpe-CvBro
*C 211399	Rear Compt Opening Panel Assy-LH Side	1948 thru 1950 BsCpe-ClubCpe-CvBro
*C 211400	Rear Compt Opening Panel Assy-RH Side	1948 thru 1950 Bro-Sed
*C 211401	Rear Compt Opening Panel Assy-LH Side	1948 thru 1950 Bro-Sed
C 211410	Shelf Panel-Rear Seat Back	1948 thru 1950 Cpes
BZ 211421	Washer-F Bumper Impact Bar Bolt	481,483
*BO 211430	Speedometer Assy-Miles	482,484,492,494
BO 211431	Speedometer Assy-Metric	482,484,492,494
*BO 211432	Speedometer Assy-Miles	481,483,491,493
BO 211433	Speedometer Assy-Metric	481,483,491,493
BO 211437	Clock Assy-Mechanical	481,483,491,493
C 211442	Panel-Upper-Rear Compt Opening	1948 thru 1950 CvBro
C 211443	Molding-Rocker Panel Extension	1948-1949 Bro-Cpes-CvBro
C 211444	Molding-Front-Rocker Panel Extension	1948-1949 Sedan
C 211445	Molding-Rear-Rocker Panel Extension	1948-1949 Sedan
BO 211446	Clock Assy-Electric	481,483,491,493
BO 211447	Clock Assy-Electric	482,484,492,494
*HA 211448	Electric Clock Kit	481,483,491,493
BO 211449	Wire Assy-Electric Clock	1948,1949,1950
BO 211450	Hinge Assy-RH-Glove Box-RHD	1948,1949
BO 211450	Hinge Assy-Inst Mtg Panel-RHD	1950
BO 211451	Hinge Assy-LH-Glove Box-LHD	1948,1949
BO 211451	Hinge Assy-Inst Mtg Panel-LHD	1950
BO 211468	Knob-Clock	482,484,492,494,501 thru 504
BO 211469	Nut-Clock Knob	482,484,492,494,501 thru 504
BO 211471	Lock,Cylinder & Keys-Glove Box Door	1948 thru 1950
BO 211474	Cylinder-uncoded-Glove Box Door Lock	1948 thru 1950
BO 211475	Cylinder and Keys-Glove Box Door Lock	1948 thru 1950
C 211476	Brace Assy-Rear Compt Opening Upper Panel	1948-1949 CvBro
BO 211478	Striker-Glove Box Door Lock	1948 thru .1950
*A 211482	Front Extension Assy-Front Fender-RH	1948,1949
*A 211483	Front Extension Assy-Front Fender-LH	1948,1949
BO 211485	Seal-Steering Column Hole	1948,1949
BO 211486	Bezel-Electrical & Mechanical Clock	1948,1949,501 thru 504
BO 211487	Retainer-Steering Column Hole Seal	1948,1949
211488	Crystal-Electrical & Mechanical Clock (Use 217348)	1948,1949
BO 211489	Gasket-Electrical & Mechanical Clock Crystal	1948,1949,1950
BO 211497	Bracket-Steering Column	481,483,491,493,501,503
BO 211498	Bracket-Steering Column	482,484,492,494,502,504
211500	Baffle-Radiator Grille-Upper-RH (Use 212273)	1948,1949
211501	Baffle-Radiator Grille-Upper-LH (Use 212273)	1948,1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
211502	Baffle-Radiator Grille-Center-RH (Use 212274)	1948,1949
211503	Baffle-Radiator Grille-Center-LH (Use 212274)	1948,1949
211504	Baffle-Radiator Grille-Lower-RH (Use 212275)	1948,1949
211505	Baffle-Radiator Grille-Lower-LH (Use 212275)	1948,1949
BO 211506	Cap-Strg Column Brkt-Without DI	482,484,492,494,502,504
BO 211507	Cap-Strg Column Brkt-With DI	482,484,492,494,502,504
BO 211512	Housing-Hood Front Ornament	1948,1949
BO 211513	Ornament Assy-Hood Front	1948,1949
BO 211514	Lens-Hood Front Ornament	1948,1949
BO 211517	Clamp-Hood Front Ornament	1948 thru 1950
BO 211519	Stud-Hood Front Ornament Housing	1948 thru 1950
BO 211523	Handle-Front Seat Adjusting-LHD	1948-1949-501 thru 504
BO 211525	Bracket-Front Seat Adjusting Handle Link	1948 thru 1950
211530	Tail Lamp Assy-RH (Use 216350)	481,483
211531	Tail Lamp Assy-LH (Use 216351)	481,483
211532	Bezel Assy-Tail Lamp-RH (Use 216352)	481,483
211533	Bezel Assy-Tail Lamp-LH (Use 216353)	481,483
211534	Base Plate-Tail Lamp-RH (Use 216354)	481,483
211535	Base Plate-Tail Lamp-LH (Use 216355)	481,483
BO 211536	Lens-Tail Lamp	481,483,491,493,500,501,503
211537	Gasket-Tail Lamp Lens (Use 216327)	481,483
BO 211538	Pad-Tail Lamp Housing	481,483,491,493,500,501,503
211540	Tail Lamp Assy-RH (Use 216340)	482,484
211541	Tail Lamp Assy-LH (Use 216341)	482,484
211542	Bezel Assy-Tail Lamp-RH (Use 216342)	482,484
BO 211543	Bezel Assy-Tail Lamp-LH	482,484
211544	Base Plate-Tail Lamp (Use 216458)	482,484
BO 211546	Lens-Tail Lamp	482,484,492,494,502,504
211547	Gasket-Tail Lamp Lens (Use 216326)	482,484
BO 211548	Pad-Tail Lamp Housing	482,484,492,494,502,504
BO 211549	Ornament-Tail Lamp	482,484
BO 211552	Regulator Assy-Quarter Wdo-RH	1948 thru 1950 Bro-ClubCpe
BO 211553	Regulator Assy-Quarter Wdo-LH	1948 thru 1950 Bro-ClubCpe
BO 211554	Spring-Tail Lamp Ornament Retainer	482,484,492,494
BO 211555	Bracket-Tail Lamp Ornament Retainer	482,484,492,494
C 211556	Channel-Upper-RH-Quarter Window Glass Run	1948-1949 Cpes
C 211557	Channel-Upper-LH-Quarter Window Glass Run	1948-1949 Cpes
C 211560	Molding-Radiator Grille-Center	1948,1949
C 211561	Molding-Radiator Grille-Lower	1948,1949
BO 211562	Clamp-Hood Lock Contact Cable	1948 thru 1950
C 211563	Molding-Radiator Grille-Upper	1948,1949
BO 211570	Rest Channel Assy-Door Window-RH	1948 thru 1950 Bro-ClubCpes-BsCpe
BO 211571	Rest Channel Assy-Door Window-LH	1948 thru 1950 Bro-ClubCpes-BsCpe
BO 211572	Rest Channel Assy-Front Door Glass-RH	1948 thru 1950 Sed-Cab-CabPu
BO 211573	Rest Channel Assy-Front Door Glass-LH	1948 thru 1950 Sed-Cab-CabPu
BO 211574	Rest Channel Assy-Rear Door Glass-RH	1948 thru 1950 Sedan
BO 211575	Rest Channel Assy-Rear Door Glass-LB	1948 thru 1950 Sedan
C 211585	Carpet Assy-F Seat Foot Rest	1948-1949 Bro
BO 211590	Weatherseal-F Door Glass Rest Channel (Use 217066-RH & 217067-LH)	1948-1949. Sed
BO 211591	Weatherseal-R Door Glass Rest Channel	1948-1949 Sed
BO 211592	Weatherseal-Door Glass Rest Channel	1948-1949 Bro-Cpes
BO 211593	Weatherseal-Qtr Window Glass Rest Channel-RH	1948-1949 BsCpe-ClubCpe
BO 211594	Weatherseal-Qtr Window Glass Rest Channel-LH	1948-1949 Bro
C 211616	Toe Board Riser Assy-RH-RHD	1948,1949,501 thru 504
C 211617	Toe Board Riser Assy-LH-RHD	1948,1949,501 thru 504
BO 211618	Clip-Instr Mtg Panel or Stationary Glove Box Door	1948 thru 1950
BO 211619	Clip-Glove Box Door-Lower	1948
BO 211640	Grille-Radio Speaker	1948,1949
BO 211650	Regulator Assy-Rear Door Window-RH	1948 thru 1950 Sed
BO 211651	Regulator Assy-Rear Door Window-LH	1948 thru 1950 Sed
BO 211657	Clip-Wdo Regulator Link Roller Stud	1948 thru 1950 Bro-Cpes,481-491-500-501 CvBro
*A 211658 Pr	Sealing Strip Assy-Front Fender-RH	1948,1949,501 thru 504
*A 211659 Pr	Sealing Strip Assy-Front Fender-LH	1948,1949,501 thru 504
BO 211660	Regulator Assy-Front Door Window-RH	1948 thru 1950 Sed-Cab-CabPu
BO 211661	Regulator Assy-Front Door Window-LH	1948 thru 1950 Sed-Cab-CabPu
BO 211662	Regulator Assy-Door Wdo-RH	1948 thru 1950 Bro-Cpes
BO 211663	Regulator Assy-Door Wdo-LH	1948 thru 1950 Bro-Cpes
BO 211664	Cross Arm Assy-Door Window Regulator-RH	1948 thru 1950 Bro-Cpes,481-491-500-501 CvBro
BO 211665	Cross Arm Assy-Door Window Regulator-LH	1948 thru 1950 Bro-Cpes,481-491-500-501 CvBro
BO 211668	Rest Channel & Drain Trough Assy-Qtr Wdo Glass-RH	1948 thru 1950 ClubCpe
BO 211669	Rest Channel & Drain Trough Assy-Qtr Wdo Glass-LH	1948 thru 1950 ClubCpe
C 211682	Mldg-F Door & Qtr Trim Panel-Lower	1948-1949 Sed-Bro
C 211683	Mldg-Rear Door Trim Panel-Lower	1948 thru 1950 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 211684	Mldg-Door Trim Panel-Lower	1948 thru 1950 Bro-Cpes-CvBro
BO 211685	Mktg-Quarter Trimboard	1948 thru 1950 Bro
C 211691	Stringer Assy-#4 to #6 Frame Crossmember	1948
BO 211697	Bracket Assy-Instrument Switch Mtg Panel LH End	1948 thru 1950 LHD
BO 211698	Bracket Assy-Instrument Switch Mtg Panel-RH End	1948 thru 1950 RHD
BZ 211702	Bracket-#4 Crossmember to Sidemember	1948 thru 1950
BO 211705	Bracket Assy-Inst Switch Panel-Center & RH end	1948-1949 LHD,1950 RHD
BO 211706	Bracket Assy-Inst Switch Panel-Center & LH end	1948-1949 RHD,1950 LHD
C 211708	Rest Channel & Drain Trough Assy-Qtr Wdo Glass-RH	1948 thru 1950 Bro
C 211709	Rest Channel & Drain Trough Assy-Qtr Wdo Glass-LH	1948 thru 1950 Bro
*C 211711	Panel & Hinge Brkt Assy-Rear Compt Partition	1948-1949 CvBro
BZ 211712	Bracket Assy-#3 Cross Member to Side Member-RH	1948 thru 1950 Exc 500
BZ 211713	Bracket Assy-#3 Cross Member to Side Member-LH	1948 thru 1950 exc 500
BO 211717	Bracket Assy-Antenna Control	1948 thru 1950
BO 211718	Escutcheon-Door & Wdo Handle	481,483,491,493
BO 211720	Handle-Window Regulator	481,483,491,493
BO 211722	Handle-Door Inside	481,483,491,493,501,503,500 CvBro
BO 211724	Regulator Assy-Door Window-RH-Manual	481-491-500-501 CvBro
BO 211725	Regulator Assy-Door Window-LH-Manual	481-491-500-501 CvBro
*C 211726	Dash Panel Assy	1948,1949,501 thru 504
BO 211730	Handle-Front Door Wing Regulator	482,484,492,494,502,504
BO 211731	Escutcheon-Front Door Wing Reg Handle	482,484,492,494,502,504
BO 211732	Handle-Door & Qtr Wdo Regulator	482-484-492-494-502-504 exc CvBro
BO 211734	Handle-Door Inside	482,484,492,494,502,504
BO 211735	Escutcheon-Rear Door Inside Handle	482,484,492,494,502,504
*C 211738 Pr	Panel Assy-Outer-Rear Door-RH	1948 thru 1950 Sedan
*C 211739 Pr	Panel Assy-Outer-Rear Door-LH	1948 thru 1950 Sedan
*C 211740 Pr	Panel Assy-Outer-Front Door-RH	1948 thru 1950 Sed-Cab-CabPu
*C 211741 Pr	Panel Assy-Outer-Front Door-LH	1948 thru 1950 Sed-Cab-CabPu
*C 211742 Pr	Panel Assy-Outer-Door-RH	1948 thru 1950 Bro-Cpes
*C 211743 Pr	Panel Assy-Outer-Door-LH	1948 thru 1950 Bro-Cpes
*C 211744 Pr	Panel Assy-Door-RH-Outer	1948 thru 1950 CvBro
*C 211745 Pr	Panel Assy-Outer-Door-LH	1948 thru 1950 CvBro
*C 211748	Center Pillar Assy-RH	482-484-492-494-502-504 Sed
*C 211749	Center Pillar Assy-LH	482-484-492-494-502-504 Sed
BO 211759	Support Assy-Quarter Window Glass	1948 thru 1950 BsCpe
F 211760	Handle-Rear Door Outside-RH	482-484-492-494-502-504 Sedan
F 211761	Handle-Rear Door Outside-LH	482-484-492-494-502-504 Sedan
BO 211770	Retainer-Lower-Center Pillar Hinge-RH	1948 thru 1950 Sed
BO 211771	Retainer-Lower-Center Pillar Hinge-LH	1948 thru 1950 Sed
A 211774	Instrument Finish Panel Assy	481,483
A 211775	Instrument Finish Panel Assy	1948,1949
BO 211779	Push Button-Door Outside Handle	481,483,491,493,501,503
BO 211780	Push Button-Door Outside Handle	482,484,492,494,502,504
F 211781	Handle Assy-Front Door Outside	482-484-492-494-502-504 Sedan
BO 211785	Name Plate-Rear Compt Door	481,483,491,493
BO 211786	Support-Rear Compt Opening Upper Panel Brace to W/house	1948-1949 CvBro
BO 211787	Support-Rear Compt Opening Upper Panel Brace to W/house	1948-1949 CvBro
BO 211788	Striker-Door Lock-RH	1948,1949,1950 Sed-Cab-CabPu
BO 211789	Striker-Door Lock-LH	1948,1949,1950 Sed-Cab-CabPu
F 211791	Handle Assy-Door Outside	482-484-492-494-502-504 exc Sedan
F 211793	Handle Assy-Front Door Outside	481-483-491-493-501-503 Sed
F 211794	Handle Assy-Rear Door Outside-RH	481-483-491-493-501-503 Sed
F 211795	Handle Assy-Rear Door Outside-LH	481-483-491-493-501-503 Sed
F 211796	Handle Assy-Door Outside	481-483-491-493-501-503 exc Sed
C 211798	Hood Louvre-RH	1948,1949
C 211799	Hood Louvre-LH	1948,1949
*C 211800	Frame & II/body Assy Comp-RHD	1948-1949-501 thru 504 Sed-Bro-Cpes
C 211801	Frame & U/body Assy-Front-RHD	1948-1949-501 thru 504 Sed-Bro-Cpes
BO 211814	Spacer-Door Outside Handle Lock Screw	1948-1949-501 thru 504 Sedan
BO 211815	Cover-Floor Mat Steering Column Hole-Black	481,483,491,493
BO 211816	Cover-Floor Mat Steering Column Hole-Taupe	1948,1949
BO 211819	Spring-Hood Hinge Return	1948 thru 1950
A 211821 Pr	Brace Assy-Brace Assy-Hood Rear Reinf	1948 thru 1950
BO 211824	Hinge Assy-Hood-RH	1948 thru 1950
BO 211825	Hinge Assy-Hood-LH	1948 thru 1950
C 211854	Molding-Lower-Front Door Panel	1948-1949-500 Sed
C 211856	Molding-Lower-Door Panel	1948-1949-500 Bro-Cpes-CvBro
C 211858	Molding-Lower-Rear Door Panel	1948-1949-500 Sed
BO 211860	Retainer-Fender Molding	1948,1949,501 thru 504
BO 211861	Retainer-Door Molding	1948,1949
BO 211862	Cover Assy-Radio Speaker Hole	1948

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 211864	Cover Assy-Radio Speaker Hole	1948-1949 without Radio
BO 211868	Silencer-Hood Rear Reinf Brace	1948 thru 1950
BZ 211876	Seal Assy-F Fender Side Dust Shield Strg Spdl Arm-Right	1948,1949,501 thru 504
BZ 211877	Seal Assy-F Fender Side Dust Shield Strg Spdl Arm-Left	1948,1949,501 thru 504
C 211882	Mldg-Door Pocket-RH	482-484-492-494-501 thru 504 Bro-Cpes
C 211883	Mldg-Door Pocket-LH	482-484-492-494-501 thru 504 Bro-Cpes
C 211884	Mldg-Front Door Pocket-RH	482-484-492-494-501 thru 504 Sedan
C 211885	Mldg-Front Door Pocket-LH	482-484-492-494-501 thru 504 Sedan
C 211886	Mldg-Rear Door Pocket-RH	482-484-492-494-501 thru 504 Sedan
C 211887	Mldg-Rear Door Pocket-LH	482-484-492-494-501 thru 504 Sedan
C 211888	Mldg-Quarter Pocket-RH	482-484-492-494 ClubCpe,501 thru 504 Bro-ClubCpe
C 211889	Mldg-Quarter Pocket-LH	482-484-492-494 ClubCpe,501 thru 504 Bro-ClubCpe
*C 211890	Quarter Panel Assy-Inner-RH	1948 thru 1950 Bro
*C 211891	Quarter Panel Assy-Inner-LH	1948 thru 1950 Bro
C 211892 Pr	Quarter Panel Assy-Inner-RH	1948 thru 1950 ClubCpe
C 211893 Pr	Quarter Panel Assy-Inner-LH	1948 thru 1950 ClubCpe
C 211896	Cross Member #5 & Stringer Assy-RH	1948
C 211897	Cross Member #5 & Stringer Assy-LH	1948
211899	Frame #5 Crossmember Assy-Outer (Use 211896 for RH & 211897 for LH)	1948
BO 211905	Escutcheon-Window Regulator Handle	481-491 CvBro with Manual Wdo Reg
BO 211908	Spring-Door Handle Push Button Return	1948 thru 1950
BO 211909	Spring-Door Handle Push Button Anti-Rattle	1948,1949,501 thru 504
BZ 211912	Bracket Assy-Frame Rear Jack Ext-RH	1948 thru 1950
BZ 211913	Bracket Assy-Frame Rear Jack Ext-LH	1948 thru 1950
C 211914	Door Assy-Rear Compt Partition-Trimmed	1948 thru 1950 BsCpe
BZ 211916	Bracket-Rear Bumper-Center-RH	1948 thru 1950
BZ 211917	Bracket-Rear Bumper-Center-LH	1948 thru 1950
BO 211918	Spacer-Front Seat Track	1948 thru 1950
C 211921	Bar-Rear Compt Partition Door Stop	1948 thru 1950 BsCpe
BO 211924	Clamp-Front-Front Seat Track	1948 thru 1950
BO 211926	Retainer-Door Safety Lock	1948 thru 1950
BO 211928	Clamp-Rear-Front Seat Track	1948 thru 1950
BO 211930	Remote Control Assy-Front Door Lock-RH	1948 thru 1960 Sed-Cab-CabPu
BO 211931	Remote Control Assy-Front Door Lock-LH	1948 thru 1950 Sed-Cab-CabPu
BO 211932	Remote Control Assy-Door Lock-RH	1948 thru 1950 Bro-Cpes
BO 211933	Remote Control Assy-Door Lock-LH	1948 thru 1950 Bro-Cpes
BO 211937	Pivot Bolt-Rear Door Remote Lock Link	1948-1949 Sedan
BO 211938	Spring-F Seat Adjusting Handle Link	1948 thru 1950
BO 211939	Gasket-Front Seat Track Clamp	1948 thru 1950
BO 211940	Remote Control Assy-Rear Door Lock-RH	481-483-491-493-500-501-503 Sed
BO 211941	Remote Control Assy-Rear Door Lock-LH	481-483-491-493-500-501-503 Sed
BO 211942	Remote Control Assy-Rear Door Lock-RH	482-484-492-494-502-504 Sed
BO 211943	Remote Control Assy-Rear Door Lock-LH	482-484-492-494-502-504 Sed
C 211944	Track Assy-Front Seat-RH-LHD	1948 thru 1950
C 211945	Track Assy-Front Seat-LH-LHD	1948 thru 1950
C 211946	Track Assy-Front Seat-RH-RHD	1948 thru 1950
C 211947	Track Assy-Front Seat-LH-RHD	1948 thru 1950
C 211948	Tie Bar-Front Seat Track	1948 thru 1950
BO 211950	Hinge-Front Door-Upper-Body Half-RH	1948 Sedan
BO 211951	Hinge-Front Door-Upper-Body Half-LH	1948 Sedan
211952	Hinge-Front Door-Upper-Body Half (Use 212426)	1948 Sedan
BO 211953	Link Assy-Front Seat Adjusting Handle-LHD	1948-1949-501 thru 504
BO 211954	Link Assy-Front Seat Adjusting Handle-RHD	1948-1949-501 thru 504 1948 thru 1950 exc CvBro
211960	Hinge-Front Door-Lower-Body Half-RH	1948 thru 1950 exc CvBro
BO 211961	Hinge-Front Door-Lower-Body Half-LB	1948 thru 1950 exc CvBro
BO 211962	Hinge-Front Door-Lower-Door Half	1948,1949
BO 211963	Silencer-Instrument Finish Panel	1948 thru 1950 Sedan
BO 211964	Link Assy-Rear Door Remote Lock-RH	1948 thru 1950 Sedan
BO 211965	Link Assy-Rear Door Remote Lock-LH	1948 thru 1950 Sedan
BO 211972	Retainer-Front-Door Lock Striker Tapping Plate	1948,1949,1950 Sed-Cab-CabPu
BO 211974	Retainer-Door Lock Striker Tapping Plate	1948-1949 Sedan
211980	Hinge-Rear Door-Upper-Body Half (Use 211982)	1948 thru 1950 Sedan
BO 211981	Hinge-Rear Door-Upper-Door Half	1949-1950 Sedan
BO 211982	Hinge-Rear Door-Upper-Body Half-RH	1949-1950 Sedan
BO 211983	Hinge-Rear Door-Upper-Body Half-LH	1948 thru 1950 Bro-Cpes-CvBro
BO 211984	Sleeve Assy-Door Remote Control Silencer	1948 thru 1950 Sedan-Cab-CabPu
BO 211985	Sleeve Assy-Door Remote Control Silencer	
211988	Seal Assy-F Fender Side Dust Shield Strg Spdl Arm- Right-RHD (Use 211876)	1948
211989	Seal Assy-F Fender Side Dust Shield Strg Spdl Arm- Left-RHD (Use 211877)	1948

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 211990	Hinge-Rear Door-Lower-Body Half	1948-1949 Sedan
BO 211991	Hinge-Rear Door-Lower-Door Half	1948 thru 1950 Sedan
BO 211992	Hinge-Rear Door-Lower-Body Half-RH	1948-1949 Sedan
BO 211993	Hinge-Rear Door-Lower-Body Half-LH	1948-1949 Sedan
BO 211994	Anti-Rattle Strip-Door Lock Release Rod Knob	1948 thru 1950
BO 211995	Knob-Door Lock Release Rod	1948 thru 1950
BO 211997	Tapping Plate-Upper-Front Door Hinge	1948 thru 1950
BO 211998	Tapping Plate-Lower-Front Door Hinge	1948 thru 1950
BO 211999	Tapping Plate-Lower-Rear Door Hinge	1948 thru 1950 Sedan
212000	Fender Assy-Front-RH (Use 220214)	1948,1949
212001	Fender Assy-Front-LH (Use 220215)	1948,1949
BO 212014	Filler-W/Shield Upper Finish Mldg Lower Joint-RH	1948 thru 1950
BO 212015	Filler-W/Shield Upper Finish Mldg Lower Joint-LH	1948 thru 1950
*A 212020 Pr	Fender Assy-Rear-RH	1948 thru 1950 Sedan
*A 212021 Pr	Fender Assy-Rear-LH	1948 thru 1950 Sedan
*A 212026 Pr	Fender Assy-Rear-RH	1948 thru 1950 Bro-ClubCpe-BsCpe-CvBro
*A 212027 Pr	Fender Assy-Rear-LH	1948 thru 1950 Bro-ClubCpe-BsCpe-CvBro
C 212048	Glass Run & Clip Assy-Rear Door Wdo-RH	1948 thru 1950 Sedan
C 212049	Glass Run & Clip Assy-Rear Door Wdo-LH	1948 thru 1950 Sedan
C 212076	Glass Run Assy-Quarter Window-RH	1948-1949 Bro
C 212077	Glass Run Assy-Quarter Window-LH	1948-1949 Bro
BO 212080	Bracket-Quarter Wing Weatherstrip Retainer	1948-1949-501 thru 504 Sedan
BO 212086	Channel Assy-Front RH-Rear Door Window	1948 thru 1950 Sedan
BO 212087	Channel Assy-Front LH-Rear Door Window	1948 thru 1950 Sedan
BO 212088	Channel Assy-Rear RH-Rear Door Window	1948 thru 1950 Sedan
BO 212089	Channel Assy-Rear LH-Rear Door Window	1948 thru 1950 Sedan
212097	Filler-Windshield Mldg Joint (Use 212014 for RH 212015 for LH)	1948
C 212100	Finish Mldg-Windshield-Lower-RH	1948,1949
C 212101	Finish Mldg-Windshield-Lower-LH	1948,1949
C 212125	Back Assy-Front Seat-LHD	1948-1949-501 thru 504 Sedan
C 212126	Back Assy-Front Seat-RH	1948 thru 1950 exc Sed
C 212127	Back Assy-Front Seat-LH	1948 thru 1950 exc Sed
212150	Hinge Assy-Rear Compt Door (Use 214268)	1948-1949 Bro-Sed
BO 212157	Spring-Rear Compt Door Hinge	1948 thru 1950 Bro-Sed
BO 212163	Spring-Rear Compt Door Hinge	1948 thru 1950 ClubCpe-BsCpe-CvBro
212164	Hinge Assy-Rear Compt Door (Use 214269)	1948-1949 ClubCpe-BsCpe-CvBro
BO 212174	Screw-Visor Attaching	482-484-492-494-502-504 Exc CvBro
BO 212177	Arm-Visor Bracket	482-484-492-494-502-504 exc CvBro
BO 212184	Center Bar & Weatherstrip Assy-Front Door-RH	1948-1949 exc CvBro
BO 212185	Center Bar & Weatherstrip Assy-Front Door-LH	1948-1949 exc CvBro
BO 212192	Handle Assy-Rear Compt Door-Less Lock Cyl	482,484,492,494,502,504
BO 212193	Gasket-Rear Compt Door License Lamp Housing	482,484,492,494
BO 212194	Lens-Rear Compt Door License Lamp	482,484,492,494
BO 212195	Gasket-Rear Compt Door License Lamp Lens	482,484,492,494
BO 212196	Retainer-Rear Compt Door License Lamp Lens	482,484,492,494
BO 212197	Handle-Rear Compt Door-Stationary	482,484,492,494,502,504
212200	Wing, Retainer & W/Strip Complete-Front-RH (Use 217500)	482,484,492,494 exc CvBro
212201	Wing, Retainer & W/Strip Complete-LH (Use 217501)	482,484,492,494 exc CvBro
212204	Wing, Retainer & W/Strip Complete Comp-Fr Door- RH (Use 217504)	481-483-491-493 exc CvBro
212205	Wing, Retainer & W/Strip Complete-Comp-Fr Door- LH (Use 217505)	481-483-491-493 exc CvBro
BO 212208	Glass & Frame Assy-F Door Wing-RH	482-484-492-494-502-504 exc CvBro
BO 212209	Glass & Frame Assy-F Door Wing-LH	482-484-492-494-502-504 exc CvBro
BO 212210	Frame Assy-Front Door Wing Glass-RH	482-484-492-494-502-504 exc CvBro
BO 212211	Frame Assy-Front Door Wing Glass-LH	482-484-492-494-502-504 exc CvBro
BO 212212	Glass & Frame Assy-F Door Wing-RH	481-483-491-493-501-503 exc CvBro
BO 212213	Glass & Frame Assy-F Door Wing-LH	481-483-491-493-501-503 exc CvBro
BO 212214	Frame Assy-Front Door Wing Glass-RH	481-483-491-493-501-503 exc CvBro
BO 212215	Frame Assy-Front Door Wing Glass-LH	481-483-491-493-501-504 exc CvBro
BO 212218	Retainer Assy-Front Door Wing W/Strip-RH	482-484-492-494 exc CvBro
BO 212219	Retainer Assy-Front Door Wing W/Strip-LH	482-484-492-494 exc CvBro
BO 212220	Retainer Assy-Front Door Wing W/Strip-RH	481-483-491-493 exc CvBro
BO 212221	Retainer Assy-Front Door Wing W/Strip-LH	481-483-491-493 exc CvBro
BO 212222	Weatherstrip-Front Door Wing-RH	482-484-492-494-502-504 exc CvBro
BO 212223	Weatherstrip-Front Door Wing-LH	482-484-492-494-502-504 exc CvBro
BO 212224	Weatherstrip-Front Door Wing-RH	481-483-491-493-500-501-503 exc CvBro
BO 212225	Weatherstrip-Front Door Wing-LH	481-482-491-493-500-501-503 exc CvBro
BO 212228	Cup Washer-License Lamp	482,484,492,494,502,504
BO 212234	Locking Plate-Door & Qtr wing	481-483-491-493-500-501-503 exc CvBro
BO 212234	Locking Plate-Door & Qtr Wing	1948-1949-501 thru 504 Sedan
BO 212238	Pivot-Upper-Front Door Wing-RH	1948 thru 1950 exc CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models	
BO 212240	Lock Assy-Front Door-RH	1948 thru 1950	
BO 212241	Lock Assy-Front Door-LH	1948 thru 1950	
BO 212245	Screw-Front Door Handle Lock Actuating	1948-1949-501 thru 504 Sedan	
BO 212246	Screw-Door Handle Lock Actuating	1948-1949-501 thru 504 exc Sedan	
BO 212247	Screw-Rear Door Handle Lock Actuating	1948-1949-501 thru 504 Sedan	
	212263	W/Strip-Quarter Wdo Belt-Outer (Use 216732)	1948-1949 CvBro
BO 212264	Retainer-Quarter Wdo Belt Outer W/Strip	1948 thru 1950 CvBro	
C 212265	Glass Run-Door Wdo Center Bar	1948 thru 1950 exc CvBro	
BO 212270	Stop-Door Wing Lower Pivot	481-483-491-493-500-501-503 exc CvBro	
BO 212272	Spring-F Door Wing Lower Pivot	481-482-491-493-500-501-503 exc CvBro	
BO 212272	Spring-Qtr Wing Lower Pivot	1948-1949-501 thru 504 Sed	
A 212273	Baffle Assy-Upper-Radiator Grille	1948,1949	
A 212274	Baffle Assy-Center-Radiator Grille	1948,1949	
A 212275	Baffle Assy-Lower-Radiator Grille	1948,1949	
BO 212276	Locking Handle & Bracket AsAy-F Door Wing-RH	481-483-491-493-500-501-503 exc CvBro	
BO 212277	Locking Handle & Bracket Assy-F Door Wing-LH	481-483-491-493-500-501-503 exc CvBro	
BO 212282	Lower Pivot-Front Door Wing-RH	481-483-491-493-500-501-503 exc CvBro	
BO 212283	Lower Pivot-Front Door Wing-LH	481-483-491-493-500-501-503 exc CvBro	
BO 212284	Lower Pivot-Front Door Wing-RH	482-484-492-494-502-504 exc CvBro	
BO 212285	Lower Pivot-Front Door Wing-LH	482-484-492-494-502-504 exc CvBro	
BO 212286	Socket-Front Door Wing Upper Pivot-RH	1948-1949 exc CvBro	
BO 212287	Socket-Front Door Wing Upper Pivot-LH	1948-1949 exc CvBro	
C 212288	Retainer-Rear Fender Panel Lower Mldg	1948 thru 1950 Sedan	
C 212289	Retainer-Rear Fender Panel Lower Mldg	1948 thru 1950 Bro-Cpes-CvBro	
C 212290	Trim Panel & Silencer Assy-Dash-RH-LHD	1948,1949	
C 212291	Trim Panel & Silencer Assy-Dash-LH-LHD	1948,1949	
C 212300	Trim Panel & Silencer Assy-Dash-RH-RHD	1948,1949	
C 212301	Trim Panel & Silencer Assy-Dash-LH-RHD	1948,1949	
BO 212310	Cover-Windshield Finish Mldg Lower Joint- Without Radio	1948,1949	
BO 212311	Cover-Windshield Finish Mldg Lower-Joint- With Radio	1948,1949	
BO 212320	Regulator Assy-Front Door Wing-RH	482,484,492,494,502,504	
BO 212321	Regulator Assy-Front Door Wing-LH	482,484,492,494,502,504	
BZ 212322	Seal-Front Fender Dust Shield Extension	1948,1949,501 thru 504	
BO 212323	Retainer-Front Pillar Trim	1948 thru 1950	
BO 212328	Locking Handle & Brkt Assy-Qtr Wing-RH	1948-1949-501 thru 504 Sedan	
BO 212329	Locking Handle & Brkt Assy-Qtr Wing-LH	1948-1949-501 thru 504 Sedan	
*HA 212331	Thermaster Bottle		
*HA 212333	Thermaster Portable Refrigerator		
BO 212336	Support Assy-Rear Seat Cushion-RH	1948 ClubCpe-CvBro	
BO 212337	Support Lisy-Rear Seat Cushion-LH	1948 ClubCpe-CvBro	
BO 212338	Lock Assy-Rear-Door-Ril	1948 thru 1950 Sedan	
BO 212339	Lock Assy-Rear-Door-LH	1948 thru 1950 Sedan	
BO 212341	Bracket Assy-Front Seat Back Hinge-Center	1948 thru 1950 exc Sed	
BO 212344	Guide-Quarter Window Regulator	1948 thru 1950 Bro-ClubCpe	
*A 212358	Side Dust Shield Assy-Front Fender-RH-RHD	1948,1949,501 thru 504	
*A 212359	Side Dust Shield Assy-Front Fender-LH-RHD	1948,1949,501 thru 504	
*HA 212361	Venetian Sun Shade Kit	1948-1949-500 Sed-Bro	
BO 212364	Socket-F Door Wing Upper Pivot-RH	1948-1949 exc CvBro	
BO 212365	Socket-F Door Wing Upper Pivot-LH	1948-1949 exc CvBro	
BO 212366	Channel Assy-Lower-Quarter Window-RH	1948 thru 1950 Bro-ClubCpe	
BO 212367	Channel Assy-Lower-Quarter Window-LH	1948 thru 1950 Bro-ClubCpe	
BO 212368	Brkt Assy-Rear Wdo Venetian Sun Shade-RH	1948-1949-500 Sed-Bro	
BO 212369	Brkt Assy-Rear Wdo Venetian Sun Shade-LH	1948-1949-500 Sed-Bro	
BO 212370	Weatherstrip-Front Door Window Center Bar	1948 thru 1950 exc CvBro	
	212376	Weatherstrip-Door Opening-Front-RH (Use 216546)	1948-1949 Sed-Bro-Cpes
	212377	Weatherstrip-Door Opening-Front-LH (Use 1-216547 2-213648,1-216898,1-216899, & 8-170685)	1948-1949 Sed-Bro-Cpes
BO 212378	Weatherstrip-Qtr Window Belt-RH	1948 Bro	
BO 212379	Weatherstrip-Qtr Window Belt-LH	1948 Bro	
C 212380	Weatherstrip-Door Window Belt	1948-1949-501 thru 504 Bro-Cpes	
C 212381	Weatherstrip-Door Window Belt	1948-1949-501 thru 504 Bro-Cpes	
C 212382	Weatherstrip-Front Door Window Belt	1948-1949-501 thru 504 Sed	
BO 212383	Weatherstrip-Front Door Window Belt	1948-1949-501 thru 504 Sed	
C 212384	Weatherstrip-Rear Door Window Belt	1948-1949-501 thru 504 Sed	
*HA 212385	Bracket-Comb Fire Extinguisher & Tire Inflating Tank		
BO 212386	Hose-Cowl Vent Air Dust Drain-RHD	1948 thru 1950	
BO 212387	Clip-Cowl Vent Air Dust Hose-RHD	1948 thru 1950	
C 212388	Weatherstrip-Qtr Wdo Belt	1948-1949-501 thru 504 Bro	
C 212389	Weatherstrip-Qtr Wdo Belt	1948-1949-501 thru 504 Bro	
C 212390	Frame & Back Assy-Front Seat Cushion-LHD	1948-1949-501 thru 504 Sed	
C 212391	Frame Assy-Front Seat Cushion-LHD	1948-1949-501 thru 504 Bro-Cpes-CvBro	
C 212394	Retainer-Door Bottom Trimboard	1948-1949 Bro-Cpes-CvBro	
C 212395	Retainer-Front Door Bottom Trimboard	1948-1949 Sedan	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 212396	Retainer-Rear Door Bottom Trimboard	1948-1949 Sedan
C 212404	Trimboard-Rear Pillar-RH	482-484-492-494 ClubCpe
C 212405	Trimboard-Rear Pillar-LH	482-484-492-494 ClubCpe
BO 212421	Lens & Rim Assy-Rear Quarter Lamp	482-484-492-494-502-504 Bro-Sed-ClubCpe
BO 212422	Reflector-Rear Quarter Lamp	482-484-492-494-502-504 Bro-Sed-ClubCpe
212423	Bumper-Door & Top (Use 216527 & 171388)	1948-1949 CvBro
BO 212424	Hinge-Door-Upper-Body Half-RH	1948 Bro-ClubCpe-BsCpe
BO 212425	Hinge-Door-Upper-Body Half-LH	1948 Bro-ClubCpe-BsCpe
BO 212426	Hinge-Door-Upper-Door Half	1948 Bro-ClubCpe-BsCpe
BO 212428	Wing & W/ Strip Retainer, complete With Glass-RH-Qtr	1948-1949-501 thru 504 Sedan
BO 212429	Wing & W/Strip Retainer, Complete With Glass-LH-Qtr	1948-1949-501 thru 504 Sedan
BO 212432	Frame & Glass Assy-Qtr Wing-RH	1948-1949-501 thru 504 Sedan
BO 212433	Frame & Glass Assy-Qtr Wing-LH	1948-1949-501 thru 504 Sedan
BO 212434	Frame Assy-Qtr Wing Glass-RH	1948-1949-501 thru 504 Sedan
BO 212435	Frame Assy-Quarter Wing Glass-LH	1948-1949-501 thru 504 Sedan
BO 212440	Retainer Assy-Qtr Wing Weatherstrip-RH	1948-1949-501 thru 504 Sedan
BO 212441	Retainer Assy-Qtr Wing Weatherstrip-LH	1948-1949-501 thru 504 Sedan
BO 212443	Clip-Qtr Wing Weatherstrip Retainer	1948-1949-501 thru 504 Sedan
BO 212444	Weatherstrip-Quarter Wing-RH	1948-1949-501 thru 504 Sedan
BO 212445	Weatherstrip-Quarter Wing-LH	1948-1949-501 thru 504 Sedan
*HA 212457	Rear Window Wiper Kit	1948-1949 Sed-Bro-Cpes, 1950 Cpes
BO 212458	Weatherstrip-Door Panel Upper Flange	1948-1949 Sed-Bro-ClubCpe-BsCpe
BO 212462	Pivot-Upper-Quarter Wing	1948-1949-501 thru 504 Sedan
BO 212464	Retainer-Quarter Wing Upper Pivot	1948-1949-501 thru 504 Sedan
BO 212465	Socket-Quarter Wing Upper Pivot	1948-1949-501 thru 504 Sedan
BO 212467	Clip-Front-Qtr Wing Weatherstrip Retainer	1948-1949-501 thru 504 Sedan
BO 212469	Stop-F Door Wing Lower Pivot	481-483-491-493-500-501-503 exc CvBro
BO 212469	Stop-Quarter Wing Lower Pivot	1948-1949-501 thru 504 Sedan
C 212472	Glass-Rear Qtr Wdo	1948 thru 1950 BsCpe-ClubCpe
C 212476	Glass Run Assy-Quarter Window-RH	1948-1949 ClubCpe
C 212477	Glass Run Assy-Quarter Window-LH	1948-1949 ClubCpe
212484	Trim Retainer & Windlace Assy-Front Pillar-RH (Use 216986)	1948, 1949
212485	Trim Retainer & Windlace Assy-Front Pillar-LH (Use 216987)	1948, 1949
A 212488 Pr	Support Assy-Side-Radiator Grille Baffle-RH	1948, 1949
A 212489 Pr	Support Assy-Side-Radiator Grille Baffle-LH	1948, 1949
BO 212497	Support Assy-Center-Radiator Grille Baffle	1948, 1949
BO 212498	Center Bar-Radiator Grille	1948, 1949
BZ 212499	Center Bar-Lower-Radiator Grille	1948, 1949
BZ 212535 Pr	Door Assy-Rear Fender Gas Filler	1948 thru 1950
BO 212537	Bolt-Top Operating Cylinder Hinge	1948 thru 1950 CvBro
212542	Spring-Rear Fender Gas Filler Door-RH(Use 217346)	1948, 1949
212543	Spring-Rear Fender Gas Filler Door-LH(Use 217347)	1948, 1949
BZ 212545	Drain Hose-Gasoline Overflow	1948
BO 212546	Bumper-Inst Cluster Mtg Panel or Stationary Glove Box Door	1948 thru 1950
BO 212546	Bumper-Rear Fender Gas Filler Door	1948, 1949
BO 212547	Bumper-Glove Box Door-Inner	1948 thru 1950
BO 212548	Bumper-Glove Box Door-Outer	1948 thru 1950
*C 212552 Pr	Door Assy-Front-RH	1948 thru 1950 Sed-Cab-CabPu
*C 212553 Pr	Door Assy-Front-LH	1948 thru 1950 Sed-Cab-CabPu
*C 212562 Pr	Door Assy-Rear-RH	1948-1949 Sedan
*C 212563 Pr	Door Assy-Rear-LH	1948-1949 Sedan
*C 212572 Pr	Door Assy-RH	1948 thru 1950 Bro-BsCpe-ClubCpe
*C 212573 Pr	Door Assy-LH	1948 thru 1950 Bro-BsCpe-ClubCpe
212592	Door Assy-Right	481-491-500-501 CvBro Without Hyd Wdo Reg
212593	Door Assy-Left	481-491-500-501 CvBro Without Hyd Wdo Reg
*C 212596	Door Assy-Right	1948 thru 1950 CvBro with Hyd Wdo Reg
*C 212597	Door Assy-Left	1948 thru 1950 CvBro with Hyd Wdo Reg
C 212672	Finish Molding-Quarter Window-RH	1948-1949 Sedan
C 212673	Finish Molding-Quarter Window-LH	1948-1949 Sedan
BO 212680	Prop Assy-Hood	1948 thru 1950 All
BO 212686	Spring-Hood Prop	1948 thru 1950 All
BO 212687	Rivet-Hood Prop Spring	1948 thru 1950 All
BO 212688	Rivet-Hood Prop Arm Pivot	1948 thru 1950
BO 212689	Rivet-Hood Prop Lower Arm Pivot	1948 thru 1950
212724	Weatherstrip-W/Shield-On Pillar-RH (Use 217064)	1948-1949 CvBro
212725	W/Strip-Windshield-On Pillar-LH (Use 217065)	1948-1949 CvBro
*HA 212727	Fog Lamp Kit	1948, 1949
HA 212728	Fog Lamp Assy	1948 thru 1950
*HA 212729	Fog Lamp Installation Kit	1948 thru 1950
BO 212768	Socket Assy-F Door Wing Upper Pivot-RH	1948 thru 1950 CvBro
BO 212769	Socket Assy-F Door Wing Upper Pivot-LH	1948 thru 1950 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 212770	Channel Assy-Qtr Wdo Glass Run-Lower Rear-RH	1948-1949 Bro
BO 212771	Channel Assy-Qtr Wdo Glass Run-Lower Rear-LH	1948-1949 Bro
C 212778	Support-Rear Seat Back & Center Arm Rest	482-484-492-494-502-504 Sed
BO 212779	Retainer-Ash Receiver	481,483,491,493
BO 212788	Pin-Rear Seat Back Center Arm Rest Link to Hinge Or Brkt	482-484-492-494-502-504 Bro-Sed-ClubCpe
BO 212789	Hinge Assy-R Seat Back Center Arm Rest	482-484-492-494-502-504 Bro-Sed-ClubCpe
BZ 212795	Grommet-Rear Fender Gas Filler	1948 thru 1950
BO 212812	Bracket Assy-Front Seat Side Panel-RH	1948 thru 1950 exc Sed
BO 212813	Bracket Assy-Front Seat Side Panel-LH	1948 thru 1950 exc Sed
212817	Support Assy-R Seat Back Center Arm Rest (Use 214139)	482-484 ClubCpe
BO 212822	Bushing-Top Operating Cylinder Bracket	1948 thru 1950 CvBro
BO 212825	Frame-Inner-Rear Curtain Window	481-491-1950 CvBro
BO 212828	Support & Silencer Assy-Qtr Wdo Glass	1948 thru 1950 BsCpe
BO 212836	Hanger Assy-Front Seat Back Panel Spring	1948 thru 1950
BO 212838	Pivot-Lower-Quarter Wing-RH	1948-1949-501 thru 504 Sedan
BO 212839	Pivot-Lower-Quarter Wing-LH	1948-1949-501 thru 504 Sedan
212856	Rear Curtain & Wdo Assy-Folding Top (Use 216640)	484 CvBro
C 212858	Board Assy-Foot Rest	1948-1949-501 thru 504 Bro-Sed
BO 212860	Headlamp Assy-6V-LHD	1948
BO 212862	Connector & Wires Assy-Headlamp	1948 thru 1950 All
BO 212866	Hinge-Door-Lower-Body Half-RH	1948 thru 1950 CvBro
BO 212867	Hinge-Door-Lower-Body Half-LH	1948 thru 1950 CvBro
BO 212868	Hinge-Door-Lower-Door Half	1948 thru 1950 CvBro
BO 212870	Headlamp Assy-6V-RHD	1948
BO 212880	Rim-Headlamp Lens	1948 thru 1950 All
BO 212881	Housing Assy-Headlamp	1948
C 212882	Windlace Assy-Pillar & Header-RH	1948-1949 Bro-Cpes
C 212883	Windlace Assy-Pillar & Header-LH	1948-1949 Bro-Cpes
C 212886	Welt Assy-Door Wdo Finish Mldg	1948-1949-501 thru 504 Bro-Cpes
C 212887	Welt Assy-F Door Wdo Finish Mldg	1948-1949-501 thru 504 Sed
C 212888	Welt Assy-R Door Wdo Finish Mldg	1948-1949-501 thru 504 Sed
C 212896	Glass Run Assy-Qtr Wdo-RH	1948-1949 BsCpe
C 212897	Glass Run Assy-Qtr Wdo-LH	1948-1949 BsCpe
*HA 212918	Door Ventshade Kit	1948 thru 1950 Sed
C 212919	Sealer-Dolphin #2524-Qt	1948 thru 1950
C 212922	Reveal Molding-Quarter Window-RH	1948 thru 1950 Cpes
C 212923	Reveal Molding-Quarter Window-LH	1948 thru 1950 Cpes
BZ 212925	Support Assy-Radiator Grille Lower Center Bar	1948,1949
BO 212930	Weatherstrip-Quarter Wdo Belt	1948 thru 1950 Cpes
BO 212931	Weatherstrip-Quarter Wdo Belt	1948 thru 1950 Cpes
BO 212933	Support-Hydraulic Power Unit	1948 thru 1950 CvBro
BO 212934	Channel Assy-Lower Rear-Quarter Wdo-RH	1948 thru 1950 BsCpe-ClubCpe
BO 212935	Channel Assy-Lower Rear-Quarter Wdo-LH	1948 thru 1950 BsCpe-ClubCpe
BO 212940	Tubing-Windshield Wiper	481-482-491-492 Without Comb Pump, 483-484-493-494 LHD
BO 212941	Tubing-Windshield Wiper	1948 thru 1950 6 cyl with Comb Fuel Pump
BO 212942	Tubing-Windshield Wiper	1948-1949 8 Cyl All RHD,603-504 with Comb Pump
BO 212943	Tubing-Windshield Wiper	491-492-1950 Without Comb Pump
C 212954	Roof Bow #4	1948-1949 BsCpe-ClubCpe
C 212955	Roof Bow #5	1948-1949 BsCpe-ClubCpe
C 212956	Roof Bow #6	1948-1949 BsCpe-ClubCpe
C 212958	Flexseal-Vibradamp #244-Qt	1948 thru 1950
C 212986	Silencer-F Seat Cushion Frame	1948 thru 1950
C 212992	Finish Mldg & Weatherstrip Assy-Qtr Wdo-RH	1948-1949 Bro
C 212993	Finish Mldg & Weatherstrip Assy-Qtr Wdo-LH	1948-1949 Bro
C 213012	Finish Mldg & Weatherstrip Assy-Fr Door Wdo-RH	1948-1949 Sed
C 213013	Finish Mldg & Weatherstrip Assy-Fr Door Wdo-LH	1948-1949 Sed
C 213032	Finish Mldg & Weatherstrip Assy-Rear Door Wdo-RH	1948-1949 Sed
C 213033	Finish Mldg & Weatherstrip Assy-Rear Door Wdo-LH	1948-1949 Sed
C 213046	Weatherstrip-Upper-Top Front Head Joint	1948-1949 CvBro
C 213052	Finish Mldg-& W/Strip Assy-Door Wdo-RH	1948-1949 Bro-ClubCpe-BsCpe
C 213053	Finish Mldg & W/Strip Assy-Door Wdo-LH	1948-1949 Bro-ClubCpe-BsCpe
BO 213066	Hinge-Door-Upper-Body Half-RH	1948 thru 1950
BO 213067	Hinge-Door-Upper-Body Half-LH	1948 thru 1950
BO 213068	Hinge-Door-Upper-Door Half	1948 thru 1950
BO 213069	Pin-Door Hinge	1948 thru 1950
C 213077	Trim Panel-Rear Seat Back	1948 ClubCpe
BO 213096	Reinf-Rear Compt Door Hinge Bracket	1948-1949 Cpes-CvBro
BO 213097	Cover-Front Splash Guard Mldg Joint	1948,1949
213098	Mldg-Front Splash Guard (Use 2-213106 & 1-213097)	1948,1949
C 213100	Finish Mldg & W/Strip Assy-Qtr Wdo-RH	1948-1949 BsCpe-ClubCpe
C 213101	Finish Mldg & W/Strip Assy-Qtr Wdo-LH	1948-1949 BsCpe-ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 213106	Molding-Front Splash Guard	1948,1949
C 213116	Weatherstrip-Lower-Top Front Header Joint	1948 thru 1950 CvBro
C 213122	Qtr Window Reveal Mldg & W/Strip Assy-RH	1948 thru 1950 ClubCpe-BsCpe
C 213123	Qtr Window Reveal Mldg & W/Strip Assy-LH	1948 thru 1950 ClubCpe-BsCpe
BO 213131	Bolt-Front Splash Guard Molding	1948,1949,500
C 213134	Reveal Mldg & W/Strip Assy-Front Door Wdo-RH	1948 thru 1950 Sedan
C 213135	Reveal Mldg & W/Strip Assy-Front Door Wdo-LH	1948 thru 1950 Sedan
TC 213136	Trim Panel Assy-Rear Seat Back	1948-1949 ClubCpe
BO 213137	Glove Box Assy-Pass Side-LHD	1948 thru 1950
BO 213138	Glove Box Assy-Pass Side-RHD	1948 thru 1950
C 213148	Reveal Molding & W/Strip Assy-Qtr Wdo-RH	1948 thru 1950 Bro
C 213149	Reveal Molding & Weatherstrip AssyQtr-Wdo-LH	1948 thru 1950 Bro
C 213154	Reveal Molding & W/Strip Assy-Door Wdo-RH	1948 thru 1950 Bro-ClubCpe-BsCpe
C 213155	Reveal Molding & W/Strip Assy-Door Wdo-LH	1948 thru 1950 Bro-ClubCpe-BsCpe
C 213162	Reveal Mldg & W/Strip Assy-Rear Door Wdo-RH	1948 thru 1950 Sedan
C 213163	Reveal Mldg & W/Strip Assy-Rear Door Wdo-LH	1948 thru 1950 Sedan
C 213164	Trimboard-Rear Shelf	1948-1949 Bro-Sed
C 213167	Trimboard-Rear Shelf	1948 thru 1950 BsCpe
C 213174	Trimboard-Front Door	482-484-492-494 Sedan
C 213176	Trimboard-Rear Door	482-484-492-494 Sedan
C 213180	Trimboard-Door	482-484-492-494 ClubCpe-CvBro
C 213182	Trim Panel & Silencer Assy-Cowl-RH	1948,1949
C 213183	Trim Panel & Silencer Assy-Cowl-LH	1948,1949
*HA 213192	Back-up Lamp Installation Kit	1948 thru 1950
C 213193	Spring-F Seat Cushion	1948 thru 1950 CvBro
C 213194	Spring-F Seat Back-RH	1948 thru 1950 CvBro
C 213195	Spring-F Seat Back-LH	1948 thru 1950 CvBro
*A 213198 Pr	Extension Assy-Fr Fender Side Dust Shield-RH-RHD	1948,1949
*A 213199 Pr	Extension Assy-Fr Fender Side Dust Shield-LH-RHD	1948,1949
213200	Instrument Cluster-Complete (Use 217150)	481,483,491,493
BO 213201	Instrument Cluster-Less Instruments	481,483,491,493
F 213202	Gauge-Fuel	481,483,491,493
F 213203	Gauge-Temperature	481,483,491,493
BO 213205	Instrument Cluster-Complete	482,484,492,494
BO 213206	Instrument Cluster-Less Instruments	482,484,492,494
F 213207	Gauge-Fuel	482,484,492,494
F 213208	Gauge-Temperature	482,484,492,494
A 213210	Support Assy-Front Fender Stone Guard-RH	1948,1949,501 thru 504
A 213211	Support Assy-Front Fender Stone Guard-LH	1948,1949,501 thru 504
BZ 213212	Seal-Fr Fender Side Dust Shield-Steering	1948,1949,501 thru 504
BZ 213213	Seal-Fr Fender Side Dust Shield-Frame	1948,1949,501 thru 504
*HA 213215	Cigar Lighter Kit	481,483,491,493
213216	Handle-Rear Compt Door (Use 220319)	481,483,491,493
BO 213217	Heating Element & Knob Assy-Cigar Lighter	481,483,491,493
BO 213218	Washer-Cigar Lighter Knob	1948 thru 1950
213219	Knob Assy-Cigar Lighter (Use 220376)	481,483,491,493
BO 213223	Handle-Front Seat Adjusting-RHD	1948-1949-501 thru 504
*A 213228 Pr	Extension Assy-Fr Fender Side Dust Shield-RH-LHD	1948,1949
*A 213229 Pr	Extension Assy-Fr Fender Side Dust Shield-LH-LHD	1948,1949
C 213232	Valance-Door Window-RH	482-484-492-494 exc Sedan
C 213233	Valance-Door Window-LH	482-484-492-494 exc Sedan
C 213244	Panel-Outside Visor-RH	1948 thru 1950
C 213245	Panel-Outside Visor-LH	1948 thru 1950
BO 213246	Brkt-Outside Visor Center Support-RH	1948 thru 1950
213247	Brkt-Outside Visor Center Support-LH	1948 thru 1950
BO 213248	Molding-Outside Visor-Center	1948 thru 1950
C 213252	Valance-Front Door Wdo-RH	482-484-492-494 Sedan
C 213253	Valance-Front Door Wdo-LH	482-484-492-494 Sedan
BO 213264	Support-Outside Visor Center	1948 thru 1950
BO 213268	Bracket-Outside Visor-End-RH	1948 thru 1950
BO 213269	Bracket-Outside Visor-End-LH	1948 thru 1950
C 213272	Valance-Rear Door Window-RH	482-484-492-494 Sedan
C 213273	Valance-Rear Door Window-LH	482-484-492-494 Sedan
*HA 213288	Outside Visor Kit	1948 thru 1950
BO 213291	Valance-Center Pillar	482-484-492-494 Sedan
213300	Arm Rest Assy-Door & Qtr Panel (Use 215938)	481-483 exc CvBro
213301	Arm Rest Assy-Door & Qtr Panel (Use 215936)	482-484 exc CvBro
BO 213302	Arm Rest Assy-Door & Qtr Panel	482-484 exc CvBro
213303	Arm Rest Assy-Door & Qtr Panel (Use 215936)	1948 Sed-Bro-ClubCpe-BsCpe
213304	Arm Rest Assy-Door & Qtr Panel (Use 216090)	1948 Sed-Bro-ClubCpe-BsCpe
213305	Arm Rest Assy-Door (Use 216092)	484 CvBro
BO 213306	Base-Door Arm Rest	1948,1949
BO 213313	Cover-Rear Compt Floor Drain-Hole	1948,1949,500
BO 213314	Plug-Rear Compt Floor, Dash Panel & Door Holes	1948 thru 1950

Part No.	Name	Models
BO 213315	Switch-Fog Lamp	1948 thru 1950
BO 213316	Brkt Assy-Door & Qtr Arm Rest-RH	1948 thru 1950 exc CvBro
BO 213317	Brkt Assy-Door & Qtr Arm Rest-LH	1948 thru 1950 exc CvBro
C 213342	Valance-Qtr Wdo-RH	482-484-492-494 Sedan
C 213343	Valance-Qtr Wdo-LH	482-484-492-494 Sedan
C 213362	Valance-Quarter Window-RH	482-484-492-494 ClubCpe
C 213363	Valance-Quarter Window-LH	482-484-492-494 ClubCpe
C 213374	Finish Mldg & Weatherstrip Assy-Door Wdo-RH	1948 thru 1950 CvBro
C 213375	Finish Mldg & Weatherstrip Assy-Door Wdo-LH	1948 thru 1950 CvBro
C 213382	Valance-Front Seat Back-RH	482-484-492-494 Bro-ClubCpe-CvBro
C 213383	Valance-Front Seat Back-LH	482-484-492-494 Bro-ClubCpe-CvBro
BO 213392	Valance-Front Door-RH	481, 483
BO 213393	Valance-Front Door-LH	481, 483
BO 213394	Valance-Front Door-RH	481, 483, 491, 493
BO 213395	Valance-Front Door-LH	481, 483, 491, 493
BO 213396	Valance-Front Door-RH	491, 493
BO 213397	Valance-Front Door-LH	491, 493
BO 213399	Screw-Robe Hanger Brkt & Assist Handle	482, 484, 492, 494, 502, 504
C 213403	Robe Hanger-Gray Trim	482, 484, 492, 494 Sedan
C 213404	Robe Hanger-Tan Trim	482, 484, 492, 494 Sedan
C 213405	Robe Hanger-Russet Leather Trim	482, 484, 492, 494 Sedan
C 213406	Robe Hanger-Gray Leather Trim	482, 484, 492, 494 Sedan
C 213408	Robe Hanger-Dar Red Leather	482, 484, 492, 494 Sedan
BO 213410	Parking. Lamp Assy-exc With DI	1948, 1949, 500
BO 213412	Parking Lamp & Direction Indicator Assy	1948, 1949, 500
BO 213415	Lens-Parking Lamp	1948, 1949, 500
BO 213416	Retainer-Parking Lamp Lens	1948, 1949, 500
BO 213417	Gasket-Parking Lamp Lens	1948, 1949, 500
BO 213418	Door-Parking Lamp	1948, 1949, 500
BO 213419	Socket, Brkt & Wire Assy-Parking Lamp-Without DI	1948, 1949, 500
BO 213420	Socket, Brkt & Wire Assy-Parking Lamp & DI	1948, 1949, 500
*C 213426	Pillar Assy-Rear-RH	482-484-492-494-502-504 CvBro
*C 213427	Pillar Assy-Rear-LH	482-484-492-494-502-504 CvBro
*C 213428	Pillar Assy-Rear-RH	481-491-500-501 CvBro
*C 213429	Pillar Assy-Rear-LH	481-491-500-501 CvBro
C 213433	Valance-Front Seat Back	482-484-492-494 Sed
C 213444 Pr	Pillar Assy-Front-RH-LHD	481, 483, 491, 493, 500, 501, 503
C 213445 Pr	Pillar Assy-Front-LH	481, 483, 491, 493, 501, 503
*C 213446	Pillar Assy-Center-RH	481-483-491-493-500-501-503 Sedan
*C 213447	Pillar Assy-Center-LH	481-483-491-493-500-501-503 Sedan
*C 213448	Pillar Assy-Rear-RH	481-483-491-493-500-501-503 Bro-Cpes
*C 213449	Pillar Assy-Rear-LH	481-483-491-493-500-501-503 Bro-Cpes
C 213456 Pr	Pillar Assy-Front-RH-RHD	481-483-491-493-501-503 exc CvBro
*C 213458 Pr	Pillar Assy-Front-RH-RHD	482-484-492-494-502-504 exc CvBro
C 213478	Mldg-Rocker Panel-Upper-RH	482, 484, 492, 494, 502, 504
C 213479	Mldg-Rocker Panel-Upper-LH	482, 484, 492, 494, 502, 504
C 213480	Molding-Rear Wheel Cover-Upper	481, 483, 491, 493, 501, 503
C 213480	Molding-Rear Wheel Cover-Lower	1948 thru 1950
BO 213481	Molding-Rear Rocker Panel-Lower	1948 thru 1950
BO 213482	Molding-Rear Rocker Panel-Upper	481, 483, 491, 493, 501, 503
C 213484	Molding-Rear Wheel Cover-Upper	482, 484, 492, 494, 502, 504
BO 213486	Molding-Rear Rocker Panel-Upper-RH	482, 484, 492, 494, 502, 504
BO 213487	Molding-Rear Rocker Panel-Upper-LH	482, 484, 492, 494, 502, 504
BO 213490	Bracket-Windshield Wiper Motor	1948 thru 1950
BO 213491	Support-Windshield Cable Tension Pulley Brkt	1948 thru 1950
BO 213494	Molding-Front Vertical-Door Trim Panel	482, 484, 492, 494, 502, 504
BO 213495	Molding-Vertical-Door Trim Panel	482, 484, 492, 494, 502, 504
BO 213496	Molding-Vertical Rear-Rear Door Trim Panel	482-484-492-494 Sed
BO 213497	Molding-Vertical-Quarter Trim Panel	482-484-492-494-502-504 Bro-Sedan
BO 213502	Robe Hanger & Assist Handle-RH	482-484-492-494 Sed-Bro-ClubCpe-CvBro
BO 213503	Robe Hanger & Assist Handle-LH	482-484-492-494 Sed-Bro-ClubCpe-CvBro
BO 213511	Washer-Strg Column Brace Vibration-Dampener	1948, 1949, 501 thru 504, 500 CvBro
C 213512	Impact Bar-Front Bumper	1948, 1949
BO 213513	Grommet-F Pillar & Door Hydraulic Hose	1948 thru 1950 CvBro with Hyd Wdo Reg
C 213514	Bar-Front Bumper Impact Bar to Frame	1948, 1949
C 213516	Frame & Back Assy-Front Scat Cushion-RHD	1948-1949-501 thru 504 Sedan
C 213517	Frame Assy-Front Seat Cushion-RHD	1948-1949-501 thru 504 Bro-Cpes
BZ 213519	Spacer-Frt & Rr Bumper Guard & Impact Bar	1948 thru 1950
C 213520	Impact Bar-Outer-Rear Bumper-RH	1948 thru 1950
C 213521	Impact Bar-Outer-Rear Bumper-LH	1948 thru 1950
C 213522	Impact Bar-Center-Rear Bumper	1948, 1949, 500
213523	Brace-Steering Column (Use 216799)	1948, 1949, 500 CvBro
BO 213524	Pad-Vibration-Dampner-Steering Column Brace	1948, 1949, 500 CvBro
BZ 213525	Spacer-Fr Bumper Upper License Guard	1948, 1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 213528	Guard-License-Front Bumper-Lower	1948,1949,501 thru 504
BZ 213529	Guard-License-Front Bumper-Upper	1948,1949
BZ 213530	Guard Assy-Front Bumper-Inner-RH	1948,1949
BZ 213531	Guard Assy-Front Bumper-Inner-LH	1948,1949
BZ 213532	Guard Assy-Front Bumper-RH	481,483,491,493
BZ 213533	Guard Assy-Front Bumper-LH	481,483,491,493
BZ 213536	Guard Assy-Front Bumper-Outer-RH	1948,1949
BZ 213537	Guard Assy-Front Bumper-Outer-LH	1948,1949
BZ 213540	Guard Assy-Rear Bumper-RH	1948,1949
BZ 213541	Guard Assy-Rear Bumper-LH	1948,1949
BO 213542	Filler-Quarter Wdo Finish Mldg-RH	1948 thru 1950 ClubCpe
BO 213543	Filler-Quarter Wdo Finish Mldg-LH	1948 thru 1950 ClubCpe
BO 213554	Cross Pin-Rear Compt Partition Door Fastener	1948 thru 1950 BsCpe
BO 213557	Handle & Stud As sy-Rear Compt Partition Door Fastener	1948 thru 1950 BsCpe
BO 213558	Receptacle-Rear Compt Partition Door Fastener	1948 thru 1950 BsCpe
BO 213559	Washer-Rear Compt Partition Door Fastener	1948 thru 1950 BsCpe
BO 213562	Socket & Brkt Assy-Parking Lamp-Without DI	1948,1949,500
BO 213563	Socket & Brkt Assy-Parking Lamp & DI	1948,1949,500
BO 213564	Retainer-Instrument Panel Steering-Column Escutcheon	1948,1949
BO 213565	Bracket-Locating-Rear Seat Cushion Spring	1948 thru 1950 ClubCpe-CvBro
BO 213566	Spacer-Radio Dial Hole Cover Stud Nut	1948 thru 1950
BO 213567	Dust Shield-Windshield Wiper Cable	1948
213572	Wiper Arm-Windshield-Right (Use 216878)	1948,1949
213573	Wiper Arm-Windshield-Left (Use 216879)	1948,1949
BO 213576	Motor Assy-Windshield Wiper	1948,1949
BO 213578	Pulley Assy-W/Shield Wiper Cable Tension-RH	1948 thru 1950
BO 213579	Pulley Assy-W/Shield Wiper Cable Tension-LH	1948 thru 1950
BO 213580	Housing & Cable Assy-Windshield Wiper Pulley-RH	1948 thru 1950
BO 213581	Housing & Cable Assy-Windshield Wiper Pulley-LH	1948 thru 1950
BO 213582	Clamp-W/Shield Wiper Pulley Hsg	1948 thru 1950
BO 213583	Gasket-W/Shield Wiper Pulley Hsg	1948 thru 1950
213584	Control Assy-Windshield Wiper (Use 215978)	1948
*SP 213587	Wiper Blade-W/Shield	All
BO 213588	Reinforcement-W/Shield Wiper Pulley Brkt	All
BO 213590	Ornament-Instrument Finish Panel-"6"	482,492
BO 213591	Ornament-Instrument Finish Panel-"8"	484,494
BO 213592	Bracket-Door Window Regulator	481-491-500-501 CvBro
BO 213593	Cover-Inst Panel Radio Dial Hole-Without Radio	481,483,491,493
BO 213594	Cover-Inst Panel Radio Dial Hole-Without Radio	482,484,492,494
BO 213595	Shim-Strg Column Brace-Front & Top Control Valve Mtg Brkt	1948,1949,500 CvBro
BO 213596	Ornament-Glove Box Door-RH	481,483,491,493
BO 213597	Ornament-Glove Box Door-LH	481,483,491,493
BO 213598	Ornament-Glove Box Door-Right (Commodore)	482,484,492,494
BO 213599	Ornament-Glove Box Door-Left (Hudson)	482,484,492,494
BO 213602	Retainer-Fog Lamp Switch	1948 thru 1950
BO 213603	Tee Bolt-Inst Switch-Mounting Panel	1948 thru 1950
A 213608	Instrument Switch Mounting Panel Assy-Right-LHD (Use 215908)	1948
A 213609	Instrument Switch Mounting Panel Assy-Left-LHD (Use 215909)	1948
A 213610	Instrument Switch Mounting Panel Assy-Right-RHD	1948
A 213611	Instrument Switch Mounting Panel Assy-Left-RHD	1948
BO 213621	Ornament-Inst Switch-Mounting Panel-Left-LHD	1948-1949 Sed-Bro-Cpes
BO 213622	Ornament-Inst Switch-Mounting Panel-Right-RHD	1948,1949
BO 213624	Ornament-Inst Switch-Mounting Panel-Right-LHD	1948,1949
BO 213625	Ornament-Inst Switch-Mounting Panel-Left-RHD	1948-1949 Bro-Scd-Cpes
BO 213626	Ornament-Inst Switch-Mounting Panel-Center-LHD	481-483-491-493 Without HDM or VD
BO 213627	Ornament-Inst Switch-Mounting Panel-Center-LHD	482-484-492-494 Without HDM or VD
BO 213628	Ornament-Inst Switch-Mounting Panel-Center-RED	481,483,491,493
BO 213629	Ornament-Inst Switch-Mounting Panel-Center-RHD	482-484-492-494 Without HDM or VD
A 213630	Instrument Panel Assy-Dark Walnut	481,483
213631	Instrument Panel Assy-Dark Walnut (Use 213633)	482,484
*A 213632	Instrument Panel Assy-Light Brown	481,483,491,493
*A 213633	Instrument Panel Assy-Light Brown	482,484,492,494
C 213642	Mat & Pad Assy-Front Floor-LHD	491-493 with Cloth Trim
C 213643	Mat & Pad Assy-Front Floor-LHD	492,494,491-493 exc CvBro with Leather Trim
BO 213648	Cover-Hinge Pocket-Front Door Inner Panel	1949,1950
C 213650	Molding-Rocker Panel-Upper-RH	481,483,491,493,501,503
C 213651	Molding-Rocker Panel-Upper-LH	481,483,491,493,501,503
C 213652	Molding-Rocker Panel-Lower-RH	1948,1949,501 thru 504
C 213653	Molding-Rocker Panel-Lower-LH	1948,1949,501 thru 504
BO 213654	Shim-Short-Front End Panel to Hood	1948 thru 1950
BO 213658	Seal Assy-Rear Seat Tray to Rear Fender-RH	1948 Bro-ClubCpe-BsCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 213659	Seal Assy-Rear Seat Tray to Rear Fender-LH	1948 Bro-ClubCpe-BsCpe
213660	Quarter Panel Assy-Inner-RH	1948 thru 1950 BsCpe
213661	Quarter Panel Assy-Inner-LH	1948 thru 1950 BsCpe
213682	Front Door Opening Belt W/Strip RH (Use 1-216852, 3-170958 & 1-217339)	1948
BO 213684	Escutcheon-Instrument Panel Strg Column-RH-LHD	1948,1949
BO 213685	Escutcheon-Instrument Panel Strg Column-LH-LHD	1948,1949
BO 213686	Escutcheon-Instrument Panel Strg Column-RH-RHD	1948,1949
BO 213687	Escutcheon-Instrument Panel Strg Column-LH-RHD	1948,1949
213688	Retainer-Inst Panel Strg-Column Escutcheon (Use 213564)	1948
BO 213691	Retainer-Front Seat Back Valance	482-484-492-494-502-504 Sedan
BO 213701	Retainer-Windshield Wiper Cable Dust Shield	1948 thru 1950
213706	Weatherstrip-Front Door-Front (Use 213742)	1948
C 213711	Weatherstrip Assy-Front Door Bottom	1948-1949 Sed
C 213712	Weatherstrip Assy-Rear Door Bottom	1948-1949 Sed
C 213713	Weatherstrip Assy-Door Bottom	1948-1949 Bro-ClubCpe-BsCpe-CvBro
HA 213724	Back-up Lamp Assy	1948 thru 1950
*HA 213725	Back-up Lamp Kit	1948 thru 1950
213736	Weatherstrip-Fr Door Opening Belt-RH (Use 1-216852, 3-170958 & 1-217339)	1948,1949
213737	Weatherstrip-Fr Door Opening Belt-LH (Use 1-216853, 3-170958 & 1-217339)	1948,1949
BO 213738	Spacer Block-Rear Seat Center Arm Rest	482-484-492-494-502-504 CvBro
BO 213742	Weatherstrip-Fr Door-Front	1948,1949
BO 213743	Weatherstrip-Rear Door-Front	1948 thru 1950 Sedan
213752	Weatherstrip-Door Opening-Rear (Use 216360 & 216361)	1948-1949 Bro-ClubCpe-BsCpe
213754	Weatherstrip-Door Opening-Rear-RH (Use 216362)	1948-1949 Sed
213755	Weatherstrip-Door Opening-Rear-LH (Use 216363)	1948-1949 Sed
BO 213779	Retainer-Lower Outer-Windshield Glass	1948,1949
213780	Trim Panel-Rear Seat Back (Use 214218)	1948 Bro-Sed
C 213781	Spring-F Seat Back	1948 thru 1950 Sed
C 213782	Spring-F Seat Back-RH	1948 thru 1950 Bro-Cpes
C 213783	Spring-F Seat Back-LH	1948 thru 1950 Bro-Cpes
BO 213796	Ornament-Inst Switch-Mounting Panel-Center-LHD	481-483-491-493 with HDM or VD
BO 213797	Ornament-Inst Switch-Mounting Panel-Center-LHD	482-484-492-494 with HDM or VD
C 213828	Mldg-Rear-Top Front Header	1948 thru 1950 CvBro
BO 213830	Door Assy-Glove Box-Right-LHD	481,483
BO 213831	Door Assy-Glove Box-Left-LHD	481,483
BO 213832	Door Assy-Glove Box-Right	1948,1949
BO 213833	Door Assy-Glove Box-Left-LHD	1948,1949
BO 213834	Door Assy-Glove Box-Right-RHO	481,483
BO 213835	Door Assy-Glove Box-Left-RHD	481,483
BO 213836	Door Assy-Glove Box-Right-RHD	1948,1949
BO 213837	Door Assy-Glove Box-Left	1948,1949
C 213854	Trimboard-Qtr Trim Support Panel Trimboard	1948-1949 CvBro
213857	Liner-F Door Inner Panel-LH (Use 216885)	1948-1949 Sedan
BO 213859	Spacer-Visor Brkt-Trimmed	481 exc CvBro,483
BO 213860	Door Assy-Glove Box-Right-LHD	431,483
BO 213861	Door Assy-Glove Box-Left-LHD	481,483
BO 213862	Door Assy-Glove Box-Right-RHD	481,483
BO 213863	Door Assy-Glove Box-Left-RHD	481,483
BO 213864	Door Assy-Glove Box-Right	482,484,492,494
BO 213865	Door Assy-Glove Box-Left-LHD	482,484
BO 213866	Door Assy-Glove Box-Right-RHD	482,484
BO 213867	Door Assy-Glove Box-Left	482,484,492,494
*C 213868	Top Complete-Trimmed	481-491-500-501 CvBro
*C 213869	Top Complete-Trimmed	484-494-502-504 CvBro
HA 213872	Radio Assy-Export	1948,1949
213875	Weatherstrip Kit-F Door Opening Belt (Use 1-216852, 1-216853,1-217339 & 6-170958)	1948,1949
BO 213876	Radio Warranty Registration Tag-Export	1948,1949
BO 213877	Radio Owner Manual-Export	1948,1949
213880	Speaker Assy-Radio (Use 213921)	1948
BO 213881	Screen-Radio Speaker	1948 thru 1950
BO 213882	Cable Assy-Radio Speaker	1948,1949
BO 213883	Pad-Radio Antenna Control Insulator	1948 thru 1950
BO 213884	Stop-Radio Antenna Tube	1948 thru 1950
BO 213885	Bushing-Radio Antenna Control	1948 thru 1950
BO 213886	Escutcheon-Radio Antenna Control Knob	1948 thru 1950
BO 213887	Knob Assy-Radio Antenna Control	1948 thru 1950
BO 213888	Control Assy-Radio Antenna	1948 thru 1950
BO 213889	Cable Assy-Radio Antenna	1948 thru 1950
*HA 213890	Radio Antenna Kit	1948 thru 1950
BO 213891	Tube & Rod Assy-Radio Antenna	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 213892	Lead Rod Assy-Radio Antenna	1948 thru 1950
BO 213893	Spacer-Radio Antenna Lead Rod	1948 thru 1950
BO 213894	Spring-Radio Tuning Control Trim Ring	1948 thru 1950
BO 213895	Ring-Radio Tone Control	1948 thru 1950
BO 213896	Trim Ring-Radio Tuning Control	1948 thru 1950
*HA 213898	Radio Kit Complete-Domestic	1948,1949
HA 213899	Radio Kit Complete-Export	1948,1949
213900	Headlining Assy	1948-1949 Bro
213901	Headlining Assy	1948-1949 Sed
213902	Headlining Assy	1948-1949 Cpes
BO 213903	Clip-Front Splash Guard Molding	1948,1949
BO 213904	Seal-Frame Side Member to Rear Fender Hole	1949-1950 Sedan
BO 213906	Hinge-Rear Compt Partition Door-Door Half	1948 thru 1950 BsCpe
BO 213907	Hinge-Rear Compt Partition Door-Body Half	1948 thru 1950 BsCpe
*HA 213908	Rear Seat Radio Speaker Kit	1948-1949 Sed-Bro-ClubCpe
BO 213921	Speaker & Screen Assy-Radio	1948 thru 1950
213923	Carpet Assy-Rear Compt Floor Panel Extension	1948 thru 1950 CvBro
* 213927	Rear Curtain & Window Assy-Top	481-491-1950 CvBro
C 213928	Carpet-Front Seat Tray-RH	1948,1949
C 213929	Carpet-Front Seat Tray-LH	1948,1949
BO 213946	Visor Assy-Inside-Hinge Type-Cloth Trim	481-483-491-493 exc CvBro
BO 213947	Visor Assy-Inside-Hinge Type-Russet Leather	481-483-491-493-500 exc CvBro
BO 213948	Visor Assy-Inside-Hinge Type-Gray Leather	481-483-491-493-500 exc CvBro
213976	Liner-Quarter Panel (Use 216236 RH or 216237 LH)	1948 CvBro
BO 213979	Nut-Antenna Lead Rod	1948 thru 1950
BO 213982	Bushing-Radio Antenna Lead Rod	1948 thru 1950
BO 213984	Wrench-Antenna Control Arm Set Screw	1948 thru 1950
213985	Liner-Door Inner Panel-LH (Use 216889)	1948-1949 Bro-BsCpe-ClubCpe-CvBro
*HA 213986	Lamp Kit-Under Hood, Locker Box & Rear Compt	1948 thru 1950
*HA 213987	Lamp Kit-Under Hood	1948 thru 1950
*HA 213988	Lamp Kit-Locker Box	1948 thru 1950
*HA 213989	Lamp Kit-Rear Compt	1948 thru 1950
BO 213990	Trimboard-End-Front Seat Foot Rest-RH	1948-1949 Sedan
BO 213991	Trimboard-End-Front Seat Foot Rest-LH	1948-1949 Sedan
*C 213998	Cushion Complete-Front Seat-Lea Trim	1948 thru 1950 CvBro
*C 213999	Cushion Complete-Front Seat-Comb Trim	1948-1949 CvBro
214000	Trim Assy-F Seat Cushion-Lea Trim	1948-1949 CvBro
214001	Trim Assy-F Seat Cushion-Comb Trim	1948-1949 CvBro
214006	Trim Assy-F Seat Back-RH-Lea Trim	1948-1949 CvBro
214007	Trim Assy-F Seat Back-LH-Lea Trim	1948-1949 CvBro
214008	Trim Assy-F Seat Back-RH-Comb Trim	1948-1949 CvBro
214009	Trim Assy-F Seat Back-LH-Comb Trim	1948-1949 CvBro
214010	Liner-R Door Inner Panel-RH (Use 216886)	1948-1949 Sedan
214011	Arm Rest Assy (Use 216091)-Dark Red Lea	1948 exc 484 CvBro
C 214016	Trim Assy-F Seat Side Panel Ext-RH	1948-1949 Bro-Cpes
C 214017	Trim Assy-F Seat Side Panel Ext-LH	1948-1949 Bro-Cpes
*C 214018	Frame & Back Complete-F Seat Cushion-LHD Les Trim	481-491 CvBro
*C 214019	Frame & Back Complete-F Seat Cushion-LHD Comb Trim	481-491 CvBro
C 214020	Frame & Back Complete-F Seat Cushion-RHD Lea Trim	481-491 CvBro
C 214021	Frame & Back Complete-F Seat Cushion-RHD Comb Trim	481-491 CvBro
C 214024	Trim Assy-Front Pillar-Upper-RH	1948 thru 1950 CvBro
C 214025	Trim Assy-Front Pillar-Upper-LH	1948 thru 1950 CvBro
214026	Clip-Dash Trim Panel & Silencer (Use 215099)	1949
C 214028	Retainer-Top Front Header Front Lower Mldg	1948 thru 1950 CvBro
C 214036	Cover-Folding Top-Plastic	1949 CvBro
214037	Bag Assy-Top Dust Boot	1948 thru 1950 CvBro
214038	Dust Boot Assy-Top	1948 thru 1950 CvBro
*C 214039	Deck & Side Quarters Assy-Top	1948 thru 1950 CvBro
214040	Robe Hanger Assy (Use 214343) Cloth Trim	481-483 Sed
BO 214041	Robe Hanger Assy-Russet Leather	481-483 Sed
214042	Robe Hanger Assy-Gray Leather (Use 216576)	481-483-491-493 Sedan
BO 214044	Robe Hanger Assy-Dark Red Lea	481-483-491-493 Sedan
BO 214045	Robe Hanger Assy-Dar Red Lea	481-483-491-493 Bro-ClubCpe
C 214056	Windlace Assy-Center Pillar-Front-RH	1948 thru 1950 Sedan
C 214057	Windlace Assy-Center Pillar-Front-LH	1948 thru 1950 Sedan
C 214058	Windlace Assy-Center Pillar-Rear-RH	1948-1949 Sedan
C 214059	Windlace Assy-Center Pillar-Rear-LH	1948-1949 Sedan
214060	Liner-Quarter Inner Panel-RH (Use 216882)	1948-1949 Bro
C 214086	Carpet Assy-Rear-F Seat Cushion Frame	1948-1949 ClubCpe-CvBro
C 214088	Rubber Pad-F Seat Cushion Spring-Cloth Trim	481-483-491-493-500 Bro-Cpes
BO 214089	Seal-Door Front Lower Corner	1948,1949
BO 214090	Bracket-Robe Hanger-RH	482-484-492-494-502-504 Bro-ClubCpe CvBro
BO 214091	Bracket-Robe Hanger-LH	482-484-492-494-502-504 Bro-ClubCpe CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 214108	Binding-Double Fold-Gray	1948-1949 CvBro
C 214120	Silencer-Rear Compt Door Outer Panel	1948 thru 1950 Cpes-CvBro
214129	Clip-Upper-Door Pocket Trimboard Retaining (Use 210829)	482,484
C 214134	Trimboard-Rear Compt Floor to Rear Seat Tray	1948-1949 BsCpe
C 214139	Support Assy-Rear Seat Back Center Arm Rest	482-484-492-494-502-504 ClubCpe
*C 214145	Cushion Complete-F Seat-Without Rubber Pad- Cloth Trim	481-483-491-493 Sed
*C 214146	Cushion Complete-F Seat-With Rubber Pad-Cloth Trim	481-483-491-493 Sed
C 214147	Trim Assy-F Seat Cushion-Cloth Trim	481-483-491-493 Sed
*C 214148	Cushion Complete-F Seat-Cloth Trim	482-484-492-494-501-503 Sed
C 214149	Trim Assy-F Seat Cushion-Cloth Trim	482-484-492-494 Sedan
*C 214150	Cushion Complete-F Seat-Without Rubber Pad-Cloth Trim	481-483-491-493 Bro-Cpes
*C 214151	Cushion Complete-F Seat-With Rubber Pad-Cloth Trim	481-483-491-493 Bro-Cpes
*C 214152	Cushion Complete-F Seat-Cloth Trim	482-484-492-494-501-503 Bro-Cpes
HS 214153	Display Rack-For Touch-Up Lacquers	1948 thru 1950
C 214155	Spring Pad & Protector-F Seat Cushion	1948 thru 1950 CvBro
*C 214156	Cushion Complete-R Seat-Without Rubber Pad-Cloth Trim	481-483 Bro-Sed-ClubCpe
*C 214157	Cushion Complete-R Seat-With Rubber Pad-Cloth Trim	481-483 Bro-Sed-ClubCpe
214158	Cushion Complete-R Seat-Cloth Trim(Use 216484)	482-484 Bro-Sed
*C 214159	Cushion Complete-R Seat-Without Rubber Pad-Cloth Trim	481-483 ClubCpe
*C 214160	Cushion Complete-R Seat-With Rubber Pad-Cloth Trim	481-483 ClubCpe
*C 214161	Cushion Complete-R Seat-Cloth Trim	482-484 ClubCpe
C 214162	Trim Assy-F Seat Cushion-Cloth Trim	481-483-491-493 Bro-Cpes
C 214163	Trim Assy-F Seat Cushion-Cloth Trim	482-484-492-494 Bro-Cpes
*C 214164	Frame & Back Comp-F Seat Cushion-Less Rubber Pad- LHD	481-491 BsCpe
C 214165	Frame & Back Comp-F Seat Cushion-Less Rubber Pad- RHD	481-491 BsCpe
C 214166	Trim Assy-Rear Seat Cushion-Cloth Trim	481-483 Bro-Sed
C 214167	Trim Assy-Rear Seat Cushion-Cloth Trim	482-484 Bro-Sed
C 214168	Trim Assy-Rear Seat Cushion-Cloth Trim	481-483 ClubCpe
C 214169	Trim Assy-Rear Seat Cushion-Cloth Trim	482-484 ClubCpe
214172	Cushion Comp-Rear Seat-Lea Trim	1948 CvBro
214173	Cushion Comp-Rear Seat-Comb Trim	1948 CvBro
214174	Trim Assy-Rear Seat Cushion-Lea Trim	1948 CvBro
214175	Trim Assy-Rear Seat Cushion-Comb Trim	1948 CvBro
C 214176	Trim Assy-Front Seat Back-RH-Cloth Trim	481-483-491-493 Bro-Cpes
C 214177	Trim Assy-Front Seat Back-LH-Cloth Trim	481-483-491-493 Bro-Cpes
C 214178	Trim Assy-Front Seat Back-RH-Less Rubber Pads Cloth Trim	482-484-492-494 Bro-ClubCpe
C 214179	Trim Assy-Front Seat Back-LB-Less Rubber Pads Cloth Trim	482-484-492-494 Bro-ClubCpe
C 214180	Trim Assy-Front Seat Back-Cloth Trim	481-483-491-493 Sed
C 214181	Trim Assy-Front Seat Back-Less Rubber Pads- Cloth Trim	482-484-492-494 Sed
*C 214182	Spring & Trim Assy-Front Seat Back-RH-Cloth Trim	481-483-491-493 Bro-Cpes
*C 214183	Spring & Trim As sy-Front Seat Back-LH-Cloth Trim	481-483-491-493 Bro-Cpes
*C 214184	Spring & Trim Assy-Front Seat Back-RH-Less Rubber Pads	482-484-492-494-501-503 Bro-Cpes
*C 214185	Spring & Trim Assy-Front Seat Back-LH-Less Rubber Pads	482-484-492-494-501-503 Bro-Cpes
*C 214186	Spring & Trim Assy-Front Seat Back-Less Rubber Pads-Cloth Trim	481-483-491-493 Sedan
*C 214187	Spring & Trim Assy-Front Seat Back-Less Rubber Pads-Cloth Trim	482-484-492-494-501-503 Sedan
*C 214188	Back Complete-Rear Seat-Cloth Trim	481-483-491-493 Bro-Sedan
*C 214190	Back Complete-Rear Seat-Cloth Trim	481-483-491-493 ClubCpe
BZ 214191	Drain Hose-Gas Overflow-Rear Fender	1948 thru 1950
*C 214192	Front Seat Cushion Frame-LHD-Less Rubber Pads	481-483-491-493 Bro
C 214193	Front Seat Cushion Frame-RHD-Less Rubber Pads	481-483-491-493 Bro
*C 214196	Frame & Back Comp-F Seat Cushion-LHD-less Rubber Pads-Cloth Trim	481-483-491-493 Sed
C 214197	Frame & Back Comp-F Seat Cushion-RHD-less Rubber Pads-Cloth Trim	481-483-491-493 Sed
*C 214198	Frame & Back Comp-F Seat Cushion-LHD-Less Rubber Pads-Cloth Trim	482-484-492-494 Sed
C 214199	Frame & Back Comp-F Seat Cushion-RHD-Less Rubber Pads-Cloth Trim	482-484-492-494 Sed
M 214200	Seat Cloth-Gray	482-484-492-494 exc CvBro,501-503 Bro
M 214201	Sidewall Cloth-Gray	482-484-492-494 exc CvBro,501-503 Bro
M 214202	Headlining Cloth-Gray	1948 All
C 214203	Seaming Lace-Gray	1948,1949,1950
M 214206	Seat Leather-Gray	1948-1949 exc CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
M 214207	Sidewall Imitation Leather-Gray	1948-1949 exc CvBro
M 214208	Headlining Imitation Leather-Gray	1948-1949 exc CvBro
C 214218	Trim Panel-Rear Seat Back	1948-1949 Sed-Bro
*C 214224	Arm Rest-Comp-Rear Seat Back-Lea Trim	482-484-492-494 Sed-ClubCpe
*C 214238	Spring & Trim Assy-Rear Seat Back-RH-Cloth Trim	482-484-492-494 ClubCpe
*C 214239	Spring & Trim Assy-Rear Seat Back-LH-Cloth Trim	482-484-492-494 ClubCpe
C 214240	Trim Assy-Rear Seat Back-Cloth Trim	481-483-491-493 Bro-Sed
BO 214241	Seal-Burlap-R Seat Back Trim Panel Extension	1948 Sed-Bro-Cpes
*C 214242	Spring & Trim Assy-Rear Seat Back-RH-Cloth Trim	482-484-492-494 Sed
*C 214243	Spring & Trim Assy-Rear Seat Back-LH-Cloth Trim	482-484-492-494 Sed
C 214244	Trim Assy-Rear Seat Back-RH-Cloth Trim	482-484-492-494 Sed
C 214245	Trim Assy-Rear Seat Back-LH-Cloth Trim	482-484-492-494 Sed
C 214246	Trim Assy-Rear Seat Back-Cloth Trim	481-483-491-493 ClubCpe
*C 214260	Arm Rest Comp-Rear Seat Back	482-484-492-494 ClubCpe-Sed
C 214263	Pad-Rear Seat Back Center Arm Rest	482-484-492-494-502-504 Bro-Sed-ClubCpe
BO 214268	Hinge & Cover Assy-Rear Compt Door	1948-1949 Bro-Sed
BO 214269	Hinge & Cover Assy-Rear Compt Door	1948-1949 Cpes-CvBro
C 214270	Carpet Assy-Front Seat Foot Rest	1948-1949 Sedan
C 214274	Carpet Assy-Rear Floor	1948-1949-501-503 ClubCpe
C 214275	Carpet Assy-Front Seat Tray-Rear	1948-1949 CvBro
C 214276	Carpet Assy-Frame Sidemember	1948,1949
C 214277	Carpet Assy-Frame Sidemember	1948,1949
C 214278	Covering Assy-Rear Compt Floor	1948-1949 BsCpe
C 214279	Carpet Assy-Rear Seat Tray	1948-1949 BsCpe
C 214280	Carpet Assy-Rear Floor	1948-1949 BsCpe
C 214281	Carpet Assy-Rear Floor	1948-1949-501-503 Bro-Sed
C 214282	Carpet Assy-Side-Rear Floor-RH	1948-1949 Sed
C 214283	Carpet Assy-Side-Rear Floor-LH	1948-1949 Sedan
C 214286	Carpet Assy-Side-Rear Floor-RH	1948-1949 Bro-Cpes-CvBro
C 214287	Carpet Assy-Side-Rear Floor-LH	1948-1949 Bro-Cpes-CvBro
C 214290	Mat-Rear Compt Floor	482-484-492-494-502-504 Bro-Sed
C 214291	Mat-Rear Compt Floor	482-484-492-494-502-504 ClubCpe
C 214292	Covering Assy-Rear Compt Floor	481-483 Bro-Sed
C 214293	Rubber Mat-Rear Compt Floor	481-483 ClubCpe
M 214300	Seat Cloth-Gray-Green	481-483-491-493 exc CvBro,500 ClubCpe
M 214301	Sidewall Cloth-Gray-Green	481 exc CvBro,483
M 214302	Sidewall Cloth-Gray	481-483-491-493 exc CvBro
C 214305	Carpet-Gray	481-483-491-493 exc CvBro
214306	Carpet Assy-Hydraulic Power Unit Housing Gear	1948 thru 1950 CvBro
M 214307	Sidewall Imitation Leather-Light Gray	481-483-491-493 exc CvBro
BO 214308	Seal-Qtr Panel to Rear Fender-Long	1948 thru 1950 CvBro
BO 214310	Seal-Qtr Panel to Rear Fender-Short	1948 thru 1950 CvBro
C 214320	Cowl Side Trim Panel & Carpet Assy-RH	1948
C 214321	Cowl Side Trim Panel & Carpet Assy-LH	1948
BO 214340	Robe Hanger Assy-Gray Cloth	481-483 Bro-ClubCpe
BO 214341	Robe Hanger Assy-Russet Lea	481-483 Bro-ClubCpe
BO 214342	Robe Hanger Assy-Gray Lea	481-483-491-493 Bro-ClubCpe
BO 214343	Robe Hanger Assy-Gray Cloth	481-483-491-493 Sed
BO 214344	Robe Hanger Assy-Gray Cloth	491-493 Bro-ClubCpe
214370	Trim Assy-Rear Seat Back-RH-Lea Trim	482-484-492-494 CvBro
214371	Trim Assy-Rear Seat Back-LH-Lea Trim	482-484-492-494 CvBro
214372	Trim Assy-Rear Seat Back-RH-Comb Trim	482-484-492-494 CvBro
214373	Trim Assy-Rear Seat Back-LH-Comb Trim	482-484-492-494 CvBro
BO 214375	Button-Seat Upholstery-Cloth Trim	1948
BO 214378	Button-Upholstery	1948 thru 1950
BO 214394	Patch-R Door Inner Panel Liner	1948-1949 Sedan
C 214395	Rubber Pad Assy-Rear Seat Back Center Arm Rest	482-484-492-494-502-504 CvBro
BO 214397	Cement-EC-711-3 oz	1948 thru 1950
BO 214398	Cement-EC-308-3 oz	1948 thru 1950
BO 214399	Dolphinite Sealer #3580 -6 oz	1948 thru 1950
M 214400	Seat Cloth-Tan	482-484-492-494 Exc CvBro
M 214401	Sidewall Cloth-Tan	482-484-492-494 exc CvBro,501-503 Cpes-Sedan
M 214402	Headlining Cloth-Tan	482-484-492-494 exc CvBro
C 214403	Seaming Lace-Tan	482-484-492-494 exc CvBro,501-503 Cpes-Sed
C 214404	Windlace-Tan	482-484-492-494 exc CvBro,501-503 Cpes-Sed
M 214405	Carpet-Tan	482,484,492,494
M 214406	Seat Leather-Russet	1948-1949 exc CvBro
M 214407	Sidewall Imitation Leather-Russet	1948-1949 exc CvBro
M 214408	Headlining Imitation Leather-Russet	1948-1949 exc CvBro
M 214411	Sidewall Imitation Leather-Brown	482-484-492-494 exc CvBro
C 214418	Carpet Assy-F Seat Side Panel Extension-RH	1948 BsCpe
C 214419	Carpet Assy-F Seat Side Panel Extension-LH	1948 BsCpe
214420	Cushion Complete-R Seat-Less Rubber Pads(Use 216486)	481-483 Bro-Sed
214421	Cushion Complete-R Seat-With Rubber Pads(Use 216489)	1948 ClubCpe

Part No.	Name	Models
214422	Cushion Complete-R Seat-Without Rubber Pads (Use 216488)	481-483 ClubCpe
214423	Trim-Rear Seat Cushion (Use 216499)	1948 ClubCpe
*C 214430	Frame & Back Comp-F Seat Cushion-Lea-LHD	481-483-491-493 Sedan
C 214431	Frame & Back Comp-F Seat Cushion-Lea-RHD	481-483-491-493 Sedan
C 214432	Frame & Back Contp-F Seat Cushion-Lea-LHD	481-483-491-493 Bro
C 214433	Frame & Back Comp-F Seat Cushion-Lea-RHD	481-483-491-493 Bro
*C 214434	Frame & Back Comp-F Seat Cushion-Lea-LHD	481-483-491-493 ClubCpe
C 214435	Frame & Back Comp-F Seat Cushion-Lea-RHD	481-483-491-493 ClubCpe
*C 214436	Frame & Back Comp-F Seat Cushion-Lea-LHD	482-484-492-494 ClubCpe
C 214437	Frame & Back Comp-F Seat Cushion-Lea-RHD	482-484-492-494 ClubCpe
*C 214438	Cushion Complete-F Seat-Less Rubber Pads-Lea	481-483-491-493-501-503 Sedan
*C 214439	Cushion Complete-F Seat-With Rubber Pads-Lea	1948-1949 Bro-BsCpe-ClubCpe
C 214440	Cushion Complete-F Seat-Less Rubber Pads-Lea	481-483-491-493 Bro-BsCpe-ClubCpe
214470	Visor Assy-Hinge Type (Use 213946) Cloth	481 exc CvBro, 483
214471	Visor Assy-Hinge Type (Use 213948) Gray Lea	481 exc CvBro, 483
214472	Visor Assy-Hinge Type (Use 213947) Russet Lea	481 exc CvBro, 483
BO 214473	Visor Assy-Hinge Type-Maroon Lea	481 exc CvBro, 483
BO 214474	Visor Assy-Hinge Type-Red Lea	500-501-503 exc CvBro
BO 214480	Visor Assy-Swivel-Tan Cloth	482-484-492-494 exc CvBro
BO 214481	Visor Assy-Swivel-Gray Cloth	482-484-492-494 exc CvBro
BO 214483	Visor Assy-Swivel-Gray Lea	482-484-492-494 exc CvBro
BO 214484	Visor Assy-Swivel-Russet Lea	482-484-492-494 exc CvBro
BO 214485	Visor Assy-Swivel-Maroon Lea	482-484-492-494-502-504 exc CvBro
C 214486	Molding-Quarter Trim Panel-Lower-Cloth Trim	481-483-491-493 ClubCpe
BO 214488	Mldg-Rear Door Trim Panel-Upper-Front	481-483-491-493-501-503 Sed
BO 214489	Mldg-Rear Door Trim Panel-Upper-Rear	481-483-491-493-501-503 Sed
C 214490	Mldg-Front Door Trim Panel-Upper	481-483-491-493 Sedan
C 214491	Mldg-Door Trim Panel-Upper	481-483-491-493 Bro-Cpes
C 214493	Mldg-Qtr Trim Panel-Cloth Trim	481-483-491-493 Bro-ClubCpe, 501-503 ClubCpe
*HA 214494	Molding Kit-Door Pocket	481-483-491-493 Sed
*HA 214495	Mldg Kit-Door Pocket	481-483-491-493 Bro-ClubCpe
*HA 214496	Molding Kit-Door Pocket	481-483-491-493 BsCpe
*HA 214497	Molding Kit-Door Pocket	481-491 CvBro
C 214498	Rubber Pad -Center-Front Seat Cushion-RH-Cloth Trim	482-484-492-494 ClubCpe, 501-503 Bro-Cpes
C 214499	Rubber Pad-Center-Front Seat Cushion-LH-Cloth Trim	482-484-492-494 ClubCpe, 501-503 Bro-Cpes
C 214500	Rubber Pad-End-Front Seat Cushion-RH-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 exc CvBro
C 214501	Rubber Pad-End-Front Seat Cushion-LH-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501 503 exc CvBro
C 214502	Rubber Pad-Inner-Front Seat Cushion-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 exc CvBro
C 214503	Rubber Pad-Ft Seat Pad-Cloth Trim	481-483-491-493-500 Sedan
C 214504	Rubber Pad-Frt Seat Pad-RH-Cloth Trim	481-483-491-493-500 Bro-Cpes
C 214505	Rubber Pad-Frt Seat Pad-LH-Cloth Trim	481-483-491-493-500 Bro-Cpes
BZ 214506	Tapping Plate-Spare Wheel Support	1948, 1949
C 214508	Rubber Pad-End-Front Seat Back-RH-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 exc CvBro
C 214509	Rubber Pad-End-Front Seat Back-LH-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 exc CvBro
C 214510	Rubber Pad-End-Rear Seat Cushion-RH-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 Bro-Sed-ClubCpe
C 214511	Rubber Pad-End-Rear Seat Cushion-LH-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 Bro-Sed-ClubCpe
C 214512	Rubber Pad-Inner-Seat Cushion-Cloth Trim	482-484-492-494 Sed-ClubCpe, 501-503 exc CvBro
BO 214528	Assist Strap Assy	481-483-491-493 Sed-Bro-ClubCpe
BO 214529	Assist Strap Assy	481-483-491-493-500-501-503 Bro-Sed-ClubCpe
BO 214530	Assist Strap Assy	481-483-491-493-500-501-503 Bro-Sed-ClubCpe
BO 214531	Assist Strap Assy	481-483-491-493-500-501-503 Bro-Sed-ClubCpe
BO 214540	Robe Hanger-Maroon Lea	482-484-492-494 CvBro
BO 214541	Robe Hanger-Gray Cloth	482-484-492-494 ClubCpe
BO 214542	Robe Hanger-Tan Cloth	482-484-492-494 ClubCpe
BO 214543	Robe Hanger-Russet Lea	482-484-492-494 ClubCpe
BO 214544	Robe Hanger-Gray Lea	482-484-492-494 ClubCpe
BO 214545	Robe Hanger-Dark Red Lea	482-484-492-494 ClubCpe
214554	Trim Assy-Rear Seat Back Arm Rest-Lea Trim	482-484-492-494 CvBro
214555	Trim Assy-Rear Seat Back Arm Rest-Comb Trim	482-484-492-494 CvBro
C 214560	Trimboard & Trim Assy-Rear Shelf Panel-Cloth Trim	1948-1949 Bro-Sed
C 214561	Trimboard & Trim Assy-Rear Shelf Panel-Cloth Trim	1948-1949 Cpes
C 214562	Trimboard & Trim Assy-Rear Shelf Panel-Lea Trim	1948-1949 Bro-Sed
BO 214564	Weatherstrip-Door Opening-Upper	1948-1949 Sedan
214565	Weatherstrip-Door Opening-Upper (Use 217164 for RH, 217165 for LH)	1948-1949 Bro-ClubCpe-BsCpe
*C 214567	Tray Assy-Rear Seat	1948 thru 1950 CvBro
C 214569	Covering Assy-Rear Compt Floor	481-491 CvBro
C 214570	Rubber Pad-Rear Compt Floor	482-484-492-494-502-504 CvBro
*C 214571	Spring & Trim Assy-Rear Seat Back-Lea Trim	481-491 CvBro
*C 214572	Spring & Trim Assy-Rear Seat Back-Comb Trim	481-491 CvBro
C 214573	Trim Assy-Rear Scat Back-Lea Trim	481-491 CvBro
C 214574	Trim Assy-Rear Seat Back-Comb Trim	481-491 CvBro
*C 214580	Spring & Trim Assy-Rear Seat Back-Comb Trim	482-484-492-494 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

345

Part No.	Name	Models
214582	Arm Rest-R Scat Back Center	482-484-492-494-502-504 CvBro
C 214591	Spring-Rear Seat Cushion	1948-1949-501 thru 504 Bro-Sed
C 214592	Spring-Rear Seat Cushion	1948-1949-501 thru 504 ClubCpe
C 214593	Spring-Rear Seat Cushion	1948 thru 1950 CvBro
BO 214616	Slide Fastener Assy-Top Rear Curtain-RH-Black	481-491 CvBro
BO 214617	Slide Fastener Assy-Top Rear Curtain-LH-Black	481-491 CvBro
BO 214618	Slide Fastener Assy-Top Rear Curtain-RH-Gray	481-491-1950 CvBro less Opt plastic wdo
BO 214619	Slide Fastener Assy-Top Rear Curtain-LH-Gray	481-491-1950 CvBro less Opt Plastic wdo
*HA 214622	Seat Cover-Front & Rear	481-483-491-493 ClubCpe
*HA 214623	Seat Cover-Front & Rear	481-483-491-493 ClubCpe
*HA 214624	Seat Cover-Front & Rear	481-483-491-493 ClubCpe
*HA 214625	Seat Cover-Front & Rear	481-483-491-493 Sed
*HA 214626	Seat Cover-Front & Rear	1948-1949 Bro
*HA 214629	Seat Cover-Front & Rear	481-483-491-493 Sedan
*HA 214630	Seat Cover-Front & Rear	1948-1949 Bro
*HA 214633	Seat Cover-Front & Rear	482-484-492-494 Sedan
*HA 214634	Seat Cover-Front & Rear	482-484-492-494 ClubCpe
*HA 214637	Seat Cover-Front & Rear	482-484-492-494 Sedan
*HA 214638	Seat Cover-Front & Rear	482-484-492-494 ClubCpe
*HA 214641	Seat Cover-Front & Rear	482-484-492-494 Sedan
*HA 214642	Seat Cover-Front & Rear	482-484-492-494 ClubCpe
*HA 214645	Seat Cover-Front & Rear	482-484-492-494 Sedan
*HA 214646	Seat Cover-Front & Rear	482-484-492-494 ClubCpe
C 214650	Frame & Back Comp-F Seat Cushion-Lea Trim-LHD	482-484-492-494 Sed
C 214651	Frame & Back Comp-F Seat Cushion-Lea Trim-RIM	482-484-492-494 Sed
C 214658	Side Panel & Trim Assy-Rear Compt Partition-RH	1948 thru 1950 BsCpe
C 214659	Side Panel & Trim Assy-Rear Compt Partition-LH	1948 thru 1950 BsCpe
C 214670	Cushion Complete-F Seat-With Rubber Pads-Lea	1948-1949-501 thru 504 Sed
214672	Cushion Complete-R Seat-With Rubber Pads-Lea	1948 Bro-Sed
BO 214674	Seal-Door Hyd Wdo Regulator Switch	1949 CvBro
C 214684	Spring & Trim Assy-Rear Seat Back-RH	482-484-492-494-502-504 Bro-Sed
C 214685	Spring & Trim Assy-Rear Seat Back-LH	482-484-492-494-502-504 Bro-Sed
*C 214686	Spring Si Trim Assy-Rear Seat Back	481-491-483-493 Sed-Bro
*C 214687	Spring & Trim Assy-Rear Seat Back	481-491-483-493 ClubCpe
C 214688	Spring & Trim Assy-Rear Seat Back-RH	482-484-492-494-502-504 ClubCpe
C 214689	Spring & Trim Assy-Rear Seat Back-LH	482-484-492-494-502-504 ClubCpe
C 214695	Pad-R Seat Back Center Arm Rest	482-484-492-494 CvBro
*HS 214698	Sealzit Glass Sealer-2 oz	All
BO 214699	Spring-Rear Compt Door Handle	482,484,492,494,502,504
M 214702	Windlace-Russet	1948 thru 1950 exc CvBro
M 214703	Windlace-Gray	1948 thru 1950 exc CvBro
M 214704	Seaming Lace-Russet	1948 thru 1950 exc CvBro
M 214705	Seaming Lace-Gray	1948 thru 1950 exc CvBro
M 214706	Seat Leather-Maroon	1948 thru 1950 CvBro
M 214707	Leather-Imitation-Sidewall-Maroon	1948 thru 1950 CvBro
M 214708	Leather-Imitation-Headlining-Maroon	1948 thru 1950 CvBro
M 214709	Windlace-Maroon	1948 thru 1950 CvBro
M 214710	Seaming Lace-Maroon	1948 thru 1950 CvBro
M 214723	Top Material-Black	1948-1949 CvBro
M 214724	Top-Material-Gray	1948 thru 1950 CvBro
M 214726	Bow Drill-Folding Top-Black	1948-1949 CvBro
M 214730	Seat Leather-Dark Red	481-491 CvBro,1950
M 214731	Sidewall Imit Leather-Dark Red	481-491 CvBro,1950
M 214733	Seat Cloth-Brown	1948-1949 CvBro,502-504 ClubCpe
M 214736	Bow Drill-Folding Top-Gray	1948 thru 1950 CvBro
M 214738	Bow Drill-Folding Top-Gray	1948 thru 1950 CvBro
C 214746	Carpet Assy-F Seat Side Panel Extension-RH	1948 Bro
C 214747	Carpet Assy-F Seat Side Panel Extension-LH	1948 Bro
C 214751	Rubber Pad-F Seat Cushion	1948 thru 1950 Sedan
C 214752	Rubber Pad-F Seat Cushion	1948 thru 1950 Bro-Cpes-CvBro
C 214753	Rubber Pad-R Seat Cushion	1948 thru 1950 Bro-Cpes
BO 214766	Visor Assy-Inside-Maroon	1948 thru 1950 CvBro exc 500
BO 214767	Visor Assy-Inside-Dark Red Lea	500 CvBro
HS 214772	Dressing-Convertible Top-Pint	All
*HS 214773	Dressing-Convertible Top-Qt	All
*HS 214774	Dressing-Convertible Top-Gal	All
*HA 214775	Seat Cover Set-Front & Rear-Green Matting	481-483-491-493 Sedan
*RA 214776	Seat Cover Set-Front & Rear-Green Matting	481-483-491-493 Bro
*HA 214781	Seat Cover Set-Fr & Rear-Brown Matting	482-484-492-494 Sedan
*HA 214782	Seat Cover Set-Fr & Rear-Brown Matting	482-484-492-494 ClubCpe
*HA 214785	Seat Cover Set-Fr & Rear-Blue Matting	482-484-492-494 Sed
*HA 214786	Seat Cover Set-Front & Rear-Blue Matting	482-484-492-494 ClubCpe
C 214794	Trimboard-Rear Door Pocket	481-483-491-493 Sedan
C 214796	Trimboard-Door Pocket	481-483-491-493 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 214800	Trimboard-Door Pocket	481-483-491-493 Bro-Cpes
C 214861	Trimboard-Rear Seat Back-Complete	1948 thru 1950 CvBro
C 214862	Liner-Quarter Inner Panel-RH	1948-1949 Sedan
C 214863	Liner-Quarter Inner Panel-LH	1948-1949 Sedan
BO 214868	Frame-Outer-Rear Curtain Window	481-491-1950 CvBro
C 214869	Spring-Rear Seat Back	481-491 CvBro
BO 214899	Support Assy-Rear Compt Floor Panel Extension	1948 thru 1950 CvBro
214904	Liner-F Door Inner Panel-RH (Use 216884)	1948-1949 Sedan
214905	Liner-R Door Inner Panel-LH (Use 216887)	1948-1949 Sedan
214906	Liner-Door Inner Panel (Use 216888)	1948-1949 Bro-Cpes-CvBro
214907	Liner-Qtr Inner Panel (Use 216883)	1948-1949 Bro
214908	Liner-Qtr Inner Panel-RH (Use 216880)	1948-1949 Cpes
214909	Liner-Qtr Inner Panel-LH (Use 216881)	1948-1949 Cpes
*HA 214910	Radio Short Wave Converter Kit	1948 thru 1950
BO 214912	Brkt-Door Tie Rod-Upper-RH	1948-1949 CvBro
BO 214913	Brkt-Door Tie Rod-Upper-LH	1948-1949 CvBro
BO 214914	Brkt-Door Tie Rod-Lower	1948-1949 CvBro
BO 214916	Support-Rear Seat Back-RH	1948-1949 CvBro
BO 214917	Support-REar Seat Back-LH	1948-1949 CvBro
C 214924	Retainer-Body Header Windlace-RH	1948 thru 1950 CvBro
C 214925	Retainer-Body Header Windlace-LH	1948 thru 1950 CvBro
214927	Spring-Rear Seat Cushion (Use 214593)	1948 CvBro
C 214928	Spring-Rear Seat Back	482-484-492-494 CvBro
C 214930	Quarter Window Assy-RH	1948 thru 1950 CvBro
C 214931	Quarter Window Assy-LH	1948 thru 1950 CvBro
C 214932	Frame Assy-Qtr Window-RH	1948 thru 1950 CvBro
C 214933	Frame Assy-Qtr Window-LH	1948 thru 1950 CvBro
BO 214934	Hinge-Quarter Window-RH	1948 thru 1950 CvBro
BO 214935	Hinge-Quarter Window-LH	1948 thru 1950 CvBro
BO 214936	Bracket-Quarter Wdo Hinge	1948 thru 1950 CvBro
BO 214937	Pin-Qtr Wdo Hinge to Window	1948 thru 1950 CvBro
C 214938	Reinforcement-Lower-Top Rear Curtain	1948 thru 1950 CvBro
BO 214943	Hinge As'sy-Rear Seat Back Arm Rest	482-484-492-494-502-504 CvBro
BO 214946	Pivot-Lower-Door Wing-RH	1948 thru 1950 CvBro
BO 214947	Pivot-Lower-Door Wing-LH	1948 thru 1950 CvBro
BO 214950	Frame Assy-Door Wing Glass-RH	1948 thru 1950 CvBro
BO 214951	Frame Assy-Door Wing Glass-LH	1948 thru 1950 CvBro
BO 214952	Glass & Frame Assy-Door Wing-RH	1948 thru 1950 CvBro
BO 214953	Glass & Frame Assy-Door Wing-LH	1948 thru 1950 CvBro
BO 214954	Weatherstrip-Door Wing-RH	1948 thru 1950 CvBro
BO 214955	Weatherstrip-Door Wing-LH	1948 thru 1950 CvBro
BO 214956	Guide-Door Wing Glass Frame	1948 thru 1950 CvBro
C 214962	Center Bar & W/Strip-Door Wdo-RH	1948 thru 1950 CvBro
C 214963	Center Bar & W/Strip-Door Wdo-LH	1948 thru 1950 CvBro
BO 214964	Glass Run-Door Wdo Center Bar•	1948-1949 CvBro
214966	Weatherstrip-Front-Qtr Window (Use 216602-RH, or 216603 LH)	1948 CvBro
BO 214967	Air Stop Block-Windshield Lower Mldg	1948 thru 1950
BO 214970	Cylinder & Yoke Assy-Folding Top	1948 thru 1950 CvBro
BO 214972	Yoke-Top Operating Cylinder	1948 thru 1950 CvBro
BO 214973	Sealing Block-Rear Shelf Panel Extension to Roof Panel	1948-1949 Bro-Sed-ClubCpe,1950 Bro-Sed
C 214974	Mldg-Front Lower-Top Front Header	1948 thru 1950 CvBro
*C 214978	Brace Assy-Rear Pillar to Wheelhouse-RH	1948 thru 1950 CvBro
*C 214979	Brace Assy-Rear Pillar to Wheelhouse-LH	1948 thru 1950 CvBro
BO 214980	Regulator Assy-Door Window-Hydraulic-RH	1948 thru 1950 CvBro
BO 214981	Regulator Assy-Door Window-Hydraulic-LH	1948 thru 1950 CvBro
BO 214982	Frame Assy-Door Wdo Hyd Regulator-RH	1948 thru 1950 CvBro
BO 214983	Frame Assy-Door Wdo Hyd Regulator-LH	1948 thru 1950 CvBro
BO 214984	Spring-Inner-Door Wdo Hyd Regulator	1948 thru 1950 CvBro
BO 214985	Spring-Outer-Door Wdo Hyd Regulator	1948 thru 1950 CvBro
BO 214986	Cylinder Assy-Door Wdo Hyd Regulator	1948 thru 1950 CvBro
M 214989	Top Material-Maroon	1948 thru 1950 CvBro
214990	Weatherstrip-Door Wdo Center Bar (Use 217124)	1948-1949 CvBro
BO 214991	Screw-Qtr Wdo Hinge Pivot	1948 thru 1950 CvBro
BO 214992	Regulator Assy-Door Wing-RH	481-491-500-501 CvBro
BO 214993	Regulator Assy-Door Wing-LH	481-491-500-501 CvBro
C 214998	Glass, Frame & Rest Channel-Door Wdo-RH	1948 thru 1950 CvBro
C 214999	Glass, Frame & Rest Channel-Door Wdo-LH	1948 thru 1950 CvBro
BO 215099	Clip-Dash Trim Panel & Silencer	1949,1950
215118	Pillar Assy-Front-Right-LHD	481-491-500-501 CvBro with Hyd Wdo Reg
215119	Pillar Assy-Front-Left	481-491-501 CvBro with Hyd Wdo Reg
*C 215122	Pillar Assy-Front-Right-LED	482-484-492-494-502-504 CvBro
*C 215123	Pillar Assy-Front-Left	482-484-492-494-502-504 CvBro
BO 215126	Spring-F Scat Track Lock Lever	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
HS 215134	Liquid Glaze Applicator Cloth	All
HS 215136	Liquid Glaze Merchandising Pkg	All
*HS 215137	Liquid Glaze Duo-Kit	All
*HA 215138	Directional Signal Kit	All
*C 215139	Paint Kit-Qts	1949
BO 215150	Ash Receiver-Quarter	1948 thru 1950 CvBro
*HA 215169	Assist Strap Kit-Gray	482-484 Sed-ClubCpe
*HA 215170	Assist Strap Kit-Russet	482-484 Sed-ClubCpe
BO 215172	Channel Assy-Door Wdo Glass Run-RH	1948 thru 1950 CvBro
BO 215173	Channel Assy-Door Wdo Glass Run-LH	1948 thru 1950 CvBro
BO 215174	Cradle-Door Wing-RH	1948 thru 1950 CvBro
BO 215175	Cradle-Door Wing-LH	1948 thru 1950 CvBro
C 215176	Tie Rod-Door	1948-1949 CvBro
BO 215177	Sleeve-Door Tie Rod Adjusting	1948-1949 CvBro
BO 215180	Bracket-Door Wdo Regulator	1948 thru 1950 CvBro with Hyd Wdo Reg
BO 215190	Tapping Plate-Door Window Stop	1948 thru 1950 CvBro
BO 215191	Bumper-Door Window Stop	1948 thru 1950 CvBro
C 215192	Spring-R Seat Back Center Arm Rest	482-484-492-494-502-504 CvBro
C 215196	Mat & Pad Assy-Rear Floor-Gray Green	481-491 CvBro
C 215197	Mat & Pad Assy-Rear Floor-Mottled Taupe	482-484-492-494 CvBro
C 215198	Mat & Pad Assy-Rear Floor-Gray Green	491 CvBro
C 215199	Mat & Pad Assy-Rear Floor-Red Brown	492-494 CvBro
BO 215213	Glass-Speedometer	1948,1949,501 thru 504
BO 215219	Board & Tee Nut Assy-R Seat Back Center Arm Rest	482-484-492-494-502-504 CvBro
C 215220	Molding-Door Belt-RH	1948 thru 1950 CvBro
C 215221	Molding-Door Belt-LH	1948 thru 1950 CvBro
C 215224	Channel Assy-Qtr Wdo Glass Run-RH	1948 thru 1950 CvBro
C 215225	Channel Assy-Qtr Wdo Glass Run-LB	1948 thru 1950 CvBro
BO 215229	Lock-Qtr Wdo Hinge Pivot Screw	1948 thru 1950 CvBro
BO 215240	Regulator Assy-Quarter Wdo-Hydraulic-RH	1948 thru 1950 CvBro
BO 215241	Regulator Assy-Quarter Wdo-Hydraulic-LH	1948 thru 1950 CvBro
BO 215242	Frame Assy-Quarter Wdo Hyd Regulator-RH	1948 thru 1950 CvBro
BO 215243	Frame Assy-Quarter Wdo Hyd Regulator-LH	1948 thru 1950 CvBro
BO 215244	Cylinder Assy-Quarter Wdo Hyd Regulator	1948 thru 1950 CvBro
BO 215245	Spring-Quarter Wdo Hyd Regulator	1948 thru 1950 CvBro
BO 215246	Clip-Hyd Wdo Regulator Arm	1948 thru 1950 CvBro
BO 215247	Gasket-Speedometer Glass	1948,1949,1950
BO 215248	Bezel-Speedometer	1948,1949
BO 215249	Clip-Inside Visor Binding	1948 thru 1950 CvBro
BO 215250	Retainer-Quarter Ash Receiver	1948 thru 1950 CvBro
BO 215252	Retainer-Top Belt Flap-RH	1948 thru 1950 CvBro
BO 215253	Retainer-Top Belt Flap-LH	1948 thru 1950 CvBro
BO 215254	Retainer-Top Quarter Flap-RH	1948-1949 CvBro
BO 215255	Retainer-Top Quarter Flap-LH	1948-1949 CvBro
BO 215260	Handle-Door Wing Regulator	481-491 CvBro
BO 215261	Weatherstrip-Door Wdo Belt-Inner	1948 thru 1950 CvBro
BO 215262	Brkt-Folding Top Pivot-RH	1948 thru 1950 CvBro
BO 215263	Brkt-Folding Top Pivot-LH	1948 thru 1950 CvBro
BO 215264	Support-Folding Top Pivot Brkt-RH	1948 thru 1950 CvBro
BO 215265	Support-Folding Top Pivot Brkt-LH	1948 thru 1950 CvBro
C 215266	Panel Assy-Quarter Trim Support-Front-RH	1948 thru 1950 CvBro
C 215267	Panel Assy-Quarter Trim Support-Front-LH	1948 thru 1950 CvBro
*C 215268	Panel Assy-Quarter Trim Support-Rear-RH	1948-1949 CvBro
*C 215269	Panel Assy-Quarter Trim Support-Rear-LH	1948-1949 CvBro
215270	Weatherstrip-Door-Rear-RH (Use 217120)	1948-1949 CvBro
215271	Weatherstrip-Door-Rear-LH (Use 217121)	1948-1949 CvBro
C 215272	Molding-Rear Belt-RH	1948 thru 1950 CvBro
C 215273	Molding-Rear Belt-LH	1948 thru 1950 CvBro
215274	Regulator Assy-Qtr Wdo-RH (Use 217058)	481-491 CvBro
215275	Regulator Assy-Qtr Wdo-LH (Use 217059)	481-491 CvBro
215276	Weatherstrip-Door Wing Cradle to Belt Mldg-RH (Use 216998)	1948-1949 CvBro
215277	Weatherstrip-Door Wing Cradle to Belt Mldg-LH (Use 216999)	1948-1949 CvBro
BO 215304	Dial-Speedometer-Miles	481,483,491,493
BO 215305	Dial-Speedometer-Kilometers	481,483,491,493
BO 215307	Weatherstrip-Quarter Wdo Belt-Inner	1948 thru 1950 CvBro
C 215308	Mldg-Top Rear Bow	1948 thru 1950 CvBro
C 215309	Retainer-Top Rear Bow Mldg	1948 thru 1950 CvBro
BO 215314	Pad-Rear Pillar Qtr Wdo Hinge Brkt	1948 thru 1950 CvBro
C 215316	Molding-Door Pocket-RH	482-484-492-494-501-502-504 CvBro
C 215317	Molding-Door Pocket-LH	482-484-492-494-501-502-504 CvBro
BO 215318	Molding-Qtr Belt-RH	1948 thru 1950 CvBro
BO 215319	Molding-Qtr Belt-LH	1948 thru 1950 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	215321 Headlining Assy	1948-1949 BsCpe
BO	215324 Dial-Speedometer-Miles	482,484,492,494
BO	215325 Dial-Speedometer-Kilometers	482,484,492,494
*C	215326 Frame & Back Complete-F Seat Cushion-LHD- Cloth Trim-Less Rubber Pads	482-484-492-494 ClubCpe
C	215327 Frame & Back Complete-F Seat Cushion-RHD- Cloth Trim-Less Rubber Pads	482-484-492-494 ClubCpe
*C	215328 Frame & Back Complete-F Seat Cushion-LHD- Cloth Trim-Less Rubber Pads	481-483-491-493 ClubCpe
C	215329 Frame & Back Complete-F Seat Cushion-RHD- Cloth Trim-Less Rubber Pads	481-483-491-493 ClubCpe
BO	215333 Cover-Rear Belt Mldg Joint	1948 thru 1950 CvBro
BO	215346 Remote Control Assy-Door Lock-RH	1948 thru 1950 CvBro
BO	215347 Remote Control Assy-Door Lock-LB	1948 thru 1950 CvBro
BO	215348 Tie Bar Assy-Door Wdo Regulator Roller Guide-RH	1948 thru 1950 CvBro with Hyd Wdo Reg
BO	215349 Tie Bar Assy-Door Wdo Regulator Roller Guide-LH	1948 thru 1950 CvBro with Hyd Wdo Reg
BO	215350 Tie Bar Assy-Door Wdo Regulator Roller Guide	481-491-500-501 CvBro with Manual Wdo Reg
BO	215358 Dial-Clock	481,483,491,493
BO	215359 Dial-Clock	482,484,492,494
BO	215364 Weatherstrip-Inner-Door Window Belt-RH	1948 thru 1950 CvBro
BO	215366 Seal-Top Operating Cylinder Rod-Rubber	1948 thru 1950 CvBro
BO	215367 Seal-Top Operating Cylinder Rod-Felt	1948 thru 1950 CvBro
BO	215368 Washer-Top Operating Cylinder Rod Seal	1948 thru 1950 CvBro
BO	215369 Ring-Top Operating Cylinder Rod Seal	1948 thru 1950 CvBro
C	215375 Seat Cloth-Tan	492-494 exc CvBro
BO	215386 Weatherstrip-Door-Rear-RH	1949 CvBro
BO	215387 Weatherstrip-Door-Rear-LH	1949 CvBro
BO	215388 Brace-Rear Compt Opening Panel-Side-to Wheelhouse-RH	1948 thru 1950 Cpes-CvBro
BO	215389 Brace-Rear Compt Opening Panel-Side-to Wheelhouse-LH	1948 thru 1950 Cpes-CvBro
	215390 Brace-Rear Compt Opening Panel-Side-to Wheelhouse-RH (Use 215388)	1948 Cpes-CvBro
	215391 Brace-Rear Compt Opening Panel-Side-to Wheelhouse-LH (Use 215389)	1948 Cpes-CvBro
BO	215392 Finish Mldg & AV/Strip Assy-Qtr Wdo-RH	1948 thru 1950 CvBro
BO	215393 Finish Mldg & W/Strip Assy-Qtr Wdo-LH	1948 thru 1950 CvBro
BO	215396 Glove Box Assy-Drivers Side-LHD	482,484,492,494
BO	215397 Glove Box Assy-Drivers Side-RHD	482,484,492,494
C	215398 Trimboard & Trim Assy-Rear Shelf-Cloth Trim	481-491 BsCpe
C	215399 Trimboard & Trim Assy-Rear Shelf-Lea Trim	481-491 BsCpe
BO	215434 Push Button Assy-Radio	1948 thru 1950
BO	215435 Antenna & RF Coil Iron Coil & Screw-Radio	1948,1949
BO	215436 Oscillator Shunt Coil Iron Core & Screw-Radio	1948,1949
BO	215437 Washer-Radio	1948,1949
BO	215439 Mounting Stud & Spring Assy-Radio Case Cover Set	1948,1949
BO	215440 Scale-Radio Dial	1948,1949
BO	215441 Knob-Automatic Tuning-Radio	1948,1949
BO	215442 Cross Arm Guide Rod-Radio	1948,1949
BO	215443 Escutcheon-Radio	1948,1949
BO	215444 Escutcheon Window-Radio	1948 thru 1950
BO	215445 Retaining Plate-Escutcheon Window-Radio	1948 thru 1950
BO	215446 Dial Pointer-Radio	1948,1949
BO	215447 Retaining Spring-Radio Pointer	1948,1949
BO	215448 Tension Spring-Radio Pointer	1948,1949
BO	215449 Tuner Assy-Radio	1948,1949
BO	215451 Bracket & Stud Assy-Radio Pointer	1948,1949
BO	215452 Drive Link & Stud Assy-Radio Pointer	1948,1949
BO	215453 Socket & Wire Assy-Radio Dial Light	1948,1949
BO	215454 Cross Arm & Bushing Assy-Radio	1948,1949
BO	215455 Tension Spring-Cross Arm-Radio	1948,1949
BO	215456 Transformer-1st inter-Radio	1948,1949
BO	215457 Transformer-2nd inter-Radio	1948,1949
BO	215458 Tuner Coil Unit Assy-Radio	1948,1949
BO	215459 Oscillator Shunt Coil Assy-Radio	1948,1949
BO	215460 Oscillator Series Coil Assy-Radio	1948,1949
BO	215461 Oscillator Coil Assy-Radio	1948 thru 1950
BO	215462 Coil Assy-Radio Antenna & Frequency	1948 thru 1950
BO	215463 Condenser-500V-100 Mmfd-Radio	1948 thru 1950
BO	215464 Condenser-120V-5 Mfd-Radio	1948,1949
BO	215465 Condenser-200V-02 Mfd-Radio	1948 thru 1950
BO	215466 Condenser-20 Mfd-Radio	1948 thru 1950
BO	215467 Condenser-260 Mmfd-Radio	1948,1949
BO	215468 Condenser-50 Mmfd-Antenna-Radio	1948,1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 215469	Condenser-50 Mmfd-Converter-Radio	1948,1949
BO 215470	Condenser-50 Mmfd-Oscillator-Radio	1948,1949
BO 215471	Condenser-100V-5 Mfd-Radio	1948 thru 1950
BO 215472	Condenser-500V-100 Mmfd-Radio	1948,1949
BO 215473	Resistor-Volume Tone Control & Switch-Radio	1948 thru 1950
BO 215474	Resistor-2 Watt-1800 Ohm-Radio	1948 thru 1950
BO 215475	Resistor-1 Watt-270 Ohm-Radio	1948 thru 1950
BO 215476	Resistor-1/2 Watt-82 Ohm-Radio	1948 thru 1950
BO 215477	Resistor-1/2 Watt-150 Ohm-Radio	1948,1949
BO 215478	Resistor-1/2 Watt-15 M Ohm-Radio	1948,1949
BO 215479	Resistor-1/2 Watt-18 M Ohm-Radio	1948,1949
BO 215480	Resistor-1/2 Watt-22 M Ohm-Radio	1948 thru 1950
BO 215481	Resistor-1/2 Watt-33 M Ohm-Radio	1948,1949
BO 215482	Resistor-1/2 Watt-68 M Ohm-Radio	1948,1949
BO 215483	Resistor-1/2 Watt-330 M Ohm-Radio	1948 thru 1950
BO 215484	Resistor-1/2 Watt-1 Megohm-Radio	1948 thru 1950
BO 215485	Resistor-1/2 Watt-10 Megohm-Radio	1948,1949
BO 215486	Resistor-1/2 Watt-15 Megohm-Radio	1948 thru 1950
BO 215487	Battery Cable-Fuse to Radio Set	1948
BO 215488	Cable & Plug-Radio Speaker	1948,1949
BO 215489	Cable-Volume Control-Radio	1948,1949
BO 215490	Socket-Loktal Tube-Radio	1948,1949
BO 215491	Socket-Octal Tube-Radio	1948 thru 1950
BO 215492	Socket-Minature Tube-Radio	1948,1949
BO 215493	Socket-Antenna Connector-Radio	1948 thru 1950
BO 215494	Socket-Vibrator-Radio	1948 thru 1950
BO 215495	Vibrator-Radio	1948,1949
BO 215496	Cushion Washer-Radio Vibrator	1948,1949
BO 215497	Transformer-Output-Radio	1948,1949
BO 215498	Transformer-Power-Radio	1948,1949
BO 215499	Shield-Minature Tube-Radio	1948,1949
C 215518	Mldg-Lower-Top Rear Curtain	1948 thru 1950 CvBro
C 215531	Slot-H1-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215532	Slot-#2-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215533	Slot-#3-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215534	Slot-#4-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215535	Slot-#5-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215536	Slot-H0-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215537	Slot-#7-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215538	Slot-#8-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215539	Slot-#9-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
C 215540	Slot-010-Rear Wdo Venetian Sun Shade	1948-1949-500 Bro-Sed
BO 215542	Bolt-Rear Belt Molding Retainer	1948 thru 1950 CvBro
215544	W/Strip-Front-Top Side Rail-RH (Use 216714)	1948 CvBro
215545	W/Strip-Front-Top Side Rail-LH (Use 216715)	1948 CvBro
215546	W/Strip-Intermediate-Top Side Rail-RH (Use 216716 & 216718)	1948 CvBro
215547	W/Strip-Intermediate-Top Side Rail-LH (Use 216717 & 216719)	1948 CvBro
BO 215548	W/Strip-Rear-Top Side Rail-RH	1948 thru 1950 CvBro
BO 215549	W/Strip-Rear-Top Side Rail-LH	1948 thru 1950 CvBro
EZ 215555	Washer-Front Bumper Impact Bar Bolt	481,483,491,493,500,501
BO 215556	Glass-Fuel & Temperature Gauge	1948,1949
BO 215557	Gasket-Fuel & Temperature Gauge	1948,1949
BO 215558	Bezel-Fuel & Temperature Gauge Glass	1948,1949
BO 215560	Jewelled Lens-Oil & Ampere Indicator	1948,1949
BO 215561	Gasket-Oil & Ampere Indicator Jewelled Lens	1948,1949
BO 215562	Bezel-Oil & Ampere Indicator Jewelled Lens	1948,1949
BO 215564	Retainer-Front-Top Side Rail W/Strip-RH	1948 thru 1950 CvBro
BO 215565	Retainer-Front-Top Side Rail W/Strip-LH	1948 thru 1950 CvBro
BO 215566	Retainer-Intermediate-Top Side Rail W/ Strip-RH	1948 thru 1950 CvBro
BO 215567	Retainer-Intermediate-Top Side Rail W/ Strip-LH	1948 thru 1950 CvBro
BO 215568	Retainer-Rear-Top Side Rail W/Strip-RH	1948 thru 1950 CvBro
BO 215569	Retainer-Rear-Top Side Rail W/Strip-LH	1948 thru 1950 CvBro
BO 215577	Housing-Hydraulic Power Unit	1948 thru 1950 CvBro
BO 215578	Housing-Bottom-Hydraulic Power Unit	1948 thru 1950 CvBro
BO 215579	Cover-Hydraulic Power Unit Housing	1948 thru 1950 CvBro
*HA 215580	Wind & Rain Deflector Kit	
BO 215581	Shim-Dash to Frame Brace	1948,1949,501 thru 504
BO 215584	Brace Assy-Dash to Frame-RH	1948,1949,501 thru 504
BO 215585	Brace Assy-Dash to Frame-LH	1948,1949,501 thru 504
BO 215586	Dampner Pad-Dash to Frame Brace	1948,1949,501 thru 504
BO 215588	Plate-Dampner to Frame & Brace	1948,1949,501 thru 504
BO 215597	Bracket Assy-Hydraulic Power Unit Support	1948 thru 1950 CvBro

Part No.	Name	Models
C 215600	Trim & Windlace-Center Pillar-RH-Cloth Trim	491-493 Sedan
C 215601	Trim & Windlace-Center Pillar-LH-Cloth Trim	491-493 Sedan
C 215602	Trim & Windlace-Center Pillar-RH-Lea Trim	491-493 Sedan
C 215603	Trim & Windlace-Center Pillar-LH-Lea Trim	491-493 Sedan
C 215604	Trim & Windlace-Center Pillar-RH-Cloth Trim	492-494 Sedan
C 215605	Trim & Windlace-Center Pillar-LH-Cloth Trim	492-494 Sedan
C 215606	Trim & Windlace-Center Pillar-RH-Lea Trim	492-494 Sedan
C 215607	Trim & Windlace-Center Pillar-LH-Lea Trim	492-494 Sedan
BO 215624	Spacer-Top Hold-Down Clamp	1948 thru 1950 CvBro
BO 215689	Battery Cable Assy-Radio-Fuse to Circuit Breaker	1948 LHD
BO 215690	Battery Cable Assy-Radio-Fuse to Circuit Breaker	1948 RHD
BO 215693	Battery Cable Assy-Radio-Fuse to Circuit Breaker	1948-1949 LHD
BO 215694	Battery Cable Assy-Radio-Fuse to Circuit Breaker	1948-1949 LHD
BO 215695	Battery Cable Assy-Radio-Set to Fuse	1948,1949
C 215766	Trimboard Complete-Rear Pillar-RH-Lea Trim	481-483-491-493 Sedan
C 215767	Trimboard Complete-Rear Pillar-LH-Lea Trim	481-483-491-493 Sedan
C 215768	Trimboard Complete-Rear Pillar-RH-Cloth Trim	482-484-492-494 Sedan
C 215769	Trimboard Complete-Rear Pillar-LH-Cloth Trim	482-484-492-494 Sedan
*HS 215784	"Lock Ease"-Graphited Lock Fluid-4 oz	All
BZ 215785	Filler-Frame Front Sidemember	1949-1950 CvBro
BZ 215786	Filler-Frame Front Sidemember	1949-1950 exc CvBro
BZ 215787	Filler-Frame Rear Sidemember	1949,1950
BO 215790	Retainer-Top Side Rail Fastener Button	1948 thru 1950 CvBro
BO 215791	Battery Cable Replacement Pkg-Radio-LHD	1948,1949
BO 215792	Battery Cable Replacement Pkg-Radio-RHD	1948,1949
BO 215806	Brkt-Top Front Header to Side Rail-RH	1948 thru 1950 CvBro
BO 215807	Brkt-Top Front Header to Side Rail-LH	1948 thru 1950 CvBro
BO 215808	Spacer-Top Side Rail Weatherstrip Screw	1949-1950 CvBro
*C 215810	Header Assy-Front Top	1948 thru 1950 CvBro
C 215820	Bow Assy-Rear-Top	481-491-500-501 CvBro
C 215821	Bow Assy-Rear-Top	482-484-492-494-502-504 CvBro
BO 215822	Slat-Top Rear Bow-RH	481-491-500-501 CvBro
BO 215823	Slat-Top Rear Bow-LH	481-491-500-501 CvBro
BO 215824	Slat-Top Rear Bow-RH	482-484-492-494-502-504 CvBro
BO 215825	Slat-Top Rear Bow-LH	482-484-492-494-502-504 CvBro
BO 215826	Bolt-Top Rear Bow to Pivot Brkt	1948 thru 1950 CvBro
BO 215827	Pivot Bolt-Hinge to Bracket-Top	1948 thru 1950 CvBro
BO 215828	Bolt-Top Balance Link to Pivot Brkt	1948 thru 1950 CvBro
BO 215829	Nut-Top Balance Link to Pivot Brkt Bolt	1948 thru 1950 CvBro
C 215835	Side Rail Assy-Folding Top-Front-LH	481-491-500-501 CvBro
C 215836	Side Rail Assy-Folding Top-Front-RH	482-484-492-494-502-504 CvBro
C 215837	Side Rail Assy-Folding Top-Front-LH	482-484-492-494-502-504 CvBro
BO 215848	Hinge & Link Assy-Folding Top Front Side Rail-RH	481-491-500-501 CvBro
BO 215849	Hinge & Link Assy-Folding Top Front Side Rail-LH	481-491-500-501 CvBro
BO 215850	Hinge & Link Assy-Folding Top Front Side Rail-RH	482-484-492-494-502-504 CvBro
BO 215851	Hinge & Link Assy-Folding Top Front Side Rail-LH	482-484-492-494-502-504 CvBro
BO 215858	Stud-Top Side Rail Hinge Link	1948 thru 1950 CvBro
BO 215859	Washer-Top #2 Bow Link to Side Rail Bolt	1948 thru 1950 CvBro
BO 215860	Brkt-Top Side Rail #2 Bow Link-RH	1948 thru 1950 CvBro
BO 215861	Brkt-Top Side Rail #2 Bow Link-LH	1948 thru 1950 CvBro
BO 215862	Link-Folding Top Side Rail Hinge-Rear-RH	481-491-500-501 CvBro
BO 215863	Link-Folding Top Side Rail Hinge-Rear-LH	481-491-500-501 CvBro
BO 215864	Link-Folding Top Side Rail Hinge-Rear-RH	482-484-492-494-502-504 CvBro
BO 215865	Link-Folding Top Side Rail Hinge-Rear-LH	482-484-492-494-502-504 CvBro
215866	Link-Front-Top #2 Bow-RH (Use 216240)	481-491 CvBro
215867	Link-Front-Top #2 Bow-LH (Use 216241)	481-491 CvBro
215868	Link-Front-Top #2 Bow-RH (Use 216242)	482-484-492-494 CvBro
215869	Link-Front-Top #2 Bow-LH (Use 216243)	482-484-492-494 CvBro
215874	Link Assy-Rear-Top #2 Bow-RH (Use 216240)	481-491 CvBro
215875	Link Assy-Rear-Top #2-Bow-LH (Use 216241)	481-491 CvBro
215876	Link Assy-Rear-Top #2-Bow-RH (Use 216242)	482-484-492-494 CvBro
215877	Link Assy-Rear-Top #2-Bow-LH (Use 216243)	482-484-492-494 CvBro
C 215878	Balance Link-Folding Top-RH	481-491-500-501 CvBro
C 215879	Balance Link-Folding Top-LH	481-491-500-501 CvBro
C 215880	Balance Link-Folding Top-RH	482-484-492-494-502-504 CvBro
C 215881	Balance Link-Folding Top-LH	482-484-492-494-502-504 CvBro
BO 215882	Slat-Top #3 Bow to Upper Pillar Brkt	481-491-500-501 CvBro
BO 215883	Slat-Top #3 Bow to Upper Pillar Brkt	482-484-492-494-502-504 CvBro
C 215884	Bow #2 and Linkage Assy-Top	481-491 CvBro
C 215885	Bow #2 and Linkage Assy-Top	482-484-492-494 CvBro
C 215886	Bow #2 Top	1948-1949 CvBro
C 215892	Bow #3-Top	1948 thru 1950 CvBro
BO 215895	Nut-Top #3 Bow Pivot Bolt Sleeve	1948 thru 1950 CvBro
BO 215896	Control Spring-Top #3 Bow-RH	1948 thru 1950 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 215897	Control Spring-Top #3 Bow-LH	1948 thru 1950 CvBro
BO 215898	Bolt-Top #2 Bow Link to Side Rail	1948 thru 1950 CvBro
BO 215899	Pivot Bolt-Top #3 Bow	1948 thru 1950 CvBro
BO 215900	Actuating Link-Top Front Side Rail-RH	481-491-500-501 CvBro
BO 215901	Actuating Link-Top Front Side Rail-LH	481-491-500-501 CvBro
BO 215902	Actuating Link-Top Front Side Rail-RH	482-484-492-494-502-504 CvBro
BO 215903	Actuating Link-Top Front Side Rail-LH	482-484-492-494-502-504 CvBro
A 215908	Instrument Switch-Mounting Panel Assy-RH	1948-1949 LHD
A 215909	Instrument Switch-Mounting Panel Assy-LH	1948-1949 LHD
A 215910	Instrument Switch-Mounting Panel Assy-RH	1948-1949 RHD
A 215911	Instrument Switch-Mounting Panel Assy-LH	1948-1949 RHD
BO 215926	Screen-Rear Seat Radio Speaker	1948-1949
BO 215927	Switch-Rear Seat Radio Speaker	1948-1949 Sed-Bro-ClubCpe
BO 215928	Wire Assy-Switch to Rear Seat Radio Speaker	1948-1949
BO 215929	Wire Assy-Rear Seat Radio Speaker to Rear Junction Mtg Screw	1948-1949
BO 215930	Wire Assy-Switch to Front Radio Speaker	1948,1949
BO 215936	Arm Rest Assy-Gray Cloth Trim	1948-1949 exc CvBro
BO 215937	Arm Rest Assy-Tan Cloth Trim	482-484-492-494 exc CvBro
BO 215938	Arm Rest Assy-Cloth Trim	481,483,491,493
BO 215940	Weatherstrip-Door Opening Belt-RH	1948 CvBro
BO 215941	Weatherstrip-Door Opening Belt-LH	1948 CvBro
BO 215942	Weatherstrip-Front-Door Opening-RH	1948 CvBro
BO 215943	Weatherstrip-Front-Door Opening-LH	1948 CvBro
C 215944	Mldg-Front Upper-Top Front Header-RH	1948 thru 1950 CvBro
C 215945	Mldg-Front Upper-Top Front Header-LH	1948 thru 1950 CvBro
C 215946	Retainer-Top Front Header Front Upper-Mldg	1948 thru 1950 CvBro
BO 215948	Cover-Top Front Header Mldg Joint	1948 thru 1950 CvBro
A 215949	Instrument Finish Panel Assy	481,483
BO 215950	Door Assy-Glove Box-RH	481-483 LHD
BO 215951	Door Assy-Glove Box-LH	481-483 LHD
BO 215952	Door Assy-Glove Box-RH	481-483 RHD
BO 215953	Door Assy-Glove Box-LH	481-483 RHD
BO 215954	Door Complete-Glove Box-RH	481-483 LHD
BO 215955	Door Complete-Glove Box-LH	481-483 LHD
BO 215956	Door Complete-Glove Box-RH	481-483 RHD
BO 215957	Door Complete-Glove Box-LH	481-483 RHD
C 215970	Trim & Windlace Complete-Center Pillar-RH-Cloth Trim	481-483 Sedan
C 215971	Trim & Windlace Complete-Center Pillar-LH-Cloth Trim	481-483 Sedan
C 215972	Trim & Windlace Complete-Center Pillar-RH-Lea Trim	481-483 Sedan
C 215973	Trim & Windlace Complete-Center Pillar-LH-Lea Trim	481-483 Sedan
C 215974	Trim & Windlace Complete-Center Pillar-RH-Cloth Trim	482-484 Sedan
C 215975	Trim & Windlace Complete-Center Pillar-LH-Cloth Trim	482-484 Sedan
C 215976	Trim & Windlace Complete-Center Pillar-RH-Lea Trim	482-484 Sedan
C 215977	Trim & Windlace Complete-Center Pillar-LH-Lea Trim	482-484 Sedan
BO 215978	Control Assy-Windshield Wiper	1948,1949
BO 215979	Sleeve-Windshield Wiper Operating Control Wire	1948 thru 1950
BO 215982	Cover Assy-Radio Rear Seat Speaker	1948,1949
C 215984	Silencer-Trans Opening Floor Cover-Right	1948-1949 LHD
C 215985	Silencer-Trans Opening Floor Cover-Left	1948-1949 LHD
C 215986	Silencer-Toeboard Riser	1948,1949
C 215988	Silencer-Underbody Center Panel-RH	1948 thru 1950
C 215989	Silencer-Underbody Center Panel-LH	1948 thru 1950
C 215992	Seal-Rear Shelf to Roof Panel	1948-1949 Bro-Sed
BO 215993	Seal-Rear Shelf to Roof Panel	1948 thru 1950 ClubCpe,1950 BsCpe
C 215994	Silencer-Toeboard Riser-Right-RHD	1948,1949
BO 216016	Spacer-Rear Seat Cushion Support	1948 ClubCpe-CvBro
BO 216017	Sealing Block-Qtr Wdo Opening Reinf to Qtr Panel	1948 thru 1950 ClubCpe
C 216018	Trim Assy-F Seat Side Panel Extension-RH-Cloth Trim	1948 Bro-Cpes
C 216019	Trim Assy-F Seat Side Panel Extension-LH-Cloth Trim	1948 Bro-Cpes
C 216020	Trimboard Assy-Front Door-RH	481-483-491-493 Sedan
C 216021	Trimboard Assy-Front Door-LH	481-483-491-493 Sedan
C 216022	Trimboard Assy-Rear Door-RH	481-483-491-493 Sedan
C 216023	Trimboard Assy-Rear Door-LH	481-483-491-493 Sedan
C 216024	Trimboard-Door-RH-Leather	481-491 CvBro
C 216025	Trimboard-Door-LH-Leather	481-491 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 216037	Sealing Strip-Rocker Panel Extension	1948,1949
BO 216038	Putty-1 qt container	All
BO 216039	Sealer-Black Dolphinite-1 qt Container	All
C 216043	Silencer-Rear Shelf Panel	1948-1949 Bro-Sed
C 216044	Silencer-Rear Shelf Panel	1948 thru 1950 ClubCpe
C 216048	Stringer & Underbody Stiffener-#4 to #6 Crossmember	1948 thru 1950 All
C 216049	Stringer & Underbody Stiffener-#4 to #6 Crossmember	1948 thru 1950 All
C 216078	Trimboard Complete-F Door-RH-Cloth Trim	482-484-492-494
C 216079	Trimboard Complete-F Door-LH-Cloth Trim	482-484-492-494
C 216080	Trimboard Complete-R Door-RH-Cloth Trim	482-484-492-494
C 216081	Trimboard Complete-R Door-LH-Cloth Trim	482-484-492-494
C 216082	Trimboard Complete-Door-RH-Cloth Trim	482-484-492-494 Bro-Cpes
C 216083	Trimboard Complete-Door-LH-Cloth Trim	462-484-492-494 Bro-Cpes
BO 216090	Arm Rest Assy-Door-Russet Lea	1949 Sed-Bro-Cpes
BO 216091	Arm Rest Assy-Door-Dark Red Lea	1948-1949 exc CvBro
BO 216092	Arm Rest Assy-Door-Maroon Lea	484-494 CvBro
BO 216111	Welt-Roof Front Finish Panel	1948 thru 1950 CvBro
*HA 216130	Door & Qtr Wdo Ventshade Kit	1948 thru 1950 Bro
*HA 216131	Door & Qtr Wdo Ventshade Kit	1948 thru 1950 BsCpe-ClubCpe
BO 216140	Clamp Assy-Top Hold Down	1948 thru 1950 CvBro
BO 216145	Brkt-Top Hold Down Clamp	1948-1949 CvBro
*HA 216160	Curb Signal Kit	All
C 216166	Weatherstrip-Bottom-Door Panel-RH	1948-1949 Bro-Cpes-CvBro
C 216167	Weatherstrip-Bottom-Door Panel-LH	1948-1949 Bro-Cpes-CvBro
C 216168	Weatherstrip-Bottom-Front Door Panel-RH	1948-1949 Sed
C 216169	Weatherstrip-Bottom-Front Door Panel-LH	1948-1949 Sed
C 216170	Weatherstrip-Bottom-Rear Door Panel-RH	1948-1949 Sed
C 216171	Weatherstrip-Bottom-Rear Door Panel-LH	1948-1949 Sed
BO 216174	Brkt-Upper-Top Quarter Pillar-RH	1948 thru 1950 CvBro
BO 216175	Brkt-Upper-Top Quarter Pillar-LH	1948 thru 1950 CvBro
BO 216176	Hinge-Top Quarter Pillar-RH	1948 thru 1950 CvBro
BO 216177	Hinge-Top Quarter Pillar-LH	1948 thru 1950 CvBro
*C 216180	Pillar Assy-Quarter-Folding Top-RH	1948 thru 1950 CvBro
*C 216181	Pillar Assy-Quarter-Folding Top-LH	1948 thru 1950 CvBro
BO 216182	Rail & Reinf-Top Quarter Pillar-RH	1948-1949 CvBro
BO 216183	Rail & Reinf-Top Quarter Pillar-LH	1948-1949 CvBro
BO 216198	Bolt-Top Quarter Pillar Rail	1948 thru 1950 CvBro
BO 216199	Bolt-Top Side Rail Hinge	1948 thru 1950 CvBro
C 216200	Top Assy-Less Deck & Rear Curtain	481-491-500-501 CvBro
C 216201	Top Assy-Less Deck & Rear Curtain	482-484-492-494-502-504 CvBro
BO 216206	Bolt-Top Front Side Rail Link	1948 thru 1950 CvBro
BO 216207	Bolt-Top Front Side Rail Link	1948 thru 1950 CvBro
216208	Bolt-Top Balance Link to Side Rail (Use 217338)	1948-1949 CvBro
C 216210	Tacking Strip-Top Front Header-RH	1948 thru 1950 CvBro
C 216211	Tacking Strip-Top Front Header-LH	1948 thru 1950 CvBro
BO 216212	Tacking Strip-Top Front Header-End	1948 thru 1950 CvBro
BO 216213	Rivet-Top #2 Bow Control Link	1948 thru 1950 CvBro
C 216214	Side Rail Assy-Folding Top-Rear-RH	481-491-500-501 CvBro
C 216215	Side Rail Assy-Folding Top-Rear-LH	481-491-500-501 CvBro
C 216216	Side Rail Assy-Folding Top-Rear-RH	482-484-492-494-502-504 CvBro
C 216217	Side Rail Assy-Folding Top-Rear-LH	482-484-492-494-502-504 CvBro
BO 216218	Rivet-Top #2 Bow Control Link	1948 thru 1950 CvBro
C 216220	Roof Bow #1	1948 Sedan,1949-1950 Sed-Bro-Cpes
C 216221	Roof Bow #2	1948 thru 1950 Sedan
C 216222	Roof Bow #3	1948 thru 1950 Sedan
C 216223	Roof Bow #4	1948 thru 1950 Sedan
C 216224	Roof Bow #5	1948 thru 1950 Sedan
C 216225	Roof Bow #6	1948 thru 1950 Sedan
C 216226	Roof Bow #2	1949-1950 Bro-BsCpe-ClubCpe
C 216277	Roof Bow #3	1949-1950 Bro
C 216228	Roof Bow #4	1949-1950 Bra
C 216229	Roof Bow #5	1949-1950 Bro
C 216230	Roof Bow #6	1949-1950 Bro
C 216231	Roof Bow #4	1949-1950 BsCpe-ClubCpe
C 216232	Roof Bow #5	1949-1950 BsCpe-ClubCpe
C 216236	Liner Assy-Quarter Panel-RH	1948 thru 19.50 CvBro with Hyd Wdo Reg
C 216237	Liner Assy-Quarter Panel-LH	1948 thru 1950 CvBro with Hyd Wdo Reg
BO 216239	Baffle-Wheelhouse Outer Panel	1949-1950 Bro
BO 216240	Control Link Assy-Folding Top #2 Bow-RH	491-500-501 CvBro
BO 216241	Control Link Assy-Folding Top #2 Bow-LH	491-500-501 CvBro
BO 216242	Control Link Assy-Folding Top #2 Bow-RH	492-494-502-504 CvBro
BO 216243	Control Link Assy-Folding Top #2 Bow-LH	492-494-502-504 CvBro
BO 216246	Filler-Front-Door Wdo Finish Mldg	1948 thru 1950 CvBro
*HA 216257	Ash Receiver Kit-Instrument Panel	1948,1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 216270	Extension-Frt Fender Side Dust Shield-RH	1949-501 thru 504 LHD
A 216271	Extension-Frt Fender Side Dust Shield-LH	1949-501 thru 504 LHD
A 216272	Extension-Frt Fender Side Dust Shield-RH	1949-501 thru 504 RHD
A 216273	Extension-Frt Fender Side Dust Shield-LH	1949-501 thru 504 RHD
BO 216283	Water Baffle-Frame Sidemember	1948 thru 1950 CvBro
BO 216296	Dust Shield-Windshield Wiper Cable	1948 thru 1950
*HA 216297	Front Door Wing Rain Shield Kit	1948 thru 1950
BO 216298	Attaching Strip-Quarter Inner Panel Liner	1948-1949 Sedan
BO 216300	Seal-Rear Shelf to Roof & Quarter Panel	1948-1949 Sed-Bro-ClubCpe
BO 216302	Body Sealing Supplementary Kit	1948-1949 Sed-Bro-ClubCpes
C 216303	Seal Kit-Rear Seat Back Trim Panel	1948-1949 ClubCpes
C 216304	Seal-Rear Seat Back Trim Panel-Side	1948-1949 ClubCpes
C 216305	Seal-Rear Seat Back Trim Panel-Bottom	1948-1949 ClubCpes
BZ 216322	Seal-Front-Rocker Panel Extension	1948,1949
BZ 216323	Seal-Rear-Rocker Panel Front Extension	1948-1949 Sed
216324	Seal-Rear-Rocker Panel Extension (Use 217340)	1948-1949 Bro-Cpes-CvBro
BZ 216325	Seal-Rear-Rocker Panel Rear Extension	1948-1949 Sedan
BO 216326	Gasket-Tail Lamp Lens	482,484,492,494,502,504
BO 216327	Gasket-Tail Lamp Lens	481,483,491,493,500,501,503
BO 216329	Stud-Tail Lamp	1948 thru 1950
C 216330	Silencer-Trans Opening Floor Cover-Right-RHD	1948,1949
C 216331	Silencer:-Trans Opening Floor Cover-Left-RHD	1948,1949
BO 216340	Tail Lamp Assy-RH	482,484,492,494
BO 216341	Tail Lamp Assy-LH	482,484,492,494
BO 216342	Bezel Assy-Tail Lamp-RH	482,484,492,494,502,504
BO 216343	Bezel Assy-Tail Lamp-LH	482,484,492,494,502,504
BO 216350	Tail Lamp Assy-RH	481,483,491,493,500,501,503
BO 216351	Tail Lamp Assy-LH	481,483,491,493,500,501,503
BO 216352	Bezel-Tail Lamp-RH	481,483,491,493,500,501,503
BO 216353	Bezel-Tail Lamp-LH	481,483,491,493,500,501,503
BO 216354	Base Plate-Tail Lamp-RH	481,483,491,493,500,501,503
BO 216355	Base Plate-Tail Lamp-LH	481,483,491,493,500,501,503
BZ 216356	Sealing Strip-Front Fender Side Dust Shield	1948,1949,501 thru 504
BO 216360	Weatherstrip-Door Opening-Rear-RH	1949-1950 Bro-ClubCpe-BsCpes
BO 216361	Weatherstrip-Door Opening-Rear-LH	1949-1950 Bro-ClubCpe-BsCpes
BO 216362	Weatherstrip-Door Opening-Rear-RH	1949-1950 Sedan
BO 216363	Weatherstrip-Door Opening-Rear-LH	1949-1950 Sedan
BO 216365	Support Assy-Rear Seat Cushion	1948 thru 1950 ClubCpe-CvBro
*HA 216370	Ash Receiver Kit-Front Scat Back	1948-1949 exc BsCpe
BO 216380	Roller Assy-Qtr Wdo Frame-RH	1948 thru 1950 CvBro
BO 216381	Roller Assy-Qtr Wdo Frame-LH	1948 thru 1950 CvBro
C 216382	Glass-Quarter Window	1948 thru 1950 CvBro
BO 216383	Weatherseal-Quarter Window Glass	1948 thru 1950 CvBro
C 216394	Rest Channel & Brkts Assy-Door Wdo Glass-RH	1948 thru 1950 CvBro
C 216395	Rest Channel & Brkts Assy-Door Wdo Glass-LH	1948 thru 1950 CvBro
BO 216405	Tapping Plate-Door Wdo Glass Rest Channel Roller Brkt	1948 thru 1950 CvBro
BO 216408	Roller Assy-Door Window	1948 thru 1950 CvBro
BO 216409	Spring-Door Window Roller	1948 thru 1950 CvBro
BO 216410	Retainer-Door Window Roller	1948 thru 1950 CvBro
C 216412	Frame Assy-Door Window-RH	1948 thru 1950 CvBro
C 216413	Frame Assy-Door Window-LH	1948 thru 1950 CvBro
C 216418	Glass-Door Window	1948 thru 1950 CvBro
BO 216419	Weatherseal-Upper-Door Wdo Glass	1948 thru 1950 CvBro
BO 216420	Weatherseal-Lower-Door Wdo Glass	1948 thru. 1950 CvBr(
BO 216427	Plug-Door Tie-Rod Lower Brkt	1948 thru 1950 CvBro
C 216442	Cushion Frame & Back Complete-Lea Trim	481-491 BsCpe-LHD
C 216443	Cushion Frame & Back Complete-Lea Trim	481-491 BsCpe-RHD
*C 216444	Cushion Frame & Back Complete-Lea Trim	482-484-492-494 CvBro
*C 216446	Cushion Frame & Back Complete-Comb Trim	482-484-492-494 CvBro
BO 216448	Sleeve-Insulating-Antenna Lead Rod	1948 thru 1950
BO 216450	Sleeve-Threaded-Antenna Lead Rod	1948 thru 1950
BO 216458	Base Plate-Tail Lamp	482,484,492,494,502,504
BO 216459	Plug-Door Tie Rod	1948 thru 1950 CvBro
BO 216460	Headlamp-Complete-LH	1948,1949
BO 216461	Headlamp-Complete-RH	1948,1949
BO 216462	Housing Assy-Headlamp	1948,1949
BO 216464	Mounting Ring Assy-Headlamp	1948,1949
BO 216466	Retainer-Headlamp Adjusting Nut	1948 thru 1950
BO 216467	Retainer-Headlamp Adjusting Screw	1948,1949
BO 216468	Anchor-Headlamp Mounting Ring Spring	1948,1949
BO 216469	Anchor-Headlamp Housing Spring	1948,1949
BO 216470	Screw Lug-Headlamp Mounting Ring Retainer	1948,1949
BO 216471	Seal-Top Side Rail Front W/Strip to Header Brkt	1949-1950 CvBro
C 216472	Trim Panel-R Seat Back	1948-1949 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 216474	Trim Panel-Roof Frt Finish Panel	1948-1949 CvBro
*C 216480	Cushion Complete-Rear Seat-Without Rubber Pad-Cloth Trim	481-483-491-493 Bro-Sed
*C 216481	Cushion Complete-Rear Seat-With Rubber Pad-Cloth Trim	481-483-491-493 Bro-Sed
*C 216482	Cushion Complete-Rear Seat-Without Rubber Pad-Cloth Trim	481-483-491-493 ClubCpe
*C 216483	Cushion Complete-Rear Seat-With Rubber Pad-Cloth Trim	481-483-491-493 ClubCpe
*C 216484	Cushion Complete-Rear Seat-With Rubber Pad-Cloth Trim	482-484-492-494-501-503 Bro-Sed
*C 216485	Cushion Complete-Rear Seat-With Rubber Pad-Cloth Trim	482-484-492-494-501-503 ClubCpe
*C 216486	Cushion Complete-Rear Seat-Without Rubber Pad-Lea Trim	481-483-491-493-501-503 Bro-Sed
*C 216487	Cushion Complete-Rear Seat-With Rubber Pad-Lea Trim	1948-1949-501 thru 504 Bro-Sed
*C 216488	Cushion Complete-Rear Seat-Without Rubber Pad-Lea Trim	481-483-491-493-501-503 ClubCpe
*C 216489	Cushion Complete-Rear Seat-With Rubber Pad-Lea Trim	1948-1949-501 thru 504 ClubCpe
*C 216490	Cushion Complete-Rear Seat-Lea Trim	1948 thru 1950 CvBro
*C 216491	Cushion Complete-Rear Seat-Comb Trim	1948-1949 CvBro
C 216492	Trim Assy-Rear Seat Cushion-Lea Trim	1948-1949 CvBro
C 216493	Trim Assy-Rear Seat Cushion-Comb Trim	1948-1949 CvBro
C 216494	Trim Assy-Rear Seat Cushion-Cloth Trim	481-483-491-493 Bro-Sed
C 216495	Trim Assy-Rear Seat Cushion-Cloth Trim	481-483-491-493 ClubCpe
C 216496	Trim Assy-Rear Seat Cushion-Cloth Trim	482-484-492-494 Sedan
C 216497	Trim Assy-Rear Seat Cushion-Cloth Trim	482-484-492-494 ClubCpe
C 216498	Trim Assy-Rear Seat Cushion-Lea Trim	1948-1949 Bro-Sed
C 216499	Trim Assy-Rear Seat Cushion-Lea Trim	1948-1949 ClubCpe
BO 216504	Dial "Temp"-Black	481,483,491,493
BO 216505	Dial "Temp"-Brown	482,484,492,494
BO 216506	Dial "Fuel"-Black	481,483,491,493
BO 216507	Dial "Fuel"-Brown	482,484,492,494
BO 216508	Lettered Disc "Oil"	1948,1949
BO 216509	Lettered Disc "Amp"	1948,1949
216518	Ornament Instrument Switch Mounting Panel-RH (Use 213622)	1948 CvBro AHD
BO 216519	Ornament-Instrument Switch-Mounting Panel-LB	1948-1949 CvBro-LHD
C 216520	Weatherstrip-Door Panel-Bottom-RH	1949 Bro-Cpes-CvBro
216521	Weatherstrip-Door Panel-Bottom-LB (Use 217003 & 216785)	1949 Bro-Cpes-CvBro
C 216522	Weatherstrip-Front Door Panel-Bottom-RH	1949 Sedan
C 216523	Weatherstrip-Front Door Panel-Bottom-LH	1949 Sedan
C 216524	Weatherstrip-Rear Door Panel-Bottom-RH	1949 Sedan
C 216525	Weatherstrip-Rear Door Panel-Bottom-LH	1949 Sedan
BO 216526	Seal-Top Quarter Pillar Hinge to Belt	1948 thru 1950 CvBro
BO 216527	Bumper-Quarter Panel Top Linkage	1949-1950 CvBro
BO 216527	Bumper-Door	1949-1950 CvBro
BO 216534	Seal-Frame Sidemember to Rocker Panel-Rear	1948 thru 1950 CvBro
BO 216537	Bumper-Top Side Rail-Front	1948-1949 CvBro
BO 216538	Brace-Top Pivot Bracket-RH	1948 thru 1950 CvBro
BO' 216539	Brace-Top Pivot Bracket-LH	1948 thru 1950 CvBro
BO 216546	Weatherstrip-Door-Front-RH	1949,1950
BO 216547	Weatherstrip-Door-Front-LH	1949,1950
BO 216548	Plug-Quarter Window Finish Mldg	1948 thru 1950 CvBro
BO 216549	Shim-Rear Pillar Qtr Wdo Hinge Brkt Pad-Thick	1948 thru 1950 CvBro
BO 216550	Shim-Rear Pillar Qtr Wdo Hinge Brkt Pad-Thin	1948 thru 1950 CvBro
BO 216559	Binding-Double Fold-Black	1948 thru 1950 CvBro
BO 216574	Robe Hanger Assy	491-501 CvBro
BO 216575	Robe Hanger Assy-Russet Lea	491-493 Sedan
BO 216576	Robe Hanger Assy-Gray Lea	491-493 Sedan
BO 216577	Robe Hanger Assy-Dark Red Lea	491-493-501-503 Sedan
BO 216578	Robe Hanger Assy-Russet Lea	491-493 Bro-ClubCpe
BO 216579	Robe Hanger Assy-Gray Lea	491-493 Bro-ClubCpe
BO 216580	Robe Hanger Assy-Dark Red Lea	491-493-501-503 Bro-ClubCpe
C 216581	Robe Hanger Assy-Russet Lea	492-494 Sedan
C 216582	Robe Hanger Assy-Gray Lea	492-494 Sedan
C 216583	Robe Hanger Assy-Dark Red Lea	492-494-502-504 Sedan
BO 216584	Robe Hanger Assy-Russet Lea	492-494 Bro-ClubCpe
BO 216585	Robe Hanger Assy-Gray Lea	492-494 Bro-ClubCpe
BO 216586	Robe Hanger Assy-Dark Red Lea	492-494-502-504 Bro-ClubCpe
BO 216587	Robe Hanger Assy	492-494-502-504 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 216588	Trimboard & Trim Assy-Frame Sidemember-Frt-RH	1949
C 216589	Trimboard & Trim Assy-Frame Sidemember-Frt-LH	1949
C 216590	Trimboard & Trim Assy-Frame Sidemember-Rear-RH	1949 Sedan
C 216591	Trimboard & Trim Assy-Frame Sidemember-Rear-LH	1949 Sedan
C 216592	Trimboard & Trim Assy-Frame Sidemember-Rear-RH	1949 Bro-Cpes
C 216593	Trimboard & Trim Assy-Frame Sidemember-Rear-LH	1949 Bro-Cpes
C 216594	Trimboard & Trim Assy-Frame Sidemember-Rear-RH	1949 CvBro
C 216595	Trimboard & Trim Assy-Frame Sidemember-Rear-LH	1949 CvBro
BO 216602	Weatherstrip-Front-Qtr Window-RH	1948 thru 1950 CvBro
BO 216603	Weatherstrip-Front-Qtr Window-LH	1948 thru 1950 CvBro
BO 216604	Filler-Rear-Door Wdo Finish Mldg-RH	1948 thru 1950 CvBro
BO 216605	Filler-Rear-Door Wdo Finish Mldg-LH	1948 thru 1950 CvBro
BO 216608	Panel Assy-Quarter Window Regulator-RH	1948 thru 1950 CvBro
BO 216609	Panel Assy-Quarter Window Regulator-LH	1948 thru 1950 CvBro
BO 216630	Slide Fastener Assy-Top Rear Curtain-Black-RH	1948-1949 CvBro with Plastic Rear Wdo
BO 216631	Slide Fastener Assy-Top Rear Curtain-Black-LH	1948-1949 CvBro with Plastic Rear Wdo
BO 216632	Slide Fastener Assy-Top Rear Curtain-Gray-RH	1948 thru 1950 CvBro with Plastic Rear Wdo
BO 216633	Slide Fastener Assy-Top Rear Curtain-Gray-LH	1948 thru 1950 CvBro with Plastic Rear Wdo
*SC 216640	Rear Curtain & Plastic Window Assy-Folding Top	1948 thru 1950 CvBro
BO 216644	Bracket-Top Operating Cylinder-RH	1948 thru 1950 CvBro
BO 216645	Bracket-Top Operating Cylinder-LH	1948 thru 1950 CvBro
BO 216650	Plug-Door Inner Panel Hydraulic Tube Hole	491-500-501 CvBro with manual wdo reg
C 216651	Insulation-Roof Panel	1948 Sed,1949 Sed-Bro-Cpes
*HA 216652	License Plate Frame Assy-Rayline-Pair	1948 thru 1950
BZ 216658	Weatherseal-Rear Wheel Cover to Frame	1948 thru 1950
*SP 216662	Sealed Beam Assy-Spotlamp	1948 thru 1950
BO 216664	Glove Box Door Assy-Comp-Right-LHD	481,483,491,493
BO 216665	Glove Box Door Assy-Comp-Left-LHD	481,483,491,493
BO 216666	Glove Box Door Assy-Comp-Right-RHD	481,483,491,493
BO 216667	Glove Box Door Assy-Comp-Left-RHD	481,483,491,493
C 216670	Trimboard Complete-F Door-RH-Lea Trim	481-483-491-493 Sed
C 216671	Trimboard Complete-F Door-LH-Lea Trim	481-483-491-493 Sed
C 216672	Trimboard Complete-R Door-RH-Lea Trim	481-483-491-493 Sed
C 216673	Trimboard Complete-R Door-LH-Lea Trim	481-483-491-493 Sed
C 216674	Trimboard Complete-Door-RH-Lea Trim	491-493 Bro-BsCpe-ClubCpe
C 216675	Trimboard Complete-Door-LH-Lea Trim	491-493 Bro-BsCpe-ClubCpe
C 216682	Trimboard-Quarter-RH-Lea Trim	491-493 Bro
C 216683	Trimboard-Quarter-RH-Lea Trim	481-493 Bro
C 216684	Trimboard-Quarter-RH-Lea Trim	491-493 ClubCpe
C 216685	Trimboard-Quarter-LH-Lea Trim	491-493 ClubCpe
BO 216688	Weatherstrip-Front-Front Door	1948,1949
BZ 216691	Seal-Rocker Panel to Frame	1949,1950
*HA 216696	Auxiliary Floor Mat-Gray Green	All
*HA 216697	Auxiliary Floor Mat-Mottled Taupe	All
C 216702	Silencer-Front Floor-Right-LHD	1948,1949,501 thru 504
C 216703	Silencer-Front Floor-Left-LHD	1948,1949,501 thru 504
C 216704	Silencer-Front Floor-Right-RHD	1949,501 thru 504
C 216705	Silencer-Front Floor-Left-RHD	1949,501 thru 504
C 216712	Liner Assy-Quarter Panel-RH	481-491-500-501 CvBro with Manual Wdo Reg
C 216713	Liner Assy-Quarter Panel-LH	481-491-500-501 CvBro with Manual Wdo Reg
BO 216714	Weatherstrip-Top Side Rail-Front-RH	1948-1949 CvBro
BO 216715	Weatherstrip-Top Side Rail-Front-LH	1948-1949 CvBro
BO 216716	Weatherstrip-Top Side Rail-Front Inter-RH	1948-1949 CvBro
BO 216717	Weatherstrip-Top Side Rail-Front Inter-LH	1948-1949 CvBro
BO 216718	Weatherstrip-Top Side Rail-Rear Intermediate-RH	1948 thru 1950 CvBro.
BO 216719	Weatherstrip-Top Side Rail-Rear Inter-LH	1948 thru 1950 CvBro
BO 216720	Escutcheon-Windshield Wiper Operating Control	1948,1949
BO 216721	Escutcheon-Fog Lamp Switch	1948 thru 1950
BO 216730	Support-Top Control Valve Mtg Brkt-RHD	1949 CvBro
BZ 216731	Plug-Front Seat Tray Hole	1949,1950
BZ 216731	Plug-Front Fender to Pillar	1949,1950
BO 216732	Weatherstrip-Quarter Window Belt-Outer	1949-1950 CvBro
BO 216735	Reinforcing Plate-Rear Compt Floor Panel	1949
BO 216737	Assist Strap Assy-Blue Gray Cloth	491 Bro
C 216739	Trim Panel & Silencer Assy-Dash-LH-RHD	1949 CvBro
BZ 216744	Shim-Rear Fender to Frame	1949,1950
BZ 216745	Rail-Rear Bumper Guard & Radiator Grille Guard	1948 thru 1950
BZ 216746	Radiator Grille Guard Assy-RH	1948,1949
BZ 216747	Radiator Grille Guard Assy-LH	1948,1949
BZ 216748	Clamp-Radiator Grille Guard-Upper	1948,1949
BZ 216749	Clamp-Rear Bumper Guard & Radiator Grille Guard-Lower	1948,1949,500
BZ 216750	Clamp-Rear Bumper Guard Rail & Radiator Grille Guard Rail	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 216751	Bracket-Radiator Grille Guard	1948,1949
BZ 216752	Clamp-Radiator Grille Guard Bracket	1948,1949
BZ 216753	Bracket-Rear Bumper Center Guard	1948,1949,500
BZ 216754	Guard Assy-Rear Bumper-Center-RH	1948,1949,500
BZ 216755	Guard Assy-Rear Bumper-Center-LH	1948,1949,500
BZ 216756	Clamp-Rear Bumper Center Guard-Upper	1948,1949,500
216757	Retainer-Windshield Glass (Use 217109)	1949
BO 216760	Weatherstrip & Retainer Assy- Top Side Rail-Front-RH	1949 CvBro
BO 216761	Weatherstrip & Retainer Assy- Top Side Rail-Front-LH	1949 CvBro
BO 216762	Weatherstrip & Retainer Assy-Top Side Rail-Intermediate-RH	1949 CvBro
BO 216763	Weatherstrip & Retainer Assy-Top Side Rail-Intermediate-LH	1949 CvBro
BO 216766	Ornament-Instrument Switch Mounting Panel-Left-RHD.	1948-1949 CvBro
*HA 216767	Accessory Lamp Display Stand	1948 thru 1950
216768	Support Assy-Instrument Panel-RHD (Use 211323)	1949 CvBro
BO 216769	Control Assy-Hood Lock	1949,501 thru 504
BO 216770	Wire & Knob Assy-Hood Lock Control	1949,501 thru 504
BO 216771	Support-Hood Lock Control Brkt-RHD	1949,501 thru 504
BO 216772	Support-Rear View Mirror Bracket	1949,1950
BO 216773	Cover-Rear View Mirror Bracket Support	1949,1950
BZ 216776	Seal-Rocker Panel to Frame-End-Rear-RH	1949,1950
BZ 216777	Seal-Rocker Panel to Frame-End-Rear-LH	1949,1950
BO 216779	Screw-Visor Bracket Arm to Clamp	492-494-502-504 exc CvBro
216780	Weatherstrip & Retainer Assy-Top Side Rail-Intermediate (Use 216762)	1949 CvBro
216781	Weatherstrip & Retainer Assy-Top Side Rail-Intermediate (Use 216763)	1949 CvBro
C 216784	Weatherstrip Assy-Upper-Top Front Header Joint	1949-1950 CvBro
C 216785	Retainer-Lower Door Outer Panel Mldg	1949-1950 Bro-Cpes-CvBro
C 216786	Retainer-Lower-Front Door Outer Panel Mldg	1949-1950 Sed
C 216787	Retainer-Lower-Rear Door Outer Panel Mldg	1949-1950 Sedan
216788	Weatherstrip-Front Door Opening Belt-RH-(Use 1-216852, 3-170958 & 1-217339)	1949 exc CvBro
216789	Weatherstrip-Front Door Opening Belt-LH-(Use 1-216853, 3-170950 & 1-217339)	1949 exc CvBro
BO 216792	Channel Assy-Lower Rear RH-Qtr Wdo Glass Run	1949-1950 Bro
BO 216793	Channel Assy-Lower Rear LH-Qtr Wdo Glass Run	1949-1950 Bro
216794	Weatherstrip & Retainer-Top Side Rail-Front-RH (Use 216760)	1949 CvBro
216795	Weatherstrip & Retainer-Top Side Rail-Front-LH (Use 216761)	1949 CvBro
BO 216796	Shim-Door Scuff Plate	1949 Bro-Cpes-CvBro
BO 216797	Shim-F Door Scuff Plate	1949 Sed
BO 216798	Shim-R Door Scuff Plate	1949 Sedan
BO 216799	Brace Assy-Steering Column	501 thru 504,500 CvBro
BO 216804	Shim-F Door Scuff Plate to Seat Tray	1949
C 216810	Scuff Plate-Door-RH	491-493-501-503 Bro-Cpes-CvBro
C 216811	Scuff Plate-Door-LH	491-493-501-503 Bro-Cpes-CvBro
C 216812	Scuff Plate-Door-RH	492-494-502-504 ClubCpe-CvBro
C 216813	Scuff Plate-Door-LH	492-494-502-504 ClubCpe-CvBro
C 216814	Scuff Plate-Front Door-RH	491-493-501-503 Sedan
C 216815	Scuff Plate-Front Door-LH	491-493-501-503 Sedan
C 216816	Scuff Plate-Front Door-RH	492-494-502-504 Sedan
C 216817	Scuff Plate-Front Door-LH	492-494-502-504 Sedan
216819	Support-Rear Door Scuff Plate (Use 217395)	1949 Sedan
C 216820	Scuff Plate-Rear Door-RH	491-493-501-503 Sedan
C 216821	Scuff Plate-Rear Door-LH	491-493-501-503 Sedan
C 216822	Scuff Plate-Rear Door-RH	492-494-502-504 Sedan
C 216823	Scuff Plate-Rear Door-LH	492-494-502-504 Sedan
216824	Support Door Scuff Plate-RH (Use 217392)	1949 Bro-Cpes-CvBro
216825	Support Door Scuff Plate-LH (Use 217393)	1949 Bro-Cpes-CvBro
216827	Support-Front Door Scuff Plate (Use 217394)	1949-1950 Sedan
BO 216829	Reinf Plate Kit-Rear Compartment Floor	1949
BO 216832	Seal-Rocker Panel Extension-Front	1949-1950 All
BO 216833	Seal-Rocker Panel Front Extension-Rear	1949-1950 Sedan
BO 216834	Seal-Rocker Panel Rear Extension-Front	1949-1950 Sedan
BO 216835	Seal-Rocker Panel Rear Extension-Rear	1949-1950 Sedan
BO 216840	Retainer-Top Quarter Flap-RH	1949-1950 CvBro
BO 216841	Retainer-Top Quarter Flap-LH	1949-1950 CvBro
BO 216842	Sealing Kit	1949 CvBro
C 216850	Mldg-Upper-Qtr Trim Panel-Cloth Trim	491-493-501-503 Bro
C 216850	Mldg-Lower-Front Door Trim Panel	1949-1950 Sedan
BO 216852	Weatherstrip-Front Door-Front-At Belt-RH	1949-1950 exc CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 216853	Weatherstrip-Front Door-Front-At Belt-LH	1949-1950 exc CvBro
BO 216854	Weatherstrip-Front Door-Front-Lower	1949,1950
BO 216858	Weatherstrip-Front Door-Front-At Belt-RH	1949-1950 exc CvBro
BO 216859	Weatherstrip-Front Door-Front-At Belt-LH	1949-1950 exc CvBro
BO 216860	Drain Trough-F Door Wing-RH	1949-1950 exc CvBro
BO 216861	Drain Trough-F Door Wing-LH	1949-1950 exc CvBro
BO 216866	Bumper-Rear Fender Gas Filler Door	1949,1950
C 216867	Molding-Top Front Header-Front-Upper	1949-1950 CvBro
BO 216872	Control Assy-Rear Window Wiper	1948-1949 exc CvBro
BO 216877	Pump, Jar & BracketAssy-Automatic W/Shield Washer	1948 thru 1950
*SP 216878	Wiper Arm-Windshield-RH	1949,1950
*SP 216879	Wiper Arm-Windshield-LH	1949,1950
C 216880	Liner Assy-Quarter Inner Panel-RH	1949-1950 ClubCpe-BsCpe
C 216881	Liner Assy-Quarter Inner Panel-LH	1949-1950 ClubCpe-BsCpe
C 216882	Liner Assy-Quarter Inner Panel-RH	1949-1950 Bro
C 216883	Liner Assy-Quarter Inner Panel-LH	1949-1950 Bro
C 216884	Liner Assy-Front Door Inner Panel-RH	1949-1950 Sedan
C 216885	Liner Assy-Front Door Inner Panel-LH	1949-1950 Sedan
C 216886	Liner Assy-Rear Door Inner Panel-RH	1949 Sedan
C 216887	Liner Assy-Rear Door Inner Panel-LH	1949 Sedan
C 216888	Liner Assy-Door Inner Panel-RH	1949-1950 Bro-Cpes-CvBro
C 216889	Liner Assy-Door Inner Panel-LH	1949-1950 Bro-Cpes-CvBro
C 216892	Glass Run-Door Window Center Bar	1949-1950 CvBro
C 216894	Water Baffle-Quarter Panel	1949-501 thru 504 Sedan
BO 216896	Water Baffle-Wheelhouse Panel to Rear Pillar-RH	1949-1950 Sedan
BO 216897	Water Baffle-Wheelhouse Panel to Rear Pillar-LH	1949-1950 Sedan
BO 216898	Cover-Front Door Inner Panel Lower Hinge Pocket-RH	1949,1950
BO 216899	Cover-Front Door Inner Panel Lower Hinge Pocket-LH	1949,1950
216900	Hinge Assy-RH Glove Box Door (Use 220398) LHD	1949,1950
216901	Hinge Assy-LH-Glove Box Door (Use 220399) RHD	1949,1950
BO 216934	Filler-Front Door W/o Finish Mldg	1949-1950 exc CvBro
BO 216940	Weatherseal-Front Door Window Glass Rest Channel	1949 Sedan
BO 216941	Weatherseal-Rear Door Window Glass Rest Channel	1949-1950 Sedan
BO 216942	Weatherseal-Door Window Glass Rest Channel	1949 Bro-ClubCpe-BsCpe
BO 216943	Weatherseal-Quarter Window Glass Rest Channel	1949-1950 BsCpe-ClubCpe
BO 216944	Weatherseal-Quarter Window Glass Rest Channel	1949-1950 Bro
BO 216949	Drain Hose-Windshield Opening Reinforcement	1949,1950
C 216950	Trim& Windlace Assy-Center Pillar-RH-Cloth Trim	491-493 Sedan
C 216951	Trim& Windlace Assy-Center Pillar-LH-Cloth Trim	491-493 Sedan
C 216952	Trim & Windlace Assy-Center Pillar-RH-Lea Trim	491-493 Sedan
C 216953	Trim& Windlace Assy-Center Pillar-LH-Lea Trim	491-493 Sedan
C 216954	Trim & Windlace Assy-Center Pillar-RH-Cloth Trim	492-494 Sedan
C 216955	Trim& Windlace Assy-Center Pillar-LH-Cloth Trim	492-494 Sedan
C 216956	Trim& Windlace Assy-Center Pillar-RH-Lea Trim	492-494 Sedan
C 216957	Trim & Windlace Assy-Center Pillar-LH-Lea Trim	492-494 Sedan
C 216960	Windlace Assy-Center Pillar-Rear-RH	1949-1950 Sedan
C 216961	Windlace Assy-Center Pillar-Rear-LH	1949-1950 Sedan
C 216962	Windlace Assy-Pillar & Header-RH	1949-1950 Bro-BsCpe-ClubCpe
C 216963	Windlace Assy-Pillar & Header-LH	1949-1950 Bro-BsCpe-ClubCpe
C 216986	Windhose-Front Pillar-Lower-RH	1949,500,501,503,502-504 Cpes
C 216987	Windhose-Front Pillar-Lower-LH	1949,500,501,503,502-504 Cpes
C 216988	Baffle-Rear Pillar to Wheelhouse	1948 thru 1950 Bro-Cpes
BO 216998	Weatherstrip-Door Wing Cradle to Belt Mldg-RH	1949-1950 CvBro
BO 216999	Weatherstrip-Door Wing Cradle to Belt Mldg-LH	1949-1950 CvBro
C 217002	Weatherstrip-Door Panel Bottom-RH	1949-1950 Bro-Cpes-CvBro
C 217003	Weatherstrip-Door Panel Bottom-LH	1949-1950 Bro-Cpes-CvBro
C 217004	Weatherstrip-Front Door Panel Bottom-RH	1949-1950 Sedan
C 217005	Weatherstrip-Front Door Panel Bottom-LH	1949-1950 Sedan
C 217006	Weatherstrip-Rear Door Panel Bottom-RH	1949-1950 Sedan
C 217007	Weatherstrip-Rear Door Panel Bottom-LH	1949-1950 Sedan
*C 217010	Frame & Back Complete-F Scat Cushion-With Rubber Pads-Cloth Trim	491 Bro-LHD
C 217011	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491 Bro-RHD
*C 217012	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491-493 Sedan LHD
C 217013	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491-493 Sedan RHD
*C 217014	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491-493 BsCpe LHD
C 217015	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491-493 BsCpe RHD
*C 217016	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491-493 ClubCpe LHD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 217017	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	491-493 ClubCpe RHD
*C 217020	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	492-494 Sedan LHD
C 217021	Frame & Back Complete-F Seat Cushion-With Rubber Pads-Cloth Trim	492-494 Sedan RHD
*C 217026	Frame & Back Complete-F Seat Cushion-Cloth Trim-With Rubber Pads	492-494 ClubCpe LHD
C 217027	Frame & Back Complete-F Seat Cushion-Cloth Trim-With Rubber Pads	492-494 ClubCpe RIID
*C 217029	Front Seat Back Spring & Trim Assy-Cloth Trim-With Rubber Pads	491-493 Sedan
C 217030	Front Seat Back Spring & Trim Assy-RH-Cloth Trim-With Rubber Pads	491-493 Bro-BsCpe-ClubCpe
C 217031	Front Seat Back Spring & Trim Assy-LH-Cloth Trim-With Rubber Pads	491-493, Bro-BsCpe-ClubCpe
C 217033	Spring & Trim Assy-Front Seat Back-Cloth Trim-With Rubber Pads	492-494-501-503 Sedan
C 217034	Spring & Trim Assy-Front Seat Back-RH-Cloth Trim-With Rubber Pads	492-494-501-503 Bro-BsCpe-ClubCpe
C 217035	Spring & Trim Assy-Front Seat Back-LH-Cloth Trim-With Rubber Pads	492-494-501-503 Bro-BsCpe-ClubCpe
C 217036	Trim Assy-Front Seat Back-RH- Cloth Trim-With Rubber Pads	492-494 Bro-BsCpe-ClubCpe
C 217037	Trim Assy-Front Seat Back-LH- Cloth Trim-With Rubber Pads	492-494 Bro-BsCpe-ClubCpe
C 217038	Trim Assy-Front Seat Back-RH- Cloth Trim-With Rubber Pads	492-494 Sedan
C 217039	Trim Assy-Front Seat Back-LH- Cloth Trim-With Rubber Pads	492-494 Sedan
BO 217040	W/Strip-Top Side Rail-Front-RH	1949-1950 CvBro
BO 217041	W/Strip-Top Side Rail-Front-LH	1949-1950 CvBro
BO 217042	W/Strip & Retainer-Top Side Rail-Front-RH	1949-1950 CvBro
BO 217043	W/ Strip & Retainer-Top Side Rail-Front-LH	1949-1950 CvBro
BO 217044	W/Strip-Top Side Rail W/Strip-Front Inter-RH	1949-1950 CvBro
BO 217045	W/Strip-Top Side Rail W/Strip-Front Inter-LH	1949-1950 CvBro
BO 217046	W/Strip & Retainer-Top Side Rail-Inter-RH	1949-1950 CvBro
BO 217047	W/Strip & Retainer-Top Side Rail-Inter-LH	1949-1950 CvBro
BO 217048	Bumper-Top Side Rail-Front-RH	1949-1950 CvBro
BO 217049	Bumper-Top Side Rail-Front-LH	1949-1950 CvBro
C 217051	Windcord Assy-Front Door Bottom	1949 Sedan
C 217052	Windcord Assy-Rear Door Bottom	1949 Sedan
C 217053	Windcord Assy-Door Bottom	1949 Bro-Cpes-CvBro
BO 217056	Bolt-Rear Door Remote Lock Link	1949-1950 Sedan
BO 217058	Regulator Assy-Quarter Wdo-RH-Manual	491-500-501 CvBro
BO 217059	Regulator Assy-Quarter Wdo-LH-Manual	491-500-501 CvBro
BO 217064	Weatherstrip-Frt Pillar Windshield-RH	1949-1950 CvBro
BO 217065	Weatherstrip-Frt Pillar Windshield-LH	1949-1950 CvBro
BO 217066	Weatherseal-F Door Wdo Glass Rest Channel-RH	1949-1950 Sedan
BO 217067	Wcatherseal-F Door Wdo Glass Rest Channel-LH	1949-1950 Sedan
BO 217068	Weatherseal-Door Wdo Glass Rest Channel-RH	1949-1950 Bro-BsCpe-ClubCpe
BO 217069	Weatherseal-Door Wdo Glass Rest Channel-LH	1949-1950 Bro-BsCpe-ClubCpe
C 217070	Liner-Front Door Inner Panel-Outer-RH	1949-1950 Sedan
C 217071	Liner-Front Door Inner Panel-Outer-LH	1949-1950 Sedan
C 217072	Liner-Rear Door Inner Panel-Outer-RH	1949-1950 Sedan
C 217073	Liner-Rear Door Inner Panel-Outer-LH	1949-1950 Sedan
C 217074	Liner-Door Inner Panel-Outer-RH	1949-1950 Bro-BsCpe-ClubCpe
C 217075	Liner-Door Inner Panel-Outer-LH	1949-1950 Bro-BsCpe-ClubCpe
C 217078	Liner-Quarter Panel-Outer-RH	1949-1950 Bro
C 217079	Liner-Quarter Panel-Outer-LH	1949-1950 Bro
C 217082	Trim Panel-Quarter-RH-Lea Trim	491 BsCpe
C 217083	Trim Panel-Quarter-LH-Lea Trim	491 BsCpe
C 217088	Liner-Quarter Inner Panel-Outer-RH	1949-1950 ClubCpe-BsCpe
C 217089	Liner-Quarter Inner Panel-Outer-LH	1949-1950 ClubCpe-BsCpe
BZ 217094	Tapping Plate-Spare Wheel Support Assy	1949,1950
BZ 217095	Support Assy-Rear Compt Spare Wheel	1949,1950
C 217100	Spring-Rear Seat Back	491-500-501 CvBro
C 217101	Spring-Rear Seat Back	492-494-502-504 CvBro
BO 217104	Support-Rear Seat Back-RH	1949-4950 CvBro
BO 217105	Support-Rear Seat Back-LH	1949-1950 CvBro
C 217106	Panel Assy-Qtr Trim Support-RH	1949-1950 CvBro
C 217107	Panel Assy-Qtr Trim Support-LH	1949-1950 CvBro
BO 217109	Retainer-Lower-Windshield	1949,1950
217118	Brace-Rear Compt Opening Side Panel-RH	1948 thru 1950 Cpes-CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	217119 Brace-Rear Compt Opening Side Panel-LH	1948 thru 1950 Cpes-CvBro
BO	217120 Weatherstrip-Door-Rear-RH	1949-1950 CvBro
BO	217121 Weatherstrip-Door-Rear-LB	1949-1950 CvBro
BO	217124 Weatherstrip-Door Wdo Center Bar	1949-1950 CvBro
BO	217128 Lens-Back-up Lamp	1948 thru 1950
BO	217129 Spring-Back-up Lamp Lens	1948 thru 1950
BO	217132 Speedometer Assy-Miles	491,493
BO	217133 Speedometer Assy-Kilometer	491,493
BO	217134 Dial-Speedometer-Miles	492,494
BO	217135 Dial-Speedometer-Kilometer	492,494
BO	217136 Dial-Speedometer-Miles	491,493
BO	217137 Dial-Speedometer-Kilometer	491,493
BO	217141 Clock Assy-Electric	491,493
BO	217147 Clock Assy-Mechanical	491,493
*HA	217148 Clock Kit-Electric	491,493
BO	217150 Instrument Cluster-With Instruments	491,493
BO	217151 Instrument Cluster-Less Instruments	491,493
F	217154 Gauge-Fuel	491,493
F	217156 Gauge-Temperature	491,493
F	217158 Glass-Fuel Gauge Dial	1949
BO	217159 Glass-Temperature Gauge Dial	1949
BO	217162 Weatherstrip-Door Opening-Upper-RH	1949-1950 Sedan
BO	217163 Weatherstrip-Door Opening-Upper-LH	1949-1950 Sedan
BO	217164 Weatherstrip-Door Opening-Upper-RH	1949-1950 Bro-BsCpe-ClubCpe
BO	217165 Weatherstrip-Door Opening-Upper-LH	1949-1950 Bro-BsCpe-ClubCpe
BO	217168 Seal-Door Scuff Plate Support	1949-1950 Bro-Cpes-CvBro
BO	217169 Seal-Front Door Scuff Plate Support	1949-1950 Sedan
BO	217170 Seal-Rear Door Scuff Plate Support	1949-1950 Sedan
C	217196 Trimboard-Door-RH-Cloth Trim	491-493 Bro-ClubCpe-BsCpe
C	217197 Trimboard-Door-LH-Cloth Trim	491-493 Bro-ClubCpe-BsCpe
C	217198 Trimboard-Front Door-RH-Cloth Trim	492-494 Sedan
C	217199 Trimboard-Front Door-LH-Cloth Trim	492-494 Sedan
C	217200 Trimboard-Rear Door-RH-Cloth Trim	492-494 Sedan
C	217201 Trimboard-Rear Door-LB-Cloth Trim	492-494 Sedan
C	217202 Trimboard-Door-RH-Cloth Trim	492-494 ClubCpe
C	217203 Trimboard-Door-LH-Cloth Trim	492-494 ClubCpe
C	217204 Trimboard-Front Door-RH-Lea Trim	491-493 Sedan
C	217205 Trimboard-Front Door-LH-Lea Trim	491-493 Sedan
C	217206 Trimboard-Rear Door-RH-Lea Trim	491-493 Sedan
C	217207 Trimboard-Rear Door-LH-Lea Trim	491-493 Sedan
C	217208 Trimboard-Door-RH-Lea Trim	491-493 Bro-ClubCpe-BsCpe
C	217209 Trimboard-Door-LH-Lea Trim	491-493 Bro-ClubCpe-BsCpe
C	217210 Trimboard-Front Door-RH-Lea Trim	492-494 Sedan
C	217211 Trimboard-Front Door-LH-Lea Trim	492-494 Sedan
C	217212 Trimboard-Rear Door-RH-Lea Trim	492-494 Sedan
C	217213 Trimboard-Rear Door-LH-Lea Trim	492-494 Sedan
C	217214 Trimboard-Door-RH-Lea Trim	492-494 ClubCpe
C	217215 Trimboard-Door-LH-Lea Trim	492-494 ClubCpe
C	217216 Trimboard-Door-RH-Lea Trim	491 CvBro
C	217217 Trimboard-Door-LH-Lea Trim	491 CvBro
C	217218 Trimboard-Door-RH-Lea Trim	492-494 CvBro
C	217219 Trimboard-Door-LH-Lea Trim	492-494 CVBro
BO	217241 Anchor-Frt Seat Tract Spring	1949,1950
*HA	217242 Charcoal Grille	
BO	217243 Bracket-Inside-Spot Lamp-LH	1948 thru 1950
BO	217245 Bracket-Outside-Spot Lamp-LHD	1948 thru 1950
BO	217246 Bracket-Outside-Spot Lamp-RHD	1948 thru 1950
BO	217247 Gasket-Spot Lamp-Inside Bracket	1948 thru 1950
BO	217248 Attaching Screw Set-Spot Lamp Inside Bracket	1948 thru 1950
BO	217249 Attaching Screw Set-Spot Lamp Outside Bracket	1948 thru 1950
C	217252 Liner Assy-Door Inner Panel-Outer-RH	491-500-501 CvBro without Hyd Wdo Reg
C	217253 Liner Assy-Door Inner Panel-Outer-LH	491-500-501 CvBro without Hyd Wdo Reg
C	217256 Trimboard-Front Door-RH-Cloth Trim	491-493 Sedan
C	217257 Trimboard-Front Door-LH-Cloth Trim	491-493 Sedan
C	217258 Trimboard-Rear Door-RH-Cloth Trim	491-493 Sedan
C	217259 Trimboard-Rear Door-LH-Cloth Trim	491-493 Sedan
C	217260 Trimboard-Door-RH-Cloth Trim	491-493 Bro-ClubCpe-BsCpe
C	217261 Trimboard-Door-LH-Cloth Trim	491-493 Bro-ClubCpe-BsCpe
C	217262 Trimboard-Front Door-RH-Cloth Trim	491-493 Sedan
C	217263 Trimboard-Front Door-LH-Cloth Trim	491-493 Sedan
C	217264 Trimboard-Rear Door-RH-Cloth Trim	491-493 Sedan
C	217265 Trimboard-Rear Door-LH-Cloth Trim	491-493 Sedan
C	217266 Trimboard-Door-RH-Cloth Trim	492-494 ClubCpe
C	217267 Trimboard-Door-LH-Cloth Trim	492-494 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 217268	Trimboard-Front Door-RH-Cloth Trim	492-494 Sedan
C 217269	Trimboard-Front Door-LH-Cloth Trim	492-494 Sedan
C 217270	Trimboard-Rear Door-RH-Cloth Trim	492-494 Sedan
C 217271	Trimboard-Rear Door-LH-Cloth Trim	492-494 Sedan
C 217272	Trimboard-Door-RH-Lea Trim	491-493 Bro-BsCpe-ClubCpe
C 217273	Trimboard-Door-LH-Lea Trim	491-493 Bro-BsCpe-ClubCpe
C 217274	Trimboard-Front Door-RH-Lea Trim	491-493 Sedan
C 217275	Trimboard-Front Door-LH-Lea Trim	491-493 Sedan
C 217276	Trimboard-Rear Door-RH-Lea Trim	491-493 Sedan
C 217277	Trimboard-Rear Door-LH-Lea Trim	491-493 Sedan
C 217278	Trimboard-Door -RH-Lea Trim	492-494 ClubCpe
C 217279	Trimboard-Door-LH-Lea Trim	492-494 ClubCpe
C 217280	Trimboard-Front Door-RH-Lea Trim	492-494 Sedan
C 217281	Trimboard-Front Door-LH-Lea Trim	492-494 Sedan
C 217282	Trimboard-Rear Door-RH-Lea Trim	492-494 Sedan
C 217283	Trimboard-Rear Door-LH-Lea Trim	492-494 Sedan
C 217284	Trimboard-Door-RH	491 CvBro
C 217285	Trimboard-Door-L\$	491 CvBro
C 217286	Trimboard-Door-RH	492-494 CvBro
C 217287	Trimboard-Door-LH	492-494 CvBro
C 217291	Windcord-Front Door Bottom	1949 Sedan
C 217292	Windcord-Rear Door Bottom	1949 Sedan
C 217293	Windcord-Door Bottom	1949 exc Sedan
C 217308	Liner Assy-Outer-Door Inner Panel-RH	1949-1950 CvBro with Hyd Wdo Reg
C 217309	Liner Assy-Outer-Door Inner Panel-LH	1949-1950 CvBro with Hyd Wdo Reg
C 217310	Trimboard-Quarter-RH-Cloth Trim	491-493 Bro
C 217311	Trimboard-Quarter-LH-Cloth Trim	491-493 Bro
C 217312	Trimboard-Quarter-RH-Cloth Trim	491-493 ClubCpe
C 217313	Trimboard-Quarter-LH-Cloth Trim	491-493 ClubCpe
C 217316	Trimboard-Quarter-RH-Cloth Trim	492-494 ClubCpe
C 217317	Trimboard-Quarter-LH-Cloth Trim	492-494 ClubCpe
C 217318	Trimboard-Quarter-RH-Lea Trim	491-493 Bro
C 217319	Trimboard-Quarter-LH-Lea Trim	491-493 Bro
C 217320	Trimboard-Quarter-RH-Lea Trim	491-493 ClubCpe
C 217321	Trimboard-Quarter-LH-Lea Trim	491-493 ClubCpe
C 217324	Trimboard-Quarter-RH-Lea Trim	492-494 ClubCpe
C 217325	Trimboard-Quarter-LH-Lea Trim	492-494 ClubCpe
HA 217331	Kar Visor Display Stand	1948 thru 1950
BO 217332	Weatherstrip-Stationary Quarter Wdo Glass	500 Sedan
C 217336	Glass-Stationary Quarter Window	500 Sedan
BO 217338	Bolt-Top Balance Link to Side Rail	1949-1950 CvBro
BO 217339	Weatherstrip End-Door Opening-Upper-Front	1948,1949
BO 217340	Seal-Rocker Panel Extension-Rear	1949-1950 Bro-Cpes-CvBro
BO 217342	Seal-Top Front Header Upper Mldg	1949-1950 CvBro
BO 217344	Roof Bracket-Top Hold Down Clamp	1950 CvBro
BO 217346	Spring-Rear Fender Gas Filler Door-RH	1949,1950
BO 217347	Spring-Rear Fender Gas Filler Door-LH	1949,1950
BO 217348	Crystal-Clock	1949
BO 217349	Lens-Speedometer	1949
BO 217358	Spacer-Rear Compt Door Hinge	1949 CvBro
217370 Pr	Rear Compt Door Assy	491-493 Bro-Sedan
*C 217371 Pr	Rear Compt Door Assy	492-494 Bro-Sedan
*C 217372 Pr	Rear Compt Door Assy	491-493 Cpes-CvBro
*C 217373 Pr	Rear Compt Door Assy	492-494 Cpes-CvBro
C 217380	Trimboard-Qtr Trim Support Panel-RH	1949 CvBro
C 217381	Trimboard-Qtr Trim Support Panel-LH	1949 CvBro
C 217382	Trimboard-Qtr Trim Support Panel-RH	1949 CvBro
C 217383	Trimboard-Qtr Trim Support Panel-LH	1949 CvBro
BO 217390	Channel Assy-Front Door Window Glass Run	1949-1950 exc CvBro
BO 217391	Channel Assy-Front Door Window Glass Run	1949-1950 exc CvBro
C 217392	Support Assy-Door Scuff Plate-RH	1949-1950 Bro-Cpes-CvBro
C 217393	Support Assy-Door Scuff Plate-LH	1949-1950 Bro-Cpes-CvBro
C 217394	Support Assy-Front Door Scuff Plate	1949-1950 Sedan
C 217395	Support Assy4tear Door Scuff Plate	1949-1950 Sedan
C 217410	Trimboard-Quarter Pocket-RH-Cloth Trim	491-493 Bro
C 217411	Trimboard-Quarter Pocket-LH-Cloth Trim	491-493 Bro
C 217412	Trimboard-Quarter Pocket-RH-Cloth Trim	491-493 ClubCpe
C 217413	Trimboard-Quarter Pocket-LH-Cloth Trim	491-493 ClubCpe
C 217414	Trimboard-Quarter Pocket-RH-Lea Trim	491-493 Bro
C 217415	Trimboard-Quarter Pocket-LH-Lea Trim	491-493 Bro
C 217416	Trimboard-Quarter Pocket-RH-Lea Trim	491-493 ClubCpe
C 217417	Trimboard-Quarter Pocket-LH-Lea Trim	491-493 ClubCpe
C 217418	Trimboard-Front Door Pocket-RH-Cloth Trim	491-493 Sedan
C 217419	Trimboard-Front Door Pocket-LH-Cloth Trim	491-493 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 217420	Trimboard-Rear Door Pocket-RH-Cloth Trim	491-493 Sedan
C 217421	Trimboard-Rear Door Pocket-LH-Cloth Trim	491-493 Sedan
C 217422	Trimboard-Door Pocket-RH-Cloth Trim	491-493 Bro-ClubCpe-BsCpe
C 217423	Trimboard-Door Pocket-LH-Cloth Trim	491-493 Bro-ClubCpe-BsCpe
C 217424	Trimboard-Front Door Pocket-RH-Lea Trim	491-493 Sedan
C 217425	Trimboard-Front Door Pocket-LH-Lea Trim	491-493 Sedan
C 217426	Trimboard-Rear Door Pocket-RH-Lea Trim	491-493 Sedan
C 217427	Trimboard-Rear Door Pocket-LH-Lea Trim	491-493 Sedan
C 217428	Trimboard-Door Pocket-RH-Lea Trim	491-493 Bro-ClubCpe-BsCpe
C 217429	Trimboard-Door Pocket-LH-Lea Trim	491-493 Bro-ClubCpe-BsCpe
C 217442	Trimboard Assy-F Door Pocket-RH-Cloth	491-493 Sedan
C 217443	Trimboard Assy-F Door Pocket-LH-Cloth	491-493 Sedan
C 217444	Trimboard Assy-Door Pocket-RH-Cloth	491-493 Bro-Cpes
C 217445	Trimboard Assy-Door Pocket-LH-Cloth	491-493 Bro-Cpes
C 217446	Trimboard Assy-F Door Pocket-RH-Leather	491-493 Sedan
C 217447	Trimboard Assy-F Door Pocket-LH-Leather	491-493 Sedan
C 217448	Trimboard Assy-Door Pocket-RH-Leather	491-493 Bro-Cpes
C 217449	Trimboard Assy-Door Pocket-LH-Leather	491-493 Bro-Cpes
C 217480	Headlining Cloth Gray	1949
C 217481	Headlining Cloth-Tan	1949,501-503 exc CvBro
BO 217488	Locking Handle-Quarter Wing-RH	1948-1949-501 thru 504 Sedan
BO 217489	Locking Handle-Quarter Wing-LH	1948-1949-501 thru 504 Sedan
BO 217494	Center Bar & Weatherstrip Assy-Front Door Window-RH	1949-501 thru 504 CvBro
BO 217495	Center Bar & Weatherstrip Assy-Front Door Window-LB	1949-501 thru 504 CvBro
BO 217496	Retainer-Frt Door Wing Weatherstrip-RH	491-493-500-501-503 exc CvBro
BO 217497	Retainer-Frt Door Wing Weatherstrip-LH	491-493-500-501-503 exc CvBro
BO 217500	Wing Complete-Front Door-RH	492-494-502-504 exc CvBro
BO 217501	Wing Complete-Front Door-LH	492-494-502-504 exc CvBro
BO 217504	Wing Complete-Front Door-RH	501-503 exc CvBro
BO 217505	Wing Complete-Front Door-LH	501-503 exc CvBro
C 217510	Glass Run Assy-Quarter Window-RH	1949-1950 BsCpe
C 217511	Glass Run Assy-Quarter Window-LH	1949-1950 BsCpe
C 217514	Glass Run Assy-Quarter Window-RH	1949-1950 ClubCpe
C 217515	Glass Run Assy-Quarter Window-LH	1949-1950 ClubCpe
C 217518	Glass Run Assy-Quarter Window-RH	1949-1950 Bro
C 217519	Glass Run Assy-Quarter Window-LH	1949-1950 Bro
C 217520	Channel-Quarter Window Glass Run-RH	1949-1950 BsCpe-ClubCpe
C 217521	Channel-Quarter Window Glass Run-LH	1949-1950 BsCpe-ClubCpe
C 217522	Channel-Upper-Quarter Window Glass Run-RH	1949-1950 Bro
C 217523	Channel-Upper-Quarter Window Glass Run-LH	1949-1950 Bro
A 217534	Dust Shield As sy-Frame Sidemember to Rear Fender-RH	1949-1950 Bro-ClubCpe-BsCpe
A 217535	Dust Shield As sy-Frame Sidemember to Rear Fender-LB	1949-1950 Bro-ClubCpe-BsCpe
C 217575	Paint Kit	1949
C 217576	Binding-Double Fold-Gray	1949,1950 CvBro
C 217580	Trimboard Assy-Front Door-RH	491-493 Sedan
C 217581	Trimboard Assy-Front Door-LH	491-493 Sedan
C 217582	Trimboard Assy-Rear Door-RH	491-493 Sedan
C 217583	Trimboard Assy-Rear Door-LH	491-493 Sedan
C 217584	Trimboard Assy-Door-RH	491-493 Bro-Cpes-CvBro
C 217585	Trimboard Assy-Door-LH	491-493 Bro-Cpes-CvBro
C 217590	Trimboard-Front Door-RH-Cloth	491-493 Sedan
C 217591	Trimboard-Front Door-LH-Cloth.	491-493 Sedan
C 217592	Trimboard-Roar Door-RH-Cloth	491-493 Sedan
C 217593	Trimboard-Rear Door-LH-Cloth	491-493 Sedan
C 217594	Trimboard-Door-RH-Cloth	491-493 Bro-Cpes
C 217595	Trimboard-Door-LH-Cloth	491-493 Bro-Cpes
C 217596	Trimboard-Front Door-RH-Leather	491-493 Sedan
C 217597	Trimboard-Front Door-LB-Leather	491-493 Sedan
C 217598	Trimboard-Rear Door-RH-Leather	491-493 Sedan
C 217599	Trimboard-Rear Door-LH-Leather	491-493 Sedan
C 217600	Trimboard-Door-RH-Leather	491-493 Bro-Cpes
C 217601	Trimboard-Door-LH-Leather	491-493 Bro-Cpes
C 217604	Trimboard-Quarter-RH-Cloth	491-493 Bro
C 217605	Trimboard-Quarter-LH-Cloth	491-493 Bro
C 217606	Trimboard-Quarter-RH-Cloth	491-493 ClubCpe
C 217607	Trimboard-Quarter-LH-Cloth	491-493 ClubCpe
C 217608	Trimboard-Quarter-RH-Leather	491-493 Bro
C 217609	Trimboard-Quarter-LH-Leather	491-493 Bro
C 217610	Trimboard-Quarter-RH-Leather	491-493 ClubCpe
C 217611	Trimboard-Quarter-LH-Leather	491-493 ClubCpe
BO 217625	Visor Assy-Inside-Tan Cloth	492,494

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 220000	Panel-Roof	501 thru 504 Bro-Sed
*HA 220006	Radiator Grille Guard Kit	1950
220008	Sleeve-Speedometer Cable Core Silencer	1948 thru 1950
BZ 220011	Clamp-Lower-Radiator Grille Guard	1950
BZ 220012	Radiator Grille Guard Assy-RH	1950
BZ 220013	Radiator Grille Guard Assy-LH	1950
BZ 220014	Anchor Bracket-Radiator Grille Guard	1950
C 220019	Mat & Pad Assy-Front Floor-LHD	500
C 220021	Mat & Pad Assy-Front Floor-RHD	500
BZ 220028	Clamp-Upper-Radiator Grille Guard	500
BZ 220029	Clamp-Upper-Radiator Grille Guard	501 thru 504
C 220036	Retainer & Windhose Assy-F-Pillar Lower Trim-RH	1950
C 220037	Retainer & Windhose Assy-F-Pillar Lower Trim-LH	1950
BZ 220038	Escutcheon-Accelerator Pedal	500
BO 220041	Anti-Rattle Strip-Door Lock Release Rod Knob	1950
BO 220046	Ash Receiver Assy-Front Seat Back	500 Bro-ClubCpe
BO 220047	Ash Receiver & Lid Assy-Front Seat Back	500 Bro-ClubCpe
*A 220051	Hood Assembly	501 thru 504
A 220056	Reinforcement Assy-Hood Panel-Front	1950
220057	Frame & Back Complete-Front Seat Cushion	500 Sedan
BO 220060	Lock Assy-Hood-Upper Half	1950
BO 220063	Tapping Plate-Hood Lock Upper Mounting Plate	1950
BO 220070	Lock Assy-Hood-Lower Half	1950
BO 220073	Pivot-Hood Lock Safety Hook	1950
BO 220074	Bracket-Hood Lock Safety Hook	1950
BO 220075	Spring-Hood Lock Safety Hook	1950
BO 220076	Lever-Hood Lock	1950
BO 220077	Safety Hook-Hood Lock	1950
BO 220078	Retainer-Hood Lock Lever Wire	1950
BO 220079	Guide-Hood Lock Lever	1950
BO 220080	Spring-Hood Lock Lever	1950
C 220088	Louvre-Hood-RH	1950
C 220089	Louvre-Hood-LH	1950
BO 220091	Ornament-Hood Front	1950
BO 220093	Gasket-Hood Front Ornament Lens	1950
BO 220094	Reflector-Hood Front Ornament Lamp	1950
BO 220095	Ornament Assy-Hood Front	1950
BO 220096	Lens-Hood Front Ornament	1950
C 220119	Name Plate Assy-Rear Cmpt Door	502,504
BO 220132 Pr	Brace Assy-Cowl Side Panel to Frame-RH	1950
C 220134 Pr	Brace Assy-Cowl Side Panel to Frame-RH	1950 exc CvBro
BO 220135 Pr	Brace Assy-Cowl Side Panel to Frame-LH	1950
BO 220138	Rear View Mirror Assy	1950
A 220144	Side Support Assy-Radiator Grille Baffle-RH	1950
A 220145	Side Support Assy-Radiator Grille Baffle-LH	1950
BO 220151	Motor Assy-Windshield Wiper	1950
BO 220153	Washer-Front Fender Side Ornament Seal	1950
BO 220153	Washer-Rear Cmpt Door Drive Master & Super Matic Drive Name Plate	1950
C 220154	Louvre-Radiator Grille-RH	501 thru 504
C 220155	Louvre-Radiator Grille-LH	501 thru 504
BO 220160	Cover-Radiator Grille Louvre Joint	501 thru 504
A 220162	Baffle-Radiator Grille-Upper-RH	1950
A 220163	Baffle-Radiator Grille-Upper-LH	1950
A 220164	Baffle-Radiator Grille-Center-RH	1950
A 220165	Baffle-Radiator Grille-Center-LH	1950
A 220166	Baffle-Radiator Grille-Lower-RH	501 thru 504
A 220167	Baffle-Radiator Grille-Lower-LH	501 thru 504
A 220168	Baffle-Radiator Grille-Lower-RH	500
A 220169	Baffle-Radiator Grille-Lower-LH	500
C 220179	Center Support Assy-Radiator Grille	1950
BO 220180	Strut-Radiator Grille Triangle-RH	501 thru 504
BO 220181	Strut-Radiator Grille Triangle-LH	501 thru 504
BO 220182	Strut-Radiator Grille Triangle-RH	500
BO 220183	Strut-Radiator Grille Triangle-LH	500
BZ 220188	Bracket-Radiator Grille Triangle Strut-Upper Right	1950
BZ 220189	Bracket-Radiator Grille Triangle Strut-Upper Left	1950
C 220198	Molding-Front Door Trimboard-Upper	501-503 Sedan
C 220199	Molding-Door Trimboard-Upper	501-503 Bro-Cpes
A 220212 Pr	Front Extension Assy-Front Fender-RH	501 thru 504
A 220213 Pr	Front Extension Assy-Front Fender-LH	501 thru 504
*A 220214	Fender Assy-Front-RH	1948,1949,501 thru 504
*A 220215	Fender Assy-Front-LH	1948,1949,501 thru 504
*A 220217	Tie Panel & Hood Lock Support Assy-Front Fender	1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
A 220220 Pr	Splash Guard-Front-RH	1950
A 220221 Pr	Splash Guard-Front-LH	1950
BO 220222 Pr	Cover-Front Splash Guard Joint	1950
*SP 220223	Vertabrae-Windshield Wiper Blade-10"	1949,1950
220224	Vertabrae-Windshield Wiper Blade-11"	1948,1949
220238	Retainer-Rear Shelf Panel Front Extension Headlining	1950 BsCpe
*C 220240	Panel-Rear Shelf	1950 Bro-Sed
C 220242	Extension-Rear Shelf Panel-Rear	501 thru 504 Bro-Sed
C 220243	Extension-Rear Shelf Panel-Rear	1950 BsCpe-ClubCpe
BO 220244	Sealing Block-Rear Shelf Panel Extension Roof Panel	500 Bro-Sed
C 220250	Glass-Rear Window-RH	501 thru 504 Bro-Sed
C 220251	Glass-Rear Window-LH	501 thru 504 Bro-Sed
C 220252	Weatherstrip-Rear Window	501 thru 504 Bro-Sed
BO 220258	Molding-Rear Window Center-Outer	501 thru 504 Bro-Sed
BO 220260	Molding-Rear Window Center-Inner	501 thru 504 Bro-Sed
BO 220262	Retainer-Rear Window Center Mldg-Outer	501 thru 504 Bro-Sed
BO 220264	Retainer-Rear Window Center Mldg-Innet	501 thru 504 Bro-Sed
C 220266	Molding-Rear Window Reveal-RH	501 thru 504 Bro-Sed
C 220267	Molding-Rear Window Reveal-LH	501 thru 504 Bro-Sed
C 220270	Reinforcement-Rear Window Opening	501 thru 504 Bro-Sed
C 220276	Panel & Hinge Bracket Assy-Rear Compt Partition	1950 CvBro
*SP 220278	Blade-Windshield Wiper	1949,1950
BO 220279	Seal-Rocker Panel Rear Pillar to Frame	1950 Sedan
BO 220290	Protector-Rear License Lamp Wiring	501 thru 504
BO 220291	Cover-Rear Compt Floor Drain-Hole-Large	501 thru 504
BO 220294	Brkt Assy-Rear Door Arm Rest-RH	1950 Sedan
BO 220295	Brkt Assy-Rear Door Arm Rest-LH	1950 Sedan
C 220305	Impact Bar-Rear Bumper-Center	501 thru 504
C 220306	Reinforcement-Rear Bumper Center Impact Bar	501 thru 504
C 220310	Impact Bar-Front Bumper	1950
C 220312	Bar-Front Bumper Impact Bar to Frame	1950
BO 220316	Ornament-Front Fender-Top	1950
BO 220317	Name Plate-Rear Compt Door	501,503
BO 220318	Escutcheon-Rear Compt Door Handle	501,503
BO 220319	Handle Assy-Rear Compt Door	500,501,503
220321	Ornament-Rear Compartment Door	502,504
BO 220322	Gasket-Rear Compartment Door Ornament	502,504
BZ 220324	Guard Assy-Front Bumper-Inner-RH	501 thru 504
BZ 220325	Guard As sy-Front Bumper-Inner-LH	501 thru 504
BZ 220326	Guard Assy-Front Bumper-Inner-RH	500
BZ 220327	Guard Assy-Front Bumper-Inner-LH	500
BZ 220330	Guard Assy-Front Bumper-Outer-RH	1950
BZ 220331	Guard Assy-Front Bumper-Outer-LH	1950
BZ 220332	Guard Assy-Rear Bumper-Outer-RH	501 thru 504
BZ 220333	Guard Assy-Rear Bumper-Outer-LH	501 thru 504
BZ 220334	Guard Assy-Rear Bumper-Outer-RH	500
BZ 220335	Guard Assy-Rear Bumper-Outer-LH	500
BZ 220338	Guard Assy-Rear Bumper-Inner-RH	501 thru 504
BZ 220339	Guard Assy-Rear Bumper-Inner-LH	501 thru 504
BO 220341	Pad-Rear Compt Door Handle Escutcheon	501,503
BO 220342	Pad-Rear Compt Door License Lamp Housing	500
BO 220343	Name Plate-Rear Compt Door	500
BO 220346	Crest Assy-Hood	502,504
BO 220347	Ornament-Hood Crest	502,504
BO 220348	Crest-Hood	501,503
BO 220350	Crest-Hood	502,504
BO 220361	Spring-Outside Rear View Mirror Lock Screw	1950
BO 220362	Lock Washer-Outside Rear View Mirror Lock Screw	1950
BO 220363	Lock Screw-Outside Rear View Mirror	1950
BO 220370	Weatherstrip-Quarter Window-Front-RH	1950 CvBro
BO 220371	Weatherstrip-Quarter Window-Front-LH	1950 CvBro
BO 220375	Knob Assy-Cigar Assy	500 exc CvBro
BO 220376	Knob Assy-Cigar Assy	501,503,500 CvBro
BO 220390	Hinge Assy-Rear Compt Door	1950 Bro-Sed
BO 220393	Hinge & Cover Assy-Rear Compt Door	1950 CvBro
BO 220395	Name Plate-"Drive Master"-Rear Compt Door	1950
BO 220396	Name Plate-"Super Matic Drive" Rear Compt Door	1950
BO 220398	Hinge Assy-Glove Box Door-RH	1950
BO 220399	Hinge Assy-Glove Box Door-LH	1950
BO 220402	Cap-Radiator Grille Triangle Strut-Upper-RH	501 thru 504
BO 220403	Cap-Radiator Grille Triangle Strut-Upper-LH	501 thru 504
BZ 220405	Nut Assy-Radiator Grille Intermediate Mldg End Tee Bolt	1950
BZ 220406	Tee Bolt-Radiator Grille Upper & Intermediate Mldg	1950

Part No.	Name	Models
BZ 220407	Tee Bolt-Radiator Grille Intermediate Mldg-End	1950
BO 220412	Cap-Radiator Grille Triangel Strut-Lower-RH	501 thru 504
BO 220413	Cap-Radiator Grille Triangle Strut-Lower-LH	501 thru 504
BO 220416	Cap-Radiator Grille Triangle Strut-Upper-RH	500
BO 220417	Cap-Radiator Grille Triangle Strut-Upper-LH	500
BO 220420	Cap-Radiator Grille Triangle Strut-Lower-RH	500
BO 220421	Cap-Radiator Grille Triangle Strut-Lower-LH	500
BO 220430	Lamp Assy-Rear License	501 thru 504
BO 220432	Lens-Rear License Lamp	501 thru 504
BO 220433	Gasket-Rear License Lamp Lens	501 thru 504
BO 220434	Bezel-Rear License Lamp Lens	501 thru 504
BO 220436	Base Plate-Rear License Lamp	501 thru 504
BO 220437	Socket & Wire Assy-Rear License Lamp	501 thru 504
BO 220440	Parking Lamp Assy-RH	501 thru 504 Less DI
BO 220441	Parking Lamp Assy-LH	501 thru 504 Less DI
BO 220442	Parking Lamp & Direction Indicator Assy-RH	501 thru 504 With DI
BO 220443	Parking Lamp & Direction Indicator Assy-LH	501 thru 504 With DI
BO 220446	Gasket-Parking Lamp Base	501 thru 504
BO 220448	Lens-Parking Lamp-RH	501 thru 504
BO 220449	Lens-Parking Lamp-LB	501 thru 504
BO 220450	Door-Parking Lamp-RH	501 thru 504
BO 220451	Door-Parking Lamp-LH	501 thru 504
BO 220452	Gasket-Parking Lamp Lens	501 thru 504
220454	Panel Assy-Rear Compt Seat Back-RH	1950 ClubCpe
220455	Panel Assy-Rear Compt Seat Back-LH	1950 ClubCpe
BO 220457	Bracket-Cowl Ventilator Air Duct to Radio	1950 with Radio
BO 220461	Bracket Assy-Inst Panel Support to Pillar-LH	1950
BO 220462	Bracket Assy-Inst Panel Support to Pillar-RH	1950 RHD
C 220465	Pillar Assy-Front-Left	500-501-503 cxc CvBro with Hyd Wdo Reg
C 220466	Pillar Assy-Front-Right	500-501-503 RHD
C 220467	Pillar Assy-Front-Left	500-501 CvBro with Hyd Wdo Reg
BZ 220474	Support Assy-Rear License & Name Plate	500
BZ 220479	Spacer-Front Fender Side Name Plate Rear Screw	501 thru 504
BZ 220480	Ornament-Front Fender Side-RH	500
BZ 220481	Ornament-Front Fender Side-LH	500
BO 220496	Grille-Radio Speaker	500
BO 220497	Grille-Radio Speaker	501 thru 504
*A 220502	Instrument Panel	501,503
*A 220503	Instrument Panel	502,504
*A 220517	Instrument Panel Assy	500
BO 220540	Tail Lamp Assy-RH	502-504
BO 220541	Tail Lamp Assy-LH	502-504
BO 220542	Ornament-Tail Lamp	502-504
BO 220550	Ornament-Inner-Instrument Switch Mounting Panel	500,501,503
BO 220551	Ornament-Inner-Instrument Switch Mounting Panel	502,504
BO 220556	Ornament-Outer-Instrument Switch Mounting Panel	1950 exc CvBro
BO 220557	Ornament-Outer-Instrument Switch-Mounting Panel	1950 CvBro
BO 220558	Control Assy-Windshield Wiper & Washer	1950
BO 220559	Knob Assy-Windshield Wiper & Washer	1950
BO 220560	Nut-Windshield Wiper & Washer Operating Control	1950
BO 220561	Washer-Windshield Wiper & Washer Operating Control	1950
*HA 220563	Radio Speaker Grille Kit	1948,1949
220564	Carpet Assy-Front Seat Foot Rest	501 thru 504 Bro-Sed
*HA 220565	Automatic Windshield Washer Kit	1950
BO 220566	Name Plate-Glove Box Door-"Super Six"	501
BO 220567	Name Plate- Glove Box Door-"Super Eight"	503
BO 220568	Name Plate Assy-Glove Box Door "Commodore Six"	502
BO 220569	Name Plate Assy-Glove Box Door "Commodore Eight"	504
BO 220570	Ornament-Glove Box Door	500
BO 220572	Name Plate-Glove Box Door	502
BO 220573	Name Plate-Glove Box Door	504
BO 220574	Ornament-Instrument Panel-Center	501 thru 504
BO 220576	Ornament-Instrument Panel-Side	501,503
BO 220578	Ornament-Instrument Panel-Side-RH	502,504
BO 220579	Ornament-Instrument Panel-Side-LH	502,504
BO 220584	Cover-Glove Box Door Name Plate-Back	502,504
BO 220586	Ash Receiver Assy-Front Seat Back	500 Sedan
BO 220587	Retainer-Front Seat Back Ash Receiver	500 Sedan
BO 220628	Hinge-Quarter Window-RH	1948 thru 1950 CvBro
BO 220629	Hinge-Quarter Window-LH	1948 thru 1950 CvBro
BO 220631	Handle-& Bracket Assy-Front Seat Adjusting	500
BO 220632	Handle & Bracket Assy-Front Seat Adjusting	500
220639	Clip-Door Trimboard	1950
BO 220646	Hole Cover-Front Floor Mat Steering Column	501 thru 504,500 RHD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 220648	Silencer-Instrument Finish Panel-Upper	500
BO 220649	Silencer-Instrument Finish Panel-Lower	500
220650	Cover-Radio Dial Hole	500 without radio
220651	Cover-Radio Dial Hole	501 thru 504 without radio
BO 220654	Cover-Front Floor Mat Steering Column Hole	500
BO 220660	Ash Receiver Assy-Instrument Panel	500
BO 220661	Ash Receiver Assy-Instrument Panel	501 thru 504
BO 220664	Finish Panel-Instrument Panel Ash Receiver	500
BO 220665	Bezel-Instrument Panel Ash Receiver	500
BO 220666	Knob-Instrument Panel Ash Receiver	1950
BO 220667	Ornament-Instrument Panel Ash Receiver	501 thru 504
BO 220673	Retainer-Instrument Panel Ash Receiver	1950
BO 220679	Handle Assy-Cowl Ventilator	500
BO 220683	Handle Assy-Cowl Ventilator	501 thru 504
BO 220685	Clip-Frame Sidemember Rear Trimboard	1950
A 220688 Pr	Rocker Panel Assy-Rear-RH	500
A 220689 Pr	Rocker Panel Assy-Rear-LH	500
C 220692 Pr	Cover & Rod Assy-Rear Wheel-RH	500
C 220693 Pr	Cover & Rod Assy-Rear Wheel-LH	500
BO 220698	Seal-Floor Steering-Column Hole	1950
BO 220700	Headlamp	1950
BO 220701	Headlamp	1950
BO 220703	Housing Assy-Headlamp	1950
BO 220704	Mounting Ring Assy-Headlamp	1950
BO 220705	Gasket-Headlamp to Fender	1950
BO 220706	Base & Wire Assy-Parking Lamp-RH	501 thru 504 less DI
BO 220707	Base & Wire Assy-Parking Lamp-LH	501 thru 504 less DI
BO 220708	Base & Wire Assy-Parking Lamp & Direction Indicator-RH	501 thru 504 with DI
BO 220709	Base & Wire Assy-Parking Lamp & Direction Indicator-LH	501 thru 504 with DI
BO 220710	Rim-Headlamp Lens	500
*HA 220712	Electric Clock Kit	500
*HA 220713	Electric Clock Kit	501,503
*HA 220714	Kit-Front Fender Top Ornament	500,501,503
F 220720	Handle Assy-Door-Outside	500
BO 220728	Push Button-Door Outside Handle	500
BO 220729	Retainer-Door Outside Handle Push Button Return	500
BO 220730	Speedometer Assy-Miles	500
BO 220731	Speedometer Assy-Kilometer	500
BO 220732	Dial-Speedometer-Kilometer	500
BO 220733	Dial-Speedometer-Miles	500
BO 220734	Bezel-Speedometer	500
BO 220735	Gasket-Speedometer Dial	500
BO 220740	Clock Assy-Mechanical	500
BO 220741	Clock Assy-Electric	500
BO 220742	Dial-Clock	500
BO 220744	Bezel-Clock	500
BO 220745	Knob-Clock	500,501,503
BO 220750	Handle-Door Inside	500 exc CvBro
BO 220752	Knob-Door Lock Release Rod	500
BO 220754	Knob-Clock	501,503
BO 220755	Handle-Door Wing Regulator	500-501 CvBro
BO 220756	Handle-Quarter Wdo Regulator	500 exc CvBro
BO 220757	Handle-Quarter & Door Wdo Regulator	501,503,500 CvBro
BO 220758	Escutcheon-Door & Window Handles	500 exc CvBro
BO 220759	Escutcheon-Quarter Window Reg Handle	501,503,500 CvBro
BO 220760	Escutcheon-Quarter Wdo Regulator Handle	500-501 CvBro with manual wdo reg
BO 220761	Spring-Door Window Hydraulic Regulator	1950 CvBro
BO 220765	Heating Element & Knob Assy-Cigar Lighter	500 exc CvBro
BO 220766	Heating Element & Knob Assy-Cigar Lighter	501,503,500 CvBro
*HA 220775	Cigar Lighter Kit	500 exc CvBro
*HA 220776	Cigar Lighter Kit	501,503,500 CvBro
BO 220780	Instrument Cluster Complete	1950
BO 220787	Stop-Rear License Lamp Wire	501 thru 504
BO 220788	Grommet-Rear License Lamp Wire	501 thru 504
BO 220789	Clinch Ring-Rear License Lamp Wire Grommet	501 thru 504
F 220790	Gauge-Temperature	1950
F 220791	Gauge-Fuel	1950
BO 220792	Dial-Instrument Cluster	1950
BO 220793	Bezel-Instrument Cluster	1950
BO 220794	Gasket-Instrument Cluster Bezel	1950
BO 220795	Mask-Oil & Ampere Signal	1950
BO 220800	Door Assy-Glove Box	500

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 220801	Mounting Panel Assy-Instrument Cluster	500
BO 220802	Door Assy-Glove Box	500
BO 220803	Mounting Panel Assy-Instrument Cluster	500
BO 220804	Door Assy-Glove Box	501,503
BO 220805	Mounting Panel Assy-Instrument Cluster	501,503
BO 220806	Door Assy-Glove Box	501,503
BO 220807	Mounting Panel Assy-Instrument Cluster	501,503
BO 220808	Door Assy-Glove Box	502,504
BO 220809	Mounting Panel Assy-Instrument Cluster	502,504
BO 220810	Door Assy-Glove Box	502,504
BO 220811	Mounting Panel Assy-Instrument Cluster	502,504
BO 220820	Door-Glove Box-Complete	500
BO 220821	Mounting Panel Complete-Instrument Cluster	500
BO 220822	Door-Glove Box-Complete	500
BO 220823	Mounting Panel Complete-Instrument Cluster	500
BO 220824	Door-Glove Box-Complete	501,503
BO 220825	Mounting Panel Complete-Instrument Cluster	501,503
BO 220826	Door-Glove Box-Complete	501,503
BO 220827	Mounting Panel Complete-Instrument Cluster	501,503
BO 220828	Door-Glove Box-Complete	502,504
BO 220829	Mounting Panel Complete-Instrument Cluster	502,504
BO 220830	Door-Glove Box-Complete	502,504
BO 220831	Mounting Panel Complete-Instrument Cluster	502,504
BO 220840	Speedometer Assy-Miles	501 thru 504
BO 220841	Speedometer Assy-Kilometer	501 thru 504
BO 220844	Bezel-Speedometer	501 thru 504
BO 220850	Clock Assy-Mechanical	501,503
BO 220852	Clock Assy-Electric	502,504 Opt 501-503
BO 220858	Knob Assy-Antenna Control	1950
BO 220860	Escutcheon-Antenna Control Knob	1950
C 220863	Support Assy-Instrument Panel	1950
C 220864	Support Assy-Instrument Panel	1950
C 220868	Molding-Radiator Grille Lower	500
BO 220869	Cover-Radiator Grille Lower Molding Joint	500
C 220872	Panel Assy-Instrument Switch-Mounting-RH- Without HDM or SMD	500 LHD
BO 220873	Panel Assy-Instrument Switch-Mounting-LH	500 LHD
BO 220874	Panel Assy-Instrument Switch-Mounting-RH	500 RHD
C 220875	Panel Assy-Instrument Switch-Mounting-LH	500 RHD
C 220876	Panel Assy-Instrument Switch-Mounting-RH- Without HDM or SMD	501-503 LHD
BO 220877	Panel Assy-Instrument Switch-Mounting-LB	501-503 LHD
BO 220878	Panel Assy-Instrument Switch-Mounting-RH	501-503 RHD
C 220879	Panel Assy-Instrument Switch-Mounting-LH	501-503 RHD
C 220880	Panel Assy-Instrument Switch-Mounting-RH- Without HDM or SMD	502-504 LHD
BO 220881	Panel Assy-Instrument Switch-Mounting-LH	502-504 LHD
BO 220882	Panel Assy-Instrument Switch-Mounting-RH	502-504 RHD
C 220883	Panel Assy-Instrument Switch-Mounting-LH	502-504 RHD
C 220884	Panel Assy-Instrument Switch-Mounting-RH-With HDM	500 LHD
C 220886	Panel Assy-Instrument Switch-Mounting-LH-With HDM	501-503 LHD
C 220888	Panel Assy-Instrument Switch-Mounting-RH-With HDM	502-504 LHD
C 220890	Molding-Door Window Finish-RH	500 Sedan
C 220891	Molding-Door Window Finish-LH	500 Sedan
C 220896	Molding-Rear Door Window Finish-RH	500 Sedan
C 220897	Molding-Rear Door Window Finish-LH	500 Sedan
C 220902	Molding-Door Window Finish-RH	500 Bro-Cpes
C 220903	Molding-Door Window Finish-LH	500 Bro-Cpes
C 220908	Molding-Quarter Window Finish-RH	500 Sedan
C 220909	Molding-Quarter Window Finish-LH	500 Sedan
C 220914	Molding-Quarter Window Finish-RH	500 Bro
C 220915	Molding-Quarter Window Finish-LH	500 Bro
C 220920	Molding-Quarter Window Finish-RH	500 BsCpe-ClubCpe
C 220921	Molding-Quarter Window Finish-LH	500 BsCpe-ClubCpe
*HA 220940	Fog Lamp Kit	1950
BO 220941	Bracket-Fog Lamp Switch	1950
BO 220943	Spacer-Fog Lamp Switch	1950
TC 220946	Trim Panel Assy-Rear Seat Back	1950 ClubCpe
TC 220948	Trim Panel-Rear Seat Back	1950 Bro-Sed
BO 221067	Bolt-Front Door Outside Handle Lock Actuating	500
221068	Bolt-Rear Door Outside Handle Lock Actuating	500 Sedan
BO 221069	Pin-Door Outside Handle Push Button Stop	500
C 221100	Molding-Windshield Finish-Upper-RH	501,503
C 221101	Molding-Windshield Finish-Upper-LH	501,503

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 221102	Molding-Windshield Finish-Upper-RH	502,504
C 221103	Molding-Windshield Finish-Upper-LH	502,504
C 221104	Molding-Windshield Finish-Upper-RH	500
C 221105	Molding-Windshield Finish-Upper-LH	500
C 221110	Molding-Windshield Finish-Lower-RH	501,503
C 221111	Molding-Windshield Finish-Lower-LB	501,503
C 221112	Molding-Windshield Finish-Lower-RH	502,504
C 221113	Molding-Windshield Finish-Lower-LH	502,504
C 221114	Molding-Windshield Finish-Lower-RH	500
C 221115	Molding-Windshield Finish-Lower-LH	500
BO 221121	Cover-Windshield Finish Mldg Lower Joint	501,503
BO 221123	Cover-Windshield Finish Mldg Lower Joint	502,504
BO 221125	Cover-Windshield Finish Mldg Lower Joint	500
C 221160	Molding-Quarter Window Finish-RH	501-503 Sedan
C 221161	Molding-Quarter Window Finish-LH	501-503 Sedan
C 221162	Molding-Quarter Window Finish-RH	502-504 Sedan
C 221163	Molding-Quarter Window Finish-LH	502-504 Sedan
C 221190	Molding & W/Strip Assy-Front Door Window-RH	501-503 Sedan
C 221191	Molding & W/Strip Assy-Front Door Window-LH	501-503 Sedan
C 221192	Molding & W/Strip Assy-Front Door Window-RH	502-504 Sedan
C 221193	Molding & W/Strip Assy-FrontDoor Window-LH	502-504 Sedan
C 221200	Mldg &W/Strip Assy-Rear Door Window Finish-RH	501-503 Sedan
C 221201	Mldg&W/Strip Assy-Rear Door Window Finish-LH	501-503 Sedan
C 221202	Mldg& W/Strip Assy-Rear Door Window Finish-RH	502-504 Sedan
C 221203	Mldg& W/Strip Assy-Rear Door Window Finish-LH	502-504 Sedan
C 221210	Molding & Weatherstrip Assy-Door Window Finish-RH	501-503 Bro-Cpes
C 221211	Molding & Weatherstrip Assy-Door Window Finish-LH	501-503 Bro-Cpes
C 221212	Molding & Weatherstrip Assy-Door Window Finish-RH	502-504 Bro-Cpes
C 221213	Molding & Weatherstrip Assy-Door Window Finish-LH	502-504 Bro-Cpes
C 221220	Molding & Weatherstrip-Quarter Window Finish-RH	501-503 Bro
C 221221	Molding & Weatherstrip-Quarter Window Finish-LH	501-503 Bro
C 221222	Molding & Weatherstrip-Quarter Window Finish-RH	502-504 Bro
C 221223	Molding & Weatherstrip-Quarter Window Finish-LH	502-504 Bro
C 221230	Molding & Weatherstrip Assy-Quarter Window Finish-RH	501-503 BsCpe-ClubCpe
C 221231	Molding & Weatherstrip Assy-Quarter Window Finish-LH	501-503 BsCpe-ClubCpe
C 221232	Molding & Weatherstrip Assy-Quarter Window Finish	502-504 BsCpe-ClubCpe
C 221233	Molding & Weatherstrip Assy-Quarter Window Finish	502-504 BsCpe-ClubCpe
C 221240	Scuff Plate-Door-RH	500 exc Sedan
C 221241	Scuff Plate-Door-LH	500 exc Sedan
C 221242	Scuff Plate-Front Door-RH	500 Sedan
C 221243	Scuff Plate-Front Door-LH	500 Sedan
C 221244	Scuff Plate-Rear Door-RH	500 Sedan
C 221245	Scuff Plate-Rear Door-LH	500 Sedan.
BO 221254	Frame Assy-Front Door Wing Glass-RH	500 exc CvBro
BO 221255	Frame Assy-Front Door Wing Glass-LH	500 exc CvBro
BO 221256	Glass & Frame Assy-Front Door Wing-RH	500 exc CvBro
BO 221257	Glass & Frame Assy-Front Door Wing-LH	500 exc CvBro
BO 221264	Center Bar & Weatherstrip Assy-Front Door Window-RH	500 exc CvBro
BO 221265	Center Bar & Weatherstrip Assy-Front Door Window-LH	500 exc CvBro
BO 221266	Wing Complete-Front Door-RH	500 exc CvBro
BO 221267	Wing Complete-Front Door-LH	500 exc CvBro
C 221270	Mat & Pad Assy-Rear Seat Floor	500 Bro-Sed-BsCpe
C 221272	Mat & Pad Assy-Rear Seat Floor	500 ClubCpe
C 221274	Mat & Pad Assy-Rear Seat Floor	500 CvBro
C 221278	Mat-Rear Seat Tray Floor Board	500 BsCpe
BO 221280	Valance-Door-RH	501 CvBro
BO 221281	Valance-Door-LH	501 CvBro
BO 221282	Valance-Door-RH	500 CvBro
BO 221283	Valance-Door-LH	500 CvBro
C 221286	Trim Panel & Silencer Assy-Dash-RH	500
C 221287	Trim Panel & Silencer Assy-Dash-LH	500 exc CvBro
C 221288	Trim Panel & Silencer Assy-Dash-RH	500
C 221289	Trim Panel & Silencer Assy-Dash-LH	500
C 221300	Trim Panel & Silencer Assy-Dash-RH	501 thru 504
C 221301	Trim Panel & Silencer Assy-Dash-LH	501 thru 504
C 221310	Trim Panel & Silencer Assy-Dash-RH	501 thru 504
C 221311	Trim Panel & Silencer Assy-Dash-LH	501 thru 504
C 221316	Trim Panel & Silencer Assy-Cowl-RH	501 thru 504 exc CvBro
C 221317	Trim Panel & Silencer Assy-Cowl-LH	501 thru 504 exc CvBro
C 221318	Trim Panel & Silencer Assy-Cowl-RH	501 thru 504

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 221319	Trim Panel & Silencer Assy-Cowl-LH	501 thru 504
C 221320	Trim Panel & Silencer Assy-Cowl-RH	501,503
C 221321	Trim Panel & Silencer Assy-Cowl-LH	501,503
C 221322	Trim Panel & Silencer Assy-Cowl-RH	500
C 221323	Trim Panel & Silencer Assy-Cowl-LH	500
C 221324	Trim Panel & Silencer Assy-Cowl-RH	500
C 221325	Trim Panel & Silencer Assy-Cowl-LH	500
C 221340	Weatherstrip-Rear Window	501 thru 504 Cpes
C 221341	Trim Panel & Silencer Assy-Dash	500 CvBro
C 221350	Mat & Pad Assy-Front Floor-With Cloth Trim	501,503
C 221351	Mat & Pad Assy-Front Floor-With Tan or Brown Cloth; Brown or Red Leather Trim	502-504 exc CvBro
C 221352	Mat & Pad Assy-Front Floor-With Gray Cloth or Blue Leather Trim	502-504 exc CvBro
C 221360	Mat & Pad Assy-Front Floor-With Cloth Trim	501,503
C 221361	Mat & Pad Assy-Front Floor-With Tan or Brown Cloth; Brown or Red Leather Trim	502-504 exc CvBro
C 221362	Mat & Pad Assy-Front Floor-With Gray Cloth or Blue Leather Trim	502-504 exc CvBro
C 221370	Mat & Pad Assy-Rear Floor	501 CvBro
C 221371	Mat & Pad Assy-Rear Floor	502-504 CvBro
BO 221381	Inside Visor Assy-Hinge Type	500 exc CvBro
BO 221382	Inside Visor Assy-Hinge Type	500 exc CvBro
BO 221395	Inside Visor Assy-Hinge Type	501 Bro
BO 221396	Inside Visor Assy-Hinge Type	501-503 Sed-Cpes
BO 221397	Inside Visor Assy-Hinge Type	500-501-503 exc CvBro
BO 221398	Inside Visor Assy-Hinge Type	500-501-503 exc CvBro
BO 221410	Inside Visor Assy-Swivel Type	502-504 Sedan
BO 221411	Inside Visor Assy-Swivel Type	502-504 exc CvBro
BO 221412	Inside Visor Assy-Swivel Type	502-504 exc CvBro
BO 221413	Inside Visor Assy-Swivel Type	502-504 exc CvBro
BO 221414	Inside Visor Assy-Swivel Type	502-504 ClubCpe
BO 221426	Cover-Door Pull-to Strap Ends	500
BO 221427	Cover-Door Pull-to Strap Ends	500
BO 221430	Arm Rest Assy-Qtr & Door-RH	501-503 exc CvBro,500 All
BO 221431	Arm Rest Assy-Qtr & Door-LH	501-503 exc CvBro,500 All
BO 221432	Arm Rest Assy-Qtr & Door-RH	500 exc CvBro
BO 221433	Arm Rest Assy-Qtr & Door-LH	500 exc CvBro
BO 221434	Arm Rest Assy-Qtr & Door-RH	1950 exc CvBro
BO 221435	Arm Rest Assy-Qtr & Door-LH	1950 exc CvBro
BO 221436	Arm Rest Assy-Qtr & Door-RH	501-503 Bro,502-504 ClubCpe
BO 221437	Arm Rest Assy-Qtr & Door-LH	501-503 Bro,502-504 ClubCpe
BO 221438	Arm Rest Assy-Qtr & Door-RH	1950
BO 221439	Arm Rest Assy-Qtr & Door-LH	1950
BO 221440	Arm Rest Assy-Qtr & Door-RH	1950 exc 501-502-504 CvBro
BO 221441	Arm Rest Assy-Qtr & Door-LH	1950 exc 501-502-504 CvBro
BO 221442	Arm Rest Assy-Qtr & Door-RH	502-504 exc CvBro
BO 221443	Arm Rest Assy-Qtr & Door-LH	502-504 exc CvBro
BO 221444	Arm Rest Assy-Qtr & Door-RH	500,501,503,502-504 CvBro
BO 221445	Arm Rest Assy-Qtr & Door-LH	500,501,503,502-504 CvBro
BO 221446	Arm Rest Assy-Qtr & Door-RH	500 exc CvBro
BO 221447	Arm Rest Assy-Qtr & Door-LH	500 exc CvBro
BO 221460	Arm Rest Assy-Rear Door-RH	500-501-503 Sedan
BO 221461	Arm Rest Assy-Rear Door-LH	500-501-503 Sedan
BO 221462	Arm Rest Assy-Rear Door-RH	502-504 Sedan
BO 221463	Arm Rest Assy-Rear Door-LH	502-504 Sedan
BO 221464	Arm Rest Assy-Rear Door-RH	1950 Sedan
BO 221465	Arm Rest Assy-Rear Door-LH	1950 Sedan
BO 221466	Arm Rest Assy-Rear Door-RH	1950 Sedan
BO 221467	Arm Rest Assy-Rear Door-LH	1950 Sedan
BO 221468	Arm Rest Assy-Rear Door-RH	500 Sedan
BO 221469	Arm Rest Assy-Rear Door-LH	500 Sedan
BO 221470	Arm Rest Assy-Rear Door-RH	500-501-503 Sedan
BO 221471	Arm Rest Assy-Rear Door-LH	500-501-503 Sedan
BO 221472	Arm Rest Assy-Rear Door-RH	500 Sedan
BO 221473	Arm Rest Assy-Rear Door-LH	500 Sedan
BO 221474	Arm Rest Assy-Rear Door-RH	1950 Sedan
BO 221475	Arm Rest Assy-Rear Door-LB	1950 Sedan
A 221490	Finish Panel Assy-Instrument	500
TC 221499	Top Material-Black	1950 CvBro
C 221500	Seat Cloth-Gray Bedford Cord	500 exc CvBro
C 221502	Headlining-Cloth-Gray	500-501-503 exc CvBro
C 221504	Seat Cloth-Tan Striped Broadcloth	501-503 exc CvBro
C 221505	Seat Cloth-Gray Checked	501-503 exc CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 221510	Seat Cloth-Gray	502-504 exc CvBro
C 221511	Sidewall Cloth-Gray	502-504 exc CvBro
C 221515	Seat Cloth-Tan	502-504 exc CvBro
C 221516	Seat Cloth-Tan Striped Nylon Cord	502-504 Sedan
C 221517	Headlining Cloth-Tan	1950 exc CvBro
C 221518	Sidewall Cloth-Tan	502-504 exc CvBro
C 221519	Headlining Cloth-Gray	502-504 exc CvBro
C 221520	Carpet	501-503 exc CvBro
C 221521	Carpet-Gray	502-504 exc CvBro
C 221522	Carpet-Tan	502-504 exc CvBro
*C 221526	Panel Assy-Cowl Side-RH	1948 thru 1950 Bro-Sed-Cpes
*C 221527	Panel Assy-Cowl Side-LH	1948 thru 1950 Bro-Sed-Cpes
*C 221528	Panel Assy-Cowl Side-RH	1948 thru 1950 CvBro
*C 221529	Panel Assy-Cowl Side-LH	1948 thru 1950 CvBro
BO 221551	Assist Strap Assy	500 Bro-Sed-ClubCpe
BO 221575	Assist Strap Assy	501-503 Sed-Bro-ClubCpe
BO 221577	Assist Strap Assy	501-503 Bro
BO 221578	Assist Strap Assy	500-501-503 Bro-Sed-ClubCpe
BO 221579	Assist Strap Assy	500-501-503 Bro-Sed-ClubCpe
BO 221601	Strap-Front Door Pull-to	500
BO 221602	Strap-Rear Door Pull-to	500 Sedan
BO 221603	Strap-Front Door Pull-to	500 Bro-Sed-BsCpe-ClubCpe
BO 221604	Strap-Rear Door Pull-to	500 Sedan
BO 221605	Strap-Front Door Pull-to	500 Sed-Bro-Cpes
BO 221606	Strap-Rear Door Pull-to	500 Sedan
BO 221607	Strap-Front Door Pull-to	500
BO 221608	Strap-Rear Door Pull-to	500 Sedan
BO 221609	Strap-Front Door Pull-to	500 Bro-Sed-Cpes
BO 221610	Strap-Rear Door Pull-to	500 Sedan
BO 221611	Strap-Front Door Pull-to	500 Bro-Sed-Cpes
BO 221612	Strap-Rear Door Pull-to	500 Sedan
BO 221613	Strap-Front Door Pull-to	500 Bro-Sed-Cpes
BO 221614	Strap-Rear Door Pull-to	500 Sedan
C 221616	Spring-Rear Seat Cushion	500 ClubCpe
C 221617	Spring-Rear Seat Cushion	500 Bro-Sed
C 221618	Spring-Front Seat Cushion	500 Bro-Cpes
C 221619	Spring-Front Seat Cushion	500 Sed
C 221620	Spring-Rear Seat Back-RH	502-504 Bro-Sed
C 221621	Spring-Rear Seat Back-LH	502-504 Bro-Sed
C 221622	Spring-Rear Seat Back-RH	502-504 ClubCpe
C 221623	Spring-Rear Seat Back-LH	502-504 ClubCpe
C 221624	Spring-Rear Seat Back Center Arm Rest	502-504 Bro-Sed-ClubCpe
C 221627	Rubber Pad-Front Seat Back	502-504 Sedan
C 221628	Rubber Pad-Front Seat Back-RH	502-504 Bro-Cpes
C 221629	Rubber Pad-Front Seat Back-LH	502-504 Bro-Cpes
221634	Trimboard Complete-Front Seat Tray-Side-RH	1950
221635	Trimboard Complete-Front Seat Tray-Side-LH	1950
221636	Trimboard Complete-Fram Sidemember-Front-RH	501 thru 504
221637	Trimboard Complete-Fram Sidemember-Front-LH	501 thru 504
221638	Trimboard Complete-Fram Sidemernber-Rear-RH	1950 Bro-Sed-Cpes
221639	Trimboard Complete-Fram Sidemember-Rear-LH	1950 Bro-Sed-Cpes
221640	Trimboard Complete-Fram Sidemember-Rear-RH	1950 CvBro
221641	Trimboard Complete-Fram Sidemember-Rear-LH	1950 CvBro
221655	Frame &Back-Front Seat Cushion-Less Rubber Pads	500 Sedan
221656	Frame &Back-Front Seat Cushion-Less Rubber Pads	500 Bro-ClubCpe
221657	Frame &Back-Front Seat Cushion-Less Rubber Pads	500 BsCpe
C 221661	Frame &Back-Front Seat Cushion-With Rubber Pads	500 Sedan
C 221662	Frame &Back-Front Seat Cushion-With Rubber Pads	500 Bro-ClubCpe
C 221663	Frame &Back-Front Seat Cushion-With Rubber Pads	500 BsCpe
C 221670	Cushion-Front Seat-Less Rubber Pads	500 Sedan
C 221671	Cushion-Front Seat-Less Rubber Pads	500 Bro-Cpes
C 221672	Cushion-Front Seat-With Rubber Pads	500 Sedan
C 221673	Cushion-Front Seat-With Rubber Pads	500 Bro-Cpes
C 221684	Spring & Trim Assy-Front Seat Back-Less Rubber Pads	500 Sedan
C 221685	Spring & Trim Assy-Front Seat Back-With Rubber Pads	500 Sedan
C 221686	Spring & Trim Assy-Front Seat Back-Less Rubber Pads-RH	500 Bro-Cpes
C 221687	Spring & Trim Assy-Front Seat Back-Less Rubber Pads-LH	500 Bro-Cpes
C 221688	Spring & Trim Assy-Front Seat Back-With Rubber Pads-RH	500 Bro-Cpes
C 221689	Spring & Trim Assy-Front Scat Back-With Rubber Pads-LH	500 Bro-Cpes
TC 221692	Top Material-Tan	1950 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 221694	Binding-Double Fold-Tan	1950 CvBro
C 221700	Cushion Comp-Rear Seat-Less Rubber Pads	500 Bro-Sed
C 221701	Cushion Comp-Rear Seat-Less Rubber Pads	500 ClubCpe
C 221702	Cushion Comp-Rear Seat-With Rubber Pads	500 Bro-Sed
C 221703	Cushion Comp-Rear Seat-With Rubber Pads	500 ClubCpe
C 221712	Spring & Trim Assy-Rear Seat Back	500 Bro-Sed
C 221713	Spring & Trim Assy-Rear Seat Back	500 ClubCpe
C 221720	Frame & Back-Front Seat Cushion-Without Rubber Pads	501-503 Sed
C 221721	Frame & Back-Front Seat Cushion-Without Rubber Pads-LHD	501-503 Sed
C 221722	Frame & Back-Front Seat Cushion-Without Rubber Pads-RHD	501-503 Sed
C 221723	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	501-503 Sed
C 221724	Frame & Back-Front Seat Cushion-Without Rubber Pads-LHD	501-503 Bro
C 221725	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	501-503 Bro
C 221726	Frame & Back-Front Seat Cushion-Without Rubber Pads-RHD	501-503 Bro
C 221727	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	501-503 Bro
C 221728	Frame & Back-Front Seat Cushion-Without Rubber Pads-LHD	501-503 BsCpe
C 221729	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	501-503 BsCpe
C 221730	Frame & Back-Front Seat Cushion-Without Rubber Pads-RHD	501-503 BsCpe
C 221731	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	501-503 BsCpe
C 221732	Frame & Back-Front Seat Cushion-Without Rubber Pads-LHD	501-503 ClubCpe
C 221733	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	501-503 ClubCpe
C 221734	Frame & Back-Front Seat Cushion-Without Rubber Pads-RHD	501-503 ClubCpe
C 221735	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	501-503 ClubCpe
C 221736	Cushion Complete-Front Seat-Less Rubber Pads	501-503 Sed
C 221737	Cushion Complete-Front Seat-Less Rubber Pads	501-503 Bro-Cpes
C 221740	Cushion Complete-Rear Seat	501-503 Bro-Sed
C 221741	Cushion Complete-Rear Seat	501-503 ClubCpe
C 221744	Spring & Trim Assy-Rear Seat Back	501-503 Bro-Sed
C 221745	Spring & Trim Assy-Rear Seat Back	501-503 ClubCpe
C 221790	Frame & Back-Front Seat Cushion-Less Rubber Pads-LHD	502-504 Sed
C 221791	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	502-504 Sed
C 221792	Frame & Back-Front Seat Cushion-Less Rubber Pads-RHD	502-504 Sed
C 221793	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	502-504 Sed
C 221794	Frame & Back-Front Seat Cushion-Less Rubber Pads-LHD	502-504 Bro
C 221795	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	502-504 Bro
C 221796	Frame & Back-Front Seat Cushion-Less Rubber Pads-RHD	502-504 Bro
C 221797	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	502-504 Bro
C 221798	Frame & Back-Front Seat Cushion-Less Rubber Pads-LHD	502-504 BsCpe
C 221799	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	502-504 BsCpe
C 221800	Frame & Back-Front Seat Cushion-Less Rubber Pads-RHD	502-504 BsCpe
C 221801	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	502-504 BsCpe
C 221802	Frame & Back-Front Seat Cushion-Less Rubber Pads-LHD	502-504 ClubCpe
C 221803	Frame & Back-Front Seat Cushion-With Rubber Pads-LHD	502-504 ClubCpe
C 221804	Frame & Back-Front Seat Cushion-Less Rubber Pads-RHD	502-504 ClubCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 221805	Frame & Back-Front Seat Cushion-With Rubber Pads-RHD	502-504 ClubCpe
C 221806	Cushion Complete-Front Seat	502-504 Sed
C 221807	Cushion Complete-Front Seat	502-504 Bro-Cpes
C 221810	Spring & Trim Assy-Front Seat Back-RH-Less Rubber Pad	502-504 Bro-Cpes
C 221811	Spring & Trim Assy-Front Seat Back-LH-Less Rubber Pad	502-504 Bro-Cpes
C 221812	Spring & Trim Assy-Front Seat Back-RH-With Rubber Pad	502-504 Bro-Cpes
C 221813	Spring & Trim Assy-Front Seat Back-LH-With Rubber Pad	502-504 Bro-Cpes
C 221814	Spring & Trim Assy-Front Seat Back-Without Rubber Pads	502-504 Sedan
C 221815	Spring & Trim Assy-Front Seat Back-With Rubber Pads	502-504 Sedan
C 221819	Cushion Complete-Rear Seat	502-504 Bro-Sed
C 221820	Cushion Complete-Rear Seat	502-504 ClubCpe
C 221824	Spring & Trim Assy-Rear Seat Back-RH	502-504 Bro-Sed
C 221825	Spring & Trim Assy-Rear Seat Back-LH	502-504 Bro-Sed
C 221826	Spring & Trim Assy-Rear Seat,Back-RH	502-504 ClubCpe
C 221827	Spring & Trim Assy-Rear Seat Back-LH	502-504 ClubCpe
C 221842	Molding-Door-Upper	501 thru 504 exc Sed
C 221844	Molding-Front Door-Upper	501 thru 504 Sedan
C 221846	Molding-Rear Door-Upper	501 thru 504 Sedan
C 221848	Molding-Rear Fender-Upper-RH	501 thru 504 Bro-Cpes-CvBro
C 221849	Molding-Rear Fender-Upper-LH	501 thru 504 Bro-Cpes-CvBro
C 221850	Molding-Rear Fender-Upper-RH	501 thru 504 Sedan
C 221851	Molding-Rear Fender-Upper-LH	501 thru 504
*C 221880 Pr	Door Assy-Rear-RH	1950 Sedan
*C 221881 Pr	Door Assy-Rear-LH	1950 Sedan
C 221892	Trimboard Comp-Rear Shelf-Cloth Trim	500 Bro-Sed
C 221893	Trimboard Comp-Rear Shelf-Leather Trim	500 Bro-Sed
C 221894	Trimboard Comp-Rear Shelf-Cloth Trim	501 thru 504 Bro-Sed
C 221895	Trimboard Comp-Rear Shelf-Leather Trim..	501 thru 504 Bro-Sed
BO 221906	Suppressor-Radio-Distributor	1900
BO 221907	Battery Cable Assy-Radio-Fuse to Circuit Breaker-LHD	1950
BO 221908	Battery Cable Assy-Radio-Fuse to Circuit Breaker-RHD	1950
*HA 221940	Radio Kit	1950
*HA 221941	Radio Kit-Export	1950
*C 221945	Paint Kit	1950
C 221946	Retainer-Rear Fender Upper Molding-RH	501 thru 504 Bro-Cpes-CvBro
C 221947	Retainer-Rear Fender Upper Molding-LH	501 thru 504 Bro-Cpes-CvBro
C 221948	Retainer-Rear Fender Upper Molding-RH	501 thru 504 Sedan
C 221949	Retainer-Rear Fender Upper Molding-LH	501 thru 504 Sedan
C 221950	Windlace-Gray	1950
C 221951	Windlace	1950
C 221952	Windlace-Gray-Blue	1950
C 221953	Windlace	1950
C 221954	Windlace-Blue Spruce	1950
C 221955	Windlace-Brown	1950
C 221970	Seaming Lace	501-503 exc CvBro
C 221971	Seaming Lace	502-504 exc CvBro
C 221972	Seaming Lace	502-504 exc CvBro
C 221990	Imitation Leather-Sidewall-Blue Spruce	500
C 221991	Imitation Leather-Sidewall-Gray	500
C 221992	Imitation Leather-Sidewall-Brown	1950 exc CvBro
C 221993	Imitation Leather-Gray	500
C 221994	Imitation Leather-Gray	1950
C 221996	Imitation Leather-Sidewall-Blue Spruce	1950 exc CvBro
C 221997	Imitation Leather-Sidewall-Corn	501-504 exc CvBro
C 221998	Imitation Leather-Sidewall-Gray	501-503 Bro, 502-504 exc CvBro
C 222010	Imitation Leather-Headlining-Blue Spruce	1950 exc CvBro
C 222011	Imitation Leather-Headlining-Brown	1950 exc CvBro
C 222012	Imitation Leather-Headlining-Gray	500 exc CvBro
TC 222016	Imitation Leather-Headlining-Gray	500 exc CvBro
C 222020	Seat Leather-Blue Spruce	1950
C 222021	Seat Leather-Brown	1950 exc CvBro
C 222022	Seat Leather-Dark Red	500 CvBro
C 222023	Seat Leather-Blue Spruce	500 exc CvBro
C 222072	Frame & Back Complete-Front Seat Cushion	500 Bro-ClubCpe
BO 222074	Molding-Outer-Radiator Grille Intermediate	1950
BO 222075	Molding-Center-Radiator Grille Intermediate	1950
BO 222076	Molding-Outer-Radiator Grille Upper	1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 222077	Molding-Center-Radiator Grille Upper	1950
C 222094	Retainer-Door Upper Mldg	501 thru 504 exc Sed
C 222096	Retainer-Front Door Upper Mldg	501 thru 504 Sedan
C 222098	Retainer-Rear Door Upper Mldg	501 thru 504 Sedan
BO 222100	Button Assy-Upholstery	500 exc CvBro
BO 222101	Button Assy-Upholstery	502-504 exc CvBro
BO 222102	Button Assy-Upholstery	502-504 exc CvBro
BO 222103	Button Assy-Upholstery	502-504 Bro-Cpes
BO 222104	Button Assy-Upholstery	502-504 Bro-Cpes
222117	Board & Tee Nut Assy-Rear Seat Back Center Arm Rest	502-504 Bro-Sed-,ClubCpe
222132	Arm Rest-Rear Seat Back Center-Cloth Trim	502-504 Bro-Sed-ClubCpe
222133	Arm Rest-Rear Seat Back Center-Leather Trim	502-504 Bro-Sed-ClubCpe
BO 222139	Bracket-Hood Lock Control	500
222141	Support-Hood Lock Control Bracket-RHD	501 thru 504
BO 222147	Name Plate-Rear Compt Door	502,504
BO 222148	Protector-Rear Compt Door Name Plate	502,504
BO 222149	Clip-Rear Compt Door Name Plate Retaining	502,504
C 222151	Cover Assy-Transmission Floor Opening-LHD	501 thru 504
222156	Cover Assy-Transmission Floor Opening-RHD	501 thru 504
*C 222161	Door Assy-Rear Compt	482-484-492-494-502-504 Bro-Sed
*C 222162	Door Assy-Rear Compt	482-484-492-494-502-504 BsCpe-ClubCpe-CvBro
*C 222163	Door Assy-Rear Compt	481-483-491-493-500-501-503 Bro-Sed
*C 222164	Door Assy-Rear Compt	481-483-491-493-500-501-503 BsCpe-ClubCpe-CvCpe
C 222165	Frame & Back Assy-Front Seat Cushion	500 Sedan
C 222166	Back Assy-Front Seat	500 Sedan
C 222167	Frame Assy-Front Seat Cushion	500 exc Sedan
C 222168	Trimboard Complete-Front Seat Foot Rest End-RH	501 thru 504 Sed
C 222169	Trimboard Complete-Front Seat Foot Rest End-LH	501 thru 504 Sed
222182	Trimboard Complete-Front Sidemember-Front-RH	500
222183	Trimboard Complete-Front Sidemember-Front-LH	500
C 222270	Valance-Front Seat Back-RH	502-504 Bro-ClubCpe-CvBro
C 222271	Valance-Front Seat Back-LH	502-504 Bro-ClubCpe-CvBro
C 222272	Valance-Front Seat Back	502-504 Sedan
BO 222282	Valance-Center Pillar	502-504 Sedan
BZ 222286	Name Plate-RH-Front Fender Side-"Commodore 6"	502
BZ 222287	Name Plate-LH-Front Fender Side-"Commodore 6"	502
BZ 222288	Name Plate-RH-Front Fender Side-"Commodore 8"	504
BZ 222289	Name Plate-LH-Front Fender Side-"Commodore 8"	504
C 222292	Pad & Protector Assy-Front Seat Cushion	501-503 exc CvBro
BO 222298	Trimboard-Front Seat Footrest End	501 thru 504 Sed
TC 222308	Trimboard-Front Door Pocket	502-504 Sedan
TC 222310	Trimboard-Rear Door Pocket	502-504 Sedan
C 222376	Trimboard & Trim Assy-Front Door Pocket-RH	502-504 Sed
C 222377	Trimboard & Trim Assy-Front Door Pocket-LH	502-504 Sed
C 222378	Trimboard & Trim Assy-Rear Door Pocket-RH	502-504 Sed
C 222379	Trimboard & Trim Assy-Rear Door Pocket-LH	502-504 Sed
C 222394	Trimboard Complete-Door Pocket-RH	502-504 Bro-Cpes
C 222395	Trimboard Complete-Door Pocket-LH	502-504 Bro-Cpes
C 222402	Silencer-Rear Shelf Panel	1950 Bro-Sed
C 222403	Seal-Rear Shelf to Roof Panel	1950 Bro-Sed
TC 222409	Trimboard-Quarter Pocket	502-504 ClubCpe
C 222452	Silencer-Front Floor-RH-LHD	500
C 222453	Silencer-Front Floor-LH-LHD	500
C 222454	Silencer-Front Floor-RH-RHD	500
C 222455	Silencer-Front Floor-LH-RHD	500
C 222470	Silencer & Insulator Assy-Roof	1950 Bro-Sed-Cpes
C 222476	Trimboard-Rear Compt Floor to Rear Seat Tray	500 BsCpe
C 222480	Bow #7-Roof	1950 Sed
C 222481	Bow #7-Roof	1950 Bro
C 222482	Bow #3-Roof	1950 BsCpe-C1Cpe
C 222483	Bow #6-Roof	1950 BsCpe-C1Cpe
222490	Carpet-Rear Floor	502-504 Bro-Sed
222491	Carpet-Rear Floor	502-504 C1Cpe
222538	Carpet-Rear Seat Floor	502-504 CvBro
BO 222622	Ornament-Rear Fender-RH	501 thru 504
BO 222623	Ornament-Rear Fender-LH	501 thru 504
BO 222624	Molding-Rear Fender Ornament-RH	501 thru 504
BO 222625	Molding-Rear Fender Ornament-LH	501 thru 504
BO 222628	Retainer-Rear Fender Ornament Molding	501 thru 504
C 222698	Trimboard Complete-Quarter Pocket-RH-Tan Cloth	502-504 ClubCpe
C 222699	Trimboard Complete-Quarter Pocket-LH-Tan Cloth	502-504 ClubCpe
C 222706	Trimboard Complete-Rear Shelf-Cloth Trim	501-503 BsCpe

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

373

Part No.	Name	Models
C 222707	Trimboard Complete-Rear Shelf	501 thru 504 BsCpe With Lea. Trim, 502-504 BsCpe With Lea. Trim
222708	Trimboard Complete-Rear Shelf-Cloth Trim	501-503 ClubCpe
C 222709	Trimboard Complete-Rear Shelf	501 thru 504 ClubCpe With Lea. Trim, 502-504 ClubCpe With Cloth Trim
C 222734	Trimboard Complete-Rear Shelf-Cloth Trim	500 ClubCpe
C 222735	Trimboard Complete-Rear Shelf-Lea Trim	500 ClubCpe
C 222736	Trimboard Complete-Rear Shelf-Cloth Trim	500 BsCpe
C 222737	Trimboard Complete-Rear Shelf-Lea Trim	500 BsCpe
C 222742	Covering Assy-Rear Compt Floor	500-501-503 Bro-Sed
C 222743	Covering Assy-Rear Compt Floor	500-501-503 ClubCpe
C 222744	Covering Assy-Rear Compt Floor	500-501-503 BsCpe
C 222745	Covering Assy-Rear Compt	500-501 CvBro
C 222778	Trim Retainer & Windhose Assy-Front Pillar- Lower-RH	1950
C 222779	Trim Retainer & Windhose Assy-Front Pillar- Lower-LH	1950
C 222780	Trim Retainer & Windhose Assy-Front Pillar- Lower-RH	1950
C 222781	Trim Retainer & Windhose Assy-Front Pillar- Lower-LH	1950
BZ 222782	Name Plate-RH-Front Fender Side-"Super 6"	501
BZ 222783	Name Plate-LH-Front Fender Side-"Super 6"	501
BZ 222784	Name Plate-RH-Front Fender Side-"Super 8"	503
BZ 222785	Name Plate-LH-Front Fender Side-"Super 8"	503
BO 222787	Welt-Roof Front Finish Panel	500 CvBro
C 222810	Valance-Front Door Window-RH	502-504 Sed
C 222811	Valance-Front Door Window-LH	502-504 Sed
C 222820	Valance-Rear Door Window-RH	502-504 Sed
C 222821	Valance-Rear Door Window-LH	502-504 Sed
C 222830	Valance-Door Window-RH	502-504 exc Sod
C 222831	Valance-Door Window-LH	502-504 exc Sed
C 222840	Valance-Quarter Window-RH	502-504 Sedan
C 222841	Valance-Quarter Window-LH	502-504 Sedan
C 222850	Valance-Quarter Window-RH	502-504 ClubCpe
C 222851	Valance-Quarter Window-LH	502-504 ClubCpe
C 222858	Molding-Front Door Outer Panel- Lower	1950 Sedan,
C 222860	Molding-Door Outer Panel- Lower	1950 Bro-Cpes-CvBro
C 222862	Molding-Rear Door Outer Panel- Lower	1950 Sedan
BO 222864	Molding-Front Fender Panel- Lower-RH	501 thru 504
BO 222865	Molding-Front Fender Panel- Lower-LH	501 thru 504
C 222866	Molding-Rear Fender Panel- Lower-RH	1950 Sedan
C 222867	Molding-Rear Fender Panel- Lower-LH	1950 Sedan
C 222868	Molding-Rear Fender Panel- Lower-RH	1950 Bro-Cpes-CvBro
C 222869	Molding-Rear Fender Panel- Lower-LH	1950 Bro-Cpcs-CvBro
BO 222874	Cardboard Cover-Radio Speaker Hole	500
BO 222875	Cardboard Cover-Radio Speaker Hole	501 thru 504
BO 222878	Ornament-Front Fender Side-RH	501 thru 504
BO 222879	Ornament-Front Fender Side-LH	501 thru 504
C 222887	Support Assy-Rear Seat Back Center Arm Rest	502-504 ClubCpe
C 222920	Trimboard & Trim Assy-Front Door Pocket-RH	502-504 Sedan
C 222921	Trimboard & Trim Assy-Front Door Pocket-LH	502-504 Sedan
C 222922	Trimboard & Trim Assy-Rear Door Pocket-RH	502-504 Sedan
C 222923	Trimboard & Trim Assy-Rear Door Pocket-LH	502-504 Sedan
C 222924	Trimboard-Door Pocket-RH	502-504 Bro-Cpes
C 222925	Trimboard-Door Pocket-LH	502-504 Bro-Cpes
C 222926	Trimboard Complete-Quarter Pocket-RH-Gray Cloth	502-504 ClubCpe
C 222927	Trimboard Complete-Quarter Pocket-LH-Gray Cloth	502-504 ClubCpe
C 222976	Trim Panel & Silencer-Cowl-RH	501,503
C 222977	Trim Panel & Silencer-Cowl-LH	501,503
* A 223004 Pr	Fender Assy-Front-RH	500
* A 223005 Pr	Fender Assy-Front-LH	500
BO 223008	Retainer-Front Fender Panel Lower Mldg	500
BO 223009	Molding-Front Fender Panel- Lower	500
A 223012 Pr	Front Extension Assy-Front Fender-RH	500
A 223013 Pr	Front Extension Assy-Front Fender-LH	500
A 223032 Pr	Reinforcement Assy-Front Fender-Side Dust Shield-RH	500
A 223033 Pr	Reinforcement Assy-Front Fender-Side Dust Shield-LH	500
BO 223040	Visor Assy-Inside	500 CvBro
BO 223041	Visor Assy-Inside	501-502-504. CvBro
223043	Seal-Front Fender Side Dust Shield-Rear	500
BO 223055	Crest-Hood	500
BO 223062	Door-Parking Lamp-RH	500
BO 223063	Door-Parking Lamp-LH	500

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 223064	Parking Lamp Assy-RH	500 Less DI
BO 223065	Parking Lamp Assy-LH	500 Less DI
BO 223066	Parking Lamp & Direction Indicator Assy-RH	500 With DI
BO 223067	Parking Lamp & Direction Indicator Assy-LH	500 With DI
*A 223072	Side Dust Shield Assy-Front Fender-RH	500 LHD
*A 223073	Side Dust Shield Assy-Front Fender-LH	500 LHD
*A 223074	Side Dust Shield Assy-Front Fender-RH	500 RHD
*A 223075	Side Dust Shield Assy-Front Fender-LH	500 RHD
BZ 223076	Seal Assy-Front Fender Side Dust Shield	
	Steering Spindle Arm-RH	500
BZ 223077	Seal Assy-Front Fender Side Dust Shield	
	Steering Spindle Arm-LH	500
C 223084	Stone Guard & Flap Assy-Front Fender-RH	500
C 223085	Stone Guard & Flap Assy-Front Fender-LH	500
*C 223091	Dash Panel Assy	500
BO 223112	Molding-Front Fender-Lower-RH	500
BO 223113	Molding-Front Fender-Lower-LH	500
BO 223114	Molding-Front Fender-Upper-RH	1948-1949, 500
BO 223115	Molding-Front Fender-Upper-LH	1948, 1949, 500
BO 223116	Retainer-Front Fender Upper Mldg	1948, 1949, 500
*HA 223118	Ornamentation Kit-Body Side Panel	1948-1949-500 Sedan
*HA 223119	Ornamentation Kit-Body Side Panel	1948-1949-500 Bro-Cpes-CvBro
BO 223020	Bracket-Steering Column-LHD	500
BO 223135	Access Door-Cowl Ventilator Air Duct	500
BO 223139	Silencer-Cowl Ventilator Air Duct to Dash	500
C 223151	Air Duct Assy-Cowl Ventilator	500
C 223165	Pillar Assy-Front-LH	502-504 exc CvBro
C 223166	Pillar Assy-Front-RH	502-504 RHD
C 223167	Pillar Assy-Front-LH	502-504 CvBro
BO 223170	Bracket-Steering Column-RHD	500
BO 223184	Escutcheon-Instrument Panel Steering Column LHD	500
BO 223186	Escutcheon-Instrument Panel Steering Column RHD	500
BO 223187	Escutcheon-Instrument Panel Steering Column	501 thru 504
C 223220	Sidemember-Frame-Outer-Front-RH	500
C 223221	Sidemember-Frame-Outer-Front-LH	500
C 223226	Sidemember Assy-Frame-Inner Front-RH	500 exc CvBro
C 223227	Sidemember Assy-Frame-Inner Front-LH	500 exc CvBro
C 223228	Sidemember Assy-Frame-Inner Front-RH	500 CvBro
C 223229	Sidemember Assy-Frame-Inner Front-LH	500 CvBro
BZ 223236	Bracket Assy-Frame #3 Crossmember-RH	500
BZ 223237	Bracket Assy-Frame 03 Crossmember-LII	500
BZ 223239	Cover-Toeboard Riser Pedal-Hole-RHD	500
C 223244	Riser Assy-Toeboard-RH-LHD	500
C 223245	Riser Assy-Toeboard-LH-LHD	500
C 223246	Riser Assy-Toeboard-RH-RHD	500
C 223247	Riser Assy-Toeboard-LH-RHD	500
BZ 223248	Cover-Frame Sidemember Front End-RH	500
BZ 223249	Cover-Frame Sidemember Front End-LH	500
C 223253	Cover Assy-Transmission Floor Opening-LHD	500
C 223254	Cover Assy-Transmission Floor Opening-RHD	500
*A 223270 Pr	Rocker Panel Assy-RH	500 Sedan
*A 223271 Pr	Rocker Panel Assy-LH	500 Sedan
*A 223272 Pr	Rocker Panel Assy-RH	500 exc Sedan
*A 223273 Pr	Rocker Panel Assy-LH	500 exc Sedan
C 223288	Molding-Rocker Panel-RH	500
C 223289	Molding-Rocker Panel-LH	500
BO 223292	Bolt-Rocker Panel Molding	500
*A 223301 Pr	Panel Assy-Hood	500
C 223302	Extension-Rear Shelf Panel-Rear	500 Bro-Sed
C 223303	Trim Panel & Silencer Assy-Dash-Lower	500 Less Weather Control
BO 223308	Control Assy-Hood Lock	500
BO 223309	Wire & Knob Assy-Hood Lock Control	500
*HA 223315	Arm Rest Kit-F Door & Qtr	500 exc CvBro
*HA 223316	Arm Rest Kit-Rear Door	500 Sedan
*HA 223317	Arm Rest Kit-Door	500 CvBro
223330	Frame & Back Complete-Front Seat Cushion	500 Sedan
223331	Frame & Back Complete-Front Seat Cushion	500 Bro-ClubCpe
223332	Frame & Back Complete-Front Seat Cushion	500 BsCpe
223333	Frame & Back Complete-Front Seat Cushion	500 CvBro
223334	Frame & Back Complete-Front Scat Cushion-LHD	501-503 Sed
223335	Frame & Back Complete-Front Seat Cushion-LHD	501-503 Bro
223336	Frame & Back Complete-Front Seat Cushion-LHD	501 thru 504 BsCpe
223337	Frame & Back Complete-Front Seat Cushion-LHD	501-503 ClubCpe
223338	Frame & Back Complete-Front Seat Cushion-LHD	502-504 Sedan

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
	223339 Frame & Back Complete-Front Seat Cushion-LHD	502-504 ClubCpe
C	223341 Frame & Back Complete-Front Seat Cushion	501 CvBro
C	223342 Frame & Back Complete-Front Seat Cushion	502-504 CvBro
C	223345 Frame & Back Complete-Front Seat Cushion-RHD	501-503 Scd
C	223346 Frame & Back Complete-Front Seat Cushion-RHD	501-503 Bro
C	223347 Frame & Back Complete-Front Seat Cushion-RHD	501 thru 504 BsCpe
C	223348 Frame & Back Complete-Front Seat Cushion-RHD	501-503 ClubCpe
C	223349 Frame & Back Complete-Front Seat Cushion-RHD	502-504 Sed
C	223350 Frame & Back Complete-Front Seat Cushion-RHD	502-504 ClubCpe
C	223355 Cushion Complete-Front Seat-Less Rubber Pads	500 Sedan
C	223356 Cushion Complete-Front Seat-Less Rubber Pads	500 Bro-Cpes
C	223357 Cushion Complete-Front Seat-With Rubber Pads	500 Sedan
C	223358 Cushion Complete-Front Seat-With Rubber Pads	500 Bro-Cpes
C	223360 Trim Assy-Front Scat Side Panel Extension-RH	501 thru 504 Bro
C	223361 Trim Assy-Front Seat Side Panel Extension-LH	501 thru 504 Bro
C	223362 Trim Assy-Front Scat Side Panel Extension-RH	500 Bro,1950 Cpes-CvBro
C	223363 Trim Assy-Front Seat Side Panel Extension-LH	500 Bro,1950 Cnes-CvBro
TC	223371 Carpet Assy-Front Floor	502-504 CvBro
BO	223375 Robe Hanger Assy	501-503 Sedan
BO	223376 Robe Hanger Assy	501-503 Sedan
BO	223377 Robe Hanger Assy	501-503 Sedan
BO	223378 Robe Hanger Assy	501-503 Bro
BO	223379 Robe Hanger Assy	501-503 ClubCpe
BO	223380 Robe Hanger Assy	501-503 Bro-ClubCpe-CvBro
BO	223381 Robe Hanger Assy	501-503 Bro-ClubCpe
C	223390 Trim Panel & Silencer Assy-Cowl-RH	500 exc CvBro
C	223391 Trim Panel & Silencer Assy-Cowl-LH	500 exc CvBro
C	223392 Trim Panel & Silencer Assy-Cowl-RH	500 exc CvBro
C	223393 Trim Panel & Silencer Assy-Cowl-LH	500 exc CvBro
C	223394 Trim Panel & Silencer Assy-Cowl-RH	500
C	223395 Trim Panel & Silencer Assy-Cowl-LH	500
C	223401 Robe Hanger Assy	502-504 Sedan
C	223402 Robe Hanger Assy	502-504 Sedan
BO	223404 Robe Hanger Assy	502-504 ClubCpe
BO	223405 Robe Hanger Assy	502-504 Bro-ClubCpe
BO	223406 Robe Hanger Assy	502-504 Bro-ClubCpe-CvBro
	223425 Cushion Complete-Rear Seat-Less Rubber Pad	500 Bro-Sed
	223426 Cushion Complete-Rear Seat-With Rubber Pad	500 Bro-Sed
	223427 Cushion Complete-Rear Seat-Less Rubber Pad	500 ClubCpe
	223428 Cushion Complete-Rear Seat-With Rubber Pad	500 ClubCpe
BO	223500 Base-Arm Rest-RH	1950
BO	223501 Base-Arm Rest-LH	1950
BO	223502 Base-Arm Rest-RH	502-504 exc CvBro
BO	223503 Base-Arm Rest-LH	502-504 exc CvBro
BO	223520 Base-Rear Door Arm Rest-RH	1950 Sedan
BO	223521 Base-Rear Door Arm Rest-LH	1950 Sedan
BO	223522 Base-Rear Door Arm Rest-RH	502-504 Sedan
BO	223523 Base-Rear Door Arm Rest-LH	502-504 Sedan
C	223533 Carpet Assy-Front Floor	502-504 CvBro
C	223537 Carpet-Rear Seat Floor	502-504 CvBro
C	223538 Carpet-Rear Seat Floor	502-504 CvBro
TC	223644 Trim & Windlace Comp-Center Pillar-RH Leather-Trim	500-501-503 Sed
TC	223645 Trim & Windlace Comp-Center Pillar-LH Leather-Trim	500-501-503 Sed
BO	223700 Dial Scale-Radio	1950
BO	223701 Retaining Brkt-Radio Dial Scale	1950
BO	223702 Escutcheon-Radio	1950
BO	223703 Spring-Radio Cross Arm	1950
BO	223704 Tension Spring-Radio Pointer Pivot	1950
BO	223705 Tension Spring-Radio Pointer	1950
BO	223706 Tension Spring-Radio Cross Arm	1950
BO	223707 Washer-Radio Pointer Tension Spring	1950
BO	223708 Insulating Bushing-Radio Iron Core	1950
BO	223709 Insulating Bushing-Radio Cross Arm	1950
BO	223710 Escutcheon Assy-Radio	1950
BO	223711 Light Socket & Wire Assy-Radio Dial	1950
BO	223712 Cross Arm & Bushing Assy-Radio	1950
BO	223713 Drag Link & Stud Assy-Radio Pointer	1950
BO	223714 Support Brkt Assy-Radio Pointer	1950
BO	223715 Pointer to Brkt Assy-Radio Dial	1950
BO	223716 Choke Coil-Radio Motor Noise	1950
BO	223717 Choke Coil-Radio Motor Noise	1950
BO	223718 Transformer-2nd Int Frequency-Radio	1950
BO	223719 Transformer-1st Int Frequency-Radio	1950
BO	223720 Coil Assy-Radio Tuner Unit	1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 223721	Series Coil Assy-Radio Oscillator	1950
BO 223722	Shunt Coil Assy-Radio Oscillator	1950
BO 223723	Condenser-01 Mid 500 V-Radio	1950
BO 223724	Condenser-004 Mfd 500 V-Radio	1950
BO 223725	Condenser-0082 Mfd 1600V-Radio	1950
BO 223726	Condenser-Antenna Trimmer-Radio	1950
BO 223727	Condenser-Converter Trimmer-Radio	1950
BO 223728	Condenser-Oscillator Trimmer-Radio	1950
BO 223730	Resistor-2 Watt-12K OHM-Insulated-Radio	1950
BO 223731	Resistor-1/2 Watt-820 OHM-Insulated-Radio	1950
BO 223732	Resistor-1/2 Watt-10K OHM-Insulated-Radio	1950
BO 223733	Resistor-1/2 Watt-56 MEGOHM-Insulated-Radio	1950
BO 223734	Resistor-Sensitivity Cord-Radio	1950
BO 223735	Cable-Radio Speaker	1950
BO 223736	Battery Cable-Fuse to Set-Radio	1950
BO 223737	Cable-Two Conductor-Radio	1950
BO 223738	Capacitor Plate-Radio	1950
BO 223739	Ground Plate-Radio	1950
BO 223740	Top Ground Plate-Radio	1950
BO 223741	Capacitor Plate-Radio	1950
BO 223742	Socket-Radio Octal Tube	1950
BO 223743	Socket-Radio Octal Tube	1950
BO 223744	Insulation Strip-Radio	1950
BO 223745	Washer-Vibration Cushion-Radio	1950
BO 223746	Transformer-Output-Radio	1950
BO 223747	Transformer-Power-Radio	1950
BO 223748	Iron Core-Radio	1950
BO 223749	Vibrator-Radio	1950
BO 223750	Lock-Radio Tuner Cam	1950
BO 223751	Retaining Pin-Radio Tuner Release Bar	1950
BO 223752	Guide Plate-Radio Tuner-Front	1950
BO 223753	Set Screw-Radio Tuner	1950
BO 223754	Drive Shaft-Radio Tuner	1950
BO 223756	Spring-Radio Tuner Plunger	1950
BO 223757	Spring-Radio Tuner Release Bar	1950
BO 223759	Spring-Radio Tuner Anti-Rattle	1950
BO 223760	Spring-Radio Tuner Cam Lock	1950
BO 223761	Spring-Radio Tuner Gear Tension	1950
BO 223762	Washer-Radio Tuning Shaft	1950
BO 223764	Washer-Radio Tuner-Fishpaper	1950
BO 223765	Washer-Radio Tuner Worm Gear Tension	1950
BO 223766	Screw-Radio Tuner Rivet	1950
BO 223767	Screw-Radio Tuner Worm Retaining	1950
BO 223768	Ball-Radio Tuner-Steel	1950
BO 223769	Ring-Radio Tuner Retaining	1950
BO 223770	Gear & Bushing Assy-Radio Tuner	1950
BO 223771	Treadle Assy-Radio Tuner	1950
BO 223772	Plunger & Cam Assy-Radio Tuner	1950
BO 223773	Release Bar & Cam Assy-Radio Tuner	1950
BO 223774	Bracket & Roller Assy-Radio Tuner Clutch Release	1950
BO 223775	Worms Gear & Bracket Assy-Radio Tuner	1950
BO 223776	Plate & Shaft Assy-Radio Tuner-Front	1950
BO 223777	Screw & Knob Assy-Radio Tuner Plunger	1950
BO 223778	Clutch Plate & Washer-Radio Tuner	1950
BO 223779	Ring-Radio Tone Control	1950
C 223830	Trim Panel & Silencer Assy-Cowl-RH	501 thru 504
C 223831	Trim Panel & Silencer Assy-Cowl-LH	501 thru 504
TC 223840	Trimboard Complete-Front Door Pocket-RH	502-504 Sedan
TC 223841	Trimboard Complete-Front Door Pocket-LH	502-504 Sedan
TC 223842	Trimboard Complete-Rear Door Pocket-RH	502-504 Sedan
TC 223843	Trimboard Complete-Rear Door Pocket-LH	502-504 Sedan
C 223920	Lever Assy-Quarter Panel-RH	500 CvBro
C 223921	Lever Assy-Quarter Panel-LH	500 CvBro

ADDITIONS

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
300002	Cylinder & Piston Assy (Use 302625)	1948-1949 6 Cyl
*C 300003	Cylinder & Piston Assy	1948 thru 1950 8 Cyl
EM 300007	Gauge Assy-Oil Level	1948 thru 1950 All
EM 300008	Seal-Oil Level Gauge	1948 thru 1950 All
EM 300009	Washer-Oil Level Gauge Seal	1948 thru 1950 All
EM 300010	Support Plate-Cylinder-Rear	4948 thru 1950
F 300011	Gasket-CI Cylinder Head	1948 thru 1950 6 Cyl
C 300012	Housing Assy-Clutch	1948 thru 1950 All LHD
C 300013	Housing-Clutch	1948,1949
EM 300014	Bracket-Generator Adjusting	483,484,493,494
EM 300015	Water Outlet-Cylinder Head	1948 thru 1950 6 Cyl
EM 300017	Water Outlet-Cylinder Head	1948 thru 1950 8 Cyl
F 300019	Gasket-Cylinder Support Plate-Front	1948 thru 1950 8 Cyl
EM 300020	Bearing-Camshaft-#1	1948 thru 1950 6 Cyl
EM 300021	Bearing-Camshaft-#2	1948 thru 1950 6 Cyl
C 300022	Camshaft	1948 thru 1950 6 Cyl
EM 300023	Bearing-Camshaft-#3	1948 thru 1950 6 Cyl
EM 300024	Bearing-Camshaft-#4	1948 thru 1950 6 Cyl
F 300032	Valve-Inlet	1948 thru 1950 6 Cyl
F 300033	Valve-Exhaust	1948 thru 1950 6 Cyl
EM 300037	Seat-Valve Spring	1948 thru 1950 6 Cyl
EM 300038	Retainer-Valve Spring Seat	1948 thru 1950 6 Cyl
EM 300039	Oil Filler Tube	1948 thru 1950 6 Cyl
F 300041	Valve Spring	1948 thru 1950 6 Cyl
F 300044	Conn Rod & Cap Assy	1948-1949 6 Cyl
EM 300056	Bolt-Connecting Rod	1948 thru 1950 6 Cyl
F 300059	Bushing-Connecting Rod	1948 6 Cyl
F 300061	Piston Pin	1948 thru 1950 6 Cyl
F 300062	Piston Assembly-Semi-Finished	1948-1949 6 Cyl
F 300064	Piston Ring-Compression	1948 thru 1950 6 Cyl
F 300065	Piston Ring-Compression-.010 o/s	1948 thru 1950 6 Cyl
F 300066	Piston Ring-Compression-.020 o/s	1948 thru 1950 6 Cyl
F 300067	Piston Ring-Oil-Lower	1948 thru 1950 6 Cyl
F 300068	Piston Ring-Oil-Lower-.010 o/s	1948 thru 1950 6 Cyl
F 300069	Piston Ring-Oil-Lower-.020 o/s	1948 thru 1950 6 Cyl
C 300070	Propeller Shaft Assembly-Front-With OD	1948,1949,501 thru 504
C 300071	Propeller Shaft Assembly-Front-Without OD	1948,1949,501 thru 504
C 300072	Propeller Shaft Assembly-Rear	1948 thru 1950
300074	Bearing-Connecting Rod (Use 302745)	1948 6 Cyl
F 300075	Valve Tappet & Adjusting Screw Assy	1948 thru 1950 6 Cyl
F 300077	Adjusting Screw-Valve Tappet	1948 thru 1950 6 Cyl
EM 300078	Thrust Plate-Camshaft	1948 thru 1950 6 Cyl
EM 300079	Lock-Camshaft Thrust Plate Bolt	1948 thru 1950 6 Cyl
EM 300083	Heat Tube-Exhaust Manifold to Choke	1948 thru 1950 6 Cyl
EM 300085	Shaft-Exhaust Damper	1948 thru 1950 6 Cyl
EM 300086	Pin-Exhaust Manifold	1948 thru 1950 6 Cyl
EM 300087	Spacer-Exhaust Damper	1948 thru 1950 6 Cyl
F 300088	Guide-Inlet Valve	1948 thru 1950 6 Cyl
F 300089	Guide-Exhaust Valve	1948 thru 1950 6 Cyl
EM 300092	Seal-Crankshaft Brg Cap-Long-For #1 & 4 Caps	1948 thru 1950 6 Cyl
EM 300093	Seal-Crankshaft Brg Cap-Short-For #1 Cap	1948 thru 1950 6 Cyl
C 300096	Drag Link Assy-LHD	1948,1949,501 thru 504
300098	Vibration Dampener Assy (Use 301934)	1948
EM 300099	Hub-Vibration Dampener	1948 thru 1950 All
*C 300101	Crankshaft Assy	1948 thru 1950 8 Cyl
EM 300113	Dowel-Crankshaft Bearing Cap	1948 thru 1950 6 Cyl
EM 300115	Screw-Crankshaft Brg Cap-Short	1948 thru 1950 6 Cyl
EM 300116	Screw-Crankshaft Brg Cap-Long-For #1 Cap	1948 thru 1950 6 Cyl
300120	Intake Manifold Assy-Cast Iron (Use 301149)	1948 6 Cyl
EM 300122	Clamp-Intake & Exhaust Manifold to Cyl	1948 thru 1950 6 Cyl
F 300123	Gasket-Intake Manifold to Exhaust Manifold	1948 thru 1950 6 Cyl
F 300124	Gasket-Exhaust & Intake Manifold to Cylinder	1948 thru 1950 6 Cyl
EM 300129	Counterweight-Exhaust Damper	1948 thru 1950 6 Cyl
F 300130	Master Cylinder Assy-Brake	1948 thru 1950
F 300132	Bearing-Camshaft-#1-Reamed	1948 thru 1950 6 Cyl
F 300133	Bearing-Camshaft-#2-Reamed	1948 thru 1950 6 Cyl
F 300134	Bearing-Camshaft-#3-Reamed	1948 thru 1950 6 Cyl
F 300135	Bearing-Camshaft-#4-Reamed	1948 thru 1950 6 Cyl
EM 300139	Mounting-Front-Engine	1948 thru 1950
EM 300140	Plug-Oil Check Valve	1948 thru 1950 6 Cyl
EM 300141	Gasket-Oil Check Valve Plug	1948 thru 1950 6 Cyl
EM 300142	Plunger-Oil Check Valve	1948 thru 1950 6 Cyl
EM 300144	Oil Pump Assembly	1948 thru 1950 6 Cyl
F 300145	Gasket-Oil Pump	1948 thru 1950 6 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 300146	Drive Gear-Oil Pump Shaft	1948 thru 1950 6 Cyl
BZ 300147	Bracket-Assy-Master Cylinder-LHD	1948 thru 1950
HA 300150	Oil Filter Assy	1948-1949 6 Cyl
*BM 300151	Plate Assy-Cylinder Front Support	1948 thru 1950 6 Cyl
*BM 300154	Plate Assy-Cylinder Front Support	1948 thru 1950 8 Cyl
F 300157	Gasket-Cylinder Front Support Plate	1948 thru 1950 6 Cyl
EM 300158	Lock Plate-Cylinder Front Supt Plate Bolt	1948 thru 1950 6 Cyl
BM 300159	Thermostat-Exhaust Damper	1948 thru 1950 6 Cyl
*C 300160	Oil Pan Assy	1948 thru 1950 6 Cyl
F 300164	Gasket-Oil Pan	1948 thru 1950 6 Cyl
F 300165	Gasket-Oil Pan	1948 thru 1950 8 Cyl
BM 300166	Suction Pipe Assy-Oil Pan	1948 thru 1950 6 Cyl
EM 300169	Flange-Oil Pan Suction Pipe	1948 thru 1950 6 Cyl
*C 300170	Tray Assy-Oil Pan	1948 thru 1950 8 Cyl
EM 300174	Scrren Assy-Oil Pan	1948 thru 1950 All
BM 300175	Seal-Oil Pan Suction Pipe	1948 thru 1950 6 Cyl
EM 300178	Pipe Assy-Oil Pan Oil Return	1948 thru 1950 8 Cyl
F 300181	Gasket-Timing Gear Cover	1948 thru 1950 8 Cyl
EM 300182	Cover Assy-Timing Gear	1948 thru 1950 8 Cyl
EM 300184	Sprocket-Camshaft	1948-1949 6 Cyl
EM 300185	Sprocket-Crankshaft	1948 thru 1950 6 Cyl
EM 300186	Timing Chain	1948 thru 1950 6 Cyl
F 300189	Gasket-Timing Chain Cover	1948 thru 1950 6 Cyl
*C 300192	Oil Pan Assembly	1948 thru 1950 8 Cyl
EM 300193	Suction Pipe Assy-Oil Pan	1948 thru 1950 8 Cyl
300198	Cap Assy-Gas Tank Filler (Use 302253)	1948
BZ 300199	Strap-Gasoline Tank	1948 thru 1950
F 300201	Gasket-Cylinder Head Water Outlet	1948 thru 1950 6 Cyl
*SP 300202	Fuel Pump Assy	1948-1949 All exc 8 Cyl Rim cars
*SP 300203	Comb Fuel & Vacuum Pump Assy	1948 thru 1950 All exc 8 Cyl RHD cars
EM 300204	Spacer-Fuel Pump to Cylinder	1948 thru 1950
BZ 300205	Wheel Cyl Assy-Front-RH	1948,1949,501 thru 504
BZ 300206	Wheel Cyl Assy-Front-LH	1948,1949,501 thru 504
BZ 300207	Wheel Cyl Assy-Rear-RH	1948 thru 1950
BZ 300208	Wheel Cyl Assy-Rear-LH	1948 thru 1950
*SP 300209	Battery Assembly-17 Plate	1948,1949
300211	Cable Assy-Rear Brake (Use 302231)	1948
CF 300212	Cable Assy-Hand Brake	1948,1949
EM 300213	Pin-Piston Ring	1948 thru 1950
F 300214	Shaft, Bearing & Slinger Assy-Water Pump	1948 thru 1950
F 300216	Retainer-Water Pump Bearing	1948 thru 1950
EM 300217	Hub-Water Pump Pulley	1948 thru 1950
BM 300218	Slinger-Water Pump Shaft	1948 thru 1950
F 300219	Fan Blade Assy-Water Pump	1948
F 300220	Seal Assy-Water Pump Shaft	1948 thru 1950
F 300221	Washer-Water Pump Shaft Seal	1948 thru 1950
BM 300222	Body-Water Pump	1948 thru 1950 6 Cyl
F 300223	Impeller-Water Pump	1948 thru 1950
F 300224	Gasket-Water Pump Body to Cover	1948 thru 1950 6 Cyl
EM 300226	Body-Water Pump	1948 thru 1950 8 Cyl
F 300230	Gasket-Water Pump Body to Cover	1948 thru 1950 8 Cyl
EM 300231	Cover-Water Pump Body	1948 thru 1950 8 Cyl
F 300232	Gasket-Water Pump Body Cover	1948 thru 1950 8 Cyl
EM 300233	Stud-Water Pump Body to Cyl	1948 thru 1950
BM 300236	Cover-Water Pump Body	1948 thru 1950 6 Cyl
F 300237	Gasket-Water Pump Body Cover	1948 thru 1950 6 Cyl
C 300240	Clutch Housing Complete-LHD	1948 thru 1950
*C 300247	Crankshaft Assy-010 u/size	1948 thru 1950 8 Cyl
BM 300254	Oil Throw Assy-Upper-Crankshaft	1948 thru 1950 8 Cyl
EM 300256	Oil Throw-Lower-Crankshaft	1948 thru 1950 8 Cyl
BM 300260	Bearing-Crankshaft-#1	1948 6 Cyl
EM 300261	Bearing-Crankshaft-#2	1948 6 Cyl
300262	Bearing-Crankshaft-#3 (Use 302735)	1948 6 Cyl
EM 300263	Bearing-Crankshaft-#4	1948 6 Cyl
EM 300264	Bolt-Flywheel	1948 thru 1950
C 300265	Cylinder Head Assy-700 to 1 (Alum)	1948-1949 6 Cyl,501,502
300266	Heat Conductor Tube-Carburetor Choke(Use 300674)	1948 6 Cyl
EM 300272	Elbow-Exhaust Manifold Outlet	1948 thru 1950 6 Cyl
F 300273	Gasket-Exhaust Manifold to Elbow	1948 thru 1950 6 Cyl
EM 300274	Pipe-Cyl Water Distributor	1948 thru 1950 6 Cyl
BZ 300275	Dowel-Frame #2 Crossmember	1948 thru 1950
C 300276	Crossmember Assy-#2-Front Frame	1948 thru 1950
*C 300280	Differential Carrier & Gear Set Assy-4-1/10	1948 thru 1950
*C 300281	Differential Carrier & Gear Set Assy-4-5/9	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
F 300282	Drive Gear & Pinion-Matched-4-1/10	1948 thru 1950
F 300283	Drive Gear & Pinion-Matched-4-5/9	1948 thru 1950
300288	Screw-Drive Gear (Use 302233)	1948
F 300291	Differential Case Assy-4-1/10 or 4-5/9	1948 thru 1950
F 300297	Drive Shaft Assy	1948 thru 1950
BX 300299	Shim-Rear Pinion Bearing-.002	1948 thru 1950
BX 300300	Shim-Rear Pinion Bearing-.003	1948 thru 1950
C 300303	Differential Carrier & Cap Assy	1948 thru 1950
BX 300306	Adjusting Nut-Differential Bearing	1948 thru 1950
BX 300308	Companion Flange-Rear Axle	1948 thru 1950
BX 300309	Shim-Drive Pinion Bearing Spacer-.002	1948 thru 1950
BX 300310	Shim-Drive Pinion Bearing Spacer-.003	1948 thru 1950
BX 300311	Shim-Drive Pinion Bearing Spacer-.004	1948 thru 1950
F 300312	Oil Seal-Drive Pinion	1948 thru 1950
BX 300313	Spacer-Drive Pinion Bearing	1948 thru 1950
BX 300318	Gasket-Differential Carrier	1948 thru 1950
C 300324	Front Suspension Complete-RH-LHD	1948
C 300325	Front Suspension Complete-LH-LHD	1948
F 300326	Pivot-Strg Spindle Support Arm	1948 thru 1950 All
C 300329	Strg Spindle Support Arm Assy-Lower-RH	1948 thru 1950 All
C 300330	Strg Spindle Support Arm Assy-Lower-LH	1948 thru 1950 All
BX 300332	Strg Arm-Outer-RH-LHD	1948 thru 1950 All
BX 300333	Strg Arm-Outer-LH-LHD	1948 thru 1950 All
BX 300334	Brkt-Rear Axle Housing Stabilizer	1948 thru 1950 All
BX 300335	Steering Arm-Center-LHD	1948,1949
BX 300336	Pivot-Center Steering Arm	1948 thru 1950 All
BX 300337	Spacer-Center Steering Arm Pivot	1948 thru 1950 All
C 300338	Tie Rod Assy	1948,1949
BM 300340	Bracket-Generator Adjusting	481,482,491,492
BM 300341	Bracket-Generator Support	1948 thru 1950 6 Cyl
*BM 300342	Starting Motor-Complete	1948,1949,501 thru 504
C 300343	Tie Rod	1948 thru 1950
F 300348	Tie Rod End Assy-RH	1948 thru 1950
F 300349	Tie Rod End Assy-LH	1948 thru 1950
*F 300350	Shock Absorber Assy-Front	1948,1949
*F 300351	Shock Absorber Assy-Rear	1948 thru 1950
F 300352	Tie Rods Ends Complete	1948 thru 1950
300353	Distributor Assy (Use 302605)	481,482,491,492
BX 300354	Brkt-Center Steering Arm Pivot Support-LHD	1948 thru 1950 All
C 300355	Bar-Rear Stabilizer	1948 thru 1950
F 300356	Switch Assy-Stop Lamp-Hydraulic	1948 thru 1950 All
*BM 300357	Ignition Coil Assy	1948,1949
A 300358	Guard Assy-Flywheel	1948 thru 1950
*C 300360	Front Frame Assy-LHD	1948,1949,501 thru 504
300363	Crossmcmber Assy-#3-Frame-LHD (Use 302813)	1948,1949
BZ 300376	Support & Spring Seat Assy-Upper Arm-F Frame Susp-RH	1948 thru 1950
BZ 300377	Support & Spring Seat Assy-Upper Arm-F Frame Susp-LH	1938 thru 1950
BZ 300387	Bracket-Brake Tube-Front Frame	1948,1949,1950
BZ 300388	Bracket-Radiator Mounting	1948 thru 1950
BZ 300389	Cross Member Assy-Prop Shaft Center Bearing Support	1948
BZ 300393	Bracket-Clutch Pedal Assisting Spring-LHD	1948-1949 less VD or HDM,1950 less HDM or SMD
BZ 300394	Support-Prop Shaft Bearing Housing	1948 thru 1950
C 300398	Jacket Tube & Bearing Assy-Strg Gear-Without DI	481,483,491,493,501,503,500 LHD
BZ 300403	Dirt Shield-Prop Shaft Center Bearing	1948 thru 1950
BZ 300404	Pedal & Rod Assy-Clutch & Brake-LHD	1948,1949,501 thru 504
BZ 300407	Lever & Shaft Assy-Clutch Pedal-LHD	1948,1949,501 thru 504
BZ 300415	Lever Assy-Brake Pedal-LHD	1948,1949,501 thru 504
BZ 300417	Bushing-Brake & Clutch PedalLever	1948 thru 1950
BZ 300418	Housing & Bushing Assy-Pedal Lever Shaft	1948 thru 1950
300422	Gear-Transmission Main Drive (Use 302471)	1948-1949 exc with HDM
BZ 300425	Bushing-Pedal Lever Shaft Housing	1948
BZ 300427	Snap Ring-Pedal Lever Shaft Housing	1948 thru 1950
BZ 300428	Shaft-Pedal Lever-LHD	1948 thru 1950
BZ 300429	End Lever-Pedal Shaft-LHD	1948
300431	Bumper-Pedal Toe Plate	1948
300432	Washer-Pedal Toe Plate Bumper	1948
BZ 300433	Cushion-Rear Stabilizer Bar	1948 thru 1950
BZ 300434	Spacer-Rear Stabilizer Bar Cushion	1948 thru 1950
BZ 300435	Sleeve-Rear Stabilizer Bar Bracket	1948 thru 1950
BM 300436	Bearing-Crankshaft-#1-.010 U/S	1948 6 Cyl
BM 300437	Bearing-Crankshaft-#2-.010 U/S	1948 6 Cyl
300438	Bearing-Crankshaft-#3-.010 U/S (Use 302738)	1948 6 Cyl
BM 300439	Bearing-Crankshaft-#4-.010 U/S	1948 6 Cyl
F 300441	Pin-Rear Spring Front Mounting	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 300442	Coil Spring-Front	1948 thru 1950
BZ 300444	Cross Shaft & Coupling Lever Assy	1948
BZ 300448	Link Assy-Clutch Control-LHD	1948
BZ 300449	Link-Clutch Control-LHD	1948
*C 300452	Gasoline Tank Assy	1948,1949
300458	Filler Neck Assy-Gas Tank (Use 300552)	1948
BZ 300460	Ball Arm-Steering Gear-LHD	1948,1949,501 thru 504
BZ 300461	Housing-Prop Shaft Center Bearing	1948 thru 1950
*C 300462	Steering Gear Assy-LHD	1948,1949
300463	Retainer-Prop Shaft Center Brg Hsg Supt Cushion (Use 303924)	1948 thru 1950
300466	Gauge Assy-Gas Tank (Use 302709)	1948,1949
BZ 300467	Outlet Unit-Gas Tank	1948 thru 1950
BZ 300468	Link-Brake Pedal to Master Cylinder-LHD	1948 thru 1950
BZ 300469	Hold-down Assy-Battery	1948 thru 1950
BZ 300472	Bolt-Battery Hold-Down	1948,1949
BZ 300473	Support Assy-Battery	1948 thru 1950
300478	Drip Pan-Battery (-Use 302501)	1948,1949
BZ 300479	Cover-Pedal Pad	481,483,491,493
C 300480	Core Assy-Radiator	1948,1949,501 thru 504
BZ 300481	Outlet Tube-Radiator	1948 thru 1950
F 300482	Hose-Radiator Outlet	1948 thru 1950
F 300483	Hose-Radiator Inlet	1948 thru 1950
BZ 300484	Cage-Radiator Core Nut	1948,1949
300492	Housing Assy-Rear Axle (Use 302267)	1948,1949
C 300495	Muffler Assembly	1948 thru 1950
BZ 300496	Clamp-Rear-Muffler & Exhaust Pipe	1948 thru 1950
BZ 300497	Support Bracket Assy-Muffler Rear Clamp	1948 thru 1950
CF 300501	Exhaust Pipe Assy-Front-LHD	1948-1949 6 Cyl,501,502
CF 300503	Exhaust Pipe-Rear	1948 thru 1950
BZ 300505	Gasket-Front Exhaust Pipe Flange	1948 thru 1950 All 6 Cyl,All RHD 8 Cyl
BZ 300506	Clamp-Front Exhaust Pipe-LHD	1948 thru 1950 All
BZ 300507	Support-Front Exhaust Pipe Clamp-LHD	1948 thru 1950 6 Cyl
BZ 300508	Clamp-Exhaust Pipe-Center-Joins Front & Rear Pipes	1948 thru 1950 All
BZ 300509	Support Bracket Assy-Rear Exhaust Pipe Clamp	1948 thru 1950
BX 300516	Backing Plate Assy-Front Brake	1948,1949,501 thru 504
BX 300518	Brake Shoe & Lining Assy-Primary-Front	Temporary for 300535
BX 300519	Brake Shoe & Lining Assy-Secondary-Front	Temporary for 300535
BZ 300526	Bracket Assy-Radiator Mounting-RH	1948 thru 1950
BZ 300527	Bracket Assy-Radiator Mounting-LH	1948 thru 1950
BZ 300531	Bracket-Clutch Control Cross Shaft-LHD	1948 thru 1950
F 300532	Lining & Rivet Pkg-Front Brake Shoe-Two Wheels	1948,1949,501 thru 504
F 300535	Shoes & Lining Replacement Kit-Front Brake-Two Wheels	1948,1949,501 thru 504
BM 300537	Oil Tube-Timing Chain	1948-1949 6 Cyl
BM 300538	Clip-Timing Chain Oil Tube	1948-1949 6 Cyl
BM 300539	Cover-Valve Chamber-Front	1948 thru 1950 6 Cyl
BM 300540	Cover Assy-Valve Chamber-Rear	1948 thru 1950 6 Cyl
BM 300544	Valve Chamber Cover (Front)	1948 thru 1950 8 Cyl
BM 300545	Valve Chamber Cover (Rear)	1948 thru 1950 8 Cyl
BM 300546	Valve Chamber Cover Baffle	1948 thru 1950 8 Cyl
F 300547	Valve Chamber Cover Gasket	1948 thru 1950 8 Cyl
BZ 300551	Vent Hose-Gas Tank	1948
BZ 300552	Filler Neck-Gas Tank	1948 thru 1950
BM 300554	Lock-Vibrating Dampener Cap Screw	1948 thru 1950 All
CF 300555	Exhaust Pipe Assy-Front-LHD	1948 thru 1950 8 Cyl
F 300557	Gasket-Valve Chamber Cover	1948 thru 1950 6 Cyl
C 300558	Jacket Tube & Bearing Assy-With DI	481,483,491,493,501,503,500 RHD
*HA 300560	Oil Filter Kit	1948-1949 6 Cyl
BM 300561	Hose-Oil Filter Inlet	1948-1949 6 Cyl
F 300562	Hose-Water Pump Outlet	1948 thru 1950 8 Cyl
F 300563	Hose-Water Pump by Pass	1948 thru 1950 8 Cyl
BM 300566	Water Pump Assy	1948 thru 1950 6 Cyl
BM 300567	Water Pump Assy	1948 thru 1950 8 Cyl
BZ 300568	Tube Assy-Brake-Tee to RR Wheel	1948 thru 1950
BZ 300569	Tube Assy-Brake-Tee to LH Wheel	1948 thru 1950
BT 300577	Bracket-Handy Shift Wire Casing	1948 thru 1950
BZ 300578	Fitting-Master Cylinder Outlet	1948 thru 1950
BZ 300579	Bolt-Master Cylinder Outlet Connection	1948 thru 1950
BM 300580	Suction Pipe Assy-Oil Pump	1948 thru 1950 8 Cyl
BM 300582	Pipe Assy-Oil Pump to Check Valve-LED	1948 thru 1950 8 Cyl
C 300586	Torsion Bar Assy-Front Stabilizer	1948 thru 1950
BZ 300588	Bracket-Front Torsion Bar Bushing	1948 thru 1950
BZ 300589	Connector-Front Stabilizer	1948 thru 1950

Part No.	Name	Models
F 300590	Cushion-Front Stabilizer Connector	1948 thru 1950
BX 300595	Steering Arm & Pivot Assy-Center-LHD	1948,1949,501 thru 504
BX 300596	Spacer-Upper-Center Steering Arm Pivot	1948 thru 1950 All
	300597 Seal-Center Strg Arm Pivot Supt Brkt Brg (Use 302553)	1948,1949
BX 300598	Retainer-Center Strg Arm Pivot Supt Brkt Brg Seal	1948,1949
BX 300599	Bracket & Bearing Assy-Center Steering Arm-LHD	1948 thru 1950 All
	300601 Accelerator Pedal-Gray Green (Use 303142)	481,483,491,493
BZ 300605	Anchor Bracket-Accelerator Pedal	1948,1949,501 thru 504
BZ 300607	Anchor Bracket-Front Frame at #4 Crossmember	1948 thru 1950
	300609 Cushion-Prop Shaft Center Brg Supt (Use 301612)	1948 thru 1950
BZ 300610	Companion Flange-Prop Shaft	1948 thru 1950
BZ 300611	Bracket-Hand Brake Mounting	1948,1949
BZ 300612	Grip & Ratchet Rod Assy-Hand Brake-LHD	482,484,492,494
BZ 300613	Ratchet Rod-Hand Brake	1948,1949
BZ 300614	Housing-Hand Brake Ratchet Rod	1948 thru 1950
BZ 300615	Stabilizer-Outer-Hand Brake Ratchet Rod	1948,1949
	300616 Oil Pump Assy (Use 301941)	1948-1949 8 Cyl
BZ 300619	Support-Front Exhaust Pipe Clamp-LHD	1948 thru 1950 8 Cyl
C 300620	Steering Wheel-17"	481,483,491,493
	300621 Steering Wheel-18" (Use 301471)	1948
BZ 300625	Hand Brake Ratchet Rod Lock Spring	1948 thru 1950
	300626 Circuit Breaker Assy (Use 301853)	1948 thru 1950 CvBro
*BM 300629	Carburetor Assembly-LHD	481,482,491,492,501,502
EM 300630	Carburetor Assembly-LHD	1948 thru 1950 8 Cyl
BZ 300632	Horn Button-17" Steering Wheel	481,483,491,493
C 300635	Support-Prop Shaft Center Bearing	1948
	300640 Spring & Cover Assy-Rear (Use 301564)	1948,1949
BO 300641	Switch & Circuit Breaker Assy-Lighting	1948 thru 1950
F 300642	Switch Assy-Lighting	1948 thru 1950
BO 300643	Circuit Breaker Assy-Headlight	1948,1949
BO 300644	Ignition Lock Case & Brkt Assy-LHD	1948 thru 1950
BO 300645	Bezel-Ignition Lock Case	1948 thru 1950
BO 300646	Starter Switch & Bracket Assy	1948 thru 1950
EM 300649	Lock Ring-Piston Pin	1948 thru 1950 6 Cyl
*C 300654	Engine Assy-Cast Iron Head	481,482,491,492,501,502
*C 300655	Engine Assy-Alum Head	481,482,491,492,501,502
*C 300656	Engine Assy-Cast Iron Head	1948 thru 1950 8 Cyl
BZ 300658	Play Link Assy-Brake	1948 thru 1950
BZ 300660	Lever-Hand Brake Cable	1948 thru 1950
BZ 300661	Pivot Brace Assy-Hand Brake Cable Lever-LIID	1948,1949,501 thru 504
BZ 300664	Hanger-Hand Brake Cable Lever Pivot	1948 thru 1950
F 300665	Gasket-Aluminum Cyl Head	1948 thru 1950 6 Cyl
EM 300666	Bracket-Ignition Coil to Manifold-LHD	1948 thru 1950 8 Cyl
BZ 300667	Bushing-Front Stabilizer Torsion Bar	1948 thru 1950
F 300668	Brake Shoe & Lining-Rear-Primary	1948,1949
F 300669	Brake Shoe & Lining-Rear-Secondary	1948,1949
BZ 300670	Bracket-Engine Front Mounting-RH	1948 thru 1950
BZ 300671	Bracket-Engine Front Mounting-LH	1948 thru 1950
EM 300674	Tube & Cover Assy-Carburetor Choke Heat Conductor	1948-1949 6 Cyl
BZ 300678	Extension-Front Frame Side Member	1948 thru 1950 All
A 300679	Guard-Engine-Front	1948,1949,501 thru 504
EM 300680	Spacer-Oil Pan Bolt-LHD	1948 thru 1950 8 Cyl
F 300685	Cup-Brake Wheel Cylinder-Front	1948,1949,501 thru 504
F 300686	Piston-Brake Wheel Cylinder-Front	1948,1949,501 thru 504
F 300688	Cup-Brake Wheel Cylinder-Rear	1948 thru 1950
BZ 300690	Gasket-Brake Master Cylinder Filler Cap	1948 thru 1950
F 300695	Piston-Brake Wheel Cylinder-Rear	1948 thru 1950
BZ 300696	Inlet Fitting-Brake Wheel Cylinder-Rear	1948 thru 1950
BZ 300697	Cover-Brake Master Cylinder	1948 thru 1950
BZ 300699	Gasket-Brake Master Cylinder Cover	1948 thru 1950
BZ 300708	Boot-Brake Master Cylinder Push Rod	1948 thru 1950
BZ 300714	Lever Assy-Brake Control-LHD	1948 thru 1950
BZ 300716	Bracket-Brake Control Lever Pivot Pin-LHD	1948 thru 1950
BZ 300717	Side Brace-Cable Lever Pivot Plate	1948 thru 1950
EM 300718	Heat Shield Assy-Fuel Pump-LHD	1948 thru 1950 8 Cyl
BZ 300721	Bracket-Front Suspension Bumper-At #2 Crossmember	1948 thru 1950
C 300722	Lever,Tube & Rod Assy-Handy Shift-LHD	481-483-491-493-501-503 with HDM
C 300723	Lever,Tube & Rod Assy-Handy Shift-LHD	482-484-492-494-502-504 with HDM
C 300724	Tube & Fulcrum Bracket Assy-Handy Shift-LHD	481-483-491-493-501-503 with HDM
C 300725	Tube & Fulcrum Bracket Assy-Handy Shift-LHD	482-484-492-494-502-504 with HDM
BT 300728	Bellcrank & Bushing Assy-Handy Shift	1948-1949-501 thru 504 without HDM,500 RHD
BT 300730	Bushing-Handy Shift Bellcrank	1948-1949-501 thru 504 without HDM,500 RHD
BT 300731	Rod Assy-Handy Shift Tube to Bellcrank-LHD	1948-1949 without HDM
BT 300734	Rod Assy-Handy Shift Bellcrank to Trans	1948,1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 300736	Jacket Tube & Bearing Assy-Strg Gear-Without DI	482,484,492,494,502,504
C 300738	Jacket Tube & Bearing Assy-Strg Gear-With DI	482,484,492,494,502,504
BZ 300745	Grommet-Hand Brake Cable	482,484,492,494,502,504
BZ 300746	Grip & Ratchet Rod Assy-Hand Brake-LHD	482,484,492,494,502,504
BX 300747	Link-Brake Wheel Cylinder to Shoe	482,484,492,494,502,504
BZ 300749	Push Rod Assy-Brake Master Cylinder	1948 thru 1950
BZ 300750	Horn Ring-18" Wheel	481,483,491,493
BZ 300751	Center-Horn Ring-18" Wheel	1948,1949,1950
BZ 300752	Spring-Horn Ring-18" Wheel	1948 thru 1950 19481
BZ 300753	Insulator-Horn Ring	1948,1949
A 300754	Guard-Engine-Left	1948
BZ 300755	Lock Ring-Prop Shaft Center Bearing	1948,1949
BZ 300756	Pull Rod Complete-Brake Pedal	1948,1949,501 thru 504
BZ 300761	Guide Plate Assy-Hand Brake Cable Lever-LHD	1948 thru 1950
F 300764	Mainshaft-Transmission-With OD	1948,1949,501 thru 504
BO 300766	Knob-Instrument Switch Mtg Panel	1948 thru 1950
BO 300767	Mounting Nut-Instrument Switch Mtg Panel Knob	1948 thru 1950
BZ 300768	Spring-Clutch Shifter Yoke Shaft Coupling Lever Return	1948 thru 1950
*C 300770	Overdrive Assembly	1948 thru 1950
BZ 300774	Pipe Assy-Gas Tank to Union	1948,1949,1950
BZ 300775	Pipe Assy-Union to Fuel Pump-LHD	1948,1949
BZ 300776	Pipe Assy-Union to Fuel Pump-LHD	1948 thru 1950
BZ 300779	Tube Assy-Brake Connector to Rear Hose	481,482,491,492,501,502
300780	Knob-Handy Shift Lever (Use 301997)	1948 thru 1950 8 Cyl
BZ 300781	Tube Assy-Master Cylinder to Frame Tee-LHD	1948,1949
BZ 300782	Tube Assy-Frame Tee to Right Front Hose-LHD	1948 with 18" Strg Wheel
BZ 300783	Tube Assy-Frame Tee to Left Front Hose-LHD	1948,1949,501 thru 504
BZ 300784	Tube Assy-Master Cylinder to Connector-LHD	1948,1949,501 thru 504
BZ 300785	Frame Tee-Brake Control Tube	1948,1949,501 thru 504
BZ 300786	Rear Axle Tee-Brake Control Tube-LHD	1948,1949
300787	Brkt-Front Frame to Dash-RH (Use 1-215584,1-210197, 1-215581,20170210,3-171025,1-71126,1-171294, 1-215586,2-215588,1-170945)	1948-1949-501 thru 504 All LHD,500 All 1948 thru 1950
BZ 300788	Brkt-Front Frame to Dash-LH	1948
F 300790	Hose Assy-Brake Control	1948
F 300791	Gasket-Brake Control Hose	1948 thru 1950
*HA 300792	Weather-Control Heater Complete-Manual Control	1948 thru 1950 1948
BZ 300794	Clip-Brake Control Tube-Offset	1948 thru 1950
BZ 300795	Clip-Brake Control Tube-Plain	1948 thru 1950
BO 300796	Door Switch-Courtesy Lamps	482,484,492,494,502,504
EM 300798	Mounting-Engine Rear	1948 thru 1950
BO 300799	Switch-Headlight Dimmer	1948,1949
300801	Piston-B (Use 302406)	1948-1949 6 Cyl
300802	Piston-D (Use 302407)	1948-1949 6 Cyl
F 300803	Piston-F	1948-1949 6 Cyl
300804	Piston-J (Use 302409)	1948-1949 6 Cyl
300805	Piston-L (Use 302410)	1948-1949 6 Cyl
300806	Piston-P (Use 302717)	1948-1949 6 Cyl
300807	Piston-HO (Use 302718)	1948-1949 6 Cyl
300808	Piston-DO (Use 302413)	1948-1949 6 Cyl
300809	Piston-FO (Use 302414)	1948-1949 6 Cyl
300810	Piston-LO (Use 302415)	1948-1949 6 Cyl
300811	Piston-BB (Use 302416)	1948-1949 6 Cyl
F 300812	Piston-DD	1948-1949 6 Cyl
300813	Piston-FF (Use 302418)	1948-1949 6 Cyl
BZ 300816	Horn Ring & Center Assy-18" Wheel	1948
BZ 300817	Center Contact Cup-Horn Ring-18" Wheel	1948
BZ 300818	Retainer-Horn Ring-18" Wheel	1948
F 300820	Piston Ring-Upper Oil-Std	1948 thru 1950 6 Cyl
F 300821	Piston Ring-Upper Oil-010 o/s	1948 thru 1950 6 Cyl
F 300822	Piston Ring-Upper Oil-020 o/s	1948 thru 1950 6 Cyl
EM 300823	Sleeve-Engine Rear Mounting Bolt	1948 thru 1950
BM 300824	Air Cleaner-Carburetor-Oil Bath-Without HDM or SMD	481,482,491,492,501,502
300825	Distributor Assy (Use 302606)	483,484,493,494
F 300827	Connection-Battery to Ground	1948 thru 1950
EM 300828	Switch Assy-Oil Pressure Warning	1948 thru 1950 6 Cyl
BT 300829	Boot-Handy Shift Wiare	1948 thru 1950
EM 300830	Pipe Assy-Fuel Pump to Carburetor	1938-1949 6 Cyl
BM 300831	Pipe Assy-Comb Fuel Pump to Manifold-LHD	1948 6 Cyl
EM 300832	Tube-Carburetor Choke Heat Conductor	1948 thru 1950
BZ 300835	Rod-Accelerator Pedal to Bellcrank-LHD	1948 6 Cyl without OD or HDM
BZ 300837	Rod-Accelerator Pedal to Bellcrank-LHD	1948 8 Cyl without OD or HDM
BZ 300838	End-Accelerator Pedal to Bellcrank Rod-LHD	1948 without OD or HDM

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

383

Part No.	Name	Models
BZ 300839	Bellcrank-Accelerator Pedal Link-Without VD -HDM or OD-LHD	1948,1949,501 thru 504
BZ 300840	Bracket Assy-Accelerator Pedal Link Bellcrank-LHD	1948,1949,501 thru 504,500 with HDM
BZ 300845	Rod-Accelerator Cross Shaft Operating- Without VD or HDM-LHD	1948 thru 1950 6 Cyl
BZ 300846	Rod-Accelerator Cross Shaft Operating- Without VD or HDM-LHD	1948 thru 1950 8 Cyl
BZ 300848	Support Assy-Accelerator Cross Shaft or VD Mtg Brkt-LHD	1948 thru 1950 6 Cyl
BZ 300858	Torsion Spring-Accel Cross Shaft-LHD	1948,1949,501 thru 504 with HDM
BZ 300859	Clip-Accel Cross Shaft Torsion Spring-LHD	1948,1949,501 thru 504
BZ 300860	Spring-Throttle Control Tension-LHD	1948,1949,501 thru 504,500 with HDM
BT 300861	Lever & Pin Assy-Trans Shift Shaft-Without HDM	1948,1949,501 thru 504,500 RHD
BO 300863	Horn & Spring Plate Assy-RH	1948 thru 1950
BO 300864	Horn & Spring Plate Assy-LH	1948 thru 1950
BM 300865	Guide-Oil Level Gauge	1948 thru 1950
BO 300867	Vent Assy-Rear Axle Housing	1948 thru 1950
C 300868	Steering Gear Assy-RHD	1948,1949,501 thru 504
BT 300869	Transmission Switch Assy-HDM	1948 thru 1950
BT 300870	Power Unit Assy-HDM	1948,1949
*HA 300871	Direction Indicator Kit-LHD	481,483,491,493
*HA 300872	Direction Indicator Kit-LHD	482,484,492,494
BO 300873	Switch,Case & Cover Assy-Direction Indicator	481,483,491,493
BO 300874	Switch,Case & Cover Assy-Direction Indicator	482,484,492,494
BO 300875	Switch & Wires Assy-Direction Indicator	1948 thru 1950
BO 300877	Flasher Switch-Direction Indicator	1948 thru 1950
BT 300879	Diaphragm Cyl Assy-HDM	1948 thru 1950
BT 300881	Diaphragm Rod Assy-HDM	1948 thru 1950
BT 300886	Power Cylinder Assy-HDM	1948 thru 1950
BT 300888	Bolt-HDM Power Cylinder Mounting	1948 thru 1950
BZ 300890	Bumper-Pedal Toe Plate	1948,1949,501 thru 504
BZ 300894	Support-Clutch Control Cylinder Mtg Brkt	1948 thru 1950 6 Cyl with VD-HDM or SMD
BZ 300895	Spacer-Clutch Control Cylinder Mtg Brkt	1948 thru 1950 8 Cyl with VD-HDM or SMD
BZ 300897	Link-Accelerator Cross Shaft Lever-LHD	1948,1949,501 thru 504 with HDM
BZ 300906	Threaded Sleeve Rod Assy-VD Valve Lever Cam	1948 6 Cyl
BZ 300908	Threaded Sleeve Rod Assy-VD Valve Lever Cam	1948 thru 1950 8 Cyl with VD-HDM or SMD
BZ 300910	Rod-VD Accelerator Switch	481,482,491,492,501,502
BZ 300911	Rod-VD Accelerator Switch	1948 thru 1950 8 Cyl
BZ 300912	Cam-VD Valve Lever (Use 302549)	1948,1949
BZ 300914	Spring-Brake Control Return	1948 thru 1950
BZ 300915	Spring-Brake Control Return (Use 302169)	1948
BZ 300916	Spring-Brake Control Return	1948 thru 1950
BT 300919	Lever & Pin Assy-Trans Shift Shaft-With HDM	1948 thru 1950
BT 300923	Pin-HDM Shift Shaft Transfer Key Hub	1948 thru 1950
BT 300923	Pin-Trans Shift Shaft Lever-With HDM	1948 thru 1950
BT 300924	Pin-HDM Mounting Bracket	1948 thru 1950
BT 300925	Lever Complete-HDM Shift Shaft	1948,1949
BT 300929	Shift Shaft-HDM	1948 thru 1950
BT 300930	Lever Complete-HDM Shift Shaft-Hand Shift	1948,1949,501 thru 504
BT 300934	Hub Assy-HDM Transfer Key	1948 thru 1950
BT 300935	Bushing-HDM Transfer Key Hut (Use 164258)	1948
BT 300936	Transfer Key-HDM Shift Shaft	1948 thru 1950
BT 300939	Rod-HDM Engaging	1948 thru 1950
BT 300940	End-HDM Engaging Rod	1948 thru 1950
BT 300941	Strap-HDM Shift Switch Operating	1948 thru 1950
BT 300943	Rod-HDM Neutral & Limit Switch	1948,1949
BT 300945	Cylinder & Throttle Lock Diaphragm Assy-VD (Use 302750)	1948,1949
BM 300946	Screw-Breather Tube to Valve Chamber Cover	1948 thru 1950 6 Cyl
BM 300947	Breather Tube Assy-LHD	1948 thru 1950 6 Cyl
BM 300950	Breather Tube Assy-LHD	1948 thru 1950 8 Cyl
BM 300952	Gasket-Breather Tube	1948 thru 1950
BM 300953	Gasket-Breather Tube & Valve Chamber Cover Bolt	1948 thru 1950 8 Cyl
BT 300954	Rod Complete-HDM Trans Shift	1948,1949,501 thru 504
BT 300958	End-HDM Trans Shift Rod	1948 thru 1950
F 300959	Gasket Kit-Valve Chamber Cover	1948 thru 1950 8 Cyl
F 300960	Gasket Kit-Valve Chamber Cover	1948 thru 1950 6 Cyl
BM 300973	Wire Assy-Coil to Distributor-High Tension-LHD	1948 thru 1950 8 Cyl
F 300975	Ignition Wires Kit-Service (Use 304010)	1948-1949 6 Cyl
F 300976	Ignition Wires Kit-Service (Use 304011)	1948-1949 8 Cyl
EM 300977	Heat Deflector-Carburetor	1948,1949,501 thru 504
BZ 300978	Bumper-Front Suspension Upper Arm	1948 thru 1950
BX 300981	Upper Arm & Pivot Assy-Steering Spindle	1948 thru 1950 All
F 300984	Nut-Steering Spindle Arm to Supt Bolt	1948 thru 1950 All

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 300986	Bracket-Handy Shift Lever Fulcrum	481,483,491,493
BT 300987	Bracket-Handy Shift Lever Fulcrum	482,484,492,494
BT 300988	Ring-Handy Shift Lever Fulcrum Bracket	481,483,491,493,500,501,503
BT 300989	Ring-Handy Shift Lever Fulcrum Bracket	482,484,492,494,502,504
300990	Bearing-Connecting Rod-010 u/s (Use 302748)	1948 6 Cyl
EM 300992	Gasket-Distributor	1948 thru 1950 6 Cyl
BZ 300993	Retainer-Hand Brake Cable to Dash	1948 thru 1950
BZ 300994	Mounting Brkt & Shim Assy-Hand Brake	1948,1949
BZ 301001	Cylinder Assy-Vacumotive Drive	1948,1949
BT 301002	Support & Fulcrum Assy-Handy Shift Bellcrank- With HDM	1948,1949,501 thru 504
BT 301004	Spacer-Handy Shift Bellcrank Support-With HDM	1948,1949,501 thru 504
BT 301006	Grommet-Handy Shift Bellcrank-With HDM	1948,1949,501 thru 504
BT 301007	Rod Assy-Handy Shift Tube to Bellcrank-LHD- With HDM	1948
EM 301010	Stud-Oil Pan-For HDM Mtg Brkt Supt	1948 with HDM
BO 301011	Knob-Instrument Switch Mtg Panel	481,483,491,493
BT 301013	Rod-Handy Shift Bellcrank to Shift Shaft Lever-With HDM	1948,1949,501 thru 504
BZ 301014	Mounting Bezel-Switch Knob	1948 thru 1950
BT 301015	Shift Strap-HDM Cylinder to Lever	1948 thru 1950
BT 301019	Rod-HDM off-on Switch Operating	1948 thru 1950
301021	Grip & Ratchet Rod Assy-Hand Brake-RHD	482,484,492,494
BT 301022	Grip & Ratchet Rod Assy-Hand Brake-RHD	481,483,491,493
C 301023	Casing & Brkt Assy-Handy Shift Control Wire-Without HDM-LHD	1948,1949,501 thru 504
BT 301030	Pivot-Handy Shift Bellcrank	1948-1949-501 thru 504 without HDM,500 RIM
EM 301031	Tube Assy-Distributor Vacuum Control	481,482,491,492,501,502
BT 301033	Bellcrank & Bushing Assy-Handy Shift-With HDM	1948,1949,501 thru 504
BT 301035	Yoke,Shaft & Lever Assy-Clutch Shifter-LHD	1948 thru 1950
BT 301036	Coupling Lever-Clutch Yoke Shaft-LHD	1948 thru 1950
BZ 301038	Switch-Instrument Panel-VD & Back-up Lamp	1948 thru 1950
BZ 301039	Wire Assy-HornButton to Relay-LHD	1948 thru 1950
BO 301081	Wire Assy-Front Dome Lamp Switch-Without DI	481,483,491,493,500,501,503
BO 301082	Wire Assy-Coil to Distributor	1948 thru 1950 6 Cyl LHD Without OD-RHD
BO 301083	Wire Assy-Coil to Distributor-LHD	1948 thru 1950 8 Cyl 500 Without OD
BO 301083	Wire Assy-Top Control Valve to Circuit Breaker-LHD	1948 thru 1950 CvBro With Hyd Wdo Reg
BO 301084	Harness-Headlamp Feed-LHD	1948,1949
BO 301085	Harness-Headlamp Connector	1948 thru 1950
BO 301086	Wire Assy-Hood Lamp Feed	1948,1949,501 thru 504
BO 301087	Wire Assy-Courtesy Lamp Socket	482-482-492-494-502-504 exc CvBro
EM 301088	Wire Harness-Engine-LHD	1948-1949 6 Cyl Without OD & HDM
EM 301089	Wire Harness-Engine-LHD	1948-1949 8 Cyl Without OD & HDM
BO 301090	Instrument Harness-LHD	1948,1949
BO 301091	Harness-Charge Regulator & Horn Relay Feed	1948,1949
BO 301092	Socket & Wire Assy-Instrument Lamp	1948,1949
BO 301095	Harness-Instrument & Clock Lamp	1948
BO 301096	Wire Assy-License Lamp	1948-1949 Bro-Sed
BO 301100	Wire Harness-Body-Left Side	481-483-491-493 ClubCpe-BsCpe
BO 301101	Wire Harness-Body-Left Side-LHD	482-484-492-494 ClubCpe-BsCpe
BO 301102	Wire Harness-Body-Right Side-Without DI	482-484-492-494-502-504 Sed
BO 301103	Wire Harness-Body-Right Side-Without DI	482-484-492-494-502-504 Cpes
BO 301104	Wire Harness-Body-Right Side-With DI	481-483-491-493 Bro-Sed
BO 301105	Wire Harness-Body-Right Side-LHD-With DI	482-484-492-494 Sed
BO 301106	Wire Harness-Body-Right Side-LHD-With DI	481-483-491-493 ClubCpe-BsCpe
BO 301107	Wire Harness Body-Right Side-LHD-With DI	482-484-492-494 ClubCpe-BsCpe
BO 301108	Yoke & Socket Assy-LHD-With DI	1948 thru 1950
BO 301111	Wire Harness-Body-Rear Compt	1948-1949 Bro-Sed
BO 301112	Wire Harness-Body-Rear Compt	1948-1949 BsCpe-ClubCpe
BO 301113	Yoke & Socket Assy	1948 thru 1950
BO 301115	Harness-Direction Indicator-Front	1948-1949 LHD,1950 All
BO 301116	Wire Assy-DI Connector	1948 thru 1950
BT 301122	Bracket Assy-HDM Mounting	1948 thru 1950 6 Cyl
BT 301123	Bracket Assy-HDM Mounting	1948 thru 1950 8 Cyl
BT 301130	Support-Lower-HDM Mounting Bracket	1948 6 Cyl
BT 301131	Support-HDM Mounting Bracket	1948 8 Cyl
BT 301132	Clamp Assy-HDM Bracket to Oil Filler Tube	1948 thru 1950 6 Cyl
F 301135	Brake Shoes & Lining Kit-Front-o/s	1948,1949,501 thru 504
EM 301136	Air Cleaner-Carburetor-Dry-Without HDM or SMD	1948,1949,501 thru 504
EM 301137	Air Cleaner-Carburetor-Oil Bath-Without VD- HDM or SMD	1948 thru 1950 8 Cyl
EM 301141	Support-Breather Tube Clip	1948 thru 1950
BT 301144	Bellcrank Assy-AccelPedalLink-With VD-HDM or OD	1948 thru 1950 All LHD
301147	Lever-Acccl Pedal Link Bellcrank (Use 302156)	1948

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 301148	Torsion Spring-Accel Pedal Link Bellcrank-With HDM-VD or OD	1948 thru 1950
C 301149	Intake Manifold Assy-Aluminum	1948-1949 6 Cyl
BZ 301151	Cylinder Assy-VD Throttle Lock Diaphragm	1948-1949-501 thru 504 With HDM or SMD
BZ 301152	Bracket-Throttle Lock Diaphragm Mounting	1948-1949-501 thru 504 With HDM or SMD
BZ 301153	Clip-Hand Brake & Rear Brake Cable	1948 thru 1950
EM 301154	Pipe Assy-Fuel Pump to Carb-LHD	1948 thru 1950 8 Cyl
BM 301155	Pipe Assy-Combination Pump to Manifold-LHD	1948 thru 1950 8 Cyl
F 301159	Cable Assy-Battery to Starter Solenoid-Without-HDM	1948 exc CvBro
F 301160	Piston Ring-Compression-003 o/s	1948 thru 1950 6 Cyl
F 301161	Piston Ring-Compression-005 o/s	1948 thru 1950 6 Cyl
F 301162	Piston Ring-Compression-015 (Vs	1948 thru 1950 6 Cyl
F 301164	Piston Ring-Upper Oil-003 o/s	1948 thru 1950 6 Cyl
F 301165	Piston Ring-Upper Oil-005 o/s	1948 thru 1950 6 Cyl
F 301166	Piston Ring-Upper Oil-015 o/s	1948 thru 1950 6 Cyl
F 301168	Piston Ring-Lower Oil-003 o/s	1948 thru 1950 6 Cyl
F 301169	Piston Ring-Lower Oil-005 o/s	1948 thru 1950 6 Cyl
F 301170	Piston Ring-Lower Oil-015 o/s	1948 thru 1950 6 Cyl
BO 301172	Jucntion Block-Tail & Stop Light Wires	1948 thru 1950
BM 301174	Holder Assy-Ignition Wire-Rear-LHD	1948 thru 1950 8 Cyl
BO 301175	Wire Assy-Electric Clock Feeder	1948 thru 1950
BT 301176	Switch-HDM Instrument Panel	1948,1949
BZ 301182	Bracket-Clutch Cross Shaft-RHD	1948 thru 1950
BM 301185	Tube Assy-Distributor Vacuum Control	1948 thru 1950 8 Cyl
BO 301187	Hose-Windshield Defroster-25"-With W/Control	1948 thru 1950
BO 301190	Harness-Direction Indicator Flasher	1948,1949
301191	Bumper-Rear Axle (Use 302238)	1948
BZ 301195	Jack Ratchet Assy	1948,1949,1950
BM 301196	Connection-Engine to Ground	1948 thru 1950
301197	Ornament Cap-Steering Wheel-18" (Use 302001)	1948
EX 301198	Bolt-Differential Carrier to Hsg	1948 thru 1950
BM 301199	Cap Assy-Oil Filler Tube	1948 thru 1950 6 Cyl
301201	Housing Assy-Steering Gear-LHD (Use 303640)	1948,1949
BZ 301204	Cover-Steering Gear Shaft Housing	1948,1949,501 thru 504
BZ 301205	Gasket-Strg Gear Shaft Housing Cover	1948,1949,501 thru 504
BZ 301206	Shaft & Roller Tooth Assy-Steering Gear-LHD	1948,1949,501 thru 504
BZ 301211	Thrust Washer-Steering Gear Shaft	1948 thru 1950
C 301218	Column & Worm Assy-Steering Gear-LHD	1948,1949,501 thru 504
C 301219	Tube-Steering Gear Main Column	1948,1949,501 thru 504
BZ 301222	Shim-Steering Gear Worm Housing Cover-002	1948,1949,501 thru 504
BZ 301223	Bolt-Steering Gear Worm Housing Cover	1948,1949,501 thru 504
BZ 301224	Worm Housing Cover Assy-Steering Gear	1948,1949,501 thru 504
BZ 301226	Bracket-Brake Control Lever Pivot Pin-RHD	1948 thru 1950
BZ 301227	Guide Plate Assy-Hand Brake Cable Lever-RHD	1948 thru 1950
BO 301229	Elbow-Windshield Defroster Outlet-With W/Control	1948 thru 1950
BZ 301231	Brace Assy-Hand Brake Cable Lever Pivot-RHD	1948
BZ 301233	Bracket Assy-Brake Master Cylinder-RHD	1948 thru 1950
EM 301235	Brace-Carburetor Air Cleaner-Dry	1948 thru 1950 8 Cyl With VD-HDM or SMD
BT 301239	Clip-Handy Shift Wire & Case Assy-Without HDM	All
*F 301240	Shock Absorber Assy-Front	1948,1949
*F 301241	Shock Absorber Assy-Rear	1948 thru 1950
BO 301242	Wire Assy-License Lamp	1948-1949 BsCpe-ClubCpe-CvBro
BT 301244	Bracket Assy-HDM Diaphragm Mounting	1948 thru 1950
F 301246	Clutch Driven Disc Complete	1948,1949,501 thru 504,500 With OD,HDM or SMD
BT 301251	Clutch Assy	1948,1949,501 thru 504,500 With OD,HDM or SMD
BO 301252	Jumper Wire Assy-Weather Control-LHD	1948,1949
BT 301255	Adapter-OD Control Mounting Bracket	1948,1949
EM 301256	Cap Assy-Oil Filler	1948 thru 1950 8 Cyl
BM 301257	Brace-Carb Air Cleaner(Dry)-Without VD-HDM or SMD	1948 thru 1950 8 Cyl
BZ 301258	Protector-Gas Tank Filler Neck	1948 thru 1950
BM 301261	Carb Air Cleaner-Dry-With HDM or SMD	1948,1949,501 thru 504
*BM 301262	Carb Air Cleaner-Oil Bath-With VD-HDM or SMD	1948 thru 1950 8 Cyl
301263	Spacer-HDM Power Unit Mounting Stud (Use 301676)	1948 thru 1950
EM 301265	Brace-Carb Air Cleaner (Dry)	1948-1949 6 Cyl
BM 301266	Brace-Carb Air Cleaner(Oil)-Without VD-HDM or SMD)	1948 thru 1950 8 Cyl
EM 301267	Brace Assy-Carb Air Cleaner(Oil)-With VD-HDM or SMD	1948 thru 1950 8 Cyl
BZ 301270	Pedal Pad & Rod Assy-RHD	1948
BZ 301272	Lever-Clutch Pedal-RHD	1948
BZ 301273	Lever-Brake Pedal-AHD	1948
BO 301274	Cover-DI Switch Case	1948,1949
301275	Clamp-Gas Tank Filler Neck Protector (Use 302308)	1948
EM 301276	Pulley Assy-Water Pump	1948 thru 1950
F 301279	Fan Belt-Water Pump	1948 thru 1950
BZ 301280	Spring-Clutch Pedal Lever Return-LHD	1948

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 301281	Clip-Clutch Link Clevis Pin	1948 All,1949-501 thru 504 RHD
BZ 301282	Clip-Clutch Pedal Lever Return Spring-Rear-LHD	1948,1949,501 thru 504
BM 301286	Bearing-Crankshaft-#1	1948 6 Cyl
BM 301287	Bearing-Crankshaft-#2	1948 6 Cyl
	301288 Bearing-Crankshaft-#3 (Use 302736)	1948 6 Cyl
BM 301289	Bearing-Crankshaft-#4	1948 6 Cyl
	301290 Bearing-Connecting Rod (Use 302746)	1948 6 Cyl
C 301291	Housing Complete-Clutch-RHD	1948 thru 1950
C 301292	Housing Assy-Clutch-RHD	1948 thru 1950
C 301293	Yoke,Shaft & Lever Assy-Clutch Shifter-RED	1948 thru 1950
BT 301294	Coupling Lever-Clutch Control-RED	1948 thru 1950
BZ 301295	Cross Shaft & Coupling Lever Assy-Clutch-RHD	1948,1949,501 thru 504
BZ 301298	Link Assy-Clutch Control-RHD	1948,1949,501 thru 504
BZ 301299	Link-Clutch Control RHD	1948,1949,501 thru 504
BZ 301300	Lever Assy-Clutch Pedal-RED	1948
BZ 301301	End Lever-Brake Pedal Lever Shaft-RED	1948 thru 1950
BZ 301302	Shaft-Pedal Lever-RHD	1948 thru 1950
BZ 301303	Link-Brake Pedal to Master Cylinder-RHD	1948 thru 1950
BM 301304	Stop-Exhaust Damper Anti-Rattle	1948 thru 1950 6 Cyl
BO 301305	Socket-Courtesy Lamp	482-484-492-494-502-504 exc CvBro
BM 301308	Spring-Oil Check Valve Plunger	1948 thru 1950 6 Cyl
BZ 301309	Bracket-Grille Center Support-At #1 C/M	1948,1949
	301310 Cable A ssy-Speedometer-Without OD-LHD (Use 302288)	1948,1949
BZ 301311	Core-Speedometer Cable	1948,1949
	301312 Cable Assy-Speedometer-With OD-LHD (Use 302289)	1948,1949
BZ 301314	Bushing-Accelerator Pedal Link Bellcrank- With VD-HDM or OD	1948 thru 1950
C 301316	Hub Complete-Front	1948,1949,501 thru 504
BX 301320	Steering Spindle-RH	1948 thru 1950
BX 301321	Steering Spindle-LH	1948 thru 1950
C 301322 Pr	Wheel Assy-15 x 550	1948 thru 1950
BO 301340	Washer-Socket Insulating	1948 thru 1950 All
BO 301341	Contact-Socket Wire Retainer	1948,1949,501 thru 504
BM 301342	Cover & Shoe Assy-Timing Chain	1948 thru 1950 6 Cyl
BM 301344	Shoe-Timing Chain Cover	1948 thru 1950 6 Cyl
BM 301345	Bumper-Timing Chain Cover'Shoe	1948 thru 1950 6 Cyl
BZ 301348	Lever Assy-Brake Control-RHD	1948 thru 1950
*C 301350	Front Frame Assy-RHD	1948,1949,501 thru 504
	301351 Crossmember Assy #3-Front Frame (Use 302814)	1948,1949
BT 301356	Shift Rail-Trans Second & High	1948 thru 1950
BT 301359	Bushing-Handy Shift Bellcrank Sleeve-With-HDM	1948,1949,501 thru 504
BO 301362	Sleeve-Weather Control Bowden Wire	1948
BT 301363	Shift Rail-Trans Low & Reverse-With OD	1948 thru 1950
C 301368	Lever,Tube & Rod Assy-Handy Shift-RHD	481,483,491,493,500,501,503
C 301369	Lever Tube & Rod Assy-Handy Shift-RHD	482,484,492,494,502,504
C 301370	Tube & Fulcrum Brkt Assy-Handy Shift-RHD	481,483,491,493,500,501,503
C 301371	Tube & Fulcrum Brkt Assy-Handy Shift-RHD	482,484,492,494,502,504
BT 301374	Mounting Plate Assy-Handy Shift Bellcrank-RHD	1948,1949,501 thru 504
BT 301377	Support Assy-Handy Shift Bellcrank-RHD	1948,1949,501 thru 504
BT 301380	Rod Assy-Handy Shift Tube to Bellcrank-RHD	1948,1949,501 thru 504
BT 301382	Rod Assy-Handy Shift Bellcrank to Bellcrank-RHD	1948,1949,1950
BM 301384	Air Cleaner-Carburetor-Oil Bath-With HDM or SMD	481,482,491,492,501,502
BT 301385	Wire-Harness-Overdrive-LHD	1948
BX 301388	Steering Arm-Outer-Right-RED	1948,1949,501 thru 504
BX 301389	Steering Arm-Outer-Left-RHD	1948,1949,501 thru 504
BX 301391	Steering Arm & Pivot Assy-Center-RHD	1948 thru 1950 All
BX 301392	Steering Arm Center-RHD	1948 thru 1950 All
BX 301393	Bracket-Center Strg Arm Pivot Support-RHD	1948 thru 1950 All
BZ 301394	Pitman Arm-Steering Arm-RHD	1948,1949,501 thru 504
C 301395	Side Member Assy-Frt-Front-RH	1948,1949,501 thru 504
C 301396	Side Member Assy-Frt-Front-LH	1948,1949,501 thru 504
C 301397	Crossmember Assy-#1-Front Frame	1948 thru 1950
BX 301398	Bracket & Bearing Assy-Center Steering Arm-RHD	1948 thru 1950 All
	301402 Drag Link Assy (Use 301403)-RHD	1948
C 301403	Drag Link Assy RHD	1948 thru 1950
BZ 301405	Ball Seat-Drag Link	1948 thru 1950 RHD, 500 LHD
C 301408	Frt Suspension Comp-RH-RHD	1948
C 301409	Frt Suspension Comp-LH-RHD	1948
BT 301411	Shell Assy-HDM Power Cylinder	1948 thru 1950
BT 301413	Wire Harness-HDM	1948-1949 HDM cars Without OD
BT 301414	Wire Assy-Ignition Coil to HDM Inst Panel Switch	1948-1949 with HDM
BT 301416	Tube-HDM Power Cyl to Selector Valve	1948 thru 1950
BT 301421	Tube-HDM Valve to Cylinder (Use 301422,301425 & 48465)	1948

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 301422	Tube Assy-HDM Valve to Cyl-Cyl Stud End	1948 thru 1950
BT 301424	Tube-HDM Valve to Cyl-Valve End	1948 thru 1950
BT 301425	Tube Assy-HDM Valve to Cylinder-Valve End	1948 thru 1950
BZ 301434	VD Bracket-Complete-With VD-HDM or SMD	1948 thru 1950 6 Cyl
BZ 301438	VD Bracket-Complete-With VD-HDM or SMD	1948 thru 1950 8 Cyl
BT 301442	Screw-HDM Engaging Rod End	1948 thru 1950
BZ 301444	Cross Shaft & Lever-Accelerator-LHD	1948 8 Cyl
BZ 301451	Cylinder Assy-VD	1948-1949 with VD or HDM
BZ 301454	Tube & Nut-VD Throttle Lock Solenoid to Diaphragm	1948 thru 1950 with HDM or SMD
BZ 301456	Tube & Nut-VD Throttle Lock Diaphragm to Solenoid	1948 thru 1950 With HDM or SMD
BZ 301459	Cable Assy-VD Throttle Lock Diaphragm	1948-1949-501 thru 504 With IIDM or SMD
C 301464	Exhaust Pipe Assy-FrontRHD	1948-1949 6 Cyl,501,502
C 301466	Exhaust Pipe Assy-Front-RHD	1948 thru 1950 8 Cyl
	301469 Pedal Complete-Accelerator (Use 303142)	482,484,492,494,481-483-491-493 exc CvBro and with Lea Trim
BZ 301470	Cover-Pedal Pad-Taupe	482,484,492,494,481-483-491-493 exc CvBro and with Lea Trim
*HA 301471	Steering Wheel Kit-18"	481,483,491,493
EM 301472	Pipe Assy-Oil Pump to Check Valve-RHD	1948 thru 1950 8 Cyl
BZ 301474	Pipe Assy-Union to Fuel Pump-RHD	481,482,491,492,501,502
BZ 301475	Pipe Assy-Union to Fuel Pump-RHD	1948 thru 1950 8 Cyl
BT 301477	Spacer-HDM Mounting Bracket-Support	1948 thru 1950
BT 301479	Anchor Bracket-OD Control Cable	1948
EM 301484	Charge Regulator-Generator-6V	1948,1949
EM 301485	Charge Regulator-Generator-12V	1948,1949
BT 301490	Anchor-HDM Mounting Bracket Support	1948 thru 1950
C 301491	Case Assy-Transmission-Without OD	1948
C 301493	Case Assy-Transmission-With OD	1948
BT 301495	Seal-Trans Shift Shaft	1948 thru 1950
BZ 301496	Pipe Complete-VD Vacuum	1948-1949 6 Cyl with VD or HDM
BZ 301497	Pipe Assy-VD Vacuum-Manifold End	481,482,491,492,501,502
BZ 301498	Pipe Assy-VD Vacuum-Valve End	481,482,491,492,501,502
*HA 301500	Vacumotive Drive Kit	1948-1949 6 Cyl without OD
*HA 301501	Vacumotive Drive Kit	1948-1949 8 Cyl without OD
*HA 301502	Vacumotive Drive Kit	1948-1949 6 Cyl with OD
*HA 301503	Vacumotive Drive Kit	1948-1949 8 Cyl with OD
BZ 301504	Vacuum Pipe Assy-HDM Power Unit-VD Tee	1948 thru 1950
BZ 301505	Vacuum Pipe Assy-HDM Power Unit-Unit End	1948 thru 1950 6 Cyl
BZ 301506	Hose-HDM Power Unit Vacuum Pipe Coupling	1948 thru 1950
BZ 301507	Spring-HDM Power Unit Vacuum Pipe Hose Reinf	1948 thru 1950
BZ 301508	Pipe Assy-HDM Power Unit Intake	481-482-491-492-501-502 Less Oil Bath Air Cleaner
BZ 301509	Pipe Assy-HDM Power Unit Intake	481-482-491-492-501-502 With Oil Bath Air Cleaner
BZ 301510	Washer-Pedal Toe Plate Bumper	1948,1949,501 thr.t 504
	301512 Gasket-OD to Transmission Case (Use 302421)	1948
*HA 301513	Carb Oil Bath Air Cleaner Kit	-481,482,491,492,501,502
*HA 301514	Carb Oil Bath Air Cleaner Kit	1948 thru 1950 8 Cyl
SP 301517	Fuel Pump Assy-RHD	1948 thru 1950 8 Cyl
SP 301518	Comb Fuel & Vacuum Pump Assy-RHD	1948 thru 1950 8 Cyl
BO 301519	Wire Assy-Rear Quarter Lamp	482,484,492,494,502,504 exc CvBro
EM 301520	Elbow-Exhaust Manifold Outlet-RHD	1948 thru 1950 6 Cyl
F 301522	Pin-Piston-002 o s	1948 thru 1950 6 Cyl
F 301523	Pin-Piston-005 os	1948 thru 1950 6 Cyl
F 301524	Pin-Piston-010 o/s	1948 thru 1950 6 Cyl
BT 301526	Gear-Speedometer-11 Theth-Without OD	1948 thru 1950
BT 301527	Pinion-Speedometer-16 Teeth	1948 thru 1950
BT 301529	Pinion-Speedometer-18 Teeth	1948 thru 1950
BT 301530	Pinion-Governor-16 Teeth-Used with VD-OD or HDM	1948 thru 1950
BT 301532	Pinion-Governor-18 Teeth-Used With VD-OD or HDM	1948 thru 1950
BT 301534	Gear-Speedometer-11 Teeth-With OD	1948 thru 1950
BZ 301535	Jack Base	1948,1949,1950
BZ 301537	Clip-Clutch Pedal Lever Return Spring-RHD	1948,1949,501 thru 504
BZ 301538	Spring-Clutch Pedal Lever Return-RHD	1948,1949,501 thru 504
BT 301539	Clip-Clutch Shifter Yoke Shaft Cplg Lever Ret Spring-RHD	1948 thru 1950
BZ 301543	Pipe Complete-VD Vacuum	1948-1949 8 Cyl with VD or HDM
BZ 301544	Pipe Assy-VD-Manifold End	1948 thru 1950 8 Cyl
BZ 301545	Pipe Assy-VD-Valve End	1948 thru 1950 8 Cyl
EM 301547	Oil Check Valve Assy	1948 thru 1950 8 Cyl
BT 301548	Pipe Assy-HDM Power Unit Intake	1948 thru 1950 8 Cyl
C 301564	Spring & Cover Assy-Rear	1949 Bro-Sed-Cpes
	301566 Spring & Cover Assy-Rear (Use 302761)	1948 CvBro
*C 301569	Engine Assy-Alum Head	1948 thru 1950 8 Cyl
C 301584	Exhaust Manifold Assy	1948 thru 1950 8 Cyl
BT 301585	Vacuum Pipe Assy-HDM Power Unit	1948 thru 1950 8 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 301587	Bushing-Exhaust Damper Shaft	1948 thru 1950 8 Cyl
C 301595	Front Suspension Complete-RH	1948 thru 1950 All LHD
C 301596	Front Suspension Complete-LH	1948 thru 1950 All LHD
C 301597	Front Suspension Complete-RH	1948-1949-501 thru 504 RHD
C 301598	Front Suspension Complete-LH	1948-1949-501 thru 504 RHD
EM 301599	Damper-Exhaust	1948 thru 1950 6 Cyl
C 301605	Hub Complete-Front	1948
BZ 301609	Tool Kit-Export	1948,1949
BZ 301610	Silencer-Horn Ring	1948
BZ 301611	Spring-Horn Ring	1948
BZ 301612	Cushion-Prop Shaft Center Brg Support	1948
BZ 301613	Tool Kit	1948 thru 1950
	301614 Tool Kit (Use 301613)	1948
BO 301615	Name Plate-Hudson Weather Control	1948,1949,500
*HA 301619	Exhaust Deflector Assy-Tail Pipe	All
C 301621	Coil Spring-Front	1948 thru 1950
C 301622	Spring & Cover Assy-Rear	1948,1949
C 301624	Air Deflector-Radiator	1948 thru 1950 6 Cyl
BZ 301625	Rod Assy-Accelerator Cross Shaft-LHD-With VD or HDM	1948 6 Cyl
BZ 301627	Rod Assy-Accelerator Cross Shaft-LHD-With VD or HDM	1948-1949 8 Cyl
BZ 301630	Support Assy-Accelerator Cross Shaft-LHD	1948 thru 1950 8 Cyl
BZ 301631	Cross Shaft & Lever-Accelerator-LHD	1948-1949 6 Cyl
BZ 301632	Cross Shaft & Lever-Accelerator-LHD	1948-1949 8 Cyl
*F 301637	Shock Absorber Assy-Front-Extra Heavy Control	1948 thru 1950
*F 301638	Shock Absorber Assy-Rear-Extra Heavy Control	1948 thru 1950
C 301639	Air Deflector-Radiator	483,484,493,494,500,503,504
BO 301640	Wire Assy-OD Control Switch to Governor	1948-1949 OD cars Without HDM
*BM 301644	Carburetor Assy-RHD	1948 thru 1950 8 Cyl
*BM 301645	Carburetor Assy-RHD	481,482,491,492,501,502
BM 301646	Adaptor-Oil Check Valve-RHD	1948-1949-1950 8 Cyl
BZ 301647	Support-Exhaust Pipe Front Clamp-RHD	1948,1949,501 thru 504
BZ 301648	Tube Assy-Brake Master Cul to Frt Cover-RHD	1948,1949
BZ 301649	Tube Assy-Brake Front Conn to Rear Cover-RHD	1948,1949
BZ 301651	Anchor Bracket-Ace Pedal-RHD	1948,1949,501 thru 504
BZ 301652	Rod-Ace Pedal to Cross Shaft Lever-RHD	1948,1949,501 thru 504
BZ 301653	Cross Shaft Assy-Lower-Accelerator-RHD	1948,1949,501 thru 504
BZ 301659	Spring-Ace Cross Shaft-Lower-RED	1948 thru 1950
	301660 Cross Shaft Assy-Upper-Accelerator (Use 302123, 302128,5774,71443,71522)	1948 RHD
BZ 301666	Rod-Connecting-Ace Cross Shaft-RHD	1948
BZ 301667	Pivot-Ace Cross Shaft Connecting Rod-RED	1948 thru 1950 All
BZ 301668	Spring-Ace Cross Shaft Connecting Rod Pivot-RHD	1948 thru 1950 All
BZ 301670	Rod-Ace Cross Shaft to Carb-RHD	1948 thru 1950 6 Cyl
BZ 301672	Rod-Accelerator Cross Shaft to Carb-RHD	1948 thru 1950 8 Cyl
BT 301673	Ground Strap-HDM Power Unit	1948 thru 1950
*HA 301674	Hydraulic Jack	All
*HA 301675	Hook-Hydraulic Jack	All
BT 301676	Washer-HDM Power Unit Mtg Stud	1948 thru 1950
EM 301677	Breather Tube Assy-RHD	1948 thru 1950 6 Cyl
EM 301681	Breather Tube Assy-RHD	1948 thru 1950 8 Cyl
BZ 301683	Wire Harness-Vacumotive Drive	1948,1949
BZ 301692	Guard Assy-Brake Master Cylinder-LHD	1938 thru 1950
EM 301695	Pipe Assy-Fuel Pump to Carb-RHD	1948 thru 1950 8 Cyl
EM 301696	Pipe Assy-Comb Fuel & Vacuum Pump to Main-RHD	1948 thru 1950 8 Cyl
BT 301699	Lever-Trans Shift Selector-Outer-Without HDM	1948 thru 1950
C 301705	Housing-Overdrive	1948 thru 1950
BT 301706	Gasket-OD Housing	1948 thru 1950
BT 301708	Adapter-OD Housing	1948 thru 1950
BT 301709	Oil Baffle-Trans Mainshaft Rear Brg	1948 thru 1950 With OD
BT 301710	Stationary Gear Plate & Balk Ring Assy-OD	1948 thru 1950
BT 301712	Cover Plate, Pin & Trough Assy-OD	1948 thru 1950
BT 301717	Snap Ring-OD Cover Plate	1948 thru 1950
BT 301718	Snap Ring-OD Cover Plate	1948 thru 1950
BT 301719	Snap Ring-OD Cover Plate	1948 thru 1950
BT 301720	Pawl-OD Stationary Gear	1948 thru 1950
BT 301722	Collar-OD Stationary Gear	1948 thru 1950
BT 301723	Stationary Gear-OD	1948 thru 1950
BT 301724	Snap Ring-OD Stationary Gear	1948 thru 1950
BT 301725	Cage Assy-OD Pinion	1948 thru 1950
BT 301734	Free Wheel Cam Assy-OD	1948 thru 1950
BT 301735	Clip-OD Free Wheel Pinion Cage Retainer	1948 thru 1950
BT 301736	Free Wheel Cam-OD	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 301737	Retainer-OD Free Wheel Cam Roller	1948 thru 1950
BT 301738	Retainer-OD Free Wheel Cam	1948 thru 1950
BT 301739	Main Shaft & Ring Gear Assy-OD	1948 thru 1950
BT 301744	Shift Rail & Fork Assy-Overdrive	1948 thru 1950
BT 301745	Shift Rail-Overdrive	1948 thru 1950
BT 301746	Shift Fork-Overdrive	1948 thru 1950
BT 301747	Pin-OD Shift Rail Sleeve	1948 thru 1950
BT 301748	Sleeve-OD Shift Rail	1948 thru 1950
BT 301749	Spring-OD Shift Rail Sleeve	1948 thru 1950
BT 301750	Spring-OD Shift Rail Retractor	1948 thru 1950
BT 301751	Control Lever-OD	1948 thru 1950
BT 301752	Control Shaft-OD	1948 thru 1950
BT 301754	Washer-OD Control Shaft	1948 thru 1950
BT 301755	Switch-Overdrive Control	1948 thru 1950
BT 301756	Gasket-OD Control Switch to Hsg	1948 thru 1950
BT 301757	Solenoid Assy-OD	1948,1949
BZ 301758	Tube Assy-Brake Master Cyl to Frame Tee-RHD	1948,1949,501 thru 504
BZ 301759	Tube Assy-Frame to Front Right Brake Hose-RHD	1948,1949,501 thru 504
BZ 301760	Tube Assy-Frame Tee to Front Left Hose-RHD	1948,1949,501 thru 504
BZ 301761	Tee-Brake Tube-RHD	1948,1949,501 thru 504
C 301762	Wire & Casing Assy-OD Control-LHD	1948,1949,500
C 301763	Wire & Casing Assy-OD Control	1948-1949 501 thru 504 RHD with OD 500 LH with OD
BT 301764	Mounting Brkt-OD Control	1948,1949
C 301765	Cylinder Head Assy-Iron	1948-1949 6 Cyl,501,502
F 301767	Shock Absorber Assy-Front-Heavy Control	1948,1949
301768	Shock Absorber Assy-Rear-Heavy Control(Use 301770)	1948 thru 1950
*C 301769	Shock Absorber Assy-Front-Heavy Control	1948,1949
*F 301770	Shook Absorber Assy-Rear-Heavy Control	1948 thru 1950
BO 301771	Tube-Weather Control Core	1948,1949
EM 301772	Stud-Cylinder Head-Medium	1948 thru 1950 8 Cyl
BO 301775	Clamp-DI Flasher Switch	1948 thru 1950
BZ 301776	Shim-VD Bellcrank Shaft-With VD-HDM or SMD	1948 thru 1950
CC 301779	Crankshaft Assy	1948-1949 6 Cyl,501,502
EM 301789	Cover-Oil Pump	1948 thru 1950 6 Cyl
EM 301790	Gasket-Oil Pump Cover	1948 thru 1950 6 Cyl
BT 301791	Plunger-OD Interlock	1948 thru 1950
BT 301792	Plunger-OD Interlock	1948 thru 1950
BT 301793	Plunger-OD Interlock	1948 thru 1950
* C 301798	Crankshaft Assy-010 u/size	1948-1949 6 Cyl,501,502
301802	Transmission Assy (Use 303932)	1948-1949 Without OD or HDM
*C 301803	Transmission Assy-Without OD and With HDM	1948,1949
301804	Transmission Assy-With OD and Without HDM	1948,1949
*C 301805	Transmission Assy-With OD and 11DM	1948,1949
301806	Transmission & O/D Assy-Without HDM(Use 302812)	1948,1949
*C 301807	Transmission & O/D Assy-With HDM	1948,1949
BZ 301808	Vent Hose-Gas Tank	1948 thru 1950
BZ 301809	Vent Pipe-Gas Tank Filler Neck	1948 thru 1950
EM 301810	Seal-Crankshaft Rear Bearing	1948 thru 1950 6 Cyl
C 301813	Intake-Manifold Assy-Cast Iron	1948 thru 1950 8 Cyl
301815	Intake-Manifold Assy-Alum (Use 301813)	1948 thru 1950 8 Cyl
BX 301817	Dirt Shield-Drive Pinion Oil Seal	1948 thru 1950
BZ 301820	Tool Bag Assy	1948,1949,1950
C 301821	Wire,Casing & Brkt Assy-Handy Shift-With HDM	1948 thru 1950
BT 301822	Rod-HDM Cross-Over Switch	1948,1949
BT 301823	Lever Assy-Outer-Trans Shift Selector-With HDM	1948 thru 1950
BO 301826	Case & Bracket Assy-Ignition Lock-RHD	1948 thru 1950
BO 301828	Wire Harness-Instrument-RIM	1948,1949
BO 301829	Wire Harness-Headlamp Feed-RHD	1948,1949
BT 301830	Wire,Casing & Brkt Assy-Handy Shift-RHD	1948 thru 1950
BT 301831	Wire & Casing Assy-Handy Shift-RHD	1948 thru 1950
BZ 301833	Guard Assy-Brake Master Cylinder-RHD	1948 thru 1950 All
BM 301834	Wire Harness-Engine-RHD	1948-1949 6 Cyl
EM 301835	Wire Harness-Engine-RIM	1948-1949 8 Cyl
BO 301836	Wire Harness-Body-Left Side-RHD	482-484-492-494 Sedan
BO 301837	Wire Harness-Body-Left Side-RIM	482-484-492-494 ClubCpe-BsCpe
C 301838	Case Assy-Transmission-With OD	1948 thru 1950
C 301841	Case Assy-Transmission-Without OD	1948 thru 1950
BZ 301843	Housing Assy-Steering Gear-RHD	1948,1949,501 thru 504
BZ 301845	Shaft & Roller Tooth Assy-Strg Gear-RHD	1948,1949,501 thru 504
C 301847	Main Column & Worm-Strg Gear-RHD	1948,1949,501 thru 504
BT 301849	Compression Spring-Handy Shift Tube	1948 thru 1950
BO 301851	Lever-Direction Indicator Control	1948 thru 1950
BO 301852	Wire Protector-DI Conduit	1948 thru 1950
BO 301853	Circuit Breaker Assy-20 Amp	1948 thru 1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 301854	Wire Harness-OD	1948,1949
BO 301855	Juniper Wire Assy-Weather Control-RHD	1948,1949
EM 301856	Wire Assy-Oil Pressure Contact to Inst Harness-RHD	1948-1949 8 Cyl
BM 301857	Pipe Assy-Comb Fuel Pump to Manifold	481,482,491,492,501,502
BT 301859	Taper Pin-OD Control Shaft	1948 thru 1950
BT 301860	Clip-Handy Shift Wire & Casing Assy-RHD	1948 thru 1950
BZ 301862	Rod-Accelerator Pedal to Bellcrank-LHD	1948-1949 6 Cyl
BZ 301864	Rod-Accelerator Pedal to Bellcrank-LHD	1948-1949 8 Cyl
BZ 301865	End-Accelerator Pedal to Bellcrank Rod-LHD	1948,1949
BZ 301866	Rod Assy-VD Bellcrank to Coupling Lever	1948 thru 1950 6 Cyl With VD or HDM or SMD
BZ 301867	Rod Assy-VD Bellcrank to Coupling Lever	1948 thru 1950 8 Cyl With VD or HDM or SMD
BZ 301868	Rod-VD Bellcrank to Coupling Lever	1948 thru 1950 6 Cyl With VD-HDM or SMD
BZ 301869	Rod-VD Bellcrank to Coupling Lever	1948 thru 1950 8 Cyl With VD-HDM or SMD
BZ 301870	Cover Set-Rear Spring-Front Half	1948,1949
BZ 301871	Cover Set-Rear Spring-Rear Half	1948,1949
BO 301872	Nipple-Weather-Control Pipe	1948 thru 1950
EM 301873	Wire Assy-Coil to Distributor-High Tension-RHD	1948-1949 8 Cyl
BO 301876	Wire Assy-Coil to Distributor-Low Tension-RHD	483,484,493,494,503-504 Without OD
BZ 301877	Wire Assy-Horn Button to Horn Relay-RHD	1948 thru 1950
F 301878	Piston Assy-Brake Master Cylinder	1948 thru 1950
BO 301881	Wire Harness-Body-Right-RHD	481-483-491-493 Bro-Sed with DI
BO 301882	Wire Harness-Body-Right-RHD	482-484-492-494 Sed with DI
BO 301883	Wire Harness-Body-Right-RHD	482-484-492-494 BsCpe-ClubCpe with DI
BO 301884	Wire Harness-Body-Right-RHD	481-483-491-493 BsCpe-ClubCpe With DI
BO 301885	Wire Harness-Direction Indicator-Front-RHD	1948,1949
301886	Water Valve-Weather-Control (Use 302628 & 302629)	1948,1949
BO 301887	Seal-Weather-Control Water Valve Dash Hole	1948 thru 1950
BO 301888	Plate-Weather Control Water Valve Dash Hole Seal	1948 thru 1950
BO 301889	Clip-Weather Control Water Valve Capillary Tube	1948 thru 1950
BO 301890	Bowden Wire-Weather-Control	1948,1949
BO 301893	Hose-Weather Control-72"	1948 thru 1950
BT 301897	Cover Assembly-Transmission	1948-1949 with OD
BT 301898	Lever-Handy Shift-RHD	1948 thru 1950
BT 301899	Clip-Handy Shift Wire & Casing-With HDM	1948 thru 1950
BT 301900	Wire Harness-Overdrive-LHD	1948-1949 OD cars without HDM
BT 301901	Cover Assembly-Transmission	1948-1949 Without OD with HDM or VD
BT 301902	Clip-Cross Over Switch Rod-at Clutch Housing	1948 thru 1950
BT 301903	Clip-Control Wire Casing-At #2 Crossmember-RHD	1948 thru 1950
301904	Knob-Handy Shift Lever (Use 301996)	481-483 with 17" wheel
EM 301905	Elbow & Stud Assy-Exhaust Manifold-RHD	1948 thru 1950 8 Cyl
BZ 301906	Pad-Gas Tank	1948,1949
EM 301908	Wire Assy-Coil to Distributor-High Tension	1948-1949 6 Cyl
BO 301911	Wire Assy-Ignition Coil Lock to VD Inst Panel Switch	1948,1949
BT 301912	Washer-Handy Shift Bellcrank Pivot	1948-1949-501 thru 504 Without HDM,500 RHD
BZ 301913	Guard-Frame #3 Crossmember-RH	1948,1949,501 thru 504
BZ 301914	Guard-Frame #3 Crossmember-LH	1948,1949,501 thru 504
*HS 301915	White Sidewall Tire Cleaner-13 oz	All
BT 301918	Boot-Wire Harness Plug Socket Cap	1948-1949 with VD or HDM
BT 301919	Spring-Handy Shift Push Rod-LHD	1948 thru 1950 Without HDM or SMD
*BZ 301921	Shock Absorber Assy-Rear	1940 Export
BT 301922	Bracket-OD Control Wire Casing Anchor-RHD	1948 thru 1950
BO 301925	Wire Assy-Harness to Right Courtesy Light	482-484-492-494-502-504 CvBro
BO 301926	Wire Harness-Body Rear Compt	1948-1949 CvBro
BO 301927	Wire Harness-Body	481-491 CvBro without DI
BO 301928	Wire Harness-Body	481-491 CvBro with DI
BO 301929	Wire Harness-Body	482-484-492-494 Without DI
BO 301930	Wire Harness-Body	482-484-492-494 with DI
BO 301931	Brkt & Cable Holder Assy-Ignition Coil-RHD	1948 thru 1950 6 Cyl
BM 301934	Vibration Dampener Assy	1948 thru 1950
EM 301935	Fan Pulley-Vibration Dampener	1948 thru 1950
BZ 301938	Bushing-Pedal Lever Shaft Housing	1948 thru 1950
BT 301939	Sleeve-Overdrive Clutch Hub	1941 thru 1947
BM 301941	Oil Pump Assy-Less Fittings	1936 thru 1947 All,1948 thru 1950 8 Cyl
EM 301942	Metering Rod Pkg-Carburetor	481,482,491,492,501,502
EM 301943	Metering Rod-Carburetor-Std	1948-1949 6 Cyl
301944	Metering Rod-Carburetor-1st Leaner	481,482,491,492,501,502
301945	Metering Rod-Carburetor-2nd Leaner	481,482,491,492,501,502
301946	Metering Rod-Carburetor-3rd Leaner	481,482,491,492,501,502
EM 301947	Metering Rod Pkg-Carburetor	1948 thru 1950 8 Cyl
EM 301948	Metering Rod-Carburetor-Std	1948 thru 1950 8 Cyl
301949	Metering Rod-Carburetor-1st Leaner	1948 thru 1950 8 Cyl
301950	Metering Rod-Carburetor-2nd Leaner	1948 thru 1950 8 Cyl
301951	Metering Rod-Carburetor-3rd Leaner	1948 thru 1950 8 Cyl
BO 301954	Holder & Clip Assy-Ignition Cable-RHD	1948 thru 1950 8 Cyl

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
EM 301955	Cover-Exhaust Pipe-RHD	1948 thru 1950 8 Cyl
BO 301956	Glass Jar-Automatic Battery Filler	All
BO 301957	Plastic Cap-Automatic Battery Filler Glass Jar	All
BO 301958	Tubes & Cap Assy-Automatic Battery Filler	All
F 301959	Oil Seal-Drive Pinion	1948 thru 1950
301963	Clamp-Weather Control & Underseat Heater Hose (Use 159080)	1948
BO 301964	Bowden Wire & Sleeve Assy-Weather Control	1948
*F 301965	Shock Absorber Assy-Front-Extra Heavy Duty	1940 thru 1947 All
*F 301966	Shock Absorber Assy-Rear-Extra Heavy Duty	1940 thru 1947 All
301967	Exhaust Manifold Assy (Use 303263)	1948-1949 6 Cyl
301968	Cushion-Prop Shaft-Center Brg Support-Front (Use 301612)	1948
C 301969	Steering Wheel-18"	1948,1949
BZ 301970	Ornament & Cap Assy-18" Strg Wheel	1948,1949
BZ 301973	Horn Ring & Center Assy-18" Strg Wheel	1948,1949
BZ 301975	Spring-Horn Ring-18" Strg Wheel	1948,1949
BZ 301976	Contact Cup-Horn Ring-18" Strg Wheel	1948,1949
BZ 301977	Retainer-Horn Ring-18" Strg Wheel	1948,1949
BZ 301978	Pin-Horn Ring Retainer-18" Strg Wheel	1948,1949
*C 301979	Trim Ring-Wheel	1948 thru 1950 with 15 x 5.50 wheel
*HA 301980	Kit-Wheel Trim Ring	1948 thru 1950 with 15 x 5.50 wheel
C 301981	Propeller Shaft-Front-Without OD	1948,1949,501 thru 504
C 301982	Propeller Shaft-Front-With OD	1948,1949,501 thru 504
C 301983	Propeller Shaft-Rear	1948 thru 1950
BZ 301984	Sleeve Yoke Assy-Rear Prop Shaft	1948 thru 1950
BT 301987	Rod Assy-Handy Shift Tube to Bellcrank-With HDM	1948,1949,501 thru 504
BO 301989	Socket-Lamp	482-484-492-494-502-504 CvBro
*HA 301990	Underseat Heater-Used with Weather Control	1948 thru 1950
*HA 301991	Weather Control Heater Complete-Thermostatically Controlled	1948,1949
BO 301994	Wire Assy-Courtesy Lamp Socket	482-484-492-494-502-504 CvBro
BT 301996	Knob-Handy Shift Lever	481-483-491-493 with 17" Strg Wheel
BT 301997	Knob-Handy Shift Lever	1948-1949 with Custom Strg Wheel,501,503 Std Wheel
BZ 301998	Push Button & Clamp Assy-Gas Tank Locking Cap	1948 thru 1950
BM 301999	Shaft & Rotors Assy-Oil Pump	1948 thru 1950 6 Cyl
BZ 302001	Ornament & Horn Ring Kit-18" Strg Wheel	1948,1949
BO 302003	Power Unit Assy-Top & Window Lift	1948 thru 1950 CvBro
BO 302006	Overflow-Hose-Top Control Power Unit	1948 thru 1950 CvBro
BO 302007	Valve Assy-Top Lift	1948 thru 1950 CvBro
BO 302008	Mtg Brkt-Top Lift Valve	1948 thru 1950 CvBro
BO 302009	Hose-Hyd Power Unit & Top Control Cyl	1948 thru 1950 CvBro
BO 302010	Hose-Hyd Power Unit & Top Control Cyl	1948 thru 1950 CvBro
BO 302011	'rube Assy-Pressure-Hose to Tee-Hyd Top	1948 thru 1950 CvBro
C 302013	Tube Assy-Pressure-Tee to Tee-Hyd Top	1948 thru 1950 CvBro
BO 302014	Tube Assy-Return-Conn to Valve-Hyd Top	1948 thru 1950 CvBro
BO 302015	Tube Assy-Pressure-Tee to Valve-Hyd Top	1948 thru 1950 CvBro
BO 302016	Tube Assy-Left Door Hyd Wdo Regulator-Hose to Cyl	1948 thru 1950 CvBro
C 302017	Tube Assy-Lower-Tee 'to Right Cyl-Hyd Top	1948 thru 1950 CvBro
BO 302018	Tube Assy-Upper-Valve to Conn-Hyd Top	1948 thru 1950 CvBro
BO 302019	Tube Assy-Lower-Valve to Conn-Hyd Top	1948 thru 1950 CvBro
C 302020	Tube Assy-Upper-Conn to Tee-Hyd Top	1948 thru 1950 CvBro
C 302021	Tube Assy-Lower-Conn to Tee-Hyd Top	1948 thru 1950 CvBro
BO 302022	Tube Assy-Uppor-Tee to Left Cyl-Hyd Top	1948 CvBro
C 302023	Tube Assy-Upper-Tee to Right Cyl-Hyd Top	1948 CvBro
C 302024	Tube Assy-Hyd Wdo Reg-Right Side	1948 thru 1950 CvBro
BO 302025	Tube Assy-Left Qtr Wdo Hyd Reg	1948 thru 1950 CvBro
C 302026	Hose-Door Hyd Wdo Lift-Right	1948 thru 1950 CvBro
BO 302027	Conduit-Hyd Wdo Lift Hose & Wire	1948 thru 1950 CvBro
C 302028	Tube Assy-Right Door Hyd Wdo Regulator-Tee to Hose	1948 thru 1950 CvBro
BO 302029	Tube Assy-Right Door Hyd Wdo Regulator-Hose to Cyl	1948 thru 1950 CvBro
BO 302030	Wire Harness-Window Regulator-LHD	481-491-500-501 CvBro with Hyd Wdo Reg
BO 302031	Wire Harness-Window Regulator-LHD	482-484-492-494-502-504 CvBro
BO 302032	Tube Assy-Right Qtr Hyd Wdo Reg	1948 thru 1950 CvBro
BO 302035	Clip-License Lamp Wire Loom at Rear Compt Door Pnl	1948,1949,500
BO 302037	Switch Assy-Multiple Window Lift	1948 CvBro with Hyd
BO 302038	Plate-Multiple Window Lift Switch	1948 thru 1950 CvBro
BO 302039	Switch Assy-Single Window Lift	1948 CvBro with Hyd Wdo Reg
BO 302040	Plate-Single Window Lift Switch	1948 thru 1950 CvBro
BO 302041	Clamp-Hyd Wdo Lift Hose & Wire Conduit	1948 thru 1950 CvBro
BO 302042	Guide-Top Lift Valve Operating Rod	1948 thru 1950 CvBro
BO 302043	Retainer-Top Lift Valve Oper Rod Mtg Nut	1948 thru 1950 CvBro
C 302044	Hose-Door Hyd Wdo Lift-LH	1948 thru 1950 CvBro
C 302045	Clamp Assy-Strg Gear Jacket Tube	1949,1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 302046	Bracket Assy-Top Life Valve Lever	1948 thru 1950 CvBro
BO 302047	Knob-Top Life Valve Operating Rod	1948 thru 1950 CvBro
BO 302049	Rod-Top Life Valve Operating	1948 thru 1950 CvBro
BO 302050	Lever-Top Life Valve Operating	1948 thru 1950 CvBro
BO 302051	Swivel-Top Life Valve Operating Lever	1948 thru 1950 CvBro
BO 302053	Rod-Top Life Valve Operating Lever	1948 thru 1950 CvBro
BO 302054	Plate-Weather Control Water Valve Dash Hole Seal Plate	1948 thru 1950 Without Weather-Control
BZ 302057	Jumper Wire Assy-VD Instrument Panel Switch	1948,1949
BO 302065	Wire Assy-Domelight	1948-1949-1950 CvBro
BT 302066	Shifter Yoke, Shaft & Coupling Lever Assy-Clutch-LHD	1948 thru 1950
C 302068	Lever, Tube & Rod Assy-Handy Shift-LHD	481-483-491-493 Without HDM
C 302069	Lever, Tube & Rod Assy-Handy Shift-LHD	482-484-492-494 Without HDM
BT 302074	Plunger-OD Interlock-1386	1948 thru 1950
BT 302075	Plunger-OD Interlock-1398	1948 thru 1950
BT 302076	Plunger-OD Interlock-1442	1948 thru 1950
BO 302077	Wire Assy-DI-Rear-RH	1948 thru 1950
BO 302078	Wire Assy-DI-Rear-LH	1948 thru 1950
BZ 302082	Rod Assy-Threaded Sleeve-VD Valve Lever Cam	481,482,491,492,501,502 With VD-HDM or SMD
BZ 302090	Wire Harness-Overdrive	1948,1949
*HS 302097	White Sidewall Tire Cleaner-1 Gal	All
BZ 302098	Screw-VD Valve Lever Cam	1948 thru 1950 With VD-HDM or SMD
BO 302099	Washer-Socket	1948 thru 1950
*HS 302103	Tire Pressure Gauge	All
BO 302104	Hose-Underseat Heater-Long	1948 thru 1950
BO 302105	Hose-Underseat Heater-Short	1948 thru 1950
BO 302107	Bracket-Underseat Heater Switch	1948 thru 1950
BO 302108	Jumper Wire Assy-Underseat Heater	1948 thru 1950
BO 302109	Clip-Underseat Heater Jumper Wire Fuse	1948 thru 1950
BO 302110	Feed Wire Assy-Underseat Heater	1948 thru 1950
BM 302114	Decal-Valve Tappet Clearance	1948 thru 1950 6 Cyl
BM 302115	Clip-Throttle Control Return-LHD	500 without HDM
BM 302115	Clip-Exhaust Damper Anti-Rattle Spring	1948-1949 6 Cyl,501,502
F 302116	Cable Assy-Battery to Starter Solenoid & Hyd Power Unit	1948 thru 1950 CvBro exc 500 CvBro
BM 302117	Wire Assy-Oil Pressure Contact to Inst Harness-RHD	1948-1949 6 Cyl
BZ 302118	Pad-OD Switch-Accelerator Pedal-LHD	1948 thru 1950
BZ 302119	Accelerator Pedal-LHD	481,483,491,493
BZ 302120	Accelerator Pedal-LHD	482,484,492,494
BZ 302123	Accelerator Cross Shaft-Upper-Assy	1948,1949,501 thru 504
BZ 302128	Connecting Rod-Accelerator Cross Shaft-RHD	1948,1949,501 thru 504
BM 302129	Wire Harness-Combination Overdrive, HDM & Engine-LHD	1948-1949 6 Cyl
BM 302130	Wire Harness-Combination Overdrive, HDM & Engine-LHD	1948-1949 8 Cyl
BZ 302139	End Lever-Pedal Shaft-LHD	1948,1949
BZ 302140	Spring-Clutch Pedal Lever Return-LHD	1948,1949,501 thru 504
BZ 302141	Cross Shaft & Coupling Lever Assy-Clutch Control-LHD	1948,1949,501 thru 504
BZ 302144	Link Assy-Clutch Control-LED	1948,1949,501 thru 504
BZ 302145	Link-Clutch Control-LHD	1948,1949,501 thru 504
BT 302146	Clip-OD Control Wire & Casing Assy-LHD	1948,1949
BT 302147	Bracket-OD Control Wire Casing-Clip	1948 thru 1950
BT 302148	Clip-OD Control Wire Casing	1948 thru 1950
BZ 302149	Rod Assy-Accelerator Cross Shaft-LHD	1948-1949 6 Cyl with VD or HDM
BZ 302156	Lever-Accelerator Pedal Link Bellcrank-With VD-HDM-OD	1948 thru 1950
BZ 302158	Reinforcement Assy-Front Frame Strg Gear-Left	1948,1949,501 thru 504
BZ 302159	Reinforcement Assy-Front Frame Strg Gear-Right-RHD	1948,1949,501 thru 504
*SP 302162	Comb Fuel & Vac Pump Repair Kit-Less Rocker Arm-AC	For 166218-19
*SP 302163	Comb Fuel & Vac Pump Diaphragm Kit-Fuel Side-AC	For 166218-19
*SP 302164	Comb Fuel & Vac Pump Diaphragm Kit-Vacuum Side-AC	For 166218-19
BZ 302169	Return Spring-Hand Brake	1948 thru 1950
*SP 302174	Battery Assy-National Type 1-S-100	
*SP 302175	Battery Assy-National Type 1-KG-100	
*SP 302176	Battery Assy-National Type 2L-KG-100	
*SP 302177	Battery Assy-National Type 2-S-115	
*SP 302178	Battery Assy-National Type 2-KG-120	
*SP 302179	Battery Assy-National Type 2F-KG-120	
*SP 302180	Battery Assy-National Type 2E-S-120	
*SP 302181	Battery Assy-National Type 2E-KG-120	

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
*HA 302182	Electric Shaver Kit	All
*SP 302185	Piston Ring Set-CI	1948 thru 1950 6 Cyl
C 302192	Rebound Leaf-Rear Spring	1948,1949
C 302193	Main Leaf-Rear Spring	1948 thru 1950
*SP 302214	Battery Assy-National Type-1-N-110	
*SP 302215	Battery Assy-National Type-1-W-90	
*SP 302216	Battery Assy-National Type-2L-N-110	
*SP 302217	Battery Assy-National Type-2L-W-90	
*SP 302218	Battery Assy-National Type-2-W-100	
*SP 302219	Battery Assy-National Type-2F-W-100	
*SP 302220	Battery Assy-National Type-2E-N-130	
*SP 302221	Battery Assy-National Type-2E-W-100	
C 302222	Support & Sidemember Assy-Prop Shaft Center Brg	1948,1949
C 302231	Cable Assy-Brake Rear	1948 thru 1950
BZ 302233	Bolt-Rear Axle Drive Gear	1948 thru 1950
BZ 302238	Bumper-Rear Axle	1948 thru 1950 All
F 302239	Cable Assy-Battery to Starter Solenoid	1948 thru 1950 exc CvBro
*BZ 302241	Filler Cap Assy-Gas Tank-Pressure Type	All
BO 302244	Plastic Cap-Auto Battery Filler Glass Jar-Green	All
BO 302245	Plastic Cap-Auto Battery Filler Glass Jar-Yellow	All
C 302247	Cover Set-Rear Spring-Front Half	1948
C 302248	Cover Set-Rear Spring-Rear Half	1948
BZ 302250	Lever Assy-Clutch Pedal-RHD	1948,1949,501 thru 504
BZ 302252	Lever-Brake Pedal-RHD	1948,1949,501 thru 504
F 302253	Cap Assy-Gas Tank Filler	1948 thru 1950 All
BO 302254	Tube Assy-Top Control	1948 thru 1950 CvBro
C 302255	Tube Assy-Top Control	1948 thru 1950 CvBro
*SP 302265	Radiator Filler Cap (Pressure Type)	1948 thru 1950
C 302267	Housing-Rear Axle	1949,1950
BX 302270	Shim-Rear Axle Housing Spring Pad	1948,1949
BX 302271	Bolt-Center-Rear Spring-For 302270 Shim	1948 thru 1950
BT 302272	Clip-HDM Harness at Vacuum Pipe	1948 thru 1950
BM 302273	Bolt & Nut Assy-Carb Oil Bath Air Cleaner Clamp	481,482,491,492,501,502
BT 302274	Tie Cord-22"-HDM Harness-at Power Unit Plug	1948,1949
BO 302279	Connector Shell-DI Harness Fuse	1948,1949
BO 302280	Connector Cap-DI Harness Fuse	1948,1949
BO 302281	Insulator-Harness Fuse	1948,1949
BO 302282	Wire Assy-Direction Indicator	1948 thru 1950
C 302283	Tube Assy-Hyd Power Unit	1948 thru 1950
C 302284	Tube Assy-Hyd Power Unit	1948 thru 1950
BO 302286	Switch Assy-Multiple-Hyd Wdo Regulator	1948 thru 1950 CvBro
BO 302287	Switch Assy-Single-Hyd Wdo Regulator	1948 thru 1950 CvBro
BZ 302288	Cable Assy-Speedometer-Without OD-LHD	1949,501 thru 504
BZ 302289	Cable Assy-Speedometer-With OD-LHD	1949,501 thru 504
BZ 302290	Cable Assy-Speedometer-Without OD-RHD	1949,501 thru 504,500 LHD With OD or SMD
BZ 302291	Cable Assy-Speedometer-With OD-RHD	1949,501 thru 504
F 302293	Connecting Rod & Cap Assy	481,482,491,492
F 302295	Bushing-Connecting Rod	1948 thru 1950 6 Cyl
BO 302297	Horn & Spring Plate Assy-RH	1948 thru 1950
BO 302298	Horn & Spring Plate Assy-LH	1948 thru 1950
BX 302299	Oil Washer-Drive Pinion	1948 thru 1950
*C 302301	Rebuilt Engine Assy-3" x 5"	1936
*C 302302	Rebuilt Engine Assy-3" x 5"	1937,1938,1939
*C 302303	Rebuilt Engine Assy-3" x 4-1/8"	1938,1939
*C 302304	Rebuilt Engine Assy-3" x 5"	1940
*C 302305	Rebuilt Engine Assy-3" x 4 1/8"	1940
*C 302306	Rebuilt Engine Assy-3" x 5"	1941 thru 1947
*C 302307	Rebuilt Engine Assy-3" x 4 1/8"	1941,1942
BZ 302308	Clamp-Gas Tank Filler Neck	1948 thru 1950
F 302309	Conn Rod & Cap Assy-RH- 020 U/S-For 302301 Rebuilt Engine	1936,1937
F 302310	Conn Rod & Cap Assy-LH-020 U/S-For 302301 Rebuilt Engine	1936,1937
F 302311	Conn Rod & Cap Assy-RH-020 U/S-For 302302, 302304, & 302306 Rebuilt Engines	1938 thru 1947
F 302312	Conn Rod & Cap Assy-LH-020 U/S-For 302302, 302304, &302306 Rebuilt Engines	1938 thru 1947
F 302313	Conn Rod & Cap Assy-RH-020 U/S-For 302303, 302305, & 302307 Rebuilt Engines	1938 thru 1942
F 302314	Conn Rod & Cap Assy-LH-020 U/S-For 302303, 302305, & 302307 Rebuilt Engines	1938 thru 1942
BO 302315	Pump Assy-Folding Top Power Unit	1948 thru 1950 CvBro
BO 302316	Housing Assy-Folding Top Power Unit Pump	1948 thru 1950 CvBro
BO 302317	Rotor Assy-Inner & Outer-Folding Top Power Unit Pump	1948 thru 1950 CvBro

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 302318	Seal-Folding Top Power Unit Pump	1948 thru 1950 CvBro
BO 302319	Valve-Folding Top Power Unit Pump	1948 thru 1950 CvBro
BO 302320	Washer-Folding Top Power Unit Pump Valve	1948 thru 1950 CvBro
BO 302321	Spring-Folding Top Power Unit Pump Valve	1948 thru 1950 CvBro
BO 302322	Plug-Folding Top Power Unit Pump Valve	1948 thru 1950 CvBro
BO 302323	Motor & Solenoid Assy-Folding Top Power Unit	1948 thru 1950 CvBro
BO 302324	Brush-Folding Top Power Unit Motor	1948 thru 1950 CvBro
BO 302325	Head Band Assy-Folding Top Power Unit Motor	1948 thru 1950 CvBro
BO 302326	End Head & Brush Assy-Folding Top Power Unit Motor	1948 thru 1950 CvBro
BO 302327	Solenoid Switch-Folding Top Power Unit Motor	1948 thru 1950 CvBro
BO 302328	Washer-Folding Top Power Unit Motor Armature-Pump End	1948 thru 1950 CvBro
BO 302329	Washer-Folding Top Power Unit Motor Armature-Motor End	1948 thru 1950 CvBro
BO 302330	Mounting Rubber-Folding Top Power Unit Motor	1948 thru 1950 CvBro
BO 302331	Mounting Bracket-Folding Top Power Unit Motor	1948 thru 1950 CvBro
BO 302332	Retainer Plate-Folding Top Power Unit Pump Reservoir Fluid	1948 thru 1950 CvBro
BO 302333	Retainer-Folding Top Power Unit Pump Reservoir Fluid	1948 thru 1950 CvBro
BO 302334	Reservoir-Folding Top Power Unit Pump	1948 thru 1950 CvBro
BO 302335	Gasket-Folding Top Power Unit Pump Reservoir	1948 thru 1950 CvBro
BO 302336	Wire Bail-Folding Top Power Unit Pump Reservoir	1948 thru 1950 CvBro
BO 302337	Seal-Folding Top Power Unit Pump to Motor Mtg Screw	1948 thru 1950 CvBro
BO 302338	Switch Assy-Hyd Window Regulator	1948-1949 CvBro
BO 302339	Spring-Attaching-Hyd Wdo Regulator Switch	1948 thru 1950 CvBro
BO 302340	Spring-Locking-Hyd Wdo Regulator Switch	1948 thru 1950 CvBro
BO 302341	Toggle Pin-Hyd Window Regulator Switch	1948 thru 1950 CvBro
BO 302342	Cover-Hyd Window Regulator Switch	1948-1949 CvBro
BO 302343	Switch Assy-Hyd Wdo Regulator	1948 thru 1950 CvBro
BO 302344	Cover-Hyd Wdo Regulator Switch	1948 thru 1950 CvBro
F 302391	Conn Rod & Cap Assy-RH-010 U/S-For 302301 Rebuilt Engine	1936,1937
F 302392	Conn Rod & Cap Assy-LH-010 U/S-For 302301 Rebuilt Engine	1936,1937
F 302393	Conn Rod & Cap Assy-RH- 010 U/S-For 302302, 302304 & 302306 Rebuilt Engines	1938 thru 1947
F 302394	Conn Rod & Cap Assy-LH-010 U/S-For 302302, 302304 & 302306 Rebuilt Engines	1938 thru 1947
F 302395	Conn Rod & Cap Assy-RH-010 U/S-For 302303, 302305 & 302307 Rebuilt Engines	1938 thru 1942
F 302396	Conn Rod & Cap Assy-LH-010 U/S-For 302303, 302305 & 302307 Rebuilt Engines	1938 thru 1942
F 302398	Fan Blade Assy-Water Pump	1948 thru 1950 All
*HS 30240 Gal	Anti-freeze-54 gal drum	All
F 302406	Piston-B	491,492
F 302407	Piston-D	491,492
F 302408	Piston-F	491,492
F 302409	Piston-J	491,492
F 302410	Piston-L	491,492
302411	Piston-P (Use 302717)	491,492
302412	Piston-B0 (Use 302718)	491,492
F 302413	Piston-DO	491,492
F 302414	Piston-FO	491,492
F 302415	Piston-LO	491,492
F 302416	Piston-BB	491,492
F 302417	Piston-DD	491,492
F 302418	Piston-FF	491,492
BT 302421	Gasket-Overdrive to Trans Case	1948 thru 1950
BZ 302426	Wire Kit-Stop Lamp Switch	1936
C 302427 Pr	Wheel Assy-15 x 500	1949-1950 Bro-Sed-Cpes,500 CvBro
F 302430	Shock Absorber Assy- rout-Extra Heavy Duty	1948 thru 1950
F 302431	Shock Absorber Assy- ear-Extra Heavy Duty	1948 thru 1950
BO 302434	Clip-DI Flasher Harness Fuse Connector	1949
BO 302435	Key Blank, Ignition Lock	All
BZ 302436	Bleeder Screw-Wheel Cylinder	1949,1950
*HS 302437	Tire Pressure Gauge Kit	All
BO 302438	Jewel-DI & Back-up Lamp Beam	1948 thru 1950
BO 302439	Retainer-DI & Back-up Lamp Beam Indicator Jewel	1948 thru 1950
C 302440	Rear Spring Assy-Light Scalo	1949-1950 exc CvBro
BO 302441	Escutcheon-Lighting Switch	1949,1950
BZ 302442	Escutcheon-VD Instrument Panel Switch	1949

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BO 302443	Escutcheon-HDM Instrument Panel Switch	1949
BO 302444	Escutcheon-Top Control Valve Operating Rod	1949-1950 CvBro
BO 302445	Jewel & Retainer Assy-DI Indicator	1948,1949
*SP 302447	Piston Ring Set-CI-.010 0/S	1948 thru 1950 6 Cyl
*SP 302448	Piston Ring Set-CI-.020 0/S	1948 thru 1950 6 Cyl
EM 302457	Tapered Spacer-Carburetor to Manifold	481,482,491,492
C 302458	Intake Manifold-Cast Iron	491,492,501,502
302459	Intake Manifold-Alum (Use 302458)	491,492,501,502
BT 302468	Stop Ring-Trans Main Drive Gear	1949,1950
BT 302469	Stop Ring-Center-Trans Main Drive Gear	1949,1950
BT 302470	Spring-Trans Main Drive Gear Stop Ring	1949,1950
F 302471	Main Drive Gear & Stop Ring Assy-Trans	1949 without HDM
F 302472	Main Drive Gear & Stop Ring Assy-Trans	1949,1950
*HA 302494	Oil Filter Kit	1948 thru 1950 6 Cyl
*HA 302495	Oil Filter Kit	1948 thru 1950 8 Cyl exc 1950 RHD
*SP 302496	Cartridge & Gasket Kit-Oil Filter	1948 thru 1950 All exc 503-504 RHD
302497	Sprocket-Camshaft	1949-1950 6 Cyl
BZ 302501	Drip Pan-Battery	1949,1950
C 302504	Bracket Assy-Handy Shift Control Lever Tube & Fulcrum-LHD	491,493,501,503 Without HDM
C 302505	Bracket Assy-Handy Shift Control Lever Tube & Fulcrum-LHD	492,494,502,504 Without HDM
BT 302508	Pin-Handy Shift Control Tube Lever	1949-1950 Less HDM
BT 302509	Rod-Handy Shift Control Tube to Bellcrank-LHD	1949-501 thru 504 Without HDM
302510	Bushing-Handy Shift.Tube to Bellcrank Rod-LHD (Use 302702)	1949-1950 Less HDM or SMD
BO 302511	Spring Plate Assy-Horn	1949,501 thru 504
BO 302512	Spring Plate-Horn	1949,501 thru 504
EM 302513	Oil Trough-Timing Chain	1949-1950 6 Cyl
BM 302514	Pipe Assy-Comb Fuel Pump to Carb	491,492,501,502
BZ 302515	Cross Shaft & Lever-Accelerator-LHD	491,492,501-502 Without HDM
BZ 302517	Adjusting Screw-Accelerator Cross Shaft Lever Link-LHD	1949,501 thru 504,500 All with HDM
BM 302518	Tube & Cover Assy-Carb Choke Heat Conductor	491,492,501,502
BM 302520	Brace-Carburetor Air Cleaner-(dry)	491,492,501,502 Without VD-HDM or SMD
BM 302521	Brace-Carburetor Air Cleaner-(dry)	491,492,501,502 With VD-HDM or SMD
F 302522	Repair Kit-Brake Master Cylinder (Use 303639)	1948,1949
F 302523	Repair Kit-Brake Wheel Cylinder-Front	1948,1949,501 thru 504
F 302524	Repair Kit-Brake Wheel Cylinder-Rear	1948 thru 1950
BO 302526	Sleeve-Wiring Harness	1949
EM 302529	Mounting Bracket-Oil Filter	493,494,503-504 LHD
EM 302530	Pipe Assy-Oil Filter Outlet	493,494,503-504 LHD
EM 302531	Pipe Assy-Oil Filter Inlet'	493,494,503-504 LHD
EM 302532	Pipe Assy-Oil Filter-Pump to Valve Check	493,494,503-504 LHD
C 302537	Lever, Tube & Rod Assy-Handy Shift-LHD	491-493-501-503 Without HDM
C 302538	Lever, Tube & Rod Assy-Handy Shift-LHD	492-494-502-504 Without HDM
EM 302539	Baffle-Oil Pan Tray	493,494
EM 302540	Outlet Hose-Oil Filter	1949-1950 6 Cyl
EM 302541	Inlet Hose-Oil Filter	1949-1950 6 Cyl
BZ 302549	Cam-VD Valve Lever	1949-1950 with VD-HDM or SMD
EM 302550	Breaker Sub Plate Assy-Distributor	491,492
BO 302551	Washer-Socket	1949,501 thru 504
BO 302552	Washer-Socket	492,494,500,502,509
BX 302553	Seal-Front Susp Strg Arm Pivot Supt Brkt Brg	1949,1950
*SP 302554	Piston Ring Set-CI-.030 0/S	1939-1940 thru 1947 6 Cyl
*SP 302563	Case-Battery	1948,1949
BT 302566	Fuse Assy-Overdrive Circuit	1948,1949
*HS 302569	Anti-Freeze-Radiator-1 gallon can	All
BO 302571	Pawl Spring-DI Switch	1949,1950
BO 302572	Latch Spring-DI Switch	1949,1950
BO 302573	Return Spring-DI Switch	1949,1950
EM 302574	Bearing-Crankshaft #3-Std	491,492
EM 302575	Bearing-Crankshaft #3-Std	491,492
EM 302576	Bearing-Crankshaft #3-.010 U/S	491,492
302577	Bearing-Connecting Rod-.002 U/S (Use 302747)	491,492
302578	Bearing-Connecting Rod-.012 U/S (Use 302749)	491,492
BZ 302579	Tube Assy-Brake Master Cyl to Connector-LHD	1949 All,501 thru 504
BZ 302580	Tube Assy-Brake. Master Cyl to Front Connector-RHD	1949 All,501 thru 504
302584	Bearing-Crankshaft-No.1-.002 U/S (Use 302727)	491,492
302585	Bearing-Crankshaft-No.1-.012 U/S (Use 302729)	491,492
302586	Bearing-Crankshaft-No.2-.002 U/S (Use 302732)	491,492
302587	Bearing-Crankshaft-No.2-.012 U/S (Use 302734)	491,492
302590	Bearing-Crankshaft-No.4-.002 U/S (Use 302742)	491,492
302591	Bearing-Crankshaft-No.4-.012 U/S (Use 302744)	491,492

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
302592	Bearing-Crankshaft-No.3-.002 U/S (Use 302737)	491,492
302593	Bearing-Crankshaft-No.3-.012 U/S (Use 302739)	491,492
BM 302594	Valve Tappet & Adjusting Screw Assy-.002 0/S	1949-1950 6 Cyl
BM 302595	Valve Tappet & Adjusting Screw Assy-.004 0/S	1949-1950 6 Cyl
BM 302596	Valve Tappet & Adjusting Screw Assy-.010 0/S	1949-1950 6 Cyl
BZ 302597	Tube Assy-Brake-Frt Conn to Rear Connector-RHD	1949,1950
BZ 302598	Tube Assy-Brake-Connector to Rear Axle Hose	1949,1950
BZ 302599	Switch & Wires Kit-Stop Lamp	1936 All
F 302601	Connecting Rod & Cap Assy	1949-1950 6 Cyl
BO 302603	Gasket-Weather-Control Motor Mounting	1949
BM 302605	Distributor Assy	491,492,501,502
BM 302606	Distributor Assy	493,494,503,504
BZ 302614	Mounting Brkt & Shim Assy-Hand Brake	1949,501 thru 504
BZ 302616	Grip & Ratchet Rod Assy-Hand Brake-LHD	491,493,500,501,503
BZ 302617	Grip & Ratchet Rod Assy-Hand Brake-LHD	492,494,502,504
BZ 302618	Grip & Ratchet Rod Assy-Hand Brake-RHD	491,493,500,501,503
BZ 302619	Grip & Ratchet Rod Assy-Hand Brake-RHD	492,494,502,504
BZ 302620	Ratchet Rod-Hand Brake	1949,1950
BZ 302621	Spring-Hand Brake Ratchet Rod Stabilizer-LHD	1949,1950
BZ 302622	Spring-Hand Brake Ratchet Rod Stabilizer-RHD	1949,1950
CF 302624	Cable Assy-Hand Brake	1949,501 thru 504
*C 302625	Cylinder & Piston Assy	491,492,501,502
BO 302628	Water Valve-Weather Control	1949,1950
BO 302629	Bowden Wire-Weather Control	1949
BX 302630	Anchor Pin-Brake	1949,1950
BT 302702	Grommet-Handy Shift Tube to Bellcrank Rod-LHD	501 thru 504 Less HDM or SMD
BZ 302703	Stabilizer-Hand Brake Ratchet Rod-Inner	1949,1950
BZ 302704	Stabilizer-Hand Brake Ratchet Rod-Outer	1949,1950
*C 302705	Gas Tank Assy	1949,1950
BZ 302708	Pad-Gasoline Tank	1949,1950
F 302709	Gauge Assy-Gasoline Tank	1949,1950
*C 302710	Hypoid Gear Lubricant	1948 thru 1950
F 302712	Piston Assy-Code B	491,492,501,502
F 302713	Piston Assy-Code D	491,492,501,502
F 302714	Piston Assy-Code F	491,492,501,502
F 302715	Piston Assy-Code J	491,492,501,502
F 302716	Piston Assy-Code L	491,492,501,502
F 302717	Piston Assy-Code P	491,492,501,502
F 302718	Piston Assy-Code BO	491,492,501,502
F 302719	Piston Assy-Code DO	491,492,501,502
F 302720	Piston Assy-Code FO	491,492,501,502
F 302721	Piston Assy-Code LO	491,492,501,502
F 302722	Piston Assy-Code BB	491,492,501,502
F 302723	Piston Assy-Code DD	491,492,501,502
F 302724	Piston Assy-Code FF	491,492,501,502
BM 302725	Bearing Pkg-Crankshaft-No. 1-Std	1948 thru 1950 6 Cyl
BM 302726	Bearing Pkg-Crankshaft-No. 1-.001 U/S	1948 thru 1950 6 Cyl
BM 302727	Bearing Pkg-Crankshaft-No. 1-.002 U/S	1948 thru 1950 6 Cyl
BM 302728	Bearing Pkg-Crankshaft-No. 1-.010 U/S	1948 thru 1950 6 Cyl
BM 302729	Bearing Pkg-Crankshaft-No. 1-.012 U/S	1948 thru 1950 6 Cyl
BM 302730	Bearing Pkg-Crankshaft-No. 2-Std	1948 thru 1950 6 Cyl
BM 302731	Bearing Pkg-Crankshaft-No. 2-.001 U/S	1948 thru 1950 6 Cyl
BM 302732	Bearing Pkg-Crankshaft-No. 2-.002 U/S	1948 thru 1950 6 Cyl
BM 302733	Bearing Pkg-Crankshaft-No. 2-.010 U/S	1948 thru 1950 6 Cyl
BM 302734	Bearing Pkg-Crankshaft-No. 2-.012 U/S	1948 thru 1950 6 Cyl
BM 302735	Bearing Pkg-Crankshaft-No. 3-Std	1948 thru 1950 6 Cyl
BM 302736	Bearing Pkg-Crankshaft-No. 3-.001 U/S	1948 thru 1950 6 Cyl
BM 302737	Bearing Pkg-Crankshaft-No. 3-.002 U/S	1948 thru 1950 6 Cyl
BM 302738	Bearing Pkg-Crankshaft-No. 3-.010 U/S	1948 thru 1950 6 Cyl
BM 302739	Bearing Pkg-Crankshaft-No. 3-.012 U/S	1948 thru 1950 6 Cyl
BM 302740	Bearing Pkg-Crankshaft-No. 4-Std	1948 thru 1950 6 Cyl
BM 302741	Bearing Pkg-Crankshaft-No. 4-.001 U/S	1948 thru 1950 6 Cyl
BM 302742	Bearing Pkg-Crankshaft-No. 4-.002 U/S	1948 thru 1950 6 Cyl
BM 302743	Bearing Pkg-Crankshaft-No. 4-.010 U/S	1948 thru '1950 6 Cyl
BM 302744	Bearing Pkg-Crankshaft-No. 4-.012 U/S	1948 thru 1950 6 Cyl
F 302745	Bearing Pkg-Conn Rod-Std	.481,482,491,492
F 302746	Bearing Pkg-Conn Rod-.001 U/S	481,482,491,492
F 302747	Bearing Pkg-Conn Rod-.002 U/Size	481,482,491,492
F 302748	Bearing Pkg-Conn Rod-.010 U/S	481,482,491,492
F 302749	Bearing Pkg-Conn Rod-.012 U/S	481,482,491,492
BZ 302750	Cylinder & Throttle Lock Diaphragm-HDM Clutch Control	1949 With HDM
BZ 302751	Power Unit-Vacumotive Drive	1949 With VD
BZ 302752	Valve Assy-VD Solenoid	1949 with VD-HDM or SMD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BT 302753	Check Valve-VD Solenoid Valve Body	1949-1950 with VD--HDM or SMD
*SP 302754	Fuel Pump Assy-Mechanical	1949-1950 exc 8 Cyl RHD cars
EM 302756	Pipe Assy-Fuel Pump to Carb	491-492-501-502 Less Comb Pump
BM 302757	Pipe Assy-Fuel Pump to Carb-LHD	1949-1950 8 Cyl
C 302760	Spring & Cover Assy-Rear-Light Scale	1949-1950 exc CvBro
C 302761	Spring & Cover Assy-Rear-Light Scale	1949-1950 CvBro
C 302762	Spring & Cover Assy-Rear-Heavy Scale	1949-1950
C 302766	Tie Rod Assy	1949,1950
BZ 302768	Screen-Gas Tank Outlet	1949,1950
BO 302788	Circuit Breaker Assy-Headlight	1949,1950
BX 302789	Plate-Brake Anchor Pin Shoe Guide	1949,1950
C 302791	Cover Set-Front Half-Rear Spring	For 302760-61-62
C 302792	Cover Set-Rear Half-Rear Spring	For 302760-61-62
F 302793	Shock Absorber Assy-Rear-Light	52,53,54,172,173,174
EM 302794	Sleeve-Fuel Pump to Cylinder Bolt	1949-1950 Less Comb Pump
EM 302795	Generator Complete	1949,1950
EM 302796	Charge Regulator-Generator	1949,1950
*SP 302797	Battery Assy-Type 26-S-100	1949,1950
BZ 302799	Hold-down Bolt-Battery	1949,1950
EM 302800	Bracket-Adjusting-Generator	1949-1950 6 Cyl
EM 302801	Bracket-Adjusting-Generator'	1949-1950 8 Cyl
302810	Transmission Assy (Use 303932)	1949 All Without OD or HDM
*C 302811	Transmission Assy	1949 All With OD Less HDM
*C 302812	Transmission & Overdrive Assy	1949 All With OD Less HDM
C 302813	Crossmember Assy-#3-Frame-LHD	1949,1950
C 302814	Crossmember Assy-#3-Frame-RHD	1949,1950
BZ 302815	Bolt-Center-Rear Spring	1949-1950 exc CvBro
BZ 302816	Rebound Clip #1-Rear Spring	1949-1950 exc CvBro
BZ 302817	Rebound Clip #2 & #3-Rear Spring	1949-1950 exc CvBro
EM 302820	Ignition Coil Assy	1950
EM 302821	Wire Assy-Coil to Distributor	1950 6 Cyl
EM 302823	Wire Assy-Coil to Distributor-LHD	1950 8 Cyl
C 302827	Main Leaf-Rear Spring	1949-1950 exc CvBro
F 302834	Gasket Kit-Engine Overhaul	1948 thru 1950 6 Cyl
F 302835	Gasket Kit-Engine Overhaul	1948 thru 1950 8 Cyl
EM 302838	Metering Rod & By Pass Plug Kit-Carb-LHD	For Reworking 300629
EM 302839	Metering Rod & By Pass Plug Kit-Carb-RHD	For Reworking 301645
EM 302840	Metering Rod-Carburetor-Std	491,492,501,502
F 302841	Gasket-Cylinder Head	1949-1950 6 Cyl
EM 302858	Seal-Timing Chain Cover	491,492,1950 All
*C 303000	Cylinder & Pistons Assy	500
BZ 303002	Return Spring-Clutch Pedal Lever-LHD	500
BZ 303003	Return Spring-Clutch Pedal Lever-RHD	500
*C 303007	Crankshaft Assy-Std ..	500
*C 303010	Crankshaft Assy-.010 WS	500
C 303016	Cylinder Head Assy-Cast Iron	500
BT 303017	Coupling Lever-Clutch Cross Shaft-RHD	500
C 303018	Control Wire & Casing Assy-RHD	500
F 303019	Bearing Pkg-Conn Rod-Std	500
F 303020	Bearing Pkg-Conn Rod-.001 U/S	500
F 303021	Bearing Pkg-Conn Rod-.002 U/S	500
F 303022	Bearing Pkg-Conn Rod-.010 U/S	500
F 303023	Bearing Pkg-Conn Rod-.012 U/S	500
*C 303032	Steering Gear Assy-LHD	500
C 303033	Radiator Core Assy	500
*C 303034	Steering Gear Assy-LHD	501 thru 504
BO 303035	Dimmer Switch	1950
BX 303039	Steering Arm (center) & Pivot Assy-LHD	500
BZ 303042	Mounting Bracket & Shim Assy-Hand Brake	500
C 303045	Cable Assy-Hand Brake	500
C 303047	Exhaust Pipe Assy-Front-LHD	500
BZ 303049	Bracket-Front Frame #1 Crossmember	1950
*C 303050	Front Frame Assy-LHD	500
C 303055	Intake Manifold Assy-LHD	500
EM 303057	Stud-Carburetor to Manifold	500
BZ 303058	Steering Gear Reinforcement-Front Frame	500
*F 303060	Shock Absorber-Front-Light	1950
*F 303061	Shock Absorber-Front-Heavy	1950
F 303062	Shock Absorber-Front-Light	1950
F 303063	Shock Absorber-Front-Heavy	1950
C 303066	Drag Link Assy-LHD	500
C 303074	Propeller Shaft Assy-Front-Without OD or SMD	500
C 303075	Propeller Shaft Assy-Front-With OD or SMD	500
C 303076	Propeller Shaft-Without OD	500

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
C 303077	Propeller Shaft-With OD	500
BX 303082	Cover-Brake Drum Inspection Hole	500
F 303083	Hub Cap-Wheel-Small	500,501,503
*CF 303084	Hub Cap-Wheel-Large	1950
*HA 303085	Hub Cap Kit-for 15" Wheel	1950
BZ 303087	Brace Assy-Hand Brake Cable Lever Pivot	500
BZ 303089	Wheel Cylinder Assy-Brake-Front-RH	500
BZ 303090	Wheel Cylinder Assy-Brake-Front-LH	500
BZ 303093	Tube Assy-Brake Master Cylinder to Frame Tee	500
BZ 303094	Pull Rod Complete-Brake Pedal	500
BZ 303098	Tube Assy-Brake Master Cylinder to Connector	500
BM 303100	Distributor Assy	500
BM 303101	Carburetor Assembly	500
F 303102	Gasket-Carburetor to Manifold	500
BM 303103	Heat Deflector-Carburetor	500
BM 303104	Heat Tube & Cover Assy-Carburetor Choke	500
BZ 303106	Lever & Shaft Assy-Clutch Pedal-LHD	500
BT 303107	Relay-Overdrive	1950
BZ 303109	Lever Assy-Brake Pedal-LHD	500
C 303111	Tube & Bearing Assy-Steering Gear Jacket-without DI.	500 LHD
C 303113	Tube & Bearing Assy-Steering Gear Jacket-with DI.	500 LHD
A 303117	Guard-Engine-Front	500
A 303118	Guard-Engine-Left	500
BZ 303122	Speedometer Cable Assy-LHD	500 without OD
BZ 303123	Core-Speedometer Cable-Export-LHD	500 without OD
BZ 303124	Cross Shaft & Coupling Lever Assy-Clutch-LHD	500
BZ 303127	Link Assy-Clutch Control-LHD	500
BZ 303128	Link-Clutch Control-LHD	500
BM 303136	Pipe Assy-Fuel Pump to Carburetor	500 less Comb Pump
BM 303137	Pipe Assy-Comb Fuel Pump to Carburetor	500
BM 303138	Pipe Assy-Comb Fuel & Vac Pump to Manifold	500
BZ 303141	Accelerator Pedal Complete	501,503
BZ 303142	Accelerator Pedal Complete	1950
BZ 303143	Pedal Pad & Rod Assy-Brake-LHD	500
BZ 303144	Pedal Pad & Rod Assy-Clutch-LHD	500
HZ 303149	Cover-Pedal Pad	1950
*C 303150	Overdrive Assy	1950
BZ 303151	End Lever-Pedal Lever Shaft-Clutch-LHD	1950
BZ 303153	Cable Assy-Speedometer-RHD	500 without OD
BZ 303154	Core Assy-Speedometer-Export-RHD	500 without OD
BZ 303155	Cable Assy-Speedometer-LHD	500 with OD
BZ 303156	Core Assy-Speedometer-Export-LHD	500 with OD
BZ 303157	Cable Assy-Speedometer-RHD	500 with OD
BZ 303158	Core Assy-Speedometer-Export-RHD	500 with OD
BT 303159	Bracket-Mounting-Overdrive Control-LHD	1950
BT 303165	Solenoid Assy-Overdrive	1950
BM 303166	Air Cleaner-Carburetor-Dry	500 without HDM or SMD
BM 303167	Air Cleaner-Carburetor-Dry	500 with HDM or SMD
BM 303168	Air Cleaner-Carburetor-Oil Bath	500 without HDM or SMD
BM 303169	Air Cleaner-Carburetor-Oil Bath	500 with HDM or SMD
BM 303170	Tube Assy-Distributor Vacuum Control	500
BT 303171	Shift Shaft Lever & Pin Assy-Trans-Without HDM	500
C 303173	Tube & Fulcrum Bracket Assy-Handy Shift-LHD	500 less HDM
BT 303176	Rod Assy-Handy Shift Tube to Trans-LHD	500 less HDM
BM 303178	Starting Motor	500
BZ 303183	Cylinder & Throttle Lock Diaphragm Assy-HDM Clutch Control	500 with HDM or SMD
BZ 303185	Pitman Arm-Steering Gear-LHD	500
BZ 303186	Guard-Frame #3 Crossmember-RH	500
BZ 303187	Guard-Frame #3 Crossmember-LH	500
C 303188	Sidemember Assy-Front Frame-Right	500
C 303189	Sidemember Assy-Front Frame-Left	500
*C 303190	Front Frame Assy-RHD	500
BZ 303191	Steering Gear Reinforcement Assy-Front Frame- Right-RHD	500
C 303195	Exhaust Pipe Assy-Front-RHD	500
C 303197	Steering Wheel	500
C 303198	Steering Wheel Assy	501,503
BT 303200	Clutch Assy-9"	500 less HDM or SMD
BT 303201	Cover-Clutch-9"	500 without HDM or SMD
BZ 303202	Trim Ring-Steering Wheel Hub	501,503
BZ 303203	Horn Button	500
BZ 303204	Horn Button	501,503
C 303206	Steering Wheel	1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 303207	Spoke Cover-Steering Wheel	1950
BZ 303208	Ornament Assy-Steering Wheel	1950
BZ 303212	Horn Ring	1950
BZ 303213	Insulator-Horn Ring	1950
BT 303214	Contact Cup-Horn Ring	1950
BZ 303215	Lock Wire-Horn Ring to Insulator Screw	1950
BZ 303216	Contact Spring-Horn Ring	1950
BO 303217	Knob-Lighting Switch-Plastic	500
BO 303219	Horn and Spring Plate Assy	500
BZ 303220	Cross Shaft Assy-Accelerator-LHD	500 without HDM or SMD
BZ 303226	Bellcrank-Accelerator Pedal Link-LHD	500 without HDM or SMD
BZ 303227	Bracket Assy-Accelerator Pedal Link Bellcrank	500 without HDM or SMD
BO 303232	Bracket-Horn	500
BM 303237	Clip-Anti-Rattle-Exhaust Damper	500
C 303239	Drag Link Assy-RHD	500
BO 303242	Bracket-Horn	500
*C 303243	Steering Gear Assy-RHD	500
BZ 303244	Pitman Arm-Steering Gear-RHD	500
BZ 303245	Switch-HDM Instrument Panel	1950
BZ 303246	Push Button-off-HDM Inst Panel Switch	1950
BZ 303249	Escutcheon-HDM Instrument Panel Switch	1950 with HDM
BZ 303250	Accelerator Switch-VD	1950 with HDM or SMD
BT 303254	Throttle Switch-Overdrive	1950
C 303255	Cylinder Head Assy-Aluminum	500
BZ 303257	Tube Assy-Brake-Master Cylinder to Frame Tee	500
BZ 303258	Tube Assy-Brake-Frame Tee to Left Front Hose	500
BZ 303259	Tube Assy-Brake-Frame Tee to Right Front Hose	500
BZ 303260	Tube Assy-Brake-Frame Tee to Right Front Hose	500
BZ 303261	Tube Assy-Brake-Frame Tee to Left Front Hose	500
BZ 303262	Tube Assy-Brake-Master Cylinder to Connector	500
C 303263	Manifold & Damper Assy-Exhaust	1948 thru 1950 6 Cyl
C 303265	Wire,Casing & Bracket Assy-Handy Shift-LHD	500 Less HDM
BT 303269	Bellcrank Assy-Handy Shift-RHD	500
BT 303272	Pivot-Handy Shift Bellcrank-RHD	500
BT 303273	Rod Assy-Handy Shift Tube to Bellcrank-RHD	500
BT 303276	Rod Assy-Handy Shift Bellcrank to Trans-RHD	500
BZ 303278	Support-Exhaust Pipe (Front) Clamp-RHD	500
*HA 303280	Horn Kit	500
C 303283	Lever Tube & Rod Assy-Handy Shift-LHD	500 less HDM or SMD
BT 303288	Power Unit-HDM	1950
BT 303291	Governor Switch-HDM	501 thru 504 with HDM or SMD 500 less SMD
BT 303292	Boot-Governor Switch	1950 with HDM or SMD
BT 303293	Lever Complete-HDM Shift Shaft	1950
BT 303296	Rod Complete-HDM Trans Shift	500
BT 303302	Rod-HDM Neutral & Limit Switch	1950
BT 303303	Swivel-HDM Neutral & Limit Switch Rod	1950
BZ 303304	Assisting Spring-Clutch Pedal-LHD	500 less HDM or SMD
BZ 303305	Link-Clutch Pedal Assisting Spring-LHD	500 less HDM or SMD
BZ 303306	Pedal Pad & Rod Assy-Brake-RHD	500
BZ 303307	Pedal Pad & Rod Assy-Clutch-RHD	500
BZ 303310	Lever-Brake Pedal-RHD	500
BT 303314	Bracket-Mtg-Overdrive Control-RHD	1950
BO 303315	Control Assy-Weather Control	501 thru 504
BO 303316	Bowden Wire-Weather Control	500
BO 303317	Bowden Wire-Weather Control	501 thru 504
BZ 303319	Pipe Assy-VD-Manifold End	500 with HDM or SMD
BZ 303320	Hose-VD Pipe Coupling	500 with HDM or SMD
BZ 303321	Pipe Assy-VD-Valve End	500 with HDM or SMD
BZ 303322	Lever Assy-Clutch Pedal-RIID	500
BZ 303324	Control Link-Clutch-RHD	500
BZ 303325	Accelerator Pedal	500
BZ 303329	Lever Assy-Accelerator Pedal-LHD	500
BZ 303330	Lever Assy-Accelerator Pedal-RHD	500
BZ 303334	Mounting Bracket-Accelerator Pedal	500
BZ 303335	Seal-Accelerator Pedal Mounting Bracket	500
BZ 303336	Gasket-Accelerator Pedal Mounting Bracket	500
BZ 303337	Cover-Accelerator Pedal Mounting Bracket	500
BZ 303338	Rod Assy-Accelerator Pedal to Cross Shaft	500 without HDM or SMD
F 303342	Clutch Driven Disc Complete-9"	500 less HDM or SMD
BT 303343	Clip-Overdrive Control Wire & Casing Assy-LHD	500 with OD,501 thru 504 with OD or SMD
BT 303344	Clip-OD Control Wire & Casing Assy-LHD	500 with SMD
BT 303344	Clip-Handy Shift Wire & Casing	1950
BZ 303345	Bumper-Brake & Clutch Pedal Toe Plate	500
BZ 303347	Seal & Retainer Assy-Brake & Clutch Pedal Toe Plate Bumper	500

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 303350	Slotted Washer-Pedal Toe Plate Bumper Seal Ret	500
BT 303353	Harness-Overdrive-LHD	1950
BT 303354	Harness -Overdrive -RHD	1950
BT 303355	Harness-Hudson Drive Master	500 without OD
BT 303358	Harness-Super Matic Drive	500
BT 303361	Rod-HDM Cross Over Switch	1950
BO 303362	Harness-Instrument-RHD	1950
EM 303363	Harness-Engine-RHD	1950
EM 303364	Harness-Engine-LHD	501 thru 504,500 with HDM
BO 303365	Harness-Instrument-LHD	1950
BT 303367	Lever Complete-HDM Shift Shaft-Hand Shift	500
BT 303370	Intake Pipe Assy-HDM Power Unit	500
BT 303371	Body Harness-Right Side-LHD	500-501-503 Bro-Sed-Cpes with DI
BO 303372	Body Harness-Right Side-RHD	500-501-503 Bro-Sed-Cpes with DI
BO 303373	Body Harness-Right Side-LHD	502-504 Sed with DI
BO 303374	Body Harness-Right Side-RHD	502-504 Sed With DI
BO 303377	Body Harness-Right Side-LHD	502-504 Cpes with DI
BO 303378	Body Harness-Right Side-RHD	502-504 Cpes with DI
BO 303379	Body Harness-Left Side	500-501-503 Bro-Sed
BO 303380	Body Harness-Left Side-LHD	502-504 Sed
BO 303381	Body Harness-Left Side-RHD	502-504 Sed
BO 303382	Body Harness-Left Side	500-501-503 Cpes
BO 303383	Body Harness-Left Side-LHD	502-504 Cpes
BO 303384	Body Harness-Left Side-RHD	502-504 Cpes
BO 303385	Body Harness	500-501 CvBro without DI
BO 303386	Body Harness	500-501 CvBro with DI
BO 303387	Body Harness	502-504 CvBro without DI
BO 303388	Body Harness	502-504 CvBro with DI
BZ 303389	Pipe Assy-Gasoline-Union to Fuel Pump	500
C 303390	Lever, Tube & Fulcrum Brkt Assy-Handy Shift-LHD	500 with HDM
BT 303392	Rod Assy-Handy Shift Tube to HDM Shift Shaft Lever-LHD	500 with HDM
BT 303394	Knob-Handy Shift Lever	500
BO 303395	Wire Assy-Horn Relay to Horn	1950
BO 303396	Wire Assy-Junction Block to License Lamp	501 thru 504
EM 303397	Insulator-High Tension Wire	1950
BT 303398	Mounting Plate Assy-Handy Shift Bellcrank-RHD	500
BZ 303400	Coupling, Lever & Shaft Assy-Clutch-RHD	500
BZ 303405	Extension-Clutch Control Coupling-RHD	500
BZ 303406	Spacer-Clutch Control Coupling-RHD	500
BZ 303407	Clip-Clutch Pedal Lever Return Spring-RHD	500
BO 303408	Harness -Generator	1950 6 Cyl
BO 303409	Harness -Generator	1950 8 Cyl
BZ 303440	Rod Assy-Accel Dash Cross Shaft to Bellcrank	500 without HDM or SMD
BZ 303441	Rod Assy-Accel Bellcrank to Carb-LHD	500 without HDM or SMD
BZ 303442	Rod-Accel Pedal to Bellcrank-LHD	501 thru 504
BZ 303443	End-Accel Pedal to Bellcrank Rod-LHD	501 thru 504
BZ 303444	Sleeve-Accel Pedal to Bellcrank Rod-LHD	501 thru 504
BZ 303445	Retainer-Accel Pedal to Bellcrank Rod Sleeve	501 thru 504
BZ 303447	Stop-Accelerator Pedal-LHD	501 thru 504 without OD or SMD
BO 303448	Wire Assy-Clock and Speedometer	1950
BO 303449	Wire Assy-Instrument Lamp	1950
BO 303451	Feed Wires Assy-Headlamp-LHD	500
BO 303452	Feed Wires Assy-Headlamp-RHD	500
BO 303453	Feed Wires Assy-Headlamp-LHD	501 thru 504
BO 303454	Feed Wires Assy-Headlamp-RHD	501 thru 504
BO 303456	Wire Assy-License Lamp	500 Bro-Sed
BO 303457	Wire Assy-License Lamp	500 Cpes-CvBro
BO 303459	Wire Assy-Tool and Stop Lamp-Right	1950
BZ 303461	Rod-Accelerator Pedal to Cross Shaft Lever	500
BZ 303462	Cross Shaft Assy-Lower-Accelerator-RHD	500
BZ 303466	Cross Shaft Assy-Upper-Accelerator-RHD	500
BZ 303469	Connecting Rod Assy-Accelerator Cross Shaft	500
BZ 303471	Rod-Accelerator Cross Shaft to Bellcrank-RHD	500
BZ 303472	Bellcrank-Accelerator Manifold-RHD	500
BZ 303473	Pivot Stud-Accelerator Intake Manifold Bellcrank-RHD	500
BZ 303474	Rod Assy-Accelerator Bellcrank to Carb-RHD	500
BZ 303475	Clip-Accel Cross Shaft to Bellcrank Rod-RHD	500
BZ 303476	Clip-Accel Pedal to Cross Shaft Rod-LHD	500 without HDM
BT 303489	Knob-Handy Shift Lever-Red	1950 with Custom Strg Wheel
BO 303493	Switch, Case & Cover Assy-Direction Indicator	1950
BZ 303494	Operating Rod Assy-Accelerator Bellcrank (Engine)	500 with HDM or SMD
BZ 303496	Bracket Assy-Accel Bellcrank (Engine)	500 with HDM or SMD
BZ 303499	Bellcrank (Engine) Accelerator	500 with HDM or SMD

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BZ 303500	Lever Assy-Accel Bellcrank (Engine)	500 with HDM or SMD
BZ 303503	Torsion Spring-Accel Bellcrank (Engine)	500 with HDM or SMD
BZ 303504	Rod Assy-Accel Bellcrank (Engine) to Carb	500 with HDM or SMD
BZ 303506	Rod-VD Accelerator Switch	500 with HDM or SMD
BZ 303507	Boot-Overdrive Governor Switch	1950
BZ 303508	Return Spring-Throttle Control-LHD	500 without HDM or SMD
BZ 303511	Rod-Accelerator Pedal to Cross Shaft	500 with HDM or SMD
BZ 303512	Pivot-Accelerator Pedal to Cross Shaft Rod	500 with HDM or SMD
BZ 303513	Brkt Assy-Accelerator Dash Cross Shaft	500 with HDM or SMD
BZ 303516	Cross Shaft Assy-Accelerator-On Dash	500 with HDM or SMD
BZ 303520	Bracket Complete-Accel Pedal Link Bellcrank	500 with HDM or SMD
BZ 303522	Ball Joint Assy-Ace Pedal Link Bellcrank Lever to Cross Shaft Lever	500 with HDM or SMD
BM 303523	Carburetor Assy-RHD	500
BZ 303524	Rod Assy-Threaded Sleeve-VD Valve Lever Cam	500 with HDM or SMD
C 303526	Intake Manifold Assy-RHD	500
BO 303531	Bracket-Circuit Breaker	500 exc CvBro
BO 303532	Clip-DI and HDM Harness Fuse Connector	1950
*C 303539	Engine Assy-Cast Iron Head	500 without HDM or SMD
*C 303540	Engine Assy-Aluminum Head	500 without HDM or SMD
C 303543	Lever, Tube & Rod Assy-Handy Shift- LHD	500 with HDM or SMD
C 303544	Hub Complete-Front	500
C 303546	Front Suspension Complete-Right-RED	500
C 303547	Front Suspension Complete-Left-RHD	500
BX 303550	Steering Arm-Outer-Front Suspension-Right-RHD	500
BX 303551	Steering Arm:-Outer-Front Suspension-Left-RHD	500
BT 303566	Cover and Clip Assy-Transmission-With OD	1950
BT 303567	Cover,Baffle & Clip-Transmission-With HDM Less OD	1950
BM 303568	Clip-Generator Harness to Battery Hold-Down Bolt	1950
BM 303568	OD Harness Throttle Switch Wires	500 with SMD
BO 303569	Spring-HDM Inst Panel Switch Push Button	1950
F 303571	Cable Assy-Battery to Starter Solenoid	1950 except CvBro
BO 303572	Wire Assy-Bonnet Lamp	500
BZ 303584	Clip-Hand Brake Cable Conduit	500 LHD,501 thru 504
F 303586	Repair Kit-Wheel Cylinder-Front	500
F 303589	Cup-Front-Wheel Cylinder	500
*HA 303591	Direction Indicator Kit-LHD	500
F 303592	Piston-Front-Wheel Cylinder	500
BO 303595	Knob-Weather Control Door	501 thru 504
BM 303596	Screw-Valve Chamber Cover	1950 6 Cyl
BO 303599	Knob-Lighting Switch-Light Tan	501,503,500 CvBro
BZ 303616	Housing Assy-Steering Gear-LHD	500
BZ 303617	Housing Assy-Steering Gear-RHD	500
BZ 303621	Cover-Steering Gear Shaft Housing	500
BZ 303622	Shaft and RollerTooth Assy-Strg Gear	500
BZ 303623	Shaft and Roller Tooth Assy-Strg Gear	500
BZ 303628	Spacer-Cross Shaft Needle Bearing-LHD	500
BZ 303629	Spacer-Cross Shaft Needle Bearing-RHD	500
C 303633	Main Column & Worm Assy-Strg Gear-LHD	500
C 303634	Main Column & Worm Assy-Strg Gear-RHD	500
	303635 Tube-Strg Gear Main Column-LHD	500
	303636 Tube-Strg Gear Main Column-RHD	500
BZ 303637	Washer-Strg Gear Main Column Tube to Housing	500
BZ 303638	Shim-Strg Gear Worm Housing Cover	500
F 303639	Repair Kit-Brake Master Cylinder	1948 thru 1950
BZ 303640	Housing Assy-Steering Gear	501 thru 504
BZ 303642	Spacer-Strg Gear Shaft Needle Bearing-LHD	501 thru 504
BT 303649	Clip-Battery to Starter Sol Cable At Fender Dust Shield	500 with HDM or SMD
*HA 303652	Weather Control Complete	
*HA 303653	Weather Control Complete	501 thru 504
BO 303654	Fittings-in bog-Weather Control	501 thru 504
BO 303655	Switch Assy-Weather Control	500
BO 303656	Switch Assy-Weather Control	501 thru 504
BO 303657	Motor Assy-Weather Control	1950
BO 303658	Gasket-Weather Control Motor	1950
BO 303661	Name Plate-Weather Control	501 thru 504
BO 303662	Knob-Weather Control Door and Arm	500
BO 303663	Jumper Wire Assy-Weather Control	500
BO 303664	Wire Assy-Weather Control Switch to Ignition Switch	501 thru 504
BZ 303669	Fitting-Hill-Hold Master Cylinder Outlet	1948,1949,501 thru 504
*HA 303671	Hill-Hold Kit-LHD	1948,1949,501 thru 504
BZ 303672	Valve Assy-Hill Hold-LHD	1948,1949,501 thru 504
BT 303674	Lever-Hill-Hold Valve-LHD	1948,1949,501 thru 504

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models	
BZ 303675	Rod-Hill-Hold Valve to Lever-LHD	1948,1949,501 thru 504	
BZ 303676	Spring-Hill-Hold Valve to Lever Rod-LHD	1948,1949,501 thru 504	
BZ 303677	Sleeve-Hill-Hold Valve to Lever Rod-LHD	1948,1949,501 thru 504	
BZ 303678	Inlet Tube Assy-Hill-Hold to Master Cylinder	1948,1949,501 thru 504	
BZ 303679	Outlet Tube Assy-Hill-Hold to Master Cylinder	1948,1949,501 thru 504	
*C 303684	Engine Assembly-Cast Iron Head	500 with OD,HDM or SMD	
*C 303685	Engine Assembly-Aluminum Hd	500 with OD,HDM or SMD	
F 303686	Cable Assy-Battery to Starter Solenoid-With HDM	500 exc CvBro	
EM 303687	Harness-Engine-LHD	500 with HDM	
BT 303703	Push Button-On-HDM Inst Panel Switch	1950	
BZ 303704	Tapping Plate-Clutch Control Coupling Extension Bolt	500	
BT 303705	Clip-HDM Harness to Left Front Fender Dust Shield	500 with HDM	
C 303709	Carrier & Gear Set-Differential-3 9/11 to 1	1950 Without OD or SMD	
F 303711	Drive Gear & Pinion-Matched-3 9/11 to 1	1950 Without OD or SMD	
	303715	Differential Case and Bearing Core-3 9/11 to 1	1950 Without OD or SMD
F 303716	Differential Case-3 9/11 to 1	1950 Without OD or SMD	
*HA 303719	Tire Chains-for 600-16 or 650-15 Tires		
*HA 303720	Tire Chains-for 710-15 Tires		
*HA 303721	Tire Chains-for 650-16 or 760-15 Tires		
*HA 303722	Tire Chains-Emergency Strap-on	All	
BT 303724	Selector Valve Assy-HDM	500	
BT 303725	Contact Plate Assy-HDM Valve	500	
C 303728	Steering Wheel	1950	
BT 303729	Knob-Handy Shift Lever-Blue	1950 with Custom Strg Wheel	
BT 303736	Harness-Supermatic	501 thru 504	
BT 303737	Harness-Hudson Drive Master	501 thru 504 with HDM but without OD	
BT 303741	Cylinder & Throttle Lock Diaphragm Assy	501 thru 503 with HDM or SMD	
BZ 303742	Valve Assy-Clutch Control Solenoid	1950 with HDM or SMD	
BZ 303743	Coil & Housing Assy-Clutch Control Solenoid	1950 with HDM or SMD	
BZ 303747	Tube & Nut Assy-Clutch Control Throttle Lock Sol to Diaphragm	500 with HDM or SMD	
BZ 303749	Tube & Nut Assy-Clutch Control Throttle Lock Diaphragm to Sol	500 with HDM or SMD	
BZ 303751	Cylinder Assy-Clutch Control Throttle Lock Diaphragm	500 with HDM or SMD	
BZ 303754	Cable Assy-Clutch Control Throttle Lock Diaphragm	500 with HDM or SMD	
BZ 303755	Mounting Bracket-Clutch Control Throttle Lock Diaphragm	500 with HDM or SMD	
BZ 303756	Spacer-Clutch Control Throttle Lock Diaphragm	500 with HDM or SMD	
BO 303757	Escutcheon-Inst Panel Switch-"Super-Matic Drive"	1950	
BT 303758	Clip-Speedometer Cable	500	
BZ 303761	Jack Ratchet Assy	1950	
BZ 303762	Jack Base	1950	
BT 303763	Spring-Handy Shift Control Push Rod	1950 All with HDM,1950 RHD All	
C 303764	Control Wire & Casing Assy-Overdrive	500 with SMD	
F 303766	Pressure Plate-Clutch	501 thru 504,500 with OD,HDM or SMD	
*C 303767	Strg Wheel & Horn Ring Assy-Blue	1950	
*C 303768	Strg Wheel & Horn Ring Assy-Red	1950	
BZ 303769	Horn Ring	1950	
	303771	Lever-Handy Shift-LHD	1950
EM 303772	Support Assy-Weather Control to Water Pump Hose	1950 6 Cyl	
BO 303776	Seal-Weather Control Core Upper Tube	500	
BO 303777	Seal-Weather Control Core Lower Tube	500	
F 303778	Cable Assy-Battery (neg) to Starter Solenoid & Hyd Power Unit	500 CvBro with HDM	
BO 303779	Bracket-Horn Right	500	
BT 303781	Lever Complete-HDM Shift Shaft	1950	
BT 303784	Bushing-HDM Shift Shaft Lever Hub	1950	
BT 303785	Shift Shaft-HDM	1950	
BT 303786	Washer-HDM Shift Shaft Thrust	1950	
BT 303787	Lever Complete-HDM Shift Shaft-Hand Shift	500	
BT 303789	Lever Complete-HDM Shift Shaft-Hand Shift	501 thru 504	
BT 303792	Spring-HDM Diaphragm Return	1950	
	303797	Bracket & Shim Assy-Hand Brake Mounting	501 thru 504
BM 303799	Lock Plate-Crankshaft Bearing Cap Screw	1950 6 Cyl	
F 303801	Piston Assy-Code B		
F 303802	Piston Assy-Code D		
F 303803	Piston Assy-Code F		
F 303804	Piston Assy-Code J		
F 303805	Piston Assy-Code L		
F 303806	Piston Assy-Code P		
F 303807	Piston Assy-Code BO		
F 303808	Piston Assy-Code DO		
F 303809	Piston Assy-Code FO		

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
F 303810	Piston Assy-Code LO	
F 303811	Piston Assy-Code BB	
F 303812	Piston Assy-Code DD	
F 303813	Piston Assy-Code FF	
BZ 303815	Rod Assy-Accelerator Cross Shaft Operating	501-502 with HDM or SMD
BZ 303818	Cross Shaft & Lever Complete-Accelerator	501-502 with HDM or SMD
BZ 303819	Cross Shaft & Lever Complete-Accelerator	503-504 with HDM or SMD
BZ 303823	Lever-Accelerator Cross Shaft-LHD	501 thru 504
BZ 303824	Spring-Compression-Accelerator Cross Shaft Lever	501 thru 504 with HDM or SMD
BZ 303825	Spring-Torsion-Accelerator Cross Shaft	501 thru 504 with HDM or SMD
BZ 303827	Rod Assy-Accelerator Cross Shaft Operating	503-504 with HDM or SMD
C 303830	Front Coil Spring-Light	1950
BO 303831	Insulator-Starter Switch Terminal	1950
BT 303832	Shift Rail-Second and High	1950
303838	Harness-Instrument-RHD	501 thru 504
BX 303841	Dirt Shield-Rear Axle Drive Pinion Oil Seal	1950
EX 303842	Companion Flange-Rear Axle	1950
303843	Oil Seal-Drive Pinion	1950
EM 303844	Cover-Spark Plug	1950
BT 303847	Spring-2nd & High Shift Rail Lock Ball	1950 less OD-HDM or SMD
BO 303849	Wire Assy-Weather Control to Switch Extension-RHD	501 thru 504
BO 303850	Jumper Wire Assy-Weather Control	
BT 303851	Anchor Bracket-OD Contact Wire & Casing-RHD	500
F 303853	Throwout Bearing-Clutch	1950
BT 303854	Grease Retainer-Clutch Throwout Bearing	1950
BT 303855	Collar Assy-Clutch	1950
BO 303856	Wire Assy-Clock & Speedometer Lamp	500,501,503
BO 303857	Wire Assy-Instrument Lamp	
*HA 303862	Steering Wheel Kit-Custom-Red	500,501,503
*HA 303863	Steering Wheel Kit-Custom-Blue	500,501,503
303864	Throttle Switch-Overdrive	1950 with OD or SMD
F 303870	Repair Kit-Water Pump	1948 thru 1950 6 Cyl
F 303871	Repair Kit-Water Pump	1948 thru 1950 8 Cyl
BZ 303880	Support-VD Mounting Brkt	500 with HDM or SMD
BZ 303888	Housing-Vac Drive Throttle Lock Diaphragm-Lower	500 with HDM or SMD
C 303889	Overdrive Assy	1950 with OD or SMD
CF 303891	Hub Cap-Wheel-Large	1950
303895	Nipple-Weather-Control Hose	1950
F 303907	Hose Assy-Brake-Body to Rear Axle Toe	1948 thru 1950
BZ 303924	Retainer-Prop Shaft Center Brg Hsg Supt Cushion	1950
*HA 303929	Direction Indicator Kit-LHD	501 thru 504
*C 303932	Transmission Assy-Without HDM, SMD or OD	1950
*C 303933	Transmission Assy-With HDM	1950
*C 303934	Transmission Assy-With OD or SMD	1950
*C 303935	Transmission & Overdrive Assy-With OD or SMD	1950
BO 303936	Jumper Wire Assy-Horn	500 with Twin Horns
BT 303937	Speedometer Gear-11 teeth-3 9/11 Axle	1950
BT 303938	Speedometer Pinion-15 teeth 3 9/11 Axle	1950
BT 303939	Governor Pinion-3 9/11 Axle	1950 with HDM
BO 303944	Switch & Bracket Assy-Starter	1948 thru 1950
C 303945	Wire & Casing Assy-Overdrive Control-LHD	501 thru 504 with OD or SMD
BO 303950	Clip-DI Flasher Fuse Connector Clip	1950
SP 303955	Case-Battery	1950
SP 303956	Spark Plug-Champion Type-118	1950
C 303959	Muffler Assy	500
C 303969	Core Assy-Radiator	501 thru 504
BZ 303980	Insert-Rear Spring Leaf Cup	For Spring 302440
BZ 303985	Bracket Assy-Hill-Hold Valve Mounting-LHD	501 thru 504
BT 303992	Block Assy-Harness Multiple Terminal	1950 with OD-HDM or SMD
BT 303993	Block-Harness Multiple Terminal-Front Half	1950 with OD-HDM or SMD
BT 303994	Block-Harness Multiple Terminal-Back Half	1950 with OD-HDM or SMD
BT 303995	Terminal-Harness Multiple Terminal Block	1950 with OD-HDM Or SMD
BM 304002	Cover Assy-Starting Motor Drive	All Models
EM 304007	Kit-Starting Motor Drive Cover	All Models
F 304010	Kit-Ignition Wires	1950 6 Cyl
F 304011	Kit-Ignition Wires-LHD	1950 8 Cyl
SP 304012	Piston Ring Set-Std Size	1948 thru 1950 6 Cyl
304021	Piston Ring Set-.010 o/s	1948 thru 1950 6 Cyl
SP 304022	Piston Ring Set-.020 o/s	1948 thru 1950 6 Cyl
BT 304027	Cover Assy-Governor Switch	500 with HDM,501 thru 504 with HDM or SMD
BT 304028	Cover Assy-Governor Switch	500 with HDM or SMD
BT 304029	Cover Assy-Governor Switch	1950 with OD
BT 304032	Kit-HDM Governor Switch Cover Replacement	1946 thru 1949
BO 304054	Clip-Ignition Lock Case Bracket Retaining	1950

NUMERICAL PARTS INTERCHANGEABILITY RECORDS

Part No.	Name	Models
BM 304057	Drive Gear-Oil Pump Shaft	1950 6 Cyl
BM 304058	Tube Assy-Distributor Vacuum Control	1948 thru 1950
BM 304059	Oil Pump Assy	1950 6 Cyl
C 30406	Housing-Overdrive	1950 with OD or SMD
BT 304062	Main Shaft & Ring Gear Assy-Overdrive	1950 with OD or SMD
C 304078	Camshaft	1950 6 Cyl
BO 304111	Hose-Drain-Weather Control	1950
C 304128	Steering Wheel & Horn Ring Assy	500,501,503
C 304129	Steering Wheel-Light Tan	500,501,503
*HA 304131	Steering Wheel Kit-Light Tan	500,501,503
BM 304199	Dist. to Spark Plug Wire Terminal Cover Package	All

ADDITIONS

